CSN-A1X Micro panel printer User Manual



Protocol: Lin Xiaopeng 2017.04.06

Audit : <u>Hu Riyu 2017.04.08</u>

Standardize: Liu Zhonghua 2017.04.09

Authorize: Wang Huanyong 2017.04.11

Company: Xiamen Cashino Technology Co., Ltd.

Tel: 0592-5517253 Fax: 0592-5231815 Address: 4/F,No.318,Tongji South Road, Jimei

District, Xiamen, China. 361021

The manual is subject to change without further notice. Please contact Xiamen Cashino Technology Co., Ltd. directly for the latest version.

revision record

Item	Date	Description	Edited page	Desing	Review
1	20170406	The first draft		Lin Xiaopeng	Hu Riyu
2	20180409	Printer parameters	6.7.8	Zhu Chunyan	Hu Riyu
3	20180523	Modify installation port size	6	Zhu Chunyan	Hu Riyu
4	20170515	Add command 1B 4D n for setting font type	15	Zhu Chunyan	Hu Riyu

www.cashinotech.com

Content


1. Product overview	6
2. Features	6
3. Dimension	6
4. Specifications	7
5. Pin definition description	8
7. Command Introduction	10
7.1 Command List	10
7.2 Commands details	12
①Printing and paper feed commands	12
Printing and paper feed	12
Enter	13
Print and paper feed dots	13
Print and paper feed n line	13
②Printing set commands	14
Set print position	14
Character right space setting	14
Set line space as n dots	14
Set horizontal and vertical movement units	15
Set line space to default	15
Set character print font	16
Set character printing method	16
Set character size	17
Set、remove white printing	17
Set、remove underline	18
Set remove bold print	19
Set、remove overlapping	19
Set、cancel characters upside down	19
Set remove 90° revolving printing	20
Allow、orbid key switch	20
Set the left margin	
Set relative printing position	21
Set printing alignment	22
Select、cancel user customized characters	22
Define user customized characters	22
Cancel user customized characters	25
Set / remove quadruple angle of Chinese print	25
Set the Angle of Chinese character word space	26
Set up the Chinese characters to print mode combination	26
Set Chinese mode	27
Exit Chinese character mode	27

Set and cancel under line of Chinese character mode	27
Set and cancel under line of Chinese character mode	27
Selecting international character set	28
Select character code	29
③Graphic printing command	30
Fill Graphics vertical module data	30
Print Graphics horizontal module data	32
Define downloaded bitmap	33
Print downloaded bitmap	34
Define NV bitmap	35
Print NV bitmap	38
Print bitmap	39
Print MSB bitmap	40
4) Tab Commands	41
Horizontal tab	41
Horizontal tab position setting	42
⑤bar code command	43
bar code readable character(HRI) print position setting	43
bar code readable character(HRI)font type selection	43
bar code height setting	43
bar code width setting	44
bar code printing	44
⑥ Printing QR code	49
Mode type of QR code	49
Setting error correction level of QR code	50
Store QR code data to data buffer	51
Printing QR code	51
Setting QR code graph information	52
7 Status querying Commands	55
Transmission status	55
Transit theprinter status to host	56
Transit printer ID	57
Select peripherals	58
Real-time transmission status	59
Real-time pulse	63
	64
Forms feed	64
Data print in page print mode	64
Page print mode select	64
Line print mode select	65
Character development angle select in page print mode	65
Page print mode print area setting	66
Vertical absolute position setting in page print mode	67
Vertical relative position setting in page print mode	68

CSN-A1 user manual

9Other commands	68
Printer reset	68
Print self-test page	69

1. Product overview



Name Micro panel printer

Model: CSN-A1X

Mounting port size: 73.1 (wide) *73.55 (high) mm

Embedding depth: 34.65mm

Application: medical printing equipment, measuring equipment,

Safety equipment, on-board printing equipment, ID automation equipment, catering and retail,

EFTs POS machines, tax control printers, gas stations


2. Features


Smart appearance
Button control panel can be selected
Easy paper loading
Low noise thermal printing
Different interfaces optional


Easily embedded in various instruments and meters

Supports ESC/POS printing command


3. Dimension







建议面板开口尺寸: 73±0.1X73.45±0.1



Suggested installation port size : $73\pm0.1\text{X}73.45\pm0.1\text{MM}$

4. Specifications

	Printing Method	Thermal line printing
	Printing speed	Max 90mm/s
Printing	Resolution	203dpi(8 dots/mm)

	Printing Width	48	mm	
	Feeding accuracy	0.06	25mm	
Character set		ASCII,GBK, BIG5 etc.		
		ANK : (9*17, 1	2*24) Traditional	
character	Font	Chesese: (24*24)		
	Paper type	Thermal	paper	
Paper roll	Paper width	57.5±	0.5mm	
specificati	Paper roll diameter	Max40r	nm	
ons	Paper thickness	60-8	5 µ m	
Heating head temperature detection		Via thermistor		
Pape	r end detection	Photoelectric detection		
	Baud rate	9600bps-115200bps		
Interface		串口(RS232	2, TTL) /USB	
Printer	r head reliability	100Km, or 1 m	illion pulsed	
Po	ower supply	DC5-9V, ≥2A	DC12V, ≥2A	
Phy	Dimension(WXLXH)	76. 8*77.	4*47.7mm	
sical	Embedded port size	73. 1*7	3.55mm	
Properties	color	black/beige/white		
	Embedding depth	34.65mm		
Operating Temp 0° C~50° C		50° C		
	Operating Humidity	20%~8	5% RH	
	Storage Temp	−20° C	~60° C	
Environment	Storage Humidity	5% ~90% RH		

5. Pin definition description



Power XH03/2.54mm

No.	Pin	Definiton
1	VH	power
2		null
3	GND	ground

RS232 PH04/2.0mm

No,	Pin	Deifinition
1	DTR	Flow control
2	TXD	Data send
3	RXD	Data receive
4	GND	Ground

TTL PH04/2.0mm

No.	Pin	Definiton
1	DTR	Flow control
2	TXD	Data send
3	RXD	Data receive
4	GND	Ground

6. Basic usage

6.1 Self-test page printing

Press the K1 button on the control board to print a self - test page.

6.2 LED indicator

After power on, the red status indicator light on the control board will be on and off twice, with an interval of 1 second, indicating that the start is normal. Afterwards, the indicator light is shown as below,

Flash 1: working normally

Flash 2: the mechanism is not connected or the temperature is too low

Flash 3: paper end

Flash 5: Mechanism is overheating

6.3 Paper roll installation

- 1. Open the printer upper cover;
- 2. Put the back of the roll up;
- 3. close the upper cover of the printer and leave the paper slightly exposed.

Note: before installing the paper roll, please tear the adhesive paper affixed on the paper roll clean, No foreign matter shall remain, to protect the printer head.

7. Command Introduction

7.1 Command List

ESC Command		
ESC!	Set character printing method	
ESC - n	Set and delete underline	
ESC E n	Set and delete bold printing	
ESC G n	Set and delete overlapping printing	
ESC { n	Set and delete inversion printing	
ESC V n	Set and delete 90°rotate printing	
ESC 1	Set line space n dots(same as ESC3)	
ESC 2	Set default line space	
ESC 3	Set line space n dots	
ESC *	Bitmap vertical modulus data fillings	
ESC d	Print and paper feed n lines	
ESC % n	Choose and delete customized characters	
ESC &	Define customized characters	
ESC?n	Delete customized character	
ESC R n	International character sets	
ESC t n	Select the character code page	
ESC D	Set horizontal tabulation position	
ESC J	Print and paper feed n dots	
ESC p	Produce cashdrawer pulse	
ESC c 5 n	Allow or prohibit to switch printer by button	
ESC C	Undefined	
ESC T n	Set printing direction in page print mode	
ESC u	Peripheral device status transmission	
ESC v	Printer status transmission	
ESC i	Full cuts	
ESC @	Printer reset	
ESC =	Select peripherals device	
ESC a	Setting position alignment mode	
ESC \$ nL nH	Set absolute print position	
ESC \ nL nH	Set relative print position	
ESC W	Page print mode print area setting	
ESC L	Page print mode select	
ESC S	Line print mode select	
ESC FF	Data print in page print mode	
ESC SP n	Character right space setting	
ESC Z	QR code print	
ESC M n	Set character print font	

ESC m	Partly cuts
ESC q	Undefined
ESC Q	Undefined

GS Command		
GS!n	Set character size	
GS *	Define download bitmap	
GS/m	Print download bitmap	
GS:	Start or end macro definition	
GS ^ r t m	Run macros	
GS V m	Choose cut mode and cut	
GSPxy	Set horizontal and vertical movement units	
GSIn	Printer ID transmission	
GS B n	Set and delete white printing	
GS b	Undefined	
GS H	Set 1-D barcode readable character(HRI)	
	print position	
GSfn	Set HRI character	
GS h	Set 1-D barcoe hight	
GS w	Set 1-D barcode width	
GS k	1-D barcode	
GS L nL nH	Set left margin amount	
GS a n	Allow or prohibit to upload the status automatically	
GSrn	Transmission status	
GS v	Transfer printer status to host	
GS v 0	Bitmap horizontal modulus data print	
GS (2-D barcode print	
GS \$nL nH	Vertical absolute position setting in page print mode	
GS \ nL nH	Vertical relative position setting in page print mode	

FS Command	
FS! n	Kanji printing mode stored setting
FS &	Set Chinese character mode
FS.	Delete Chinese character mode
FS q	Define NV bitmap
FSpnm	Print NV bitmap
FS W n	Kanji quadruple size printing specification/
	cancellation
FS – n	Set and delete kanji character underline
FS S n1 n2	Kanji character space Setting
FS 2	Undefined
FSA	Undefined

US Command	
US Q	Print double QR CODE
US A	Set paper type

DLE Command	
DLE EOT n	Real-time transmission status
DLE ENQ n	Real-time request
DLE DC4 fn m t	Real- time pulse

DC2 c ommand	
DC2 T	Printing self-test page
DC2 *	Print bitmap
DC2 V	Print MSB bitmap
DC2 v	Print LSB bitmap

LF	Line feed
CR	Enter
FF	Forms feed
HT	Horizontal tab
SO	Paper feed to initial position at the next label

7.2 Commands details

①Printing and paper feed commands

Printing and paper feed

Name	print and paper feed
Code	ASCII: LF
	DEC: 10
	HEX: 0A
	Print the buffer contest,and set the paper feed as per line space,then
Function	adjust
	print position to initial position at the next line.
Range	None
Default	None
Notes	None

Example

Enter

Name	Enter
Code	ASCII: CR
	DEC: 13
	HEX: 0D
Function	Adjust print position to initial position of the same line.
Range	None
Default	None
Notes	After executing, R command, the new printing data will cover old data
	in the printing buffer.
Example	None

Print and paper feed dots

Name	Print and paper feed n dots
Code	ASCII: ESC J n
	DEC: 27 74 n
	HEX : 1B 4A n
Function	Print the buffer content and paper feed
Range	0 ≤ n ≤ 255
Default	None
Notes	Paper feed n dots when printing buffer is empty.
	After executing this command, printing position is moved to initial
Example	1b 40 30 31 32 1b 4a 10

Print and paper feed n line

Name	Print and paper feed n lines
	ASCII: ESC d n
Code	DEC: 27 100 n
	HEX : 1B 64 n
Function	Print the contents in printing buffer and paper feed n lines.
Range	0 ≤ n ≤ 255
Default	None
Notes	Print this command set as initial position of the same line
Example	1b 40 30 31 32 1b 64 01

②Printing set commands

Set print position

Name	Set print position
Code	ASCII : ESC \$ nL nH
	DEC: 27 36 nL nH
	HEX: 1B 24 nL nH
Function	Set left side blank area as (nL + nH × 256) dots
Dense	0 ≤ nL ≤ 255
Range	0 ≤ nH ≤ 255
Default	None
Notes	Set left side blank area as [(nL+nH*256)]*0.125mm]
	This command is only effective with the initial position of the line.
	This command is unavailable if it sets beyond the printing area.
Example	None

Character right space setting

Name	Character right space setting
	ASCII: ESC SP n
Code	DEC: 27 32 n
	HEX : 1B 20 n
Function	Character right space setting as (n*0.125mm)
Range	0 ≤ n ≤ 255
Default	n = 0
Notes	When characters double width, Character right space is twice of normal. When characters amplified, Character right space is n times of normal. This command doesn't affect the setting of Chinese characters. This command sets the standard values independently in each mode.
Example	None

Set line space as n dots

Name	Set line space as n dots		
	ASCII: ESC 3 n		
Code	DEC: 27 51 n		
	HEX : 1B 33 n		
Function	Set line space as n dots		
Range	0 ≤ n ≤ 255		

Default	n = 33
	Line space as below:
Notes	TAAAAAAAAAA Tine space character height BBBBBBBBBBBBBBBBBBBBBBBBBBBBBBBBBBBB
	If the line space setted is less than the highest character in that line, then this line space is equal to the height of the highest character. If ESC2,ESC@,reset the printer, the printer blackout, and the line
	space turns to default.
	1b 40
	1b 33 30
	30 31 32 0d 0a
Example	30 31 32 0d 0a
	1b 32
	30 31 32 0d 0a
	30 31 32 0d 0a

Set horizontal and vertical movement units

Name	Set horizontal and vertical movement units			
	ASCII: GSPxy			
Code	DEC: 29 80 x y			
	HEX : 1D 50 x y			
	Horizontal movement unit =25.4/x mm(1/x inch)			
Function	Vertica movement unit =I25.4/y mm(1/y inch)			
	When set X=0,Y=0, X and Y will display default value.			
Range	$0 \le x \le 255, 0 \le y \le 255$			
Default	x=180,y=360			
Notes	None			
Example	None			

Set line space to default

Name	Set line space to default				
	ASCII: ESC 2				
Code	DEC: 27 50				
	HEX: 1B 32				
Function	Set line space to default 30 dots				
Range	None				
Default	None				
	Line space in details pls check ESC 3 command.				
Notes	If the line space setted is less than the height character in the line,the				
	line space of this line is equal to the height of the highest character				

	It can use ESC 3 to define line space.	
Example	None	

Set character print font

Name	set character print font				
	ASCII : ESC M n				
Code	DEC : 27 77 n				
	HEX : 1B 4D n				
	set character print font				
Function	parameter n bit definition as below				
Tunction	n = 0,font 12*24				
	n = 1, font 9*17				
Range	None				
Default	n = 0				
Notes	The command is effective with character.				
	The command is disabled when ESC@, printer reset or blackout.				
Evample	1B 40 1B 4D 00 30 31 32 0D 0A				
Example	1B 40 1B 4D 01 30 31 32 0D 0A				

Set character printing method

Name	Set character printing method						
	ASCII: ESC!n						
Code	DEC: 27 33 n						
	HEX: 1B 21 n						
	Set character printing methods (font,highlight,inversion,bold,double						
	hight,double width and underline),parameter n bit definition as below:						
	Bit Function Value						
	0 1						
	0 Font Normal Small character						
Function	1 Undefined						
Function	2 Undefined						
	3 Bold Cancel Setting						
	4 Double hight Cancel Setting						
	5 Double width Cancel Setting						
	6 Undefined						
	7 Underline Cancel Setting						
Range	None						
Default	n = 0						
Notes	The command is effective with Chinese and foreign languages.						
INUIES	The command is disabled when ESC@, printer reset or power off						
Evample	1B 40 1B 21 01 30 31 32 0D 0A						
Example	1B 40 1B 21 02 30 31 32 0D 0A						

	1B 40 1B 21 04 30 31 32 0D 0A
	1B 40 1B 21 08 30 31 32 0D 0A
	1B 40 1B 21 10 30 31 32 0D 0A
	1B 40 1B 21 20 30 31 32 0D 0A
	1B 40 1B 21 40 30 31 32 0D 0A
	1B 40 1B 21 80 30 31 32 0D 0A

Set character size

Name	Set character size							
ASCII: GS!n								
Code	DEC : 29 33 n							
	HEX :	1d 21 r	า					
	Set cha	aracter s	size as 1-8 times wid	th,1	-8 tim	es heigh	t. Definition is as	
	below:							
	Use 0)-3 set	character height 4	- 7	bits s	et char	acter width show as	
	below:							
	Chart 1					Ch	art 2	
	Character width setting				С	haracte	r height setting	
	HEX	DEC	width		HEX	DEC	height	
Function	00	0	1(Normal)		00	0	1(Normal)	
	10	16	2(double width)		01	1	2(double height)	
	20	32	3		02	2	3	
	30	48	4		03	3	4	
	40	64	5		04	4	5	
	50	80	6		05	5	6	
	60	96	7		06	6	7	
	70	112	8		07	7	8	
Range	None							
Default	n = 0							
	This command is effective with Chinese and other foreign languages,							
Notes	except for HRI character.							
	The command setting is disable when ESC@, printer reset or power off.							
	1b 40 1d 21 11							
Example	30 31 32 0d 0a							
	30 31 32 0d 0a							

Set, remove white printing

Name	Set、 remove white printing
Code	ASCII : GS B n
	DEC : 29 66 n

	HEX : 1d 42 n						
	Set and remove white printing						
Function	When the LSB of n is 0, white printing mode is off.						
	When the LSB of n is 1,white printing mode is on.						
Range	None						
Default	n = 0						
	It is only effective for LSB of n.						
	This command is all effective with built-in characters and user-defined						
	characters.						
	It is effective with blank, which is setted by ESC CP, when white printing						
	mode is on.						
Notes	This command is not effective with bitmap, user-defined bitmap,						
Notes	barcode, HRI character and vaulting space of HT,ESC \$.						
	This command is not effective with line space.						
	The white printing mode is prior to underline mode. When it is white						
	printing mode, even underline mode is open, which can also be						
	forbidden.(But it not be canceled).						
	This command is disabled when ESC@, printer reset or power off.						
	1b 40 1d 42 01						
Example	30 31 32 0d 0a						
	30 31 32 0d 0a						

Set, remove underline

Name	Set remove underline					
	ASCII : ESC - n					
Code	DEC : 27 45 n					
	HEX : 1B 2D n					
	Set / remove underline mode,based on the value of n as follow:					
	n Functions					
Function	0, 48 Remove underline mode					
	1, 49 Set underline mode(1 dot coarse)					
	2, 50 Set underline mode(2 dot coarse)					
Range	0 ≤ n ≤ 2, 48 ≤ n ≤ 50					
Default	n = 0					
Notes	Printer can print underline for all characters(including the space to the right of the character), except for the space set by HT. Printer can not print underline for clockwise rotated 90 ° characters and white printing characters. When n is setted as 0 or 48,remove underline mode.Other data is not printed as underline,and the setted underline coarseness does not change before removing underline mode.The default underline coarseness is 1 dot.					

	It is not effective with underline coarseness to change character size.
	Using ESC! can also set and remove underline mode. However be aware
	that the last received command must be effective.
	1b 40 1b 2d 01
Example	30 31 32 0d 0a
	1b 40 1b 2d 02
	30 31 32 0d 0a
	1b 40 1b 2d 00
	30 31 32 0d 0a

Set, remove bold print

Name	Set 、 remove bold print
Code	ASCII : ESC E n
	DEC : 27 69 n
	HEX : 1B 45 n
	Set and remove bold print
Function	set and remove bold print
	When LSB of n is 0, remove bold print mode
	When MSB of n is 1, set bold print mode
Range	0 ≤ n ≤ 255
Default	n = 0
Notes	Only allow to use when LSB of n
Example	None

Set, remove overlapping

Name	Set 、 remove overlapping
Code	ASCII : ESC G n
	DEC : 27 71n
	HEX : 1B 47 n
	Set and remove overlapping print mode
Function	When LSB of n is 0,remove overlapping print mode
	When MSB of n is 1,set overlapping print mode
Range	0 ≤ n ≤ 255
Default	n = 0
Notes	Only allow to use when LSB of n
	The printer output is the same in overlapping mode and bold mode
Example	None

Set, cancel characters upside down

Name	Set、cancel characters upside down
Code	ASCII : ESC { n

	DEC : 27 123 n
	HEX : 1B 7B n
Function	n=1: set character upside down
	n=0: cancel character upside down
Default	n=0
Notes	None
Example	None

Set, remove 90° revolving printing

Name	Set 、 remove 90° revolving printing
	ASCII : ESC V n
Code	DEC : 27 86 n
	HEX : 1B 56 n
	Set or remove 90° revolving printing
Function	When n is equal to 0 or 48,remove 90°revolving printing.
	When n is equal to 1 or 49,set 90° revolving printing.
Range	$0 \le n \le 1$, $48 \le n \le 49$
Default	n = 0
Support	All
Model	
	When it is setted to underline mode, the printer is not underlined for
	characters rotated 90°.
	In the 90° rotation mode, the multiplier and double width commands
Notes	magnify the character in the opposite direction to the multiplier command
	in the normal mode.
	When ESC @, printer reset, power off, the setting of this instruction is
	invalid.
	1b 40 1b 56 01
Example	30 31 32 0d 0a
	30 31 32 0d 0a

Allow, orbid key switch

Name	Allow and forbid key switch
Code	ASCII : ESC c 5 n
	DEC : 27 99 53 n
	HEX : 1B 63 35 n
Function	n=1, Forbid key switch
	n=0, Allow key switch
Default	n = 0
Notes	None
Example	None

CSN-A1 user manual

Set the left margin

Name	Cat the left margin
ivame	Set the left margin
	ASCII : GS L nL nH
Code	DEC : 29 76 nL nH
	HEX : 1D 4C nL nH
Function	Set the left margin as (nL + nH × 256) dots
Range	0 ≤ nL ≤ 255, 0 ≤ nH ≤ 255
Default	None
Support	All
Model	
Notes	This command is only effective with the initial position of the line. The illustration is as follows: Printing area left margin width of printing area
	Use the maximum value of the printable unit, if the setting is beyond the printable area.
	1b 40 1d 4c 08 00
Example	30 31 32 0d 0a
	30 31 32 0d 0a

Set relative printing position

Name	Set relative printing position
Code	ASCII : ESC \ nL nH
	DEC : 27 92 nL nH
	HEX : 1B 5c nL nH
	Based on the current position, using horizontal or vertical motion unit, set
Function	the printing start position
Function	This command sets the printing position from the current position to the
	distance of [(nL+nH*256)]*0.125 mm]
Pango	0 ≤ nL ≤ 255
Range	0≤ nH ≤ 255
Default	None
Notes	Any out of the printable area of the Settings are ignored
	When distance N point to right:
	nL+nH*256=N
	When distance N point to left: (reverse direction)
	nL+nH*256=65536-N

	In standard mode, use level of motor unit
Example	None

Set printing alignment

Name	Set print alignment (Left, middle, right)
	ASCII : ESC a n
Code	DEC : 27 97 n
	HEX : 1B 61 n
	Align all data in one line,the meaning of n value as below:
	n mode
Function	0, 48 left
	1, 49 middle
	2, 50 right
Range	0 ≤ n ≤ 2 or 48 ≤ n ≤ 50
Default	n = 0
Notes	This command setting is disabled when ESC@,printer resets or power off.
	1B 40 1B 61 02
Example	30 31 32 0D 0A
	1B 40 1B 61 01
	30 31 32 0D 0A
	1B 40 1B 61 00
	30 31 32 0D 0A


Select, cancel user customized characters

Name	Select 、cancel user customized characters
Code	ASCII : ESC % n
	DEC : 27 37 n
	HEX : 1B 25 n
	Select 、cancel user customized characters
Function	When n LSB is 0, delete customized characters
	When n LSB is 1, select customized characters
Range	0 ≤ n ≤ 255
Default	0
Notes	When cancel customized characters, automatically select the internal
	character set.
Example	None

Define user customized characters

Name	Define user customized characters		
Code	ASCII : ESC & y c1 c2 [x1 d1 d (yx1)] [xk d1 d(y x k)]		
	DEC : 27 38 y c1 c2 [x1 d1 d(yx1)][xk d1 d(yxk)]		

	HEV 4D 00 : -4 -0 f4 -44 -46 -43 -5 1 -34 -36 -13
	HEX : 1B 26 y c1 c2 [x1 d1d(y x1)][xk d1d(yxk)]
	Define user customized characters.
	y specifies vertical direction bytes.
Function	c1 specifies the starting character encoding,c2 specifies the ending
	character encoding
	xk specifies horizontal direction dots.
	The range of x \ y, are correspond with internal fonts.
	If choosing Font 6*12, $y = 2$, $0 \le x \le 6$
Range	If choosing Font $12*24$, $y=3$, $0 \le x \le 12$
rango	$32 \le c1 \le c2 \le 126$
	0 ≤ d1 d(y*xk) ≤255
Default	None
Boldan	Definable character code range:from<20>H to <7E>H ASCII code(95
	characters).
	It can define continuous characters encoding for several characters. When
	it need one character only,make c1=c2.
	d is character's dot data, dot mode starts from left side in the horizontal
	direction.It is blank for the rest dots in the right side.
	Defined user defines characters data is (y*x) byte.
	Set corresponding bit of printing dots as 1, or corresponding bit of no
	printing dots as 0.
	This command defines different customized characters for each type of
	font. Set font with ESC !.
Notes	Customized characters and downlink bitmaps cannot be defined at the
	same time. When the command is executed, the downlink bitmap is
	cleared.
	User Customized characters will be cleared in these situations:
	Execute ESC @。
	Execute GS *。
	Execute ESC ?。
	Printer reset or power off
	Graphic:
	When set font A(12 24).



	1b 3f 20
	30 20 30 20 0d 0a

Cancel user customized characters

Name	Cancel user customized characters			
	ASCII : ESC?n			
Code	DEC : 27 63 n			
	HEX : 1B 3F n			
Function	Cancel user customized characters of specified code by n			
Range	32 ≤ n ≤ 126			
Default	None			
Notes	This command terminates the use of styles defined for character encoding, which is specified by n. After the user customized character is canceled, it is printed in the corresponding mode of the internal character. In the font selected with ESC!, the command removes the style defined for the specified encoding. If a user customized character is not defined, the printer ignores the command.			
Example	None			

Set / remove quadruple angle of Chinese print

Name	Set / remove quadruple angle of Chinese print			
	ASCII : FS W n			
Code	DEC : 28 87 n			
	HEX : 1C 57 n			
	Set or remove quadruple angle of Chinese print			
Function	When LSB of n is 0,Remove quadruple angle of character mode			
	When LSB of n is 1,Set quadruple angle of character mode			
Range	0 ≤ n≤ 255			
Default	n=0			
	Only the lowest bit of n is valid;			
	In quadruple angle mode,printing character size is the same as set double			
	width and double height mode to print character size at the same time			
	When the quadruple angle mode is canceled with this command,the			
Notes	characters are printed according to the size of the pass-through character;			
	When the height of some characters in a line is different, all the characters			
	in the line are aligned on the basis of the baseline;			
	When the character is enlarged in the horizontal direction, the character is			
	enlarged to the right with the left side of the character as the reference.			
Example	None			

CSN-A1 user manual

Set the Angle of Chinese character word space

Name	Set the Angle of Chinese character word space			
	ASCII : FS S n1 n2			
Code	DEC : 28 83 n1 n2			
	HEX : 1C 53 n1 n2			
	Set the left and right Chinese character space to n1 and n2 respectively.			
Function	The left character space is [n1*0.125 mm], and the right character space			
	is [n2*0.125 mm]			
Dongs	0 ≤ n1 ≤ 255			
Range	0 ≤ n2≤ 255			
Default	n1=0,n2=0			
	This command sets the left and right character space of the variable size			
	characters. When set to double width mode, the left and right character			
Notes	space is twice of the normal mode.			
	You can set the space separately in standard mode.			
	In standard mode, use horizontal motion units			
Example	None			

Set up the Chinese characters to print mode combination

Name	Set up the Chinese characters to print mode combination					
	ASCII : FS ! n					
Code	DEC : 28 33 n					
	HEX : 1C 21 n					
	Set up Chinese characters print mode, the setting of n as follows:					
	Bit	OFF/ON	HEX	DEC	ASB status	
	0				None	
	1				None	
	2	OFF	00	0	Double-width mode is forbidden	
		ON	04	4	Allow Double-height mode	
Function	3	OFF	00	0	Double-height mode is forbidden	
		ON	80	8	Allow Double-height mode	
	4				None	
	5				None	
	6				None	
	7	OFF	00	0	Underline mode is forbidden	
		ON	80	128	Allow the underline mode	
Range	0 ≤ n ≤ 255					
Default	n=0					
	Setting both double width mode and double height mode ,(including the					
Notes	right and left character space),it will print out character in four times of the					
	size.					

	The printer can underline all characters (including the right and left		
	character space), but not the spaces set by the HT command, and		
	clockwise 90°rotation characters underlined;		
	When some characters in a line are double height or higher, all characte		
	in the line will be aligned along the baseline;		
	The width of the underline is specified by FS – regardless of the character		
	size;		
Example	None		

Set Chinese mode

Name	Set Chinese mode			
	ASCII : FS &			
Code	DEC : 28 38			
	HEX : 1C 26			
Function	Set Chinese mode			
Range	None			
Default	None			
	When the Chinese character mode is selected, the printer processes all			
Notes	Chinese character codes(ASCII code) , two bytes at a time.			
Notes	The Chinese character code(ASCII code) is processed in the order of the			
	first byte and the second byte.			
Example	1b 40 1C 26 B0 AE C9 CF D7 D4 BC BA 0d 0a			
Lample	1C 2E B0 AE C9 CF D7 D4 BC BA 0d 0a			

Exit Chinese character mode

Name	Exit Chinese character mode		
	ASCII: FS.		
Code	DEC : 28 46		
	HEX : 1C 2E		
Function	Exit Chinese character mode, cancel Chinese character mode		
Range	None		
Default	None		
Notes	None		
Example	None		

Set and cancel under line of Chinese character mode

Name	Set and cancel under line of Chinese character mode			
	ASCII : FS - n			
Code	DEC : 28 45 n			
	HEX: 1C 2D n			

	Set/cancel under line mode,based on n value as below:				
	n Function				
Function	0,48	Cancel underline mode			
	1,49	Set underline mode(1 dot coarse)			
	2,50	Set underline mode(2 dot coarse)			
Range	0 ≤ n ≤2, 48≤ n ≤ 50				
Default	n=0				
	Printer can print underline for all characters(including characters space in				
	left and right),but expect for setted blank by HT and Clockwise 90°				
	rotation character underlined;				
Notes	Setting n to 0, after cancel under line of Chinese character, the underline				
Notes	printing will not be performed, but the previously specified underline width				
	remains unchanged. The default underline width is 1 dot.t				
	The specified slip line width remains the same even if the character size				
	had chang	ged			
Example	None				

Selecting international character set

Name	Selecting international character set				
	ASCII : ESC R n				
Code	DEC : 27 82 n				
	HEX: 1B 52 n				
	Selecting international character set n from the following table:				
	n Character				
	0 U.S.A				
	1 France				
	2 Germany				
	3 U.K				
	4 Denmark I				
	5 Sweden				
Function	6 Italy				
Function	7 Spain I				
	8 Japan				
	9 Norway				
	10 Denmark II				
	11 Spain II				
	12 Latin America				
	13 Korea				
	14 Slovenia				
	15 China				
Range	0 ≤ n ≤ 15				
Default	0				

Notes	None
	1B 40 1B 52 00
	20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F 30 31 32 33 34 35 36
Example	37 38 39 3A 3B 3C 3D 3E 3F 40 41 42 43 44 45 46 47 48 49 4A 4B 4C 4D
	4E 4F 50 51 52 53 54 55 56 57 58 59 60 6A 6B 6C 6D 6E 6F 70 71 72 73
	74 75 76 78 79 7A 7B 7C 7D 7E 0D 0A

Select character code

Name	Select character code					
	ASCII : ESC t n					
Code	DEC : 27 116 n					
	HEX : 1B 74 n					
	Selects n from character code					
	N Code Page					
	0 CP437 [U.S.A., Standard Europe]					
	1 KataKana					
	2 CP850 [Multilingual]					
	3 CP860 [Portuguese]					
	4 CP863 [Canadian-French]					
	5 CP865 [Nordic]					
	6 WCP1251 [Cyrillic]					
	7 CP866 Cyrilliec #2					
	8 MIK [Cyrillic /Bulgarian]					
	9 CP755 [East Europe,Latvian 2]					
	10 Iran					
	11 Reserve					
Function	12 Reserve					
	13 Reserve					
	14 Reserve					
	15 CP862 [Hebrew]					
	16 WCP1252 Latin I					
	17 WCP1253 [Greek]					
	18 CP852 [Latina 2]					
	19 CP858 Multilingual Latin I +Euro)					
	20 Iran II					
	21 Latvian					
	22 CP864 [Arabic]					
	23 ISO-8859-1 [West Europe]					
	24 CP737 [Greek]					
	25 WCP1257 [Baltic]					
	26 Thai					
	27 CP720[Arabic]					

	28 CP855			
	29 CP857[Turkish]			
	30 WCP1250[Central Europe]			
	31 CP775			
	32 WCP1254[Turkish]			
	33 WCP1255[Hebrew]			
	34 WCP1256[Arabic]			
	35 WCP1258[Vietnam]			
	36 ISO-8859-2[Latin 2]			
	37 ISO-8859-3[Latin 3]			
	38 ISO-8859-4[Baltic]			
	39 ISO-8859-5[Cyrillic]			
	40 ISO-8859-6[Arabic]			
	41 ISO-8859-7[Greek]			
	42 ISO-8859-8[Hebrew]			
	43 ISO-8859-9[Turkish]			
	44 ISO-8859-15 [Latin 9]			
	45 Thai2			
	46 CP856			
	47 Cp874			
	252 CP932 SHIFT_JIS			
	253 UNICODE UCS-2			
	254 BIG5			
	255 GBK			
Range	0 ≤ n ≤ 255			
Default	0			
Notes	None			
	1B 40 1C 2E 1B 74 00			
	80 81 82 83 84 85 86 87 88 89 8A 8B 8C 8D 8E 8F 90 91 92 93 94 95 96			
	97 98 9A 9B 9C 9D 9E 9F A0 A1 A2 A3 A4 A5 A6 A7 A8 A9 AA AB AC AD			
Example	AE AF B0 B1 B2 B3 B4 B5 B6 B7 B8 B9 BA BB BC BD BE BF C0 C1 C2			
	C3 C4 C5 C6 C7 C8 C9 CA CB CC CD CE CF D0 D1 D2 D3 D4 D5 D6 D7			
	D8 D9 DA DB DC DD DE DF E0 E1 E2 E3 E4 E5 E6 E7 E8 E9 EA EB			
	ED EE EF F0 F1 F2 F3 F4 F5 F6 F7 F8 F9 FA FB FC FD FE FF 0D 0A			

③Graphic printing command

Fill Graphics vertical module data

Name	Fill Graphics vertical module data		
Code	ASCII : ESC * m HI Hh [d]k		
	DEC : 27 42 m Hl Hh [d]k		

	HEX : 1B 2A m HI Hh [d]k				
	Print vertical module graphic data,the parameters are as below:				
	m is bit map format:				
	m mode horizontal scale vertical scale				
	0 8dots single density ×2 ×3				
	1 8dots double density ×1 ×3				
Function	32 24dots single density ×2 ×1				
	33 24dots double density ×1 ×1				
	HI、Hh is horizontal direction dots(HI+256×Hh)				
	[d]k is bit map data				
	K used for indicating bit map data bytes,not for transfer.				
	XX58:				
	m = 0, 1, 32, 33				
	1 ≤ HI + Hh × 256 ≤ 384				
	0 ≤ d ≤ 255				
	k = HI + Hh × 256 (when m = 0、1)				
Parameter	k = (HI + Hh × 256) × 3 (when m = 32、33)				
range	XX80:				
	m = 0, 1, 32, 33				
	1 ≤ HI + Hh × 256 ≤ 576				
	0 ≤ d ≤ 255				
	k = HI + Hh × 256 (when m = 0、1)				
	$k = (HI + Hh \times 256) \times 3 \text{ (when m} = 32, 33)$				
Default	None				
	[d]k corresponding bit is 1,which means that this bit can print. While it is				
	0,it means that this bit can not print.				
	The part of graphics horizontal direction which exceeds the printing area				
	will be ignored.				
	The relations between Bit map data and printing effects is as below:				
	8 dot 24 dot				
	high d1 d4 d7 - high				
	d1 d2 d3 d2 d5 d8				
Notes					
	low d3 d6 d9 low				
	bitmap data bitmap data				
	The command fills only the printing buffer, graphics printing can start only				
	after receiving the printing commands.Printing buffer will be cleared after				
	graphic printing.				
	If you need to print higher graphics,you can divide it into several				
	If you need to print higher graphics, you can divide it into several				

	0、1) or 24(m = 32、33)dots graphics to print.
	After filling graphic data, you can continue to fill other information to
	make graphic and other information print simultaneously.
	After filling bitmap,you can use ESC J(n=24) command to print, and
	also can use LF command to print.But using LF command will cause
	paper feeding(feeding paper according to the line space),and make
	graphic continuous between different lines. And can set line space as 0 to
	avoid feeding too much.(Dot matrix printer may drift when it starts,pls
	send data continuously if occurs line broken.
	1B 40
=	1b 2a 00 0C 00 FF
Example	1B 33 00
	0A

Print Graphics horizontal module data

Name	Print Graphics horizontal module data				
	ASCII : GS v 0				
Code	DEC : 29 118 48 m xL xH yL yH [d]k				
	HEX : 1D 76 30 m xL xH yL yH [d]k				
	Print horizontal module graphic data,the parameters are as below:				
	m as bitmap method:				
	m Model Horizontal scale Vertacal scale				
	0,48 Normal × 1 × 1				
	1,49 Double-width × 2 × 1				
	2,50 Double-height × 1 × 2				
Function	3,51 Quadruple × 2 × 2				
	xL xH were selected as the data bytes (xL+xH×256) in the horizontal				
	direction for the bitmap.				
	yL, yH were selected as the data bytes (yL+yH×256) in the vertical				
	direction for the bitmap.				
	[d]k for bitmap data				
	k for bitmap data bytes, k used for indicating, not for transfer.				
	XX58:				
	0 ≤ m ≤ 3; 48 ≤ m ≤ 51				
	1 ≤ xL + xH×256 ≤ 48				
Parameter	0 ≤ yL ≤255,0 ≤ yH ≤255				
range	0 ≤ d ≤ 255				
rango	$k = (HI + Hh \times 256) \times (yL + yH \times 256)$				
	XX80:				
	0 ≤ m ≤ 3; 48 ≤ m ≤ 51				
	1≤ xL + xH×256 ≤ 72				

	0 < 1 < 0 = 0 < 11 < 0 = 0							
	0 ≤ yL ≤ 255, 0 ≤ yH ≤ 255							
	0 ≤ d ≤ 255							
	$k = (HI + Hh \times 256) \times (yL + yH \times 256)$							
Default	None							
	[d] k	corresponding	bit is 1,which	n means that t	his bit can pri	nt. While it is		
	0,it me	eans that this	bit can not pri	nt.				
	If the	horizontal byt	es exceed pri	nting area, th	en the excee	ding part will		
	be ign	be ignored.						
	The pa	The paper feeds accordingly to the image size when this commanding is						
	using, not influenced by the setting of ESC 2, ESC 3 line space.							
	After this command, the printing coordinates will be reset to the left							
	margin and the image content will be cleared.							
	the rel	the relationship between bitmap data and the printing effect is as below:						
Notes		·		·	_			
	3	d1	d2		dx			
		d(x+1)	d(x+2)		d(x×2)			
		- 1	1		1			
			d(k-2)	d(k-1)	dk			
	MSB LSBMSB LSBMSB LSB							
	Т	his command	has the prir	ntina function	. data will be	transferred		
	This command has the printing function, data will be transferred while printing, no need to use the printing command again							
	1B 40							
E	1d 76	30 00 03 00 0	9 00					
Example	FF FF	FF FF FF FF	FF FF FF FF	FF FF FF FF	FF FF FF FF I	FF FF FF FF		
	FF FF	FF FF FF						

Define downloaded bitmap

Name	Define downloaded bitmap			
	ASCII : GS * x y d1d(x×y×8)			
Code	DEC : 29 42 x y d1d(x×y×8)			
	HEX : 1D 2A x y d1d(x×y×8)			
	using x and y to appoint dots to define the downloaded bitmap			
Function	x appoints that the horizontal dots as 8*x.			
	y appoints that the vertical dots as 8*y.			
	1 ≤ x ≤ 255			
Parameter	1 ≤ y ≤ 48			
range	x*y ≤ 1536			
	0 ≤ d ≤ 255			
Default	None			
Notes	If x*y is out of the specified range, this command will be forbidden.			
Notes	The d indicates bitmap data. Data (d) specifies the printing bit as 1			

and the not printing bit as 0. The downloaded bitmap definition will be cleared when: ESC @ is executed. ESC & is executed. Printer is reset or the power is turned off. The following figure shows the relationship between the downloaded bitmap and the printed data x × 8 dots d1 dy + 1dy \$2+1 MSB d2 y × 8 dots dy dyx2 dxxyx8 1B 40 1D 2A 03 03 FF FF Example FF FF FF FF 1D 2F 00

Print downloaded bitmap

Name	Print downloaded bitmap			
	ASCII : GS/m			
Code	DEC : 29 47 m			
	HEX: 1D 2F m			
Function	Prints a downloaded bitmap using the mode specified by m.			
	Using the mode that m appointed to print downloaded bitmap			

			I			
		m	Model			
	0, 48 Normal		Normal			
		1, 49	Double-width			
		2, 50	Double-height			
		3, 51	Quadruple			
Parameter	0 :	≤ m ≤ 3				
range	48	3 ≤ m ≤ 51				
Default	No	None				
		this command will be ignored if the bitmap data has not been defined.				
	In standard mode, this command is effective only when there is no					
	data in the buffer area.					
Notes	This command has no effect in the print modes (emphasized,					
Notes	double-strike, downloadedline, character size, or white/black reverse					
	pri	printing), except for upsidedown printing mode.				
		If the downloaded bitmap which will be printed exceeds the printing				
	area, then the excess data will not be printed.					
Example	No					

Define NV bitmap

Name	Define NV bitmap
	ASCII : FS q n [xL xH yL yH d1dk]1[xL xH yL yH d1dk]n
Code	DEC : 28 113 n [xL xH yL yH d1dk]1[xL xH yL yH d1dk]n
	HEX : 1C 71 n [xL xH yL yH d1dk]1[xL xH yL yH d1dk]n
	Define the NV bitmap using the specified n.
	n specifies the number of the defined NV bitmap.
	xL, xH means that the defined NV bitmap specifies the horizontal dots as
Function	(xL+xH*256)*8
	yL, yH means that the defined NV bitmap specifies the vertical dots as
	(yL + yHx256)*8
	1 ≤ n ≤ 255
	0 ≤ xL ≤ 255
	0 ≤ xH ≤ 3
	(1 ≤ (xL+xH*256) ≤ 1023)
Parameter	$0 \le yL \le 255)$
range	0 ≤ yH ≤ 1
	(1 ≤ (yL+yH*256) ≤ 288)
	$0 \le d \le 255$
	k = (xL+xH*256)*(yL+yH*256)*8
	Totaled the defined data Area = 64 k bytes
Default	None
Support	All

Model	
	Frequent writing command executions may damage the NV
	memory.
	Therefore, it is recommended to write the NV memory no more than 10
	times per day.
	The printer performs a hardware reset operation after the
	procedure of placing the image into the NV memory. Therefore,
	user-defined characters, downloaded bitmaps should be defined only
	after completing this command. The printer clears the receiving and
	printing buffers and resets the printer to the mode that workable when
	power on. (hardware reset interface is not supported)
	This command cancels all NV bitmaps that have already been
	defined by this command.
	From the beginning of the processing of this command till the
	accomplishment of hardware reset, mechanical operations (including
	initializing the position of the print head when the cover is open, paper
	feeding using the FEED button, etc.) cannot be performed.
	During this command processing, the printer is busy and stops
	receiving data when writing data to the user's NV memory. Therefore,
	data transmission, including real-time commands, is prohibited during
	the execution of this command.
	NV bitmap is a bitmap defined in non-volatile memory, Define FS
Notes	p printing with FS q.
	In standard mode, this command is valid only when processed at
	the beginning of the line.
	This command is valid when 7 bytes <fs yh=""> of the command</fs>
	are processed normally.
	When the data volume exceeds the left capacity of the range
	defined by xL, xH, yL, and yH, the printer will process the range
	defined by xL, xH, yL, and yH outside the defined range.
	In the first group of NV bitmaps, when any one of xL, xH, yL, yH is
	out of the definition range, this command is disabled.
	In groups of NV bitmaps other than the first group, when xL, xH,
	yL, yH out of the defined range, it stops processing this command and
	starts writing into the NV images. At this time, NV bitmaps that haven't
	been defined are disabled (undefined), but any NV bitmaps before that
	are enabled.
	The d indicates the definition data. In data (d) a 1 bit specifies a
	dot to be printed and a 0 bit specifies a dot not to be printed.
	This command defines n as the number of a NV bitmap. Numbers
	rise in order from NV bitmap 01H. Therefore, the first data group [xL
	xH yL yH d1dk] is NV bitmap 01H, and the last data group [xL xH yL
	yH d1dk] is NV bitmap n. The total agrees with the number of NV
	bitmaps specified by the command FS p.

The definition data for an NV bitmap consists of [xL xH yL yH d1...dk]. Therefore, when only one NV bitmap is defined n=1, the printer processes a data group [xL xH yL yH d1...dk] once. The printer uses ([data: $(xL xH 256) \times (yL yH 256) \times 8$] [header :4]) bytes of NV memory.


The definition area in this printer is a maximum of 192K bytes. This command can define several NV bitmaps, but cannot define bitmap data whose total capacity [bitmap data header] exceeds 192K bytes.

The printer does not transmit ASB status or perform status detection during processing of this command even when ASB is specified.

Once an NV bitmap is defined, it is not erased by performing ESC @, reset, and power off.

This command performs only definition of an NV bitmap and does not perform printing. Printing of the NV bitmap is performed by the FS pcommand.

Diagram: when xL = 64, xH = 0, yL = 96, yH = 0




Print NV bitmap

Name	Print NV bitmap
------	-----------------

	ASCII : FS p n m			
Code	DEC : 28 112 n m			
	HEX : 1C 70 n m			
	Print NV bitmap n using the mode specified by m.			
	m Mode			
	0, 48 Normal			
Function	1, 49 Double-width			
	2, 50 Double-height			
	3, 51 Quadruple			
Parameter	0 ≤ m ≤ 3			
range	48 ≤ m ≤ 51			
range	1 ≤ n ≤ 255			
Default	None			
Support	All			
	n is the number of the NV bitmap (defined using the FS q command).			
	m specifies the bitmap mode.			
	NV bitmap is a bitmap defined in non-volatile memory by			
	FS q and printed by FS p.			
	This command is not effective when the specified NV bitmap has not			
	been defined.			
	In standard mode, this command is effective only when there is no			
	data in the print buffer.			
	This command is not affected by print modes (Bold printing,			
Notes	overlapping,underline, character size, white/black reverse printing, or 90°			
	rotated characters, etc.), except upside-down printing mode.			
	If the downloaded bit-image to be printed exceeds one line, the			
	excess data is not printed.			
	This command feeds dots (for the height n of the NV bitmap) in			
	normal and double-width modes, and (for the height n 2 of the NV			
	bitmap) in double height and quadruple modes, regardless of the line			
	space specified by ESC 2 or ESC 3.			
	After printing the bitmap, this command sets the print position to the			
	beginning of the line and processes the data that follows as normal data.			
Example	None			

Print bitmap

Name	Print bitmap
	ASCII : DC2 * r n [d1dn]
Code	DEC : 18 41 r n [d1dn]
	HEX : 12 2A r n [d1dn]



Print MSB bitmap

Name	Print MSB bitmap				
	ASCII : DC2	V nL nH [d1	.dn]		
Code	DEC : 18 86 r	nL nH [d1dn]		
	HEX : 12 56 nL	nH [d1dn]			
	The width of the b	itmap must be	e the same a	s that of the p	orinter
	Bitmap Height: nL	+nH*256			
	Bitmap format				
			384 dots		to seed to
Function	1th byte	2th byte		47th byte	48th byte
	n+1th byte	n+2th byte		n+47th byte	n+48th byte
	MSB LS	В		<< n = n	L + nH*256 >>
Parameter	0 ≤ m ≤ 3				
	48 ≤ m ≤ 51				
range	1 ≤ n ≤ 255				
Default	None				
Support	All				
Notes	None				

Example	None
•	

Print LSB bitmap

Name	Print LSB bitmap				
	ASCII : DC2	v nL nH [d1	.dn]		
Code	DEC : 18 118	nL nH [d1d	n]		
	HEX: 12 76 nL	nH [d1dn]			
	The width of the b Bitmap Height: nL Bitmap format	•	e the same a	as that of the p	orinter
			384 dots		
Function	1th byte	2th byte	••••	47th byte	48th byte
	n+1th byte	n+2th byte		n+47th byte	n+48th byte
	LSB MS	В		<< n = n	L +nH*256 >>
Parameter	None				
range					
Default	None				
Support	All				
Notes	None				
Example	None				

4 Tab Commands

Horizontal tab

Name	Horizontal tab		
	ASCII : HT		
Code	DEC : 9		
	HEX: 09		
FUNCTION	Move the print position to the next tab position		
Parameter	None		
range			
Defaults	None		
	Tab position set by ESC D		
Notes	If the tab position is not set(the default is no horizontal position),this		
	command will be treated as an LF command		

	If the tab position exceeds the print area,the coordinates will move to the
	star position of the next line(as the data is full,print and wrap)
Example	none

Horizontal tab position setting

Name	horizontal tab position setting			
	ASCII : ESC D [d]k NUL			
Code	DEC : 27 68 [d]k 0			
	HEX : 1B 44 [d]k 00			
Function	Set horizontal tab position, parameter meaning as below:			
Function	d1 dk: horizontal position,in 8 as unit,null as the terminator			
Parameter	XX58: $1 \le d \le 46 \ (d1 < d2 < \dots dk, 1 \le k \le 16)$			
range	XX80: $1 \le d \le 70 \ (d1 < d2 < \dots dk , 1 \le k \le 16)$			
Defaults	The default positioning position is the 8-character interval(Column 9 17 25)			
Delaults	of the font A(12-24)			
Support	All			
model				
	Tab position as below:			
	Print area			
	 			
	Not margin of az			
	TAB position d1 and d2 setting table 1 table 2 table 3			
Notes				
	Maximum august for the patting of 16 tab position			
	Maximum support for the setting of 16 tab position			
	Using this command, the setting of previous tab position will be canceled			
	k is for indication purpose,no transmission When transport [d]k,and come across NULL,should be considered over			
	If dk less than or equal to dk-1, should be considered over, and balance			
	data is treated as normal data processing			
	TAB position could be changed by HT command			
	When the left margin changes, the TAB position changes simultaneously			
	The command setting will be valid after ESC @\ printer reset\ power off			
Example	1B 44 04 06 08 0A 00 09 30 09 31 09 32 09 33 0D 0A			
Litarripic	15 11 31 33 33 37 37 30 37 30 30 30 30 31 33 32 33 33 33 37			

5bar code command

bar code readable character(HRI) print position setting

Name	bar code readable character(HRI)print position setting		
	ASCII : GS H n		
Code	DEC : 29 72 n		
	HEX: 1D 48 n		
	Set bar code readable character(HRI)print position,n parameter meaning		
	as below:		
	n print position		
Function	0,48 don't print		
	1, 49 above the bar code		
	2, 50 below the bar code		
	3, 51 above and below the bar code		
Parameter	0 ≤ n ≤ 3 or 48 ≤ n ≤ 51		
range			
Defaults	n = 0		
Notes	The command setting will be valid after ESC @ printer reset power off		
Example	None		

bar code readable character(HRI)font type selection

Name	bar code readable	bar code readable character(HRI)font type selection		
	ASCII : GS f n			
Code	DEC : 29 102 n			
	HEX : 1D 66 n			
	Select a font for the HRI character to be used when print the bar code			
	The relationship between n and selection contents as below			
Function	n	Font		
	0,48	Font A (12*24)		
	1,49	Font B (9*17)		
Parameter	n =0,1,48,49			
range				
Defaults	n = 0			
Notes	None			
Example	None			

bar code height setting

Name bar code height setting	Name
------------------------------	------

	ASCII : GS h n
Code	DEC : 29 104 n
	DEX: 1D 68 n
	Parameter n specifies the height of a bar code in dots:
Function	Height 50
	Height 100
Parameter	1 ≤ n ≤ 255
range	
Defaults	n = 64
Notes	The command setting will be valid after ESC @、printer reset、power off
Example	None

bar code width setting

Name	bar code width setting
	ASCII : GS w n
Code	DEC : 29 119 n
	HEX : 1D 77 n
	Parameter n specifies the unit of a bar code in dots:
Function	Width 3 Width 4
Parameter	1 ≤ n ≤ 6
range	
Defaults	n = 2
Noted	The command setting will be valid after ESC @、printer reset、power off
Example	None

bar code printing

Name	bar code printing							
	(A) ASCII : GS k m [d]k NUL							
Codo	DEC : 29 107 m [d]k NUL							
Code	Hex: 1D 6B m [d]k NUL							
	(B) ASCII : GS k m n [d]k							

		DEC 1	20.407.	[-d]].								
		DEC : 2 Hex : 1D	29 107 r 68 m n									
	har			ıuık arameters mear	ning as helow.							
		encoding	ig,tile pe		iiig as below:							
	n is code data length,only for (command B),the difference between (A)											
	and (B)is that the data (A) end with NULL, but (B) indicates the data length											
	[d]k is bar code data											
				ar code data for	sign,no transmiss	sion						
		ameters rela			oign,no tranomic	31011						
	l	mmand A)	a	3 do 50.0 W.								
		,		Bar code le	ngth (SP show sp	pace)						
		Coding	Data									
	m	system	lengt	k	Character set	Data (d)						
			h									
	0	UPC-A	fixed	k = 11, 12	0~9	48≤d≤57						
						48≤d≤57						
	1	UPC-E	fixed	6≤k≤8,	0~9	[when k =						
	'	UPC-E	lixed	k = 11, 12	0 3	7,8,11,12,						
						d1 = 48]						
	2	JAN13 (EAN13)	fixed	k = 12, 13	0~9	48≤d≤57						
		JAN8	الان ما	L = 7 0	0.0	40<4<57						
Function	3	(EAN8)	fixed	k = 7, 8	0~9	48≤d≤57						
T directori						48≤d≤57,						
		CODE39	chan geab le		0~9,A~Z	65≤d≤90,						
	4			1≤k	SP, \$, %, *,							
					+, -, ., /	42, 43, 45,						
						46, 47						
		ITF	chan	2≤k≤255								
	5	(Interlea	geab	(even	0~9	48≤d≤57						
		ved 2 of 5)	le	numbers)								
		<u> </u>				48≤d≤57,						
						65≤d≤68,						
						97≤d≤100,						
		CODAB	chan			d = 36, 43, 45,						
	6	AR	geab	1≤k	0~9, A~D, a~d	46, 47, 58						
		(NW-7)	le		\$, +, -, ., /, :	(65≤d1≤68,						
						65≤dk≤68,						
						97≤d1≤100,						
						97≤dk≤100)						
		•			•							
	(Co	mmand B)										
	m	Coding		Bar code le	ngth (SP show s	pace)						

		I	Ι_						
		system	Dat a leng th	n	Character set	Data (d)			
	65	UPC-A	fixe d	n = 11, 12	0~9	48≤d≤57			
	66	UPC-E	fixe d	6≤n≤8, n = 11, 12	0~9	48≤d≤57 [when n = 7,8,11,12, d1 = 48]			
	67	JAN13 (EAN13)	fixe d	n = 12, 13	0~9	48≤d≤57			
	68	JAN8 (EAN8)	fixe d	n = 7, 8	0~9	48≤d≤57			
	69	CODE3	cha nge able	1≤n	0~9, A~Z SP, \$, %, *, +, -, ., /	48≤d≤57, 65≤d≤90, d = 32, 36, 37, 42, 43, 45, 46, 47			
	70	ITF (Interlea ved 2 of 5)	cha nge able	2≤n≤255 (even numbers)	0~9	48≤d≤57			
	71	CODAB AR (NW-7)	cha nge able	1≤n	0~9, A~D, a~d \$, +, -, ., /, :	48≤d≤57, 65≤d≤68, 97≤d≤100, d = 36, 43, 45, 46, 47, 58 (65≤d1≤68, 65≤dk≤68, 97≤d1≤100, 97≤dk≤100)			
	72	CODE9	cha nge able	1≤n≤255	00H~7FH	0≤d≤127			
	73	CODE1 28	cha nge able	1≤n≤255	00H~7FH C1H~C4H(FN C)	0≤d≤127 d = 193, 194,195,196			
	74	UCC/EA N128	cha nge able	1≤n≤255	00H~7FH C1H~C4H(FN C)	0≤d≤127 d = 193, 194,195,196			
Parameter range	` '	(A) $0 \le m \le 6$ (B) $65 \le m \le 74$							
Defaults	None								

If the bar code width exceed the printable area, the printer does not perform barcode printing

Paper feed as needed when the command is carried out, that not affected by ESC2, ESC3 line space settings, and do not influence line space settings. The command is not affected by ESC ! character style setting. The print position is resorted to the print start location after the command is executed.

m parameter $0 \sim 6(A)$ and $65 \sim 71(B)$ select the same coding system,the same printing effect

m parameter is $0 \sim 6(A)$, barcode data end with NULL

m parameter is 65 ~ 74(B),barcode data n stand for data length

K is for sign, no transmission

When print UPCA (m = 0 or 65), Please pay attention for the following points:

Whatever the input data length is 11 or 12,the check bit is automatically inserted or corrected

Initial character,central split character,and terminator are inserted automatically

When print UPCE (m = 1 or 66), Please pay attention as following:

The system character (NSC) 0 will be inserted automatically when data

length is 6

The first system character (NSC) d1 must be 0 when the data length is 7,8,11 and 12.

Whatever the data length is 6,7,8,11 and 12,the check bit inserted or corrected automatically

Whatever the input data length is 6,7,8,11,and 12,the barcode readable character(HRI) just show 6 as data,but excluded system character (NSC) and check code;

The transition relation between transmission and printing data as below:

	Transmitted data										F	Printe	ed da	ıta	
d2	d3	d4	d5	d6	d7	d8	d9	d10	d11	d1	d2	d3	d4	d5	d6
0~9	0~9	0	0	0	-	71-	0~9	0~9	0~9	d2	d3	d9	d10	d11	0
0~9	0~9	1	0	0	-	×-	0~9	0~9	0~9	d2	d3	d9	d10	d11	1
0~9	0~9	2	0	0	-	:=	0~9	0~9	0~9	d2	d3	d9	d10	d11	2
0~9	0~9	3~9	0	0	-	-	-	0~9	0~9	d2	d3	d4	d10	d11	3
0~9	0~9	0~9	1~9	0	-	2. 	-	-	0~9	d2	d3	d4	d5	d11	4
0~9	0~9	0~9	0~9	1~9		:: -	-	-	5~9	d2	d3	d4	d5	d6	d11

When d6 is 1~9,be sure d7,d8,d9,d10 are 0,and d11 is 5~9 Initial character,terminator automatically inserted

Notes

When print EAN13(m = 2 or 67), Please pay attention as following:

Whatever the input data length is 12 or 13,check bit is automatically inserted or corrected

Initial character,central split character and terminator inserted automatically

When print EAN8(m = 3 or 68), please pay attention as following:

Whatever input data length is 7 or 8,the check bit is automatically inserted or corrected

Initial character,central split character and terminator inserted automatically

When print CODE39(m = 4 or 69), please pay attention as following:

When d1 or dn are not Initial character/terminator "*", encoder is automatically inserted "*"

When middle of the data encounter "*", the encoder regard it as terminator, the other data as the normal data;

The check bit could not calculate and add automatically

When print ITF25(m = 5 or 70), please pay attention as following:

Initial character and terminator inserted automatically

The check bit could not calculate and add automatically

When print CODABAR (NW-7) (m = 6 or 71), please pay attention as following:

Initial character and terminator could not inserted automatically,but manual addition by user, that the range from "A"~"D" or "a"~"d"

Check bit could not calculate and add automatically

When print CODE93(m = 72), please pay attention as following:

Initial character and terminator inserted automatically

The two check code are automatically calculated and then inserted

When barcode readable character(HRI) is set to print, there is no HRI character which indicating start/end

When barcode readable character(HRI) is set to print, the control character will be replaced with space

When print CODE128(m = 73), please pay attention as following:

The encoding system intelligently identifies data and implements minimum length encoding without the user set character (include starting character set) or switch character

Function character FNC1~FNC4 use C1H~C4H and input it

The check bit could calculate and add automatically

When barcode readable character(HRI) is set to print, the control character and FNC1~FNC4 will be replaced with space

When print EAN128(m = 74), please pay attention as following:

Basic construction as below:

Initial	ENC4	Λ1	Data	Check	Check	Terminato
charact	FNC1	Ai	part	bit	bit	r

	er set						А		В		
	Ins	t		(d	1dk)		Inserted				
	auton	natic	ally		(u	autor	matically				
	Con	necti	on stru	cture a	s belov	v:					
	char	FN C1	AI	Dat a part	Che ck bit A	FN C1	AI	Dat a part	Che ck bit A	Che ck bit B	Ter min ator
	Inserte				(d1dk)		ı	auton	
	Ily The encoding system intelligently identifies data and implement minimum length encoding without the user set character (include starting character set) or switch character Function character FNC1~FNC4 use C1H~C4H and input it User input data Al, which do not need "("")" for indication, encoding system inserted automatically, otherwise it will be wrong. For example, Grant 18 "019501234567890*", 01 is Al, the following will be wrong: GS k 7 18 "(01)9501234567890*"								ments tarting coding ble,GS S k 74 insert ving:		
Example	1b 40 1d 48 02 1d 6b 41 0c 31 32 33 34 35 36 37 38 39 30 31 32 1d 6b 42 0c 30 32 33 34 35 36 30 30 30 38 39 1d 6b 43 0c 30 32 33 34 35 36 30 30 30 38 39 1d 6b 44 08 30 32 33 34 35 36 30 30 1d 6b 45 08 30 32 33 34 35 36 30 30 1d 6b 46 08 30 32 33 34 35 36 30 30 1d 6b 47 08 41 32 33 34 35 36 30 41 1d 6b 48 08 41 30 32 33 34 35 36 41 1d 6b 49 08 41 30 32 33 34 35 36 41										

(6) Printing QR code

Mode type of QR code

Name	Mode typ	oe of QR co	de					
Code	ASCII	: GS(k	pL	рΗ	cn	fn	n

	Decimal : 29 40 107 pL pH cn fn n
	Hexadecimal : 1D 28 6b pL pH cn fn n
Function	Setting mode type of QR code to [n dot × n dot].
	pL=3, pH=0
Parameter	cn=49
range	fn=67
	0 ≤ n ≤ 16
Default	n=3
Notes	Setting mode type of QR code to [n dot × n dot].
Example	None
Name	Mode type of QR code

Setting error correction level of QR code

Name	Setting error correction level of QR code									
Code	ASCII : GS (k pL pH cn fn n DEC : 29 40 107 pL pH cn fn n HEX : 1D 28 6b pL pH cn fn n									
Function	Setting error correction level of QR code									
Parameter range	pL=3, pH=0 cn=49 fn=69 48 ≤ n ≤ 51									
Default	n=48									
Natas	Setting error correction level of QR code Approximate Amount of correction 4 Error correction level (L) 7% 8									
Notes	4 Error correction level (M) 15% 9									
	5 Error correction level(Q) 25% 0									
	5 Error correction level (H) 30%									
Example	None									
Name	Setting error correction level of QR code									

Store QR code data to data buffer

Name	Store QR code data to data buffer
	ASCII : GS (k pL pH cn fn m d1dk
Code	DEC : 29 40 107 pL pH cn fn m d1dk
	HEX: 1D 28 6b pL pH cn fn m d1dk
Function	Store QR code data to data buffer
	$4 \le (pL + pH \times 256) \le 7092 (0 \le pL \le 255, 0 \le pH \le 28)$
	cn=49
Parameter	fn=80
range	m=48
	0 ≤ d ≤ 255
	$k = (pL + pH \times 256) - 3$
Default	No
	Store QR code data (d1dk) to data buffer.
Notes	((pL + pH×256) - 3) bytes is processed as a graphic data after the m (d1
	dk).
Example	None
Name	Store QR code data to data buffer

Printing QR code

Name	Printing QR code		
	ASCII : GS (k pL pH cn fn m		
Code	DEC : 29 40 107 pL pH cn fn m		
	HEX: 1D 28 6b pL pH cn fn m		
Function	Printing QR code		
	pL=3, pH=0		
Parameter	cn=49		
range	fn=81		
	m=48		
Default	None		
	Printing QR code.		
Notes	Users must consider QR code graph space. (The space of up and down,		
	left and right of QR code graph is specified in the specification.)		
	1b 40		
	1d 28 6b 03 00 31 43 03		
	1d 28 6b 03 00 31 45 30		
Example	1d 28 6b 06 00 31 50 30 41 42 43		
	1b 61 01		
	1d 28 6b 03 00 31 52 30		
	1d 28 6b 03 00 31 51 30		
Name	Printing QR code		

Setting QR code graph information

Name	Setting QR code graph information					
Code	ASCII : GS (k pL pH cn fn m DEC : 29 40 107 pL pH cn fn m HEX : 1D 28 6b pL pH cn fn m					
	Setting QR code graph information					
	The detailed graph information is as follows:					
	Transmit data	Hexadecim al	Decimal	Data type		
	Header	37H	55	1byte		
	Flag	36H	54	1byte		
	Width	30H-39H	48-57	1-5byte		
	Separator	1FH	31	1byte		
	Height	30H-39H	48-57	1-5byte		
	Separator	1FH	31	1byte		
Function	Fixed Value	31H	49	1byte		
	Separator	1FH	31	1byte		
	Other	30H or 31H	48 or 49	1byte		
	Information					
	NUL	00H	0	1byte L		
	and H data transmit graph: use dot for unit.					
	Other information data transmit:					
	"Hexadecimal=30H/Decimal=48": Data is not printed.					
	"Hexadecimal=31H/Decimal=49": Data is not printed.					
	pL=3, pH=0					
Parameter	cn=49					
range	fn=82					
	m=48					
Default	None					
Notes	This command do not print QR code graph.					
Notes	Users must consider QR code graph space.					
Example	None					
Name	Setting QR code graph	information				

Printing two dimensional code

Name	Printing two dimensional code

	ASCII : GS k m v r nL nH d1dk		
Code	DEC : 29 107 97 v r nL nH d1dk		
	HEX: 1D 6B 61 v r nl nH d1dk		
	Printing two dimensional code.		
	v: describes two dimensional code specification		
Function	v=0: describes automatically select two dimensional code specification		
Function	r: describes error correction rank		
	nL nH: describes data length		
	d1dk: describes two dimensional code to be printed		
Doromotor	0 ≤ v ≤ 17		
Parameter	1 ≤ r ≤ 4		
range	k = nL + 256 * nH		
Default	None		
Notes	Printing QR code.		
F	1b 40		
Example	1D 6B 61 08 02 08 00 30 31 32 33 34 35 36 37		
Name	Printing two dimensional code		

Printing two dimensional code

Name	Printing two dimensional code			
	ASCII : ESC Z m n k dL dH d1dn			
Code	DEC : 27 90 m n k dL dH d1dn			
	HEX: 1B 5A m n k dL dH d1dn			
	①PDF417: bar code type 0			
	m specify the number of columns of two dimensional code. (1 ≤m≤30)			
	When the bar code image is damaged, n specify a safety and stable			
	recovery. (1 ≤n≤8)			
	K defines horizontal and vertical ratios. (2≤K≤5)			
	d is the data length and contains 2 bytes.			
	dL: the first byte is the low-order byte.			
	dH: the second byte is the high-order byte.			
	d1dn is bar code data			
Function	affect PDF417 type by the bar code width command.			
	②QR-CODE: bar code type 2			
	m specify version flag. (1~40, 0: auto size)			
	N specify EC level. (L: 7%, M: 15%, Q: 25%, H:30%)			
	K specify component type. (1~8)			
	d is the data length and contains 2 bytes.			
	dL: the first byte is the low-order byte.			
	dH: the second byte is the high-order byte.			
	QR-CODE model form is as follows:			
	Version Capacity (encoding) via EC level			

		L: 7%	M: 15%	Q: 25%	H: 30%
	1	19	16	13	9
	2	34	28	22	16
	3	55	44	34	26
	4	80	64	48	36
	5	108	86	62	46
	6	136	108	76	60
	7	156	124	88	66
	8	194	154	110	86
	9	232	182	132	100
	10	274	216	154	122
	11	324	254	180	140
	12	370	290	206	158
	13	428	334	244	180
	14	461	365	261	197
	15	523	415	195	223
	16	589	453	325	253
	17	647	507	367	283
	18	721	563	397	313
	19	795	627	445	341
Range	None				
Default	None				
Notes	None				
Example	None				
Name	Printing two di	mensional cod	e		

Printing double QR code

Name	Printing double QR code			
	ASCII : US Q m n p1H p1L l1H l1L ecc1 v1 d1dn			
	p2H p2L 12H l2L ecc2 v2 dkdm			
Code	DEC : 27 81 m n p1H p1L l1H l1L ecc1 v1 d1dn			
Code	p2H p2L 12H I2L ecc2 v2 dkdm			
	HEX : 1F 51 m n p1H p1L l1H l1L ecc1 v1 d1dn			
	p2H p2L 12H l2L ecc2 v2 dkdm			
Function	Printing double QR code			
	QR code numbers: 0 <m>3</m>			
	QR code size: n(1~8)			
	P1H,p1L specify the location of QR1: (p1H*256+p1L)			
Range	L1H,I1L specify the data length of QR1: (I1H*256+I1L)			
range	Ecc1 specify error correction level about QR1 : (0:7%,			
	1:15%,2:25%,3:30%)			
	V1 specify QR1 version of the symbol.(1~40, 0:auto size)			
	D1d2 as the data of QR1;			

	P2H,p2L specify the location of QR2: (p2H*256+p2L)				
	L2H,I2L specify the data length of QR2: (I2H*256+I2L)				
	Ecc2 specify error correction level about QR2 : (0:7%,				
	1:15%,2:25%,3:30%)				
	V2 specify QR2 version of the symbol.(1~40, 0:auto size)				
	Dkdm as the data of QR2				
Default	None				
Notos	If module size is bigger than printing width, the QR data will be treated as				
Notes	normal data				
	To Print string "0123456789" in QR Code at position 32 with ecc 1and				
	Print string "987654321" in QR Code at position 192 with ecc 2, and				
	module size 3, you should send command as follow。				
Example	1f 51 02 03				
	00 20 00 0a 01 06 30 31 32 33 34 35 36 37 38 39				
	00 C0 00 0a 02 00 39 38 37 36 35 34 33 32 31 30				

7Status querying Commands

Transmission status

Name	Transmission status			
	ASCII : GS r n			
Code	DEC : 29	9 114 n		
	HEX : 1D 7	72 n		
	Transmits th	e status specified by n as follows:		
Function	n	Function		
	1, 49	Transmits paper sensor status		
Range	n = 1, 49			
Default	None			
	When using a serial interface			
	When DTR/DSR control is selected, the printer transmits only 1 byte after			
	confirming the host is ready to receive data (DSR signal is SPACE). If the			
	host computer is not ready to receive data (DSR signal is MARK), the			
Notes	printer will wait until the host is ready.			
	When XON/XOFF control is selected, the printer transmits only 1 byte			
	without confirming the status of the DSR signal.			
	This command is executed when data is generated in the print			
	buffer.There	fore, there may be a time interval between receiving the		

command and sending status, depending on the status of the receiving buffer

When Auto Status Back (ASB) is enabled using GS a, the status transmitted by GS r and the ASB status must be differentiated using.

The status types to be transmitted are shown as below:

Bit	Off/On	Hex	Decima	Status for ASB
			I	
0,1	-	-	-	Undefined.
2,3	Off	00	0	Paperend sensor: paper adequate.
	On	(0C)	(12)	Paperend sensor: paper near end.
4	Off	00	0	unused. fixed to be Off.
5,6	-	-	-	Undefined.
7	Off	00	0	unused. fixed to be Off.

Paper sensor status (n = 1, 49):

Bits 2 and 3: When the paper end sensor detects the paper end, the printer goes offline and does not execute this command. Therefore, bits 2 and 3 do not transmit the status of paper end.

Example None

Transit theprinter status to host

Name	Transit the printer status to host					
	ASCII	SCII : GS v				
Code	DEC :	27 118				
	HEX : 11	3 76				
	transit a b	transit a byte printer status to host.				
	Only work	s in serial printer.				
	Send byte	end bytes are defined as follows:				
	byte	function	number			
	0					
Function	1					
Function	2	No paper	1			
	3	Printer failure	1			
	4	0	0			
	5					
	6	The heating plate is overheated	1			
	7					

Default	None
Notes	None
Example	None

Transit printer ID

Name	Transit printer ID						
	ASCII	: GS	Ιn				
Code	DEC : 29 73 n						
	HEX :	1D 49 n					
	Transit p	rinter ID	or the i	nformation	that specified	I by printer	
	Send bytes are defined as follows:						
	n			ļ	of printer	ID	
	1,49			ID of prin	ter type	HEX: 20/DEC: 32	
	2,50			ID type		Check below	
		1					
	Bites	Off/on	HEX	DEC	Content		
	0	off	00	0	Double-byt	e character code is not	
					supported		
		on	01	1	_	e character code can	
Function					be supported		
	1	1 on 02		2		Automatic paper cutter has been	
				installed			
	2, 3				unused		
	4	off	00	0	fixed		
	5				retain		
	6				unused		
	7	off	00	0	fixed		
	Information B can be specified						
	n	Printer		Conica	Content		
	65	Fixed v	,			software version	
	66	manufa	cturer		"Cashino"		
	67	Printing	name		"LPM260"or"PTP-II"		
	68	Printing			Seiral No.		
	69	Chinese		cters	Simplified C	hinese mode: GBK	
					Traditional C	Traditional Chinese mode: BIG-5	
Danas	n=1,2,49	9,50 [prin	ter ID]		•	<u>'</u>	
Range	65 ≤ n ≤	69[printe	er inforn	nation B]			
Default	None						
Notes	None						
Example	None						

CSN-A1 user manual

Select peripherals

Name	Select peripherals				
	ASCII : ESC=N				
Code	DEC : 27 61 n				
	HEX : 1B 3D n				
	Select host device to transit the data				
Function	n function				
Tariotion	1,3 Enable printer				
	2 Forbid printer				
Range	0 ≤ n ≤ 255				
Default	N=1				
Notes	None				
Example	None				

Transit the status of peripherals to host

Name	Transit the status of peripherals to host				
	ASCII : ESC u				
Code	DEC: 27 117				
	HEX :1B 75				
	Transit the status of peripherals to host, only works in serial printer.				
Function	Senddefinition of bytes				
Function	byte 0: drawer kick (0) /close electrical level (1)				
	byte 4: constant to be0				
Default	None				
Notes	None				
Example	None				

Allow, forbid status uploading automatically

Name	Allow,	Allow, forbid status uploading automatically						
	ASCII	ASCII : GS a n						
Code	DEC	DEC : 27 97 n						
	HEX :	1D 61 n						
	Only w	orks in serial printer						
	n are c	fined as follows:						
	byte	Function	Number					
	ll .		0	1				
Function	0 fixed to be 0							
	1							
	2	Forbid	Allow					
	3-4							
	5	Forbid,allowERROR set BUSY RTS=BUSY	Forbid	Allow				

	6-7						
Default	None						
Notes	When effective, printer found status changed, the status will be						
140103	automatically sent to the host						
Example	None						

Real-time transmission status

Name	Real-time transmission status				
Code	ASCII : DLE EOT n DEC : 16 4 n HEX : 10 04 n				
Function	According to below parameters, transit the real-time status of printer,n stands for printer status: N=1:transmit printer status N=2:transmit off-line status N=3:transmit error status N=4:transmit paper sensor status				
Range	1 ≤ n ≤ 4				
Default	None				
Support	All				

- •Printer return to the relative status immediately after receiving the command
- this command try not to put in command list between 2 or more bite .

Though printer being forbid by ESC=,this command still effective.

Printer transmit current situation ,each situation show by 1 bite data.

It is not sure host computer will receive printer transmit situation.

Printer executed immediately after received the command.

The command only effective for serial printer. Printer start to work immediately after receiving this command at any situation.

n=1: printer status

Bit	0/	Hexadecim	decimalis	Function
	1	al	m	
0	0	00	0	Fixed to be 0
1	1	02	2	Fixed to be 1
2	0	00	0	Two drawers kick(no drawer,
				fixed to be 0)
	1	04	4	Turn off two cashbox
3	0	00	0	On-line
	1	08	8	Off-line
4	1	10	16	Fixed to be 1
5,				undefined
6				
7	0	00	00	The paper has been torn away
	1	80	96	The paper hasn't been torn away

Notes

n=2: transit off-line status

bite	0	Hexadecim	decimalism	Function
	1	al		
	1			
0	0	00	0	Fixed to be 0
1	1	02	2	Fixed to be 1
2	0	00	0	Turn off upper cover

	1	04	4	Open upper cover
3	0	00	0	Not press feed key
	1	08	8	press feed key
4	1	10	16	Fixed to be 1
5	0	00	0	Paper adequate
	1	20	32	Paper shortage
6	0	00	00	No error
	1	40	64	Error
7	0	00	0	Fixed to be 0

n=3: transmit error status

	o. transmit on or otated						
bite	e 0	Hexadecim	decimalis	Function			
	1	al	m				
	1						
0	0	00	0	Fixed to be 0			
1	1	02	2	Fixed to be 1			
2				Undefined			
3	0	00	0	No cutter error			
	1	08	8	Cutter error			
4	1	10	16	Fixed to be 1			
5	0	00	0	No unrecoverable error			
	1	20	32	Unrecoverableerroe			
6	0	00	00	Printer head tempand voltage			
				are normal			
	1	40	64	Printer head temp.and voltage			
				are exceed			
7	0	00	0	Fexed to be 0			

Unrecoverable error: abnormal input voltage

Automatic recovery error: refers to the printing head overheating error. When the printing head overheating error occurs, wait for a period of time. When the printing head temperature drops, the error will be automatically recovered.

	n=4: paper sensor status				
	bite	0	Hexadecim	decimalis	Function
		1	al	m	
		1			
	0	0	00	0	Fixed to be 0
	1	1	02	2	Fixed to be 1
	2, 3	0	00	0	Paper
		1	0C	12	Paper near-end
	4	1	10	16	Fixed to be 1
	5, 6	0	00	0	Paper
		1	60	96	Paper end
	7	0	00	0	Fixed to be 0
	40.04.0				
	10 04 0 10 04 0				
Example	10 04 0				
	10 04 0	4			

Real-time request

Name	Real-time request						
	ASCII : DLE ENQ n						
Code	DEC :	DEC : 16 5 n					
	HEX : 10	0 05 n					
	The print	er responds to the request n of the host by specifying the					
	following request						
	n	Request					
Function	1	Restart printing from the error recovery and from the					
Function		line where the error occurred					
		This command is ignored unless a recoverable error					
		occurs					
	2	Restore the printer from the error status and empty					

		the command receiving buffer and printing buffer, which is ignored unless a failure is too lazy to occur	
Range	N=1,2		
Default	None		
	This command valids only when the cutter goes wrong		
	Consider the following:		
	1. If the printer data contains the same data as the command, the data will		
Notes	be executed as the command. Users need to consider this situation.		
	Example: the graphic data may contain strings that matchs it 2. Do not embed this command into another command		
	Example:	the graphical data may contain this command	
Example	None		

Real-time pulse

Name	Real-time pulse	
	ASCII : DLE D	C4 fn m t
Code	DEC : 16 20 fn m t	
	HEX : 10 14 fn m $$	t
Function	T stands for the re	eal-time output pulse, and m is the connection pin
1 dilottori	0 drawer s	socket pin 2
	1 drawer s	socket pin 2
	T specifies that the	starting/closing time of the pulse is (t*100ms)
Range	Fn=1, m=0,1,10≤ t≤ 8	
Default	None	
	Consider the follow	ng:
	1. If the printer data	contains the same data as the command, the data will
Notes	be executed as the command. Users need to consider this situation.	
notes	Example: the graphic data may contain strings that matchs it	
	Do not embed this command into another command	
	Example: the graph	ical data may contain this command
Example	None	

®Commands in page print mode

Forms feed

Name	Forms feed
	ASCII : FF
Code	Decimal : 12
	Hex : 0C
	The FF command prints the data already contained in the print buffer,
Function	then
Function	sets the next-data receive position at the leftmost column on the next
	page.
Range	None
Default value	None
	Valid only when this command is input in page print mode.
Notes	Remove data from print buffers after printing
	This command sets the print location as the starting point for the line
Example	None

Data print in page print mode

Name	Data print in page print mode	
Code	ASCII : ESC FF	
	Decimal: 27 12	
	Hex : 1B 0C	
Function	Performs the batch printing of data developed in the entire print area in	
	page print mode.	
Range	None	
Default value	None	
Notes	Valid only when this command is input in page print mode.	
Example	None	

Page print mode select

Name	Page print mode select	
	ASCII : ESC L	
Code	Decimal : 27 76	
	Hex : 1B 4C	
Function	Switches from standard mode to page mode.	
Range	None	
Default value	None	
Notes	Valid only when this command is input in page print mode.	
	In the line print mode, this function is valid only when this	


	command is input in the beginning of the line
	After turning on power, or resetting printer printing by ESC@ ,page print
	mode is returned to line print
	mode.
Example	None

Line print mode select.

Name	Line print mode select.
	ASCII : ESC S
Code	Decimal : 27 83
	Hex : 1B 53
Function	The ESC S command selects line print mode.
Range	None
Default value	None
	Valid only when this command is input in page print mode.
Notes	Data developed in page print mode is erased.
	This command sets the print location as the starting point for the line.
	The print locale set by ESC W is initialized
Example	None

Character development angle select in page print mode.

Name	Character de	evelopment angle sele	ect in page print mode.
	ASCII :	ESC T n	
Code	Decimal :	27 84 n	
	Hex :	1B 54 n	
	This comma	and sets the print dir	ection of characters in the page print
	mode and		
	the start pos	sition of data developm	nent.
	The relatio	nship of n, print o	direction and start position of data
	a	Development	Development start position
Function		direction	
	0,48	Left → right	Upper left [(a) in drawing at right]
	1,49	Bottom → top	Lower left [(b) in drawing at right]
	2,50	Right → left	Lower right ([(c) in drawing at right]
	3,51	Top→bottom	Upper right [(d) in drawing at right]
	developmen	t is as follows.:	



Page print mode print area setting

Nama	Dago print mode print area catting		
Name	Page print mode print area setting.		
Code	ASCII : ESC W xL XH yL yH dxL dxH dyL dyH		
	Decimal : 27 87 xL XH yL yH dxL dxH dyL dyH		
	Hex : 1B 57 xL XH yL yH dxL dxH dyL dyH		
	X0,y0,dx,dy define respectively Horizontal start point, Vertical start		
	point,Horizontal length,Vertical length		
	Each parameter sets the following functions:		
Function	X0=[(xL+xH*256)*0.125mm]		
	y0=[(yL+yH*256)*0.125mm]		
	dx=[(dxL+dxH*256)*0.125mm]		
	dy=[(dyL+dyH*256)*0.125mm]		
Range	$0 \le xL,xH,yL,yH,dxL,dxH,dyL,dyH \le 255$		
Range	(Except dxL=dxH=0 or dyL=dyH=0)		
Default value	None		
	When line mode is specified, only the internal set values are		
	changed, and		
Notes	printing in line mode is not influenced by this command;		
	If the horizontal start point or the vertical start point is not in a printable		
	area, printer stops the command processing and follows the following		
	data to normal processing;		
	If the print area width and height are set to 0, printer stops the		

command processing and follows the following data to normal processing;


This command sets the area of the data buffer, which is the area specified by the ESC T in the Print area range;

If the (horizontal start point+width of print area) exceed the print area, then the print area width is automatically set to (horizontal printable area-horizontal start point);

If the (vertical start point+height of print area) exceed the print area, then the print area width is automatically set to (vertical printable area-vertical start point);

Use 0.125mm space to set the horizontal start position and print area width, and use 0.125mm space to set the vertical start position and print area height;

If the horizontal start point is X, the vertical start point is Y, the horizontal length is dX and the vertical length is dY, then the printable area is as follows.:



Vertical absolute position setting in page print mode

Name	Vertical absolute position setting in page print mode
Code	ASCII : GS \$ nL nH
	Decimal : 29 36 nL nH
	Hex : 1D 24 nL nH
	The GS \$ command sets vertical absolute position in page print
Function	mode.。
	The absolute position is at [(nL+nH*256)*0.125mm]
Range	0 ≤ nL≤255, 0 ≤ nH≤255
Default value	None
	Valid only when this command is input in page print mode.
	If [(nL+nH*256)* (vertical or horizontal movement unit)] this command is
Notes	ignored
	Does not move at the horizontal starting area of the buffer
	The command operates as follows, depending on the starting area of the
	print area set by the ESC T

	If start area is set to upper left or lower right, then this command sets
	absolute area in vertical direction
	If start area is set to upper right or lower left, then this command sets
	absolute area in horizontal direction
Example	None

Vertical relative position setting in page print mode

Name	Vertical relative position setting in page print mode		
Code	ASCII : GS \ nL nH		
	Decimal : 29 92 nL nH		
	Hex : 1D 5C nL nH		
	Page mode setting starts at the current position and prints the start		
Function	position relatively vertically		
1 unction	This command sets the distance from the current position to		
	[(nl+nh*256) *0.125mm]		
Range	0 ≤ nL≤255, 0 ≤ nH≤255		
Default value	None		
	When the specified n is a downward motion:		
	nL+nH*256=N		
	When you specify N as the upward motion (negative direction), use the		
	65536 complement		
	When the specified n is up motion:		
Notes	nL+nH*256=65536-N		
	Any settings that exceed the specified print area are ignored		
	Use vertical motion units(y) when you set the start position to the		
	upper-left or lower-right of the print area		
	Use horizontal Motion unit (x) when you set the start position to the		
	upper right or lower left of the print area		
Example	None		

9Other commands

Printer reset

Name	Printer reset
Code	ASCII : ESC @
	Decimal : 27 64
	Hex : 1B 40
Function	The ESC @ command initializes the printer as following:
	This command prints the data contained in the print buffer, and
	initializes various setup items.
	Restore default values for each parameter

Range	None
Default value	None
Notes	None
Example	None

Print self-test page

Name	Print self-test page
Code	ASCII : DC2 T
	Decimal : 18 84
	Hex : 12 54
Function	Printing a self-test page which including firmware
	version,interface,codepage and other some information
Range	None
Default value	None
Notes	None
Example	1B 40 12 54