SimulationInterfaceMacro 5.0

Generated by Doxygen 1.8.5

Wed Jun 1 2022 12:04:46

Contents

1	Mod	lule Inde	X														1
	1.1	Module	3										 	 	 	 	 1
2	Nam	nespace l	ndex														3
	2.1	Namesp	oace List										 	 	 	 	 3
3	Hier	archical	Index														5
	3.1	Class H	ierarchy										 	 	 	 	 5
4	Data	a Structu	re Index														7
	4.1	Data St	ructures										 	 	 	 	 7
5	File	Index															9
	5.1	File List											 	 	 	 	 9
6	Mod	lule Docu	umentatio	on													11
	6.1	Models											 	 	 	 	 11
		6.1.1	Detailed	Description	n								 	 	 	 	 11
	6.2	Utils .											 	 	 	 	 12
		6.2.1	Detailed	Descriptio	n								 	 	 	 	 12
	6.3	SimInte	rface										 	 	 	 	 13
		6.3.1	Detailed	Description	n								 	 	 	 	 15
		6.3.2	Macro De	efinition Do	ocume	entatio	n .						 	 	 		 15
			6.3.2.1	CLASS .									 	 	 		 15
			6.3.2.2	ER7_UT	ILS_A	LWAY	/S_IN	ILINE					 	 	 	 	 15
			6.3.2.3	ER7_UT	ILS_R	ESTF	RICT						 	 	 	 	 15
			6.3.2.4	ER7_UT	ILS_U	NUSE	D.						 	 	 	 	 15
			6.3.2.5	JEOD_A	TTRIE	BUTES	S_PO	INTE	R_T	YPE			 	 	 	 	 15
			6.3.2.6	JEOD_A	TTRIE	BUTES	S_PO	INTE	R_T	YPE			 	 	 	 	 15
			6.3.2.7	JEOD_A	TTRIE	BUTES	S_SIN	√_EN	IGIN	E_H	EAD	ER	 	 	 	 	 15
			6.3.2.8	JEOD_A													16
			6.3.2.9	JEOD_A	TTRIE	BUTES	S_TY	PE .					 	 	 	 	 16
			6.3.2.10	JEOD_C													16

iv CONTENTS

			6.3.2.11	JEOD_DECLARE_SIM_INTERFACES	16
			6.3.2.12	JEOD_INTPTR_T	16
			6.3.2.13	JEOD_MAKE_SIM_INTERFACES	16
			6.3.2.14	JEOD_PTRDIFF_T	16
			6.3.2.15	JEOD_SIM_INTEGRATOR_ENUM	16
			6.3.2.16	JEOD_SIM_INTEGRATOR_FORWARD	17
			6.3.2.17	JEOD_SIM_INTEGRATOR_POINTER_TYPE	17
			6.3.2.18	JEOD_SIM_INTEGRATOR_POINTER_TYPE	17
			6.3.2.19	JEOD_SIM_INTEGRATOR_SIM_ENGINE_HEADER	17
			6.3.2.20	JEOD_SIZE_T	17
			6.3.2.21	JEOD_UINTPTR_T	17
			6.3.2.22	JEOD_UNUSED	17
			6.3.2.23	MAKE_MESSAGE_CODE	17
				MAX_MSG_SIZE	17
				PATH	17
		6.3.3	Variable I	Documentation	17
			6.3.3.1	trick_curr_integ	17
			6.3.3.2	trick_MM	18
			6.3.3.3	trick_MM	18
			6.3.3.4	trick_MM	18
			6.3.3.5	trick_MM	18
7	Nam	espace	Documer	ntation	19
	7.1	er7_uti	ls Namesp	pace Reference	19
		7.1.1	Detailed	Description	19
	7.2	jeod N	amespace	Reference	19
		7.2.1	Detailed	Description	20
	7.3	Trick N	amespace	Reference	20
		7.3.1	Detailed	Description	20
8	Data	Structi	ure Docun	nentation	21
	8.1	jeod::J	eodTrickM	emoryInterface::AllocationMapEntry Struct Reference	21
		8.1.1	Detailed	Description	21
		8.1.2	Construc	stor & Destructor Documentation	21
			8.1.2.1	AllocationMapEntry	21
		8.1.3	Field Doo	cumentation	22
			8.1.3.1	is_array	22
			8.1.3.2	nelements	22
			8.1.3.3	typeid_info	22
	8.2	jeod::B	asicJeodT	rickSimInterface Class Reference	22
		8.2.1	Detailed	Description	24

CONTENTS

8.2.2	Construc	tor & Destructor Documentation	24
	8.2.2.1	BasicJeodTrickSimInterface	24
	8.2.2.2	$\sim\! BasicJeodTrickSimInterface \ . \ . \ . \ . \ . \ . \ . \ . \ . \ $	25
	8.2.2.3	BasicJeodTrickSimInterface	25
8.2.3	Member	Function Documentation	25
	8.2.3.1	checkpoint_allocations	25
	8.2.3.2	checkpoint_containers	25
	8.2.3.3	close_checkpoint_file	25
	8.2.3.4	close_restart_file	25
	8.2.3.5	create_integrator_internal	25
	8.2.3.6	get_checkpoint_file_name	26
	8.2.3.7	get_checkpoint_reader_internal	26
	8.2.3.8	get_checkpoint_writer_internal	26
	8.2.3.9	get_job_cycle_internal	26
	8.2.3.10	get_memory_interface_internal	27
	8.2.3.11	open_checkpoint_file	27
	8.2.3.12	open_restart_file	27
	8.2.3.13	operator=	27
	8.2.3.14	restore_allocations	27
	8.2.3.15	restore_containers	28
	8.2.3.16	set_checkpoint_file_name	28
	8.2.3.17	set_mode	28
8.2.4	Friends A	And Related Function Documentation	28
	8.2.4.1	init_attrjeodBasicJeodTrickSimInterface	28
	8.2.4.2	InputProcessor	28
8.2.5	Field Doo	cumentation	28
	8.2.5.1	checkpoint_file_name	28
	8.2.5.2	checkpoint_reader	29
	8.2.5.3	checkpoint_writer	29
	8.2.5.4	generic_message_handler	29
	8.2.5.5	memory_manager	29
	8.2.5.6	section_end	29
	8.2.5.7	section_start	29
	8.2.5.8	trick_memory_interface	30
jeod::C	heckPoint	InputManager Class Reference	30
8.3.1	Detailed	Description	31
8.3.2	Construc	tor & Destructor Documentation	31
	8.3.2.1	CheckPointInputManager	31
	8.3.2.2	CheckPointInputManager	31
8.3.3	Member	Function Documentation	31

8.3

vi CONTENTS

		8.3.3.1	create_section_reader	31
		8.3.3.2	create_section_reader	32
		8.3.3.3	create_trick_section_reader	32
		8.3.3.4	deregister_reader	33
		8.3.3.5	have_active_reader	33
		8.3.3.6	initialize	33
		8.3.3.7	operator!	33
		8.3.3.8	operator=	33
		8.3.3.9	register_reader	34
	8.3.4	Field Do	cumentation	34
		8.3.4.1	current_reader	34
		8.3.4.2	filename	34
		8.3.4.3	is_open	34
		8.3.4.4	section_end	34
		8.3.4.5	section_start	34
		8.3.4.6	sections	35
		8.3.4.7	stream	35
8.4	jeod::C	heckPoint	tOutputManager Class Reference	35
	8.4.1	Detailed	Description	36
	8.4.2	Construc	ctor & Destructor Documentation	36
		8.4.2.1	CheckPointOutputManager	36
		8.4.2.2	CheckPointOutputManager	37
	8.4.3	Member	Function Documentation	37
		8.4.3.1	create_section_writer	37
		8.4.3.2	create_section_writer	37
		8.4.3.3	create_trick_section_writer	38
		8.4.3.4	deregister_writer	38
		8.4.3.5	have_active_writer	38
		8.4.3.6	operator!	38
		8.4.3.7	operator=	38
		8.4.3.8	register_writer	39
	8.4.4	Friends /	And Related Function Documentation	39
		8.4.4.1	MemoryManagerWrapper	39
	8.4.5	Field Do	cumentation	39
		8.4.5.1	current_writer	39
		8.4.5.2	filename	39
		8.4.5.3	is_open	39
		8.4.5.4	section_end	39
		8.4.5.5	section_start	40
		8.4.5.6	stream	40

CONTENTS vii

8.5	jeod::J	d::JeodTrickMemoryInterface::ContainerListEntry Struct Reference						
	8.5.1	Detailed	Description	40				
	8.5.2	Construc	stor & Destructor Documentation	41				
		8.5.2.1	ContainerListEntry	41				
	8.5.3	Field Doo	cumentation	41				
		8.5.3.1	container	41				
		8.5.3.2	elem_name	41				
		8.5.3.3	owner	41				
		8.5.3.4	owner_type	41				
8.6	jeod::J	eodDynbo	dyIntegrationLoop Class Reference	42				
	8.6.1	Detailed	Description	44				
	8.6.2	Construc	stor & Destructor Documentation	44				
		8.6.2.1	JeodDynbodyIntegrationLoop	44				
		8.6.2.2	JeodDynbodyIntegrationLoop	44				
		8.6.2.3	\sim JeodDynbodyIntegrationLoop	45				
		8.6.2.4	JeodDynbodyIntegrationLoop	45				
	8.6.3	Member	Function Documentation	45				
		8.6.3.1	add_integrable_object	45				
		8.6.3.2	add_sim_object	45				
		8.6.3.3	add_sim_object_bodies	46				
		8.6.3.4	add_sim_object_bodies	46				
		8.6.3.5	collect_derivatives	46				
		8.6.3.6	find_containing_sim_object	46				
		8.6.3.7	gravitation	47				
		8.6.3.8	initialize_integ_loop	47				
		8.6.3.9	integrate_dt	47				
		8.6.3.10	operator=	47				
		8.6.3.11	remove_integrable_object	47				
		8.6.3.12	remove_sim_object	47				
		8.6.3.13	remove_sim_object_bodies	48				
		8.6.3.14	set_deriv_ephem_update	48				
		8.6.3.15	set_time_to_loop_start	48				
		8.6.3.16	update_integration_group	48				
	8.6.4	Friends A	And Related Function Documentation	49				
		8.6.4.1	init_attrjeodJeodDynbodyIntegrationLoop	49				
		8.6.4.2	InputProcessor	49				
	8.6.5	Field Doo	cumentation	49				
		8.6.5.1	deriv_ephem_update	49				
		8.6.5.2	dyn_manager	49				
		8.6.5.3	gravity_manager	49				

viii CONTENTS

		8.6.5.4	integ_constructor	49
		8.6.5.5	integ_group	50
		8.6.5.6	integ_group_factory	50
		8.6.5.7	integ_interface	50
		8.6.5.8	loop_sim_object	50
		8.6.5.9	time_manager	50
8.7	jeod::J	eodIntegra	torInterface Class Reference	50
	8.7.1	Detailed	Description	51
	8.7.2	Construc	tor & Destructor Documentation	51
		8.7.2.1	\sim JeodIntegratorInterface	51
	8.7.3	Member	Function Documentation	51
		8.7.3.1	get_integrator	51
		8.7.3.2	interpret_integration_type	52
	8.7.4	Friends A	And Related Function Documentation	52
		8.7.4.1	init_attrjeodJeodIntegratorInterface	52
		8.7.4.2	InputProcessor	52
8.8	jeod::J	eodMemor	ryInterface Class Reference	52
	8.8.1	Detailed	Description	53
	8.8.2	Construc	tor & Destructor Documentation	53
		8.8.2.1	JeodMemoryInterface	53
		8.8.2.2	~JeodMemoryInterface	53
		8.8.2.3	JeodMemoryInterface	53
	8.8.3	Member	Function Documentation	54
		8.8.3.1	deregister_allocation	54
		8.8.3.2	deregister_container	54
		8.8.3.3	find_attributes	54
		8.8.3.4	find_attributes	54
		8.8.3.5	get_address_at_name	55
		8.8.3.6	get_name_at_address	55
		8.8.3.7	is_checkpoint_restart_supported	56
		8.8.3.8	operator=	56
		8.8.3.9	pointer_attributes	56
		8.8.3.10	primitive_attributes	56
		8.8.3.11	register_allocation	57
		8.8.3.12	register_container	57
		8.8.3.13	structure_attributes	57
		8.8.3.14	void_pointer_attributes	57
	8.8.4	Friends A	And Related Function Documentation	58
		8.8.4.1	init_attrjeodJeodMemoryInterface	58
		8.8.4.2	InputProcessor	58

CONTENTS

8.9	jeod::Je	leodSimulationInterface Class Reference						
	8.9.1	Detailed Description						
	8.9.2	Member E	Enumeration Documentation	60				
		8.9.2.1	Mode	60				
	8.9.3	Constructo	or & Destructor Documentation	60				
		8.9.3.1	JeodSimulationInterface	60				
		8.9.3.2	\sim JeodSimulationInterface	60				
		8.9.3.3	JeodSimulationInterface	61				
	8.9.4	Member F	Function Documentation	61				
		8.9.4.1	configure	61				
		8.9.4.2	create_integrator_interface	61				
		8.9.4.3	create_integrator_internal	61				
		8.9.4.4	get_address_at_name	61				
		8.9.4.5	get_checkpoint_reader	62				
		8.9.4.6	get_checkpoint_reader_internal	62				
		8.9.4.7	get_checkpoint_writer	62				
		8.9.4.8	get_checkpoint_writer_internal	62				
		8.9.4.9	get_job_cycle	63				
		8.9.4.10	get_job_cycle_internal	63				
		8.9.4.11	get_memory_interface	63				
		8.9.4.12	get_memory_interface_internal	63				
		8.9.4.13	get_mode	64				
		8.9.4.14	get_name_at_address	64				
		8.9.4.15	operator=	64				
		8.9.4.16	set_mode	64				
	8.9.5	Friends Ar	nd Related Function Documentation	65				
		8.9.5.1	init_attrjeodJeodSimulationInterface	65				
		8.9.5.2	InputProcessor	65				
	8.9.6	Field Docu	umentation	65				
		8.9.6.1	mode	65				
		8.9.6.2	saved_mode	65				
		8.9.6.3	sim_interface	65				
8.10	jeod::Je	eodSimulati	ionInterfaceInit Class Reference	65				
	8.10.1	Detailed D	Description	66				
	8.10.2	Constructo	or & Destructor Documentation	66				
		8.10.2.1	JeodSimulationInterfaceInit	66				
	8.10.3	Field Docu	umentation	66				
		8.10.3.1	memory_debug_level	66				
		8.10.3.2	message_suppress_id	66				
		8.10.3.3	message_suppress_location	67				

CONTENTS

		8.10.3.4 n	nessage_suppression_level	67
8.11	jeod::Je	eodTrick10M	lemoryInterface Class Reference	67
	8.11.1	Detailed De	escription	68
	8.11.2	Constructor	r & Destructor Documentation	69
		8.11.2.1 J	leodTrick10MemoryInterface	69
		8.11.2.2 ~	~JeodTrick10MemoryInterface	69
		8.11.2.3 J	leodTrick10MemoryInterface	69
	8.11.3	Member Fu	unction Documentation	69
		8.11.3.1 c	checkpoint_allocations	69
		8.11.3.2	checkpoint_containers	69
		8.11.3.3 d	deregister_container	69
		8.11.3.4 g	get_address_at_name	70
		8.11.3.5 g	get_container_id	70
		8.11.3.6 g	get_name_at_address	71
		8.11.3.7 g	get_trick_checkpoint_file	71
		8.11.3.8 is	s_checkpoint_restart_supported	71
		8.11.3.9	pperator=	71
		8.11.3.10 r	egister_container	72
		8.11.3.11 r	estore_allocations	72
		8.11.3.12 r	estore_containers	72
		8.11.3.13 ti	ranslate_addr_to_name	73
		8.11.3.14 ti	ranslate_name_to_addr	73
	8.11.4	Friends And	d Related Function Documentation	73
		8.11.4.1 in	nit_attrjeodJeodTrick10MemoryInterface	73
		8.11.4.2 li	nputProcessor	73
	8.11.5	Field Docur	mentation	73
		8.11.5.1 ti	rick_checkpoint_agent	74
8.12	jeod::Je	eodTrickInte	grator Class Reference	74
	8.12.1	Detailed De	escription	75
	8.12.2	Constructor	r & Destructor Documentation	75
		8.12.2.1 J	leodTrickIntegrator	75
		8.12.2.2	~JeodTrickIntegrator	75
		8.12.2.3 J	leodTrickIntegrator	75
	8.12.3	Member Fu	unction Documentation	76
		8.12.3.1 g	get_dt	76
		8.12.3.2 g	get_first_step_derivs_flag	76
		8.12.3.3 g	get_integrator	76
		8.12.3.4 in	nterpret_integration_type	76
		8.12.3.5	pperator=	76
		8.12.3.6 r	eset_first_step_derivs_flag	76

CONTENTS xi

		8.12.3.7	restore_first_step_derivs_flag	77
		8.12.3.8	set_first_step_derivs_flag	77
		8.12.3.9	set_step_number	77
		8.12.3.10	set_time	77
	8.12.4	Friends A	nd Related Function Documentation	77
		8.12.4.1	init_attrjeodJeodTrickIntegrator	77
		8.12.4.2	InputProcessor	77
	8.12.5	Field Doc	umentation	77
		8.12.5.1	default_first_step_deriv	78
		8.12.5.2	trick_integrator	78
8.13	jeod::Je	eodTrickMe	emoryInterface Class Reference	78
	8.13.1	Detailed D	Description	80
	8.13.2	Member 7	Typedef Documentation	80
		8.13.2.1	AllocationMap	80
		8.13.2.2	ContainerList	81
	8.13.3	Construct	or & Destructor Documentation	81
		8.13.3.1	JeodTrickMemoryInterface	81
		8.13.3.2	$\sim \!\! JeodTrickMemoryInterface \; . \; . \; . \; . \; . \; . \; . \; . \; . \; $	81
		8.13.3.3	JeodTrickMemoryInterface	81
	8.13.4	Member F	Function Documentation	81
		8.13.4.1	checkpoint_allocations	81
		8.13.4.2	checkpoint_containers	81
		8.13.4.3	construct_identifier	82
		8.13.4.4	deregister_allocation	82
		8.13.4.5	deregister_container	82
		8.13.4.6	find_attributes	83
		8.13.4.7	find_attributes	83
		8.13.4.8	get_address_at_name	83
		8.13.4.9	get_name_at_address	83
		8.13.4.10	get_trick_checkpoint_file	84
		8.13.4.11	is_checkpoint_restart_supported	84
		8.13.4.12	operator=	84
		8.13.4.13	pointer_attributes	84
		8.13.4.14	primitive_attributes	85
		8.13.4.15	register_allocation	85
		8.13.4.16	register_container	85
		8.13.4.17	restore_allocations	87
		8.13.4.18	restore_containers	87
		8.13.4.19	set_mode	87
		8.13.4.20	structure_attributes	87

xii CONTENTS

		8.13.4.21 \	void_pointer_attributes	. 88
	8.13.5	Friends An	nd Related Function Documentation	. 88
		8.13.5.1 i	init_attrjeodJeodTrickMemoryInterface	. 88
		8.13.5.2 I	InputProcessor	. 88
	8.13.6	Field Docu	mentation	. 88
		8.13.6.1	allocation_map	. 88
		8.13.6.2	container_list	. 88
		8.13.6.3	dlhandle	. 89
		8.13.6.4 i	id_length	. 89
		8.13.6.5 i	id_prefix	. 89
		8.13.6.6 r	mode	. 89
8.14	jeod::Je	eodTrickSim	Interface Class Reference	. 89
	8.14.1	Detailed De	escription	. 90
	8.14.2	Constructo	or & Destructor Documentation	. 90
		8.14.2.1	JeodTrickSimInterface	. 90
		8.14.2.2	~JeodTrickSimInterface	. 90
		8.14.2.3	JeodTrickSimInterface	. 91
	8.14.3	Member Fu	unction Documentation	. 91
		8.14.3.1	operator=	. 91
	8.14.4	Friends An	nd Related Function Documentation	. 91
		8.14.4.1 i	init_attrjeodJeodTrickSimInterface	. 91
		8.14.4.2 I	InputProcessor	. 91
8.15	jeod::S	ectionedInp	outBuffer Class Reference	. 91
	8.15.1	Detailed De	escription	. 92
	8.15.2	Constructo	or & Destructor Documentation	. 92
		8.15.2.1	~SectionedInputBuffer	. 92
		8.15.2.2	SectionedInputBuffer	. 93
		8.15.2.3	SectionedInputBuffer	. 93
	8.15.3	Member Fu	unction Documentation	. 93
		8.15.3.1 a	activate	. 93
		8.15.3.2	deactivate	. 93
		8.15.3.3	operator!	. 93
		8.15.3.4	operator=	. 94
		8.15.3.5 u	underflow	. 94
	8.15.4	Friends An	nd Related Function Documentation	. 94
		8.15.4.1	SectionedInputStream	. 94
	8.15.5	Field Docu	mentation	. 94
		8.15.5.1 a	at_eof	. 94
		8.15.5.2 k	buf	. 94
		8.15.5.3	curr_pos	. 94

CONTENTS xiii

		8.15.5.4	end_pos	 	95
		8.15.5.5	file_buf	 	95
		8.15.5.6	start_pos	 	95
8.16	jeod::Se	ectionedIn	nputStream Class Reference	 	95
	8.16.1	Detailed	Description	 	97
	8.16.2	Construc	tor & Destructor Documentation	 	98
		8.16.2.1	SectionedInputStream	 	98
		8.16.2.2	SectionedInputStream	 	98
		8.16.2.3	$\sim\!\!SectionedInputStream\ldots\ldots\ldots\ldots\ldots\ldots$	 	99
		8.16.2.4	SectionedInputStream	 	99
	8.16.3	Member	Function Documentation	 	99
		8.16.3.1	activate	 	99
		8.16.3.2	deactivate	 	99
		8.16.3.3	is_activatable	 	100
		8.16.3.4	operator void *	 	100
		8.16.3.5	operator!	 	100
		8.16.3.6	operator=	 	100
	8.16.4	Friends A	And Related Function Documentation	 	100
		8.16.4.1	CheckPointInputManager	 	100
	8.16.5	Field Doo	cumentation	 	101
		8.16.5.1	end_pos	 	101
		8.16.5.2	is_active	 	101
		8.16.5.3	is_copy	 	101
		8.16.5.4	manager	 	101
		8.16.5.5	sectbuf	 	101
		8.16.5.6	start_pos	 	101
		8.16.5.7	stream	 	102
8.17	jeod::Se	ectionedO	OutputBuffer Class Reference	 	102
	8.17.1	Detailed	Description	 	103
	8.17.2	Construc	tor & Destructor Documentation	 	103
		8.17.2.1	~SectionedOutputBuffer	 	103
		8.17.2.2	SectionedOutputBuffer	 	103
		8.17.2.3	SectionedOutputBuffer	 	103
		8.17.2.4	SectionedOutputBuffer	 	103
	8.17.3	Member	Function Documentation	 	103
		8.17.3.1	activate	 	103
		8.17.3.2	deactivate	 	104
		8.17.3.3	operator!	 	104
		8.17.3.4	operator=	 	104
		8.17.3.5	overflow	 	104

XIV

	8.17.4	Friends And Related Function Documentation	105
		8.17.4.1 SectionedOutputStream	105
	8.17.5	Field Documentation	105
		8.17.5.1 file_buf	105
8.18	jeod::S	ectionedOutputStream Class Reference	105
	8.18.1	Detailed Description	106
	8.18.2	Constructor & Destructor Documentation	107
		8.18.2.1 SectionedOutputStream	107
		8.18.2.2 SectionedOutputStream	107
		8.18.2.3 ~SectionedOutputStream	107
		8.18.2.4 SectionedOutputStream	107
	8.18.3	Member Function Documentation	107
		8.18.3.1 activate	107
		8.18.3.2 deactivate	108
		8.18.3.3 is_activatable	
		8.18.3.4 operator void *	108
		8.18.3.5 operator!	
		8.18.3.6 operator=	
	8.18.4	Friends And Related Function Documentation	
		8.18.4.1 CheckPointOutputManager	
	8.18.5	Field Documentation	
		8.18.5.1 is_active	
		8.18.5.2 is_copy	
		8.18.5.3 manager	
		8.18.5.4 sectbuf	
		8.18.5.5 section_end	
		8.18.5.6 section_start	
		8.18.5.7 stream	
		8.18.5.8 tag	
8.19		heckPointInputManager::SectionInfo Struct Reference	
		Detailed Description	
	8.19.2	Constructor & Destructor Documentation	
		8.19.2.1 SectionInfo	
	8.19.3	Field Documentation	
		8.19.3.1 end_pos	
		8.19.3.2 start_pos	
8.20		imInterfaceMessages Class Reference	
		Detailed Description	
	8.20.2	Constructor & Destructor Documentation	
		8.20.2.1 SimInterfaceMessages	112

CONTENTS xv

		8.20.2.2 SimInterfaceMessages		 	 	 112
	8.20.3	Member Function Documentation		 	 	 112
		8.20.3.1 operator=		 	 	 112
	8.20.4	Field Documentation		 	 	 112
		8.20.4.1 implementation_error		 	 	 112
		8.20.4.2 integration_error		 	 	 112
		8.20.4.3 interface_error		 	 	 112
		8.20.4.4 phasing_error		 	 	 113
		8.20.4.5 singleton_error		 	 	 113
8.21	jeod::Tr	ickJeodIntegrator Class Reference		 	 	 113
	8.21.1	Detailed Description		 	 	 114
	8.21.2	Constructor & Destructor Documentation		 	 	 114
		8.21.2.1 \sim TrickJeodIntegrator		 	 	 114
	8.21.3	Member Function Documentation		 	 	 114
		8.21.3.1 initialize		 	 	 114
		8.21.3.2 integrate		 	 	 114
8.22	jeod::Tr	ickMessageHandler Class Reference		 	 	 114
	8.22.1	Detailed Description		 	 	 115
	8.22.2	Constructor & Destructor Documentation		 	 	 115
		8.22.2.1 TrickMessageHandler		 	 	 115
		8.22.2.2 \sim TrickMessageHandler		 	 	 115
		8.22.2.3 TrickMessageHandler		 	 	 115
	8.22.3	Member Function Documentation		 	 	 116
		8.22.3.1 operator=		 	 	 116
		8.22.3.2 process_message		 	 	 116
		8.22.3.3 register_contents		 	 	 116
	8.22.4	Friends And Related Function Documentation	n	 	 	 116
		8.22.4.1 init_attrjeodTrickMessageHandle	er	 	 	 116
		8.22.4.2 InputProcessor		 	 	 116
8.23	jeod::Tr	ickMessageHandlerMixin Class Reference .		 	 	 116
	8.23.1	Detailed Description		 	 	 117
	8.23.2	Constructor & Destructor Documentation		 	 	 117
		8.23.2.1 TrickMessageHandlerMixin		 	 	 117
		8.23.2.2 \sim TrickMessageHandlerMixin		 	 	 117
		8.23.2.3 TrickMessageHandlerMixin		 	 	 118
	8.23.3	Member Function Documentation		 	 	 118
		8.23.3.1 operator=		 	 	 118
	8.23.4	Friends And Related Function Documentation	n	 	 	 118
		8.23.4.1 init_attrjeodTrickMessageHandle	erMixin .	 	 	 118
		8.23.4.2 InputProcessor		 	 	 118

xvi CONTENTS

		8.23.5 Field Documentation	118
		8.23.5.1 message_handler	118
9	File I	Documentation	119
	9.1	checkpoint_input_manager.cc File Reference	119
		9.1.1 Detailed Description	119
	9.2	checkpoint_input_manager.hh File Reference	119
		9.2.1 Detailed Description	120
	9.3	checkpoint_output_manager.cc File Reference	120
		9.3.1 Detailed Description	120
	9.4	checkpoint_output_manager.hh File Reference	120
		9.4.1 Detailed Description	121
	9.5	class_declarations.hh File Reference	121
		9.5.1 Detailed Description	121
	9.6	config.hh File Reference	121
		9.6.1 Detailed Description	122
	9.7	config_test_harness.hh File Reference	122
		9.7.1 Detailed Description	122
	9.8	config_trick10.hh File Reference	122
		9.8.1 Detailed Description	122
	9.9	jeod_class.hh File Reference	123
		9.9.1 Detailed Description	123
	9.10	jeod_integrator_interface.hh File Reference	123
		9.10.1 Detailed Description	124
	9.11	jeod_trick_integrator.hh File Reference	124
		9.11.1 Detailed Description	124
	9.12	memory_attributes.hh File Reference	124
		9.12.1 Detailed Description	125
		9.12.2 Macro Definition Documentation	125
		9.12.2.1 JEOD_ATTRIBUTES	125
		9.12.2.2 JEOD_DECLARE_ATTRIBUTES	125
	9.13	memory_interface.cc File Reference	125
		9.13.1 Detailed Description	126
	9.14	memory_interface.hh File Reference	126
		9.14.1 Detailed Description	126
	9.15	sim_interface_messages.cc File Reference	126
		9.15.1 Detailed Description	127
	9.16	sim_interface_messages.hh File Reference	127
		9.16.1 Detailed Description	127
	9.17	simulation_interface.cc File Reference	127

CONTENTS xvii

	9.17.1 Detailed Description	128
9.18	simulation_interface.hh File Reference	128
	9.18.1 Detailed Description	128
9.19	trick10_memory_interface.cc File Reference	128
	9.19.1 Detailed Description	129
9.20	trick10_memory_interface.hh File Reference	129
	9.20.1 Detailed Description	129
9.21	trick_dynbody_integ_loop.cc File Reference	130
	9.21.1 Detailed Description	130
9.22	trick_dynbody_integ_loop.hh File Reference	130
	9.22.1 Detailed Description	131
9.23	trick_memory_interface.cc File Reference	131
	9.23.1 Detailed Description	131
9.24	trick_memory_interface.hh File Reference	131
	9.24.1 Detailed Description	132
9.25	trick_memory_interface_alloc.cc File Reference	132
	9.25.1 Detailed Description	133
9.26	trick_memory_interface_attrib.cc File Reference	133
	9.26.1 Detailed Description	133
9.27	trick_memory_interface_chkpnt.cc File Reference	133
	9.27.1 Detailed Description	134
9.28	trick_memory_interface_xlate.cc File Reference	134
	9.28.1 Detailed Description	134
9.29	trick_message_handler.cc File Reference	135
	9.29.1 Detailed Description	135
9.30	trick_message_handler.hh File Reference	135
	9.30.1 Detailed Description	136
9.31	trick_sim_interface.cc File Reference	136
	9.31.1 Detailed Description	136
9.32	trick_sim_interface.hh File Reference	136
	9.32.1 Detailed Description	137

138

Index

Chapter 1

Module Index

1.1 Modules

Here is a list of all modules:	
Models	

Models	 ш
Utils	 12
SimInterface	 13

2 **Module Index**

Chapter 2

Namespace Index

2.1 Namespace List

Here is a list of all namespaces with brief descriptions:

er7_utils		
	Namespace er7_utils contains the state integration models used by JEOD	19
jeod		
	Namespace jeod	19
Trick		
	Namespace Trick furnishes several standard functions for use in the Trick environment	20

Namespace Index

Chapter 3

Hierarchical Index

3.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:	
, ,	21 30
	35
· · ·	40
IntegLoopScheduler	
jeod::JeodDynbodyIntegrationLoop	42
Integrator	
jeod::TrickJeodIntegrator	13
IntegratorInterface	
jeod::JeodIntegratorInterface	
jeod::JeodTrickIntegrator	74
std::ios_base	
std::basic_ios	
std::basic_istream	
std::istream	
jeod::SectionedInputStream	95
std::basic_ostream	
std::ostream	٠.
jeod::SectionedOutputStream	05
JeodIntegrationGroupOwner	4.0
jeod::JeodDynbodyIntegrationLoop	
jeod::JeodMemoryInterface	
jeod::JeodTrickMemoryInterface	
jeod::JeodTrick10MemoryInterface	
jeod::JeodSimulationInterface	58
jeod::BasicJeodTrickSimInterface	22
jeod::JeodTrickSimInterface	89
jeod::JeodSimulationInterfaceInit	65
jeod::CheckPointInputManager::SectionInfo	10
jeod::SimInterfaceMessages	11
streambuf	
jeod::SectionedInputBuffer	91
jeod::SectionedOutputBuffer	02
SuppressedCodeMessageHandler	
jeod::TrickMessageHandler	
jeod::TrickMessageHandlerMixin	16
jeod::JeodTrickSimInterface	89

6 **Hierarchical Index**

Chapter 4

Data Structure Index

4.1 Data Structures

	Here	are	the	data	structures	with	brief	descri	ptions
--	------	-----	-----	------	------------	------	-------	--------	--------

jeod::JeodTrickMemoryInterface::AllocationMapEntry	
Describes a chunk of JEOD-allocated memory	21
jeod::BasicJeodTrickSimInterface	
The BasicJeodTrickSimInterface implements the required capabilities of the generic Jeod-	
SimulationInterface in a Trick simulation environment	22
jeod::CheckPointInputManager	
A CheckPointInputManager provides tools for reading a checkpoint file	30
jeod::CheckPointOutputManager	
A CheckPointOutputManager provides the basic tools for writing a checkpoint file	35
jeod::JeodTrickMemoryInterface::ContainerListEntry	
Describes a Checkpointable object	40
jeod::JeodDynbodyIntegrationLoop	
A Trick::IntegLoopScheduler that provides the ability to integrate a collection of Trick::SimObject	
instances over time, with the sim objects capable of being moved from one integration loop to	
another during run time	42
jeod::JeodIntegratorInterface	
A JeodIntegratorInterface extends the ER7 IntegratorInterface with the concept of a pointer to	
the simulation engine's integration object	50
jeod::JeodMemoryInterface	
Abstract interface between the JEOD memory manager and the simulation engine	52
jeod::JeodSimulationInterface	
This abstract class defines the basis for the interface between JEOD and a simulation engine .	58
jeod::JeodSimulationInterfaceInit	
Define configuration data needed to configure the dynamically-created message handler and	
memory manager	65
jeod::JeodTrick10MemoryInterface	
A TrickMemoryInterface implements the two required methods needed to register and deregister	0-
memory with the simulation engine, Trick in this case	67
jeod::JeodTrickIntegrator	
A JeodTrickIntegrator specializes the JeodIntegratorInterface for use with Trick as the simulation	74
engine	74
jeod::JeodTrickMemoryInterface	
A TrickMemoryInterface implements the two required methods needed to register and deregister	70
memory with the simulation engine, Trick in this case jeod::JeodTrickSimInterface	78
•	
A JEODTrickSimInterface implements the required capabilities of the generic JeodSimulation-	90

8 Data Structure Index

jeod::SectionedInputBuffer	
A SectionedInputBuffer is a std::streambuf that reads from a section in a checkpoint file	91
jeod::SectionedInputStream	
A SectionedInputStream is a std::istream that reads from a section in a checkpoint file	95
jeod::SectionedOutputBuffer	
A SectionedOutputBuffer is a std::streambuf that writes a section of a checkpoint file	102
jeod::SectionedOutputStream	
A SectionedOutputStream is a std::ostream that writes a section of a checkpoint file	105
jeod::CheckPointInputManager::SectionInfo	
A SectionInfo contains the start and end positions of a checkpoint file section	110
jeod::SimInterfaceMessages	
Specifies the message IDs used in the sim_interface model	111
jeod::TrickJeodIntegrator	
A TrickJeodIntegrator specializes the Trick::Integrator to provide the Trick side of the integration	
interface between Trick and JEOD	113
jeod::TrickMessageHandler	
The MessageHandler class for designed for use in Trick-based simulations	114
jeod::TrickMessageHandlerMixin	
The TrickMessageHandlerMixin implements the required capabilities of the generic Jeod-	
SimulationInterface in a Trick simulation environment	116

Chapter 5

File Index

5.1 File List

Here is a list of all files with brief descriptions:

checkpoint_input_manager.cc	
Define CheckPointInputManager member functions and of related classes	119
checkpoint_input_manager.hh	
Define class CheckPointInputManager and related classes	119
checkpoint_output_manager.cc	
Define CheckPointOutputManager member functions and of related classes	120
checkpoint_output_manager.hh	
Define class CheckPointOutputManager and related classes	120
class_declarations.hh	
Forward declarations of classes defined in the utils/sim_interface model	121
config.hh	
Configure JEOD for use by some simulation engine	121
config_test_harness.hh	
Configure JEOD for use in standalone test mode	122
config_trick10.hh	400
Configure JEOD for use in a Trick10 environment	122
jeod_class.hh	
Define the JEOD class declaration macros JEOD_MAKE_SIM_INTERFACES and and JEODDECLARE_SIM_INTERFACES	123
jeod_integrator_interface.hh	
Define the interface for accessing / updating elements of a simulation engine's integrator object	123
jeod_trick_integrator.hh	
Define the interface for accessing / updating elements of a Trick simulation integrator object	124
memory_attributes.hh	
Define JEOD memory interface macros	124
memory_interface.cc	
Implement the MemoryInterface class	125
memory_interface.hh	
Define the MemoryInterface class, which abstractly defines the interface between the memory manager and the simulation engine	126
sim interface messages.cc	
Implement the class SimInterfaceMessages	126
sim_interface_messages.hh	
Define the class SimInterfaceMessages, the class that specifies the message IDs used in the	
sim interface model	127
simulation_interface.cc	
Implement SimulationInterface methods	127

10 File Index

simulation_interface.hh	
Define the abstract class JeodSimulationInterface	128
trick10_memory_interface.cc	
Define JeodTrickMemoryInterface methods	128
trick10_memory_interface.hh	
Define the interface for registering / deregistering memory with Trick	129
trick_dynbody_integ_loop.cc	
Define JeodDynbodyIntegrationLoop methods	130
trick_dynbody_integ_loop.hh	
Define the class IntegrationGroupIntegLoopScheduler, which replaces the base Trick integration	
loop for multi-rate JEOD-based simulations	130
trick_memory_interface.cc	
Define JeodTrickMemoryInterface methods	131
trick_memory_interface.hh	
Define the interface for registering / deregistering memory with Trick	131
trick_memory_interface_alloc.cc	
Define JeodTrickMemoryInterface methods related to allocation/deallocation	132
trick_memory_interface_attrib.cc	
Define JeodTrickMemoryInterface methods related to attributes	133
trick_memory_interface_chkpnt.cc	
Define JeodTrick10MemoryInterface methods related to checkpoint/restart	133
trick_memory_interface_xlate.cc	
Define JeodTrickMemoryInterface methods related to name translation	134
trick_message_handler.cc	
Define member functions for the class TrickMessageHandler	135
trick_message_handler.hh	
Define the class TrickMessageHandler, the message handler designed for use in Trick-based	
simulations	135
trick_sim_interface.cc	
Implement TrickSimInterface methods	136
trick_sim_interface.hh	
Define the class JeodTrickSimInterface	136

Chapter 6

Module Documentation

6.1 Models

Modules

• Utils

6.1.1 Detailed Description

12 Module Documentation

6.2 Utils

Modules

• SimInterface

6.2.1 Detailed Description

6.3 SimInterface 13

6.3 SimInterface

Files

· file checkpoint_input_manager.hh

Define class CheckPointInputManager and related classes.

· file checkpoint output manager.hh

Define class CheckPointOutputManager and related classes.

· file class_declarations.hh

Forward declarations of classes defined in the utils/sim_interface model.

· file config.hh

Configure JEOD for use by some simulation engine.

file config_test_harness.hh

Configure JEOD for use in standalone test mode.

file config trick10.hh

Configure JEOD for use in a Trick10 environment.

· file jeod_class.hh

Define the JEOD class declaration macros JEOD_MAKE_SIM_INTERFACES and and JEOD_DECLARE_SIM_INTERFACES.

· file jeod_integrator_interface.hh

Define the interface for accessing / updating elements of a simulation engine's integrator object.

• file jeod_trick_integrator.hh

Define the interface for accessing / updating elements of a Trick simulation integrator object.

· file memory_attributes.hh

Define JEOD memory interface macros.

· file memory interface.hh

Define the MemoryInterface class, which abstractly defines the interface between the memory manager and the simulation engine.

file sim_interface_messages.hh

Define the class SimInterfaceMessages, the class that specifies the message IDs used in the sim interface model.

· file simulation interface.hh

Define the abstract class JeodSimulationInterface.

file trick10_memory_interface.hh

Define the interface for registering / deregistering memory with Trick.

file trick_dynbody_integ_loop.hh

Define the class IntegrationGroupIntegLoopScheduler, which replaces the base Trick integration loop for multi-rate JEOD-based simulations.

· file trick memory interface.hh

Define the interface for registering / deregistering memory with Trick.

· file trick_message_handler.hh

Define the class TrickMessageHandler, the message handler designed for use in Trick-based simulations.

• file trick_sim_interface.hh

Define the class JeodTrickSimInterface.

file checkpoint_input_manager.cc

Define CheckPointInputManager member functions and of related classes.

file checkpoint_output_manager.cc

Define CheckPointOutputManager member functions and of related classes.

file memory_interface.cc

Implement the MemoryInterface class.

file sim_interface_messages.cc

Implement the class SimInterfaceMessages.

14 Module Documentation

· file simulation_interface.cc

Implement SimulationInterface methods.

file trick10_memory_interface.cc

Define JeodTrickMemoryInterface methods.

file trick_dynbody_integ_loop.cc

Define JeodDynbodyIntegrationLoop methods.

· file trick_memory_interface.cc

Define JeodTrickMemoryInterface methods.

file trick_memory_interface_alloc.cc

Define JeodTrickMemoryInterface methods related to allocation/deallocation.

• file trick_memory_interface_attrib.cc

Define JeodTrickMemoryInterface methods related to attributes.

file trick_memory_interface_chkpnt.cc

Define JeodTrick10MemoryInterface methods related to checkpoint/restart.

· file trick_memory_interface_xlate.cc

Define JeodTrickMemoryInterface methods related to name translation.

· file trick message handler.cc

Define member functions for the class TrickMessageHandler.

file trick_sim_interface.cc

Implement TrickSimInterface methods.

Namespaces

jeod

Namespace jeod.

Trick

Namespace Trick furnishes several standard functions for use in the Trick environment.

er7_utils

Namespace er7_utils contains the state integration models used by JEOD.

Macros

- #define JEOD UNUSED
- #define ER7 UTILS UNUSED
- #define ER7_UTILS_RESTRICT
- #define ER7_UTILS_ALWAYS_INLINE
- #define JEOD_ATTRIBUTES_TYPE int
- #define JEOD ATTRIBUTES POINTER TYPE void *
- #define JEOD_SIM_INTEGRATOR_POINTER_TYPE void *
- #define JEOD_SIZE_T size_t
- #define JEOD_PTRDIFF_T long int
- #define JEOD_INTPTR_T long int
- #define JEOD_UINTPTR_T unsigned long int
- #define JEOD_CLASS_ESTABLISH_FRIENDS(class_name)
- #define JEOD_ATTRIBUTES_SIM_ENGINE_HEADER "sim_services/MemoryManager/include/attributes.h"
- #define JEOD_ATTRIBUTES_TYPE struct ATTRIBUTES_tag
- #define JEOD_ATTRIBUTES_POINTER_TYPE JEOD_ATTRIBUTES_TYPE *
- #define JEOD_SIM_INTEGRATOR_SIM_ENGINE_HEADER "sim_services/Integrator/include/Integrator.hh"
- #define JEOD SIM INTEGRATOR FORWARD namespace Trick { class Integrator; }
- #define JEOD SIM INTEGRATOR POINTER TYPE Trick::Integrator *
- #define JEOD_SIM_INTEGRATOR_ENUM Integrator_type

6.3 SimInterface 15

#define JEOD_MAKE_SIM_INTERFACES(class_name) JEOD_CLASS_ESTABLISH_FRIENDS(class_name)

JEOD_MAKE_SIM_INTERFACES(class_name) Defines friends of the given class.

• #define JEOD_DECLARE_SIM_INTERFACES(class_name)

JEOD_DECLARE_SIM_INTERFACES(class_name) Forward declare classes and external functions needed to make the JEOD_MAKE_SIM_INTERFACES(class_name) expansion compilable.

- #define PATH "utils/sim_interface/"
- #define CLASS SimInterfaceMessages
- #define MAKE_MESSAGE_CODE(id) char const * CLASS::id = PATH #id
- #define MAX MSG SIZE 4096

Variables

- Trick::MemoryManager * trick MM
- Trick::Integrator * trick_curr_integ
- Trick::MemoryManager * trick MM
- Trick::MemoryManager * trick MM
- Trick::MemoryManager * trick_MM
- 6.3.1 Detailed Description
- 6.3.2 Macro Definition Documentation
- 6.3.2.1 #define CLASS SimInterfaceMessages

Definition at line 40 of file sim_interface_messages.cc.

6.3.2.2 #define ER7_UTILS_ALWAYS_INLINE

Definition at line 79 of file config.hh.

6.3.2.3 #define ER7 UTILS RESTRICT

Definition at line 74 of file config.hh.

6.3.2.4 #define ER7_UTILS_UNUSED

Definition at line 69 of file config.hh.

6.3.2.5 #define JEOD_ATTRIBUTES_POINTER_TYPE void *

Definition at line 45 of file config test harness.hh.

6.3.2.6 #define JEOD_ATTRIBUTES_POINTER_TYPE JEOD_ATTRIBUTES_TYPE *

Definition at line 58 of file config_trick10.hh.

6.3.2.7 #define JEOD_ATTRIBUTES_SIM_ENGINE_HEADER "sim_services/MemoryManager/include/attributes.h"

Definition at line 55 of file config_trick10.hh.

16 Module Documentation

6.3.2.8 #define JEOD_ATTRIBUTES_TYPE int

Definition at line 44 of file config_test_harness.hh.

6.3.2.9 #define JEOD_ATTRIBUTES_TYPE struct ATTRIBUTES_tag

Definition at line 57 of file config trick10.hh.

6.3.2.10 #define JEOD_CLASS_ESTABLISH_FRIENDS(class_name)

Value:

```
friend class InputProcessor; \
  friend void init_attrjeod__ ## class_name();
```

Definition at line 42 of file config trick10.hh.

6.3.2.11 #define JEOD_DECLARE_SIM_INTERFACES(class_name)

JEOD_DECLARE_SIM_INTERFACES(class_name) Forward declare classes and external functions needed to make the JEOD_MAKE_SIM_INTERFACES(class_name) expansion compilable.

All JEOD files that use JEOD_MAKE_SIM_INTERFACES within classes (will) make a parallel call to this macro at file scope in the global namespace.

Parameters

class_name	Name of the class defined later in the header in question.
------------	--

Definition at line 107 of file jeod_class.hh.

6.3.2.12 #define JEOD_INTPTR_T long int

Definition at line 33 of file config_trick10.hh.

6.3.2.13 #define JEOD_MAKE_SIM_INTERFACES(class_name) JEOD_CLASS_ESTABLISH_FRIENDS(class_name)

JEOD_MAKE_SIM_INTERFACES(class_name) Defines friends of the given class.

This macro is to be invoked in the body of all JEOD classes. The intent is to make all parts of the class visible to the designated simulation engine classes and functions.

Parameters

class_name	Name of the class being defined.

Definition at line 71 of file jeod_class.hh.

6.3.2.14 #define JEOD_PTRDIFF_T long int

Definition at line 32 of file config_trick10.hh.

6.3.2.15 #define JEOD_SIM_INTEGRATOR_ENUM Integrator_type

Definition at line 73 of file config_trick10.hh.

6.3 SimInterface 17

6.3.2.16 #define JEOD_SIM_INTEGRATOR_FORWARD namespace Trick { class Integrator; }

Definition at line 70 of file config_trick10.hh.

6.3.2.17 #define JEOD_SIM_INTEGRATOR_POINTER_TYPE void *

Definition at line 55 of file config_test_harness.hh.

6.3.2.18 #define JEOD_SIM_INTEGRATOR_POINTER_TYPE Trick::Integrator *

Definition at line 72 of file config trick10.hh.

6.3.2.19 #define JEOD_SIM_INTEGRATOR_SIM_ENGINE_HEADER "sim_services/Integrator/include/Integrator.hh"

Definition at line 68 of file config_trick10.hh.

6.3.2.20 #define JEOD_SIZE_T size_t

Definition at line 31 of file config_trick10.hh.

6.3.2.21 #define JEOD_UINTPTR_T unsigned long int

Definition at line 34 of file config_trick10.hh.

6.3.2.22 #define JEOD_UNUSED

Definition at line 64 of file config.hh.

6.3.2.23 #define MAKE_MESSAGE_CODE(id) char const * CLASS::id = PATH #id

Definition at line 41 of file sim_interface_messages.cc.

6.3.2.24 #define MAX_MSG_SIZE 4096

Definition at line 50 of file trick_message_handler.cc.

 $Referenced\ by\ jeod:: Trick Message Handler:: process_message().$

6.3.2.25 #define PATH "utils/sim_interface/"

Definition at line 39 of file sim_interface_messages.cc.

6.3.3 Variable Documentation

6.3.3.1 Trick::Integrator* trick_curr_integ

Referenced by jeod::JeodDynbodyIntegrationLoop::integrate_dt().

18 Module Documentation

- 6.3.3.2 Trick::MemoryManager* trick_MM
- 6.3.3.3 Trick::MemoryManager* trick_MM
- 6.3.3.4 Trick::MemoryManager* trick_MM
- 6.3.3.5 Trick::MemoryManager* trick_MM

 $Referenced\ by\ jeod:: JeodTrickMemoryInterface:: deregister_allocation(),\ jeod:: JeodTrick10MemoryInterface:: JeodTrick10MemoryI$

Chapter 7

Namespace Documentation

7.1 er7_utils Namespace Reference

Namespace er7 utils contains the state integration models used by JEOD.

7.1.1 Detailed Description

Namespace er7_utils contains the state integration models used by JEOD.

7.2 jeod Namespace Reference

Namespace jeod.

Data Structures

- · class SectionedInputBuffer
 - A SectionedInputBuffer is a std::streambuf that reads from a section in a checkpoint file.
- · class SectionedInputStream
 - A SectionedInputStream is a std::istream that reads from a section in a checkpoint file.
- class CheckPointInputManager
 - A CheckPointInputManager provides tools for reading a checkpoint file.
- class SectionedOutputBuffer
 - A SectionedOutputBuffer is a std::streambuf that writes a section of a checkpoint file.
- class SectionedOutputStream
 - A SectionedOutputStream is a std::ostream that writes a section of a checkpoint file.
- class CheckPointOutputManager
 - A CheckPointOutputManager provides the basic tools for writing a checkpoint file.
- · class JeodIntegratorInterface
 - A JeodIntegratorInterface extends the ER7 IntegratorInterface with the concept of a pointer to the simulation engine's integration object.
- · class TrickJeodIntegrator
 - A TrickJeodIntegrator specializes the Trick::Integrator to provide the Trick side of the integration interface between Trick and JEOD.
- · class JeodTrickIntegrator
 - A JeodTrickIntegrator specializes the JeodIntegratorInterface for use with Trick as the simulation engine.
- · class JeodMemoryInterface

Abstract interface between the JEOD memory manager and the simulation engine.

• class SimInterfaceMessages

Specifies the message IDs used in the sim interface model.

· class JeodSimulationInterfaceInit

Define configuration data needed to configure the dynamically-created message handler and memory manager.

· class JeodSimulationInterface

This abstract class defines the basis for the interface between JEOD and a simulation engine.

class JeodTrick10MemoryInterface

A TrickMemoryInterface implements the two required methods needed to register and deregister memory with the simulation engine, Trick in this case.

class JeodDynbodyIntegrationLoop

A Trick::IntegLoopScheduler that provides the ability to integrate a collection of Trick::SimObject instances over time, with the sim objects capable of being moved from one integration loop to another during run time.

class JeodTrickMemoryInterface

A TrickMemoryInterface implements the two required methods needed to register and deregister memory with the simulation engine, Trick in this case.

· class TrickMessageHandler

The MessageHandler class for designed for use in Trick-based simulations.

class BasicJeodTrickSimInterface

The BasicJeodTrickSimInterface implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

class TrickMessageHandlerMixin

The TrickMessageHandlerMixin implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

· class JeodTrickSimInterface

A JEODTrickSimInterface implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

7.2.1 Detailed Description

Namespace jeod.

7.3 Trick Namespace Reference

Namespace Trick furnishes several standard functions for use in the Trick environment.

7.3.1 Detailed Description

Namespace Trick furnishes several standard functions for use in the Trick environment.

Chapter 8

Data Structure Documentation

8.1 jeod::JeodTrickMemoryInterface::AllocationMapEntry Struct Reference

Describes a chunk of JEOD-allocated memory.

```
#include <trick_memory_interface.hh>
```

Public Member Functions

AllocationMapEntry (const std::type_info &type_info, uint32_t nelem, bool arrayp)
 Construct an AllocationMapEntry object.

Data Fields

- const std::type_info & typeid_info
- Descriptor of the data type.

 uint32_t nelements

The number of elements in the allocated chunk of memory.

bool is_array

Is the item an array or a single object?

8.1.1 Detailed Description

Describes a chunk of JEOD-allocated memory.

Definition at line 263 of file trick_memory_interface.hh.

8.1.2 Constructor & Destructor Documentation

8.1.2.1 jeod::JeodTrickMemoryInterface::AllocationMapEntry::AllocationMapEntry (const std::type_info & type_info, uint32_t nelem, bool arrayp) [inline]

Construct an AllocationMapEntry object.

Parameters

type_info	Type info
nelem	Array size
arrayp	Is item an array?

Definition at line 286 of file trick_memory_interface.hh.

8.1.3 Field Documentation

8.1.3.1 bool jeod::JeodTrickMemoryInterface::AllocationMapEntry::is_array

Is the item an array or a single object?

trick_units(-)

Definition at line 278 of file trick_memory_interface.hh.

Referenced by jeod::JeodTrick10MemoryInterface::checkpoint_allocations().

8.1.3.2 uint32_t jeod::JeodTrickMemoryInterface::AllocationMapEntry::nelements

The number of elements in the allocated chunk of memory.

trick_units(-)

Definition at line 273 of file trick_memory_interface.hh.

Referenced by jeod::JeodTrick10MemoryInterface::checkpoint_allocations().

8.1.3.3 const std::type_info& jeod::JeodTrickMemoryInterface::AllocationMapEntry::typeid_info

Descriptor of the data type.

trick_units(-)

Definition at line 268 of file trick_memory_interface.hh.

Referenced by jeod::JeodTrick10MemoryInterface::checkpoint_allocations().

The documentation for this struct was generated from the following file:


• trick_memory_interface.hh

8.2 jeod::BasicJeodTrickSimInterface Class Reference

The BasicJeodTrickSimInterface implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

#include <trick_sim_interface.hh>

Inheritance diagram for jeod::BasicJeodTrickSimInterface:



Public Member Functions

BasicJeodTrickSimInterface (MessageHandler &message handler)

Construct a BasicJeodTrickSimInterface object.

virtual ~BasicJeodTrickSimInterface ()

Destroy a BasicJeodTrickSimInterface object.

void set_checkpoint_file_name (std::string name)

Set the checkpoint file name.

std::string get checkpoint file name () const

Get the checkpoint file name.

virtual void set_mode (JeodSimulationInterface::Mode new_mode)

Set the mode.

void checkpoint_allocations (void)

Dump the allocation information to the checkpoint file.

void restore_allocations (void)

Restore the allocated data per the checkpoint file.

void checkpoint_containers (void)

Dump the container objects to the checkpoint file.

void restore containers (void)

Restore the container objects from the checkpoint file.

void open_checkpoint_file (void)

Open the checkpoint output file.

void close_checkpoint_file (void)

Close the checkpoint output file.

· void open_restart_file (void)

Open the checkpoint input file.

void close_restart_file (void)

Close the checkpoint input file.

Protected Member Functions

virtual JeodIntegratorInterface * create_integrator_internal (void)

Create an integration interface object.

virtual double get_job_cycle_internal (void)

Get the current job's cycle time.

virtual JeodMemoryInterface & get_memory_interface_internal (void)

Get the memory interface.

virtual SectionedInputStream get_checkpoint_reader_internal (const std::string §ion_id)

Get a reader to a section of the currently open checkpoint file.

virtual SectionedOutputStream get_checkpoint_writer_internal (const std::string §ion_id)

Get a writer to a section of the currently open checkpoint file.

Protected Attributes

· MessageHandler & generic message handler

The global MessageHandler.

JeodTrick10MemoryInterface trick_memory_interface

The interface between JEOD and Trick's memory management schemes.

• JeodMemoryManager memory_manager

The global JEOD memory manager.

· std::string checkpoint_file_name

The name of the segmented checkpoint file used for the next checkpoint / restart action.

• std::string section_start

String indicating the start of a checkpoint file section.

· std::string section end

String indicating the end of a checkpoint file section.

CheckPointInputManager * checkpoint_reader

The object that manages reading from a checkpoint file.

CheckPointOutputManager * checkpoint_writer

The object that manages writing to a checkpoint file.

Private Member Functions

BasicJeodTrickSimInterface (const BasicJeodTrickSimInterface &)

Not implemented.

• BasicJeodTrickSimInterface & operator= (const BasicJeodTrickSimInterface &)

Not implemented.

Friends

- · class InputProcessor
- void init_attrjeod__BasicJeodTrickSimInterface ()

Additional Inherited Members

8.2.1 Detailed Description

The BasicJeodTrickSimInterface implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

By virtue of member data ownership, the class creates the requisite MessageHandler and MemoryManager and does so in the correct order.

Definition at line 57 of file trick sim interface.hh.

8.2.2 Constructor & Destructor Documentation

8.2.2.1 jeod::BasicJeodTrickSimInterface::BasicJeodTrickSimInterface (MessageHandler & message_handler)

[explicit]

Construct a BasicJeodTrickSimInterface object.

Parameters

in,out	message	handler
	handler	Units: Message

Definition at line 66 of file trick_sim_interface.cc.

References generic_message_handler, section_end, and section_start.

8.2.2.2 jeod::BasicJeodTrickSimInterface::~BasicJeodTrickSimInterface (void) [virtual]

Destroy a BasicJeodTrickSimInterface object.

Definition at line 102 of file trick_sim_interface.cc.

References checkpoint reader, and checkpoint writer.

8.2.2.3 jeod::BasicJeodTrickSimInterface::BasicJeodTrickSimInterface (const BasicJeodTrickSimInterface &)
[private]

Not implemented.

8.2.3 Member Function Documentation

8.2.3.1 void jeod::BasicJeodTrickSimInterface::checkpoint_allocations (void)

Dump the allocation information to the checkpoint file.

Definition at line 325 of file trick sim interface.cc.

References jeod::JeodTrick10MemoryInterface::checkpoint_allocations(), jeod::JeodTrick10MemoryInterface::is_checkpoint_restart_supported(), and trick_memory_interface.

8.2.3.2 void jeod::BasicJeodTrickSimInterface::checkpoint_containers (void)

Dump the container objects to the checkpoint file.

Definition at line 351 of file trick_sim_interface.cc.

 $References\ jeod:: JeodTrick10 MemoryInterface:: checkpoint_containers(),\ jeod:: JeodTrick10 MemoryInterface:: is_checkpoint_restart_supported(),\ and\ trick_memory_interface.$

8.2.3.3 void jeod::BasicJeodTrickSimInterface::close_checkpoint_file (void)

Close the checkpoint output file.

Definition at line 238 of file trick_sim_interface.cc.

References checkpoint writer.

8.2.3.4 void jeod::BasicJeodTrickSimInterface::close_restart_file (void)

Close the checkpoint input file.

Definition at line 311 of file trick_sim_interface.cc.

References checkpoint_reader.

8.2.3.5 JeodIntegratorInterface * jeod::BasicJeodTrickSimInterface::create_integrator_internal (void) [protected], [virtual]

Create an integration interface object.

Returns

Integrator interface that encapsulates an sim engine integrator.

Implements jeod::JeodSimulationInterface.

Definition at line 144 of file trick_sim_interface.cc.

8.2.3.6 std::string jeod::BasicJeodTrickSimInterface::get_checkpoint_file_name() const [inline]

Get the checkpoint file name.

Definition at line 78 of file trick_sim_interface.hh.

References checkpoint_file_name.

8.2.3.7 SectionedInputStream jeod::BasicJeodTrickSimInterface::get_checkpoint_reader_internal (const std::string & section_id) [protected], [virtual]

Get a reader to a section of the currently open checkpoint file.

Returns

Checkpoint reader

Parameters

in	section_id	Section name

Implements jeod::JeodSimulationInterface.

Definition at line 292 of file trick_sim_interface.cc.

References checkpoint_reader, jeod::CheckPointInputManager::create_section_reader(), and jeod::SimInterface-Messages::phasing error.

8.2.3.8 SectionedOutputStream jeod::BasicJeodTrickSimInterface::get_checkpoint_writer_internal (const std::string & section_id) [protected], [virtual]

Get a writer to a section of the currently open checkpoint file.

Returns

Checkpoint writer

Parameters

in	section_id	Section name

Implements jeod::JeodSimulationInterface.

Definition at line 219 of file trick_sim_interface.cc.

References checkpoint_writer, jeod::CheckPointOutputManager::create_section_writer(), and jeod::SimInterface-Messages::phasing_error.

8.2.3.9 double jeod::BasicJeodTrickSimInterface::get_job_cycle_internal (void) [protected], [virtual]

Get the current job's cycle time.

Returns

Current job's cycle time

Implements jeod::JeodSimulationInterface.

Definition at line 156 of file trick_sim_interface.cc.

8.2.3.10 JeodMemoryInterface & jeod::BasicJeodTrickSimInterface::get_memory_interface_internal (void) [protected], [virtual]

Get the memory interface.

Returns

Memory interface

Implements jeod::JeodSimulationInterface.

Definition at line 168 of file trick_sim_interface.cc.

References trick_memory_interface.

8.2.3.11 void jeod::BasicJeodTrickSimInterface::open_checkpoint_file (void)

Open the checkpoint output file.

Definition at line 179 of file trick_sim_interface.cc.

References checkpoint_file_name, checkpoint_writer, jeod::JeodTrick10MemoryInterface::get_trick_checkpoint_file(), jeod::JeodTrick10MemoryInterface::is_checkpoint_restart_supported(), section_end, section_start, and trick_memory_interface.

8.2.3.12 void jeod::BasicJeodTrickSimInterface::open_restart_file (void)

Open the checkpoint input file.

Definition at line 252 of file trick_sim_interface.cc.

References checkpoint_file_name, checkpoint_reader, jeod::JeodTrick10MemoryInterface::get_trick_checkpoint_file(), jeod::JeodTrick10MemoryInterface::is_checkpoint_restart_supported(), section_end, section_start, and trick_memory_interface.

8.2.3.13 BasicJeodTrickSimInterface& jeod::BasicJeodTrickSimInterface::operator= (const BasicJeodTrickSimInterface &) [private]

Not implemented.

8.2.3.14 void jeod::BasicJeodTrickSimInterface::restore_allocations (void)

Restore the allocated data per the checkpoint file.

Definition at line 338 of file trick_sim_interface.cc.

References jeod::JeodTrick10MemoryInterface::is_checkpoint_restart_supported(), memory_manager, jeod::Jeod-Trick10MemoryInterface::restore_allocations(), and trick_memory_interface.

8.2.3.15 void jeod::BasicJeodTrickSimInterface::restore_containers (void)

Restore the container objects from the checkpoint file.

Definition at line 364 of file trick sim interface.cc.

References jeod::JeodTrick10MemoryInterface::is_checkpoint_restart_supported(), jeod::JeodTrick10MemoryInterface::restore_containers(), and trick_memory_interface.

8.2.3.16 void jeod::BasicJeodTrickSimInterface::set_checkpoint_file_name(std::string name) [inline]

Set the checkpoint file name.

Definition at line 72 of file trick_sim_interface.hh.

References checkpoint file name.

8.2.3.17 void jeod::BasicJeodTrickSimInterface::set_mode (JeodSimulationInterface::Mode new_mode)
[virtual]

Set the mode.

Assumptions and Limitations

· See SimulationInterface::set mode.

Parameters

		AL I
ın	new_mode	New mode.

Reimplemented from jeod::JeodSimulationInterface.

Definition at line 125 of file trick_sim_interface.cc.

References jeod::JeodSimulationInterface::get_mode(), memory_manager, jeod::JeodTrickMemoryInterface::set_mode(), jeod::JeodSimulationInterface::set_mode(), and trick_memory_interface.

8.2.4 Friends And Related Function Documentation

```
8.2.4.1 void init_attrjeod_BasicJeodTrickSimInterface() [friend]
```

8.2.4.2 friend class InputProcessor [friend]

Definition at line 58 of file trick_sim_interface.hh.

8.2.5 Field Documentation

8.2.5.1 std::string jeod::BasicJeodTrickSimInterface::checkpoint_file_name [protected]

The name of the segmented checkpoint file used for the next checkpoint / restart action.

If the name is the empty string (default), the checkpoint / restart mechanisms will attempt to construct a name from the corresponding Trick checkpoint file name.trick units(-)

Definition at line 168 of file trick_sim_interface.hh.

Referenced by get_checkpoint_file_name(), open_checkpoint_file(), open_restart_file(), and set_checkpoint_file_name().

8.2.5.2 CheckPointInputManager* jeod::BasicJeodTrickSimInterface::checkpoint_reader [protected]

The object that manages reading from a checkpoint file.

trick_io(**)

Definition at line 183 of file trick sim interface.hh.

Referenced by close_restart_file(), get_checkpoint_reader_internal(), open_restart_file(), and \sim BasicJeodTrick-SimInterface().

8.2.5.3 CheckPointOutputManager* jeod::BasicJeodTrickSimInterface::checkpoint_writer [protected]

The object that manages writing to a checkpoint file.

trick_io(**)

Definition at line 188 of file trick_sim_interface.hh.

Referenced by close_checkpoint_file(), get_checkpoint_writer_internal(), open_checkpoint_file(), and \sim BasicJeod-TrickSimInterface().

8.2.5.4 MessageHandler& jeod::BasicJeodTrickSimInterface::generic message handler [protected]

The global MessageHandler.

trick_units(-)

Definition at line 149 of file trick_sim_interface.hh.

Referenced by BasicJeodTrickSimInterface().

8.2.5.5 JeodMemoryManager jeod::BasicJeodTrickSimInterface::memory_manager [protected]

The global JEOD memory manager.

trick_units(-)

Definition at line 159 of file trick_sim_interface.hh.

Referenced by restore allocations(), and set mode().

8.2.5.6 std::string jeod::BasicJeodTrickSimInterface::section_end [protected]

String indicating the end of a checkpoint file section.

trick_io(*o) trick_units(-)

Definition at line 178 of file trick_sim_interface.hh.

Referenced by BasicJeodTrickSimInterface(), open_checkpoint_file(), and open_restart_file().

8.2.5.7 std::string jeod::BasicJeodTrickSimInterface::section_start [protected]

String indicating the start of a checkpoint file section.

trick_io(*o) trick_units(-)

Definition at line 173 of file trick_sim_interface.hh.

Referenced by BasicJeodTrickSimInterface(), open_checkpoint_file(), and open_restart_file().

8.2.5.8 JeodTrick10MemoryInterface jeod::BasicJeodTrickSimInterface::trick_memory_interface [protected]

The interface between JEOD and Trick's memory management schemes.

trick_units(-)

Definition at line 154 of file trick sim interface.hh.

Referenced by checkpoint_allocations(), checkpoint_containers(), get_memory_interface_internal(), open_checkpoint_file(), open_restart_file(), restore_allocations(), restore_containers(), and set_mode().

The documentation for this class was generated from the following files:

- · trick sim interface.hh
- trick_sim_interface.cc

8.3 jeod::CheckPointInputManager Class Reference

A CheckPointInputManager provides tools for reading a checkpoint file.

#include <checkpoint_input_manager.hh>

Data Structures

struct SectionInfo

A SectionInfo contains the start and end positions of a checkpoint file section.

Public Member Functions

CheckPointInputManager (const std::string &fname, const std::string &start_marker, const std::string &end_marker)

Construct a CheckPointInputManager object.

SectionedInputStream create section reader (const std::string &tag)

Create a C++ input stream that reads from a checkpoint file section.

• bool operator! () const

Conversion to boolean.

· bool have_active_reader () const

Is there an active checkpoint section reader?

bool register_reader (SectionedInputStream *reader)

Register the supplied section reader as the currently-active reader.

 $\bullet \ \ bool\ deregister_reader\ (SectionedInputStream\ *reader)$

Deregister the supplied section reader as the currently-active reader.

Private Member Functions

· void initialize (void)

Determine the locations of the various sections that comprise the file.

• SectionedInputStream create_section_reader (bool trick, const std::string &tag)

Create a C++ input stream that reads from a checkpoint file section.

• SectionedInputStream create_trick_section_reader ()

Create a C++ input stream that reads from the Trick checkpoint file section.

CheckPointInputManager (const CheckPointInputManager &)

Not implemented.

• CheckPointInputManager & operator= (const CheckPointInputManager &)

Not implemented.

Private Attributes

std::map< std::string,
 SectionInfo > sections

Maps section names to section start/end positions.

• std::ifstream stream

The C++ file stream that reads the checkpoint file.

• SectionedInputStream * current_reader

The reader that currently is active.

const std::string filename

The name of the checkpoint file.

const std::string & section_start

The string that indicates the start of a checkpoint file section.

· const std::string & section_end

The string that indicates the start of a checkpoint file section.

bool is open

Is the checkpoint file open?

8.3.1 Detailed Description

A CheckPointInputManager provides tools for reading a checkpoint file.

A Trick 10 checkpoint file comprises multiple sections delineated by section markers. This class recognizes those markers and generates C++ input streams that other objects can use to read the contents of one of those checkpoint file sections. The interpretation of the contents of a checkpoint file section is the responsibility of those other objects.

Definition at line 383 of file checkpoint_input_manager.hh.

8.3.2 Constructor & Destructor Documentation

8.3.2.1 jeod::CheckPointInputManager::CheckPointInputManager (const std::string & *fname*, const std::string & *start_marker*, const std::string & *end_marker*)

Construct a CheckPointInputManager object.

Parameters

in	fname	Name of file to be opened
in	start_marker	Start of section marker
in	end_marker	End of section marker

Definition at line 317 of file checkpoint_input_manager.cc.

References filename, jeod::SimInterfaceMessages::implementation_error, initialize(), is_open, and stream.

8.3.2.2 jeod::CheckPointInputManager::CheckPointInputManager (const CheckPointInputManager &) [private]

Not implemented.

8.3.3 Member Function Documentation

8.3.3.1 SectionedInputStream jeod::CheckPointInputManager::create_section_reader (const std::string & tag)
[inline]

Create a C++ input stream that reads from a checkpoint file section.

Error handling

A null SectionedInputStream is created when the CheckPointInputManager itself is invalid or when the designated section is not present in the checkpoint file.

Parameters

tag	Tag that identifies the section to be read.
-----	---

Returns

A SectionedInputStream object, which must be used to initialize a local SectionedInputStream variable.

Definition at line 402 of file checkpoint input manager.hh.

Referenced by create_trick_section_reader(), and jeod::BasicJeodTrickSimInterface::get_checkpoint_reader_internal().

8.3.3.2 SectionedInputStream jeod::CheckPointInputManager::create_section_reader (bool *trick*, const std::string & *tag*)

[private]

Create a C++ input stream that reads from a checkpoint file section.

Usage

Use this function as the initializer of a section reader variable.

Error handling

A null SectionedInputStream is created when the CheckPointInputManager itself is invalid or when the designated section is not present in the checkpoint file.

Returns

A SectionedInputStream object.

Parameters

in	trick	OK to create the Trick section reader?
in	tag	Tag identifying the section to be read.

Definition at line 427 of file checkpoint_input_manager.cc.

References jeod::CheckPointInputManager::SectionInfo::end_pos, filename, jeod::SimInterfaceMessages::implementation_error, is_open, sections, jeod::CheckPointInputManager::SectionInfo::start_pos, and stream.

8.3.3.3 SectionedInputStream jeod::CheckPointInputManager::create_trick_section_reader(void) [private]

Create a C++ input stream that reads from the Trick checkpoint file section.

Returns

Trick SectionedInputStream object.

Definition at line 470 of file checkpoint input manager.cc.

References create_section_reader(), current_reader, and jeod::SectionedInputStream::deactivate().

8.3.3.4 bool jeod::CheckPointInputManager::deregister_reader (SectionedInputStream * reader)

Deregister the supplied section reader as the currently-active reader.

Returns

True => success.

Parameters

in	reader	Reader to be deregistered

Definition at line 507 of file checkpoint_input_manager.cc.

References current_reader.

Referenced by jeod::SectionedInputStream::deactivate(), and jeod::SectionedInputStream::~SectionedInputStream().

8.3.3.5 bool jeod::CheckPointInputManager::have_active_reader() const [inline]

Is there an active checkpoint section reader?

Returns

True if there is an active reader, false otherwise.

Definition at line 418 of file checkpoint_input_manager.hh.

References current_reader.

Referenced by jeod::SectionedInputStream::is_activatable().

8.3.3.6 void jeod::CheckPointInputManager::initialize (void) [private]

Determine the locations of the various sections that comprise the file.

Definition at line 347 of file checkpoint_input_manager.cc.

References filename, jeod::SimInterfaceMessages::implementation_error, section_end, section_start, sections, and stream.

Referenced by CheckPointInputManager().

8.3.3.7 bool jeod::CheckPointInputManager::operator! () const [inline]

Conversion to boolean.

Returns

False if object is OK.

Definition at line 410 of file checkpoint_input_manager.hh.

References is_open, and stream.

8.3.3.8 CheckPointInputManager& jeod::CheckPointInputManager::operator=(const CheckPointInputManager &)

[private]

Not implemented.

8.3.3.9 bool jeod::CheckPointInputManager::register_reader (SectionedInputStream * reader)

Register the supplied section reader as the currently-active reader.

Returns

True => success.

Parameters

in	reader	Reader to be registered

Definition at line 488 of file checkpoint_input_manager.cc.

References current reader.

Referenced by jeod::SectionedInputStream::activate().

8.3.4 Field Documentation

8.3.4.1 SectionedInputStream* jeod::CheckPointInputManager::current_reader [private]

The reader that currently is active.

trick io(**)

Definition at line 488 of file checkpoint_input_manager.hh.

Referenced by create_trick_section_reader(), deregister_reader(), have_active_reader(), and register_reader().

8.3.4.2 const std::string jeod::CheckPointInputManager::filename [private]

The name of the checkpoint file.

trick io(**)

Definition at line 493 of file checkpoint_input_manager.hh.

Referenced by CheckPointInputManager(), create section reader(), and initialize().

8.3.4.3 bool jeod::CheckPointInputManager::is_open [private]

Is the checkpoint file open?

trick_io(**)

Definition at line 508 of file checkpoint_input_manager.hh.

Referenced by CheckPointInputManager(), create_section_reader(), and operator!().

8.3.4.4 const std::string& jeod::CheckPointInputManager::section_end [private]

The string that indicates the start of a checkpoint file section.

trick_io(**)

Definition at line 503 of file checkpoint_input_manager.hh.

Referenced by initialize().

8.3.4.5 const std::string& jeod::CheckPointInputManager::section_start [private]

The string that indicates the start of a checkpoint file section.

```
trick_io(**)
```

Definition at line 498 of file checkpoint input manager.hh.

Referenced by initialize().

8.3.4.6 std::map<std::string, SectionInfo> jeod::CheckPointInputManager::sections [private]

Maps section names to section start/end positions.

trick_io(**)

Definition at line 478 of file checkpoint_input_manager.hh.

Referenced by create_section_reader(), and initialize().

8.3.4.7 std::ifstream jeod::CheckPointInputManager::stream [private]

The C++ file stream that reads the checkpoint file.

trick_io(**)

Definition at line 483 of file checkpoint_input_manager.hh.

Referenced by CheckPointInputManager(), create_section_reader(), initialize(), and operator!().

The documentation for this class was generated from the following files:

- · checkpoint_input_manager.hh
- · checkpoint_input_manager.cc

8.4 jeod::CheckPointOutputManager Class Reference

A CheckPointOutputManager provides the basic tools for writing a checkpoint file.

```
#include <checkpoint_output_manager.hh>
```

Public Member Functions

CheckPointOutputManager (const std::string &fname, const std::string &start_marker, const std::string &end-marker)

Construct a CheckPointOutputManager object.

• SectionedOutputStream create_section_writer (const std::string &tag)

Create a C++ output stream that writes a checkpoint file section.

• bool operator! () const

Conversion to boolean.

• bool have_active_writer () const

Is there an active checkpoint section writer?

• bool register_writer (SectionedOutputStream *writer)

Register the supplied section writer as the currently-active writer.

bool deregister_writer (SectionedOutputStream *writer)

Deregister the supplied section writer as the currently-active writer.

Private Member Functions

SectionedOutputStream create section writer (bool trick, const std::string &tag)

Create a C++ output stream that writes to a checkpoint file section.

SectionedOutputStream create_trick_section_writer ()

Create a C++ output stream that writes a Trick checkpoint file section.

CheckPointOutputManager (const CheckPointOutputManager &)

Not implemented.

• CheckPointOutputManager & operator= (const CheckPointOutputManager &)

Not implemented.

Private Attributes

• std::ofstream stream

The C++ file stream that writes to the checkpoint file.

SectionedOutputStream * current writer

The writer that currently is active.

const std::string filename

The name of the checkpoint file.

const std::string & section_start

The string that indicates the start of a checkpoint file section.

· const std::string & section_end

The string that indicates the start of a checkpoint file section.

bool is_open

Is the checkpoint file open?

Friends

· class MemoryManagerWrapper

8.4.1 Detailed Description

A CheckPointOutputManager provides the basic tools for writing a checkpoint file.

Section markers split a Trick 10 checkpoint file into multiple parts. This class generates C++ output streams that write the section markers and that other objects can use to write checkpoint file section data.

Definition at line 243 of file checkpoint output manager.hh.

8.4.2 Constructor & Destructor Documentation

8.4.2.1 jeod::CheckPointOutputManager::CheckPointOutputManager (const std::string & fname, const std::string & start_marker, const std::string & end_marker)

Construct a CheckPointOutputManager object.

Parameters

in	fname	Name of file to be opened

in	start_marker	Start of section marker
in	end_marker	End of section marker

Definition at line 321 of file checkpoint_output_manager.cc.

References filename, jeod::SimInterfaceMessages::implementation_error, is_open, and stream.

8.4.2.2 jeod::CheckPointOutputManager::CheckPointOutputManager (const CheckPointOutputManager &) [private]

Not implemented.

8.4.3 Member Function Documentation

8.4.3.1 SectionedOutputStream jeod::CheckPointOutputManager::create_section_writer (const std::string & tag) [inline]

Create a C++ output stream that writes a checkpoint file section.

Returns

Constructed SectionedOutputStream.

Definition at line 257 of file checkpoint_output_manager.hh.

Referenced by create_trick_section_writer(), and jeod::BasicJeodTrickSimInterface::get_checkpoint_writer_internal().

8.4.3.2 SectionedOutputStream jeod::CheckPointOutputManager::create_section_writer(bool *trick*, const std::string & tag) [private]

Create a C++ output stream that writes to a checkpoint file section.

Usage

Use this function as the initializer of a section writer variable.

Error handling

A null SectionedOutputStream is created when the CheckPointOutputManager itself is invalid or the designated section is invalid.

Returns

A SectionedOutputStream object.

Parameters

in	trick	OK to create the Trick section writer?
in	tag	Tag identifying the section to be written.

Definition at line 355 of file checkpoint_output_manager.cc.

References filename, jeod::SimInterfaceMessages::implementation_error, is_open, section_end, section_start, and stream.

8.4.3.3 SectionedOutputStream jeod::CheckPointOutputManager::create_trick_section_writer(void) [private]

Create a C++ output stream that writes a Trick checkpoint file section.

Create a C++ output stream that writes to the Trick checkpoint file section.

Returns

A SectionedOutputStream object, which must be used to initialize a local SectionedOutputStream variable. Trick SectionedOutputStream object.

Definition at line 388 of file checkpoint_output_manager.cc.

References create_section_writer(), current_writer, and jeod::SectionedOutputStream::deactivate().

8.4.3.4 bool jeod::CheckPointOutputManager::deregister_writer (SectionedOutputStream * writer)

Deregister the supplied section writer as the currently-active writer.

Returns

True => success.

Parameters

in	writer	Writer to be deregistered

Definition at line 425 of file checkpoint_output_manager.cc.

References current writer.

Referenced by jeod::SectionedOutputStream::deactivate().

8.4.3.5 bool jeod::CheckPointOutputManager::have_active_writer() const [inline]

Is there an active checkpoint section writer?

Returns

True if there is an active writer, false otherwise.

Definition at line 273 of file checkpoint_output_manager.hh.

References current_writer.

Referenced by jeod::SectionedOutputStream::is_activatable().

8.4.3.6 bool jeod::CheckPointOutputManager::operator! () const [inline]

Conversion to boolean.

Returns

False if object is OK.

Definition at line 265 of file checkpoint_output_manager.hh.

References is_open, and stream.

8.4.3.7 CheckPointOutputManager&jeod::CheckPointOutputManager::operator=(const CheckPointOutputManager &) [private]

Not implemented.

8.4.3.8 bool jeod::CheckPointOutputManager::register_writer (SectionedOutputStream * writer)

Register the supplied section writer as the currently-active writer.

Returns

True => success.

Parameters

in	writer	Writer to be Registered
		•

Definition at line 406 of file checkpoint_output_manager.cc.

References current writer.

Referenced by jeod::SectionedOutputStream::activate().

8.4.4 Friends And Related Function Documentation

8.4.4.1 friend class MemoryManagerWrapper [friend]

Definition at line 244 of file checkpoint_output_manager.hh.

8.4.5 Field Documentation

8.4.5.1 SectionedOutputStream*jeod::CheckPointOutputManager::current_writer [private]

The writer that currently is active.

trick io(**)

Definition at line 309 of file checkpoint_output_manager.hh.

Referenced by create trick_section_writer(), deregister_writer(), have_active_writer(), and register_writer().

8.4.5.2 const std::string jeod::CheckPointOutputManager::filename [private]

The name of the checkpoint file.

trick io(**)

Definition at line 314 of file checkpoint_output_manager.hh.

Referenced by CheckPointOutputManager(), and create_section_writer().

8.4.5.3 bool jeod::CheckPointOutputManager::is_open [private]

Is the checkpoint file open?

trick_io(**)

Definition at line 329 of file checkpoint_output_manager.hh.

Referenced by CheckPointOutputManager(), create_section_writer(), and operator!().

8.4.5.4 const std::string& jeod::CheckPointOutputManager::section_end [private]

The string that indicates the start of a checkpoint file section.

trick_io(**)

Definition at line 324 of file checkpoint_output_manager.hh.

Referenced by create section writer().

8.4.5.5 const std::string& jeod::CheckPointOutputManager::section_start [private]

The string that indicates the start of a checkpoint file section.

trick_io(**)

Definition at line 319 of file checkpoint_output_manager.hh.

Referenced by create_section_writer().

8.4.5.6 std::ofstream jeod::CheckPointOutputManager::stream [private]

The C++ file stream that writes to the checkpoint file.

trick io(**)

Definition at line 304 of file checkpoint_output_manager.hh.

Referenced by CheckPointOutputManager(), create_section_writer(), and operator!().

The documentation for this class was generated from the following files:

- · checkpoint output manager.hh
- · checkpoint_output_manager.cc

8.5 jeod::JeodTrickMemoryInterface::ContainerListEntry Struct Reference

Describes a Checkpointable object.

```
#include <trick memory interface.hh>
```

Public Member Functions

 ContainerListEntry (const void *parent, const JeodMemoryTypeDescriptor &tdesc, const std::string &sub_id, JeodCheckpointable &obj)

Construct an ContainerListEntry object.

Data Fields

const void * owner

The object that contains the container.

const JeodMemoryTypeDescriptor & owner type

Type description of the object that contains the container.

• std::string elem_name

The name of the element of the container in the owning object.

• JeodCheckpointable & container

The container itself.

8.5.1 Detailed Description

Describes a Checkpointable object.

Definition at line 216 of file trick_memory_interface.hh.

8.5.2 Constructor & Destructor Documentation

8.5.2.1 jeod::JeodTrickMemoryInterface::ContainerListEntry::ContainerListEntry (const void * parent, const JeodMemoryTypeDescriptor & tdesc, const std::string & sub_id, JeodCheckpointable & obj) [inline]

Construct an ContainerListEntry object.

Parameters

parent	Parent object
tdesc	Type descriptor
sub_id	Parent element
obj	Checkpointable itself

Definition at line 246 of file trick_memory_interface.hh.

8.5.3 Field Documentation

8.5.3.1 JeodCheckpointable& jeod::JeodTrickMemoryInterface::ContainerListEntry::container

The container itself.

trick units(-)

Definition at line 236 of file trick_memory_interface.hh.

Referenced by jeod::JeodTrick10MemoryInterface::restore_containers().

8.5.3.2 std::string jeod::JeodTrickMemoryInterface::ContainerListEntry::elem_name

The name of the element of the container in the owning object.

trick_units(-)

Definition at line 231 of file trick_memory_interface.hh.

Referenced by jeod::JeodTrick10MemoryInterface::deregister_container(), jeod::JeodTrick10MemoryInterface::get-container id(), and jeod::JeodTrick10MemoryInterface::register container().

8.5.3.3 const void* jeod::JeodTrickMemoryInterface::ContainerListEntry::owner

The object that contains the container.

trick units(-)

Definition at line 221 of file trick_memory_interface.hh.

Referenced by jeod::JeodTrick10MemoryInterface::deregister_container(), jeod::JeodTrick10MemoryInterface::get_container_id(), and jeod::JeodTrick10MemoryInterface::register_container().

8.5.3.4 const JeodMemoryTypeDescriptor& jeod::JeodTrickMemoryInterface::ContainerListEntry::owner_type

Type description of the object that contains the container.

trick_units(-)

Definition at line 226 of file trick memory interface.hh.

Referenced by jeod::JeodTrick10MemoryInterface::deregister_container(), jeod::JeodTrick10MemoryInterface::get_container_id(), and jeod::JeodTrick10MemoryInterface::register_container().

The documentation for this struct was generated from the following file:


· trick_memory_interface.hh

8.6 jeod::JeodDynbodyIntegrationLoop Class Reference

A Trick::IntegLoopScheduler that provides the ability to integrate a collection of Trick::SimObject instances over time, with the sim objects capable of being moved from one integration loop to another during run time.

```
#include <trick_dynbody_integ_loop.hh>
```

Inheritance diagram for jeod::JeodDynbodyIntegrationLoop:



Public Member Functions

• JeodDynbodyIntegrationLoop ()

JeodDynbodyIntegrationLoop default constructor.

JeodDynbodyIntegrationLoop (double cycle, Trick::SimObject &sim_object_in, TimeManager &time_-manager_in, DynManager &dyn_manager_in, GravityManager &grav_manager_in, er7_utils::Integrator-Constructor *&integ_cotr_in, DynamicsIntegrationGroup &integ_group_factory)

JeodDynbodyIntegrationLoop non-default constructor.

virtual ~JeodDynbodyIntegrationLoop ()

JeodDynbodyIntegrationLoop destructor.

void initialize_integ_loop (void)

S_define-level function to initialize the integration loop.

void set_time_to_loop_start ()

S_define-level function to reset JEOD time to the time at the start of the current integration loop.

virtual void update_integration_group (JeodIntegrationGroup &group)

Update the provided integration group, which must be the integration group contained within this integration loop object.

• virtual int add_sim_object (Trick::SimObject &sim_obj)

Add a sim object to the set of objects to be integrated by this integration loop object.

• virtual void add_integrable_object (er7_utils::IntegrableObject &integrable_object)

Add the specified integrable object, which should not be a DynBody, to the integration group's set of integrable objects.

virtual int remove_sim_object (Trick::SimObject &sim_obj)

Remove a sim object from the set of objects to be integrated by this integration loop object.

• virtual void remove_integrable_object (er7_utils::IntegrableObject &integrable_object)

Remove the specified integrable object from the integration group's set of integrable objects.

virtual void gravitation (void)

Compute the gravitational accelerations of each dynamic body that is integrated by this integration loop.

virtual void collect derivatives (void)

Collect the derivatives for each dynamic body that is integrated by this integration loop.

virtual void set_deriv_ephem_update (bool val)

Set the deriv_ephem_update flag for the integration group.

Protected Member Functions

• Trick::SimObject * find_containing_sim_object (er7_utils::IntegrableObject &integrable_object)

Find the sim object that contains the specified integrable object.

virtual void add_sim_object_bodies (Trick::SimObject &sim_obj)

Add the DynBody objects contained in the specified sim object to the set of DynBody objects integrated by this integration loop.

virtual void add sim object bodies (void)

Add the dyn bodies contained in all the sim objects integrated by this integration loop to the loop's integration group.

virtual void remove_sim_object_bodies (Trick::SimObject &sim_obj)

Remove the DynBody objects contained in the specified sim object from the set of DynBody objects integrated by this integration loop.

• virtual int integrate_dt (double beg_sim_time, double del_sim_time)

Integrate sim objects over the specified time span.

Protected Attributes

Trick::SimObject * loop_sim_object

The simulation object that contains this integration loop object.

DynManager * dyn_manager

The JEOD dynamics manager.

• TimeManager * time_manager

The JEOD time manager.

GravityManager * gravity_manager

The gravity model manager.

• JeodTrickIntegrator integ_interface

Dummy integration interface; needed by the integ_group.

er7_utils::IntegratorConstructor ** integ_constructor

Handle to the integration constructor used to create integrators.

const DynamicsIntegrationGroup * integ_group_factory

The externally-supplied integration group used as a template for creating this integration loop's integration group.

• DynamicsIntegrationGroup * integ_group

The integration group that performs the integration.

· bool deriv ephem update

If set, ephemerides will be updated at the derivative rate.

Private Member Functions

- JeodDynbodyIntegrationLoop (const JeodDynbodyIntegrationLoop &)
 - < Deleted.
- JeodDynbodyIntegrationLoop & operator= (const JeodDynbodyIntegrationLoop &)

Friends

- class InputProcessor
- void init_attrjeod__JeodDynbodyIntegrationLoop ()

8.6.1 Detailed Description

A Trick::IntegLoopScheduler that provides the ability to integrate a collection of Trick::SimObject instances over time, with the sim objects capable of being moved from one integration loop to another during run time.

A JeodDynbodyIntegrationLoop augments this capability in a number of regards:

- All DynBody objects contained in the sim objects integrated by a JeodDynbodyIntegrationLoop object are integrated using JEOD integration.
- The DynBody objects to be integrated by a JeodDynbodyIntegrationLoop object are automatically collected as a member of the DynamicsIntegrationGroup object contained within a JeodDynbodyIntegrationLoop object.
- Non-DynBody integrable objects can also be integrated using JEOD integration.
- Non-DynBody integrable objects that are elsewhere identified as being associated with a DynBody object are automatically collected along with the DynBody objects with which they are associated.
- The DynBody and associated integrable objects are integrated using the DynamicsIntegrationGroup object contained in the loop object.

Users of this class are strongly encouraged to do so via a JeodIntegLoopSimObject. See \$JEOD_HOME/lib/jeod/-JEOD_S modules/integ_loop.sm.

Definition at line 101 of file trick_dynbody_integ_loop.hh.

8.6.2 Constructor & Destructor Documentation

8.6.2.1 jeod::JeodDynbodyIntegrationLoop::JeodDynbodyIntegrationLoop ()

JeodDynbodyIntegrationLoop default constructor.

Note

This exists only for the purpose of automated checkpoint/restart.

Warning

Do not use the default constructor outside of this context.

Definition at line 60 of file trick dynbody integ loop.cc.

8.6.2.2 jeod::JeodDynbodyIntegrationLoop::JeodDynbodyIntegrationLoop (double *cycle*, Trick::SimObject & *sim_object_in*, TimeManager & *time_manager_in*, DynManager & *dyn_manager_in*, GravityManager & *grav_manager_in*, er7_utils::IntegratorConstructor *& *integ_cotr_in*, DynamicsIntegrationGroup & *integ_group_factory*)

JeodDynbodyIntegrationLoop non-default constructor.

This is the constructor that should be used in the S_define file. The SimObject that contains this JeodDynbody-IntegrationLoop instance must register an "integ_loop" class job that calls the loop's integrate method.

Parameters

cycle	The integration interval in simulation seconds. This must be the same interval as specified in
	the integ_loop job specification.

sim_object_in	The SimObject that contains this JeodDynbodyIntegrationLoop instance.
time_manager	The simulation's time manager object.
in	
dyn_manager_in	The simulation's dynamics manager object.
grav_manager	The simulation's gravity manager object.
in	
integ_cotr_in	The integrator constructor used to create integration artifacts.
integ_group	The integration group object used to create this loop's integ group.
factory	

Definition at line 76 of file trick_dynbody_integ_loop.cc.

References add sim object(), jeod::SimInterfaceMessages::integration error, and loop sim object.

8.6.2.3 jeod::JeodDynbodyIntegrationLoop::~JeodDynbodyIntegrationLoop(void) [virtual]

JeodDynbodyIntegrationLoop destructor.

Definition at line 111 of file trick_dynbody_integ_loop.cc.

References integ group.

8.6.2.4 jeod::JeodDynbodyIntegrationLoop::JeodDynbodyIntegrationLoop (const JeodDynbodyIntegrationLoop &) [private]

< Deleted.

Deleted.

8.6.3 Member Function Documentation

8.6.3.1 void jeod::JeodDynbodyIntegrationLoop::add_integrable_object (er7_utils::IntegrableObject & integrable_object)

[virtual]

Add the specified integrable object, which should not be a DynBody, to the integration group's set of integrable objects.

Parameters

integrable_object	Object to be added.

Definition at line 189 of file trick_dynbody_integ_loop.cc.

 $References\ integ_group,\ and\ jeod::SimInterfaceMessages::integration_error.$

8.6.3.2 int jeod::JeodDynbodyIntegrationLoop::add_sim_object (Trick::SimObject & sim_obj) [virtual]

Add a sim object to the set of objects to be integrated by this integration loop object.

The job queues for this loop are rebuilt after adding the sim object.

Parameters

sim_obj	The SimObject to be added to this loop object.

Returns

Zero => success, non-zero => error.

Definition at line 290 of file trick_dynbody_integ_loop.cc.

References add sim object bodies(), and dyn manager.

Referenced by JeodDynbodyIntegrationLoop().

8.6.3.3 void jeod::JeodDynbodyIntegrationLoop::add_sim_object_bodies (Trick::SimObject & sim_obj) [protected], [virtual]

Add the DynBody objects contained in the specified sim object to the set of DynBody objects integrated by this integration loop.

Parameters

```
sim_obj | The SimObject being added to this loop object.
```

Definition at line 334 of file trick_dynbody_integ_loop.cc.

References dyn_manager, find_containing_sim_object(), and integ_group.

```
8.6.3.4 void jeod::JeodDynbodyIntegrationLoop::add_sim_object_bodies ( void ) [protected], [virtual]
```

Add the dyn bodies contained in all the sim objects integrated by this integration loop to the loop's integration group.

Definition at line 353 of file trick_dynbody_integ_loop.cc.

References dyn manager, find containing sim object(), and integ group.

Referenced by add_sim_object(), and update_integration_group().

```
8.6.3.5 virtual void jeod::JeodDynbodyIntegrationLoop::collect_derivatives( void ) [inline], [virtual]
```

Collect the derivatives for each dynamic body that is integrated by this integration loop.

Definition at line 252 of file trick_dynbody_integ_loop.hh.

References integ_group.

8.6.3.6 Trick::SimObject * jeod::JeodDynbodyIntegrationLoop::find_containing_sim_object (er7_utils::IntegrableObject & integrable_object) [protected]

Find the sim object that contains the specified integrable object.

Parameters

integrable_object	Object to be found.
-------------------	---------------------

Returns

Sim object that contains the specified object, or null if none.

Definition at line 151 of file trick dynbody integ loop.cc.

References jeod::JeodSimulationInterface::get_address_at_name(), and jeod::JeodSimulationInterface::get_name_at_address().

Referenced by add_sim_object_bodies(), and remove_sim_object_bodies().

8.6.3.7 virtual void jeod::JeodDynbodyIntegrationLoop::gravitation(void) [inline], [virtual]

Compute the gravitational accelerations of each dynamic body that is integrated by this integration loop.

Definition at line 242 of file trick_dynbody_integ_loop.hh.

References dyn manager, gravity manager, and integ group.

8.6.3.8 void jeod::JeodDynbodyIntegrationLoop::initialize_integ_loop (void)

S define-level function to initialize the integration loop.

This function should be called as a very low phase integration class job.

Definition at line 122 of file trick dynbody integ loop.cc.

References deriv_ephem_update, dyn_manager, integ_constructor, integ_group, integ_group_factory, integ_interface, jeod::SimInterfaceMessages::integration_error, and time_manager.

```
8.6.3.9 int jeod::JeodDynbodyIntegrationLoop::integrate_dt ( double beg_sim_time, double del_sim_time ) [protected], [virtual]
```

Integrate sim objects over the specified time span.

This is an overridable internal integration function and is called by the externally-visible integrate method and by call dynamic event jobs.

Returns

Zero/non-zero success indicator. Out-of-sync integrators cause a non-zero return.

Parameters

beg_sim_time	The time at the start of the integration interval.
del_sim_time	The time span of the integration interval.

Definition at line 227 of file trick_dynbody_integ_loop.cc.

References integ_group, jeod::SimInterfaceMessages::integration_error, and trick_curr_integ.

8.6.3.10 JeodDynbodyIntegrationLoop& jeod::JeodDynbodyIntegrationLoop::operator= (const JeodDynbodyIntegrationLoop &) [private]

```
8.6.3.11 void jeod::JeodDynbodyIntegrationLoop::remove_integrable_object ( er7_utils::IntegrableObject & integrable_object )
[virtual]
```

Remove the specified integrable object from the integration group's set of integrable objects.

Parameters

integrable_object	Object to be removed.

Definition at line 210 of file trick_dynbody_integ_loop.cc.

References integ_group.

```
8.6.3.12 int jeod::JeodDynbodyIntegrationLoop::remove_sim_object ( Trick::SimObject & sim_obj ) [virtual]
```

Remove a sim object from the set of objects to be integrated by this integration loop object.

The job queues for this loop are rebuilt after removing the sim object.

Parameters

sim_obj The SimObject to be removed from this loop object.

Returns

Zero => success, non-zero => error.

Definition at line 312 of file trick_dynbody_integ_loop.cc.

References dyn_manager, and remove_sim_object_bodies().

8.6.3.13 void jeod::JeodDynbodyIntegrationLoop::remove_sim_object_bodies (Trick::SimObject & sim_obj)

[protected], [virtual]

Remove the DynBody objects contained in the specified sim object from the set of DynBody objects integrated by this integration loop.

Parameters

sim_obj | The SimObject being removed from this loop object.

Definition at line 374 of file trick_dynbody_integ_loop.cc.

References dyn_manager, find_containing_sim_object(), and integ_group.

Referenced by remove_sim_object().

8.6.3.14 virtual void jeod::JeodDynbodyIntegrationLoop::set_deriv_ephem_update(bool val) [inline], [virtual]

Set the deriv ephem update flag for the integration group.

Parameters

val	New value for deriv_ephem_update.

Definition at line 262 of file trick_dynbody_integ_loop.hh.

References deriv_ephem_update, and integ_group.

8.6.3.15 void jeod::JeodDynbodyIntegrationLoop::set_time_to_loop_start()

S_define-level function to reset JEOD time to the time at the start of the current integration loop.

This function should be called as a very low phase pre-integration class job in simulations that have multiple integration loops.

Definition at line 219 of file trick_dynbody_integ_loop.cc.

References time manager.

8.6.3.16 void jeod::JeodDynbodyIntegrationLoop::update_integration_group (JeodIntegrationGroup & group) [virtual]

Update the provided integration group, which must be the integration group contained within this integration loop object.

Note

This function is public because it is called (indirectly) from DynManager::initialize_simulation. It should otherwise be viewed as a protected or private function.

Parameters

group	The IntegrationGroup to be updated, which must be the integration loop's integration group
	object.

Definition at line 393 of file trick_dynbody_integ_loop.cc.

References add_sim_object_bodies(), integ_group, and jeod::SimInterfaceMessages::integration_error.

8.6.4 Friends And Related Function Documentation

8.6.4.1 void init_attrjeod_JeodDynbodyIntegrationLoop() [friend]

8.6.4.2 friend class InputProcessor [friend]

Definition at line 106 of file trick_dynbody_integ_loop.hh.

8.6.5 Field Documentation

8.6.5.1 bool jeod::JeodDynbodyIntegrationLoop::deriv_ephem_update [protected]

If set, ephemerides will be updated at the derivative rate.

If clear, ephemerides will not be updated at the derivative rate by the ephemerides manager. Derivative-rate updates can still be attained by explicitly calling the various ephemerides model's update functions as derivative class jobs.-trick_units(-)

Definition at line 372 of file trick_dynbody_integ_loop.hh.

Referenced by initialize_integ_loop(), and set_deriv_ephem_update().

8.6.5.2 DynManager* jeod::JeodDynbodyIntegrationLoop::dyn_manager [protected]

The JEOD dynamics manager.

trick_units(-)

Definition at line 332 of file trick_dynbody_integ_loop.hh.

Referenced by add_sim_object(), add_sim_object_bodies(), gravitation(), initialize_integ_loop(), remove_sim_object(), and remove_sim_object_bodies().

8.6.5.3 GravityManager* jeod::JeodDynbodyIntegrationLoop::gravity_manager [protected]

The gravity model manager.

trick_units(-)

Definition at line 342 of file trick_dynbody_integ_loop.hh.

Referenced by gravitation().

8.6.5.4 er7_utils::IntegratorConstructor** jeod::JeodDynbodyIntegrationLoop::integ_constructor [protected]

Handle to the integration constructor used to create integrators.

trick_units(-)

Definition at line 352 of file trick_dynbody_integ_loop.hh.

Referenced by initialize_integ_loop().

8.6.5.5 DynamicsIntegrationGroup*jeod::JeodDynbodyIntegrationLoop::integ_group [protected]

The integration group that performs the integration.

trick units(-)

Definition at line 363 of file trick dynbody integ loop.hh.

Referenced by add_integrable_object(), add_sim_object_bodies(), collect_derivatives(), gravitation(), initialize_integ_loop(), integrate_dt(), remove_integrable_object(), remove_sim_object_bodies(), set_deriv_ephem_update(), update_integration_group(), and ~JeodDynbodyIntegrationLoop().

8.6.5.6 const DynamicsIntegrationGroup* jeod::JeodDynbodyIntegrationLoop::integ_group_factory [protected]

The externally-supplied integration group used as a template for creating this integration loop's integration group.

trick_units(-)

Definition at line 358 of file trick dynbody integ loop.hh.

Referenced by initialize_integ_loop().

8.6.5.7 JeodTrickIntegrator jeod::JeodDynbodyIntegrationLoop::integ_interface [protected]

Dummy integration interface; needed by the integ_group.

trick_units(-)

Definition at line 347 of file trick_dynbody_integ_loop.hh.

Referenced by initialize_integ_loop().

8.6.5.8 Trick::SimObject* jeod::JeodDynbodyIntegrationLoop::loop_sim_object [protected]

The simulation object that contains this integration loop object.

trick units(-)

Definition at line 327 of file trick dynbody integ loop.hh.

Referenced by JeodDynbodyIntegrationLoop().

8.6.5.9 TimeManager* jeod::JeodDynbodyIntegrationLoop::time_manager [protected]

The JEOD time manager.

trick_units(-)

Definition at line 337 of file trick_dynbody_integ_loop.hh.

Referenced by initialize_integ_loop(), and set_time_to_loop_start().

The documentation for this class was generated from the following files:


- trick_dynbody_integ_loop.hh
- trick_dynbody_integ_loop.cc

8.7 jeod::JeodIntegratorInterface Class Reference

A JeodIntegratorInterface extends the ER7 IntegratorInterface with the concept of a pointer to the simulation engine's integration object.

#include <jeod_integrator_interface.hh>

Inheritance diagram for jeod::JeodIntegratorInterface:



Public Member Functions

virtual ~JeodIntegratorInterface ()

Destructor.

virtual

er7_utils::Integration::Technique interpret_integration_type (int) const =0

Interpret the integration technique.

virtual Trick::Integrator * get_integrator ()=0

Get the simulation engine's integrator.

Friends

- class InputProcessor
- void init_attrjeod__JeodIntegratorInterface ()

8.7.1 Detailed Description

A JeodIntegratorInterface extends the ER7 IntegratorInterface with the concept of a pointer to the simulation engine's integration object.

Definition at line 55 of file jeod_integrator_interface.hh.

8.7.2 Constructor & Destructor Documentation

8.7.2.1 virtual jeod::JeodIntegratorInterface::~JeodIntegratorInterface() [inline], [virtual]

Destructor.

Definition at line 67 of file jeod integrator interface.hh.

8.7.3 Member Function Documentation

8.7.3.1 virtual Trick::Integrator* jeod::JeodIntegratorInterface::get_integrator() [pure virtual]

Get the simulation engine's integrator.

Returns

Pointer to the simulation engine's integrator.

Implemented in jeod::JeodTrickIntegrator.

8.7.3.2 virtual er7_utils::Integration::Technique jeod::JeodIntegratorInterface::interpret_integration_type (int) const [pure virtual]

Interpret the integration technique.

Implemented in jeod::JeodTrickIntegrator.

8.7.4 Friends And Related Function Documentation

```
8.7.4.1 void init_attrjeod__JeodIntegratorInterface() [friend]
```

8.7.4.2 friend class InputProcessor [friend]

Definition at line 56 of file jeod_integrator_interface.hh.

The documentation for this class was generated from the following file:


· jeod_integrator_interface.hh

8.8 jeod::JeodMemoryInterface Class Reference

Abstract interface between the JEOD memory manager and the simulation engine.

```
#include <memory_interface.hh>
```

Inheritance diagram for jeod::JeodMemoryInterface:



Public Member Functions

• JeodMemoryInterface ()

Default constructor.

• virtual \sim JeodMemoryInterface ()

Destructor.

JeodMemoryInterface (const JeodMemoryInterface &)

Copy constructor.

• JeodMemoryInterface & operator= (const JeodMemoryInterface &)

Assignment operator.

- virtual struct ATTRIBUTES_tag * find_attributes (const std::string &type_name) const =0
 Find the attributes for a given class name.
- virtual struct ATTRIBUTES_tag * find_attributes (const std::type_info &data_type) const =0
 Find the attributes for a given class.
- virtual struct ATTRIBUTES_tag primitive_attributes (const std::type_info &data_type) const =0
 Create an attributes structure that represents a primitive type.
- virtual struct ATTRIBUTES_tag pointer_attributes (const struct ATTRIBUTES_tag &pointed_to_attr) const =0 Create an attributes structure that represents a pointer type.

• virtual struct ATTRIBUTES_tag void_pointer_attributes (void) const =0

Create a simulation engine description of void*.

virtual struct ATTRIBUTES_tag structure_attributes (const struct ATTRIBUTES_tag *target_attr, std::size_t target size) const =0

Create an attributes structure that represents a structured type.

 virtual bool register_allocation (const void *addr, const JeodMemoryItem &item, const JeodMemoryType-Descriptor &tdesc, const char *file, unsigned int line)=0

Register allocated memory with the simulation engine.

 virtual void deregister_allocation (const void *addr, const JeodMemoryItem &item, const JeodMemoryType-Descriptor &tdesc, const char *file, unsigned int line)=0

Revoke registation of memory that is about to be deleted.

 virtual void register_container (const void *container, const JeodMemoryTypeDescriptor &container_type, const char *elem_name, JeodCheckpointable &checkpointable)=0

Register a JeodCheckpointable object with the simulation engine.

 virtual void deregister_container (const void *container, const JeodMemoryTypeDescriptor &container_type, const char *elem_name, JeodCheckpointable &checkpointable)=0

Deregister a JeodCheckpointable object with the simulation engine.

virtual bool is checkpoint restart supported (void) const =0

Indicates whether the checkpoint/restart methods are viable.

virtual const std::string get_name_at_address (const void *addr, const JeodMemoryTypeDescriptor *tdesc)
 const =0

Get the simulation engine's name (if any) of the address.

virtual void * get address at name (const std::string &name) const =0

Get the address (if any) identified by the given name.

Friends

- class InputProcessor
- void init attrjeod JeodMemoryInterface ()

8.8.1 Detailed Description

Abstract interface between the JEOD memory manager and the simulation engine.

Definition at line 58 of file memory_interface.hh.

8.8.2 Constructor & Destructor Documentation

8.8.2.1 jeod::JeodMemoryInterface::JeodMemoryInterface (void)

Default constructor.

Definition at line 45 of file memory_interface.cc.

8.8.2.2 jeod::JeodMemoryInterface:: \sim JeodMemoryInterface (void) [virtual]

Destructor.

Definition at line 55 of file memory_interface.cc.

8.8.2.3 jeod::JeodMemoryInterface:JeodMemoryInterface (const JeodMemoryInterface & src) [explicit]

Copy constructor.

Parameters

in	src	Item to be copied

Definition at line 66 of file memory_interface.cc.

8.8.3 Member Function Documentation

8.8.3.1 virtual void jeod::JeodMemoryInterface::deregister_allocation (const void * addr, const JeodMemoryItem & item, const JeodMemoryTypeDescriptor & tdesc, const char * file, unsigned int line) [pure virtual]

Revoke registation of memory that is about to be deleted.

Parameters

in	addr	Address of allocated memory to be de-registered.
in	item	JEOD descriptor of the memory
in	tdesc	JEOD descriptor of the type of the allocated memory
in	file	File in which allocation was performed
in	line	Line number in that file

Implemented in jeod::JeodTrickMemoryInterface.

Deregister a JeodCheckpointable object with the simulation engine.

Parameters

in	container	Object that contains the checkpointable
in	container_type	Checkpointable container type info
in	elem_name	Element name of checkpointable object
in,out	checkpointable	The checkpointable object itself

Implemented in jeod::JeodTrickMemoryInterface, and jeod::JeodTrick10MemoryInterface.

8.8.3.3 virtual struct ATTRIBUTES_tag* jeod::JeodMemoryInterface::find_attributes (const std::string & type_name) const [pure virtual]

Find the attributes for a given class name.

Parameters

in	type_name	Name of the class.

Returns

Attributes pointer. Note: This is not an allocated pointer.

 $Implemented\ in\ jeod:: JeodTrickMemoryInterface.$

8.8.3.4 virtual struct ATTRIBUTES_tag* jeod::JeodMemoryInterface::find_attributes (const std::type_info & data_type) const [pure virtual]

Find the attributes for a given class.

in	data_type	RTTI descriptor of the type.
----	-----------	------------------------------

Returns

Attributes pointer. Note: This is not an allocated pointer.

Implemented in jeod::JeodTrickMemoryInterface.

Get the address (if any) identified by the given name.

Note

An implementation that does not support name translation will return the null pointer.

A stubbed implementation should have its is_checkpoint_restart_supported method return false.

Returns

Address corresponding to the given name, if any

Parameters

in	name	Value previously constructed by get_name_at_address()
----	------	---

Implemented in jeod::JeodTrickMemoryInterface, and jeod::JeodTrick10MemoryInterface.

8.8.3.6 virtual const std::string jeod::JeodMemoryInterface::get_name_at_address (const void * addr, const JeodMemoryTypeDescriptor * tdesc) const [pure virtual]

Get the simulation engine's name (if any) of the address.

A derived class associated with a simulation engine that does not support this translation should return an empty string for all calls. When the underlying simulation engine does support this translation, the implementation should return values as follows:

- The string "NULL" if the input address is the null pointer.
- The empty string to indicate an invalid input address or an input address that is unknown to the simulation engine.
- A non-empty, non-"NULL" string to indicate a valid address. Applying the get_address_at_name method to this result must yield the input address.

Note

A stubbed implementation should have its is_checkpoint_restart_supported method return false.

Returns

Name of the address, if any

in	addr	Address of memory to identified by name
in	tdesc	Type context in which to interpret the address

Implemented in jeod::JeodTrickMemoryInterface, and jeod::JeodTrick10MemoryInterface.

8.8.3.7 virtual bool jeod::JeodMemoryInterface::is_checkpoint_restart_supported (void) const [pure virtual]

Indicates whether the checkpoint/restart methods are viable.

Checkpoint/restart can be used only in an environment that provides viable checkpoint/restart methods.

Returns

True if the checkpoint / restart is supported, false otherwise.

Implemented in jeod::JeodTrickMemoryInterface, and jeod::JeodTrick10MemoryInterface.

8.8.3.8 JeodMemoryInterface & jeod::JeodMemoryInterface::operator=(const JeodMemoryInterface & src)

Assignment operator.

Returns

*this

Parameters

in	src	Item to be copied

Definition at line 79 of file memory_interface.cc.

8.8.3.9 virtual struct ATTRIBUTES_tag jeod::JeodMemoryInterface::pointer_attributes (const struct ATTRIBUTES_tag & pointed_to_attr) const [pure virtual]

Create an attributes structure that represents a pointer type.

Parameters

in	pointed_to_attr	Attributes of the pointed-to type.
----	-----------------	------------------------------------

Returns

Attribute structure.

Implemented in jeod::JeodTrickMemoryInterface.

8.8.3.10 virtual struct ATTRIBUTES_tag jeod::JeodMemoryInterface::primitive_attributes (const std::type_info & data_type)
const [pure virtual]

Create an attributes structure that represents a primitive type.

in	data_type	RTTI descriptor of the type.

Returns

Attributes structure.

Implemented in jeod::JeodTrickMemoryInterface.

8.8.3.11 virtual bool jeod::JeodMemoryInterface::register_allocation (const void * addr, const JeodMemoryItem & item, const JeodMemoryTypeDescriptor & tdesc, const char * file, unsigned int line) [pure virtual]

Register allocated memory with the simulation engine.

Parameters

in	addr	Address of allocated memory to be registered.
in	item	JEOD descriptor of the allocated memory
in	tdesc	JEOD descriptor of the type of the allocated memory
in	file	File in which allocation was performed
in	line	Line number in that file

Implemented in jeod::JeodTrickMemoryInterface.

8.8.3.12 virtual void jeod::JeodMemoryInterface::register_container(const void * container, const JeodMemoryTypeDescriptor & container_type, const char * elem_name, JeodCheckpointable & checkpointable) [pure virtual]

Register a JeodCheckpointable object with the simulation engine.

Parameters

in	container	Object that contains the checkpointable
in	container_type	Checkpointable container type info
in	elem_name	Element name of checkpointable object
in,out	checkpointable	The checkpointable object itself

Implemented in jeod::JeodTrickMemoryInterface, and jeod::JeodTrick10MemoryInterface.

Create an attributes structure that represents a structured type.

Parameters

in	target_attr	Attributes from find_attributes
in	target_size	Size of the underlying type

Returns

Attribute structure.

Implemented in jeod::JeodTrickMemoryInterface.

8.8.3.14 virtual struct ATTRIBUTES_tag jeod::JeodMemoryInterface::void_pointer_attributes (void) const [pure virtual]

Create a simulation engine description of void*.

Returns

Attribute structure.

Implemented in jeod::JeodTrickMemoryInterface.

8.8.4 Friends And Related Function Documentation

```
8.8.4.1 void init_attrjeod__JeodMemoryInterface() [friend]
```

```
8.8.4.2 friend class InputProcessor [friend]
```

Definition at line 60 of file memory_interface.hh.

The documentation for this class was generated from the following files:


- · memory_interface.hh
- · memory_interface.cc

8.9 jeod::JeodSimulationInterface Class Reference

This abstract class defines the basis for the interface between JEOD and a simulation engine.

```
#include <simulation_interface.hh>
```

Inheritance diagram for jeod::JeodSimulationInterface:



Public Types

```
    enum Mode {
        Construction = 0, PreCheckpoint = 1, Checkpoint = 2, PostCheckpoint = 3,
        Restart = 4, Restore = 5, Initialization = 6, Operational = 7,
        Shutdown = 8, Dead = 9, NumModes = 10 }
```

Defines the states of the JeodSimulationInterface state machine.

Public Member Functions

JeodSimulationInterface ()

Construct a JeodSimulationInterface object.

virtual ~JeodSimulationInterface ()

Destruct a JeodSimulationInterface object.

virtual void configure (const JeodSimulationInterfaceInit &config)

Configure a JeodSimulationInterface object.

Mode get_mode (void) const

Get the current mode.

• virtual void set_mode (Mode new_mode)

Set the mode, but only if allowed per the mode state transition diagram.

Static Public Member Functions

static JeodIntegratorInterface * create_integrator_interface (void)

Create a simulation integrator interface object.

static double get_job_cycle (void)

Get the cycle time of the currently executing job.

• static std::string get_name_at_address (const void *addr, const JeodMemoryTypeDescriptor *tdesc)

Translate the given address to a symbolic name.

static void * get_address_at_name (const std::string &name)

Translate the given symbolic name to an address.

static JeodMemoryInterface & get_memory_interface (void)

Get the interface with the simulation memory model.

static SectionedInputStream get_checkpoint_reader (const std::string §ion_id)

Get a reader of a section of the currently open checkpoint file.

static SectionedOutputStream get_checkpoint_writer (const std::string §ion_id)

Get a writer to a section of the currently open checkpoint file.

Protected Member Functions

• virtual JeodIntegratorInterface * create_integrator_internal (void)=0

Create an integration interface object.

• virtual double get_job_cycle_internal (void)=0

Get the simulation cycle time of the currently executing function.

virtual JeodMemoryInterface & get_memory_interface_internal (void)=0

Get the interface with the simulation memory manager.

virtual SectionedInputStream get_checkpoint_reader_internal (const std::string §ion_id)=0

Get a checkpoint section reader.

virtual SectionedOutputStream get_checkpoint_writer_internal (const std::string §ion_id)=0

Get a checkpoint section writer.

Protected Attributes

Mode mode

The mode in which the simulation interface is operating.

· Mode saved_mode

The mode prior to a checkpoint or restart process.

Static Protected Attributes

static JeodSimulationInterface * sim_interface = NULL

The singleton instance of a SimulationInterface object that must be created by a conforming JEOD simulation before any call can be made to one of the three static methods declared above.

Private Member Functions

JeodSimulationInterface (const JeodSimulationInterface &)

Not implemented.

• JeodSimulationInterface & operator= (const JeodSimulationInterface &)

Not implemented.

Friends

- · class InputProcessor
- void init_attrjeod__JeodSimulationInterface ()

8.9.1 Detailed Description

This abstract class defines the basis for the interface between JEOD and a simulation engine.

A compliant derived class must contain one instance each of a class that derives from MessageHandler and a class that derives from JeodMemoryManager. The MessageHandler object must be constructed before the JeodMemory-Manager object; destruction must be performed in reverse order.

Definition at line 105 of file simulation_interface.hh.

8.9.2 Member Enumeration Documentation

8.9.2.1 enum jeod::JeodSimulationInterface::Mode

Defines the states of the JeodSimulationInterface state machine.

Enumerator

Construction

PreCheckpoint

Checkpoint

PostCheckpoint

Restart

Restore

Initialization

Operational

Shutdown

Dead

NumModes

Definition at line 115 of file simulation interface.hh.

8.9.3 Constructor & Destructor Documentation

8.9.3.1 jeod::JeodSimulationInterface::JeodSimulationInterface (void)

Construct a JeodSimulationInterface object.

Definition at line 75 of file simulation interface.cc.

References sim_interface, and jeod::SimInterfaceMessages::singleton_error.

8.9.3.2 jeod::JeodSimulationInterface::~JeodSimulationInterface(void) [virtual]

Destruct a JeodSimulationInterface object.

Definition at line 95 of file simulation_interface.cc.

References sim_interface.

8.9.3.3 jeod::JeodSimulationInterface (const JeodSimulationInterface &) [private]

Not implemented.

8.9.4 Member Function Documentation

8.9.4.1 void jeod::JeodSimulationInterface::configure (const JeodSimulationInterfaceInit & config) [virtual]

Configure a JeodSimulationInterface object.

Parameters

in	config	Configuration spec

Definition at line 109 of file simulation_interface.cc.

References jeod::JeodSimulationInterfaceInit::memory_debug_level, jeod::JeodSimulationInterfaceInit::message_suppress_id, jeod::JeodSimulationInterfaceInit::message_suppress_location, and jeod::JeodSimulationInterfaceInit::message_suppression_level.

8.9.4.2 JeodIntegratorInterface * jeod::JeodSimulationInterface::create_integrator_interface(void) [static]

Create a simulation integrator interface object.

Returns

Constructed IntegratorInterface object.

Definition at line 131 of file simulation interface.cc.

References create_integrator_internal(), sim_interface, and jeod::SimInterfaceMessages::singleton_error.

```
8.9.4.3 virtual JeodIntegratorInterface* jeod::JeodSimulationInterface::create_integrator_internal ( void ) [protected], [pure virtual]
```

Create an integration interface object.

The calling object is responsible for destroying the created object.

Returns

Created integration interface object.

Implemented in jeod::BasicJeodTrickSimInterface.

Referenced by create_integrator_interface().

8.9.4.4 void * jeod::JeodSimulationInterface::get_address_at_name (const std::string & name) [static]

Translate the given symbolic name to an address.

Returns

Address

in	name	Symbolic name
----	------	---------------

Definition at line 225 of file simulation_interface.cc.

References get memory interface internal(), sim interface, and jeod::SimInterfaceMessages::singleton error.

Referenced by jeod::JeodDynbodyIntegrationLoop::find containing sim object().

8.9.4.5 SectionedInputStream jeod::JeodSimulationInterface::get_checkpoint_reader (const std::string & section_id) [static]

Get a reader of a section of the currently open checkpoint file.

Returns

Checkpoint reader

Parameters

in	section_id	Section ID

Definition at line 250 of file simulation interface.cc.

References get_checkpoint_reader_internal(), sim_interface, and jeod::SimInterfaceMessages::singleton_error.

Referenced by jeod::JeodTrick10MemoryInterface::restore_allocations(), and jeod::JeodTrick10MemoryInterface::restore_containers().

8.9.4.6 virtual SectionedInputStream jeod::JeodSimulationInterface::get_checkpoint_reader_internal (const std::string & section_id) [protected], [pure virtual]

Get a checkpoint section reader.

Implemented in jeod::BasicJeodTrickSimInterface.

Referenced by get checkpoint reader().

8.9.4.7 SectionedOutputStream jeod::JeodSimulationInterface::get_checkpoint_writer (const std::string & section_id) [static]

Get a writer to a section of the currently open checkpoint file.

Returns

Checkpoint writer

Parameters

in	section id	Section ID
	000	- C-

Definition at line 271 of file simulation interface.cc.

 $References\ get_checkpoint_writer_internal(),\ sim_interface,\ and\ jeod::SimInterfaceMessages::singleton_error.$

Referenced by jeod::JeodTrick10MemoryInterface::checkpoint_allocations(), and jeod::JeodTrick10MemoryInterface::checkpoint_containers().

8.9.4.8 virtual SectionedOutputStream jeod::JeodSimulationInterface::get_checkpoint_writer_internal (const std::string & section_id) [protected], [pure virtual]

Get a checkpoint section writer.

Implemented in jeod::BasicJeodTrickSimInterface.

Referenced by get checkpoint writer().

8.9.4.9 double jeod::JeodSimulationInterface::get_job_cycle (void) [static]

Get the cycle time of the currently executing job.

Returns

Cycle time in simulation engine seconds of the currently executing job. Units: s

Definition at line 154 of file simulation_interface.cc.

References get_job_cycle_internal(), sim_interface, and jeod::SimInterfaceMessages::singleton_error.

8.9.4.10 virtual double jeod::JeodSimulationInterface::get_job_cycle_internal (void) [protected], [pure virtual]

Get the simulation cycle time of the currently executing function.

Returns

Cycle time in simulation engine seconds

Implemented in jeod::BasicJeodTrickSimInterface.

Referenced by get_job_cycle().

8.9.4.11 JeodMemoryInterface & jeod::JeodSimulationInterface::get_memory_interface (void) [static]

Get the interface with the simulation memory model.

Returns

Memory interface

Definition at line 177 of file simulation_interface.cc.

 $References\ get_memory_interface_internal(),\ sim_interface,\ and\ jeod::SimInterfaceMessages::singleton_error.$

8.9.4.12 virtual JeodMemoryInterface& jeod::JeodSimulationInterface::get_memory_interface_internal (void) [protected], [pure virtual]

Get the interface with the simulation memory manager.

Returns

JEOD/simulation engine memory interface.

Implemented in jeod::BasicJeodTrickSimInterface.

Referenced by get_address_at_name(), get_memory_interface(), and get_name_at_address().

8.9.4.13 Mode jeod::JeodSimulationInterface::get_mode (void) const [inline]

Get the current mode.

Definition at line 217 of file simulation interface.hh.

References mode.

Referenced by jeod::BasicJeodTrickSimInterface::set_mode().

8.9.4.14 std::string jeod::JeodSimulationInterface::get_name_at_address (const void * addr, const JeodMemoryTypeDescriptor * tdesc) [static]

Translate the given address to a symbolic name.

Returns

Symbolic name

Parameters

in	addr	Address
in	tdesc	Descriptor

Definition at line 199 of file simulation interface.cc.

References get_memory_interface_internal(), sim_interface, and jeod::SimInterfaceMessages::singleton_error.

Referenced by jeod::JeodDynbodyIntegrationLoop::find_containing_sim_object().

8.9.4.15 JeodSimulationInterface& jeod::JeodSimulationInterface::operator= (const JeodSimulationInterface &) [private]

Not implemented.

8.9.4.16 void jeod::JeodSimulationInterface::set mode (Mode new mode) [virtual]

Set the mode, but only if allowed per the mode state transition diagram.

Assumptions and Limitations

The standard JEODSys Trick sim object follows the correct state transition diagram. A similar sequence
must be implemented when JEOD is used outside of the Trick environment. In a Trick environment, nobody
should call this function except the Trick scheduler, and these calls must conform with the sequence in
the standard JEODSys Trick sim object.

Parameters

in	new_mode	New mode
----	----------	----------

Reimplemented in jeod::BasicJeodTrickSimInterface.

Definition at line 298 of file simulation interface.cc.

References Checkpoint, Construction, Dead, jeod::SimInterfaceMessages::implementation_error, mode, Num-Modes, jeod::SimInterfaceMessages::phasing_error, PostCheckpoint, PreCheckpoint, Restart, Restore, saved_mode, and Shutdown.

 $Referenced\ by\ jeod:: Basic Jeod Trick Sim Interface:: set_mode().$

8.9.5 Friends And Related Function Documentation

8.9.5.1 void init_attrjeod__JeodSimulationInterface() [friend]

8.9.5.2 friend class InputProcessor [friend]

Definition at line 106 of file simulation interface.hh.

8.9.6 Field Documentation

8.9.6.1 Mode jeod::JeodSimulationInterface::mode [protected]

The mode in which the simulation interface is operating.

trick units(-)

Definition at line 280 of file simulation interface.hh.

Referenced by get_mode(), and set_mode().

8.9.6.2 Mode jeod::JeodSimulationInterface::saved_mode [protected]

The mode prior to a checkpoint or restart process.

set_mode(Restore) restores the mode to this saved value.trick_units(-)

Definition at line 286 of file simulation_interface.hh.

Referenced by set mode().

```
8.9.6.3 JeodSimulationInterface * jeod::JeodSimulationInterface::sim_interface = NULL [static], [protected]
```

The singleton instance of a SimulationInterface object that must be created by a conforming JEOD simulation before any call can be made to one of the three static methods declared above.

The first created instance of a class that derives from this base class becomes **the** SimulationInterface object used during the course of the simulation. Creation of more than one SimulationInterface objects is a non-fatal error. Attempts to allocate memory or generate a message prior creating a SimulationInterface object is a fatal error.trick_io(*o) trick_units(-)

Definition at line 237 of file simulation_interface.hh.

Referenced by create_integrator_interface(), get_address_at_name(), get_checkpoint_reader(), get_checkpoint_writer(), get_job_cycle(), get_memory_interface(), get_name_at_address(), JeodSimulationInterface(), and \sim JeodSimulationInterface().

The documentation for this class was generated from the following files:

- · simulation_interface.hh
- · simulation interface.cc

8.10 jeod::JeodSimulationInterfaceInit Class Reference

Define configuration data needed to configure the dynamically-created message handler and memory manager.

```
#include <simulation_interface.hh>
```

Public Member Functions

JeodSimulationInterfaceInit ()

Construct a JeodSimulationInterfaceInit object.

Data Fields

• unsigned int message_suppression_level

Specifies the message handler's message suppression level; see MessageHandler::suppression_level for details.

· bool message_suppress_id

Specifies the message handler's suppress_id flag; see MessageHandler::suppression_id for details.

• bool message_suppress_location

Specifies the message handler's suppress_location flag; see MessageHandler::suppression_location for details.

· unsigned int memory debug level

Specifies the memory manager's debug level; see JeodMemoryManager::debug_level for details.

8.10.1 Detailed Description

Define configuration data needed to configure the dynamically-created message handler and memory manager. Definition at line 54 of file simulation interface.hh.

8.10.2 Constructor & Destructor Documentation

8.10.2.1 jeod::JeodSimulationInterfaceInit::JeodSimulationInterfaceInit (void)

Construct a JeodSimulationInterfaceInit object.

Definition at line 53 of file simulation interface.cc.

References memory_debug_level, and message_suppression_level.

8.10.3 Field Documentation

 $8.10.3.1 \quad unsigned\ int\ jeod:: JeodSimulationInterfaceInit:: memory_debug_level$

Specifies the memory manager's debug level; see JeodMemoryManager::debug_level for details.

Default value: 0.trick_units(-)

Definition at line 94 of file simulation_interface.hh.

Referenced by jeod::JeodSimulationInterface::configure(), and JeodSimulationInterfaceInit().

8.10.3.2 bool jeod::JeodSimulationInterfaceInit::message_suppress_id

Specifies the message handler's suppress_id flag; see MessageHandler::suppression_id for details.

Default value: false.trick_units(-)

Definition at line 80 of file simulation_interface.hh.

Referenced by jeod::JeodSimulationInterface::configure().

8.10.3.3 bool jeod::JeodSimulationInterfaceInit::message_suppress_location

Specifies the message handler's suppress_location flag; see MessageHandler::suppression_location for details.

Default value: false.trick_units(-)

Definition at line 87 of file simulation interface.hh.

Referenced by jeod::JeodSimulationInterface::configure().

8.10.3.4 unsigned int jeod::JeodSimulationInterfaceInit::message_suppression_level

Specifies the message handler's message suppression level; see MessageHandler::suppression_level for details.

Default value: MessageHandler::Warning (warnings and non-fatal errors).trick units(-)

Definition at line 73 of file simulation interface.hh.

Referenced by jeod::JeodSimulationInterface::configure(), and JeodSimulationInterfaceInit().

The documentation for this class was generated from the following files:


- · simulation interface.hh
- · simulation_interface.cc

8.11 jeod::JeodTrick10MemoryInterface Class Reference

A TrickMemoryInterface implements the two required methods needed to register and deregister memory with the simulation engine, Trick in this case.

#include <trick10_memory_interface.hh>

Inheritance diagram for jeod::JeodTrick10MemoryInterface:



Public Member Functions

JeodTrick10MemoryInterface ()

Construct a JeodTrick10MemoryInterface object.

virtual ~JeodTrick10MemoryInterface ()

Destruct a JeodTrick10MemoryInterface object.

• virtual void register_container (const void *owner, const JeodMemoryTypeDescriptor &owner_type, const char *elem_name, JeodCheckpointable &container)

Register the checkpointable object with Trick.

• virtual void deregister_container (const void *owner, const JeodMemoryTypeDescriptor &owner_type, const char *elem_name, JeodCheckpointable &container)

Revoke the registrations performed by register_container.

virtual const std::string get_name_at_address (const void *addr, const JeodMemoryTypeDescriptor *tdesc)
 const

Get the simulation name, if any, associated with the address.

virtual void * get_address_at_name (const std::string &name) const

Get the address, if any, that corresponds to the given name.

virtual bool is_checkpoint_restart_supported (void) const

The Trick10 memory interface supports checkpoint/restart.

virtual const std::string get_trick_checkpoint_file (bool checkpoint)

Get the name of the current Trick checkpoint file.

· virtual void checkpoint containers (void)

Dump the checkpointable objects to the checkpoint file.

virtual void restore_containers (void)

Restore the checkpointable objects from the checkpoint file.

virtual void checkpoint allocations (void)

Dump the allocation information to the checkpoint file.

virtual void restore_allocations (JeodMemoryManager &memory_manager)

Restore the allocated data per the checkpoint file.

Protected Member Functions

• std::string get_container_id (const ContainerListEntry &entry) const

Construct the identifier for a checkpointable object.

• std::string translate_addr_to_name (const void *addr, const ATTRIBUTES *attr) const

Translate the given address to an address specification string, with the address interpreted in the context of the supplied attributes.

void * translate_name_to_addr (const std::string &spec) const

Translate the given address specification string to an address.

Protected Attributes

Trick::ClassicCheckPointAgent * trick_checkpoint_agent

Trick checkpoint agent.

Private Member Functions

JeodTrick10MemoryInterface (const JeodTrick10MemoryInterface &)

Not implemented.

• JeodTrick10MemoryInterface & operator= (const JeodTrick10MemoryInterface &)

Not implemented.

Friends

- · class InputProcessor
- void init_attrjeod__JeodTrick10MemoryInterface ()

Additional Inherited Members

8.11.1 Detailed Description

A TrickMemoryInterface implements the two required methods needed to register and deregister memory with the simulation engine, Trick in this case.

Definition at line 77 of file trick10_memory_interface.hh.

8.11.2 Constructor & Destructor Documentation

8.11.2.1 jeod::JeodTrick10MemoryInterface::JeodTrick10MemoryInterface (void)

Construct a JeodTrick10MemoryInterface object.

Definition at line 69 of file trick10 memory interface.cc.

References jeod::SimInterfaceMessages::interface_error, trick_checkpoint_agent, and trick_MM.

 $\textbf{8.11.2.2} \quad jeod:: JeodTrick10 MemoryInterface:: \sim JeodTrick10 MemoryInterface (\ void\) \quad [\texttt{virtual}]$

Destruct a JeodTrick10MemoryInterface object.

Definition at line 91 of file trick10_memory_interface.cc.

8.11.2.3 jeod::JeodTrick10MemoryInterface::JeodTrick10MemoryInterface (const JeodTrick10MemoryInterface &) [private]

Not implemented.

8.11.3 Member Function Documentation

8.11.3.1 void jeod::JeodTrick10MemoryInterface::checkpoint_allocations(void) [virtual]

Dump the allocation information to the checkpoint file.

Reimplemented from jeod::JeodTrickMemoryInterface.

Definition at line 438 of file trick_memory_interface_chkpnt.cc.

References jeod::SectionedOutputStream::activate(), jeod::JeodTrickMemoryInterface::allocation_map, jeod::JeodTrickMemoryInterface::container_list, jeod::JeodSimulation-Interface::get_checkpoint_writer(), jeod::SimInterfaceMessages::interface_error, jeod::JeodTrickMemoryInterface::AllocationMapEntry::is_array, jeod::JeodTrickMemoryInterface::AllocationMapEntry::nelements, and jeod::JeodTrickMemoryInterface::AllocationMapEntry::typeid_info.

Referenced by jeod::BasicJeodTrickSimInterface::checkpoint allocations().

8.11.3.2 void jeod::JeodTrick10MemoryInterface::checkpoint_containers(void) [virtual]

Dump the checkpointable objects to the checkpoint file.

Reimplemented from jeod::JeodTrickMemoryInterface.

Definition at line 250 of file trick_memory_interface_chkpnt.cc.

References jeod::SectionedOutputStream::activate(), jeod::JeodTrickMemoryInterface::container_list, jeod::SectionedOutputStream::deactivate(), jeod::JeodSimulationInterface::get_checkpoint_writer(), get_container_id(), and jeod::SimInterfaceMessages::interface_error.

Referenced by jeod::BasicJeodTrickSimInterface::checkpoint_containers().

8.11.3.3 void jeod::JeodTrick10MemoryInterface::deregister_container (const void * owner, const JeodMemoryTypeDescriptor & owner_type, const char * elem_name, JeodCheckpointable & container) [virtual]

Revoke the registrations performed by register_container.

This function is typically called at destruction time via JEOD_DEREGISTER_CHECKPOINTABLE.

Assumptions and Limitations

- · The following unenforced assumptions are made:
 - A corresponding register_container was previously made.
 - Trick has been pre-initialized.

Enforcement of the above is the responsibility the simulation developer, the JEOD memory manager, and the simulation interface.

Parameters

in	owner	Owner of the container
in	owner_type	Owner type descriptor
in	elem_name	Container element
in,out	container	The container

Reimplemented from jeod::JeodTrickMemoryInterface.

Definition at line 152 of file trick_memory_interface_chkpnt.cc.

References jeod::JeodTrickMemoryInterface::container_list, jeod::JeodTrickMemoryInterface::ContainerListEntry::elem_name, jeod::SimInterfaceMessages::interface_error, jeod::JeodTrickMemoryInterface::ContainerListEntry::owner, and jeod::JeodTrickMemoryInterface::ContainerListEntry::owner_type.

8.11.3.4 void * jeod::JeodTrick10MemoryInterface::get_address_at_name (const std::string & name) const [virtual]

Get the address, if any, that corresponds to the given name.

Returns

Name of the address, if any

Parameters

in	name	of an address
		Units: Name

Reimplemented from jeod::JeodTrickMemoryInterface.

Definition at line 126 of file trick memory interface xlate.cc.

References translate_name_to_addr().

8.11.3.5 std::string jeod::JeodTrick10MemoryInterface::get_container_id (const ContainerListEntry & entry) const [protected]

Construct the identifier for a checkpointable object.

Returns

Container ID

Parameters

in	entry	Container list entry

Definition at line 207 of file trick memory interface chkpnt.cc.

References jeod::JeodTrickMemoryInterface::ContainerListEntry::elem_name, jeod::JeodTrickMemoryInterface::ContainerListEntry::owner_type, translate_addr_to_name(), and translate_name_to_addr().

Referenced by checkpoint_containers(), register_container(), and restore_containers().

8.11.3.6 const std::string jeod::JeodTrick10MemoryInterface::get_name_at_address (const void * addr, const JeodMemoryTypeDescriptor * tdesc) const [virtual]

Get the simulation name, if any, associated with the address.

Returns

Name of the address, if any

Parameters

in	addr	Address of memory whose name is to be found
in	tdesc	How to interpret address

Reimplemented from jeod::JeodTrickMemoryInterface.

Definition at line 90 of file trick_memory_interface_xlate.cc.

References translate_addr_to_name(), and translate_name_to_addr().

8.11.3.7 const std::string jeod::JeodTrick10MemoryInterface::get_trick_checkpoint_file (bool checkpoint) [virtual]

Get the name of the current Trick checkpoint file.

Returns

Name of the current Trick checkpoint file.

Units:

Parameters

in	checkpoint	True for checkpoint, false for restart
----	------------	--

Reimplemented from jeod::JeodTrickMemoryInterface.

Definition at line 69 of file trick_memory_interface_xlate.cc.

Referenced by jeod::BasicJeodTrickSimInterface::open_checkpoint_file(), and jeod::BasicJeodTrickSimInterface::open restart file().

8.11.3.8 virtual bool jeod::JeodTrick10MemoryInterface::is_checkpoint_restart_supported (void) const [inline], [virtual]

The Trick10 memory interface supports checkpoint/restart.

Reimplemented from jeod::JeodTrickMemoryInterface.

Definition at line 117 of file trick10_memory_interface.hh.

Referenced by jeod::BasicJeodTrickSimInterface::checkpoint_allocations(), jeod::BasicJeodTrickSimInterface::checkpoint_containers(), jeod::BasicJeodTrickSimInterface::open_checkpoint_file(), jeod::BasicJeodTrickSimInterface::restore_allocations(), and jeod::BasicJeodTrickSimInterface::restore_allocations(), and jeod::BasicJeodTrickSimInterface::restore_containers().

8.11.3.9 JeodTrick10MemoryInterface& jeod::JeodTrick10MemoryInterface::operator= (const JeodTrick10MemoryInterface &) [private]

Not implemented.

8.11.3.10 void jeod::JeodTrick10MemoryInterface::register_container (const void * owner, const JeodMemoryTypeDescriptor & owner_type, const char * elem_name, JeodCheckpointable & container) [virtual]

Register the checkpointable object with Trick.

This function is typically called at construction or initialization time via JEOD REGISTER CHECKPOINTABLE.

Assumptions and Limitations

- The following unenforced assumptions are made:
 - Sim objects have been constructed and registered with Trick.
 - Checkpointable objects are unique.
 - Trick has been pre-initialized.
 - Not in shutdown mode.

Enforcement of the above is the responsibility the simulation developer, the JEOD memory manager, and the simulation interface.

Parameters

in	owner	Owner of the container
in	owner_type	Owner type descriptor
in	elem_name	Container element
in,out	container	The container

Reimplemented from jeod::JeodTrickMemoryInterface.

Definition at line 89 of file trick_memory_interface_chkpnt.cc.

References jeod::JeodTrickMemoryInterface::container_list, jeod::JeodTrickMemoryInterface::ContainerListEntry::elem_name, get_container_id(), jeod::SimInterfaceMessages::interface_error, jeod::JeodTrickMemoryInterface::ContainerListEntry::owner, and jeod::JeodTrickMemoryInterface::ContainerListEntry::owner type.

8.11.3.11 void jeod::JeodTrick10MemoryInterface::restore_allocations (JeodMemoryManager & memory_manager)
[virtual]

Restore the allocated data per the checkpoint file.

Parameters

in,out	memory	JEOD memory manager
	manager	

 $Reimplemented\ from\ jeod:: JeodTrickMemoryInterface.$

Definition at line 508 of file trick memory interface chkpnt.cc.

References jeod::SectionedInputStream::activate(), jeod::JeodTrickMemoryInterface::container_list, jeod::JeodSimulationInterface::get_checkpoint_reader(), and jeod::SimInterfaceMessages::interface_error.

 $Referenced\ by\ jeod:: Basic Jeod Trick SimInterface:: restore_allocations ().$

8.11.3.12 void jeod::JeodTrick10MemoryInterface::restore_containers(void) [virtual]

Restore the checkpointable objects from the checkpoint file.

Reimplemented from jeod::JeodTrickMemoryInterface.

Definition at line 319 of file trick_memory_interface_chkpnt.cc.

References jeod::SectionedInputStream::activate(), jeod::JeodTrickMemoryInterface::ContainerListEntry::container, jeod::JeodTrickMemoryInterface::container_list, jeod::SectionedInputStream::deactivate(), jeod::JeodSimulation-Interface::get_checkpoint_reader(), get_container_id(), and jeod::SimInterfaceMessages::interface_error.

Referenced by jeod::BasicJeodTrickSimInterface::restore containers().

8.11.3.13 std::string jeod::JeodTrick10MemoryInterface::translate_addr_to_name (const void * addr, const ATTRIBUTES * attr) const [protected]

Translate the given address to an address specification string, with the address interpreted in the context of the supplied attributes.

It is the attributes structure that resolves the A versus A.B versus A.B.C ambiguity.

Note

The attributes structure must be that of a pointer type.

Parameters

addr	The address to be translated.
attr	The context in which to interpret the address.

Returns

Address specification string, e.g., &foo.bar.baz[42]

Definition at line 158 of file trick_memory_interface_xlate.cc.

References jeod::SimInterfaceMessages::interface_error, jeod::JeodTrickMemoryInterface::pointer_attributes(), and trick checkpoint agent.

Referenced by get_container_id(), and get_name_at_address().

8.11.3.14 void * jeod::JeodTrick10MemoryInterface::translate_name_to_addr (const std::string & spec) const [protected]

Translate the given address specification string to an address.

This is the inverse of translate_addr_to_name.

Parameters

spec	The address specification to be interpreted.
------	--

Returns

Address corresponding to the address specification.

Definition at line 198 of file trick_memory_interface_xlate.cc.

References jeod::SimInterfaceMessages::interface_error.

Referenced by get_address_at_name(), get_container_id(), and get_name_at_address().

8.11.4 Friends And Related Function Documentation

8.11.4.1 void init_attrjeod__JeodTrick10MemoryInterface() [friend]

8.11.4.2 friend class InputProcessor [friend]

Definition at line 79 of file trick10_memory_interface.hh.

8.11.5 Field Documentation

8.11.5.1 Trick::ClassicCheckPointAgent* jeod::JeodTrick10MemoryInterface::trick_checkpoint_agent [protected]

Trick checkpoint agent.

trick_io(**)

Definition at line 151 of file trick10 memory interface.hh.

Referenced by JeodTrick10MemoryInterface(), and translate_addr_to_name().

The documentation for this class was generated from the following files:


- trick10_memory_interface.hh
- trick10_memory_interface.cc
- · trick_memory_interface_chkpnt.cc
- trick_memory_interface_xlate.cc

8.12 jeod::JeodTrickIntegrator Class Reference

A JeodTrickIntegrator specializes the JeodIntegratorInterface for use with Trick as the simulation engine.

```
#include <jeod_trick_integrator.hh>
```

Inheritance diagram for jeod::JeodTrickIntegrator:



Public Member Functions

• JeodTrickIntegrator ()

Default constructor.

virtual ~JeodTrickIntegrator ()

Destructor.

· virtual

er7_utils::Integration::Technique interpret_integration_type (int integ_technique) const

Interpret the integration technique.

virtual ::Trick::Integrator * get_integrator ()

Get the simulation engine's integrator.

• virtual double get_dt () const

Get the integration cycle time step.

virtual bool get_first_step_derivs_flag () const

Get the flag that tells the simulation engine to compute derivatives on the initial step of each integration cycle.

virtual void set_first_step_derivs_flag (bool value)

Set the flag that tells the simulation engine to compute derivatives on the initial step of each integration cycle.

virtual void reset_first_step_derivs_flag ()

Reset the flag that tells the simulation engine to compute derivatives on the initial step of each integration cycle.

virtual void restore first step derivs flag ()

Restore the flag that tells the simulation engine to compute derivatives on the initial step of each integration cycle to it's value prior to the most recent call to reset first step derivs flag.

• virtual void set_step_number (unsigned int stepno)

Set the step number within an integration cycle.

virtual void set_time (double sim_time)

Update the time model given the simulation time.

Private Member Functions

• JeodTrickIntegrator (const JeodTrickIntegrator &)

Not implemented.

• JeodTrickIntegrator & operator= (const JeodTrickIntegrator &)

Not implemented.

Private Attributes

· TrickJeodIntegrator trick_integrator

Trick integration structure.

· bool default_first_step_deriv

Default value of trick_integrator.first_step_deriv.

Friends

- · class InputProcessor
- void init_attrjeod__JeodTrickIntegrator ()

8.12.1 Detailed Description

A JeodTrickIntegrator specializes the JeodIntegratorInterface for use with Trick as the simulation engine.

Definition at line 87 of file jeod_trick_integrator.hh.

8.12.2 Constructor & Destructor Documentation

```
8.12.2.1 jeod::JeodTrickIntegrator::JeodTrickIntegrator( ) [inline]
```

Default constructor.

Definition at line 97 of file jeod_trick_integrator.hh.

```
8.12.2.2 virtual jeod::JeodTrickIntegrator::~JeodTrickIntegrator() [inline], [virtual]
```

Destructor.

Definition at line 107 of file jeod_trick_integrator.hh.

8.12.2.3 jeod::JeodTrickIntegrator::JeodTrickIntegrator (const JeodTrickIntegrator &) [private]

Not implemented.

8.12.3 Member Function Documentation

8.12.3.1 virtual double jeod::JeodTrickIntegrator::get_dt() const [inline], [virtual]

Get the integration cycle time step.

Returns

Simulation time delta t, in seconds

Definition at line 133 of file jeod_trick_integrator.hh.

References trick_integrator.

```
8.12.3.2 virtual bool jeod::JeodTrickIntegrator::get_first_step_derivs_flag( ) const [inline], [virtual]
```

Get the flag that tells the simulation engine to compute derivatives on the initial step of each integration cycle.

Returns

Value of the first step derivatives flag

Definition at line 143 of file jeod_trick_integrator.hh.

References trick_integrator.

```
8.12.3.3 virtual::Trick::Integrator*jeod::JeodTrickIntegrator::get_integrator() [inline],[virtual]
```

Get the simulation engine's integrator.

Returns

Pointer to the simulation engine's integrator.

Implements jeod::JeodIntegratorInterface.

Definition at line 124 of file jeod_trick_integrator.hh.

References trick_integrator.

```
8.12.3.4 virtual er7_utils::Integration::Technique jeod::JeodTrickIntegrator::interpret_integration_type ( int integ_technique ) const [inline], [virtual]
```

Interpret the integration technique.

Implements jeod::JeodIntegratorInterface.

Definition at line 112 of file jeod_trick_integrator.hh.

8.12.3.5 JeodTrickIntegrator& jeod::JeodTrickIntegrator::operator=(const JeodTrickIntegrator &) [private]

Not implemented.

```
8.12.3.6 virtual void jeod::JeodTrickIntegrator::reset_first_step_derivs_flag( ) [inline], [virtual]
```

Reset the flag that tells the simulation engine to compute derivatives on the initial step of each integration cycle.

Derivatives are always needed just after a reset. The behavior should revert to nominal after the reset has been performed.

Definition at line 164 of file jeod_trick_integrator.hh.

References default first step deriv, and trick integrator.

```
8.12.3.7 virtual void jeod::JeodTrickIntegrator::restore_first_step_derivs_flag( ) [inline], [virtual]
```

Restore the flag that tells the simulation engine to compute derivatives on the initial step of each integration cycle to it's value prior to the most recent call to reset_first_step_derivs_flag.

Definition at line 175 of file jeod trick integrator.hh.

References default_first_step_deriv, and trick_integrator.

```
8.12.3.8 virtual void jeod::JeodTrickIntegrator::set_first_step_derivs_flag (bool value) [inline], [virtual]
```

Set the flag that tells the simulation engine to compute derivatives on the initial step of each integration cycle.

Parameters

in	value	Value of the first step derivatives flag
----	-------	--

Definition at line 153 of file jeod_trick_integrator.hh.

References trick_integrator.

8.12.3.9 virtual void jeod::JeodTrickIntegrator::set_step_number (unsigned int stepno) [inline], [virtual]

Set the step number within an integration cycle.

Parameters

in	stepno	Step number
----	--------	-------------

Definition at line 184 of file jeod_trick_integrator.hh.

References trick_integrator.

8.12.3.10 virtual void jeod::JeodTrickIntegrator::set_time(double sim_time) [inline], [virtual]

Update the time model given the simulation time.

Parameters

	1	
in	sim_time	Simulation time

Definition at line 193 of file jeod_trick_integrator.hh.

References trick_integrator.

8.12.4 Friends And Related Function Documentation

8.12.4.1 void init_attrjeod__JeodTrickIntegrator() [friend]

8.12.4.2 friend class InputProcessor [friend]

Definition at line 88 of file jeod_trick_integrator.hh.

8.12.5 Field Documentation

8.12.5.1 bool jeod::JeodTrickIntegrator::default_first_step_deriv [private]

Default value of trick_integrator.first_step_deriv.

trick units(-)

Definition at line 211 of file jeod trick integrator.hh.

Referenced by reset_first_step_derivs_flag(), and restore_first_step_derivs_flag().

8.12.5.2 TrickJeodIntegrator jeod::JeodTrickIntegrator::trick_integrator [private]

Trick integration structure.

trick_units(-)

Definition at line 206 of file jeod trick integrator.hh.

Referenced by get_dt(), get_first_step_derivs_flag(), get_integrator(), reset_first_step_derivs_flag(), restore_first_step_derivs_flag(), set_first_step_derivs_flag(), set_step_number(), and set_time().

The documentation for this class was generated from the following file:


· jeod_trick_integrator.hh

8.13 jeod::JeodTrickMemoryInterface Class Reference

A TrickMemoryInterface implements the two required methods needed to register and deregister memory with the simulation engine, Trick in this case.

```
#include <trick_memory_interface.hh>
```

Inheritance diagram for jeod::JeodTrickMemoryInterface:



Data Structures

struct AllocationMapEntry

Describes a chunk of JEOD-allocated memory.

struct ContainerListEntry

Describes a Checkpointable object.

Public Member Functions

• JeodTrickMemoryInterface ()

JeodTrickMemoryInterface default constructor.

virtual ~JeodTrickMemoryInterface ()

JeodTrickMemoryInterface destructor.

void set_mode (JeodSimulationInterface::Mode new_mode)

Set the mode and perform mode transitions.

• std::string construct identifier (uint32 t unique id number)

Construct an identifier for a chunk of JEOD-allocated memory.

• virtual struct ATTRIBUTES_tag * find_attributes (const std::string &type_name) const

Find the attributes for a class in the symbol table.

• virtual struct ATTRIBUTES_tag * find_attributes (const std::type_info &data_type) const

Find the attributes for a class in the symbol table.

• virtual struct ATTRIBUTES_tag primitive_attributes (const std::type_info &data_type) const

Create an attributes structure that represents a primitive type.

virtual struct ATTRIBUTES tag pointer attributes (const struct ATTRIBUTES tag &target attr) const

Create an attributes structure that represents a pointer type.

virtual struct ATTRIBUTES_tag void_pointer_attributes () const

Create an attributes structure that represents a void* pointer.

virtual struct ATTRIBUTES_tag structure_attributes (const struct ATTRIBUTES_tag *target_attr, std::size_t target_size) const

Create an attributes structure that represents a structured type.

 virtual bool register_allocation (const void *addr, const JeodMemoryItem &item, const JeodMemoryType-Descriptor &tdesc, const char *file, unsigned int line)

Register newly allocated memory with Trick.

 virtual void deregister_allocation (const void *addr, const JeodMemoryItem &item, const JeodMemoryType-Descriptor &tdesc, const char *file, unsigned int line)

Delete Trick information about some pointer - but not the pointer itself.

• virtual void register_container (const void *owner, const JeodMemoryTypeDescriptor &owner_type, const char *elem name, JeodCheckpointable &container)

Register the checkpointable object with Trick.

• virtual void deregister_container (const void *owner, const JeodMemoryTypeDescriptor &owner_type, const char *elem_name, JeodCheckpointable &container)

Revoke the registrations performed by register_container.

virtual const std::string get_name_at_address (const void *addr, const JeodMemoryTypeDescriptor *tdesc)

Stubbed-out implementation of get_name_at_address for Trick implementations that do not fully support JEOD check-point/restart requirements.

• virtual void * get_address_at_name (const std::string &name) const

Stubbed-out implementation of get_address_at_name for Trick implementations that do not fully support JEOD check-point/restart requirements.

virtual bool is_checkpoint_restart_supported () const

The generic Trick memory interface does not support checkpoint/restart.

virtual const std::string get_trick_checkpoint_file (bool checkpoint)

Get the name of the current Trick checkpoint file.

virtual void checkpoint_containers ()

Dump the container checkpointable objects to the checkpoint file.

virtual void restore_containers ()

Restore the container checkpointables objects from the checkpoint file.

· virtual void checkpoint allocations ()

Dump the allocation information to the checkpoint file.

virtual void restore_allocations (JeodMemoryManager &memory_manager)

Restore the allocated data per the checkpoint file.

Protected Types

typedef std::map< uint32_t,

AllocationMapEntry > AllocationMap

Maps JEOD-allocated data names to (type, size) pairs.

- · typedef std::list
 - < ContainerListEntry > ContainerList

Container of a list of ContainerListEntry objects.

Protected Attributes

void * dlhandle

dlhandle, from dlopen.

• AllocationMap allocation_map

Map of allocated names to type info.

· ContainerList container_list

List of container checkpointables.

const std::string id prefix

Prefix used for constructing a unique name for JEOD-allocated memory.

const uint32_t id_length

Number of digits in the numeric part of the unique identifier.

· JeodSimulationInterface::Mode mode

Simulation interface mode.

Private Member Functions

• JeodTrickMemoryInterface (const JeodTrickMemoryInterface &)

Not implemented.

• JeodTrickMemoryInterface & operator= (const JeodTrickMemoryInterface &)

Not implemented.

Friends

- · class InputProcessor
- void init_attrjeod__JeodTrickMemoryInterface ()

8.13.1 Detailed Description

A TrickMemoryInterface implements the two required methods needed to register and deregister memory with the simulation engine, Trick in this case.

Definition at line 66 of file trick_memory_interface.hh.

8.13.2 Member Typedef Documentation

8.13.2.1 typedef std::map<uint32_t, AllocationMapEntry> jeod::JeodTrickMemoryInterface::AllocationMap [protected]

Maps JEOD-allocated data names to (type, size) pairs.

Definition at line 301 of file trick_memory_interface.hh.

8.13.2.2 typedef std::list<ContainerListEntry> jeod::JeodTrickMemoryInterface::ContainerList [protected]

Container of a list of ContainerListEntry objects.

Definition at line 306 of file trick_memory_interface.hh.

8.13.3 Constructor & Destructor Documentation

8.13.3.1 jeod::JeodTrickMemoryInterface::JeodTrickMemoryInterface()

JeodTrickMemoryInterface default constructor.

Definition at line 62 of file trick_memory_interface.cc.

References dlhandle, and jeod::SimInterfaceMessages::implementation_error.

```
8.13.3.2 jeod::JeodTrickMemoryInterface::~JeodTrickMemoryInterface( ) [virtual]
```

JeodTrickMemoryInterface destructor.

Definition at line 83 of file trick_memory_interface.cc.

References dlhandle.

8.13.3.3 jeod::JeodTrickMemoryInterface::JeodTrickMemoryInterface (const JeodTrickMemoryInterface &) [private]

Not implemented.

8.13.4 Member Function Documentation

8.13.4.1 virtual void jeod::JeodTrickMemoryInterface::checkpoint_allocations(void) [inline], [virtual]

Dump the allocation information to the checkpoint file.

Note

The default implementation does nothing; checkpoint/restart is not supported by default.

Reimplemented in jeod::JeodTrick10MemoryInterface.

Definition at line 195 of file trick_memory_interface.hh.

```
8.13.4.2 virtual void jeod::JeodTrickMemoryInterface::checkpoint_containers(void) [inline], [virtual]
```

Dump the container checkpointable objects to the checkpoint file.

Note

The default implementation does nothing; checkpoint/restart is not supported by default.

Reimplemented in jeod::JeodTrick10MemoryInterface.

Definition at line 179 of file trick_memory_interface.hh.

8.13.4.3 std::string jeod::JeodTrickMemoryInterface::construct_identifier (uint32_t unique_id_number)

Construct an identifier for a chunk of JEOD-allocated memory.

Returns

Identifier string

Parameters

unique_id	Identifier number
number	

Definition at line 110 of file trick_memory_interface.cc.

References id_length, and id_prefix.

Referenced by jeod::JeodTrick10MemoryInterface::checkpoint_allocations(), and register_allocation().

8.13.4.4 void jeod::JeodTrickMemoryInterface::deregister_allocation (const void * addr, const JeodMemoryItem & item, const JeodMemoryTypeDescriptor & tdesc, const char * file, unsigned int line) [virtual]

Delete Trick information about some pointer – but not the pointer itself.

Assumptions and Limitations

• Some other agent must freeing the memory at the input address itself. This function merely deletes Trick's knowledge of that pointer.

Parameters

in	addr	Allocated memory
in	item	Description of the memory
in	tdesc	Description of the type
in	file	Source file containing JEOD_ALLOC
in	line	Line number containing JEOD_ALLOC

Implements jeod::JeodMemoryInterface.

Definition at line 145 of file trick memory interface alloc.cc.

References allocation_map, jeod::SimInterfaceMessages::interface_error, and trick_MM.

8.13.4.5 void jeod::JeodTrickMemoryInterface::deregister_container (const void * owner, const JeodMemoryTypeDescriptor & owner_type, const char * elem_name, JeodCheckpointable & container) [virtual]

Revoke the registrations performed by register_container.

This function is typically called at destruction time via JEOD_DEREGISTER_CHECKPOINTABLE. This default implementation does nothing.

Parameters

in	owner	Owner of the container
in	owner_type	Owner type descriptor
in	elem_name	Container element
in,out	container	The container

Implements jeod::JeodMemoryInterface.

Reimplemented in jeod::JeodTrick10MemoryInterface.

Definition at line 155 of file trick_memory_interface.cc.

8.13.4.6 struct ATTRIBUTES_tag * jeod::JeodTrickMemoryInterface::find_attributes (const std::string & type_name) const [virtual]

Find the attributes for a class in the symbol table.

Returns

Found attributes

Parameters

in	type_name	Demangled type name
	· · · ·	1 2 2.

Implements jeod::JeodMemoryInterface.

Definition at line 63 of file trick_memory_interface_attrib.cc.

References dlhandle, and jeod::SimInterfaceMessages::interface error.

Referenced by find attributes().

8.13.4.7 struct ATTRIBUTES_tag * jeod::JeodTrickMemoryInterface::find_attributes (const std::type_info & data_type) const [virtual]

Find the attributes for a class in the symbol table.

Returns

Found attributes

Parameters

2	data tuna	Data type descriptor
ΤU	data_type	Data type descriptor

Implements jeod::JeodMemoryInterface.

Definition at line 94 of file trick_memory_interface_attrib.cc.

References find_attributes().

8.13.4.8 void * jeod::JeodTrickMemoryInterface::get_address_at_name(const std::string & name) const [virtual]

Stubbed-out implementation of get_address_at_name for Trick implementations that do not fully support JEOD checkpoint/restart requirements.

Returns

Address of named item in memory

Parameters

name	Name of item to be found

Implements jeod::JeodMemoryInterface.

Reimplemented in jeod::JeodTrick10MemoryInterface.

Definition at line 189 of file trick_memory_interface.cc.

8.13.4.9 const std::string jeod::JeodTrickMemoryInterface::get_name_at_address (const void * addr, const JeodMemoryTypeDescriptor * tdesc) const [virtual]

Stubbed-out implementation of get_name_at_address for Trick implementations that do not fully support JEOD checkpoint/restart requirements.

Returns

Name of the address, if any.

Parameters

addr Address of memory whose name is to be found	
tdesc How to interpret address	

Implements jeod::JeodMemoryInterface.

Reimplemented in jeod::JeodTrick10MemoryInterface.

Definition at line 172 of file trick_memory_interface.cc.

8.13.4.10 virtual const std::string jeod::JeodTrickMemoryInterface::get_trick_checkpoint_file (bool checkpoint) [inline], [virtual]

Get the name of the current Trick checkpoint file.

Parameters

in	checkpoint	Irue for checkpoint, false for restart

Returns

Current checkpoint file, or the empty string.

Note

The default implementation always returns the empty string; checkpoint/restart is not supported by default.

Reimplemented in jeod::JeodTrick10MemoryInterface.

Definition at line 167 of file trick memory interface.hh.

8.13.4.11 virtual bool jeod::JeodTrickMemoryInterface::is_checkpoint_restart_supported (void) const [inline], [virtual]

The generic Trick memory interface does not support checkpoint/restart.

Implements jeod::JeodMemoryInterface.

Reimplemented in jeod::JeodTrick10MemoryInterface.

Definition at line 157 of file trick_memory_interface.hh.

8.13.4.12 JeodTrickMemoryInterface& jeod::JeodTrickMemoryInterface::operator= (const JeodTrickMemoryInterface &) [private]

Not implemented.

8.13.4.13 struct ATTRIBUTES_tag jeod::JeodTrickMemoryInterface::pointer_attributes (const struct ATTRIBUTES_tag & target_attr) const [virtual]

Create an attributes structure that represents a pointer type.

Returns

Constructed pointer attributes.

in	target_attr	Pointed-to type attributes.
----	-------------	-----------------------------

Implements jeod::JeodMemoryInterface.

Definition at line 214 of file trick_memory_interface_attrib.cc.

Referenced by jeod::JeodTrick10MemoryInterface::translate_addr_to_name().

8.13.4.14 struct ATTRIBUTES_tag jeod::JeodTrickMemoryInterface::primitive_attributes (const std::type_info & data_type) const [virtual]

Create an attributes structure that represents a primitive type.

Returns

Constructed attributes.

Parameters

in	data_type	Data type descriptor

Implements jeod::JeodMemoryInterface.

Definition at line 108 of file trick_memory_interface_attrib.cc.

References jeod::SimInterfaceMessages::interface_error.

8.13.4.15 bool jeod::JeodTrickMemoryInterface::register_allocation (const void * addr, const JeodMemoryItem & item, const JeodMemoryTypeDescriptor & tdesc, const char * file, unsigned int line) [virtual]

Register newly allocated memory with Trick.

Assumptions and Limitations

- · Memory was indeed allocated.
- The input address is not null.
- The number of elements is positive.

Returns

True if registered

Parameters

in	addr	Allocated memory
in	item	Description of the memory
in	tdesc	Description of the type
in	file	Source file containing JEOD_ALLOC
in	line	Line number containing JEOD_ALLOC

Implements jeod::JeodMemoryInterface.

Definition at line 82 of file trick_memory_interface_alloc.cc.

References allocation_map, construct_identifier(), jeod::SimInterfaceMessages::interface_error, and trick_MM.

8.13.4.16 void jeod::JeodTrickMemoryInterface::register_container (const void * owner, const JeodMemoryTypeDescriptor & owner_type, const char * elem_name, JeodCheckpointable & container) [virtual]

Register the checkpointable object with Trick.

This function is typically called at construction or initialization time via JEOD_REGISTER_CHECKPOINTABLE. This default implementation does nothing.

in	owner	Owner of the container
in	owner_type	Owner type descriptor
in	elem_name	Container element
in,out	container	The container

Implements jeod::JeodMemoryInterface.

Reimplemented in jeod::JeodTrick10MemoryInterface.

Definition at line 134 of file trick_memory_interface.cc.

8.13.4.17 virtual void jeod::JeodTrickMemoryInterface::restore_allocations (JeodMemoryManager & memory_manager) [inline], [virtual]

Restore the allocated data per the checkpoint file.

Parameters

memory	JEOD memory manager
manager	

Note

The default implementation does nothing; checkpoint/restart is not supported by default.

Reimplemented in jeod::JeodTrick10MemoryInterface.

Definition at line 204 of file trick memory interface.hh.

8.13.4.18 virtual void jeod::JeodTrickMemoryInterface::restore_containers(void) [inline], [virtual]

Restore the container checkpointables objects from the checkpoint file.

Note

The default implementation does nothing; checkpoint/restart is not supported by default.

Reimplemented in jeod::JeodTrick10MemoryInterface.

Definition at line 187 of file trick_memory_interface.hh.

8.13.4.19 void jeod::JeodTrickMemoryInterface::set_mode (JeodSimulationInterface::Mode new_mode)

Set the mode and perform mode transitions.

Parameters

new_mode	New mode

Definition at line 97 of file trick_memory_interface.cc.

References mode.

Referenced by jeod::BasicJeodTrickSimInterface::set_mode().

8.13.4.20 struct ATTRIBUTES_tag jeod::JeodTrickMemoryInterface::structure_attributes (const struct ATTRIBUTES_tag * target_attr, std::size_t target_size) const [virtual]

Create an attributes structure that represents a structured type.

Returns

Constructed structure attributes.

Parameters

in	target_attr	Return value from find_attributes.
in	target_size	Structure size.

Implements jeod::JeodMemoryInterface.

Definition at line 287 of file trick memory interface attrib.cc.

8.13.4.21 struct ATTRIBUTES_tag jeod::JeodTrickMemoryInterface::void_pointer_attributes (void) const [virtual]

Create an attributes structure that represents a void* pointer.

Returns

Constructed pointer attributes.

Implements jeod::JeodMemoryInterface.

Definition at line 262 of file trick memory interface attrib.cc.

8.13.5 Friends And Related Function Documentation

8.13.5.1 void init_attrjeod__JeodTrickMemoryInterface() [friend]

8.13.5.2 friend class InputProcessor [friend]

Definition at line 68 of file trick_memory_interface.hh.

8.13.6 Field Documentation

8.13.6.1 AllocationMap jeod::JeodTrickMemoryInterface::allocation_map [protected]

Map of allocated names to type info.

trick_io(**)

Definition at line 319 of file trick_memory_interface.hh.

Referenced by jeod::JeodTrick10MemoryInterface::checkpoint_allocations(), deregister_allocation(), and register_allocation().

8.13.6.2 ContainerList jeod::JeodTrickMemoryInterface::container_list [protected]

List of container checkpointables.

trick_io(**)

Definition at line 324 of file trick_memory_interface.hh.

Referenced by jeod::JeodTrick10MemoryInterface::checkpoint_allocations(), jeod::JeodTrick10MemoryInterface::checkpoint_containers(), jeod::JeodTrick10MemoryInterface::deregister_container(), jeod::JeodTrick10MemoryInterface::restore_allocations(), and jeod::JeodTrick10MemoryInterface::restore_containers().

8.13.6.3 void* jeod::JeodTrickMemoryInterface::dlhandle [protected]

dlhandle, from dlopen.

trick_io(**)

Definition at line 314 of file trick_memory_interface.hh.

Referenced by find_attributes(), JeodTrickMemoryInterface(), and ~JeodTrickMemoryInterface().

8.13.6.4 const uint32_t jeod::JeodTrickMemoryInterface::id_length [protected]

Number of digits in the numeric part of the unique identifier.

trick_io(*o) trick_units(-)

Definition at line 334 of file trick_memory_interface.hh.

Referenced by construct_identifier().

8.13.6.5 const std::string jeod::JeodTrickMemoryInterface::id_prefix [protected]

Prefix used for constructing a unique name for JEOD-allocated memory.

trick_io(*o) trick_units(-)

Definition at line 329 of file trick_memory_interface.hh.

Referenced by construct_identifier().

8.13.6.6 JeodSimulationInterface::Mode jeod::JeodTrickMemoryInterface::mode [protected]

Simulation interface mode.

trick units(-)

Definition at line 339 of file trick_memory_interface.hh.

Referenced by set_mode().

The documentation for this class was generated from the following files:


- trick_memory_interface.hh
- trick_memory_interface.cc
- trick_memory_interface_alloc.cc
- trick_memory_interface_attrib.cc

8.14 jeod::JeodTrickSimInterface Class Reference

A JEODTrickSimInterface implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

#include <trick_sim_interface.hh>

Inheritance diagram for jeod::JeodTrickSimInterface:



Public Member Functions

• JeodTrickSimInterface ()

Non-default constructor.

virtual ~JeodTrickSimInterface ()

Destructor.

Private Member Functions

JeodTrickSimInterface (const JeodTrickSimInterface &)

Not implemented.

• JeodTrickSimInterface & operator= (const JeodTrickSimInterface &)

Not implemented.

Friends

- · class InputProcessor
- void init_attrjeod__JeodTrickSimInterface ()

Additional Inherited Members

8.14.1 Detailed Description

A JEODTrickSimInterface implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

By virtue of member data ownership, the class creates the requisite MessageHandler and MemoryManager and does so in the correct order.

Definition at line 264 of file trick sim interface.hh.

8.14.2 Constructor & Destructor Documentation

```
\textbf{8.14.2.1} \quad \textbf{jeod::JeodTrickSimInterface::JeodTrickSimInterface())} \quad \texttt{[inline], [explicit]}
```

Non-default constructor.

Definition at line 273 of file trick_sim_interface.hh.

```
8.14.2.2 virtual jeod::JeodTrickSimInterface::~JeodTrickSimInterface( ) [inline], [virtual]
```

Destructor.

Definition at line 279 of file trick_sim_interface.hh.

8.14.2.3 jeod::JeodTrickSimInterface::JeodTrickSimInterface &) [private]

Not implemented.

8.14.3 Member Function Documentation

8.14.3.1 JeodTrickSimInterface& jeod::JeodTrickSimInterface::operator=(const JeodTrickSimInterface &) [private]

Not implemented.

8.14.4 Friends And Related Function Documentation

```
8.14.4.1 void init_attrjeod__JeodTrickSimInterface() [friend]
```

8.14.4.2 friend class InputProcessor [friend]

Definition at line 266 of file trick_sim_interface.hh.

The documentation for this class was generated from the following file:


· trick_sim_interface.hh

8.15 jeod::SectionedInputBuffer Class Reference

A SectionedInputBuffer is a std::streambuf that reads from a section in a checkpoint file.

#include <checkpoint_input_manager.hh>

Inheritance diagram for jeod::SectionedInputBuffer:



Public Member Functions

∼SectionedInputBuffer ()

Destructor.

• bool operator! () const

Conversion to boolean.

Private Member Functions

SectionedInputBuffer (void)

Default constructor.

void activate (std::ifstream &stream, std::size_t spos, std::size_t epos)

Activate the object.

· void deactivate (void)

Deactivate the object.

virtual std::streambuf::int_type underflow ()

Get a character in the case of depletion of the read buffer.

SectionedInputBuffer (const SectionedInputBuffer &)

Not implemented.

SectionedInputBuffer & operator= (const SectionedInputBuffer &)

Not implemented.

Private Attributes

std::filebuf * file buf

The file buffer that reads from the checkpoint file.

size_t start_pos

The position of the start of the contents of the checkpoint file section being read by this object.

• size_t end_pos

The position just after the end of the contents of the checkpoint file section being read by this object.

· size_t curr_pos

The current position of the file_buf reader.

· bool at_eof

At EOF in the file or in the section?

· char buf

Input buffer.

Friends

· class SectionedInputStream

8.15.1 Detailed Description

A SectionedInputBuffer is a std::streambuf that reads from a section in a checkpoint file.

This class will indicate EOF when the input pointer in the checkpoint file file buffer goes beyond the end of the section.

This is a barebones implementation. It does not provide buffering, it does not support seek and tell, and it does not support putback or unget.

Note that with the exception of the destructor and the inherited members from std::streambuf, *everything* in this class is private. This class is not extensible.

Definition at line 53 of file checkpoint input manager.hh.

8.15.2 Constructor & Destructor Documentation

8.15.2.1 jeod::SectionedInputBuffer::~SectionedInputBuffer() [inline]

Destructor.

For now, this does nothing.

Definition at line 62 of file checkpoint_input_manager.hh.

8.15.2.2 jeod::SectionedInputBuffer::SectionedInputBuffer(void) [private]

Default constructor.

This constructor creates an empty SectionedInputBuffer – one that will return EOF on the first read attempt. An empty SectionedInputBuffer has two purposes:

- As the basis for a copy constructor of a containing stream, and
- · As a graceful means of handling of erroneous conditions.

Definition at line 45 of file checkpoint input manager.cc.

8.15.2.3 jeod::SectionedInputBuffer::SectionedInputBuffer &) [private]

Not implemented.

8.15.3 Member Function Documentation

8.15.3.1 void jeod::SectionedInputBuffer::activate (std::ifstream & stream, std::size_t spos, std::size_t epos)

[private]

Activate the object.

Note

Using the object for reading prior to activation will result in EOF.

Parameters

in	stream	Checkpoint file input file stream
in	spos	Section data start position
in	epos	Section data end position

Definition at line 68 of file checkpoint_input_manager.cc.

References at_eof, curr_pos, end_pos, file_buf, and start_pos.

Referenced by jeod::SectionedInputStream::activate().

8.15.3.2 void jeod::SectionedInputBuffer::deactivate (void) [inline], [private]

Deactivate the object.

Used to force a badly behaving stream to disconnect.

Definition at line 87 of file checkpoint_input_manager.hh.

References at_eof, and file_buf.

Referenced by jeod::SectionedInputStream::deactivate().

8.15.3.3 bool jeod::SectionedInputBuffer::operator! () const [inline]

Conversion to boolean.

Returns

False if object is OK.

Definition at line 69 of file checkpoint_input_manager.hh.

References file buf.

```
8.15.3.4 SectionedInputBuffer& jeod::SectionedInputBuffer::operator= ( const SectionedInputBuffer & )
         [private]
Not implemented.
8.15.3.5 std::streambuf::int_type jeod::SectionedInputBuffer::underflow(void) [private], [virtual]
Get a character in the case of depletion of the read buffer.
For now, the buffer is always depleted.
Returns
     Character read from the underlying file.
Definition at line 86 of file checkpoint_input_manager.cc.
References at eof, buf, curr pos, end pos, and file buf.
8.15.4 Friends And Related Function Documentation
8.15.4.1 friend class SectionedInputStream [friend]
Definition at line 54 of file checkpoint_input_manager.hh.
8.15.5 Field Documentation
8.15.5.1 bool jeod::SectionedInputBuffer::at_eof [private]
At EOF in the file or in the section?
trick_io(**)
Definition at line 123 of file checkpoint_input_manager.hh.
Referenced by activate(), deactivate(), and underflow().
8.15.5.2 char jeod::SectionedInputBuffer::buf [private]
Input buffer.
trick_io(**)
Definition at line 128 of file checkpoint_input_manager.hh.
Referenced by underflow().
8.15.5.3 size_t jeod::SectionedInputBuffer::curr_pos [private]
The current position of the file_buf reader.
trick_io(**)
```

Definition at line 118 of file checkpoint_input_manager.hh.

Referenced by activate(), and underflow().

8.15.5.4 size_t jeod::SectionedInputBuffer::end_pos [private]

The position just after the end of the contents of the checkpoint file section being read by this object.

trick_io(**)

Definition at line 113 of file checkpoint_input_manager.hh.

Referenced by activate(), and underflow().

```
8.15.5.5 std::filebuf* jeod::SectionedInputBuffer::file_buf [private]
```

The file buffer that reads from the checkpoint file.

trick_io(**)

Definition at line 101 of file checkpoint_input_manager.hh.

Referenced by activate(), deactivate(), operator!(), and underflow().

```
8.15.5.6 size_t jeod::SectionedInputBuffer::start_pos [private]
```

The position of the start of the contents of the checkpoint file section being read by this object.

trick_io(**)

Definition at line 107 of file checkpoint_input_manager.hh.

Referenced by activate().

The documentation for this class was generated from the following files:


- · checkpoint_input_manager.hh
- · checkpoint_input_manager.cc

8.16 jeod::SectionedInputStream Class Reference

A SectionedInputStream is a std::istream that reads from a section in a checkpoint file.

```
#include <checkpoint_input_manager.hh>
```

 $Inheritance\ diagram\ for\ jeod:: Sectioned Input Stream:$



Public Member Functions

SectionedInputStream ()

Construct a SectionedInputStream object.

• SectionedInputStream (const SectionedInputStream &)

Construct a SectionedInputStream object by copying from another.

∼SectionedInputStream ()

Destruct a SectionedInputStream object.

· bool is_activatable () const

Determine if the stream is able to be activated.

• bool activate ()

Activate the object.

void deactivate (void)

Deactivate the object.

• bool operator! () const

Conversion to boolean.

operator void * () const

Conversion to void*.

Private Member Functions

SectionedInputStream (CheckPointInputManager *mngr, std::ifstream &fstream, std::size_t spos, std::size_t epos)

Construct a SectionedInputStream object that is connected to a file stream and to a CheckPointInputManager.

• SectionedInputStream & operator= (const SectionedInputStream &)

Not implemented.

Private Attributes

· SectionedInputBuffer sectbuf

The std::streambuf that does the reading from the file.

CheckPointInputManager * manager

The input manager that created this object.

• std::ifstream * stream

The C++ file stream that reads from the checkpoint file.

· size_t start_pos

The position of the start of the contents of the checkpoint file section being read by this object.

size_t end_pos

The position just after the end of the contents of the checkpoint file section being read by this object.

· bool is_copy

Is this a copy of some other SectionedInputStream? Copies of copies are verboten.

• bool is_active

Is this an active object? In the end, there can be only one.

Friends

class CheckPointInputManager

8.16.1 Detailed Description

A SectionedInputStream is a std::istream that reads from a section in a checkpoint file.

This class will indicate EOF when the input pointer in the checkpoint file file buffer goes beyond the end of the section.

This is a barebones implementation. It does not provide buffering, it does not support seek and tell, and it does not support putback or unget.

Usage

A SectionedInputStream object is used in a preload_checkpoint or restart job to read and then act on contents stored in a checkpoint file.

```
return_type function_name (
  SomeStructureType & stuff_to_restore)
  std::string section_name;
  double number;
  char c_style_line[256];
  std::string cpp_line;
  char character;
  int char_as_int;
  std::string section name;
  // Set to name of the checkpoint section
   // Construct a checkpoint input stream.
   // Notes:
   // - This object must go out of scope by the end of the job.
  // - DO NOT make a copy of this object. // - DO NOT save a pointer to this object in a permanent structure.
   // - The code below assumes that function_name is called as a
        preload_checkpoint or a restart job.
  SectionedInputStream reader (
    JeodSimulationInterface::get_checkpoint_reader(
     section_name));
  // Activate the reader.
  // Fail to do so and you'll get EOF on the first read.
  reader.activate();
  // You can use the C++ operator >> to read various kinds of data ...
  reader >> number;
  // ... even data structures if the structure has a deserializer.
  reader >> stuff_to_restore;
  // Lines can be read with the getline member or std::getline global.
  reader.getline (c_style_line, 255);
  std::getline (reader, cpp_line);
  // Individual characters can be read in a variety of ways.
  reader >> std::noskipws >> character;
  reader.get (character);
  char_as_int = reader.rdbuf()->sbumpc();
  // A bunch of numbers can be read using operator >>:
  while (!! (reader >> number)) {
    stuff_to_restore.add_number (number);
  // An alternative is to implicitly use operator void*:
  while (reader >> number) {
    stuff_to_restore.add_number (number);
  // The file can be scanned via getline, here using the bang-bang trick:
  while (!! std::getline (reader, cpp_string)) {
    process_line (cpp_string);
  // Same as the above, but implicitly using operator void*:
  while (std::getline (reader, cpp_string)) {
    process_line (cpp_string);
  // The file can be processed a character at a time.
  // Once again, either the bang-bang trick or operator void* can be
  // used to check for EOF.
  while (!! std::get (reader, character)) +
     stuff_to_restore.add_char (character);
```

```
}

// Yet another alternative is to test for EOF using sbumpc:
while ((char_as_int = rdbuf->sbumpc()) != EOF) {
    stuff_to_restore.add_char ((char)char_as_int);
}

// Or use sgetc/sbumpc if the above grates too much:
while (reader.rdbuf->sgetc()) != EOF) {
    stuff_to_restore.add_char ((char)reader.rdbuf()->sbumpc());
}
```

Diagnosing problems

- · Nothing is being read. This can be caused by several problems, described below.
- Is the JEOD checkpoint file open for input?
 Checkpoint file sections can only be read from a JEOD checkpoint file that is open for input. In a Trick context, the checkpoint file is only open for preload_checkpoint and restart jobs. Reading from a checkpoint file in other contexts won't work.
- Are multiple threads trying to read from the same checkpoint file?
 Don't do that. This package is not thread-safe.
- Have you cached some another active checkpoint reader somewhere?
 Don't do that, either. Only one reader can be active at a time.
- Is the checkpoint file section in the checkpoint file?
 You will get a diagnostic message if the section doesn't exist.
- Is the checkpoint reader viable?

The above problems will result in a non-viable checkpoint reader. The method is_activatable() can be called prior to calling activate() to check whether the stream is viable.

• Did you call reader.activate()?

Whether compilers make two different objects in the construction of the SectionedInputStream or just one object depends on the compiler and on the optimization level. Making the package robustly handle the complexities of RVO (return value optimization) was too much for the author of the package. The call to reader.activate() is essential.

- Did the call to reader.activate() work?
 The method activate() returns true or false to indicate success or failure. While the above code did not check status, doing so is a good idea.
- Did you call reader.deactivate()?
 Don't do that until you are done reading. The call to deactivate() is irreversible.
- Did you mix scanned input with line reading?
 As with any other stream, operator >> will mark the stream as failed if the operator fails to parse.

Definition at line 273 of file checkpoint input manager.hh.

8.16.2 Constructor & Destructor Documentation

8.16.2.1 jeod::SectionedInputStream::SectionedInputStream ()

Construct a SectionedInputStream object.

Note

This default constructor creates a disconnected and hence unusable stream. Usable streams are created by the non-default constructor.

Definition at line 130 of file checkpoint_input_manager.cc.

8.16.2.2 jeod::SectionedInputStream::SectionedInputStream (const SectionedInputStream & source)

Construct a SectionedInputStream object by copying from another.

Parameters

in	source	Source object

Definition at line 176 of file checkpoint_input_manager.cc.

References jeod::SimInterfaceMessages::implementation error, is active, is copy, manager, and stream.

8.16.2.3 jeod::SectionedInputStream::~SectionedInputStream (void)

Destruct a SectionedInputStream object.

Definition at line 204 of file checkpoint_input_manager.cc.

References jeod::CheckPointInputManager::deregister reader(), is active, and manager.

8.16.2.4 jeod::SectionedInputStream::SectionedInputStream (CheckPointInputManager * mngr, std::ifstream & ifstream, std::size_t spos, std::size_t epos) [private]

Construct a SectionedInputStream object that is connected to a file stream and to a CheckPointInputManager.

Parameters

in	mngr	The stream manager
in	ifstream	The input file stream
in	spos	Start position of section data
in	epos	End position of section data

Definition at line 153 of file checkpoint input manager.cc.

8.16.3 Member Function Documentation

8.16.3.1 bool jeod::SectionedInputStream::activate (void)

Activate the object.

Note

Using the object for reading prior to activation will result in EOF.

Returns

True if activated.

Definition at line 246 of file checkpoint_input_manager.cc.

References jeod::SectionedInputBuffer::activate(), end_pos, jeod::SimInterfaceMessages::implementation_error, is_active, manager, jeod::CheckPointInputManager::register_reader(), sectbuf, start_pos, and stream.

Referenced by jeod::JeodTrick10MemoryInterface::restore_allocations(), and jeod::JeodTrick10MemoryInterface::restore_containers().

8.16.3.2 void jeod::SectionedInputStream::deactivate (void)

Deactivate the object.

Note

Deactivation is undoable.

Definition at line 292 of file checkpoint input manager.cc.

References jeod::SectionedInputBuffer::deactivate(), jeod::CheckPointInputManager::deregister_reader(), is_active, manager, sectbuf, and stream.

Referenced by jeod::CheckPointInputManager::create_trick_section_reader(), and jeod::JeodTrick10Memory-Interface::restore containers().

8.16.3.3 bool jeod::SectionedInputStream::is_activatable (void) const

Determine if the stream is able to be activated.

Returns

True if object can be activated.

Definition at line 219 of file checkpoint_input_manager.cc.

References jeod::CheckPointInputManager::have_active_reader(), is_active, manager, and stream.

8.16.3.4 jeod::SectionedInputStream::operator void * () const [inline]

Conversion to void*.

This method provides an alternative to the bang-bang trick to determine if the object is OK.

Returns

this pointer (cast to void*) if object is OK, NULL otherwise.

Definition at line 310 of file checkpoint_input_manager.hh.

8.16.3.5 bool jeod::SectionedInputStream::operator! () const [inline]

Conversion to boolean.

Use the bang-bang trick to determine if the object is OK.

Returns

False if object is OK, true if something is wrong.

Definition at line 301 of file checkpoint_input_manager.hh.

References is_active, sectbuf, and stream.

8.16.3.6 SectionedInputStream&jeod::SectionedInputStream::operator=(const SectionedInputStream &)
[private]

Not implemented.

8.16.4 Friends And Related Function Documentation

8.16.4.1 friend class CheckPointInputManager [friend]

Definition at line 274 of file checkpoint_input_manager.hh.

8.16.5 Field Documentation

```
8.16.5.1 size_t jeod::SectionedInputStream::end_pos [private]
```

The position just after the end of the contents of the checkpoint file section being read by this object.

trick_io(**)

Definition at line 351 of file checkpoint_input_manager.hh.

Referenced by activate().

```
8.16.5.2 bool jeod::SectionedInputStream::is_active [private]
```

Is this an active object? In the end, there can be only one.

trick io(**)

Definition at line 363 of file checkpoint_input_manager.hh.

Referenced by activate(), deactivate(), is_activatable(), operator!(), SectionedInputStream(), and \sim SectionedInputStream().

```
8.16.5.3 bool jeod::SectionedInputStream::is_copy [private]
```

Is this a copy of some other SectionedInputStream? Copies of copies are verboten.

trick_io(**)

Definition at line 357 of file checkpoint_input_manager.hh.

Referenced by SectionedInputStream().

8.16.5.4 CheckPointInputManager* jeod::SectionedInputStream::manager [private]

The input manager that created this object.

trick_io(**)

Definition at line 334 of file checkpoint input manager.hh.

Referenced by activate(), deactivate(), is_activatable(), SectionedInputStream(), and ~SectionedInputStream().

8.16.5.5 SectionedInputBuffer jeod::SectionedInputStream::sectbuf [private]

The std::streambuf that does the reading from the file.

trick_io(**)

Definition at line 329 of file checkpoint_input_manager.hh.

Referenced by activate(), deactivate(), and operator!().

```
8.16.5.6 size_t jeod::SectionedInputStream::start_pos [private]
```

The position of the start of the contents of the checkpoint file section being read by this object.

trick_io(**)

Definition at line 345 of file checkpoint_input_manager.hh.

Referenced by activate().

8.16.5.7 std::ifstream* jeod::SectionedInputStream::stream [private]

The C++ file stream that reads from the checkpoint file.

trick_io(**)

Definition at line 339 of file checkpoint input manager.hh.

Referenced by activate(), deactivate(), is_activatable(), operator!(), and SectionedInputStream().

The documentation for this class was generated from the following files:


- checkpoint_input_manager.hh
- · checkpoint_input_manager.cc

8.17 jeod::SectionedOutputBuffer Class Reference

A SectionedOutputBuffer is a std::streambuf that writes a section of a checkpoint file.

#include <checkpoint_output_manager.hh>

Inheritance diagram for jeod::SectionedOutputBuffer:



Public Member Functions

∼SectionedOutputBuffer ()

Destructor.

• bool operator! () const

Conversion to boolean.

Private Member Functions

SectionedOutputBuffer (void)

Default constructor.

- SectionedOutputBuffer (std::ofstream *stream)
- void activate (std::ofstream &stream)

Activate the object.

· void deactivate (void)

Deactivate the object.

virtual std::streambuf::int_type overflow (std::streambuf::int_type c)

Write a character in the case of overflow of the write buffer.

• SectionedOutputBuffer (const SectionedOutputBuffer &)

Not implemented.

• SectionedOutputBuffer & operator= (const SectionedOutputBuffer &)

Not implemented.

Private Attributes

std::filebuf * file buf

The file buffer that writes to the checkpoint file.

Friends

· class SectionedOutputStream

8.17.1 Detailed Description

A SectionedOutputBuffer is a std::streambuf that writes a section of a checkpoint file.

This is a barebones implementation. It does not provide buffering, and it does not support seek and tell.

Note that with the exception of the destructor and the inherited members from std::streambuf, *everything* in this class is private. This class is not extensible.

Definition at line 50 of file checkpoint_output_manager.hh.

8.17.2 Constructor & Destructor Documentation

```
8.17.2.1 jeod::SectionedOutputBuffer::~SectionedOutputBuffer( ) [inline]
```

Destructor.

For now, this does nothing.

Definition at line 59 of file checkpoint_output_manager.hh.

```
8.17.2.2 jeod::SectionedOutputBuffer::SectionedOutputBuffer(void) [private]
```

Default constructor.

This constructor creates an empty SectionedOutputBuffer – one that will return EOF on the first write attempt. An empty SectionedOutputBuffer has two purposes:

- · As the basis for a copy constructor of a containing stream, and
- · As a graceful means of handling of erroneous conditions.

Definition at line 45 of file checkpoint_output_manager.cc.

```
8.17.2.3 jeod::SectionedOutputBuffer::SectionedOutputBuffer ( std::ofstream * stream ) [explicit], [private]
```

8.17.2.4 jeod::SectionedOutputBuffer::SectionedOutputBuffer (const SectionedOutputBuffer &) [private]

Not implemented.

8.17.3 Member Function Documentation

```
8.17.3.1 void jeod::SectionedOutputBuffer::activate ( std::ofstream & stream ) [private]
```

Activate the object.

Note

Using the object for writing prior to activation will result in EOF.

Parameters

in	stream	Output file stream

Definition at line 61 of file checkpoint_output_manager.cc.

References file_buf.

Referenced by jeod::SectionedOutputStream::activate().

8.17.3.2 void jeod::SectionedOutputBuffer::deactivate (void) [inline], [private]

Deactivate the object.

Used to disconnect the buffer when the stream is done, sometimes by force.

Definition at line 85 of file checkpoint_output_manager.hh.

References file_buf.

Referenced by jeod::SectionedOutputStream::deactivate().

8.17.3.3 bool jeod::SectionedOutputBuffer::operator! () const [inline]

Conversion to boolean.

Returns

False if object is OK.

Definition at line 66 of file checkpoint_output_manager.hh.

References file_buf.

8.17.3.4 SectionedOutputBuffer& jeod::SectionedOutputBuffer::operator= (const SectionedOutputBuffer &) [private]

Not implemented.

8.17.3.5 std::streambuf::int_type jeod::SectionedOutputBuffer::overflow(std::streambuf::int_type ch) [private], [virtual]

Write a character in the case of overflow of the write buffer.

For now, the buffer always overflows.

Returns

Status: EOF => failed

Parameters

in	ch	Character to be writter
----	----	-------------------------

Definition at line 76 of file checkpoint_output_manager.cc.

References file_buf.

8.17.4 Friends And Related Function Documentation

8.17.4.1 friend class SectionedOutputStream [friend]

Definition at line 51 of file checkpoint_output_manager.hh.

8.17.5 Field Documentation

8.17.5.1 std::filebuf* jeod::SectionedOutputBuffer::file_buf [private]

The file buffer that writes to the checkpoint file.

trick_io(**)

Definition at line 101 of file checkpoint_output_manager.hh.

Referenced by activate(), deactivate(), operator!(), and overflow().

The documentation for this class was generated from the following files:


- checkpoint_output_manager.hh
- checkpoint_output_manager.cc

8.18 jeod::SectionedOutputStream Class Reference

A SectionedOutputStream is a std::ostream that writes a section of a checkpoint file.

#include <checkpoint_output_manager.hh>

Inheritance diagram for jeod::SectionedOutputStream:



Public Member Functions

SectionedOutputStream ()

Construct a SectionedOutputStream object.

• SectionedOutputStream (const SectionedOutputStream &)

Construct a SectionedOutputStream object by copying from another.

∼SectionedOutputStream ()

Destruct a SectionedOutputStream object.

• bool is_activatable () const

Determine if the stream is able to be activated.

• bool activate ()

Activate the object.

· void deactivate ()

Deactivate the object.

• bool operator! () const

Conversion to boolean.

operator void * () const

Conversion to void*.

Private Member Functions

• SectionedOutputStream (CheckPointOutputManager *mngr, std::ofstream &ofstream, const std::string &start_marker, const std::string §ion_name)

Construct a SectionedOutputStream object that is connected to a file stream and to a CheckPointOutputManager.

SectionedOutputStream & operator= (const SectionedOutputStream &)

Not implemented.

Private Attributes

· SectionedOutputBuffer sectbuf

The std::streambuf that does the writing to the file.

CheckPointOutputManager * manager

The input manager that created this object.

• std::ofstream * stream

The C++ file stream that writes to the checkpoint file.

const std::string * section_start

The string that indicates the start of a checkpoint file section.

const std::string * section end

The string that indicates the start of a checkpoint file section.

const std::string tag

The name of the checkpoint file section.

· bool is_copy

Is this a copy of some other SectionedOutputStream? Copies of copies are verboten.

bool is_active

Is this an active object? In the end, there can be only one.

Friends

· class CheckPointOutputManager

8.18.1 Detailed Description

A SectionedOutputStream is a std::ostream that writes a section of a checkpoint file.

This class automatically writes the start and end markers. Standard C++ output mechanisms can be used to write the contents of the section.

This is a barebones implementation. It does not provide buffering, it does not support seek and tell, and it does not support putback or unget.

Note that most of the content of this class is private. This class is not extensible and is intended to be used within the context of a CheckPointOutputManager.

Definition at line 132 of file checkpoint_output_manager.hh.

8.18.2 Constructor & Destructor Documentation

8.18.2.1 jeod::SectionedOutputStream::SectionedOutputStream ()

Construct a SectionedOutputStream object.

Note

This default constructor creates a disconnected and hence unusable stream. Usable streams are created by the non-default constructor.

Definition at line 118 of file checkpoint_output_manager.cc.

8.18.2.2 jeod::SectionedOutputStream::SectionedOutputStream (const SectionedOutputStream & source)

Construct a SectionedOutputStream object by copying from another.

Parameters

in	source	Source object

Definition at line 168 of file checkpoint output manager.cc.

References jeod::SimInterfaceMessages::implementation_error, is_active, is_copy, manager, and stream.

8.18.2.3 jeod::SectionedOutputStream::~SectionedOutputStream (void)

Destruct a SectionedOutputStream object.

Definition at line 197 of file checkpoint_output_manager.cc.

References deactivate().

8.18.2.4 jeod::SectionedOutputStream::SectionedOutputStream (CheckPointOutputManager * mngr, std::ofstream & ofstream, const std::string & start_marker, const std::string & end_marker, const std::string & section_name)

[private]

Construct a SectionedOutputStream object that is connected to a file stream and to a CheckPointOutputManager.

Parameters

in	mngr	The stream manager
in	ofstream	The output file stream
in	start_marker	Start of section marker
in	end_marker	End of section marker
in	section_name	Name of the section

Definition at line 143 of file checkpoint_output_manager.cc.

8.18.3 Member Function Documentation

8.18.3.1 bool jeod::SectionedOutputStream::activate (void)

Activate the object.

Note

Using the object for writing prior to activation will write nothing.

Returns

True if activated.

Definition at line 237 of file checkpoint output manager.cc.

References jeod::SectionedOutputBuffer::activate(), jeod::SimInterfaceMessages::implementation_error, is_active, manager, jeod::CheckPointOutputManager::register_writer(), sectbuf, section_start, stream, and tag.

Referenced by jeod::JeodTrick10MemoryInterface::checkpoint_allocations(), and jeod::JeodTrick10MemoryInterface::checkpoint containers().

8.18.3.2 void jeod::SectionedOutputStream::deactivate (void)

Deactivate the object.

Note

Deactivation is undoable.

Definition at line 291 of file checkpoint_output_manager.cc.

References jeod::SectionedOutputBuffer::deactivate(), jeod::CheckPointOutputManager::deregister_writer(), is_active, manager, sectbuf, section end, stream, and tag.

Referenced by jeod::JeodTrick10MemoryInterface::checkpoint_containers(), jeod::CheckPointOutputManager::create_trick_section_writer(), and \sim SectionedOutputStream().

8.18.3.3 bool jeod::SectionedOutputStream::is_activatable (void) const

Determine if the stream is able to be activated.

Returns

True if object can be activated.

Definition at line 210 of file checkpoint_output_manager.cc.

References jeod::CheckPointOutputManager::have_active_writer(), is_active, manager, and stream.

8.18.3.4 jeod::SectionedOutputStream::operator void * () const [inline]

Conversion to void*.

This method provides an alternative to the bang-bang trick to determine if the object is OK.

Returns

this pointer (cast to void*) if object is OK, NULL otherwise.

Definition at line 168 of file checkpoint_output_manager.hh.

8.18.3.5 bool jeod::SectionedOutputStream::operator! () const [inline]

Conversion to boolean.

Returns

False if object is OK.

Definition at line 159 of file checkpoint output manager.hh.

References is_active, sectbuf, and stream.

8.18.3.6 SectionedOutputStream&jeod::SectionedOutputStream::operator=(const SectionedOutputStream &)

[private]

Not implemented.

8.18.4 Friends And Related Function Documentation

8.18.4.1 friend class CheckPointOutputManager [friend]

Definition at line 133 of file checkpoint_output_manager.hh.

8.18.5 Field Documentation

8.18.5.1 bool jeod::SectionedOutputStream::is_active [private]

Is this an active object? In the end, there can be only one.

trick_io(**)

Definition at line 225 of file checkpoint_output_manager.hh.

Referenced by activate(), deactivate(), is_activatable(), operator!(), and SectionedOutputStream().

8.18.5.2 bool jeod::SectionedOutputStream::is_copy [private]

Is this a copy of some other SectionedOutputStream? Copies of copies are verboten.

trick_io(**)

Definition at line 219 of file checkpoint output manager.hh.

Referenced by SectionedOutputStream().

8.18.5.3 CheckPointOutputManager* jeod::SectionedOutputStream::manager [private]

The input manager that created this object.

trick_io(**)

Definition at line 193 of file checkpoint output manager.hh.

Referenced by activate(), deactivate(), is_activatable(), and SectionedOutputStream().

8.18.5.4 SectionedOutputBuffer jeod::SectionedOutputStream::sectbuf [private]

The std::streambuf that does the writing to the file.

trick_io(**)

Definition at line 188 of file checkpoint output manager.hh.

Referenced by activate(), deactivate(), and operator!().

 $\textbf{8.18.5.5} \quad \textbf{const std::string}* \textbf{jeod::SectionedOutputStream::section_end} \quad \texttt{[private]}$

The string that indicates the start of a checkpoint file section.

trick io(**)

Definition at line 208 of file checkpoint_output_manager.hh.

Referenced by deactivate().

8.18.5.6 const std::string* jeod::SectionedOutputStream::section_start [private]

The string that indicates the start of a checkpoint file section.

trick_io(**)

Definition at line 203 of file checkpoint_output_manager.hh.

Referenced by activate().

8.18.5.7 std::ofstream* **jeod::SectionedOutputStream::stream** [private]

The C++ file stream that writes to the checkpoint file.

trick_io(**)

Definition at line 198 of file checkpoint_output_manager.hh.

Referenced by activate(), deactivate(), is_activatable(), operator!(), and SectionedOutputStream().

8.18.5.8 const std::string jeod::SectionedOutputStream::tag [private]

The name of the checkpoint file section.

trick_io(**)

Definition at line 213 of file checkpoint_output_manager.hh.

Referenced by activate(), and deactivate().

The documentation for this class was generated from the following files:

- checkpoint_output_manager.hh
- · checkpoint_output_manager.cc

8.19 jeod::CheckPointInputManager::SectionInfo Struct Reference

A SectionInfo contains the start and end positions of a checkpoint file section.

Public Member Functions

SectionInfo (std::size_t start, std::size_t end)

Non-default constructor.

Data Fields

· size t start pos

Position of the first readable character of a section.

size_t end_pos

Position of the first unreadable character after a section.

8.19.1 Detailed Description

A SectionInfo contains the start and end positions of a checkpoint file section.

Definition at line 436 of file checkpoint_input_manager.hh.

8.19.2 Constructor & Destructor Documentation

8.19.2.1 jeod::CheckPointInputManager::SectionInfo::SectionInfo (std::size_t start, std::size_t end) [inline]

Non-default constructor.

Parameters

in	start	Start position
in	end	End position

Definition at line 452 of file checkpoint input manager.hh.

8.19.3 Field Documentation

8.19.3.1 size_t jeod::CheckPointInputManager::SectionInfo::end_pos

Position of the first unreadable character after a section.

trick_io(**)

Definition at line 445 of file checkpoint input manager.hh.

 $Referenced\ by\ jeod:: CheckPointInputManager:: create_section_reader().$

8.19.3.2 size_t jeod::CheckPointInputManager::SectionInfo::start_pos

Position of the first readable character of a section.

trick_io(**)

Definition at line 440 of file checkpoint_input_manager.hh.

Referenced by jeod::CheckPointInputManager::create_section_reader().

The documentation for this struct was generated from the following file:

· checkpoint_input_manager.hh

8.20 jeod::SimInterfaceMessages Class Reference

Specifies the message IDs used in the sim interface model.

#include <sim_interface_messages.hh>

Static Public Attributes

• static char const * singleton error = "utils/sim interface/" "singleton error"

Message issued when multiple instance of a class that should be a singleton are created or when no such instance exists (but should).

• static char const * interface_error = "utils/sim_interface/" "interface_error"

Message issued when issues arise from interacting with the sim engine.

• static char const * phasing error = "utils/sim interface/" "phasing error"

Message issued when things happen out of order.

static char const * integration_error = "utils/sim_interface/" "integration_error"

Message issued when something goes awry with integration.

• static char const * implementation_error = "utils/sim_interface/" "implementation_error"

Message issued when something went wrong with the implementation.

Private Member Functions

- SimInterfaceMessages (void)
- SimInterfaceMessages (const SimInterfaceMessages &)
- SimInterfaceMessages & operator= (const SimInterfaceMessages &)

8.20.1 Detailed Description

Specifies the message IDs used in the sim interface model.

Definition at line 45 of file sim_interface_messages.hh.

8.20.2 Constructor & Destructor Documentation

```
8.20.2.1 jeod::SimInterfaceMessages::SimInterfaceMessages ( void ) [private]
```

8.20.2.2 jeod::SimInterfaceMessages::SimInterfaceMessages (const SimInterfaceMessages &) [private]

8.20.3 Member Function Documentation

8.20.3.1 SimInterfaceMessages& jeod::SimInterfaceMessages::operator=(const SimInterfaceMessages &)

[private]

8.20.4 Field Documentation

8.20.4.1 char const * jeod::SimInterfaceMessages::implementation_error = "utils/sim_interface/" "implementation_error" [static]

Message issued when something went wrong with the implementation.

trick units(-)

Definition at line 75 of file sim interface messages.hh.

Referenced by jeod::SectionedOutputStream::activate(), jeod::SectionedInputStream::activate(), jeod::CheckPointInputManager::CheckPointInputManager(), jeod::CheckPointOutputManager::CheckPointOutputManager(), jeod::CheckPointOutputManager::create_section_reader(), jeod::CheckPointOutputManager::create_section_writer(), jeod::CheckPointInputManager::initialize(), jeod::JeodTrickMemoryInterface::JeodTrickMemoryInterface(), jeod::SectionedInputStream::SectionedOutputStream(), and jeod::JeodSimulationInterface::set_mode().

```
8.20.4.2 char const * jeod::SimInterfaceMessages::integration error = "utils/sim_interface/" "integration error" [static]
```

Message issued when something goes awry with integration.

 $trick_units(-)$

Definition at line 70 of file sim_interface_messages.hh.

Referenced by jeod::JeodDynbodyIntegrationLoop::add_integrable_object(), jeod::JeodDynbodyIntegrationLoop::initialize_integ_loop(), jeod::JeodDynbodyIntegrationLoop::integrate_dt(), jeod::JeodDynbodyIntegrationLoop::JeodDynbodyIntegrationLoop::update_integration_group().

```
8.20.4.3 char const * jeod::SimInterfaceMessages::interface_error = "utils/sim_interface/" "interface_error" [static]
```

Message issued when issues arise from interacting with the sim engine.

trick_units(-)

Definition at line 60 of file sim_interface_messages.hh.

Referenced by jeod::JeodTrick10MemoryInterface::checkpoint_allocations(), jeod::JeodTrick10MemoryInterface::checkpoint_containers(), jeod::JeodTrickMemoryInterface::deregister_allocation(), jeod::JeodTrick10MemoryInterface::deregister_container(), jeod::JeodTrickMemoryInterface::find_attributes(), jeod::JeodTrick10MemoryInterface::primitive_attributes(), jeod::JeodTrickMemoryInterface::primitive_attributes(), jeod::JeodTrickMemoryInterface::register_container(), jeod::JeodTrick10MemoryInterface::register_containers(), jeod::JeodTrick10MemoryInterface::restore_allocations(), jeod::JeodTrick10MemoryInterface::restore_containers(), jeod::JeodTrick10MemoryInterface::translate_addr_to_name(), and jeod::JeodTrick10MemoryInterface::translate_name_to_addr().

8.20.4.4 char const * jeod::SimInterfaceMessages::phasing_error = "utils/sim_interface/" "phasing_error" [static]

Message issued when things happen out of order.

trick units(-)

Definition at line 65 of file sim interface messages.hh.

Referenced by jeod::BasicJeodTrickSimInterface::get_checkpoint_reader_internal(), jeod::BasicJeodTrickSimInterface::get_checkpoint_writer_internal(), and jeod::JeodSimulationInterface::set_mode().

8.20.4.5 char const * jeod::SimInterfaceMessages::singleton_error = "utils/sim_interface/" "singleton_error" [static]

Message issued when multiple instance of a class that should be a singleton are created or when no such instance exists (but should).

trick units(-)

Definition at line 55 of file sim_interface_messages.hh.

Referenced by jeod::JeodSimulationInterface::create_integrator_interface(), jeod::JeodSimulationInterface::get_address_at_name(), jeod::JeodSimulationInterface::get_checkpoint_reader(), jeod::JeodSimulationInterface::get_checkpoint_writer(), jeod::JeodSimulationInterface::get_job_cycle(), jeod::JeodSimulationInterface::get_memory_interface(), jeod::JeodSimulationInterface::get_name_at_address(), and jeod::JeodSimulationInterface::JeodSimulationInterface().

The documentation for this class was generated from the following files:


- sim_interface_messages.hh
- · sim interface messages.cc

8.21 jeod::TrickJeodIntegrator Class Reference

A TrickJeodIntegrator specializes the Trick::Integrator to provide the Trick side of the integration interface between Trick and JEOD.

#include <jeod_trick_integrator.hh>

Inheritance diagram for jeod::TrickJeodIntegrator:



Public Member Functions

virtual ∼TrickJeodIntegrator ()

Destructor.

• int integrate ()

Does nothing.

void initialize (int, double)

Does nothing.

8.21.1 Detailed Description

A TrickJeodIntegrator specializes the Trick::Integrator to provide the Trick side of the integration interface between Trick and JEOD.

Definition at line 51 of file jeod trick integrator.hh.

8.21.2 Constructor & Destructor Documentation

```
8.21.2.1 virtual jeod::TrickJeodIntegrator::~TrickJeodIntegrator( ) [inline], [virtual]
```

Destructor.

Definition at line 64 of file jeod_trick_integrator.hh.

8.21.3 Member Function Documentation

```
8.21.3.1 void jeod::TrickJeodIntegrator::initialize ( int , double ) [inline]
```

Does nothing.

Definition at line 79 of file jeod_trick_integrator.hh.

```
8.21.3.2 int jeod::TrickJeodIntegrator::integrate() [inline]
```

Does nothing.

Definition at line 74 of file jeod_trick_integrator.hh.

The documentation for this class was generated from the following file:


• jeod_trick_integrator.hh

8.22 jeod::TrickMessageHandler Class Reference

The MessageHandler class for designed for use in Trick-based simulations.

```
#include <trick_message_handler.hh>
```

Inheritance diagram for jeod::TrickMessageHandler:



Public Member Functions

TrickMessageHandler (void)

Default constructor.

virtual ~TrickMessageHandler (void)

Destructor.

· virtual void register_contents (void)

Register the TrickMessageHandler's checkpointable contents.

Protected Member Functions

 virtual void process_message (int severity, const char *prefix, const char *file, unsigned int line, const char *msg_code, const char *format, va_list args) const

Handle a message.

Private Member Functions

• TrickMessageHandler (const TrickMessageHandler &)

Not implemented.

TrickMessageHandler & operator= (const TrickMessageHandler &)

Not implemented.

Friends

- class InputProcessor
- void init_attrjeod__TrickMessageHandler ()

8.22.1 Detailed Description

The MessageHandler class for designed for use in Trick-based simulations.

Definition at line 58 of file trick_message_handler.hh.

8.22.2 Constructor & Destructor Documentation

```
8.22.2.1 jeod::TrickMessageHandler::TrickMessageHandler( void ) [inline]
```

Default constructor.

Definition at line 75 of file trick_message_handler.hh.

```
\textbf{8.22.2.2} \quad \textbf{virtual jeod::TrickMessageHandler::} \sim \textbf{TrickMessageHandler(void)} \quad [\texttt{inline}], [\texttt{virtual}]
```

Destructor.

Definition at line 80 of file trick_message_handler.hh.

8.22.2.3 jeod::TrickMessageHandler::TrickMessageHandler &) [private]

Not implemented.

8.22.3 Member Function Documentation

8.22.3.1 TrickMessageHandler& jeod::TrickMessageHandler::operator= (const TrickMessageHandler &) [private]

Not implemented.

8.22.3.2 void jeod::TrickMessageHandler::process_message (int *severity*, const char * *prefix*, const char * *file*, unsigned int *line*, const char * *msg_code*, const char * *format*, va_list *args*) const [protected], [virtual]

Handle a message.

All calls to the message-generating MessageHandler methods eventually result in a call to thisTrickMessage-Handler::process_message method. This method uses the Trick function exec_terminate to process fatal errors. The Trick function send_hs is used for all non-fatal messages, but only if the message severity is at or below the message suppression level.

Parameters

in	severity	Severity level
in	prefix	Message prefix (e.g., Error)
in	file	Typically FILE
in	line	Typically LINE
in	msg_code	Message code
in	format	sprintf format
in	args	Arguments

Definition at line 91 of file trick_message_handler.cc.

References MAX_MSG_SIZE.

8.22.3.3 void jeod::TrickMessageHandler::register_contents (void) [virtual]

Register the TrickMessageHandler's checkpointable contents.

Definition at line 67 of file trick_message_handler.cc.

8.22.4 Friends And Related Function Documentation

```
8.22.4.1 void init_attrjeod__TrickMessageHandler() [friend]
```

8.22.4.2 friend class InputProcessor [friend]

Definition at line 59 of file trick_message_handler.hh.

The documentation for this class was generated from the following files:


- trick_message_handler.hh
- trick_message_handler.cc

8.23 jeod::TrickMessageHandlerMixin Class Reference

The TrickMessageHandlerMixin implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

#include <trick_sim_interface.hh>

Inheritance diagram for jeod::TrickMessageHandlerMixin:



Public Member Functions

• TrickMessageHandlerMixin ()

Default constructor.

virtual ∼TrickMessageHandlerMixin ()

Destructor.

Protected Attributes

· TrickMessageHandler message handler

The global MessageHandler.

Private Member Functions

TrickMessageHandlerMixin (const TrickMessageHandlerMixin &)

Not implemented.

TrickMessageHandlerMixin & operator= (const TrickMessageHandlerMixin &)

Not implemented.

Friends

- · class InputProcessor
- void init_attrjeod__TrickMessageHandlerMixin ()

8.23.1 Detailed Description

The TrickMessageHandlerMixin implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

By virtue of member data ownership, the class creates the requisite MessageHandler and MemoryManager and does so in the correct order.

Definition at line 215 of file trick_sim_interface.hh.

8.23.2 Constructor & Destructor Documentation

8.23.2.1 jeod::TrickMessageHandlerMixin::TrickMessageHandlerMixin() [inline]

Default constructor.

Definition at line 223 of file trick_sim_interface.hh.

8.23.2.2 virtual jeod::TrickMessageHandlerMixin::~TrickMessageHandlerMixin() [inline], [virtual]

Destructor.

Definition at line 228 of file trick_sim_interface.hh.

8.23.2.3 jeod::TrickMessageHandlerMixin::TrickMessageHandlerMixin (const TrickMessageHandlerMixin &) [private]

Not implemented.

8.23.3 Member Function Documentation

8.23.3.1 TrickMessageHandlerMixin& jeod::TrickMessageHandlerMixin::operator= (const TrickMessageHandlerMixin &) [private]

Not implemented.

8.23.4 Friends And Related Function Documentation

8.23.4.1 void init_attrjeod__TrickMessageHandlerMixin() [friend]

8.23.4.2 friend class InputProcessor [friend]

Definition at line 216 of file trick_sim_interface.hh.

8.23.5 Field Documentation

8.23.5.1 TrickMessageHandler jeod::TrickMessageHandler Mixin::message_handler [protected]

The global MessageHandler.

trick_units(-)

Definition at line 237 of file trick_sim_interface.hh.

The documentation for this class was generated from the following file:

• trick_sim_interface.hh

Chapter 9

File Documentation

9.1 checkpoint_input_manager.cc File Reference

Define CheckPointInputManager member functions and of related classes.

```
#include <cstddef>
#include <cstring>
#include <iostream>
#include "utils/message/include/message_handler.hh"
#include "../include/checkpoint_input_manager.hh"
#include "../include/sim_interface_messages.hh"
```

Namespaces

jeod

Namespace jeod.

9.1.1 Detailed Description

Define CheckPointInputManager member functions and of related classes.

Definition in file checkpoint_input_manager.cc.

9.2 checkpoint_input_manager.hh File Reference

Define class CheckPointInputManager and related classes.

```
#include "utils/sim_interface/include/config.hh"
#include "utils/sim_interface/include/jeod_class.hh"
#include <cstddef>
#include <istream>
#include <fstream>
#include <string>
#include <map>
```

Data Structures

class jeod::SectionedInputBuffer

120 File Documentation

A SectionedInputBuffer is a std::streambuf that reads from a section in a checkpoint file.

• class jeod::SectionedInputStream

A SectionedInputStream is a std::istream that reads from a section in a checkpoint file.

class jeod::CheckPointInputManager

A CheckPointInputManager provides tools for reading a checkpoint file.

• struct jeod::CheckPointInputManager::SectionInfo

A SectionInfo contains the start and end positions of a checkpoint file section.

Namespaces

· jeod

Namespace jeod.

9.2.1 Detailed Description

Define class CheckPointInputManager and related classes.

Definition in file checkpoint input manager.hh.

9.3 checkpoint_output_manager.cc File Reference

Define CheckPointOutputManager member functions and of related classes.

```
#include <cstddef>
#include <cstring>
#include <iostream>
#include "utils/message/include/message_handler.hh"
#include "../include/checkpoint_output_manager.hh"
#include "../include/sim_interface_messages.hh"
```

Namespaces

• jeod

Namespace jeod.

9.3.1 Detailed Description

Define CheckPointOutputManager member functions and of related classes.

Definition in file checkpoint_output_manager.cc.

9.4 checkpoint_output_manager.hh File Reference

Define class CheckPointOutputManager and related classes.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include <ostream>
#include <fstream>
#include <string>
#include <map>
```

Data Structures

· class jeod::SectionedOutputBuffer

A SectionedOutputBuffer is a std::streambuf that writes a section of a checkpoint file.

· class jeod::SectionedOutputStream

A SectionedOutputStream is a std::ostream that writes a section of a checkpoint file.

· class jeod::CheckPointOutputManager

A CheckPointOutputManager provides the basic tools for writing a checkpoint file.

Namespaces

jeod

Namespace jeod.

9.4.1 Detailed Description

Define class CheckPointOutputManager and related classes.

Definition in file checkpoint_output_manager.hh.

9.5 class_declarations.hh File Reference

Forward declarations of classes defined in the utils/sim_interface model.

Namespaces

jeod

Namespace jeod.

9.5.1 Detailed Description

Forward declarations of classes defined in the utils/sim_interface model.

Definition in file class_declarations.hh.

9.6 config.hh File Reference

Configure JEOD for use by some simulation engine.

```
#include "config_trick10.hh"
```

Macros

- #define JEOD_UNUSED
- #define ER7_UTILS_UNUSED
- #define ER7_UTILS_RESTRICT
- #define ER7_UTILS_ALWAYS_INLINE

122 File Documentation

9.6.1 Detailed Description

Configure JEOD for use by some simulation engine.

Definition in file config.hh.

9.7 config_test_harness.hh File Reference

Configure JEOD for use in standalone test mode.

Macros

- #define JEOD_ATTRIBUTES_TYPE int
- #define JEOD_ATTRIBUTES_POINTER_TYPE void *
- #define JEOD SIM INTEGRATOR POINTER TYPE void *

9.7.1 Detailed Description

Configure JEOD for use in standalone test mode.

Definition in file config_test_harness.hh.

9.8 config_trick10.hh File Reference

Configure JEOD for use in a Trick10 environment.

Macros

- #define JEOD_SIZE_T size_t
- #define JEOD_PTRDIFF_T long int
- #define JEOD_INTPTR_T long int
- #define JEOD_UINTPTR_T unsigned long int
- #define JEOD_CLASS_ESTABLISH_FRIENDS(class_name)
- #define JEOD_ATTRIBUTES_SIM_ENGINE_HEADER "sim_services/MemoryManager/include/attributes.h"
- #define JEOD ATTRIBUTES TYPE struct ATTRIBUTES tag
- #define JEOD_ATTRIBUTES_POINTER_TYPE JEOD_ATTRIBUTES_TYPE *
- #define JEOD_SIM_INTEGRATOR_SIM_ENGINE_HEADER "sim_services/Integrator/include/Integrator.hh"
- #define JEOD_SIM_INTEGRATOR_FORWARD namespace Trick { class Integrator; }
- #define JEOD_SIM_INTEGRATOR_POINTER_TYPE Trick::Integrator *
- #define JEOD_SIM_INTEGRATOR_ENUM Integrator_type

9.8.1 Detailed Description

Configure JEOD for use in a Trick10 environment.

Definition in file config_trick10.hh.

9.9 jeod_class.hh File Reference

Define the JEOD class declaration macros JEOD_MAKE_SIM_INTERFACES and and JEOD_DECLARE_SIM_INTERFACES.

```
#include "config.hh"
```

Macros

#define JEOD_MAKE_SIM_INTERFACES(class_name) JEOD_CLASS_ESTABLISH_FRIENDS(class_name)

JEOD_MAKE_SIM_INTERFACES(class_name) Defines friends of the given class.

#define JEOD_DECLARE_SIM_INTERFACES(class_name)

JEOD_DECLARE_SIM_INTERFACES(class_name) Forward declare classes and external functions needed to make the JEOD_MAKE_SIM_INTERFACES(class_name) expansion compilable.

9.9.1 Detailed Description

Define the JEOD class declaration macros JEOD_MAKE_SIM_INTERFACES and and JEOD_DECLARE_SIM_INTERFACES. All JEOD class definitions must invoke JEOD_MAKE_SIM_INTERFACES within the body of the class. Corresponding invocations of JEOD_DECLARE_SIM_INTERFACES are made at file scope and in the context of the global namespace.

In a Trick environment, these macros gives the Trick input processor, the Trick checkpoint / checkpoint-restart facility, and the ICG-generated io_src file for the header full visibility of the class's contents. The intent is to provide the same capability outside the Trick.

Definition in file jeod class.hh.

9.10 jeod_integrator_interface.hh File Reference

Define the interface for accessing / updating elements of a simulation engine's integrator object.

```
#include "utils/sim_interface/include/config.hh"
#include "utils/sim_interface/include/jeod_class.hh"
#include "er7_utils/integration/core/include/integration_technique.hh"
#include "er7_utils/integration/core/include/integrator_interface.hh"
```

Data Structures

· class jeod::JeodIntegratorInterface

A JeodIntegratorInterface extends the ER7 IntegratorInterface with the concept of a pointer to the simulation engine's integration object.

Namespaces

Trick

Namespace Trick furnishes several standard functions for use in the Trick environment.

jeod

Namespace jeod.

124 File Documentation

9.10.1 Detailed Description

Define the interface for accessing / updating elements of a simulation engine's integrator object.

Definition in file jeod_integrator_interface.hh.

9.11 jeod_trick_integrator.hh File Reference

Define the interface for accessing / updating elements of a Trick simulation integrator object.

```
#include "sim_services/Integrator/include/Integrator.hh"
#include "er7_utils/trick/integration/include/translate_trick_integ_type.-
hh"
#include "jeod_class.hh"
#include "jeod_integrator_interface.hh"
```

Data Structures

· class jeod::TrickJeodIntegrator

A TrickJeodIntegrator specializes the Trick::Integrator to provide the Trick side of the integration interface between Trick and JEOD.

· class jeod::JeodTrickIntegrator

A JeodTrickIntegrator specializes the JeodIntegratorInterface for use with Trick as the simulation engine.

Namespaces

• jeod

Namespace jeod.

9.11.1 Detailed Description

Define the interface for accessing / updating elements of a Trick simulation integrator object.

Definition in file jeod trick integrator.hh.

9.12 memory_attributes.hh File Reference

Define JEOD memory interface macros.

```
#include "config.hh"
#include "sim_services/MemoryManager/include/attributes.h"
```

Namespaces

• jeod

Namespace jeod.

Macros

- #define JEOD_DECLARE_ATTRIBUTES(class_name)
 - JEOD_DECLARE_ATTRIBUTES(class_name) This macro is obsolete.
- #define JEOD_ATTRIBUTES(type) JeodSimulationInterface::get_memory_interface().find_attributes(#type)

 Get a pointer to or construct the name of the attributes for the type.

9.12.1 Detailed Description

Define JEOD memory interface macros.

- Most of the memory interface between JEOD and the simulation engine is handled by the JeodMemory-Interface.
- The macros defined in this file represent the functionality that cannot be solved using c++ classes.
- The macros prefixed with JEOD_DECLARE are used in model files that use the memory model to allocate memory.
- · The remaining macros are used internally by the JEOD memory model and should not be used in model files.

Definition in file memory_attributes.hh.

9.12.2 Macro Definition Documentation

9.12.2.1 #define JEOD ATTRIBUTES(type) JeodSimulationInterface::get memory interface().find attributes(#type)

Get a pointer to or construct the name of the attributes for the type.

Note

This is a primitive macro. Do not use it in model files.

Parameters

type	Data type.

Returns

Pointer to or symbolic name of the attributes for the type.

Definition at line 78 of file memory_attributes.hh.

9.12.2.2 #define JEOD_DECLARE_ATTRIBUTES(class_name)

JEOD DECLARE ATTRIBUTES(class name) This macro is obsolete.

Definition at line 68 of file memory_attributes.hh.

9.13 memory_interface.cc File Reference

Implement the MemoryInterface class.

#include "../include/memory_interface.hh"

126 File Documentation

Namespaces

jeod

Namespace jeod.

9.13.1 Detailed Description

Implement the MemoryInterface class.

Definition in file memory_interface.cc.

9.14 memory_interface.hh File Reference

Define the MemoryInterface class, which abstractly defines the interface between the memory manager and the simulation engine.

```
#include <cstddef>
#include <string>
#include <typeinfo>
#include "utils/sim_interface/include/jeod_class.hh"
#include "memory_attributes.hh"
```

Data Structures

· class jeod::JeodMemoryInterface

Abstract interface between the JEOD memory manager and the simulation engine.

Namespaces

• jeod

Namespace jeod.

9.14.1 Detailed Description

Define the MemoryInterface class, which abstractly defines the interface between the memory manager and the simulation engine.

Definition in file memory_interface.hh.

9.15 sim_interface_messages.cc File Reference

Implement the class SimInterfaceMessages.

```
#include "../include/sim_interface_messages.hh"
```

Namespaces

jeod

Namespace jeod.

Macros

- #define PATH "utils/sim_interface/"
- #define CLASS SimInterfaceMessages
- #define MAKE MESSAGE CODE(id) char const * CLASS::id = PATH #id

9.15.1 Detailed Description

Implement the class SimInterfaceMessages.

Definition in file sim_interface_messages.cc.

9.16 sim_interface_messages.hh File Reference

Define the class SimInterfaceMessages, the class that specifies the message IDs used in the sim interface model.

```
#include "jeod_class.hh"
```

Data Structures

• class jeod::SimInterfaceMessages

Specifies the message IDs used in the sim_interface model.

Namespaces

• jeod

Namespace jeod.

9.16.1 Detailed Description

Define the class SimInterfaceMessages, the class that specifies the message IDs used in the sim interface model. Definition in file sim_interface_messages.hh.

9.17 simulation_interface.cc File Reference

Implement SimulationInterface methods.

```
#include <cstddef>
#include "utils/message/include/message_handler.hh"
#include "utils/memory/include/memory_manager.hh"
#include "../include/simulation_interface.hh"
#include "../include/sim_interface_messages.hh"
```

Namespaces

jeod

Namespace jeod.

9.17.1 Detailed Description

Implement SimulationInterface methods.

Definition in file simulation_interface.cc.

9.18 simulation_interface.hh File Reference

Define the abstract class JeodSimulationInterface.

```
#include <string>
#include "class_declarations.hh"
#include "jeod_class.hh"
#include "checkpoint_input_manager.hh"
#include "checkpoint_output_manager.hh"
#include "jeod_integrator_interface.hh"
```

Data Structures

· class jeod::JeodSimulationInterfaceInit

Define configuration data needed to configure the dynamically-created message handler and memory manager.

· class jeod::JeodSimulationInterface

This abstract class defines the basis for the interface between JEOD and a simulation engine.

Namespaces

· jeod

Namespace jeod.

9.18.1 Detailed Description

Define the abstract class JeodSimulationInterface.

Definition in file simulation_interface.hh.

9.19 trick10_memory_interface.cc File Reference

Define JeodTrickMemoryInterface methods.

```
#include <cstddef>
#include <dlfcn.h>
#include <iomanip>
#include <sstream>
#include <iosfwd>
#include "sim_services/CheckPointAgent/include/ClassicCheckPointAgent.hh"
#include "sim_services/MemoryManager/include/MemoryManager.hh"
#include "utils/message/include/message_handler.hh"
#include "../include/simulation_interface.hh"
#include "../include/sim_interface_messages.hh"
#include "../include/trick10_memory_interface.hh"
```

Namespaces

• jeod

Namespace jeod.

Variables

• Trick::MemoryManager * trick MM

9.19.1 Detailed Description

Define JeodTrickMemoryInterface methods.

Definition in file trick10_memory_interface.cc.

9.20 trick10_memory_interface.hh File Reference

Define the interface for registering / deregistering memory with Trick.

```
#include <cstddef>
#include <cstring>
#include <list>
#include <map>
#include <stdint.h>
#include <string>
#include "jeod_class.hh"
#include "memory_attributes.hh"
#include "memory_interface.hh"
#include "simulation_interface.hh"
#include "trick_memory_interface.hh"
```

Data Structures

class jeod::JeodTrick10MemoryInterface

A TrickMemoryInterface implements the two required methods needed to register and deregister memory with the simulation engine, Trick in this case.

Namespaces

• jeod

Namespace jeod.

Trick

Namespace Trick furnishes several standard functions for use in the Trick environment.

9.20.1 Detailed Description

Define the interface for registering / deregistering memory with Trick.

Definition in file trick10_memory_interface.hh.

9.21 trick_dynbody_integ_loop.cc File Reference

Define JeodDynbodyIntegrationLoop methods.

```
#include "../include/trick_dynbody_integ_loop.hh"
#include "../include/sim_interface_messages.hh"
#include "dynamics/dyn_manager/include/dyn_manager.hh"
#include "dynamics/dyn_body/include/dyn_body.hh"
#include "environment/time/include/time_manager.hh"
#include "utils/message/include/message_handler.hh"
#include "sim_services/Executive/include/exec_proto.h"
#include <cstddef>
#include <vector>
```

Namespaces

• jeod

Namespace jeod.

Variables

• Trick::Integrator * trick_curr_integ

9.21.1 Detailed Description

Define JeodDynbodyIntegrationLoop methods.

Definition in file trick_dynbody_integ_loop.cc.

9.22 trick_dynbody_integ_loop.hh File Reference

Define the class IntegrationGroupIntegLoopScheduler, which replaces the base Trick integration loop for multi-rate JEOD-based simulations.

```
#include "jeod_trick_integrator.hh"
#include "dynamics/dyn_manager/include/dynamics_integration_group.hh"
#include "utils/integration/include/jeod_integration_group.hh"
#include "utils/sim_interface/include/jeod_class.hh"
#include "sim_services/Integrator/include/IntegLoopScheduler.hh"
```

Data Structures

class jeod::JeodDynbodyIntegrationLoop

A Trick::IntegLoopScheduler that provides the ability to integrate a collection of Trick::SimObject instances over time, with the sim objects capable of being moved from one integration loop to another during run time.

Namespaces

jeod

Namespace jeod.

Trick

Namespace Trick furnishes several standard functions for use in the Trick environment.

• er7_utils

Namespace er7_utils contains the state integration models used by JEOD.

9.22.1 Detailed Description

Define the class IntegrationGroupIntegLoopScheduler, which replaces the base Trick integration loop for multi-rate JEOD-based simulations.

Definition in file trick dynbody integ loop.hh.

9.23 trick memory interface.cc File Reference

Define JeodTrickMemoryInterface methods.

```
#include <cstddef>
#include <dlfcn.h>
#include <iomanip>
#include <sstream>
#include "utils/message/include/message_handler.hh"
#include "../include/simulation_interface.hh"
#include "../include/sim_interface_messages.hh"
#include "../include/trick_memory_interface.hh"
```

Namespaces

• jeod

Namespace jeod.

9.23.1 Detailed Description

Define JeodTrickMemoryInterface methods.

Definition in file trick_memory_interface.cc.

9.24 trick_memory_interface.hh File Reference

Define the interface for registering / deregistering memory with Trick.

```
#include <cstddef>
#include <cstring>
#include <list>
#include <map>
#include <stdint.h>
#include <string>
#include "jeod_class.hh"
#include "memory_attributes.hh"
#include "memory_interface.hh"
#include "simulation_interface.hh"
```

Data Structures

class jeod::JeodTrickMemoryInterface

A TrickMemoryInterface implements the two required methods needed to register and deregister memory with the simulation engine, Trick in this case.

struct jeod::JeodTrickMemoryInterface::ContainerListEntry

Describes a Checkpointable object.

struct jeod::JeodTrickMemoryInterface::AllocationMapEntry

Describes a chunk of JEOD-allocated memory.

Namespaces

jeod

Namespace jeod.

9.24.1 Detailed Description

Define the interface for registering / deregistering memory with Trick.

Definition in file trick_memory_interface.hh.

9.25 trick_memory_interface_alloc.cc File Reference

Define JeodTrickMemoryInterface methods related to allocation/deallocation.

```
#include <cstddef>
#include <cstdlib>
#include <cstdio>
#include <cstring>
#include <dlfcn.h>
#include <iomanip>
#include <sstream>
#include <typeinfo>
#include "sim_services/MemoryManager/include/attributes.h"
#include "sim_services/MemoryManager/include/ADefParseContext.hh"
#include "sim_services/MemoryManager/include/MemoryManager.hh"
#include "utils/memory/include/memory_item.hh"
#include "utils/memory/include/memory_manager.hh"
#include "utils/memory/include/memory type.hh"
#include "utils/message/include/message handler.hh"
#include "../include/sim_interface_messages.hh"
#include "../include/simulation_interface.hh"
#include "../include/trick memory interface.hh"
```

Namespaces

• jeod

Namespace jeod.

Variables

Trick::MemoryManager * trick_MM

9.25.1 Detailed Description

Define JeodTrickMemoryInterface methods related to allocation/deallocation.

Definition in file trick_memory_interface_alloc.cc.

9.26 trick_memory_interface_attrib.cc File Reference

Define JeodTrickMemoryInterface methods related to attributes.

```
#include <cstddef>
#include <cstring>
#include <dlfcn.h>
#include "sim_services/MemoryManager/include/attributes.h"
#include "utils/memory/include/memory_type.hh"
#include "utils/message/include/message_handler.hh"
#include "utils/named_item/include/named_item.hh"
#include "../include/sim_interface_messages.hh"
#include "../include/trick_memory_interface.hh"
```

Namespaces

jeod

Namespace jeod.

9.26.1 Detailed Description

Define JeodTrickMemoryInterface methods related to attributes.

Definition in file trick_memory_interface_attrib.cc.

9.27 trick_memory_interface_chkpnt.cc File Reference

Define JeodTrick10MemoryInterface methods related to checkpoint/restart.

```
#include <cstddef>
#include <cstdlib>
#include <cstdio>
#include <cstring>
#include <dlfcn.h>
#include <iomanip>
#include <sstream>
#include <typeinfo>
#include "sim_services/MemoryManager/include/attributes.h"
#include "sim_services/MemoryManager/include/ADefParseContext.hh"
#include "sim_services/MemoryManager/include/MemoryManager.hh"
#include "utils/container/include/checkpointable.hh"
#include "utils/memory/include/memory item.hh"
#include "utils/memory/include/memory_manager.hh"
#include "utils/memory/include/memory_type.hh"
#include "utils/message/include/message_handler.hh"
#include "../include/sim_interface_messages.hh"
#include "../include/simulation_interface.hh"
#include "../include/trick10_memory_interface.hh"
```

Namespaces

jeod

Namespace jeod.

Variables

Trick::MemoryManager * trick MM

9.27.1 Detailed Description

Define JeodTrick10MemoryInterface methods related to checkpoint/restart.

Definition in file trick memory interface chkpnt.cc.

9.28 trick_memory_interface_xlate.cc File Reference

Define JeodTrickMemoryInterface methods related to name translation.

```
#include <cstdlib>
#include <cstdlib>
#include <string>
#include "sim_services/CheckPointAgent/include/ClassicCheckPointAgent.hh"
#include "sim_services/MemoryManager/include/attributes.h"
#include "sim_services/MemoryManager/include/MemoryManager.hh"
#include "sim_services/MemoryManager/include/memorymanager_c_intf.h"
#include "sim_services/CheckPointRestart/include/CheckPointRestart_c_intf.-hh"
#include "utils/memory/include/memory_type.hh"
#include "../include/simulation_interface.hh"
#include "../include/sim_interface_messages.hh"
#include "../include/trick10_memory_interface.hh"
```

Namespaces

jeod

Namespace jeod.

Variables

• Trick::MemoryManager * trick_MM

9.28.1 Detailed Description

Define JeodTrickMemoryInterface methods related to name translation.

Definition in file trick_memory_interface_xlate.cc.

9.29 trick_message_handler.cc File Reference

Define member functions for the class TrickMessageHandler.

```
#include <cstdarg>
#include <cstdio>
#include "sim_services/Executive/include/exec_proto.h"
#include "sim_services/Message/include/message_proto.h"
#include "utils/memory/include/jeod_alloc.hh"
#include "../include/trick_message_handler.hh"
```

Namespaces

jeod

Namespace jeod.

Macros

• #define MAX MSG SIZE 4096

9.29.1 Detailed Description

Define member functions for the class TrickMessageHandler.

Definition in file trick_message_handler.cc.

9.30 trick message handler.hh File Reference

Define the class TrickMessageHandler, the message handler designed for use in Trick-based simulations.

```
#include <cstdarg>
#include <string>
#include "utils/container/include/primitive_set.hh"
#include "utils/message/include/suppressed_code_message_handler.hh"
#include "utils/sim_interface/include/jeod_class.hh"
#include "class_declarations.hh"
```

Data Structures

· class jeod::TrickMessageHandler

The MessageHandler class for designed for use in Trick-based simulations.

Namespaces

• jeod

Namespace jeod.

9.30.1 Detailed Description

Define the class TrickMessageHandler, the message handler designed for use in Trick-based simulations.

Definition in file trick_message_handler.hh.

9.31 trick_sim_interface.cc File Reference

Implement TrickSimInterface methods.

```
#include "sim_services/Executive/include/exec_proto.h"
#include "sim_services/Message/include/message_proto.h"
#include "sim_services/CommandLineArguments/include/command_line_protos.h"
#include "utils/memory/include/jeod_alloc.hh"
#include "utils/message/include/message_handler.hh"
#include "../include/sim_interface_messages.hh"
#include "../include/jeod_trick_integrator.hh"
#include "../include/trick_sim_interface.hh"
#include "../include/checkpoint_input_manager.hh"
#include "../include/checkpoint_output_manager.hh"
```

Namespaces

jeod

Namespace jeod.

9.31.1 Detailed Description

Implement TrickSimInterface methods.

Definition in file trick_sim_interface.cc.

9.32 trick_sim_interface.hh File Reference

Define the class JeodTrickSimInterface.

```
#include "utils/memory/include/memory_manager.hh"
#include "simulation_interface.hh"
#include "trick_memory_interface.hh"
#include "trick10_memory_interface.hh"
#include "trick_message_handler.hh"
#include "jeod_class.hh"
#include "utils/sim_interface/include/jeod_trick_integrator.hh"
```

Data Structures

class jeod::BasicJeodTrickSimInterface

The BasicJeodTrickSimInterface implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

• class jeod::TrickMessageHandlerMixin

The TrickMessageHandlerMixin implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

• class jeod::JeodTrickSimInterface

A JEODTrickSimInterface implements the required capabilities of the generic JeodSimulationInterface in a Trick simulation environment.

Namespaces

• jeod

Namespace jeod.

9.32.1 Detailed Description

Define the class JeodTrickSimInterface.

Definition in file trick_sim_interface.hh.

Index

\sim BasicJeodTrickSimInterface	jeod::JeodTrickMemoryInterface::AllocationMap-
jeod::BasicJeodTrickSimInterface, 24	Entry, 21
\sim JeodDynbodyIntegrationLoop	at_eof
jeod::JeodDynbodyIntegrationLoop, 45	jeod::SectionedInputBuffer, 94
\sim JeodIntegratorInterface	
jeod::JeodIntegratorInterface, 51	BasicJeodTrickSimInterface
\sim JeodMemoryInterface	jeod::BasicJeodTrickSimInterface, 24, 25
jeod::JeodMemoryInterface, 53	buf
~JeodSimulationInterface	jeod::SectionedInputBuffer, 94
jeod::JeodSimulationInterface, 60	
~JeodTrick10MemoryInterface	CLASS
jeod::JeodTrick10MemoryInterface, 69	SimInterface, 15
~JeodTrickIntegrator	CheckPointInputManager
jeod::JeodTrickIntegrator, 75	jeod::CheckPointInputManager, 31
~JeodTrickMemoryInterface	jeod::SectionedInputStream, 100
jeod::JeodTrickMemoryInterface, 81	CheckPointOutputManager
~JeodTrickSimInterface	jeod::CheckPointOutputManager, 36, 37
jeod::JeodTrickSimInterface, 90	jeod::SectionedOutputStream, 109
~SectionedInputBuffer	Checkpoint
jeod::SectionedInputBuffer, 92	jeod::JeodSimulationInterface, 60
~SectionedInputStream	checkpoint_allocations
jeod::SectionedInputStream, 99	jeod::BasicJeodTrickSimInterface, 25
~SectionedOutputBuffer	jeod::JeodTrick10MemoryInterface, 69
jeod::SectionedOutputBuffer, 103	jeod::JeodTrickMemoryInterface, 81
~SectionedOutputStream	checkpoint_containers
jeod::SectionedOutputStream, 107	jeod::BasicJeodTrickSimInterface, 25
~TrickJeodIntegrator	jeod::JeodTrick10MemoryInterface, 69
jeod::TrickJeodIntegrator, 114	jeod::JeodTrickMemoryInterface, 81
~TrickMessageHandler	checkpoint_file_name
jeod::TrickMessageHandler, 115	jeod::BasicJeodTrickSimInterface, 28
~TrickMessageHandlerMixin	checkpoint_input_manager.cc, 119
jeod::TrickMessageHandlerMixin, 117	checkpoint_input_manager.hh, 119
jeod mckiviessägeriandienviixin, 117	checkpoint_output_manager.cc, 120
-404	checkpoint_output_manager.hh, 120
activate	checkpoint_reader
jeod::SectionedInputBuffer, 93	jeod::BasicJeodTrickSimInterface, 28
jeod::SectionedInputStream, 99	checkpoint_writer
jeod::SectionedOutputBuffer, 103	jeod::BasicJeodTrickSimInterface, 29
jeod::SectionedOutputStream, 107	class_declarations.hh, 121
add_integrable_object	close_checkpoint_file
jeod::JeodDynbodyIntegrationLoop, 45	jeod::BasicJeodTrickSimInterface, 25
add_sim_object	close_restart_file
jeod::JeodDynbodyIntegrationLoop, 45	jeod::BasicJeodTrickSimInterface, 25
add_sim_object_bodies	collect_derivatives
jeod::JeodDynbodyIntegrationLoop, 46	jeod::JeodDynbodyIntegrationLoop, 46
allocation_map	config.hh, 121
jeod::JeodTrickMemoryInterface, 88	config_test_harness.hh, 122
AllocationMap	config_trick10.hh, 122
jeod::JeodTrickMemoryInterface, 80	configure
AllocationMapEntry	jeod::JeodSimulationInterface, 61

construct_identifier	jeod::JeodDynbodyIntegrationLoop, 49
jeod::JeodTrickMemoryInterface, 81	
Construction	ER7_UTILS_RESTRICT
jeod::JeodSimulationInterface, 60	SimInterface, 15
container	ER7_UTILS_UNUSED
jeod::JeodTrickMemoryInterface::ContainerList-	SimInterface, 15
Entry, 41	elem name
container_list	jeod::JeodTrickMemoryInterface::ContainerList-
jeod::JeodTrickMemoryInterface, 88	Entry, 41
ContainerList	end_pos
	jeod::CheckPointInputManager::SectionInfo, 111
jeod::JeodTrickMemoryInterface, 80	jeod::SectionedInputBuffer, 94
ContainerListEntry	jeod::SectionedInputStream, 101
jeod::JeodTrickMemoryInterface::ContainerList-	·
Entry, 41	er7_utils, 19
create_integrator_interface	file buf
jeod::JeodSimulationInterface, 61	file_buf
create_integrator_internal	jeod::SectionedInputBuffer, 95
jeod::BasicJeodTrickSimInterface, 25	jeod::SectionedOutputBuffer, 105
jeod::JeodSimulationInterface, 61	filename
create_section_reader	jeod::CheckPointInputManager, 34
jeod::CheckPointInputManager, 31, 32	jeod::CheckPointOutputManager, 39
create_section_writer	find_attributes
jeod::CheckPointOutputManager, 37	jeod::JeodMemoryInterface, 54
create_trick_section_reader	jeod::JeodTrickMemoryInterface, 82, 83
jeod::CheckPointInputManager, 32	find_containing_sim_object
create_trick_section_writer	jeod::JeodDynbodyIntegrationLoop, 46
jeod::CheckPointOutputManager, 37	
curr_pos	generic_message_handler
	jeod::BasicJeodTrickSimInterface, 29
jeod::SectionedInputBuffer, 94	get_address_at_name
current_reader	jeod::JeodMemoryInterface, 55
jeod::CheckPointInputManager, 34	jeod::JeodSimulationInterface, 61
current_writer	jeod::JeodTrick10MemoryInterface, 70
jeod::CheckPointOutputManager, 39	jeod::JeodTrickMemoryInterface, 83
deactivate	get_checkpoint_file_name
	jeod::BasicJeodTrickSimInterface, 26
jeod::SectionedInputBuffer, 93	·
jeod::SectionedInputStream, 99	get_checkpoint_reader
jeod::SectionedOutputBuffer, 104	jeod::JeodSimulationInterface, 62
jeod::SectionedOutputStream, 108	get_checkpoint_reader_internal
Dead	jeod::BasicJeodTrickSimInterface, 26
jeod::JeodSimulationInterface, 60	jeod::JeodSimulationInterface, 62
default_first_step_deriv	get_checkpoint_writer
jeod::JeodTrickIntegrator, 77	jeod::JeodSimulationInterface, 62
deregister_allocation	get_checkpoint_writer_internal
jeod::JeodMemoryInterface, 54	jeod::BasicJeodTrickSimInterface, 26
jeod::JeodTrickMemoryInterface, 82	jeod::JeodSimulationInterface, 62
deregister_container	get_container_id
jeod::JeodMemoryInterface, 54	jeod::JeodTrick10MemoryInterface, 70
jeod::JeodTrick10MemoryInterface, 69	get_dt
jeod::JeodTrickMemoryInterface, 82	jeod::JeodTrickIntegrator, 76
deregister_reader	get_first_step_derivs_flag
jeod::CheckPointInputManager, 32	jeod::JeodTrickIntegrator, 76
deregister_writer	get_integrator
- —	
jeod::CheckPointOutputManager, 38	jeod::JeodIntegratorInterface, 51
deriv_ephem_update	jeod::JeodTrickIntegrator, 76
jeod::JeodDynbodyIntegrationLoop, 49	get_job_cycle
dhandle	jeod::JeodSimulationInterface, 63
jeod::JeodTrickMemoryInterface, 88	get_job_cycle_internal
dyn_manager	jeod::BasicJeodTrickSimInterface, 26

jeod::JeodSimulationInterface, 63	initialize_integ_loop
get_memory_interface	jeod::JeodDynbodyIntegrationLoop, 47
jeod::JeodSimulationInterface, 63	InputProcessor
get_memory_interface_internal	jeod::BasicJeodTrickSimInterface, 28
jeod::BasicJeodTrickSimInterface, 27	jeod::JeodDynbodyIntegrationLoop, 49
jeod::JeodSimulationInterface, 63	jeod::JeodIntegratorInterface, 52
get_mode	jeod::JeodMemoryInterface, 58
jeod::JeodSimulationInterface, 63	jeod::JeodSimulationInterface, 65
get_name_at_address	jeod::JeodTrick10MemoryInterface, 73
jeod::JeodMemoryInterface, 55	jeod::JeodTrickIntegrator, 77
jeod::JeodSimulationInterface, 64	jeod::JeodTrickMemoryInterface, 88
jeod::JeodTrick10MemoryInterface, 70	jeod::JeodTrickSimInterface, 91
jeod::JeodTrickMemoryInterface, 83	jeod::TrickMessageHandler, 116
get_trick_checkpoint_file	jeod::TrickMessageHandlerMixin, 118
jeod::JeodTrick10MemoryInterface, 71	integ_constructor
jeod::JeodTrickMemoryInterface, 84	jeod::JeodDynbodyIntegrationLoop, 49
gravitation	integ_group
jeod::JeodDynbodyIntegrationLoop, 46	jeod::JeodDynbodyIntegrationLoop, 49
gravity_manager	integ_group_factory
jeod::JeodDynbodyIntegrationLoop, 49	jeod::JeodDynbodyIntegrationLoop, 50
joodiioood2jiiloodjiiilogialioii2oop, io	integ interface
have active reader	jeod::JeodDynbodyIntegrationLoop, 50
jeod::CheckPointInputManager, 33	integrate
have active writer	jeod::TrickJeodIntegrator, 114
jeod::CheckPointOutputManager, 38	integrate_dt
journal and a specific and a specifi	jeod::JeodDynbodyIntegrationLoop, 47
id_length	integration_error
jeod::JeodTrickMemoryInterface, 89	jeod::SimInterfaceMessages, 112
id_prefix	· · · · · · · · · · · · · · · · · · ·
jeod::JeodTrickMemoryInterface, 89	interface_error
implementation_error	jeod::SimInterfaceMessages, 112
jeod::SimInterfaceMessages, 112	interpret_integration_type
init_attrjeodBasicJeodTrickSimInterface	jeod::JeodIntegratorInterface, 51
jeod::BasicJeodTrickSimInterface, 28	jeod::JeodTrickIntegrator, 76
init_attrjeodJeodDynbodyIntegrationLoop	is_activatable
jeod::JeodDynbodyIntegrationLoop, 49	jeod::SectionedInputStream, 100
init_attrjeodJeodIntegratorInterface	jeod::SectionedOutputStream, 108
jeod::JeodIntegratorInterface, 52	is_active
init_attrjeodJeodMemoryInterface	jeod::SectionedInputStream, 101
jeod::JeodMemoryInterface, 58	jeod::SectionedOutputStream, 109
init_attrjeodJeodSimulationInterface	is_array
jeod::JeodSimulationInterface, 65	jeod::JeodTrickMemoryInterface::AllocationMap-
init_attrjeodJeodTrick10MemoryInterface	Entry, 22
jeod::JeodTrick10MemoryInterface, 73	is_checkpoint_restart_supported
init_attrjeodJeodTrickIntegrator	jeod::JeodMemoryInterface, 56
jeod::JeodTrickIntegrator, 77	jeod::JeodTrick10MemoryInterface, 71
	jeod::JeodTrickMemoryInterface, 84
init_attrjeodJeodTrickMemoryInterface	is_copy
jeod::JeodTrickMemoryInterface, 88	jeod::SectionedInputStream, 101
init_attrjeodJeodTrickSimInterface	jeod::SectionedOutputStream, 109
jeod::JeodTrickSimInterface, 91	is_open
init_attrjeodTrickMessageHandler	jeod::CheckPointInputManager, 34
jeod::TrickMessageHandler, 116	jeod::CheckPointOutputManager, 39
init_attrjeodTrickMessageHandlerMixin	IFOR ATTRIBUTES
jeod::TrickMessageHandlerMixin, 118	JEOD_ATTRIBUTES
Initialization	memory_attributes.hh, 125
jeod::JeodSimulationInterface, 60	JEOD_INTPTR_T
initialize	SimInterface, 16
jeod::CheckPointInputManager, 33	JEOD_PTRDIFF_T
jeod::TrickJeodIntegrator, 114	SimInterface, 16

JEOD_SIZE_T	is_open, 34
SimInterface, 17	operator=, 33
JEOD_UINTPTR_T	register_reader, 33
SimInterface, 17	section_end, 34
JEOD_UNUSED	section_start, 34
SimInterface, 17	sections, 35
jeod, 19	stream, 35
jeod::JeodSimulationInterface	jeod::CheckPointInputManager::SectionInfo, 110
Checkpoint, 60	end_pos, 111
Construction, 60	SectionInfo, 111
Dead, 60	start_pos, 111
Initialization, 60	jeod::CheckPointOutputManager, 35
NumModes, 60	CheckPointOutputManager, 36, 37
Operational, 60	create_section_writer, 37
PostCheckpoint, 60	create_trick_section_writer, 37
PreCheckpoint, 60	current_writer, 39
Restart, 60	deregister_writer, 38
Restore, 60	filename, 39
Shutdown, 60	have_active_writer, 38
jeod::BasicJeodTrickSimInterface, 22	is_open, 39
~BasicJeodTrickSimInterface, 24	MemoryManagerWrapper, 39
BasicJeodTrickSimInterface, 24, 25	operator=, 38
checkpoint allocations, 25	register_writer, 38
checkpoint_containers, 25	section_end, 39
checkpoint_file_name, 28	section_start, 40
checkpoint_reader, 28	stream, 40
checkpoint_writer, 29	jeod::JeodDynbodyIntegrationLoop, 42
close_checkpoint_file, 25	~JeodDynbodyIntegrationLoop, 45
close_restart_file, 25	add_integrable_object, 45
create_integrator_internal, 25	add_integrable_object, 45
generic_message_handler, 29	add_sim_object_bodies, 46
get_checkpoint_file_name, 26	collect_derivatives, 46
get_checkpoint_reader_internal, 26	deriv ephem update, 49
get_checkpoint_writer_internal, 26	dyn_manager, 49
get_job_cycle_internal, 26	find_containing_sim_object, 46
get_nemory_interface_internal, 27	gravitation, 46
	_
init_attrjeodBasicJeodTrickSimInterface, 28	gravity_manager, 49 init_attrjeodJeodDynbodyIntegrationLoop, 49
InputProcessor, 28	
memory_manager, 29	initialize_integ_loop, 47
open_checkpoint_file, 27	InputProcessor, 49
open_restart_file, 27	integ_constructor, 49
operator=, 27	integ_group, 49
restore_allocations, 27	integ_group_factory, 50
restore_containers, 27	integ_interface, 50
section_end, 29	integrate_dt, 47
section_start, 29	JeodDynbodyIntegrationLoop, 44, 45
set_checkpoint_file_name, 28	loop_sim_object, 50
set_mode, 28	operator=, 47
trick_memory_interface, 29	remove_integrable_object, 47
jeod::CheckPointInputManager, 30	remove_sim_object, 47
CheckPointInputManager, 31	remove_sim_object_bodies, 48
create_section_reader, 31, 32	set_deriv_ephem_update, 48
create_trick_section_reader, 32	set_time_to_loop_start, 48
current_reader, 34	time_manager, 50
deregister_reader, 32	update_integration_group, 48
filename, 34	jeod::JeodIntegratorInterface, 50
have_active_reader, 33	~JeodIntegratorInterface, 51
initialize, 33	get_integrator, 51

init_attrjeodJeodIntegratorInterface, 52 InputProcessor, 52	get_container_id, 70 get_name_at_address, 70
interpret_integration_type, 51	get_trick_checkpoint_file, 71
jeod::JeodMemoryInterface, 52	init_attrjeodJeodTrick10MemoryInterface, 73
\sim JeodMemoryInterface, 53	InputProcessor, 73
deregister_allocation, 54	is_checkpoint_restart_supported, 71
deregister_container, 54	JeodTrick10MemoryInterface, 69
find_attributes, 54	operator=, 71
get_address_at_name, 55	register_container, 71
get_name_at_address, 55	restore_allocations, 72
init_attrjeodJeodMemoryInterface, 58	restore_containers, 72
InputProcessor, 58	translate_addr_to_name, 72
is_checkpoint_restart_supported, 56	translate_name_to_addr, 73
JeodMemoryInterface, 53	trick_checkpoint_agent, 73
operator=, 56	jeod::JeodTrickIntegrator, 74
pointer_attributes, 56	\sim JeodTrickIntegrator, 75
primitive_attributes, 56	default_first_step_deriv, 77
register allocation, 57	get_dt, 76
register_container, 57	get_first_step_derivs_flag, 76
structure_attributes, 57	get_integrator, 76
void pointer attributes, 57	init_attrjeodJeodTrickIntegrator, 77
jeod::JeodSimulationInterface, 58	InputProcessor, 77
~JeodSimulationInterface, 60	interpret_integration_type, 76
configure, 61	JeodTrickIntegrator, 75
create_integrator_interface, 61	operator=, 76
create_integrator_internal, 61	reset_first_step_derivs_flag, 76
get_address_at_name, 61	restore_first_step_derivs_flag, 77
get_checkpoint_reader, 62	set_first_step_derivs_flag, 77
get_checkpoint_reader_internal, 62	set_step_number, 77
get_checkpoint_writer, 62	set_time, 77
get_checkpoint_writer_internal, 62	trick_integrator, 78
get_job_cycle, 63	jeod::JeodTrickMemoryInterface, 78
get_job_cycle_internal, 63	~JeodTrickMemoryInterface, 81
get_memory_interface, 63	allocation_map, 88
get_memory_interface_internal, 63	AllocationMap, 80
get_mode, 63	checkpoint_allocations, 81
get_name_at_address, 64	checkpoint_containers, 81
init_attrjeodJeodSimulationInterface, 65	construct_identifier, 81
InputProcessor, 65	container_list, 88
JeodSimulationInterface, 60	ContainerList, 80
Mode, 60	deregister_allocation, 82
mode, 65	deregister_container, 82
operator=, 64	dlhandle, 88
saved_mode, 65	find_attributes, 82, 83
set_mode, 64	get_address_at_name, 83
sim_interface, 65	get_name_at_address, 83
jeod::JeodSimulationInterfaceInit, 65	get_trick_checkpoint_file, 84
JeodSimulationInterfaceInit, 66	id_length, 89
memory_debug_level, 66	id_prefix, 89
message_suppress_id, 66	init_attrjeodJeodTrickMemoryInterface, 88
message_suppress_location, 66	InputProcessor, 88
message_suppression_level, 67	is_checkpoint_restart_supported, 84
jeod::JeodTrick10MemoryInterface, 67	JeodTrickMemoryInterface, 81
\sim JeodTrick10MemoryInterface, 69	mode, 89
checkpoint_allocations, 69	operator=, 84
checkpoint_containers, 69	pointer_attributes, 84
deregister_container, 69	primitive_attributes, 85
get_address_at_name, 70	register_allocation, 85

register_container, 85	file_buf, 105
restore_allocations, 87	operator=, 104
restore_containers, 87	overflow, 104
set_mode, 87	SectionedOutputBuffer, 103
structure_attributes, 87	SectionedOutputStream, 105
void_pointer_attributes, 88	jeod::SectionedOutputStream, 105
jeod::JeodTrickMemoryInterface::AllocationMapEntry,	\sim SectionedOutputStream, 107
21	activate, 107
AllocationMapEntry, 21	CheckPointOutputManager, 109
is_array, 22	deactivate, 108
nelements, 22	is_activatable, 108
typeid_info, 22	is_active, 109
jeod::JeodTrickMemoryInterface::ContainerListEntry, 40	is_copy, 109
container, 41	manager, 109
ContainerListEntry, 41	operator void *, 108
elem_name, 41	operator=, 108
owner, 41	sectbuf, 109
owner_type, 41	section_end, 109
jeod::JeodTrickSimInterface, 89	section start, 110
-	- · · ·
~JeodTrickSimInterface, 90	SectionedOutputStream, 107
init_attrjeodJeodTrickSimInterface, 91	stream, 110
InputProcessor, 91	tag, 110
JeodTrickSimInterface, 90	jeod::SimInterfaceMessages, 111
operator=, 91	implementation_error, 112
jeod::SectionedInputBuffer, 91	integration_error, 112
~SectionedInputBuffer, 92	interface_error, 112
activate, 93	operator=, 112
at_eof, 94	phasing_error, 113
buf, 94	SimInterfaceMessages, 112
curr_pos, 94	singleton_error, 113
deactivate, 93	jeod::TrickJeodIntegrator, 113
end_pos, 94	\sim TrickJeodIntegrator, 114
file_buf, 95	initialize, 114
operator=, 93	integrate, 114
SectionedInputBuffer, 92, 93	jeod::TrickMessageHandler, 114
SectionedInputStream, 94	\sim TrickMessageHandler, 115
start_pos, 95	init_attrjeodTrickMessageHandler, 116
underflow, 94	InputProcessor, 116
jeod::SectionedInputStream, 95	operator=, 116
~SectionedInputStream, 99	process_message, 116
activate, 99	register contents, 116
CheckPointInputManager, 100	TrickMessageHandler, 115
deactivate, 99	jeod::TrickMessageHandlerMixin, 116
end_pos, 101	~TrickMessageHandlerMixin, 117
is_activatable, 100	init_attrjeodTrickMessageHandlerMixin, 118
is_active, 101	InputProcessor, 118
is_copy, 101	message handler, 118
manager, 101	operator=, 118
operator void *, 100	TrickMessageHandlerMixin, 117
operator=, 100	jeod_class.hh, 123
sectbuf, 101	jeod_integrator_interface.hh, 123
SectionedInputStream, 98, 99	jeod_trick_integrator.hh, 124
start_pos, 101	JeodDynbodyIntegrationLoop
	jeod::JeodDynbodyIntegrationLoop, 44, 45
stream, 101	
jeod::SectionedOutputBuffer, 102	JeodMemoryInterface
~SectionedOutputBuffer, 103	jeod::JeodMemoryInterface, 53
activate, 103	JeodSimulationInterface
deactivate, 104	jeod::JeodSimulationInterface, 60

JeodSimulationInterfaceInit jeod::JeodSimulationInterfaceInit, 66	jeod::SectionedInputStream, 100 jeod::SectionedOutputStream, 108
JeodTrick10MemoryInterface	operator=
jeod::JeodTrick10MemoryInterface, 69	jeod::BasicJeodTrickSimInterface, 27 jeod::CheckPointInputManager, 33
JeodTrickIntegrator jeod::JeodTrickIntegrator, 75	jeod::CheckPointOutputManager, 38
JeodTrickMemoryInterface	jeod::JeodDynbodyIntegrationLoop, 47
jeod::JeodTrickMemoryInterface, 81	jeod::JeodMemoryInterface, 56
JeodTrickSimInterface	jeod::JeodSimulationInterface, 64
jeod::JeodTrickSimInterface, 90	jeod::JeodTrick10MemoryInterface, 71
,,	jeod::JeodTrickIntegrator, 76
loop_sim_object	jeod::JeodTrickMemoryInterface, 84
jeod::JeodDynbodyIntegrationLoop, 50	jeod::JeodTrickSimInterface, 91
	jeod::SectionedInputBuffer, 93
MAKE_MESSAGE_CODE	jeod::SectionedInputStream, 100
SimInterface, 17	jeod::SectionedOutputBuffer, 104
MAX_MSG_SIZE	jeod::SectionedOutputStream, 108
SimInterface, 17	jeod::SimInterfaceMessages, 112
manager	jeod::TrickMessageHandler, 116
jeod::SectionedInputStream, 101	jeod::TrickMessageHandlerMixin, 118
jeod::SectionedOutputStream, 109	overflow
memory_attributes.hh, 124	jeod::SectionedOutputBuffer, 104
JEOD_ATTRIBUTES, 125 memory debug level	owner
jeod::JeodSimulationInterfaceInit, 66	jeod::JeodTrickMemoryInterface::ContainerList-
memory_interface.cc, 125	Entry, 41
memory_interface.th, 126	owner_type
memory_manager	jeod::JeodTrickMemoryInterface::ContainerList-
jeod::BasicJeodTrickSimInterface, 29	Entry, 41
MemoryManagerWrapper	PATH
jeod::CheckPointOutputManager, 39	SimInterface, 17
message_handler	phasing_error
jeod::TrickMessageHandlerMixin, 118	jeod::SimInterfaceMessages, 113
message_suppress_id	pointer_attributes
jeod::JeodSimulationInterfaceInit, 66	jeod::JeodMemoryInterface, 56
message_suppress_location	jeod::JeodTrickMemoryInterface, 84
jeod::JeodSimulationInterfaceInit, 66	PostCheckpoint
message_suppression_level	jeod::JeodSimulationInterface, 60
jeod::JeodSimulationInterfaceInit, 67	PreCheckpoint
Mode	jeod::JeodSimulationInterface, 60
jeod::JeodSimulationInterface, 60	primitive_attributes
mode	jeod::JeodMemoryInterface, 56
jeod::JeodSimulationInterface, 65	jeod::JeodTrickMemoryInterface, 85
jeod::JeodTrickMemoryInterface, 89	process_message
Models, 11	jeod::TrickMessageHandler, 116
	mandatan alla astion
nelements	register_allocation
jeod::JeodTrickMemoryInterface::AllocationMap-	jeod::JeodMemoryInterface, 57
Entry, 22	jeod::JeodTrickMemoryInterface, 85
NumModes	register_container jeod::JeodMemoryInterface, 57
jeod::JeodSimulationInterface, 60	jeod::JeodMemoryInterface, 71
open_checkpoint_file	jeod::JeodTrickMemoryInterface, 71
jeod::BasicJeodTrickSimInterface, 27	register_contents
open_restart_file	jeod::TrickMessageHandler, 116
jeod::BasicJeodTrickSimInterface, 27	register_reader
Operational	jeod::CheckPointInputManager, 33
jeod::JeodSimulationInterface, 60	register_writer
operator void *	ieod::CheckPointOutputManager, 38

remove_integrable_object	jeod::BasicJeodTrickSimInterface, 28
jeod::JeodDynbodyIntegrationLoop, 47	jeod::JeodSimulationInterface, 64
remove_sim_object	jeod::JeodTrickMemoryInterface, 87
jeod::JeodDynbodyIntegrationLoop, 47	set_step_number
remove_sim_object_bodies	jeod::JeodTrickIntegrator, 77
jeod::JeodDynbodyIntegrationLoop, 48	set_time
reset_first_step_derivs_flag	jeod::JeodTrickIntegrator, 77
jeod::JeodTrickIntegrator, 76	set_time_to_loop_start
Restart	jeod::JeodDynbodyIntegrationLoop, 48
jeod::JeodSimulationInterface, 60	Shutdown
Restore	jeod::JeodSimulationInterface, 60
jeod::JeodSimulationInterface, 60	sim interface
restore_allocations	jeod::JeodSimulationInterface, 65
jeod::BasicJeodTrickSimInterface, 27	sim_interface_messages.cc, 126
jeod::JeodTrick10MemoryInterface, 72	sim_interface_messages.hh, 127
jeod::JeodTrickMemoryInterface, 87	SimInterface, 13
restore_containers	CLASS, 15
jeod::BasicJeodTrickSimInterface, 27	ER7_UTILS_RESTRICT, 15
jeod::JeodTrick10MemoryInterface, 72	ER7_UTILS_UNUSED, 15
jeod::JeodTrickMemoryInterface, 87	JEOD_INTPTR_T, 16
restore_first_step_derivs_flag	JEOD_PTRDIFF_T, 16
jeod::JeodTrickIntegrator, 77	JEOD_SIZE_T, 17
saved mode	JEOD_UINTPTR_T, 17
-	JEOD_UNUSED, 17
jeod::JeodSimulationInterface, 65	MAKE_MESSAGE_CODE, 17
sectbuf	MAX_MSG_SIZE, 17
jeod::SectionedInputStream, 101	PATH, 17
jeod::SectionedOutputStream, 109	trick_MM, 17, 18
section_end	trick_curr_integ, 17
jeod::BasicJeodTrickSimInterface, 29	SimInterfaceMessages
jeod::CheckPointInputManager, 34	jeod::SimInterfaceMessages, 112
jeod::CheckPointOutputManager, 39	simulation_interface.cc, 127
jeod::SectionedOutputStream, 109	simulation_interface.hh, 128
section_start	singleton_error
jeod::BasicJeodTrickSimInterface, 29	jeod::SimInterfaceMessages, 113
jeod::CheckPointInputManager, 34	start pos
jeod::CheckPointOutputManager, 40	jeod::CheckPointInputManager::SectionInfo, 111
jeod::SectionedOutputStream, 110	jeod::SectionedInputBuffer, 95
SectionInfo	jeod::SectionedInputStream, 101
jeod::CheckPointInputManager::SectionInfo, 111	stream
SectionedInputBuffer	jeod::CheckPointInputManager, 35
jeod::SectionedInputBuffer, 92, 93	jeod::CheckPointOutputManager, 40
SectionedInputStream	jeod::SectionedInputStream, 101
jeod::SectionedInputBuffer, 94	jeod::SectionedOutputStream, 110
jeod::SectionedInputStream, 98, 99	structure attributes
SectionedOutputBuffer	jeod::JeodMemoryInterface, 57
jeod::SectionedOutputBuffer, 103	jeod::JeodTrickMemoryInterface, 87
SectionedOutputStream	jeodoeod modwernorymteriace, or
jeod::SectionedOutputBuffer, 105	tag
jeod::SectionedOutputStream, 107	jeod::SectionedOutputStream, 110
sections	time_manager
jeod::CheckPointInputManager, 35	jeod::JeodDynbodyIntegrationLoop, 50
set_checkpoint_file_name	translate_addr_to_name
jeod::BasicJeodTrickSimInterface, 28	jeod::JeodTrick10MemoryInterface, 72
set_deriv_ephem_update	translate_name_to_addr
jeod::JeodDynbodyIntegrationLoop, 48	jeod::JeodTrick10MemoryInterface, 73
	· · · · · · · · · · · · · · · · · · ·
set_first_step_derivs_flag	Trick, 20
jeod::JeodTrickIntegrator, 77	trick10_memory_interface.cc, 128
set_mode	trick10_memory_interface.hh, 129

```
trick_MM
     SimInterface, 17, 18
trick_checkpoint_agent
    jeod::JeodTrick10MemoryInterface, 73
trick_curr_integ
     SimInterface, 17
trick_dynbody_integ_loop.cc, 130
trick_dynbody_integ_loop.hh, 130
trick integrator
    jeod::JeodTrickIntegrator, 78
trick_memory_interface
    jeod::BasicJeodTrickSimInterface, 29
trick_memory_interface.cc, 131
trick_memory_interface.hh, 131
trick_memory_interface_alloc.cc, 132
trick_memory_interface_attrib.cc, 133
trick memory interface chkpnt.cc, 133
trick memory interface xlate.cc, 134
trick_message_handler.cc, 135
trick_message_handler.hh, 135
trick sim interface.cc, 136
trick sim interface.hh, 136
TrickMessageHandler
     jeod::TrickMessageHandler, 115
TrickMessageHandlerMixin
    jeod::TrickMessageHandlerMixin, 117
typeid_info
    jeod::JeodTrickMemoryInterface::AllocationMap-
          Entry, 22
underflow
    jeod::SectionedInputBuffer, 94
update_integration_group
    jeod::JeodDynbodyIntegrationLoop, 48
Utils, 12
void_pointer_attributes
    jeod::JeodMemoryInterface, 57
    jeod::JeodTrickMemoryInterface, 88
```