

MOTOROLA Semiconductor Products Inc.

M68FD3601 - M68FD3604

EXORDisk

MOTOROLA FLOPPY DISK SYSTEM

USER'S GUIDE

The information in this manual has been carefully reviewed and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies. Furthermore, such information does not convey to the purchaser of the semiconductor devices described any license under the patent rights of Motorola Inc. or others.

The material in this manual is subject to change, and Motorola Inc. reserves the right to change specifications without notice.

EXORDisk, EXORciser, and EXbug are trademarks of Motorola Inc.

TABLE OF CONTENTS

SECTION 1: UNPACKING AND INSTALLATION INSTRUCTION	1-1	
1-1	Unpacking Instruction	1-1
1-2	EXORdisk Installation Instruction	1-1
1-3	EDOS Installation Instruction	1-1
SECTION 2: SYSTEM ORGANIZATION	2-1	
2-1	EDOS Software	2-1
2-1.1	EDOS Resident Driver	2-1
2-1.2	EDOS Executive	2-1
2-1.3	EDOS Editor	2-1
2-1.4	EDOS Assembler	2-1
2-2	EDOS Software Logic	2-2
SECTION 3: EDOS OPERATION	3-1	
3-1	EDOS Start-up Procedures	3-1
3-2	File Organization	3-1
3-3	EDOS Directives	3-2
3-3.1	Assemble	3-2
3-3.2	Copy	3-3
3-3.3	Dump	3-3
3-3.4	Edit	3-3
3-3.5	Home	3-4
3-3.6	Initialize	3-4
3-3.7	List Directory	3-5
3-3.8	Monitor (EXbug) Return	3-5
3-3.9	Name File	3-5
3-3.10	Print	3-6
3-3.11	Run A Program	3-6
3-3.12	Store	3-6
3-3.13	Transfer (Append)	3-6
3-3.14	Update EDOS System Area	3-7
3-4	Generating EDOS System Area	3-7
3-4.1	Multi-Drive System With Existing System Diskette	3-7
3-4.2	Single-Drive System With Existing System Diskette	3-8
3-4.3	No Existing System Diskette	3-8
3-5	EDOS Error Messages	3-9
SECTION 4: EDOS DRIVER	4-1	
4-1	Disk Input/Output	4-1
4-2	EXORdisk Signal Specifications	4-3
APPENDIX A: LISTING OF EDOS RESIDENT DRIVER	A-1	
APPENDIX B: EXORdisk SCHEMATICS	B-1	

Figure 1-1. M68R3602 EXORdisk

SECTION 1

UNPACKING AND INSTALLATION INSTRUCTIONS

1-1 UNPACKING INSTRUCTIONS

Unpack the EXORdisk (Motorola's Floppy Disk) in accordance with the following procedures.

- (a) Remove unit from shipping box.
- (b) Remove door bracing materials from drive unit doors.
- (c) Remove chassis shroud by removing 2 screws in upper rear and 1 screw on lower rear of each side.
- (d) Remove all packing material from inside unit.
- (e) Visually inspect for physical damage.
- (f) Replace chassis shroud.

1-2 EXORdisk INSTALLATION INSTRUCTIONS

Insert the M68IFC EXORciser Interface Module into any free board slot within the EXORciser. Connect the ribbon cable connector from the EXORTape to the Interface Board. Plug the EXORTape power cord into any 3-wire, grounded, 117 VAC, 50/60 Hz. outlet.

1-3 EDOS INSTALLATION INSTRUCTIONS

There are no installation instructions for EDOS (EXORciser floppy Disk Operating System). All EDOS software is provided on one system diskette.

SECTION 2

SYSTEM ORGANIZATION

2-1 EDOS SOFTWARE PROGRAMS

EDOS consists of the following programs:

EDOS Resident Driver
EDOS Executive
EDOS Editor
EDOS Assembler

2-1.1 EDOS Resident Driver

The EDOS Resident Driver Program is that portion of EDOS contained in the PROM. In addition to performing the disk input/output and program loading functions for EDOS, this resident driver program is available for use by a user's program to perform disk read operations, disk write operations, and program overlay and chaining operations (see Section 4).

2-1.2 EDOS Executive

The EDOS Executive Program is brought into RAM memory when the EXbug's MAID command E800;G is typed. The EDOS Executive program performs all EDOS operational and file management functions. The EDOS Executive program is in RAM, and is awaiting an EDOS directive when it prints the character ! on the console device.

2-1.3 EDOS Editor

The EDOS Editor Program is functionally equivalent to the Motorola EXORciser Resident Editor except that editor input is derived from a file on disk, and Editor Program output is stored into a file on disk.

2-1.4 EDOS Assembler

The EDOS Assembler Program is functionally equivalent to the Motorola EXORciser Resident Assembler except that source input is derived from a file on disk, and hex object output is stored into a file on disk.

EDOS SOFTWARE LOCATION

All EDOS programs have been stored on the diskette enclosed with the EXORdisk. To EDOS, the disk storage space is divided into two distinct regions: system area and user file area.

The system area contains the EDOS Executive, EDOS Editor, and EDOS Assembler Programs. The user file area contains user programs in either source or hex form.

The delivered diskette contains a ready-to-use system area, and hex object files of the EDOS Executive, EDOS Editor, and EDOS Assembler Programs in the user file area as follows:

- File 1 contains EDOS Executive Hex
- File 2 contains EDOS Editor Hex
- File 3 contains EDOS Assembler Hex

NOTE

Due to the volatility of the diskette media, it is highly recommended that back-ups of the EDOS Executive, EDOS Editor, and EDOS Assembler Programs be made as soon as possible. This may be done by dumping files 1, 2, and 3 of the supplied diskette using the EDOS D (Dump) directive.

SECTION 3

EDOS OPERATION

3-1

EDOS START-UP PROCEDURES

To start EDOS, follow the EXbug start-up procedure for the EXORciser. Two sets of operator directives now exist, those for the EXbug and those for EDOS. Since the EXbug has not changed, it is awaiting directives. When an exclamation mark (!) is printed on the console device, EDOS is awaiting directives.

The operator can go from EDOS to the EXbug at will.

To enter EDOS from EXbug's MAID simply type E800;G.

To enter EXbug from EDOS simply type M.

NOTE

The operator should get into the habit of turning the EXOR-disk power on prior to starting EXbug. No diskette media should be in a drive while the EXORDisk power is being turned on or off.

- (1) Turn EXORciser, console, and EXORDisk power on.
- (2) Start EXbug.
- (3) Insert a system diskette, one with system area initialized, into drive unit 0 (referred to as system drive) and close door.
- (4) EDOS and EXbug are now ready for use.

3-2

FILE ORGANIZATION

The user file area on each diskette media is divided into seven fixed length areas (files) numbered 1 through 7. Any file may contain either program source or hex object data. When referencing a particular file, the operator enters the diskette file number 1 through 7 preceded by the drive unit number in which that diskette is presently loaded, 0 through 3.

File numbers 1-7, or 01 through 07, refer to files 1 through 7 on the diskette loaded in drive unit 0.

File numbers 11-17 refer to files 1 through 7 on the diskette loaded in drive unit 1.

File numbers 21-27 refer to files 1 through 7 on the diskette loaded in drive unit 2.

File numbers 31-37 refer to files 1 through 7 on the diskette loaded in drive unit 3.

The files are contiguous and begin on the following tracks:

file	1	track	14
2			23
3			32
4			41
5			50
6			59
7			68

9 tracks

230

234 sectors

3-3 EDOS DIRECTIVES

When an exclamation mark (!) is printed on the console device, EDOS is awaiting any one of the following directives. The directives are also identified in Table 3-1 at the end of this Chapter.

3-3.1 ASSEMBLE

PURPOSE: To assemble a user's source program and to produce an assembly listing or a hex object or both.

FORMAT: !An, m, p)

where n is the input source file number, m is the output hex file number, and p is the desired assembly alternatives.

if p = 3 only a listing is generated to the list device.

if p = 4 only a hex object output is generated to disk file m.

if p = 2 both a listing and an hex object are generated.

NOTE

Assembler OPT directives must allow list or object for either to be executed.

COMMENTS: All 3 parameters, n, m, and p must be specified. n cannot equal m. If p = 3, existing file m is unaffected. The assembler prints, on the console device, the pass it is performing, 0 through 4, where 0 imply assembly complete.

3-3.2 COPY

PURPOSE: To copy the contents of one diskette onto another.

FORMAT: !C

The contents of the diskette in drive unit 0 are copied onto the diskette in drive unit 1.
(7 minutes)

COMMENTS: The data contained on the diskette in drive unit 0 may be of any format, EDOS or not.

3-3.3 DUMP

PURPOSE: To dump the contents of a user file to the punch output device.

FORMAT: !DCn or !DTn

where n is the user file number. DC dumps to cassette & DT dumps to a TTY terminal.

COMMENTS: Leader and trailer (blank) tape is punched if DT is used: the user file is unaffected.

3-3.4 EDIT

PURPOSE: To perform edit operations on a user's source program and to produce an updated source file.

FORMAT: !En, m)

where n is the input source file number and m is the output (updated) source file number. If n is 0, a zero-content input file is assumed (used when entering a new source program from the keyboard). n cannot equal m.

COMMENTS: When the EDOS Editor starts, it prints

EDOS EDITOR
@

All EDOS Editor operations are functionally identical to those of the Motorola EXORciser Resident Editor. Completion of a program edit must be terminated by the editor command

@E \$\$

The E command completes the editing operations, updates and closes the source output file, and returns control to the EDOS Executive Program.

3-3.5 HOME

PURPOSE: To return the head on the selected drive unit back to the "home" or track 0 position.

FORMAT: !Hu)

where u is the drive unit number (0 through 3), in which the diskette to be repositioned, is loaded.

3-3.6 INITIALIZE

PURPOSE: To clear the user file area and to delete the user file names on the specified diskette.

FORMAT: !Iu)

where u is the drive unit number (0 through 3), in which the diskette to be initialized, is loaded. If u is omitted, drive unit 0 is assumed.

COMMENTS: The initialize command does not affect the system area of the diskette media.

3-3.7 LIST DIRECTORY

PURPOSE: To produce a listing on the list device, of all user filenames, filenumbers, and file sizes (in sectors) on the specified diskette.

FORMAT: !Lu)

where u is the drive unit number (0 through 3), in which the diskette whose files are to be listed, is loaded. If u is omitted, drive unit 0 is assumed.

COMMENTS: Each line of the list output contains the file number, file name, and file size in sectors.

3-3.8 MONITOR (EXbug) RETURN

PURPOSE: To return control to EXbug, from the EDOS Executive Program.

FORMAT: !M

3-3.9 NAME FILE

PURPOSE: To assign a .1 to 10 character alphanumeric name to a user file.

FORMAT: !Nn,xxxxxxxxx)

where n is the file number to be named, and xxxxxxxxx is the 1 to 10 character alphanumeric name to be assigned to file n.

COMMENTS: Naming a file replaces any previous name assigned to that file. The Name function has no effect on the files content.

3-3.10 PRINT

PURPOSE: To print the contents of a user file to the list device.

FORMAT: !Pn

where n is the user file number.

COMMENTS: The user file is unaffected.

3-3.11 RUN A PROGRAM

PURPOSE: To execute a user program from a user file.

FORMAT: !Rn

where n is the user file number of the hex file to be loaded. This command is functionally identical to the EXbug LOAD C command.

COMMENTS: Following the loading of the user program control will return to EXbug.

3-3.12 STORE

PURPOSE: To load a user file from the tape input device.

FORMAT: !SCn, !SPn, or !STn

where n is the user file number to be loaded. SC loads from TI cassette, SP loads from the EXORtape, and ST loads from a TTY terminal.

COMMENTS: The previous contents of the specified user file are replaced with the new data.

3-3.13 TRANSFER (Append)

PURPOSE: To append one user's file to another user's file.

FORMAT: !Tn, m

where n is the file number of the input file whose contents get appended to file number m. The contents file number n are unchanged.

3-3.14

UPDATE EDOS SYSTEM AREA

PURPOSE: To update the EDOS System Area (EDOS Executive, EDOS Editor, or EDOS Assembler Programs) from the tape input device.

FORMAT: !XCn, !XPn, or !XTn

where n specifies the EDOS Program to be updated. If n = 0, the EDOS Executive is replaced; if n = 1, the EDOS Editor is replaced; if n = 2, the EDOS Assembler is replaced. (See STORE command for input device definition.)

COMMENTS: This command is used primarily to update EDOS System Programs as new versions become available, and to generate additional diskette media with EDOS modules in the System Area (see Paragraph 3-4).

3-4

GENERATING EDOS SYSTEM AREA

The EXORdisk is delivered with one diskette media which contains the EDOS programs in the system area of the diskette. When operating the EXORdisk, it is imperative that the diskette media loaded in drive unit 0 be such a system disk, since EDOS looks to drive unit 0 for the EDOS Executive, EDOS Editor, and EDOS Assembler Programs.

If additional system diskettes are desired, or if a new system diskette must be generated, follow one of the following procedures.

3-4.1

MULTI-DRIVE SYSTEM WITH EXISTING SYSTEM DISKETTE

This procedure assumes an existing system diskette and a system which contains a drive unit 0 and a drive unit 1.

(1) Load existing system diskette into drive unit 0 and a new diskette into drive unit 1.

(2) Type:

!C

(3) When EDOS returns with !, type:

!I 1

3-4. 2

SINGLE DRIVE SYSTEM WITH EXISTING SYSTEM DISKETTE

This procedure assumes an existing system diskette and a system which contains only one drive unit.

(1) Follow EDOS START-UP procedure in Paragraph 3-1.

(2) Type MAID command:

E800;G

(3) Insert a new diskette into drive unit 0.

(4) Place the EDOS Executive Program (see Paragraph 2-2) into the tape reader device and type:

!XC0 **!XP0** or **!XT0**

(5) Place the EDOS Editor Hex into the paper tape reader device and type:

!XC1 **!XP1** or **!XT1**

(6) Place the EDOS Assembler Hex into the paper tape reader device and type:

!XC2 **!XP2** or **!XT2**

(7) Type:

!I

3-4. 3

NO EXISTING SYSTEM DISKETTE

This procedure assumes that no system diskette exists.

(1) Start EXbug.

(2) Place the EDOS Executive Program (see Paragraph 2-2) into the tape reader device and load it.

(3) Type the MAID command:

20;G

(4) Proceed to step 3 of Paragraph 3-4. 2.

EDOS ERROR MESSAGES

The following error messages may be printed by EDOS during its operation.

- E1 Disk read error (CRC error after 5 read trys). Copy diskette to recover all but bad data.
- E2 Output file overflow. Output data exceeded 9 track maximum file size.
- E3 Requested drive not ready or diskette not loaded.

Table 3-1. Summary of EDOS Directives

DIRECTIVE	DESCRIPTION
An, m p)	Assemble user source file n, direct hex to file m, and perform pass 2 of p.
C	Copy contents of diskette in drive unit 0 to diskette in drive unit 1.
DCn) or DTn)	Dump contents of user file n to punch device.
En, m)	Edit user source file n, direct edited source to file m.
Hu)	Return head on drive unit u to track 0.
I u)	Initialize (clear) the user file area of the diskette in drive unit u.
Lu)	List the user file directory of the diskette in drive unit u.
M	Return to EXbug.
Nn, xxxxxxxxxxxx)	Assign the 1 to 10 character alphanumeric name to user file n.
Pn)	Print contents of user file n to list device.
Rn)	Run (load) user hex file n.
SCn) SPn) or STn)	Store tape loaded in reader device into file m.
Tn, m	Transfer (Append) the contents of file n to the contents of file m.
XCn) XPN) or XTn)	Update system module n (See Paragraph 3-3.12).

30 chas of commt
52 chs / line
MAX

@ 24 ch/line
29 952 chas/record
1200 committed lines.

SECTION 4

EDOS DRIVER

4-1

DISK INPUT/OUTPUT

Provisions have been made in the EDOS Resident Driver (see Appendix A) to enable the programmer to develop user oriented programs which utilize the EXORdisk as a peripheral mass storage device outside of the EDOS environment. Contained in the Driver is a disk read routine (RI) and a disk write routine (WRT) which provide byte oriented input and output capabilities, respectively, to the user.

In order to use the disk input/output routines, RI and WRT, it is the programmer's responsibility to first set up pointers to the area on disk which is to be accessed. This is known as "opening" a disk file. Once a file area on disk has been opened, RI and WRT may be called any number of times. Once the disk file has been opened, the Driver handles all maintenance of the file pointers from then on. It should be noted that only one input file and one output file may be opened at any given time.

The following RAM memory locations are used by the Driver:

LOC	DESCRIPTION
06	Input file size (sectors)
07	Input file's beginning track address
08	Input file's beginning unit/sector address
09	Controller's read buffer counter
0A	Output file size (sectors)
0B	Output file's beginning track address
0C	Output file's beginning unit/sector address
0D	Controller's write buffer counter
0E, 0F	Temporary locations

To open an input file, the user simply stores the appropriate input file information into locations 06-09. Then each call to RI will return the next byte of data, from the disk, in the A-register. If no more data exists (i.e. the Input file size = 0) the carry bit is returned as a "1", else the carry bit is returned as a "0". The input file size should be set to the number of sectors +1 that are to be read before the Driver is to return an end-of-file indication (carry bit set). If the programmer is going to perform his own end-of-file monitoring, the file size may be set to some

arbitrarily large number (i. e. OFFH). The input file's beginning track address should be set to the track number (00-4CH) from which input data is to begin being retrieved. The input file's beginning unit/sector address should be set to contain the drive unit number (00-A1) in bits 6 & 7, and the sector -1 (i.e. 00-19H as opposed to 01-1AH) from which input data is to begin being retrieved. Location 09 should be set to 00. Each call to RI will bring in the next sequential byte of data from the disk. As a sector (128 bytes) of data is read, RI increments the disk address (locations 07 and 08) and decrements the input file size (location 06). Any sector containing a DD mark is ignored.

To open an output file, the user simply stores the appropriate output file information into locations 0A-0D. Then each call to WRT will output to disk the byte contained in the A-register. The output file size should be set to the number of sectors that are allowed to be written before the Driver terminates by printing E3 onto the TTY console and returning to EXbug. If the programmer is going to perform his own maximum output file size monitoring, the output file size must always be kept between 01 and OFFH. The output file's beginning track address should be set to the track number (00-4CH) to which output data is to begin being written. The output file's beginning unit/sector address should be set to contain the drive unit number (00-11) in bits 6 & 7, and the sector (01-1AH) to which output data is to begin being written. Location 0D should be set to 00. Each call to WRT will take the byte contained in the A-register and output it to the EXORdisk. When 128 bytes have been sent to the EXORdisk, WRT writes that data onto the disk and increments the disk address (locations 0B & 0C) and decrements the output file size (location 0A). WRT verifies every sector it has written and if, after 5 attempts, it is unable to write a sector, it writes a DD mark to that sector and advances to the next contiguous disk address and attempts the disk write again.

When the user has written all his data to the disk, using the driver, it is possible that a partial sector of data still remains in the EXORdisk write buffer. To insure that all data has been written to disk, the user should continue outputting a pad character (i. e. 00) until the write buffer reaches 128 bytes and WRT writes it to disk. An example of such a "fill" routine is as follows:

FILL	TST	\$0D
	BNE	FILL1
	RTS	
FILL1	CLR	A
	JSR	WRT
	BRA	FILL

It should be noted that the driver utilizes a logical/physical technique of disk addressing. Sectors on a diskette are physically adjacent and contiguous from 1-26 (01-1AH). It is obvious that after accessing sector 1, an entire revolution of the disk must occur if sector 2 cannot be accessed immediately. To overcome the rotational delays, the driver translates the requested sector address (logical sector) into some other sector address (physical sector) which is then used by the driver. Table TBL is the conversion table for this translation. If sector 2 is requested, physical sector 10 (0AH) is the area on disk accessed; if sector 20 (14H) is requested, physical sector 16 (10H) is the area on disk requested. This entire technique is normally transparent to the user if he remains under the EDOS Driver. Of course, if desired, the contents of TBL may be altered, even to the point of providing a 1:1 translation of logical:physical sectoring.

4-2 EXORdisk SIGNAL SPECIFICATIONS

Electrical - All signals are compatible with MC6820 PIA chips.

Input Data and Status: 8 bits, negative true, PIA address EC00, bits 0-7.

Logic 1: 0 to 0.4 volts
Logic 0: 2.4 volts min.

Read DD Mark	-	Drive Fail Error	Drive Write Prot'd	CRC Error	Unit # MSB	Unit # LSB	-
7	6	5	4	3	2	1	0

NOTE
IRQA1 bit 7 is device BUSY

These 8 lines contain status or data, depending upon the state of the "Read Data Byte" signal.

DATA: Bits 0-7 where bit 0 is LSB.

STATUS:

Bits 1 & 2 - Defines last selected unit (00-11).

Bit 3 - If 1, a CRC error was encountered on the last read operation. This must be reset with a "clear error flags" command.

- Bit 4** - If 1, selected drive unit is write protected.
- Bit 5** - If 1, selected drive unit is not up to speed, door is opened, or no diskette is inserted.
- Bit 7** - If 1, a DD mark was encountered on the last read operation. The sector's data was still read. This must be reset with a "clear error flags" command.

Output Data: 8 bits, negative true, PIA address EC06, bits 0-7.

If data is track address:

-	Track						
7	6	5	4	3	2	1	0

If data is unit and sector address:

Unit	-	Sector					
7	6	5	4	3	2	1	0

Output Commands: 8 bits, negative true, PIA address EC02, bits 0-7.

CLR Drive Elect	Read Data Byte	Data Line Definition Bits	Drive Control Definition Bits	-
7	6	5	4	3

NOTE

CB2 provides command acceptance strobe.

Drive control definition bits (3 lines encoded)

A control operation causes "unit busy" on the leading edge of CB2. When the operation is complete, IRQ1 goes Low.

- 001 read a 128-character sector into the controller's read buffer.
- 010 write 128-character sector from controller's write buffer. Data is recycled into write buffer during write operation.
- 011 read a 128-character sector for CRC verification. Controller's read buffer is unaffected.
- 100 seek to specified unit and track.
- 101 clear the controller's error flags and abort the present operation.
- 110 return the selected unit to track 0.
- 111 write the deleted data address mark onto the specified unit/track/sector, when the next "write sector" command is issued.

Data line definition bits (2 lines encoded)

Indicates that the 8 data lines are valid, and describes the type of data contained on the 8 data lines.

- 01 data lines specify track address.
- 10 data lines specify unit and sector address.
- 11 data lines contain data which is to be written into the controller's write buffer. The data is transferred at the leading edge of the "accept-control-strobe" signal.

READ DATA BYTE

As long as this signal is false (0), the drive status signals are gated onto the output lines. When this signal is true (1), the output data is gated onto the output lines. If CB2 signal goes true (1) while this "read-data-byte" signal is true (1), the next data byte is shifted from the controller's read buffer onto the output lines.

Clear drive electronics, data buffers, and data buffer counters. This is a general controller and drive reset command.

MEDIA

IBM DISKETTE OR EQUIVALENT

- . **Tracks per inch** 48
- . **Number of tracks** 77

FORMAT

- . **Tracks Per Diskette** 77 (00-4CH)
- . **Sectors Per Track** 26 (01-1AH)
- . **Bytes Per Sector** 128
- . **Bytes Per Diskette** 256, 256
- . **Bits Per Diskette** 2, 050, 048

SECTION 5

MAINTENANCE

5-1 DIAGNOSTIC TEST

The EXORdisk diagnostic program listing is presented in Figure 5-1.

5-2 DRAWINGS

The EXORdisk schematic diagrams are presented in Appendix B.

APPENDIX A

A-1

LISTING OF EDOS RESIDENT DRIVER

00001		NAM	FDOS	RESIDENT MODULE
00002		OPT	SYMBOLS	
00003		OPT	O=RESOBJ	

00005 * 4/9/75

00007 * VERSION 2.0

00009	EC00	DKDID	EQU	\$EC00
00010	EC01	DKDIC	EQU	\$EC01
00011	EC02	DKCQD	EQU	\$EC02
00012	EC03	DKCOC	EQU	\$EC03
00013	EC06	DKDOD	EQU	\$EC06
00014	EC07	DKDOC	EQU	\$EC07

00016	F564	XBUG	EQU	\$F564
00017	F018	CO	EQU	\$F018
00018	FF90	TEMP	EQU	\$FF90
00019	FF8A	XSTACK	EQU	\$FF8A

00021	0020	EXEC	EQU	\$20
00022	0023	UPDATE	EQU	\$23

00024	0020	EDIT	EQU	\$20
00025	0400	ASMB	EQU	\$400

0027	0000	PASS	EQU	0	ASSEMBLY PASS INFO
0028	0001	OFILE	EQU	1	OFILE NUMBER
0029	0002	OUNIT	EQU	2	OFILE UNIT
0030	0003	IUNIT	EQU	3	IFILE UNIT - SCTR/UNIT
0031	0004	ISIZE	EQU	4	IFILE SIZE
0032	0006	ITRK	EQU	6	IFILE TRACK
0033	0007	ISCTR	EQU	7	IFILE SECTOR
0034	0008	ICNTR	EQU	8	IFILE BUFFER COUNTER
0035	0009	OSIZE	EQU	9	OFILE SIZE
0036	000B	OTRK	EQU	11	OFILE TRACK
0037	000C	OSCTR	EQU	12	OFILE SECTOR
0038	000D	OCNTR	EQU	13	OFILE BUFFER COUNTER
0039	000E	TITRK	EQU	14	TEMP LOC 1
0040	000F	TISZE	EQU	15	TEMP LOC 2

00042 E800 ORG \$E800

00044 E800 FDOS EQU *
 00045 E800 BD E841 JSR FDOS1
 00046 E803 7E 0020 JMP EXEC LOAD FDOS
 START EXEC

00048 E806 INTIO EQU *
 00049 E806 7E E859 JMP RESET INITIALIZE I/O

00051 E809 XRI EQU *
 00052 E8:09 7E E91B JMP RI DISK READ VECTOR

00054 E80C XWRT EQU *
 00055 E80C 7E E98E JMP WRT DISK WRITE VECTOR

00057 E80F UPDT EQU *
 00058 E8:0F 7E EA79 JMP PATCH
 00059 E8:12 7E 0023 JMP UPDATE START UPDATE

00061 E815 PROG EQU *
 00062 E8:15 BD E887 JSR REDX
 00063 E8:18 7E F564 JMP XBUG LOAD PROGRAM
 GO TO EXBUG

00065 E81B ASSEM EQU *
 00066 E8:1B BD E887 JSR REDX LOAD ASSEMBLER
 00067 E8:1E BD E82D JSR RESTR RESTORE IFILE POINTERS
 00068 E8:21 7E 0400 JMP ASMB START ASSEMBLER

00070 E824 EDITR EQU *
 00071 E824 BD E887 JSR REDX LOAD EDITOR
 00072 E827 BD E82D JSR RESTR RESTORE IFILE PNTRS
 00073 E82A 7E 0020 JMP EDIT START EDITOR

00075 E82D RESTR EQU *
 00076 E82D DE 0F LDX TISZE RESTORE IFILE PNTRS
 00077 E82F DF 04 STX ISIZE IFILE SIZE
 00078 E831 96 0E LDA A TITRK
 00079 E833 97 06 STA A ITRK TRACK
 00080 E835 96 03 LDA A IUNIT UNIT/SECTOR
 00081 E837 0C CLC
 00082 E838 46 ROR A
 00083 E839 46 ROR A
 00084 E83A 46 ROR A
 00085 E83B 97 07 STA A ISCTR
 00086 E83D 7F 0008 CLR ICNTR BUFFER COUNTER
 00087 E840 39 RTS

PAGE 003 FDOS RES

00089	E841	FDOS1	EQU	*	
00090	E841	BD E859	JSR	RESET	RESET ELECTRONICS
00091	E844	CE 004E	LDX	#78	SET ISIZE=78
00092	E847	DF 04	STX	ISIZE	
00093	E849	7F 0006	CLR	ITRK	TRACK=1
00094	E84C	7C 0006	INC	ITRK	
00095	E84F	7F 0007	CLR	ISCTR	SETCTOR=0
00096	E852	7F 0008	CLR	ICNTR	RD BFR EMPTY
00097	E855	BD E887	JSR	REDX	LOAD FDOS
00098	E858	39	RTS		

00100 * SUBROUTINE TO SET UP PIA'S AND RESET
 00101 * DRIVE ELECTRONICS.

00103	E859	RESET	EQU	*	
00104	E859	7F EC01	CLR	DKDIC	SET DIRECTIONS
00105	E85C	7F EC03	CLR	DKCOC	
00106	E85F	7F EC07	CLR	DKDOC	
00107	E862	7F EC00	CLR	DKDID	
00108	E865	86 FF	LDA A	#\$FF	
00109	E867	B7 EC02	STA A	DKC0D	
00110	E86A	B7 EC06	STA A	DKD0D	
00111	E86D	86 04	LDA A	#\$4	SET DATA IN CNTRL
00112	E86F	B7 EC01	STA A	DKDIC	
00113	E872	86 04	LDA A	#\$4	SET DATA OUT CNTRL
00114	E874	B7 EC07	STA A	DKDOC	
00115	E877	86 2C	LDA A	#\$2C	SET CMD OUT CNTRL
00116	E879	B7 EC03	STA A	DKCOC	
00117	E87C	86 80	LDA A	#\$80	ISSUE CLEAR ELECTRONICS
00118	E87E	B7 EC02	STA A	DKC0D	
00119	E881	86 0C	LDA A	#\$0C	
00120	E883	BD EA3E	JSR	LOOP	
00121	E886	39	RTS		

00123 * SUBROUTINE TO READ AN OBJECT FILE
 00124 * INTO MEMORY

00126	E887	REDX	EQU	*	
00127	E887	BD E912	JSR	RIX	GET A CHAR
00128	E88A	25 23	BCS	REDX3	EOF
00129	E88C	81 53	CMP A	#\$53	S?
00130	E88E	26 F7	BNE	REDX	NO
00131	E890	7F FF92	CLR	TEMP+2	RESET CHKSM
00132	E893	8D 7D	BSR	RIX	GET A CHAR
00133	E895	25 10	BCS	REDX2	LOAD ERROR
00134	E897	81 30	CMP A	#\$30	
00135	E899	27 FC	RFO	RFDY	HDR PI V-SKTD

00136 E89B 81 31	CMP A	##\$31	
00137 E89D 27 11	BEQ	REDX4	DATA BLK
00138 E89F 81 39	CMP A	##\$39	
00139 E8A1 27 E4	BEQ	REDX	EOF BLK-SKIP
00140 E8A3 81 1B	CMP A	##\$1B	ESC?
00141 E8A5 27 08	BEQ	REDX3	YES-END OF OBJECT FILE
00142 E8A7 86 3F	REDX2	LDA A	##\$3F ? LOAD ERROR
00143 E8A9 BD F018		JSR	CO
00144 E8AC 7E F564		JMP	XBUG

00146 E8AF 39 REDX3 RTS

00148 E8B0 8D 29	REDX4	BSR	RDBYT	GET BYTE COUNT
00149 E8B2 4A		DEC A	DECR	COUNT
00150 E8B3 B7 FF93		STA A	TEMP+3	SAVE CNT
00151 E8B6 8D 23		BSR	RDBYT	READ ADDR(H)
00152 E8B8 B7 FF90		STA A	TEMP	
00153 E8BB 8D 1E		BSR	RDBYT	READ ADDR(L)
00154 E8BD B7 FF91		STA A	TEMP+1	
00155 E8C0 7D FF93	REDX5	TST	TEMP+3	COUNT=0?
00156 E8C3 27 0D		BEQ	REDX6	YES
00157 E8C5 8D 14		BSR	RDBYT	NO-READ DATA
00158 E8C7 FE FF90		LDX	TEMP	
00159 E8CA A7 00		STA A	X	SAVE IT
00160 E8CC 08		INX		INCR ADDRESS
00161 E8CD FF FF90		STX	TEMP	
00162 E8D0 20 EE		BRA	REDX5	CONTINUE
00163 E8D2 8D 07	REDX6	BSR	RDBYT	READ CHKSM
00164 E8D4 7C FF92		INC	TEMP+2	
00165 E8D7 26 CE		BNE	REDX2	CHKSM ERROR
00166 E8D9 20 AC		BRA	REDX	CHKSM OK

00168 E8DB	RDBYT	EQU	*	
00169 E8DB 8D 35		BSR	RIX	GET A CHAR
00170 E8DD 25 C8		BCS	REDX2	EOF
00171 E8DF 8D 1D		BSR	CHEX	CONVERT TO HEX
00172 E8E1 25 C4		BCS	REDX2	
00173 E8E3 48		ASL A		
00174 E8E4 48		ASL A		
00175 E8E5 48		ASL A		
00176 E8E6 48		ASL A		
00177 E8E7 36		PSH A		
00178 E8E8 8D 28		BSR	RIX	
00179 E8EA 25 BB		BCS	REDX2	
00180 E8EC 8D 10		BSR	CHEX	
00181 E8EE 25 B7		BCS	REDX2	
00182 E8F0 33		PUL B		
00183 E8F1 1B		ABA		
00184 E8F2 16		TAB		
00185 E8F3 BB FF92		ADD A	TEMP+2	ADD TO CHKSM
00186 E8F6 B7 FF92		STA A	TEMP+2	
00187 E8F9 7A FF93		DEC	TEMP+3	DECR BYTE CNT
00188 E8FC 17		TBA		
00189 E8FD 39		RTS		

00191	E8FE	80 30	CHEX	SUB A	#\$30
00192	E900	25 0F		BCS	CHEX2
00193	E902	8B E9		ADD A	#\$E9
00194	E904	25 0B		BCS	CHEX2
00195	E906	8B 06		ADD A	#6
00196	E908	2A 04		BPL	CHEX1
00197	E90A	8B 07		ADD A	#7
00198	E90C	25 03		BCS	CHEX2
00199	E90E	8B 0A	CHEX1	ADD A	#10
00200	E910	0C		CLC	
00201	E911	39	CHEX2	RTS	

00203 * SUBROUTINE TO READ AN ASCII BYTE FROM DISK
 00204 * & RETURN IT IN A-REGISTER. IF EOF, CARRY IS SET

00206	E912	RIX	EQU	*	
00207	E912	BD E91B	JSR	RI	GET BYTE
00208	E915	25 03	BCS	RIX1	EOF
00209	E917	84 7F	AND A	#\$7F	
00210	E919	0C	CLC		
00211	E91A	39	RIX1	RTS	

00213 * SUBROUTINE TO READ AN 8-BIT BYTE FROM DISK &
 00214 * RETURN IT IN A-REGISTER. IF EOF, CARRY IS SET.

00216	E91B	RI	EQU	*	
00217	E91B	7D 0008	TST	ICNTR	COUNT=0
00218	E91E	26 4D	BNE	RI10	NO.
00219	E920	CE 0006 RI5	LDX	#ITRK	
00220	E923	BD E9EF	JSR	INCDA	
00221	E926	DE 04	LDX	ISIZE	DEC & CHK IFILE SIZE
00222	E928	09	DEX		
00223	E929	26 05	BNE	RI3	OK
00224	E92B	7F 0008	CLR	ICNTR	
00225	E92E	0D	SEC		SET EOF
00226	E92F	39	RTS		

00228	E930	DF 04	RI3	STX	ISIZE	
00229	E932	96 07		LDA A	ISCTR	XMIT U/S
00230	E934	BD EA03	JSR	XUS		
00231	E937	BD EA4D	JSR	CHK	MAKE SURE A DISK	
00232	E93A	86 80	LDA A	#128	SET CNTR =128	
00233	E93C	97 08	STA A	ICNTR		
00234	E93E	86 05	LDA A	#5	SET TRY COUNT=5	
00235	E940	B7 FF94	STA A	TEMP+4		
00236	E943	96 06	LDA A	ITRK	SEEK TRACK	

00237	E945	BD	EA2B		JSR	SEEK	
00238	E948	86	02	RI6	LDA A	#2	READ DATA
00239	E94A	BD	EA3E		JSR	LOOP	
00240	E94D	B6	EC00		LDA A	DKDID	DD MARK?
00241	E950	84	80		AND A	#\$80	
00242	E952	27	05		BEQ	RI4	NO
00243	E954	BD	EA38		JSR	RFLAG	YES-RESET FLAG
00244	E957	20	C7		BRA	RI5	GO TO NEXT SECTOR
00246	E959	B6	EC00	RI4	LDA A	DKDID	CRC ERROR
00247	E95C	84	08		AND A	#\$8	
00248	E95E	27	0D		BEQ	RI10	NO
00249	E960	BD	EA38		JSR	RFLAG	YES-RESET FLAG
00250	E963	7A	FF94		DEC	TEMP+4	DECR TRIES
00251	E966	26	E0		BNE	RI6	TRY AGAIN
00252	E968	86	01		LDA A	#1	CAN'T READ MEDIA
00253	E96A	7E	EA57		JMP	CHK1	
00255	E96D	86	3C	RI10	LDA A	#\$3C	SET CMD CNTRL
00256	E96F	B7	EC03		STA A	DKCOC	
00257	E972	86	40		LDA A	#\$40	SET FOR READ DATA
00258	E974	B7	EC02		STA A	DKCOD	
00259	E977	B6	EC00		LDA A	DKDID	READ DATA
00260	E97A	36			PSH A		
00261	E97B	86	2C		LDA A	#\$2C	RESET CMD CNTRL
00262	E97D	B7	EC03		STA A	DKCOC	
00263	E980	86	40		LDA A	#\$40	STROBE BFR
00264	E982	B7	EC02		STA A	DKCOD	
00265	E985	7F	EC02		CLR	DKCOD	
00266	E988	7A	0008		DEC	ICNTR	DECR READ CNTR
00267	E98B	32			PUL A		
00268	E98C	0C			CLC		
00269	E98D	39			RTS		

00271 * SUBROUTINE TO WRITE A BYTE TO DISK.
 00272 * EXPECTS BYTE IN A-REGISTER

00274	E98E	WRT		EQU *			
00275	E98E	B7	EC06		STA A	DKDOD	OUTPUT DATA
00276	E991	86	30		LDA A	#\$30	
00277	E993	B7	EC02		STA A	DKCOD	
00278	E996	7C	000D		INC	OCNTR	INCR BFR COUNT
00279	E999	96	0D		LDA A	OCNTR	=128?
00280	E99B	81	80		CMP A	#128	
00281	E99D	27	01		BEQ	WRT4	YES
00282	E99F	39			RTS		NO-EXIT
00284	E9A0	7F	000D	WRT4	CLR	OCNTR	CLR COUNT
00285	E9A3	96	0C	WRT1	LDA A	OSCTR	XMIT U/S
00286	E9A5	BD	EA03		JSR	XUS	
00287	E9A8	BD	EA4D		JSR	CHK	MAKE SURE A DISK
00288	E9AB	86	05		LDA A	#5	SET TRY COUNT=5

PAGE 007 FDOS RES

00289	E9AD	B7 FF94	STA A	TEMP+4		
00290	E9B0	96 0B	LDA A	OTRK	SEEK TRACK	
00291	E9B2	BD EA2B	JSR	SEEK		
00292	E9B5	86 04	WRT2	LDA A	#4	WRITE DATA
00293	E9B7	BD EA3E	JSR	LOOP		
00294	E9BA	86 06	LDA A	#6	READ FOR CRC	
00295	E9BC	BD EA3E	JSR	LOOP		
00296	E9BF	B6 EC00	LDA A	DKDID	CRC ERROR?	
00297	E9C2	84 08	AND A	#8		
00298	E9C4	27 12	BEQ	WRT3	NO	
00299	E9C6	BD EA38	JSR	RFLAG	YES-RESET FLAG	
00300	E9C9	7A FF94	DEC	TEMP+4	DECR TRY COUNT	
00301	E9CC	26 E7	BNE	WRT2	TRY AGAIN	
00302	E9CE	86 0E	LDA A	#\$E	WRTIE AS DD	
00303	E9D0	BD EA3E	JSR	LOOP		
00304	E9D3	BD E9DC	JSR	WRTN	INCR DA & CHK SIZE	
00305	E9D6	20 CB	BRA	WRT1		
00306	E9D8	BD E9DC	JSR	WRTN		
00307	E9DB	39		RTS		

00309 * SUBROUTINE TO INCR DA & CHK OFILE SIZE

00311	E9DC	WRTN	EQU	*	
00312	E9DC	CE 000B	LDX	#OTRK	
00313	E9DF	BD E9EF	JSR	INCDA	
00314	E9E2	DE 09	LDX	OSIZE	
00315	E9E4	09	DEX		
00316	E9E5	DF 09	STX	OSIZE	
00317	E9E7	2B 01	BMI	WRTN1	
00318	E9E9	39	RTS		
00319	E9EA	86 02	WRTN1	LDA A	#2
00320	E9EC	7E EA57		JMP	CHK1

00322 * SUBROUTINE TO INCR DA
00323 * TRACK IN 0,X, SECTOR IN 1,X

00325	E9EF	INCDA	EQU	*	
00326	E9EF	6C 01	INC	1,X	
00327	E9F1	A6 01	LDA A	1,X	SECTOR=27?
00328	E9F3	84 1F	AND A	#\$1F	
00329	E9F5	81 1B	CMP A	#27	
00330	E9F7	27 01	BEQ	INCDB	YES
00331	E9F9	39	RTS		NO
00333	E9FA	A6 01	INCDB	LDA A	1,X
00334	E9FB	84 C1		AND A	#\$C1
					SET SCTR=1

00335 E9FE A7 01	STA A 1, X	
00336 EA00 6C 00	INC X	INCR TRACK
00337 EA02 39	RTS	

00339 * SUBROUTINE TO XMIT UNIT/SECTOR (LOGICAL) BYTE

00341 EA03 XUS	EQU *	
00342 EA03 36	PSH A EXTRACT	LOG SCTR
00343 EA04 84 1F	AND A #\$1F	MASK OFF DRIVE NO
00344 EA06 CE EA5E	LDX #TBL	GET TABLE PNTR
00345 EA09 FF FF94	STX TEMP+4	AND SAVE FOR ARITHMETIC
00346 EA0C 5F	CLR B MAKE →	INTO SCTR PNTR
00347 EA0D BB FF95	ADD A TEMP+5	ADD SECTOR NO TO
00348 EA10 F9 FF94	ADC B TEMP+4	TABLE ADDRESS TO GET
00349 EA13 B7 FF95	STA A TEMP+5	PHYSICAL SECTOR NO
00350 EA16 F7 FF94	STA B TEMP+4	
00351 EA19 FE FF94	LDX TEMP+4	
00352 EA1C 33	PUL B MERGE →	UNIT & PHYS SCTR
00353 EA1D C4 C0	AND B #\$C0	
00354 EA1F A6 00	LDA A X	
00355 EA21 1B	ABA	
00356 EA22 B7 EC06	STA A DKDOD	ISSUE IT
00357 EA25 86 20	LDA A #\$20	
00358 EA27 B7 EC02	STA A DKCOD	
00359 EA2A 39	RTS	

00361 * SUBROUTINE TO SEEK TRACK IN A

00363 EA2B SEEK	EQU *	
00364 EA2B B7 EC06	STA A DKDOD	
00365 EA2E 86 10	LDA A #\$10	
00366 EA30 B7 EC02	STA A DKCOD	
00367 EA33 86 08	LDA A #\$8	
00368 EA35 7E EA3E	JMP LOOP	

00370 * SUBROUTINE TO RESET ERROR FLAG

00372 EA38 RFLAG	EQU *	
00373 EA38 86 0A	LDA A #\$A	
00374 EA3A B7 EC02	STA A BKEBB	

00375 EA3D 39

RTS

00377

* SUBROUTINE TO ISSUE (A) CMD & LOOP ON BUSY

00379	EA3E	LOOP	EQU	*	
00380	EA3E F6 EC00		LDA B	DKDID	CLEAR BUSY
00381	EA41 B7 EC02		STA A	DKC0D	ISSUE CMD
00382	EA44 B6 EC01	LOOP1	LDA A	DKDIC	DONE?
00383	EA47 2A FB		BPL	LOOP1	NO
00384	EA49 F6 EC00		LDA B	DKDID	YES-CLR BUSY
00385	EA4C 39		RTS		EXIT

00387

* SUBROUTINE TO CHECK IF A DISK, ELSE ERROR 3

00389	EA4D	CHK	EQU	*	
00390	EA4D B6 EC00		LDA A	DKDID	
00391	EA50 84 20		AND A	#\$20	
00392	EA52 26 01		BNE	CHK2	
00393	EA54 39		RTS		OK
00394	EA55 86 03	CHK2	LDA A	#3	ERROR

00396

* ROUTINE TO PUT ERROR (A)

00398	EA57 8A 30	CHK1	ORA A	#\$30	CONVERT TO ASCII
00399	EA59 BD F018		JSR	CO	
00400	EA5C 7E F564		JMP	XBUG	

00402
00403* PHYSICAL SECTOR TABLE IS IN ORDER OF
* LOGICAL SECTOR NUMBER.

00405	EA5E	TBL	EQU	*-1	
00407	EA5F 01		FCB	\$1	
00408	EA60 0A		FCB	\$A	
00409	EA61 13		FCB	\$13	
00410	EA62 02		FCB	\$2	
00411	EA63 0B		FCB	\$B	
00412	EA64 14		FCB	\$14	

00413 EA65 03	FCB	\$3
00414 EA66 0C	FCB	\$C
00415 EA67 15	FCB	\$15
00416 EA68 04	FCB	\$4
00417 EA69 0D	FCB	\$D
00418 EA6A 16	FCB	\$16
00419 EA6B 05	FCB	\$5
00420 EA6C 0E	FCB	\$E
00421 EA6D 17	FCB	\$17
00422 EA6E 06	FCB	\$6
00423 EA6F 0F	FCB	\$F
00424 EA70 18	FCB	\$18
00425 EA71 07	FCB	\$7
00426 EA72 10	FCB	\$10
00427 EA73 19	FCB	\$19
00428 EA74 08	FCB	\$8
00429 EA75 11	FCB	\$11
00430 EA76 1A	FCB	\$1A
00431 EA77 09	FCB	\$9
00432 EA78 12	FCB	\$12

00434 EA79 8E FF8A PATCH	LDS	#XSTACK
00435 EA7C BD E841	JSR	FDOS1
00436 EA7F 7E 0023	JMP	UPDATE

00438	EB00		ORG	\$EB00	
00440	EC04	PTDTA	EQU	\$EC04	
00441	EC05	PTCTL	EQU	\$EC05	
00443	EB00	PTLDR	EQU	*	
00444	EB00 20 0E		BRA	LDR0	
00446	EB02	RDRIN	EQU	*	
00447	EB02 20 39		BRA	GETC	
00449	EB04	INITR	EQU	*	
00450	EB04 7F EC05		CLR	PTCTL	
00451	EB07 7F EC04		CLR	PTDTA	
00452	EB0A 86 3C		LDA A	#\$3C	
00453	EB0C B7 EC05		STA A	PTCTL	
00454	EB0F 39			RTS	
00456	EB10	LDR0	EQU	*	
00457	EB10 OF		SEI		
00458	EB11 BD EB04		JSR	INITR	
00459	EB14 8D 27	LDR1	BSR	GETC	GET A CHAR
00460	EB16 25 22		BCS	LDR5	NO TAPE
00461	EB18 81 53		CMP A	#\$53	S?
00462	EB1A 26 F8		BNE	LDR1	NO
00463	EB1C 7F FF92		CLR	TEMP+2	
00464	EB1F 8D 1C		BSR	GETC	GET A CHAR
00465	EB21 25 10		BCS	LDR3	NO TAPE
****ERROR	205				
00466	EB23 81 30	D	CMPA	#\$30	
00467	EB25 27 ED		BEQ	LDR1	HEADER BLOCK-SKIP
00468	EB27 81 31		CMP A	#\$31	
00469	EB29 27 5F		BEQ	LDR6	DATA BLOCK
00470	EB2B 81 39		CMP A	#\$39	
00471	EB2D 27 E5		BEQ	LDR1	EOF BLOCK-SKIP
00472	EB2F 81 1B		CMP A	#\$1B	ESC?
00473	EB31 27 07		BEQ	LDR5	YES-END OF OBJECT FILE
00474	EB33 86 3F	LDR3	LDA A	#\$3F	PRINT ?
00475	EB35 BD F018		JSR	CO	
00476	EB38 20 00		BRA	LDR5	
00478	EB3A 7E F564	LDR5	JMP	XBUG	

00480	EB3D	GETC	EQU	*	
00481	EB3D	B6 EC04	LDA A	PTDTA	CLR INTERRUPT
00482	EB40	86 34	LDA A	#\$34	STROBE RDR
00483	EB42	B7 EC05	STA A	PTCTL	
00484	EB45	86 3C	LDA A	#\$3C	
00485	EB47	B7 EC05	STA A	PTCTL	
00486	EB4A	FF FF94	STX	TEMP+4	
00487	EB4D	CE 0000	LDX	#0	SET TIME OUT
00488	EB50	B6 EC05	LDA A	PTCTL	DONE?
00489	EB53	2B 08	BMI	GETC2	YES
00490	EB55	09	DEX		NO-TIME OUT?
00491	EB56	26 F8	BNE	GETC1	NO
00492	EB58	FE FF94	LDX	TEMP+4	
00493	EB5B	0D	SEC		
00494	EB5C	39	RTS		
00495	EB5D	B6 EC04	LDA A	PTDTA	GET CHAR
00496	EB60	84 7F	AND A	#\$7F	STRIP PARITY
00497	EB62	FE FF94	LDX	TEMP+4	
00498	EB65	0C	CLC		CLR CARRY
00499	EB66	39	RTS		

00501	EB67	RDPR	EQU	*	MAKE A BYTE FROM 2 CHARS
00502	EB67	8D D4	BSR	GETC	GET A CHAR
00503	EB69	25 C8	BCS	LDR3	
00504	EB6B	8D 23	BSR	CVHEX	CONVERT TO HEX
00505	EB6D	25 C4	BCS	LDR3	
00506	EB6F	48	ASL A		
00507	EB70	48	ASL A		
00508	EB71	48	ASL A		
00509	EB72	48	ASL A		
00510	EB73	36	PSH A		
00511	EB74	8D C7	BSR	GETC	
00512	EB76	25 BB	BCS	LDR3	
00513	EB78	8D 16	BSR	CVHEX	
00514	EB7A	25 B7	BCS	LDR3	
00515	EB7C	33	PUL B		
00516	EB7D	1B	ABA		
00517	EB7E	16	TAB		
00518	EB7F	BB FF92	ADD A	TEMP+2	ADD TO CHKSM
00519	EB82	B7 FF92	STA A	TEMP+2	
00520	EB85	7A FF93	DEC	TEMP+3	
00521	EB88	17	TBA		
00522	EB89	39	RTS		

00524	EB8A	20 18	LDR6	BRA	DATA
00525	EB8C	20 A5	LDR7	BRA	LDR3
00526	EB8E	20 84	LDR8	BRA	LDR1

00528	EB90	80 30	CVHEX	SUB A	#\$30
00529	EB92	25 0F	BCS A		CVHEX2
00530	EB94	80 F6	ADD A		#\$F0

00531	E896	25	0B	BCS	CVHEX2
00532	E898	8B	06	ADD A	#6
00533	E89A	2A	04	BPL	CVHEX1
00534	E89C	8B	07	ADD A	#7
00535	E89E	25	03	BCS	CVHEX2
00536	E8A0	8B	0A	CVHEX1	ADD A #10
00537	E8A2	0C		CLC	
00538	E8A3	39		CVHEX2	RTS

00540	E8A4	DATA	EQU	*	
00541	E8A4	8D C1	BSR	RDPR	GET COUNT BYTE
00542	E8A6	4A	DEC A	DECR	COUNT
00543	E8A7	B7 FF93	STA A	TEMP+3	
00544	E8AA	8D BB	BSR	RDPR	READ ADDR(H)
00545	E8AC	B7 FF90	STA A	TEMP	
00546	E8AF	8D B6	BSR	RDPR	READ ADDR(L)
00547	E8B1	B7 FF91	STA A	TEMP+1	
00548	E8B4	FE FF90	LDX	TEMP	
00549	E8B7	7D FF93	DATA1	TST	TEMP+3
00550	E8B8	27 07	BEQ	DATA2	YES
00551	E8BC	8D A9	BSR	RDPR	NO-READ DATA
00552	E8BE	A7 00	STA A	X	SAVE IT
00553	E8C0	08	INX		INCR ADDRESS
00554	E8C1	20 F4	BRA	DATA1	
00555	E8C3	8D A2	DATA2	BSR	READ CHKSM
00556	E8C5	7C FF92	INC	TEMP+2	
00557	E8C8	26 C2	BNE	LDR7	CHKSM ERROR
00558	E8CA	20 C2	BRA	LDR8	CHKSM OK

00560	END
-------	-----

DKDID	EC00
DKDIC	EC01
DKCOD	EC02
DKCOC	EC03
DKDOD	EC06
DKDOC	EC07
XBUG	F564
CO	F018
TEMP	FF90
XSTACK	FF8A
EXEC	0020
UPDATE	0023
EDIT	0020
ASMB	0400
PASS	0000
DFILE	0001
OUNIT	0002
IUNIT	0003
ISIZE	0004
ITRK	0006
ISCTR	0007
ICNTR	0008
OSIZE	0009
ITRK	000B

00001

NAM' DIAG68

00003

*ICOM, INC. FD360-X-68 DIAGNOSTIC

00005

*PROCEDURE:

00006

* LOAD DIAGNOSTIC TAPE INTO RAM

00007

* START THE DIAGNOSTIC PROGRAM AT LOCATION 100 HEX

00008

* INSERT A SCRATCH DISKETTE INTO THE DRIVE UNIT

00009

* TO BE TESTED.

00010

* TYPE THE DESIRED COMMAND

00011

* CONTINUOUSLY OPERATING TESTS MUST BE MANUALLY

00012

* ABORTED (CARRIAGE RETURN STARTS THE TEST)

00014

*U = DRIVE UNIT NUMBER 0, 1, 2, OR 3.

00015

*T = TRACK 0 - 76 DECIMAL -

00016

*S = SECTOR 1 - 26 DECIMAL

00018

*COMMANDS:

00020

*A - CLEAR DRIVE ELECTRONICS

00021

*BU,T - SEEK TO TRACK

00022

*DU,S - READ (SECTOR) TO BUFFER FROM PRESENT TRACK

00023

*FU,S - WRITE (BUFFER) TO SECTOR ON PRESENT TRACK

00024

*GU,S - READ/WRITE TEST (CONTINUOUS) USING (BUFFER)

00025

*HU - TRACK 0 TO TRACK 76 LOOP (CONTINUOUS)

00026

*I - UNIT SELECT TEST

00027

*JU - SEEK TEST PERFORMED ONCE

00028

*KU - SEEK TEST PERFORMED CONTINUOUSLY

00029

*LU - SEEK TEST READ ONLY (CONTINUOUS)

00030

*MU - DD MARK TEST PERFORMED ONCE

00031

*N - RETURN TO EXBUG

00032

*OXX - FILL THE BUFFER WITH THE HEX VALUE XX

00033

*P - PRINT THE CONTENTS OF THE BUFFER

00035

*LIST OF ERROR MESSAGES:

00037

*XX - SELECTED DRIVE UNIT NOT READY

00038

*01 - CRC ERROR ON 5 READ ATTEMPTS -- 01(TRK)

00039

*02 - CRC ERROR ON 5 WRITE ATTEMPTS -- 02(TRK)

00040

*03 - READ/WRITE TEST DATA ERROR --

00041

*03(REC'D)(EXP'D)(BYTE#)

00042

*04 - UNIT SELECT ERROR -- 04(REC'D)(EXP'D)

00043

*05 - SEEK ERROR -- 05(REC'D)(EXP'D)(TRK)(SCTR)

00044

*06 - DD MARK ERROR -- 06(SCTR)

00045

*07 - DD MARK ERROR ON READ/WRITE TEST

00047

*THE BUFFER IS LOCATIONS 1000-107F HEX