

## Coolant fan

from July 2010



## Battery, Motronic engine control module power supply relay

- A Battery
- B Starter
- C Generator
- 271 Motronic engine control module power supply relay
- 317 Terminal 30 power supply relay
- A1 Fuse 1 (on fuse panel A)
- SA3 Fuse 3 (on fuse panel A)
- SB24 Fuse 24 (on fuse panel B)
- T40 40-pin connector
- 1 Ground strap, battery to body
- 12 Ground connection in engine compartment, left
- (507) Terminal 30 threaded connection (on battery fuse holder)
- (652) Transmission/engine ground connection
- (A99) Connection 87 (in instrument panel wiring harness) 1
- \* Depending on equipment



## Coolant fan control module, Coolant fan, Right coolant fan, Coolant fan 2

- J293 Coolant fan control module
- J623 Engine control module
- T2ah Double connector
- T4x 4-pin connector
- 94-pin connector
- T121 121-pin connector
- Coolant fan
- Right coolant fan
- V177 Coolant fan 2

= white = black

= red = brown green = blue = grey = lilac

= lilac = yellow

= pink

or

rs

= orange

- Electronic fan control ground connection
- Refer to applicable engine wiring diagram
- Depending on equipment
- Only for vehicles with two coolant fans