Asterix category 034 - Transmission of Monoradar Service Messages

category: 034 **edition**: 1.28 **date**: 2021-03-02

Preamble

Surveillance data exchange.

Description of standard data items

I034/000 - Message Type

Definition: This Data Item allows for a more convenient handling of the messages at the receiver side by further defining the type of transaction.

Structure:

- 8 bits [.....]
- values:
 - 1: North marker message
 - 2: Sector crossing message
 - 3: Geographical filtering message
 - 4: Jamming strobe message
 - 5: Solar Storm Message

Notes:

- 1. In applications where transactions of various types are exchanged, the Message Type Data Item facilitates the proper message handling at the receiver side.
- 2. All Message Type values are reserved for common standard use.
- 3. The list of items present for the four message types is defined in the following table.

M stands for mandatory, O for optional, X for never present.

TODO: message types table

I034/010 - Data Source Identifier

Definition: Identification of the radar station from which the data are received.

Structure:

I034/010/SAC - System Area Code

- 8 bits [.....]
- raw value

I034/010/SIC - System Identification Code

- 8 bits [.....]
- · raw value

Note:

• The up-to-date list of SACs is published on the EUROCONTROL Web Site (http://www.eurocontrol.int/asterix).

1034/020 - Sector Number

Definition: Eight most significant bits of the antenna azimuth defining a particular azimuth sector.

Structure:

• 8 bits [......] • unsigned quantity • scaling factor: 360 • fractional bits: 8 • unit: "°" • LSB = $360/2^8$ ° = 360/256 ° ≈ 1.40625 °

I034/030 - Time of Day

Definition: Absolute time stamping expressed as UTC time.

Structure:

• 24 bits [.....] • unsigned quantity • scaling factor: 1 • fractional bits: 7 • unit: "s" • LSB = $1/2^7$ s = 1/128 s $\approx 7.8125e - 3$ s

Notes:

• The time of day value is reset to zero each day at midnight.

I034/041 - Antenna Rotation Speed

Definition: Antenna rotation period as measured between two consecutive North crossings or as averaged during a period of time.

Structure:

• 16 bits [.....] • unsigned quantity • scaling factor: 1 • fractional bits: 7 • unit: "s" • LSB = $1/2^7$ s = 1/128 s $\approx 7.8125e - 3$ s

Notes:

• This item represents the antenna rotation period as measured by the radar station between two consecutive North crossings, or a calculated antenna rotation speed as averaged during a period of time, or during a number of antenna rotation scans.

I034/050 - System Configuration and Status

Definition: Information concerning the configuration and status of a System.

Structure:

Compound item (FX)

I034/050/COM - Common Part

1034/050/COM/NOGO - Operational Release Status of the System

- 1 bit [.]
- · values:
 - 0: System is released for operational use
 - 1: Operational use of System is inhibited, i.e. the data shall be discarded by an operational SDPS

I034/050/COM/RDPC - Radar Data Processor Chain Selection Status

- 1 bit [.]
- · values:
 - 0: RDPC-1 selected
 - 1: RDPC-2 selected

I034/050/COM/RDPR - Event to Signal a Reset/restart of the Selected Radar Data Processor Chain, I.e. Expect a New Assignment of Track Numbers

- 1 bit [.]
- values:
 - 0: Default situation
 - 1: Reset of RDPC

IO34/O50/COM/OVLRDP - Radar Data Processor Overload Indicator

- 1 bit [.]
- values:
 - 0: Default, no overload
 - 1: Overload in RDP

I034/050/COM/OVLXMT - Transmission Subsystem Overload Status

- 1 bit [.]
- · values:
 - 0: Default, no overload
 - 1: Overload in transmission subsystem

I034/050/COM/MSC - Monitoring System Connected Status

- 1 bit [.]
- values:
 - 0: Monitoring system connected
 - 1: Monitoring system disconnected

I034/050/COM/TSV - Time Source Validity

- 1 bit [.]
- values:
 - 0: Valid
 - 1: Invalid

I034/050/COM/(spare)

• 1 bit[.]

(empty subitem)

(empty subitem)

I034/050/PSR - Specific Status Information for a PSR Sensor

I034/050/PSR/ANT - Selected Antenna

- 1 bit [.]
- values:

- 0: Antenna 1
- 1: Antenna 2

IO34/O50/PSR/CHAB - Channel A/B Selection Status

- 2 bits [...]
- values:
 - 0: No channel selected
 - 1: Channel A only selected
 - 2: Channel B only selected
 - 3: Diversity mode; Channel A and B selected

I034/050/PSR/OVL - Overload Condition

- 1 bit [.]
- values:
 - 0: No overload
 - 1: Overload

I034/050/PSR/MSC - Monitoring System Connected Status

- 1 bit [.]
- · values:
 - 0: Monitoring system connected
 - 1: Monitoring system disconnected

I034/050/PSR/(spare)

• 3 bits [...]

I034/050/SSR - Specific Status Information for a SSR Sensor

I034/050/SSR/ANT - Selected Antenna

- 1 bit [.]
- values:
 - 0: Antenna 1
 - 1: Antenna 2

I034/050/SSR/CHAB - Channel A/B Selection Status

- 2 bits [...]
- values:
 - 0: No channel selected
 - 1: Channel A only selected
 - 2: Channel B only selected
 - 3: Invalid combination

I034/050/SSR/OVL - Overload Condition

- 1 bit [.]
- values:
 - 0: No overload
 - 1: Overload

I034/050/SSR/MSC - Monitoring System Connected Status:

- 1 bit [.]
- values:
 - 0: Monitoring system connected
 - 1: Monitoring system disconnected

I034/050/SSR/(spare)

• 3 bits [...]

I034/050/MDS - Specific Status Information for a Mode S Sensor

I034/050/MDS/ANT - Selected Antenna

- 1 bit [.]
- values:
 - 0: Antenna 1
 - 1: Antenna 2

I034/050/MDS/CHAB - Channel A/B Selection Status

- 2 bits [...]
- values:
 - 0: No channel selected
 - 1: Channel A only selected
 - 2: Channel B only selected
 - 3: Illegal combination

I034/050/MDS/OVLSUR - Overload Condition

- 1 bit [.]
- values:
 - 0: No overload
 - 1: Overload

I034/050/MDS/MSC - Monitoring System Connected Status:

- 1 bit [.]
- values:
 - 0: Monitoring system connected
 - 1: Monitoring system disconnected

I034/050/MDS/SCF - Channel A/B Selection Status for Surveillance Coordination Function

- 1 bit [.]
- values:
 - 0: Channel A in use
 - 1: Channel B in use

I034/050/MDS/DLF - Channel A/B Selection Status for Data Link Function

- 1 bit [.]
- values:
 - 0: Channel A in use
 - 1: Channel B in use

I034/050/MDS/OVLSCF - Overload in Surveillance Co-ordination Function

- 1 bit [.]
- values:
 - 0: No overload
 - 1: Overload

I034/050/MDS/OVLDLF - Overload in Data Link Function

- 1 bit [.]
- values:
 - 0: No overload
 - 1: Overload

I034/050/MDS/(spare)

• 7 bits [.....]

1034/060 - System Processing Mode

Definition: Status concerning the processing options, in use during the last antenna revolution, for the various Sensors, composing the System.

Structure:

Compound item (FX)

I034/060/COM - Common Part

I034/060/COM/(spare)

• 1 bit [.]

 ${\bf I034/060/COM/REDRDP}$ - Reduction Steps in Use for An Overload of the RDP

- 3 bits [...]
- values:
 - 0: No reduction active
 - 1: Reduction step 1 active
 - 2: Reduction step 2 active
 - 3: Reduction step 3 active
 - 4: Reduction step 4 active
 - 5: Reduction step 5 active
 - 6: Reduction step 6 active
 - 7: Reduction step 7 active

 ${\bf 1034/060/COM/REDXMT}$ - Reduction Steps in Use for An Overload of the Transmission Subsystem

- 3 bits [...]
- · values:
 - 0: No reduction active
 - 1: Reduction step 1 active
 - 2: Reduction step 2 active
 - 3: Reduction step 3 active
 - 4: Reduction step 4 active
 - 5: Reduction step 5 active
 - 6: Reduction step 6 active
 - 7: Reduction step 7 active

I034/060/COM/(spare)

• 1 bit [.]

(empty subitem)

(empty subitem)

I034/060/PSR - Specific Processing Mode Information for a PSR Sensor

IO34/O60/PSR/POL - Polarization in Use by PSR

- 1 bit [.]
- values:
 - 0: Linear polarization
 - 1: Circular polarization

I034/060/PSR/REDRAD - Reduction Steps in Use as Result of An Overload Within the PSR Subsystem

- 3 bits [...]
- · values:
 - 0: No reduction active
 - 1: Reduction step 1 active
 - 2: Reduction step 2 active
 - 3: Reduction step 3 active
 - 4: Reduction step 4 active
 - 5: Reduction step 5 active
 - 6: Reduction step 6 active
 - 7: Reduction step 7 active

I034/060/PSR/STC - Sensitivity Time Control Map in Use

- 2 bits [...]
- values:
 - 0: STC Map-1
 - 1: STC Map-2
 - 2: STC Map-3
 - 3: STC Map-4

I034/060/PSR/(spare)

• 2 bits [...]

1034/060/SSR - Specific Processing Mode Information for a SSR Sensor

I034/060/SSR/REDRAD - Reduction Steps in Use as Result of An Overload Within the SSR Subsystem

- 3 bits [...]
- values:
 - 0: No reduction active
 - 1: Reduction step 1 active
 - 2: Reduction step 2 active
 - 3: Reduction step 3 active
 - 4: Reduction step 4 active
 - 5: Reduction step 5 active
 - 6: Reduction step 6 active
 - 7: Reduction step 7 active

I034/060/SSR/(spare)

• 5 bits [.....]

1034/060/MDS - Specific Processing Mode Information for a Mode S Sensor

 ${f I034/060/MDS/REDRAD}$ - Reduction Steps in Use as Result of An Overload Within the Mode S Subsystem

- 3 bits [...]
- values:
 - 0: No reduction active
 - 1: Reduction step 1 active
 - 2: Reduction step 2 active
 - 3: Reduction step 3 active
 - 4: Reduction step 4 active
 - 5: Reduction step 5 active
 - 6: Reduction step 6 active
 - 7: Reduction step 7 active

I034/060/MDS/CLU - Cluster State

- 1 bit [.]
- values:
 - 0: Autonomous
 - 1: Not autonomous

I034/060/MDS/(spare)

• 4 bits [....]

Notes:

• Applicable to all defined secondary subfields. The actual mapping between the up to seven data reduction steps and their associated data reduction measures is not subject to standardisation.

I034/070 - Message Count Values

Definition: Message Count values, according the various types of messages, for the last completed antenna revolution, counted between two North crossings

Structure:

Repetitive item, repetition factor 8 bits.

I034/070/TYP - Type of Message Counter

- 5 bits [.....]
- values:
 - 0: No detection (number of misses)
 - 1: Single PSR target reports
 - 2: Single SSR target reports (Non-Mode S)
 - 3: SSR+PSR target reports (Non-Mode S)
 - 4: Single All-Call target reports (Mode S)
 - 5: Single Roll-Call target reports (Mode S)
 - 6: All-Call + PSR (Mode S) target reports
 - 7: Roll-Call + PSR (Mode S) target reports
 - 8: Filter for Weather data
 - 9: Filter for Jamming Strobe
 - 10: Filter for PSR data
 - 11: Filter for SSR/Mode S data
 - 12: Filter for SSR/Mode S+PSR data
 - 13: Filter for Enhanced Surveillance data
 - 14: Filter for PSR+Enhanced Surveillance
 - 15: Filter for PSR+Enhanced Surveillance + SSR/Mode S data not in Area of Prime Interest
 - 16: Filter for PSR+Enhanced Surveillance + all SSR/Mode S data
 - 17: Re-Interrogations (per sector)
 - 18: BDS Swap and wrong DF replies(per sector)
 - 19: Mode A/C FRUIT (per sector)
 - 20: Mode S FRUIT (per sector)

1034/070/COUNT - COUNTER

- 11 bits [.....]
- unsigned integer

I034/090 - Collimation Error

Definition: Averaged difference in range and in azimuth for the primary target position with respect to the SSR target position as calculated by the radar station.

Structure:

I034/090/RNG - Range Error

- 8 bits [.....]
- signed quantity
- scaling factor: 1
- fractional bits: 7
- unit: "NM"
- LSB = $1/2^7$ NM = 1/128 NM $\approx 7.8125e 3$ NM

I034/090/AZM - Azimuth Error

- 8 bits [.....]
- · signed quantity

- scaling factor: 360
- fractional bits: 14
- unit: "°"
- LSB = $360/2^{14}$ ° = 360/16384 ° $\approx 2.197265625e 2$ °

Notes:

• Negative values are coded in two's complement form.

1034/100 - Generic Polar Window

Definition: Geographical window defined in polar co-ordinates.

Structure:

I034/100/RHOST - Rho Start

- 16 bits [.....]
- unsigned quantity
- scaling factor: 1
- fractional bits: 8
- unit: "NM"
- LSB = $1/2^8$ NM = 1/256 NM $\approx 3.90625e 3$ NM
- value ≤ 256 NM

1034/100/RHOEND - Rho End

- 16 bits [.....]
- unsigned quantity
- scaling factor: 1
- fractional bits: 8
- unit: "NM"
- LSB = $1/2^8$ NM = 1/256 NM $\approx 3.90625e-3$ NM
- value ≤ 256 NM

I034/100/THETAST - Theta Start

- 16 bits [.....]
- unsigned quantity
- scaling factor: 360
- fractional bits: 16
- unit: "°"
- LSB = $360/2^{16}$ ° = 360/65536 ° $\approx 5.4931640625e 3$ °

IO34/100/THETAEND - Theta End

- 16 bits [.....]
- unsigned quantity
- scaling factor: 360
- fractional bits: 16
- unit: "°"
- LSB = $360/2^{16}$ ° = 360/65536 ° $\approx 5.4931640625e 3$ °

I034/110 - Data Filter

 ${\it Definition} \hbox{: } {\it Data Filter, which allows suppression of individual data types.}$

Structure:

• 8 bits [.....]

values:

- 0: Invalid value
- 1: Filter for Weather data
- 2: Filter for Jamming Strobe
- 3: Filter for PSR data
- 4: Filter for SSR/Mode S data
- 5: Filter for SSR/Mode S + PSR data
- 6: Enhanced Surveillance data
- 7: Filter for PSR+Enhanced Surveillance data
- 8: Filter for PSR+Enhanced Surveillance + SSR/Mode S data not in Area of Prime Interest
- 9: Filter for PSR+Enhanced Surveillance + all SSR/Mode S data

Notes:

- 1. This Data Item is often used in conjunction with I034/100 and represents a Data Filter for a specific geographical subarea. A Data Source may have zero, one or multiple data filters active at any time.
- 2. If I034/110 is not accompanied with I034/100, then the Data Filter is valid throughout the total area of coverage.

I034/120 - 3D-Position Of Data Source

Definition: 3D-Position of Data Source in WGS 84 Co-ordinates

Structure:

I034/120/HGT - Height of Data Source

- 16 bits [.....]
- unsigned quantity
- scaling factor: 1
- fractional bits: 0
- unit: "m"
- LSB = 1 m

I034/120/LAT - *Latitude*

- 24 bits [.....]
- signed quantity
- scaling factor: 180
- fractional bits: 23
- unit: "°"
- LSB = $180/2^{23}$ ° = 180/8388608 ° $\approx 2.1457672119140625e 5$ °
- value >=-90 °
- value <=90 °

I034/120/LON - Longitude

- 24 bits [......]
- · signed quantity
- scaling factor: 180
- fractional bits: 23
- unit: "°"
- LSB = $180/2^{23}$ ° = 180/8388608 ° $\approx 2.1457672119140625e 5$ °
- value >= -180 °
- value ≤ 180 °

I034/RE - Reserved Expansion Field

Definition: Expansion

Structure:

Explicit item (RE)

1034/SP - Special Purpose Field

Definition: Special Purpose Field

Structure:

Explicit item (SP)

User Application Profile for Category 034

- (1) I034/010 Data Source Identifier
- (2) I034/000 Message Type
- (3) I034/030 Time of Day
- (4) I034/020 Sector Number
- (5) I034/041 Antenna Rotation Speed
- (6) I034/050 System Configuration and Status
- (7) I034/060 System Processing Mode
- (FX) Field extension indicator
- (8) I034/070 Message Count Values
- (9) I034/100 Generic Polar Window
- (10) I034/110 Data Filter
- (11) I034/120 3D-Position Of Data Source
- (12) I034/090 Collimation Error
- (13) I034/RE Reserved Expansion Field
- (14) I034/SP Special Purpose Field
- (FX) Field extension indicator