MDG LEDCLOCK (MODEL 1)

QUICKSTART GUIDE v1.6 12-2024



INDEX Index _______2 1 2 3 Setup your clock 4 3.1 Connecting to the clock.......4 3.2 Setup your clock5 Using your clock ______6 4.1 4.2 4.3 5.1 5.2 5.2.1 5.2.2 5.2.3 5.2.4 5.2.5 5.2.6 5.3 5.4 5.5

2 INTRODUCTION

First of all thank you for buying this handmade clock which is designed and manufactured in a small workshop in the Netherlands.

I hope you have much fun using this clock!

HOW TO GET HELP

If you have any problems with this clock, please leave us a message at support@mdg-design.nl and we will try to help you out.

Latest information and software version can be found at degraafm76/mdg-ledclock (github.com)

A WORD OF CAUTION

The body of the clock is made on a 3D-printer with PLA plastic. PLA has a melting temperature of about 60C/140F. Please don't leave the clock in a car on a hot summer day, or put it next to a heat source. This may deform or permanently damage your clock.

3 SETUP YOUR CLOCK

Power up your clock by connecting a micro USB cable¹ to an USB 5V power source¹ with an output of <u>at</u> <u>least 1A</u>. Most phone and tablet USB chargers should work, there is no risk in damaging the clock if an USB charger is used with an output of less than 1A but the clock won't function correctly.

When the clock is powered on, minutes 0 to 29 will light up white and minute 30 red. This will take about 30 seconds. The red light means that there is no working Wi-Fi connection, and is expected when turning the clock on for the first time. Follow the steps in 3.1 to connect to and configure your clock.

Note: 5 seconds after the red light the clock starts running but of course not on time.

¹ Not included

3.1 CONNECTING TO THE CLOCK

When the clock cannot connect to a Wi-Fi network, or the clock is not configured, the clock will start a Wi-Fi network with the SSID 'MDG-Ledclock1'. Connect to this Wi-Fi network from your mobile phone or pc, no Wi-Fi key is needed in the latest version of the clock (the key for older versions can be found on the bottom of the clock) Note: do not select the option to auto connect to this network.



When you have a connection to the Wi-Fi network 'MDG-Ledclock1' open a browser on the device that has a connection with the Wi-Fi network 'MDG-Ledclock1' and go to the following URL: http://ledclock.local. When the URL http://ledclock.local doesn't work, you can try to connect to the URL: http://192.168.4.1

*There is a know issue where the website of the clock doesn't open in safari on the latest iPhone versions (cannot parse error). Please use another browser such as Google Chrome until this issue is fixed.

After a couple of seconds the page as shown in below picture should appear. Open the settings page and follow the instructions in chapter 3.2 tot setup your clock.




3.2 SETUP YOUR CLOCK

Press the <u>Scan Networks</u> button (1) and wait until a list of Wi-Fi networks appears. Select your Wi-Fi network and type your <u>Wi-Fi password</u>.

Select your time zone (2) scroll down and press the <u>Save & Reboot</u> button (3). You can leave the MQTT fields empty for now. Wait until you see the clock running with the correct time and continue to chapter 4

Note: It can take some time for the clock to show up after there is a Wi-Fi connection (a couple of white leds, and one green)



Optional settings*

Hostname

When needed (for example when you have multiple MDG-clocks) you can change the hostname of the clock. When changing the hostname, make sure to only use numbers and letters. Also take a note of the hostname because you need it to connect to the clock. When you change the hostname the URL becomes <a href="http://<yourhostname">http://<yourhostname>.local

MQTT

MQTT configuration is optional. If you know what an MQTT client is, see chapter 5 for configuration, otherwise leave all MQTT fields default.

4 USING YOUR CLOCK

This chapter describes how you can connect to the clock, how to create different clock displays and how to create schedules to change the clock display after you have setup the clock as described in chapter 3

4.1 CONNECTING TO THE CLOCK

Open a web browser and connect to http://ledclock.local, after some time the below interface should appear¹.

1: Make sure you are disconnected from the clock's Wi-fi network and are connected to you own Wi-Fi network. If you changed the hostname as shown in 3.2, please use this to connect to the clock for example http://yourhostname.local



When the above connection method doesn't work, lookup the clock's IP-address in your router or DHCP server. When you have found the IP-address of the clock, connect to it with the URL $\underline{\text{http://x.x.x.x}}$ where x.x.x.x is the IP-address of your clock.

4.2 CREATE DIFFERENT CLOCK DISPLAYS

You can create 8 different clock displays and store them in the clock. First select a <u>clock display</u> number, change the colors and settings like auto brightness the way you want them and press the save button.

Note: Out of the box all 8 position have the same default display colors (blue background, red hours marks and white hour, minute and second hand)



4.3 CHANGE DISPLAY SCHEDULES

It is possible to change the clock display at specific times. For example: you can have a bright colorful clock display during the day and a very dim display during the night.

To create a schedule open the *Schedules* tab and click on one of the schedules. Select the time (1) and display number (2) (one of the displays you created in 4.2) and make sure the active switch (3) is on. You can create a maximum of 12 schedules. If you like to disable a specific schedule at a later time set the active switch to off (3).




5 MQTT

When you have a home automation solution which can function as an MQTT broker for example Home Assistant or Homy u can optionally configure the clock as an MQTT client. This way you can control the clock with your home automation solution.

5.1 MQTT CONFIGURATION

Fill in your MQTT broker hostname or IP-address. Fill in your MQTT broker port in, default ports are 1883 (unencrypted) and 8883 (encrypted). If you have MQTT encryption configured on the broker you can enable encryption (TLS). Be aware that when TLS is enabled that the webserver will be disabled.

See chapter 5.5 for TLS notes



5.2 MQTT TOPICS

Commands over MQTT are issued to the ledclock by using the topics and JSON payloads described in this chapter. Replace [hostname] with the configured hostname this is by default: ledclock.

5.2.1 DISPLAY

Display Topics

State topic: [hostname]/display/state Command topic: [hostname]/ display /set

On/Off

```
JSON Payload:
{
  "state": "ON|OFF"
```

5.2.2 BACKGROUND

Background Topics

State topic: [hostname]/background/state Command topic: [hostname]/background/set

```
On/Off
```

```
JSON Payload:
 "state": "ON|OFF"
}
Brightness
JSON Payload:
{
"state": "ON",
"brightness": <1 to 100>
}
Color
JSON Payload:
  "state": "ON",
  "color": {
    "r": 0 to 255,
    "g": 0 to 255,
    "b": 0 to 255
}
Effects
  "state": "ON",
  "effect": "<effect>"
```

Effects: <rgb, rainbow, bpm>

5.2.3 HOURMARKS

Hourmarks topics

State topic: [hostname]/hourmarks/state Command topic: [hostname]/hourmarks/set

```
On/Off
JSON Payload:
"state": "ON|OFF"
}
Brightness
JSON Payload:
"state": "ON",
"brightness": 1 to 100
}
Color
JSON Payload:
  "state": "ON",
  "color": {
    "r": 0 to 255,
    "g": 0 to 255,
    "b": 0 to 255
  }
```

5.2.4 HOUR

Hour topics

State topic: [hostname]/hour/state Command topic: [hostname]/hour/set

```
On/Off
JSON Payload:
 "state": "ON|OFF"
Brightness
JSON Payload:
{
"state": "ON",
"brightness": 1 to 100
}
Color
JSON Payload:
  "state": "ON",
  "color": {
    "r": 0 to 255,
    "g": 0 to 255,
    "b": 0 to 255
```

5.2.5 MINUTE

```
Minute topics
On/Off
JSON Payload:
"state": "ON|OFF"
Brightness
JSON Payload:
"state": "ON",
"brightness": 1 to 100
}
Color
JSON Payload:
  "state": "ON",
  "color": {
   "r": 0 to 255,
    "g": 0 to 255,
   "b": 0 to 255
  }
```

5.2.6 SECOND

```
Second topic
[hostname]/second/state
[hostname]/second/set
On/Off
JSON Payload:
 "state": "ON|OFF"
Brightness
JSON Payload:
{
"state": "ON",
"brightness": 1 to 100
}
Color
JSON Payload:
  "state": "ON",
  "color": {
    "r": 0 to 255,
    "g": 0 to 255,
    "b": 0 to 255
```

5.2.7 LIGHT SENSOR

Light sensor topic

[hostname]/ledclock/sensor

Sensor

JSON Payload:

```
{
    "lux": 1 to 1000
}
```

5.3 GENERIC MQTT EXAMPLES

Turn background off:

```
Topic: [hostname]/background/set
JSON Payload:
{
 "state": "OFF"
Set background brightness to 50%:
Topic: [hostname]/background/set
JSON Payload:
"state": "ON",
"brightness": 50
}
Change color of hour marks to red:
Topic: [hostname]/hourmarks/set
JSON Payload:
  "state": "ON",
  "color": {
     "r": 255,
```

"g": 0, "b": 0

} }

5.4 HOME ASSISTANT MQTT EXAMPLE CONFIGURATION

name: 'Led clock' brightness: true brightness_scale: 100 effect: true effect_list: - auto_brightness - manual_brightness - schema: json command_topic: "ledclock/hour/set" state_topic: "ledclock/hour/state" name: 'Led clock - hour hand' brightness: true color_mode: true supported_color_modes: ["rgb"] brightness_scale: 100 - schema: json command_topic: "ledclock/minute/set" state_topic: "ledclock/minute/state" name: 'Led clock - minute hand' color_mode: true supported_color_modes: ["rgb"] brightness_scale: 100 - schema: json command_topic: "ledclock/second/set" state_topic: "ledclock/second/state" name: 'Led clock - second hand' brightness: true color_mode: true supported_color_modes: ["rgb"] brightness_scale: 100 - schema: json command_topic: "ledclock/background/set" state topic: "ledclock/background/state" name: 'Led clock - background' brightness: true color_mode: true supported_color_modes: ["rgb"] brightness_scale: 100 effect: true effect_list: - rgb - rainbow - bpm - schema: json command_topic: "ledclock/hourmarks/set" state_topic: "ledclock/hourmarks/state" name: 'Led clock - hourmarks' brightness: true

- schema: json

command_topic: "ledclock/display/set" state_topic: "ledclock/display/state"

color_mode: true supported_color_modes: ["rgb"] brightness_scale: 100

5.5 TLS INFORMATION

- At the moment it is not possible to upload fingerprints or certificates for server validation.
- In general, TLS 1.2, TLS 1.1, and TLS 1.0 are supported with RSA and Elliptic Curve keys and a very rich set of hashing and symmetric encryption codes.
- When TLS is activated the webserver is stopped however you can continue to configure the clock with a serial connection 115200 baud.