ESXi Pre-Installation IP Address PowerShell Script

January 2024

Abstract

VxRail PowerShell enables you to set ESXi management IP using PowerShell cmdlets.

ESXi Pre-Installation IP Address PowerShell Script

Copyright

The information in this publication is provided as is. Dell Inc. makes no representations or warranties of any kind with respect to the information in this publication, and specifically disclaims implied warranties of merchantability or fitness for a particular purpose.

Use, copying, and distribution of any software described in this publication requires an applicable software license.

Copyright © 2021 Dell Inc. or its subsidiaries. All Rights Reserved. Dell Technologies, Dell, EMC, Dell EMC and other trademarks are trademarks of Dell Inc. or its subsidiaries. Intel, the Intel logo, the Intel Inside logo and Xeon are trademarks of Intel Corporation in the U.S. and/or other countries. Other trademarks may be trademarks of their respective owners. Published in the USA 08/21.

Dell Inc. believes the information in this document is accurate as of its publication date. The information is subject to change without notice.

Contents

About VxRail network configuration PowerShell bundle	4
Set ESXi management network	
How to install the VxRail API modules	5
PowerShell cmdlets	6
Procedure	6
VxRail API network commands	7
Parameter description	
·	c

About VxRail network configuration PowerShell bundle

Set ESXi management network Starting with VxRail 7.0.300, you can configure ESXi management network, including IP address, netmask, gateway, and vLAN.

VxRail 7.0.300 introduces the ability to set ESXi management network using iDRAC. Starting with 7.0.300, VxM supports up to 2500 single nodes. Each node can be a standalone node and can be deployed in different edge locations. Before Day 1 deployment, you must configure ESXi network (IP/netmask/gateway/vLAN) on all nodes, then VxM can establish network connections with those nodes remotely and add them into the cluster.

Note: This feature requires iDRAC version 4.40.x.x or later.

Note: VxRail supports to set up IPv6 and dual-stack environment only from VxRail 8.0.210 and later version

How to install the VxRail API modules

Note: VxRail API modules require PowerShell version 5.0 or later.

Import the modules manually, using the standard PowerShell commands.

 Extract the module contents to the following directory: C:\Program Files\WindowsPowerShell\Modules.




Figure 1 Extracting the modules

2. To import the module, run the following command from PowerShell:

Import-module VxRail.API.Network

```
PS C:\Program Files\WindowsPowerShell\Modules> Import-Module VxRail.API.Network
PS C:\Program Files\WindowsPowerShell\Modules> Get-Module

ModuleType Version Name ExportedCommands

Manifest 3.1.0.0 Microsoft.PowerShell.Management {Add-Computer, Add-Content, Checkpoint-Computer, Clear-Content...} {Add-Member, Add-Type, Clear-Variable, Compare-Object....} {Add-Member, Add-Type, Clear-Variable, Compare-Object...} {Get-PSReadLineKeyHandler of Clear-Content...} {Add-Member, Add-Type, Clear-Variable, Compare-Object...} {Get-PSReadLineKeyHandler of Clear-VxRailManagerNetworkAddr, Get-HostNetworkSettingStatus, Get-VxRailManagerNetworkStatus, Set-HostNetwork...}

PS C:\Program Files\WindowsPowerShell\Wodules>
```

Figure 2 Importing the PowerShell cmdlet

3. To confirm that the module has imported successfully, run the following command:

```
Get-Module
```

Modules with name containing "VxRail.API.Network" should be listed as shown in Figure 2.

For PowerShell documentation, go to https://docs.microsoft.com/en-us/powershell/scripting/developer/module/installing-a-powershell-module?view=powershell-6

PowerShell cmdlets

Procedure

1. Configure the ESXi management network using the following command:

Set-HostNetwork.

2. Run the Get-HostNetworkSettingStatus command to get the configuration status. The status is initializing in the first, and you could repeat running Get-HostNetworkSettingStatus. After a few minutes, the network setting will be successful. You can then check the IP address using ESXi commands in the ESXi console, or verify it using the ping command.

```
PS C:\Windows\System32\WindowsPowerShell\v1.0> Get-HostNetworkSettingStatus -Server 20.13.92.36 -Username root -Password calvin Status code: 0, message: init
The network setting is initializing.

PS C:\Windows\System32\WindowsPowerShell\v1.0> Get-HostNetworkSettingStatus -Server 20.13.92.36 -Username root -Password calvin Status code: 200, message: ok
The network setting is successful
```

VxRail API network commands

The following API commands are new for the VxRail network.

Set ESXi network using iDRAC

For IPv4-only:

Set-HostNetwork [-Server] <String> [-Username] <String> [Password] <String> [-HostIP] <String> [-Netmask] <String> [Gateway] <String> [-Vlan] <UInt16> [-Proxy] <String>] [ProxyUsername] <String>] [-ProxyPassword] <String>
[<CommonParameters>]

For IPv6-only:

Set-HostNetwork [-Server] <String> [-Username] <String> [Password] <String> [-HostIPv6] <Int> [-PrefixLen] <String> [Gatewayv6] <String> [-Vlan] <UInt16> [-Proxy] <String>] [ProxyUsername] <String>] [-ProxyPassword] <String>
[<CommonParameters>]

For Dual-stack:

Set-HostNetwork [-Server] <String> [-Username] <String> [-Password] <String> [-HostIP] <String> [-Netmask] <String> [-Gateway] <String> [-HostIPv6] <Int> [-PrefixLen] <String> [-Gatewayv6] <String> [-Vlan] <UInt16> [-Proxy] <String> [-ProxyUsername] <String> [-ProxyPassword] <String> [<CommonParameters>]

Get ESXi network setting status

Get-HostNetworkSettingStatus [-Server] <String> [-Username]
<String> [-Password] <String> [-ProxyUsername]
<String> [-ProxyPassword] <String> [<CommonParameters>]

Parameter description

- -Server <iDRAC IP>: The iDRAC IP address of the target Node
- -**Username** < iDRAC username>: The username of iDRAC account
- -**Password** < iDRAC password>: The password of iDRAC account
- -**HostIP** < *IP*>: IPv4 address to be configured to the host
- -Netmask < network mask >: The network mask to be configured to the host
- -Gateway < gateway >: Gateway IPv4 to be configured to the host
- -**HostIPv6** < *IPv6*>: IPv6 address to be configured to the host
- -**PrefixLen** < network prefix length >: The network mask to be configured to the host
- -**Gatewayv6** < *IPv6 gateway*>: Gateway IPv6 to be configured to the host
- -**vLAN** < *vLAN ID*>: Optional. The vLAN to be configured to the host.

Note: The valid value is from 0 to 4095 (including 0 and 4095). Skip it or enter 0 if no vLAN is used.

- $\label{eq:proxy} $$ \textbf{Prox} \times Proxy $$ \ensuremath{\mathsf{Prox}} \times Prox $$ \ensuremath{\mathsf{Prox}} \times Prox$
- -**ProxyUsername** < *ProxyUsername* > Username of the proxy server. Optional
- -**ProxyPassword** < *ProxyPassword* > Password of the proxy server. Optional

Help info

Get-Help cmdlet

You can run the Get-Help cmdlet for help information. If you need further information, add the -examples, -detailed, or -full parameters to the Get-Help command.