

VC-B11U

HD Camera (USB Camera)

User Manual - English



[Important]

To download the latest version of Quick Start Guide, multilingual user manual, software, or driver, etc., please visit Lumens
<https://www.MyLumens.com/support>

Table of Contents

Copyright Information	2
Chapter 1 Safety Instructions.....	3
Chapter 2 Package Contents	4
Chapter 3 Function Introduction	5
3.1 Overview	5
3.2 System Requirements	5
Chapter 4 Instruction for installation.....	6
4.1 Instruction for installation	6
4.2 Connecting devices.....	7
Chapter 5 Remote Control Buttons Descriptions.....	8
Chapter 6 Descriptions of Major Functions	9
6.1 I would like to control the camera.....	9
6.2 I would like to use Skype for video conference	9
6.3 I would like to save the current screen position data.....	9
6.4 I would like to clear the saved position data.....	9
6.5 I would like to adjust the brightness of the image.....	9
6.6 I would like to adjust the direction of the screen shot.....	9
6.7 I would like to zoom in/out images	9
6.8 I would like to use the smart viewfinder.....	9
Chapter 7 Troubleshooting.....	10
Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information	11

Copyright Information

Copyrights © Lumens Digital Optics Inc. All rights reserved.

Lumens is a trademark that is currently being registered by Lumens Digital Optics Inc.

Copying, reproducing or transmitting this file is not allowed if a license is not provided by Lumens Digital Optics Inc. unless copying this file is for the purpose of backup after purchasing this product.

In order to keep improving the product, Lumens Digital Optics Inc. hereby reserves the right to make changes to product specifications without prior notice. The information in this file is subject to change without prior notice.

To fully explain or describe how this product should be used, this manual may refer to names of other products or companies without any intention of infringement.

Disclaimer of warranties: Lumens Digital Optics Inc. is neither responsible for any possible technological, editorial errors or omissions, nor responsible for any incidental or related damages arising from providing this file, using, or operating this product.

Chapter 1 Safety Instructions

Always follow these safety instructions when setting up and using the VC-B11U USB Camera:

1 Operation

- 1.1 Please use the product in the recommended operating environment, away from water or source of heat.
- 1.2 Do not place the product on a tilted or unstable trolley, stand or table.
- 1.3 Please clean the dust on the power plug prior to usage. Do not insert the product's power plug into a multiplug to prevent sparks or a fire.
- 1.4 Do not block the slots and openings in the case of the product. They provide ventilation and prevent the product from overheating.
- 1.5 Do not open or remove covers, otherwise it may expose you to dangerous voltages and other hazards. Refer all servicing to licensed service personnel.
- 1.6 Unplug the product from the wall outlet and refer servicing to licensed service personnel when the following situations happen:
 - If the power cords are damaged or frayed.
 - If liquid is spilled into the product or the product has been exposed to rain or water.

2 Installation

- 2.1 For security considerations, please make sure the standard hanging rack you bought is in line with UL or CE safety approbations and installed by technician personnel approved by agents.

3 Storage

- 3.1 Do not place the product where the cord can be stepped on as this may result in fraying or damage to the lead or the plug.
- 3.2 Unplug this product during thunderstorms or if it is not going to be used for an extended period.
- 3.3 Do not place this product or accessories on top of vibrating equipment or heated objects.

4 Cleaning

- 4.1 Disconnect all the cables prior to cleaning and wipe the surface with a dry cloth. Do not use alcohol or volatile solvents for cleaning.

5 Batteries (for products or accessories with batteries)

- 5.1 When replacing batteries, please only use similar or the same type of batteries.
- 5.2 When disposing of batteries or products, please adhere to the relevant instructions in your country or region for disposing of batteries or products.

■ Precautions

	This symbol indicates that this equipment may contain dangerous voltage which could cause electric shock. Do not remove the cover (or back). No user-serviceable parts inside. Refer servicing to licensed service personnel.		This symbol indicates that there are important operating and maintenance instructions in this User Manual with this unit.
--	---	--	---

■ FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notice :

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment..

■ IC Warning

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus," ICES-003 of Industry Canada.


Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe B prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques," NMB-003 édictée par l'Industrie.

■ KC Warning

This equipment is Industrial (Class B) electromagnetic wave suitability equipment and seller or user should take notice of it, and this equipment is to be used in the places except for home.

Chapter 2 Package Contents


VC-B11U




**Instruction for
installation**



Remote Control




**USB cable (USB 3.0
Type A to Type C)**



Chapter 3 Function Introduction

3.1 Overview



NO.	Item	Function Descriptions
1.	Lens Modules	8.5 megapixels, 4K wide-angle lens
2.	IR Sensor	Receive IR signal
3.	LED Indicator	The indicator is displayed in blue when outputting an image through the USB and off when the USB is not in use
4.	Microphone	Capture sound while filming
5.	USB 3.0 Type C Port	Connect to a computer for power supply and use for image transmission
6.	Tripod deck lock hole	1/4" lock hole for mounting the camera

3.2 System Requirements


- Windows System: Windows 7 or later
- Chrome System
- MAC System: Mac OS X 10.12 and above

Chapter 4 Instruction for installation

4.1 Instruction for installation

4.1.1 I would like to install the camera on top of the screen

- Place the VC-B11U camera on top of the screen, and securely install it to the screen by adjusting the mount.




4.1.2 Machine Size

- Length x Width x Height:
Base Mount not included: 30 mm x 210 mm x 35 mm (1.2" x 8.3" x 1.4")
Base Mount included: 47.4 mm x 210 mm x 73.6 mm (1.9" x 8.3" x 2.9")
- Weight: 0.5 kg (1.1 lbs)

Front View	A technical drawing of the camera unit from the front. It is a long, thin, horizontal device with rounded ends. In the center is a large lens. On either side of the lens are four small circular sensors. A dimension line on the left indicates a height of 30 mm.
Side View	A technical drawing of the camera unit from the side. It shows the camera unit mounted on a bracket. The bracket has a vertical support and a horizontal arm. Dimensions are indicated: 35 mm for the width of the camera unit, 47 mm for the height of the bracket, 84.1 mm for the depth of the bracket, and 88 mm for the height of the camera unit.
Bottom	A technical drawing of the camera unit from the bottom. It shows the camera unit mounted on a bracket. The bracket has a vertical support and a horizontal arm. A dimension line indicates a width of 210 mm.


4.2 Connecting devices

4.2.1 Video Conference --- Connecting to PC




- Connect one end of the USB to the camera and the other end to the computer. VC-B11U driver will be installed in the computer automatically.

4.2.2 Connect to the touchscreen TV/touchscreen display



- Download video conference software suited for the touchscreen TV from App Store for operation.

Chapter 5 Remote Control Buttons Descriptions



Item	Description
Numeric Keys 1-6	Load the position where the Preset is saved
Preset	Appoint an ID (1 ~ 6) to save the current position data
Reset	Appoint an ID (1 ~ 6) to delete the current position data
Zoom + / -	Increase or decrease the image size
Home	Short press: The screen returns to the widest angle Press and hold for 3 seconds: Restore to the Factory Reset
◀, ▶, ▲, ▼	Move the lens
Pan Right	Adjust the screen direction to the right
Pan Left	Adjust the screen direction to the left
Tilt Up	Adjust the screen direction up
Tilt Down	Adjust the screen direction down
BRT + / -	Adjust the brightness of the image
Auto Frame	Smart viewfinder

Chapter 6 Descriptions of Major Functions

6.1 I would like to control the camera

1. Use the remote control to control VC-B11U.
2. It can be controlled using **USB PTZ Camera Controller** software.

<Remark>Please download software from the Lumens website and USB PTZ Camera Controller Manual.

6.2 I would like to use Skype for video conference

Please refer to [Chapter 4 Instruction for installation](#) to complete connecting VC-B11U with the computer. Start Skype; select the contact; press  to begin the video conference.

If it doesn't work, please refer to the following steps to setup the camera:

1. Start **Skype** -> **[Setting]** -> **[Audio & Video]**.
2. Select **[Lumens VC-B11U Video Camera]**.
3. Select **[Lumens VC-B11U Audio]**.
4. After the setting is completed, the video conference is ready to begin.

6.3 I would like to save the current screen position data

Use the remote control; press **[Preset]** key and press **[ID]** within 3 seconds to store data of the current position.

<Remark> ID shall be a digit [1 ~ 6].

6.4 I would like to clear the saved position data

Use the remote control; press **[Reset]** key and press **[ID]** within 3 seconds to clear data of the designated position.

<Remark> ID shall be a digit [1 ~ 6].

6.5 I would like to adjust the brightness of the image

1. Use the remote control; press **[BRT +]** to increase the brightness.
2. Use the remote control; press **[BRT -]** to reduce the brightness.

6.6 I would like to adjust the direction of the screen shot

1. Press **[Tilt ▲]** or **[Tilt ▼]** on the remote control to adjust the angle upward or downward.
2. Press **[Pan ►]** or **[Pan ◀]** on the remote control to adjust the angle to the right or left.

6.7 I would like to zoom in/out images

1. Press **[Zoom +]** on the remote control to zoom in images.
2. Press **[Zoom -]** on the remote control to zoom out images.

6.8 I would like to use the smart viewfinder

Press **[Auto Frame]** on the remote control. The camera will automatically detect the locations of people, and automatically adjust the zoom to the most appropriate size to accommodate all the participants according to change of the conference venues and the number of people.

Chapter 7 Troubleshooting

This chapter describes problems you may encounter while using VC-B11U. If you have questions, please refer to related chapters and follow all the suggested solutions. If the problem still occurred, please contact your distributor or the service center.

No.	Problems	Solutions
1.	There is no image output from VC-B11U	1. Replace the USB cables and make sure they are not faulty. 2. Verify whether the computer or equipment has detected the VC-B11U camera and is connected correctly.
2.	VC-B11U cannot be operated by remote control	1. Please confirm that VC-B11U has been connected to the computer, and launch video software. 2. Please verify the VC-B11U LED indicator. When the signal from the remote control received by the device is normal, the LED indicator will flash.
3.	VC-B11U output resolution is low	The default output resolution of VC-B11U is 1920 x 1080. Please go to the connected video conference software setting and adjust the video conference output resolution. <Remark> Some video conference software do not have the option of adjusting the resolution, such as Skype
4.	Water ripples appear on the VC-B11U screen	Please use the built-in camera application in the Windows 10 system or other third party software (such as AMCap) to manually adapt the applicable flicker-free value. (The default is 50Hz in Japan)

Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

Manufacturer : Lumens Digital Optics Inc.

Product Name : VC-B11U

Model Number : USB Camera

Responsible Party – U.S. Contact Information

Supplier : Lumens Integration, Inc.

4116 Clipper Court, Fremont, CA 94538, United States

e-mail : support@mylumens.com

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.