


D.C. Hayes Associates, Inc.
MICROCOMPUTER PRODUCTS

MICROMODEM 100™

with the MICROCOPPLER™



**OWNER'S
MANUAL**

MICROMODEM 100 OWNERS MANUAL

Written by Dale A. Heatherington and Donald J. Hyde

Second edition Copyright November 1979, D.C. Hayes Associates, Inc.

CONTENTS

Section	Title	Page
1.0	Background Information	3
1.1	Bell 103 compatibility	3
1.2	What is a modem	3
1.3	Baud rates	5
1.4	Half/Full duplex	6
1.5	Ringing and dialing	9
2.0	Functional description	13
2.1	S-100 interface	13
2.2	Timer	13
2.3	Serial interface	14
2.4	Baud rate generator	14
2.5	Power supply	14
2.6	Modem	14
3.0	Microcoupler	16
3.1	Microcoupler interface	17
3.2	Microcoupler characteristics	18
4.0	Installation	19
4.1	Identifying the parts	19
4.11	Installing in computer	20
4.12	Connection to telephone network	21
4.13	Notifying the phone company	22
4.2	User options	25
4.3	Selecting an I/O port	25
4.4	Wait states	26
4.5	Baud rates	26
4.51	Baud rate calculation	26
4.52	Value of N for common baud rates	27
4.6	Carrier detect sensitivity	28
4.7	Interrupts	28
4.71	Phone ringing interrupt	29
4.72	50 MS time-up interrupt	29
4.73	Receive register full interrupt	29
4.74	Transmit register empty interrupt	29
4.75	Lost carrier interrupt	29

Printed in USA

Section	Title	Page
5.0	Programming	31
5.1	Programmable registers	31
5.2	Transmit data register	31
5.3	Receive data register	31
5.4	Status register	32
5.5	Control register 1	34
5.6	Control register 2	36
5.7	Control register 3	38
5.8	Register map	39
5.9	ASCII code chart	40
Appendix A	Terminal program	42
Appendix B	CP/M remote console	74
Appendix C	Schematic diagram	86

NOTE:

MICROMODEM 100 and MICROCOUPLER are trademarks of
D.C. Hayes Associates, Inc.

TELETYPE is a registered trademark of
Teletype Corporation.

BASIC is a registered trade mark of
the Trustees of Dartmouth College.

CP/M is a trademark of
Digital Research

1.0 BACKGROUND INFORMATION

The information in this chapter is not essential to using the Micromodem 100. But I believe that you will find it to be helpful and possibly even interesting. Data communications is a fairly complex topic, combining as it does aspects of several related technologies, each of which is a complex and interesting subject in itself.

Data communications is a very confusing subject for most people, including data processing professionals. The subject is inherently complex, and the terminologies are often misleading. This is partly because of the mix of data-processing, electronic, and telephone technologies. Frequently the same words mean different things in the different fields, and when words from the different fields are combined to describe concepts which combine the different fields, they often carry a built-in confusion factor.

I have chosen several of the most important and most confusing topics and have attempted to describe them in plain English. I hope that I have succeeded at least to some extent.

1.1 Compatibility With the Bell System 103 Modem

The Micromodem 100 is designed to be completely compatible with the communication frequencies and modulation techniques of the Bell System (Western Electric) model 103 low-speed modem. The Bell System 103 (and its various equivalents) is by far the most widely-used modem in North America. It is used by virtually all time-sharing systems and dial-up data access systems as their standard mode of access. This popularity is due partly to the relative simplicity of the 103's FSK modulation technique and the reasonable cost of the circuitry required to implement it and partly due to the fact that there are so many other 103-compatible modems already installed to talk to.

1.2 What IS a modem anyway?

Early in the history of computing (back in the dim distant days of the 1950's), when computers were still huge like dinosaurs and people were just beginning to discover their data processing power, it occurred to someone that you could do a lot of neat things if you had two computers with a wire between them, or a computer and a typewriter if they had a wire connecting them. When they started thinking about wires that ran across the country, they soon began to think about how nice it would be if they could use all the phone wires that were already there.

Unfortunately, as we all know, computers talk digital and telephones are designed to carry the human voice. And the Bell System has lots of smart people who've been working for years and years building black-magic widgets of all kinds that mash and tear up those voice signals in all sorts of inconceivable ways to get them into long-distance wires in the most efficient possible way.

They spent decades researching the human voice so that they knew exactly how much they could mash and distort it and still have it come out recognizable at the other end of the line. If you could send digital data on the phone, who knows what all those widgets might do to it before it got to the other end of the line.

The phone company was worried that digital signals might hurt their various widgets, or might interfere with normal voice signals, so they weren't very encouraging at first.

But the problem did get some study, and some experiments were carried out (mostly by the Bell System). It seems that one thing all the widgets are careful not to disturb is the frequencies of the tones making up a voice. They may distort the amplitude or the phase, but they are careful not to distort frequencies. So a device was built which encoded digital data consisting of ones and zeroes into a signal containing different frequencies for ones and zeroes. This was called a modulator. That was pretty easy. The hard part was building something to un-do the modulating, and turn the tones back into digital ones and zeroes. Suffice it to say that they did figure out a way. They called the un-doer a demodulator.

It turned out that the modulator and the demodulator worked pretty good (better than most people expected). So the phone people put one of each into a box, and started to sell it as data transmission service. Like most engineering types, they weren't at their best with words, so they just took pieces of the words for the parts and stuck them together to make a word for the box. MODulator + DEModulator = MODEM, thus the modem was born.

Well, a lot of things have happened since those distant days when dinosaurs first spoke to each other over the phone. A lot of research was done on modems. They got faster. And they got bigger and more expensive. In fact, the speed and price have tracked very closely, and there is a common rule of thumb that modems cost about a dollar a baud. But that didn't matter much because the computers they worked with were even bigger and more expensive.

Things happened even faster when the Supreme Court decided to allow competition in the modem business.

At first the phone company insisted that they had a legal monopoly in the modem business because modems were part of the telephone system and they had a legal monopoly to run the phones. Nobody argued. After all, it was pretty obvious that a modem had to be wired up to the phone line, and that certainly made it part of the phones didn't it? But what about the computer wired to the modem? Certainly it wasn't a telephone and the phone company couldn't claim a monopoly on making computers, too. Then along came the acoustic coupler, a modem that wasn't wired up to the phone line. It talked into the phone just like a human, making noises into the mouthpiece, and listening to the noises coming from the earpiece.

The phone company insisted that an acoustic coupler was also a violation of their protected monopoly. The Carterfone company, which built an acoustically-coupled device for use with two-way mobile radios, went to court

after the phone company put them out of business by telling their customers that the acoustic coupler was illegal and threatening to disconnect their telephones if they didn't stop using it.

The court eventually decided in favor of Carterfone (awarding them considerable damages, which helped them to get back in business), and ruled that acoustic couplers were legal. More recent decisions have broadened the rules for interconnect, giving the FCC the power to license devices for use on the telephone network in much the same way that they have long licensed radio transmitters, and limiting the phone company's protected monopoly to running the network which connects the phones together.

Today the dinosaurs, though still very much alive and very much still with us, are giving up center stage to the much smaller, more advanced microcomputers. Small, inexpensive computers need small inexpensive modems, so the old reliable 103-style modem is now even more popular than ever.

1.3 Baud Rates

The term baud often confuses people. And with good reason. It means different things depending on who is using the term, and when. In its narrowest technical definition, a baud is defined as being a measure of the rate at which signals are transmitted through a communications channel, with one baud corresponding to a rate of one signal element per second.

Well, that sounds pretty straightforward, but what's a signal element? With digital data it seems pretty reasonable that a signal element should be the same thing as a bit so that 300 baud would be the same thing as 300 bits per second. Right!? Well, sometimes.

Baud rate is concerned with the stuff (like tones) going down the communications channel (in this case a phone line), and NOT with the stuff (like ones and zeroes) we're turning it into at the other end. In a 103-style modem, each possible change from one frequency to the other is a signal element. Since that is how we code a single bit, one baud equals one bit per second. But the phone line has a very finite rate at which it can carry signal elements. The rate is related to the frequency range the line can accomodate and the modulation technique (as well as the error rate one is willing to tolerate). In general, 1200 baud is about the highest the phones will accomodate with any degree of reliability. So the fastest that a modem can be is 1200 baud (unless you're using some other kind of telephones).


Well where do 4800-baud modems come from then? Well, the answer is that they aren't 4800-baud modems at all. They are 4800 bit-per-second modems. They do it by very cleverly encoding 4 bits of digital data onto a single signal transition (corresponding to a single cycle of a 1200 Hz carrier tone). As you can imagine, it is quite a trick encoding them that way, and even more of one to get them back out at the other end. That's why they're so expensive -- it ain't easy.

But that's not the only confusing part. As data communications users, you

and I don't care how many funny little bauds go down the phone line. In fact we really don't care about the bits even. We are trying to get some bytes moved around, but we'll probably settle for moving ASCII characters.

So how fast can I send characters with a 300 bit-per-second modem? Usually about 30 characters per second, but it can vary. You see, in order to be able to pick the characters out at the receiving end, we have to put on some extra bits to tell where the character begins and ends, etc. So our 7-bit ASCII character is accompanied by one start bit, one stop bit, an optional parity bit for error-checking, and an optional extra stop bit (I don't quite know why, it just slows things down). Thus our ASCII character could get from 2 to 4 extra bits as travelling companions.

The most common usage is one each of start bits, stop bits, and parity bits. This works out nicely because that means 10 bits per character which makes the character rate at 300 baud simple to calculate as 30 characters per second.



Normally, there is no good reason to transmit any slower than you have to (you just get a bigger phone bill), except that it won't work if you send faster than whatever's at the other end can receive it. There are an awful lot of model 33 Teletypes still kicking around. They can send and receive only at 110 baud. Between all those TTY's and the machines built to talk to them, there are still a lot of 103-type modems connected to things that only run at 110 baud.

1.4 Half- and Full- Duplex

This is another very confusing aspect of data communications, and like baud rates is mostly confusing because the terms have been used so loosely and with so little regard for their original very narrow technical meaning.

A communications link which carries data from one point to another in only one direction is said to be a simplex link. Most of the devices (such as radio) which are used for communication are basically simplex devices. To get a two-way communication link, we have to use two simplex links, one going in each direction. This is called a duplex communications link. The telephone is a duplex communications link. The people at both ends of the phone can hear each other. They can even both talk at the same time (except on long-distance sometimes).


If we have a simplex link which can be turned around, then we can have two-way communications with only one communication path. This is called half-duplex, because it has the effect of a duplex link but with only half as much stuff. CB radio is half-duplex. When one person finishes talking, he has to say "over" or "10-4" or something so the person at the other end knows it's his turn to talk. If they both try to talk at the same time, neither one can hear anything.

To have a full-duplex radio channel, each person would have to have a separate transmitter and receiver, and both people's transmitters would have to run all the time. In order for the two transmitters not to interfere with each other, they would have to use different channels. So full-duplex takes two channels.

Full-duplex communications is easier to use than half-duplex (at least for people), because it is more like normal face-to-face communication. So, even though it takes more stuff to make it work, the phones are built to work full-duplex. The phone in your house has a clever transformer called a hybrid which allows the two signal paths going in opposite directions to share the same pair of wires to the central office. But once it gets to the office, there are more circuits that sort them out, and they are kept that way until they leave another central office on their way to someone's phone.

Long-distance phone circuits always occur in pairs -- one circuit going in each direction. On calls that are over a few hundred miles, there is a problem with a full-duplex link. It takes the signals a finite length of time to get from one end to the other. When they arrive, part of the signal goes back into the phone and is sent back where it came from. You get an echo. To fix that, there are gizmos called echo suppressors in the lines. An echo suppressor is a voice-controlled switch that makes the phone line really work half-duplex, but it seems to be full-duplex because the echo suppressors turn around in the space between two syllables.


Well, the 103-type modem was designed to be able to take advantage of all those full-duplex communication paths. The designers of the 103 divided the frequency band of the telephone into two narrower bands, and assigned one for sending in one direction and the other for sending in the other. This gave them two channels to work with (like using two CB channels). It worked. Data could go in both directions at the same time. It worked on long distance, and the modems weren't at all bothered by the echos, because the modems were designed to talk on one frequency and listen on the other. They didn't care about the echos because they couldn't hear them.



The only problem was those echo suppressors. They kind of messed things up. Fortunately, someone had already thought of that and put a special disable circuit into the echo suppressors, that made them turn off if they heard a tone in a certain band. One of the tones used by the 103 just happens to correspond to this signal. So as soon as an echo suppressor hears the carrier from a 103 modem, it turns itself off.

Not all modems are full-duplex. In fact, until recently the 103-type was the only full-duplex modem. Most of the faster modems are half-duplex. This makes them more complicated to use because then the computers at both ends have to say "over" or "10-4" or something and all that. That, of course means a lot of complicated programming.

One nice thing about a full-duplex modem is that you can echo the characters. Virtually all time-sharing and data access systems echo each character back as it is received, and the character is not displayed or printed on the terminal until it has been for a full round trip to the distant computer and back. This gives the person typing a clear indication whether what he typed was received correctly. What he sees is what the computer sees. If a character gets garbled in the phone line, it shows up garbled on his terminal. If it gets lost completely, then nothing shows up on his terminal at all. This technique has a very catchy name, echo-plex.



It is because of this practice that most terminals have a switch marked full- or half-duplex. If the terminal is connected to a half-duplex modem, echo-plex won't work because the computer can't send back the characters it receives. Some systems don't use echo-plex even when they can because it introduces a slight delay which some people find objectionable. In this case, the terminal must display the characters that it sends to the computer. This is all a full-/half-duplex switch does on any terminal. Often the same switch appears on modems (especially acoustic couplers) mostly because it's cheap and looks impressive.

1.5 Ringing and Dialing

Ringing and dialing are two aspects of what the telephone company calls signaling. Signaling is the process by which a connection is established on the switched (dial) telephone network. As is the case with many commonplace things, telephone signalling is much more complicated than it looks.

First let's consider what has to happen when you place a call. The dialog looks something like this:


YOU	PHONE COMPANY
I want to make a call.	OK. Who do you want to call?
My girlfriend.	OK. I'll let her know you want to talk.
	I'm sorry, she's talking to someone else.

Now, that's not such a complicated dialog, but there are a few difficult limitations. For one thing, as we all know, there is seldom a person at the phone company, but some kind of a machine.

Everything that we say to the phone company has to be simple and exact enough for a machine, and everything the phone company says to us has to be simple enough that a machine can make the sounds. Whatever we do, we have to do it with just the two wires that connect us to the central office. And most limiting of all, we have to do it all with technology that was available in 1894, because that's when the dial telephone was invented.

Let's start simple. How does the phone company find out that we've picked up the phone to make a call? Your telephone has a switch on which the receiver normally rests when not in use (the switch hook). When you lift the receiver, this switch establishes a connection between the two wires and allows current to flow from a battery at the central office. This current can be detected at the central office by a light bulb in series with the line, or by a relay.

fig 11




To tell you that it is listening, the central office machinery connects the line to a generator which produces an audible dial tone in your receiver.

To tell the machine who you want to talk to, you dial that person's telephone number. The dial in your phone has a switch that is in series with the switch hook. This switch momentarily breaks the connection between the two wires. When the connection breaks, it causes the relay at the central office to drop out momentarily.

The dial makes a series of these pulses very rapidly. The number of pulses corresponds to the digit you have dialed, from 1 to 10 pulses for the digits 1 to 0. At the central office these pulses are counted by Strowger relays and other more recent devices.

fig 12




Once you have dialed, a whole bunch of complicated machines that I won't attempt to describe find the pair of wires corresponding to the number you have dialed.

If the line is busy, its phone will be off hook and the relay connected to it will be closed. The machine will then connect your line to another generator which makes a busy signal.

If the line is not busy, then it will connect that line to yet another generator. This one puts out 115 volts AC at 20 Hertz. Your friend's telephone has a bell which is connected to the line via a capacitor. The capacitor prevents the DC current from the battery from flowing through the bell, but allows the AC ring signal to pass through, thus making a loud noise.

When your friend picks up his phone, his switch hook makes connection, drawing current from the battery and activating the relay connected to his line. This causes the ring generator to be disconnected and stops the ringing.



Over the years, many refinements and variations have been added, including tone dialing, in which tones are used instead of the current pulses I have described. Tone dialing may eventually replace pulse dialing, but now and for many years to come, all automatic telephone exchanges accept pulses even if they are designed for tone dialing. Many older exchanges are able to accept only pulse dialing, so for now, pulse dialing is the only universally usable technique.

Well, if you understand everything this far, you can consider yourself to be a minor expert on telephones and data communications. And as the owner of a Micromodem 100, you are now equipped to use that knowledge to advance the state of the art by discovering and developing new applications. Good luck.

2.0 FUNCTIONAL DESCRIPTION

The Micromodem 100 is an S-100 bus compatible device which combines the functions of a serial interface, modem, and automatic dialer on one card. Included with the Micromodem 100 is the Microcoupler. This FCC registered device couples the Micromodem 100 directly to the telephone line without the use of a phone company supplied data access arrangement (DAA). Operation of the Microcoupler is detailed in section 3.

The Micromodem 100 has three main functional blocks. They are the S-100 bus interface, serial interface, and modem. They function together to provide the user with a quality low speed data communication system capable of communicating with other Bell 103 style modems at baud rates from 30 to 300. Operation of the Micromodem 100 is controlled with software. Baud rate selection, dialing, answering calls, originate/answer mode, character formats, etc. are all set by writing data to the Micromodem 100 control registers. See section 5 for details on these registers.

2.1 S-100 INTERFACE

The Micromodem 100 uses the low 8 address lines to decode four I/O addresses from a possible 256. A2 through A7 are used to select the base address while A0 and A1 select 1 of 4 registers for input or output operations. PDBIN is anded with SINP and the output of the base address decoder to provide a read strobe. Data is gated onto the bus during this time. The data source is determined by address line A0. When A0 is low modem received data is read. When A0 is high data from the status register is gated onto the bus. PWR is anded with SOUT and the output of the base address decoder to provide a write strobe. A0 and A1 are used to determine which of the 4 registers will be written into.

READ ONLY REGISTERSWRITE ONLY REGISTERSA0 A1

0 0	receive data	transmit data
0 1	status	control reg. 1
1 0	not used	control reg. 2
1 1	not used	control reg. 3

2.2 TIMER

A 50 millisecond hardware timer is provided so that software timing loops can be eliminated. It consists of a 555 timer chip wired as a non-retriggerable one-shot. Any output to control register 3 will start the timer. Its status may be read in the status register as bit 5. This bit goes to zero when the timer is started and returns to a one after 50 MS have elapsed. This timer bit is also available at the interrupt option socket as a low true open collector signal. This interrupt signal can be enabled or disabled under software control by changing bit 5 in control register 1. A 1 enables timer interrupts while a 0 disables them.

2.3 SERIAL INTERFACE

Serial to parallel and parallel to serial conversion is done with the popular AY-5-1013A Universal Asynchronous Receiver Transmitter (UART). The transmit and receive data registers as well as the low 5 bits of control register 1 and the status register are physically located in the UART. This 40 pin chip handles the job of serial-parallel conversion, adding start and stop bits, and generating and checking parity. The serial baud rate is controlled by the baud rate generator.

2.4 BAUD RATE GENERATOR

The baud rate generator provides a square wave clock at 16 times the desired baud rate for the UART. The UART internally divides this clock by 16. The frequency is derived from a 4 MHZ crystal oscillator divided down by U9 and U10. The division ratio of U9 can be varied to provide any baud rate from 30 to 300 baud. 300 baud or a lower user defineable baud rate can be selected under software control by changing bit 0 in control register 2. See section 4.5 for details.

2.5 POWER SUPPLY

The power supply provides 3 regulated voltages for the digital and analog circuits. Two 12 volt zener diodes, CR2 and CR3 , supply +12 and -12 volts for the analog circuits. The 7805, a 3 terminal voltage regulator, supplies +5 volts for the digital logic. The Micromodem 100 pulls about 25 MA from the S-100 +16 and -16 volt busses and 250 MA from the 8 volt bus. The Microcoupler is powered from the 5 volt supply and draws about 55 MA.

2.6 MODEM

There are four main parts in the modem section. They are: modulator/demodulator, transmit filter, receive filter, and carrier detect circuit.

The modulator/demodulator is a MC14412 CMOS chip. Serial data from the UART is converted to frequency shift keyed (FSK) data by the modulator. It is a digitally synthesized sine wave. When in ORIGINATE mode a logic 1 from the UART produces a 1270 HZ tone and a logic 0 produces a 1070 HZ tone. When in ANSWER mode a 1 produces a 2225 HZ tone and a 0 produces a 2025 HZ tone.

The demodulator section of the MC14412 takes the received FSK square wave from the limiter and converts it to serial mark/space data for the UART. In ORIGINATE mode a 2225 HZ tone is converted to a logic 1 and a 2025 HZ tone is converted to a logic 0. In ANSWER mode a 1270 HZ tone is converted to a 1 and 1070 HZ is converted to a 0.

In self-test mode the demodulator frequencies are switched to match the modulator. With an external connection, data can be looped back from the transmitter to the receiver for testing purposes.

The transmit filter is a 20 pin hybrid module which contains a 6 pole active band pass filter. Its purpose is to clean up the noise, harmonics, and modulation sidebands present in the synthesized sine wave produced by the modulator before it is sent to the phone line. In ORIGINATE mode it passes frequencies from 950 to 1400 HZ. In ANSWER mode frequencies from 1900 to 2350 are passed.

The receive filter is a 40 pin hybrid module which contains a 10 pole active band pass filter. Analog signals from the phone line pass through the Microcoupler and are sent to this filter. The desired band of frequencies are amplified by about 20 DB (10 times) and the unwanted signals (noise and transmit carrier) are attenuated by 50 DB (300 times). The receive filter has 2 outputs, a limiter output and an analog output. The analog output is simply the input signal after being filtered and amplified. The limiter output is a 5 volt square wave with the same frequency as the input signal. It is sent to the demodulator where it is converted to serial mark/space data for the UART.

In ANSWER mode the receive filter passes frequencies from 1000 HZ to 1350 HZ. In ORIGINATE mode frequencies from 1950 to 2300 HZ are passed.

The purpose of the carrier detect circuit is to provide the program with a means of determining the presence or absence of a receive data carrier. This circuit is implemented with a quad OP-AMP, U1, and half of U2, a dual timer chip. In operation it "listens" to signals passed by the receive filter and sets the carrier detect bit in the status register and lights the LED if those signals are louder than -50 DBM. Noise pulses lasting less than 2 seconds will not activate this circuit because of the action of timer, U2. Only 2 seconds or more of steady tone will register as a valid carrier.

LOST CARRIER DISCONNECT

The lost carrier circuit uses the output of the carrier detect circuit and the on/off hook control to provide an indication that the carrier has been lost for 10 seconds. The main components in the circuit are flip-flop, U6, and timer, U2. The flip-flop "remembers" that a carrier has been present since going off-hook and enables the 10 second timer to start when the carrier is lost. If the carrier returns within 10 seconds the timer is reset, otherwise it times out and activates the lost carrier signal. This signal can be used to reset the CPU if the program crashes and can't poll the carrier detect status bit.

3.0 MICROCOUPLER

The Microcoupler is an FCC registered protective coupler. It's purpose is to protect the computer user and the telephone network from the harmful effects of high voltage spikes and excessive signal levels. It also insures that the telephone billing equipment will properly register and time the calls. The Microcoupler circuitry is proprietary and, due to FCC regulations, not user serviceable. For these reasons no schematic is provided. However, to aid the user in trouble shooting his system the following functional description is provided.

The Microcoupler uses only the middle two wires in the four conductor modular telephone cable. These are the red and green wires and are called tip and ring. During the idle condition the telephone system supplies about 50 volts DC between these wires. During ringing 90 volts AC at 20 HZ is superimposed on the 50 volts DC. When a call is in progress the tip to ring voltage will be somewhere between 2 and 16 volts DC at 15 to 120 MA. The DC resistance measured between tip and ring on the Microcoupler is 137 ohms when off-hook (in use) and infinity when on-hook (idle). This measurement is made with the phone line disconnected.

A reed relay controls the on-off hook states and accomplishes the dialing function by pulsing on and off at a 10 HZ rate. The 90 volt AC ringing signal is detected with an optoisolator. The ring detect circuit requires at least 50 volts AC at any frequency between 15 and 70 HZ for 1 second or more.

The Microcoupler has an automatic transmit level control that maintains a constant -10 DBM output into 600 ohms with input levels ranging from -7 to +10 DBM. Inputs below -7 DBM will be passed with a constant 3 DB loss. The automatic level control has no effect on received signals. All transmit signals are sent through a 3 KHZ low pass filter with a 12 DB per octave rolloff.

Signals received from the phone line are passed through a duplexer. The purpose of the duplexer is to separate the received signals from the transmitted signal. About 10 DB of transmitter rejection is achieved. The duplexer has an output impedance of 600 ohms on both the user and phone line sides. The receive gain is 0 DB when connected to a 600 ohm load or 6 DB when driving a high impedance load such as the Micromodem 100.

The interface between the Micromodem 100 and the Microcoupler is simple and straight-forward. All power, control, and audio signals are sent via a 10 conductor ribbon cable. Signals received from the phone line appear on pin 1. Signals to be transmitted to the phone line are applied to pin 3. Transmitted signals will also appear mixed with the received signals at pin 1 but they will be about 10 DB weaker because of the action of the duplexer. A TTL low level on pin 7 will cause the Microcoupler to go off-hook. Dialing is accomplished by pulsing this line at a 10 HZ rate. Pin 5 is the ring detector output. It is normally high and goes low during the telephone ringing periods. It will drive 1 LS-TTL load. A single 5 volt power source runs all the digital and analog

circuits. Pin 10 is +5 volts, pin 8 is ground. The Microcoupler has a timer which inhibits the transmit and receive audio for 2 seconds after going off-hook. This is for the benefit of the phone company billing equipment.

3.1 MICROCOUPLER INTERFACE CONNECTOR

<u>PIN</u>	<u>NAME</u>	<u>FUNCTION</u>
1	Receive data	Audio signals from the phone line appear on this pin. The output impedance is 600 ohms and the level depends on telco loss. -30 dbm typical.
2	not used	Key
3	Transmit data	Audio signals to be sent to the phone line are applied to this pin. It has a 47 K ohm input impedance. The maximum input level is +10 DBM. Minimum input level is -7 DBM for a -10 DBM level on the phone line.
4	not used	
5	Ring detect	Goes low during the telephone ringing signal. It will drive 1 LS-TTL load.
6	not used	
7	Off-hook	A TTL low level on this pin will cause the Microcoupler to go off-hook or answer an incoming call. Audio will be switched through on pins 1 and 3 2 seconds after this line is brought low. It presents 1 TTL load.
8	Ground	Logic and power supply ground
9	not used	
10	+5 volts	+5 volt power supply input. Current required is 55 MA.

3.2 MICROCOUPLER ELECTRICAL CHARACTERISTICS

FCC registration number	BI986H-62226-PC-E	
Ringer equivalence number	.4B	
On-hook impedance	DC	open circuit
	AC	25 K ohms at 20 HZ
off-hook impedance	DC	137 ohms
	AC	600 ohms
Maximum loop current	130 DC MA	
Maximum output level	-10 DBM into 600 ohms	
Frequency response	+/- 3 DB 300 to 3500 HZ	
Ring detector	frequency	15 to 70 HZ
	voltage	50 to 200 VAC
	resp. time	1 second
Power	5 volts DC at 55 MA	

INSTALLATION4.1 Identifying the Parts

Your Micromodem 100 is packed with several necessary items. You should take them out of the box and verify that they are all present and in good condition. They are:

- 1) Micromodem 100 printed circuit board.
- 2) Microcoupler for attachment to the telephone line.
- 3) Ribbon cable to connect Micromodem 100 to Microcoupler.
- 4) Modular telephone cable to connect Microcoupler to telephone line.

fig 1




© 1979 D.C. Hayes Associates, Inc.

4.11 Installing the Micromodem 100 in the Computer

!!!!!!
----- MAKE SURE THE COMPUTER IS TURNED OFF! -----
!!!!!!

The Micromodem 100 may be installed in any S-100 slot. Before inserting the board in the computer you should set up the various options that you may need for your application. See section 4.2 for details. Once you have set the options and plugged the Micromodem into your computer you can connect the ribbon cable between the Microcoupler and the Micromodem 100. This 10 conductor cable is terminated on each end with identical female connectors. Pin 2 is blocked with a plastic plug. The male plugs on the Micromodem 100 and Microcoupler have pin 2 cut off. This missing pin and plugged hole arrangement form a key which makes it difficult to plug in backwards.



Both ends of the ribbon cable are the same, and are interchangeable. Pick one end and plug it into the Micromodem 100 board. If you have any difficulty plugging it in, try turning it over -- it might be backward. When the connector is properly mated, all of the pins will fit easily into their corresponding holes, and the connector body will be flush with the printed circuit board.

Run the ribbon cable out through one of the cable slots in the back wall of the case. You may now replace the cover.

The other end of the ribbon cable connects to the Microcoupler. On one end of the Microcoupler you will see two connectors. In the center of the end wall is a rectangular hole about an inch long. Just peeking through this hole you will see another set of pins just like the ones on the Micromodem 100 board. They are also keyed in the same fashion.

Plug the remaining end of the ribbon cable into this connector. Again, if you have any difficulty, check that it is turned the right way.

You are now ready to connect your computer to the national telephone network.

4.12 CONNECTING TO THE TELEPHONE NETWORK

There are a few details that you need to take care of now before you can legally connect your computer to the telephones. Keep in mind that the Microcoupler is the only part which is FCC registered. The Micromodem 100 and the computer are of no concern to the FCC or the telephone company.

Legal and Technical Details

First you CANNOT legally connect your Microcoupler to either a party line or a pay phone.

Next you need a place to plug it in. If your home or office is already equipped with modular telephone jacks, then you may already have this. You can recognize a modular telephone jack by the small squarish hole (about 3/8") where the modular plug goes in. If you have jacks with four round holes about 3/4" inch apart, then you don't have modular jacks, but an older type of connector. Keep in mind that even if you do have what appears to be a modular jack, it may not be compatible with the Microcoupler. The Microcoupler requires a USOC-RJ11W or USOC-RJ11C modular jack.

4.13 Notifying the telephone company

Before you plug anything into the telephone line you must notify the telephone company. One reason this is necessary is that they normally test all their lines on a regular basis. To do this they need to know what's attached to each line, and how many ringers there are on the line. The test measures how much current is drawn on the line. If it draws too much or too little, then they will know that there is something broken or that someone has been tampering with the line. This is how they find illegal extension phones.

You must call the telephone company business office (their telephone number is probably printed on your phone bill) and tell them that you are preparing to install an FCC registered device and wish to notify them. They will need to know what line you are connecting it to (the phone number), the FCC registration number (BI986H-62226-PC-E), the ringer equivalence number (0.4B) and that it needs to be connected to a modular jack USOC-RJ11W or USOC-RJ11C. If you plan to move your computer around, you are allowed to give the phone company a list of phone numbers. Then you won't have to notify them again as long as you move it to one of the lines on your list.

If your phone company has any additional questions about the Microcoupler, ask them to call us in Atlanta.

You are also required to notify the phone company whenever you permanently remove the Microcoupler.


If you experience trouble with your telephone line, you must first disconnect the Microcoupler and make sure that it is not causing the problem. The phone company cannot be responsible for problems caused by your equipment connected to their lines.

In the unlikely event that your Microcoupler causes trouble with your telephone line, you must disconnect it and not use it until it has been repaired. In order to keep FCC approval in force (and thereby be legal), all repairs must be performed by D.C. Hayes Associates, Inc. or our authorized agents. We can repair any problem with your Microcoupler or your Micromodem 100 very promptly. Please see your warranty for full details.

One more legal technicality and you can plug it in. We are obliged to inform you that the telephone company has the right to change their equipment and is under no obligation to make sure that their new equipment is compatible with your Microcoupler. It is very likely that they will change their equipment, but it is extremely unlikely that those changes will render your Micromodem 100 or your Microcoupler unusable. The interface between the Microcoupler and the telephone line is functionally identical to the interface between a standard dial phone and the telephone line. Since the phone companies have millions of dial phones operating today, they are very unlikely to install any new equipment that will render them all obsolete. It would cost too much to replace all those telephones.


Plugging in to the Telephone Line

Pick up the modular telephone cable. You will see that there is a small plug on each end. The plug is molded of clear plastic and has 4 gold contacts on one side and a small plastic tab on the other. The plastic tab forms a latch which will hold the plug in the jack. Insert one of the plugs into the modular jack on the Microcoupler. It will only go in one way, and when you put it all the way in, it will make a small snap as the latch takes hold. Pull on the cord. It will not unplug unless you press on the plastic tab.



Now you can plug the other end of the modular cable into the telephone jack on the wall.

This completes the installation of your Micromodem 100.



4.2 USER OPTIONS

All Micromodem 100 boards are shipped from our factory with the following options installed.

PORt ADDRESS	=	80 Hex	see section 4.3
WAIT STATES	=	NONE	see section 4.4
INTERRUPTS	=	NONE	see section 4.7
AUTODISCONNECT	=	OFF	see section 4.75
CARRIER DET. LEVEL	=	-50 DBM	see section 4.6
BAUD RATES	=	300/110	see section 4.5

Most users will find these options well suited for their application. However, if you want to change any options please read the following text.

4.3 SELECTING AN I/O PORT ADDRESS

The Micromodem 100 occupies 4 consecutive I/O port addresses on the S-100 bus. The first address (base) is set by the first 6 switches in the 8 pole dip switch (S1) on the right side of the board. Switches 1-6 correspond to address bits A7-A2. The desired port address is selected by turning these switches on or off to match the address lines. An ON switch will match a zero and an OFF switch will match a one.

Examples:

Address bits	A7	A6	A5	A4	A3	A2
Switch #	1	2	3	4	5	6
port 80 Hex	off	on	on	on	on	on (standard)
port 00	on	on	on	on	on	on
port 04	on	on	on	on	on	off
port 0C	on	on	on	on	off	off

The Micromodem 100 is shipped set to port 80 Hex. This is the standard address used by all D.C. Hayes Associates, Inc. software. If this conflicts with another board in your system you will need to set the Micromodem 100 to an unused port address and change the port equates in the software.

4.4 WAIT STATES

The Micromodem 100 will work in most systems at full speed with no wait states. However, some 4 MHZ Z80 or 5 MHZ 8085 based systems may provide a PWR (processor write) pulse which is less than the 300 nanoseconds required by the Micromodem 100. If you install the Micromodem 100 in such a system you should install the wait state jumper. This will insert one CPU wait state during outputs and extend the PWR pulse by one clock period (250 NS at 4 MHZ). No wait states are required for input operations.

Installing a jumper between the pads marked "P3" will activate the wait state circuit.

4.5 BAUD RATES

The baud rate of the Micromodem 100 can be switched under software control between 300 baud and a lower user defined baud rate. Units are shipped with the low baud rate set to 110. Any baud rate from 30.6 to 300 may be selected with an error of less than 2% by installing from 1 to 8 diodes in the baud rate select area. If frequent baud rate changes are required we suggest that you put a 16 pin IC socket in the diode area and wire up several 16 pin headers with diodes for the baud rates you will need.

4.51 BAUD RATE CALCULATION

The 8 diode positions in the baud rate select area form an 8 bit binary number which sets the divide ratio on the baud rate counter. The presence of a diode equals a logic 1 while the absence of a diode equals a logic 0.

Baud rate formulas:

$$N = \text{Divider ratio} \quad B = \text{Baud rate}$$

$$N = 7812.5/B \quad \text{or} \quad B = 7812.5/N$$

110 baud example:

$$N = 7812.5/110 = 71.0227$$

rounded off N=71 decimal or 47 hex or 01000111 binary.


Since one diode is required for each binary 1, four diodes are needed. The actual baud rate obtained will be:

$$B = 7812.5/71 = 110.0352$$

This is only .032% high.

The diodes are installed as shown in the diagram below. They are 1N4148 or equivalent silicon switching diodes. Note that no baud rate greater than 300 may be selected.

BAUD RATE SELECT



4.52 VALUE OF N FOR COMMON BAUD RATES

<u>Baud rate</u>	<u>N decimal</u>	<u>N binary</u>
45.5	172	10101100
50	156	10011100
75	104	01101000
110	71	01000111
134.5	58	00111010
150	52	00110100
200	39	00100111

BIT TO DIODE LOCATION TABLE

<u>DIODE</u>	<u>BIT</u>	<u>BINARY WEIGHT</u>
CR7	0	1
CR8	1	2
CR9	2	4
CR10	3	8
CR11	4	16
CR12	5	32
CR13	6	64
CR14	7	128


4.6 CARRIER DETECT SENSITIVITY

The carrier detection circuits in the Micromodem 100 will respond to an incoming data carrier as weak as -50 DBM. In most cases this is desirable but sometimes a very noisy line can cause a false indication of carrier. If switch number 7 on dip-switch S1 is turned OFF the carrier detect sensitivity will be reduced to -40 DBM. Since the majority of all data signals are louder than -40 DBM this will have little effect on performance.

If you have problems detecting carrier on weak signals check this switch. Make sure it is in the -50 DBM position (ON).

4.7 INTERRUPTS

The Micromodem 100 provides 5 signals which can be used to generate interrupts. All 5 of these signals and all the S-100 bus interrupt lines are brought out to a 20 pin DIP connector (J1) as illustrated below. All signals are low true and open collector.



Processor reset is also on J1 at pin 20. You may connect the LOST CARRIER or PHONE RINGING signals to this pin if you want the computer to be reset and/or re-boot on one of these conditions. This feature is useful in unattended systems which must recover automatically after a crash.

The following describes the 5 interrupt signals in detail. All signals are active low open collector and may be jumpered to VI0-VI7 or PINT. All except LOST CARRIER are individually maskable. See section 5 on control registers for details.

4.71 PHONE RINGING (E)

This signal goes low for the duration of the 20 HZ telephone ringing signal. Since this signal returns high between rings the program can count them and answer after any number have occurred. It may also be connected to the processor reset line to cause the system to re-boot when the phone rings.

NOTE: This interrupt is enabled only when the Micromodem 100 is in ANSWER mode.

4.72 50 MS TIME-UP (D)

This signal goes low 50 milliseconds after the timer was started. It will remain low until the timer is re-started or the timer interrupt enable bit (D5) in control register 1 is cleared.

4.73 RECEIVE REGISTER FULL (B)

This signal goes low when a character has been received in the data register. It is cleared by reading the data register or by clearing the receive interrupt enable bit in control register 2. (RIE, bit 6)

4.74 TRANSMIT REGISTER EMPTY (C)

This signal goes low when the transmit holding register is empty and ready for another character. It is cleared by writing a byte to the data register or by clearing the transmit interrupt enable bit in control register 2. (TIE, bit 5)

4.75 LOST CARRIER and AUTO-DISCONNECT (A)

This signal goes low 10 seconds after the receive carrier is lost only if the modem is OFFHOOK. If the receive carrier is lost but returns within 10 seconds this circuit will NOT be activated and the 10 second timer will be reset to zero. Note that the time spent dialing and establishing a connection with no

carrier present does not activate this signal because it looks for the presence of a carrier before it arms itself to detect the loss of a carrier.

This signal is provided for emergency re-boot in case the remote user crashes the system then hangs up. It is most useful in single user systems when strapped to processor reset. In normal operation the program should poll the carrier detect bit in the status register and go on hook (hang up) as soon as carrier is lost. If the program can't do this because of a system crash the lost carrier signal will reset the CPU 10 seconds later.

If you only want to reset the Micromodem 100 and hang up without resetting the CPU, the jumper option P4 may be installed.

After connecting LOST CARRIER to an interrupt or reset line you must turn switch 8 on DIP switch S1 to the OFF position to enable this option. This switch is marked ADE (AUTO DISCONNECT ENABLE).

5.1 PROGRAMMABLE REGISTERS

The Micromodem 100 has two read-only registers and four write-only registers. The I/O port address of these registers is determined by switches 1 thru 6 on DIP switch S1. See section 4.3 for details on selecting a base address. The standard base I/O port address is 80 Hex.

<u>PORt</u>	<u>READ-ONLY REGISTERS</u>	<u>WRITE-ONLY REGISTERS</u>
base+0 (80)	receive data	transmit data
base+1 (81)	status	control reg. 1
base+2 (82)	not used	control reg. 2
base+3 (83)	not used	control req. 3

5.2 TRANSMIT DATA REGISTER

ADDRESS = base+0 (write only)

Data written into this register is converted to serial FSK data and transmitted over the phone line. When 5, 6, or 7 bit characters are used the remaining most significant bits in the byte are not transmitted and their value has no effect on the transmitted data. Data should be written into this register only when the TRANSMITTER REGISTER EMPTY (TRE) bit in the status register is a one (1). This bit should be tested before each output to the transmit data register.

The transmitter is double buffered. It actually has a holding register, which the program writes characters to, and a transmit register which does the parallel to serial conversion. When a character is written into the holding register the transmit register is automatically tested to see if it is empty. If it is found to be empty, the character in the holding register is loaded into transmit register and converted to serial data. When this happens the TRE bit in the status register is set to a 1 to indicate that the holding register is ready for another character. If the transmit register had been busy sending the previous character the TRE status bit would have remained low until the holding register could transfer its contents to the transmit register. All of this may seem complex but it is all handled automatically by the UART chip so the programmer doesn't have to worry about it.

5.3 RECEIVE DATA REGISTER

ADDRESS = base+0 (read-only)

This register will contain the received data from the phone line. It should be read only when the RECEIVE REGISTER FULL (RRF) bit in the status register is a one (1). Reading this register resets the RRF bit.

5.4 STATUS REGISTER

ADDRESS = base+1 (read-only)

bit	7	6	5	4	3	2	1	0
function	-RI	CD	TMR	OE	FE	PE	TRE	RRF

BIT 0 = RRF (RECEIVE REGISTER FULL)

RRF = 0 no data
 RRF = 1 data byte received in data register

This bit indicates that a character has been received in the DATA REGISTER. Reading the data register will reset this bit.

BIT 1 = TRE (TRANSMIT REGISTER EMPTY)

TRE = 0 transmitter busy
 TRE = 1 transmitter ready for next character

This bit indicates the status of the transmit register. When it is a one (1) the transmit register is ready to accept a character.

BIT 2 = PE (PARITY ERROR)

PE = 0 no parity error
 PE = 1 parity error on last character received

This bit, when set, indicates that a parity error was detected in the current character in the receive data register. This bit will remain set until an error free character is received. If the "no parity" mode is selected this bit will always be zero.

BIT 3 = FE (FRAMING ERROR)

FE = 0 no framing error
 FE = 1 framing error on last character received

This bit, when set, indicates that the UART receiver failed to detect a stop bit at the proper time and the contents of the receive register are probably invalid. This bit is reset when a character is properly received.

BIT 4 = OE (OVERRUN ERROR)

OE = 0 no overrun error
OE = 1 lost 1 or more characters

This bit, when set, indicates that the data register was not read before the next character was received. This can only be caused by software bugs.

BIT 5 = TMR (TIMER STATUS)

TMR = 0 50 MS period in progress
TMR = 1 50 MS or more have elapsed

This bit indicates the status of the 50 MS timer. It goes to zero when the timer is started and stays zero for 50 milliseconds.

BIT 6 = CD (CARRIER DETECT)

CD = 0 no data carrier present
CD = 1 data carrier present

This bit indicates the status of the received carrier. This bit should be checked frequently during communications to make sure a connection still exist. This bit affects the LOST CARRIER circuits. See section 4.75 for details of automatic disconnect on loss of carrier.

BIT 7 = RI (RING INDICATOR [low true])

RI = 0 the phone is ringing
RI = 1 the phone is NOT ringing

When this bit is zero the phone line is ringing. It goes to a one (1) between rings so they may be counted.

5.5 CONTROL REGISTER 1

ADDRESS = base+1 (write-only)

bit	7	6	5	4	3	2	1	0
function	X	X	TMIE	PI	SBS	LS2	LS1	EPE

BIT 0 = EPE (EVEN PARITY ENABLE)

EPE = 0 odd parity
 EPE = 1 even parity

This bit selects the type of parity to be generated or checked.

BIT 1 and BIT 2 = LS1 and LS2 (WORD LENGTH SELECT)

LS2	LS1	
0	0	5 data bits
0	1	6 data bits
1	0	7 data bits
1	1	8 data bits

These two bits set the length of the data word to be transmitted and received.

BIT 3 = SBS (STOP BITS SELECT)

SBS = 0 1 stop bit
 SBS = 1 2 stop bits for 6, 7, or 8 data bits
 1.5 stop bits for 5 data bits

This bit sets the number of stop bits to be transmitted and received.

BIT 4 = PI (PARITY INHIBIT)

PI = 0 parity is generated and checked
 PI = 1 no parity

This bit determines if parity is used during transmitting and receiving.
 Bit 0 sets the type of parity (even or odd).

BIT 5 = TMIE (TIMER INTERRUPTS ENABLE)

TMIE = 0 interrupts from 50 MS timer disabled
TMIE = 1 enable timer interrupts

When this bit is set to a 1 the timer will generate an interrupt when it times out if the jumper has been installed on J1. See section 4.7 for more information about interrupts.

BITS 6 AND 7 ARE NOT USED

5.6 CONTROL REGISTER 2

ADDRESS = base+2 (write only)

bit	7	6	5	4	3	2	1	0
function	OH	RIE	TIE	ST	BRK	MS/RID	TXE	BRS

BIT 0 = BRS (BAUD RATE SELECT)

BRS = 0 low baud rate (user selectable, 110 std.)
 BRS = 1 300 baud

This bit selects 1 of 2 baud rates for transmitting and receiving. See section 4.5 for information on user defined baud rates.

BIT 1 = TXE (TRANSMITTER ENABLE)

TXE = 0 modem transmit carrier OFF
 TXE = 1 modem transmit carrier ON

This bit turns the modem transmitter on and off. It should always be turned off prior to changing the originate/answer MODE select bit.

BIT 2 = MS/RID (MODE SELECT/RING INTERRUPT DISABLE)

MS/RID = 0 answer mode, ring interrupts enabled
 MS/RID = 1 originate mode, ring interrupts disabled

This is a dual purpose bit. Its primary function to switch the modem between the answer and originate modes. It also controls interrupts from the ring detector. It must be in ANSWER mode if interrupts from the ring detector are wanted. Of course the ring interrupt jumper on J1 must be installed. See section 4.5 for details. Also note that the ring indicator bit in status register is NOT affected by the state of this bit.

The TXE bit must be ZERO before changing the state of the MS/RID bit. The MC14412 modem chip will sometimes lock up in a strange mode if this is not done.

BIT 3 = BRK (BREAK)

BRK = 0 normal operation
BRK = 1 exchange mark and space frequencys
 this effectivly sends a break (constant space)

This bit is normally used to send a break signal (required by some time-sharing services). A BREAK is a steady SPACE tone for at least 3 character times. To send a break, the program should wait 1 character time after TRE goes true to allow the last character to be sent by the UART, then set the BREAK bit for 3 character times. This bit should then be reset to return to normal operation.

You can also detect reception of a BREAK. There is no bit in the status register that will give a direct indication but it can be done indirectly. A BREAK will always cause a FRAMING ERROR and the data register will be zero. The program can check for these conditions and assume a BREAK has been received.

BIT 4 = ST (SELF-TEST)

ST = 0 normal mode
ST = 1 self-test mode

When this bit is set to a 1 the modem receiver switches modes so that it "listens" to the transmitter. Data sent by the transmitter can then be received by the receiver for local testing. The Microcoupler should be disconnected when using the self-test mode.

BIT 5 = TIE (TRANSMIT INTERRUPTS ENABLE)

TIE = 0 transmit interrupts disabled
TIE = 1 transmit interrupts enabled

This bit controls interrupts from the transmitter. When it is a one an interrupt will be sent to the CPU each time the transmit data register is empty. The interrupt jumper at J1 must be installed. See section 4.7 for details.

BIT 6 = RIE (RECEIVE INTERRUPTS ENABLE)

RIE = 0 receiver interrupts disabled
RIE = 1 receiver interrupts enabled

This bit controls interrupts from the receiver. When it is a 1 an interrupt will be sent to the CPU each time a character is received in the data register. The jumper on J1 must be installed. See section 4.7 for details.

BIT 7 = OH (OFF-HOOK)

OH = 0 on-hook (idle)
OH = 1 off-hook (pick up phone)

This bit controls the telephone switch-hook in the Microcoupler. It is set to a one to answer incoming calls and with appropriate software can perform the dialing function.

5.7 CONTROL REGISTER 3

ADDRESS = base+3 (write-only)

This register is used to start the 50 MS timer. It has no data bits. Simply writing anything to this register will start the timer. When started, bit 5 in the status register will go to a zero for 50 MS. Timer can't be triggered again until the end of the 50 MS period.

American Standard Code for Information Interchange

CODE	HEX	DEC									
NUL	00	0	SP	20	32	@	40	64	`	60	96
SOH	01	1	!	21	33	A	41	65	a	61	97
STX	02	2	"	22	34	B	42	66	b	62	98
ETX	03	3	#	23	35	C	43	67	c	63	99
EOT	04	4	\$	24	36	D	44	68	d	64	100
ENQ	05	5	%	25	37	E	45	69	e	65	101
ACK	06	6	&	26	38	F	46	70	f	66	102
BEL	07	7	'	27	39	G	47	71	g	67	103
BS	08	8	(28	40	H	48	72	h	68	104
HT	09	9)	29	41	I	49	73	i	69	105
LF	0A	10	*	2A	42	J	4A	74	j	6A	106
VT	0B	11	+	2B	43	K	4B	75	k	6B	107
FF	0C	12	.	2C	44	L	4C	76	l	6C	108
CR	0D	13	-	2D	45	M	4D	77	m	6D	109
SO	0E	14	.	2E	46	N	4E	78	n	6E	110
SI	0F	15	/	2F	47	O	4F	79	o	6F	111
DLE	10	16	0	30	48	P	50	80	p	70	112
DC1	11	17	1	31	49	Q	51	81	q	71	113
DC2	12	18	2	32	50	R	52	82	r	72	114
DC3	13	19	3	33	51	S	53	83	s	73	115
DC4	14	20	4	34	52	T	54	84	t	74	116
NAK	15	21	5	35	53	U	55	85	u	75	117
SYN	16	22	6	36	54	V	56	86	v	76	118
ETB	17	23	7	37	55	W	57	87	w	77	119
CAN	18	24	8	38	56	X	58	88	x	78	120
EM	19	25	9	39	57	Y	59	89	y	79	121
SUB	1A	26	:	3A	58	Z	5A	90	z	7A	122
ESC	1B	27	;	3B	59	[5B	91	{	7B	123
FS	1C	28	<	3C	60	\	5C	92		7C	124
GS	1D	29	=	3D	61	^	5D	93	}	7D	125
RS	1E	30	>	3E	62	_	5E	94	-	7E	126
US	1F	31	?	3F	63	—	5F	95	DEL	7F	127

NUL Null, or all zeros
 SOH Start of Heading
 STX Start of Text
 ETX End of Text
 EOT End of Transmission
 ENQ Enquiry
 ACK Acknowledge
 BEL Bell, or Alarm
 BS Backspace
 HT Horizontal Tab
 LF Line Feed
 VT Vertical Tab
 FF Form Feed
 CR Carriage Return
 SO Shift Out
 SI Shift In
 DLE Data Link Escape

DC1 Device Control 1
 DC2 Device Control 2
 DC3 Device Control 3
 DC4 Device Control 4
 NAK Negative Acknowledge
 SYN Sync
 ETB End Transmission Block
 CAN Cancel
 EM End of Medium
 SUB Substitute
 ESC Escape
 FS File Separator
 GS Group Separator
 RS Record Separator
 US Unit Separator
 SP Space
 DEL Delete

INPUT REGISTERS

RECEIVER REGISTER
ADDRESS = BASE+0

7	6	5	4	3	2	1	0
DATA							

STATUS REGISTER
ADDRESS = BASE+1

7	6	5	4	3	2	1	0
-RI	CD	TMR	OE	FE	PE	TRE	RRF

RRF	RECEIVER REGISTER FULL	1= CHARACTER IN REG.
TRE	TRANSMITTER REG. EMPTY	1= REGISTER EMPTY
PE	PARITY ERROR	1= PARITY ERROR
FE	FRAMMING ERROR	1= FRAMMING ERROR
OE	OVERFLOW ERROR	1= OVERFLOW ERROR
TMR	TIMER	1= 50 MS TIME UP
CD	CARRIER DETECT	1= CARRIER DETECTED
-RI	NOT RING INDICATOR	0= PHONE RINGING

OUTPUT REGISTERS

TRANSMIT REGISTER
ADDRESS = BASE+0

7	6	5	4	3	2	1	0
DATA							

CONTROL REGISTER #1
ADDRESS = BASE+1

7	6	5	4	3	2	1	0
X	X	TMIE	PI	SBS	LS2	LS1	EPE

EPE EVEN PARITY ENABLE 1= EVEN PARITY

LS2 LS1 WORD LENGTH SELECT

0	0	= 5 BITS
0	1	= 6 BITS
1	0	= 7 BITS
1	1	= 8 BITS

SBS STOP BIT SELECT 0= 1 STOP BIT

PI PARITY INHIBIT 1= NO PARITY

TMIE TIMER INTERRUPT ENABLE 1= ENABLE INTERRUPT

CONTROL REGISTER #2
ADDRESS = BASE+2

7	6	5	4	3	2	1	0
OH	RIE	TIE	ST	BRK	MS/RID	TXE	BRS

BRS BAUD RATE SELECT 1= 300 BAUD 0= 110

TXE TRANSMITTER ENABLE 1= CARRIER ON

MS/RID * MODE SELECT/RING INTERRUPT DIS. 1= ORIGINATE 0= ANSWER

BRK BREAK 1= EXCHANGE MARK & SPACE

ST SELF TEST 1= SELF TEST MODE

TIE TRANSMIT INTERRUPTS ENABLE 1= ENABLE

RIE RECEIVE INTERRUPTS ENABLE 1= ENABLE

OH OFF HOOK 1= PICK UP PHONE

CONTROL REGISTER #3
ADDRESS = BASE+3

7	6	5	4	3	2	1	0
X	X	X	X	X	X	X	X

ANY OUTPUT TO CONTROL REGISTER #3 WILL START THE 50 MS TIMER.

* See section 5.6 for details on MS/RID.

TERMINAL PROGRAM

The terminal program is written in 8080 assembly language. It will run on any 8080, 8085, or Z80 machine that uses the CP/M disk operating system. It can be modified for other operating systems by changing those portions of the program which are CP/M dependent. This requires a good understanding of 8080 assembly language and the system it will be run with.

The terminal program is intended to be an example of programming techniques for the Micromodem 100 and not the "last word" in data communication programs. It is split into four sections; Terminal control, Disk I/O, Console I/O, and Modem I/O. You are invited to use the modem I/O section to build your own programs around. The console and disk I/O sections are CP/M dependent and should be changed if you intend to use it with a NON-CP/M system. The terminal control section decodes and executes all user commands. It can be expanded by adding more commands to the table "TABLE".

As is, the terminal program will allow its user to call time sharing computers and transfer data or programs to or from disk. It can communicate with a copy of itself in another S-100 machine to send data back and forth. Also, it has been used to transfer messages in and out of computerized bulletin board systems (CBBS).

LIST OF COMMANDS

Command	description
A	Wait for phone to ring, then answer call
AA	Answer call immediately
AO	Answer call immediately but in ORIGINATE mode
B1	Set baud rate to 110
B3	Set baud rate to 300
C0	Clear capture buffer, disable capture
C1	Start capturing received data in buffer
C2	Stop capturing (C1 will start again at this point)
D5551212	Dial phone number 555-1212, then wait for carrier
D	Redial last number dialed
F	Set for FULL DUPLEX (no local echo)

- G Goodbye, hang up phone
- H Set for HALF DUPLEX (local echo)
- J4F13 Jump to address, in this case 4F13. This is useful for getting out of the terminal program and into a monitor or debugger. The terminal program can be re-entered at HEX 100.
- L5 Set data word length to 5 bits
L6 6 bits
L7 7 bits
L8 8 bits
- PE Set for EVEN parity
PO ODD parity
PN NO parity
- R TEST.MSG Read CP/M file "TEST.MSG" from disk and transmit it.
- S1 Set STOP BITS = 1
S2 STOP BITS = 2
- T Type capture buffer to console
- T5A Type capture buffer to console starting at the HEX 5A'th character.
NOTE: S starts and stops the listing
Carriage return aborts this function.
- W TEST.MSG Write the contents of the capture buffer to disk in a file named "TEST.MSG".
- X Exit to CP/M (does warm boot)

?1 Debug mode ON. All incoming data will be displayed in HEX with 16 bytes per line.
Please note that your console device must be at least 4 times as fast as the modem baud rate

?0 Debug mode OFF.

Multiple commands may be typed on a line if they are separated by commas or spaces.

Example: COMMAND:L7,PE,S1,F,D3944220 <CR>

In this example the word length is set to 7 bits, even parity is selected, 1 stop bit, full duplex, then the phone number 394-4220 is dialed. The line is ended with a carriage return. Once the options are set they remain in force until changed.

Some telephone exchanges require you to dial a digit then wait for a second dial tone before dialing the remaining digits. This can be done by putting a "*" in the phone number where pauses are required. The dialing program will wait 2 seconds when it encounters the "*".

example: COMMAND: D 9*3944220 <CR>

When a call is in progress you can return to the command mode without interrupting the call by typing a control A. The program will prompt with "COMMAND:". You can then enter a line of commands and hit carriage return. The commands will be executed and the program will return to communication mode. The control A and the command line will NOT be transmitted to the line. Also, all data from the line will not be received during this time.

Some time sharing systems require a BREAK to stop print-out. Type control W to send a break.

If control A or W conflict with control characters you need to transmit you can change the program to accept any control codes you want. Just change the two CPI statements in the "CSEND" subroutine and re-assemble the program.

You can exit to CP/M during a call without hanging up. Type control A then the command "X". It will then ask "do you want to hang up first". Type N and CP/M will re-boot and the connection will still exist. If you don't load any other programs which overwrite the Terminal Program RAM area at 1000 HEX you can re-enter by loading and executing the Terminal Program .COM file as if it were a cold start. When the program starts running at 100 hex it will check for a receive carrier. If none is present it will go through the cold start initialization code. If it detects a carrier it will compute the checksum of the scratch pad ram area. If the ram has not been changed it will go directly to the communication loop and type "CONNECTION ESTABLISHED". If the ram has been altered it will print "REENTRY IMPOSSIBLE", reset the modem, and cold start.

This program is available on a CP/M format 8 inch single density floppy disk from D.C. Hayes Associates, Inc. for \$25.00. Georgia residents please add 4% sales tax.

TITLE 'MICROMODEM 100 TERMINAL PROGRAM'

; VER. 1.1 5-18-79

;WRITTEN BY DALE A. HEATHERINGTON

0100		ORG	100H	
0001 =	CPM	EQU	1	;SET FOR CPM ASSEMBLY
0005 =	B DOS	EQU	5	;CPM ENTRY
0000 =	REBOOT	EQU	0	;CPM WARM BOOT
000D =	CR	EQU	ODH	;CARRIAGE RETURN
000A =	LF	EQU	OAH	;LINE FEED
0007 =	BELL	EQU	7	;ASCII BELL

0100 317B10	START:	LXI	SP,STACK	
0103 CDC109		CALL	INIT	;SET UP CP/M I/O VECTORS
0106 11B301		LXI	D,PROMPT	;PUSH A RETURN ADDRESS ON STACK
0109 D5		PUSH	D	;IN CASE CARRIER IS PRESENT
010A CDFC09		CALL	CDSTAT	;SEE IF WE GOT CARRIER
010D B7		ORA	A	
010E CA4501		JZ	STR1	;NO, DO INITIALIZATION
0111 CDCD01		CALL	CKRAM	;GET CHECKSUM OF RAM AREA
0114 4F		MOV	C,A	
0115 3A3A10		LDA	CKSUM	;GET OLD CHECKSUM
0118 B9		CMP	C	;SAME?
0119 CA9604		JZ	TALK	;RAM OK, JUMP TO COMM LOOP
011C CDE402		CALL	PRINT	
011F 5245454E54		DB	'REENTRY NOT POSSIBLE, RAM OVERWRITTEN',CR	
0145 CDD609	STR1:	CALL	RESET	;ELSE CLEAR MODEM
0148 3A0700		LDA	7	;GET PAGE ADDRESS OF CP/M
014B D601		SUI	1	;1 PAGE BELOW IT
014D 323510		STA	MTOP	;TOP OF USER MEMORY
0150 CDDF02		CALL	CRLF	
0153 CDE402		CALL	PRINT	
0156 2020202020		DB	' D.C. Hayes Associates, Inc.',CR	
0178 CDE402		CALL	PRINT	
017B 4D6963726F		DB	'Micromodem 100 Terminal program ver. 1.1',CR	
01A5 AF		XRA	A	;A=0
01A6 321010		STA	NMBR	;SET PHONE NUMBER BUFFER EMPTY
01A9 21B901		LXI	H,DFAULT	;POINT TO COMMAND STRING
01AC 223010		SHLD	BUFPNT	;OF DEFAULT OPTIONS
01AF CDF501		CALL	DEC1	;EXECUTE THE COMMANDS
01B2 D1		POP	D	;CLEAN UP STACK
01B3 CDDB01	PROMPT:	CALL	CMND	;GET AND EXECUTE COMMANDS
01B6 C3B301		JMP	PROMPT	;LOOP FOREVER

;THIS IS A COMMAND LINE THAT SETS THE DEFAULT OPTIONS.
;8 DATA BITS, 1 STOP BIT, NO PARITY, 300 BAUD, FULL DUPLEX,
;CLEAR CAPTURE BUFFER. SET DEBUG MODE OFF.

01B9 4C382C5331DFault: DB 'L8,S1,PN,B3,F,C0,?0',CR

;DOES A CHECKSUM OF THE SCRATCH PAD RAM LOCATIONS

01CD 063A	CKRAM:	MVI	B,EOR-SOR	;END OF RAM MINUS START OF RAM = COUNT
01CF 210010		LXI	H,SOR	;START OF RAM POINTER
01D2 3E00		MVI	A,0	;A IS CHECKSUM
01D4 86	CKR1:	ADD	M	;ADD MEMORY BYTE
01D5 23		INX	H	;INC. POINTER
01D6 05		DCR	B	;COUNT 'EM
01D7 C2D401		JNZ	CKR1	;LOOP IF NOT DONE
01DA C9		RET		;CHECKSUM IN REG A

;THIS ROUTINE FILLS THE COMMAND BUFFER WITH
;A COMMAND STRING FROM THE CONSOLE THEN
;DECODES AND EXECUTES THEM.

01DB CDDF02	CMND:	CALL	CRLF	
01DE CDE402		CALL	PRINT	
01E1 434F4D4D41		DB	'COMMAND:@'	
01EA CD2F02		CALL	FILBUF	;GET COMMANDS TO BUFFER
01ED B7		ORA	A	;TEST FOR NO COMMANDS
01EE C8		RZ		;RETURN IF NONE IN BUFFER
01EF 217C10	DECODE:	LXI	H,BUF	;POINT TO COMMAND BUFFER
01F2 223010		SHLD	BUFPNT	;SAVE POINTER
01F5 CD8302	DEC1:	CALL	NEXT	;GET A COMMAND
01F8 FE0D		CPI	CR	;END OF LINE?
01FA C8		RZ		
01FB B7		ORA	A	;DELIMITER?
01FC CAF501		JZ	DEC1	
01FF 21BB07		LXI	H,TABLE	;POINT TO DECODE TABLE
0202 4F		MOV	C,A	;STORE COMMAND IN C
0203 7E	SRCH:	MOV	A,M	;GET BYTE FROM TABLE
0204 B9		CMP	C	;DOES IT MATCH?
0205 CA2502		JZ	FOUND	;YES, JUMP
0208 23		INX	H	;NO, ADVANCE POINTERS
0209 23		INX	H	
020A 23		INX	H	
020B B7		ORA	A	;TEST FOR END OF TABLE
020C C20302		JNZ	SRCH	
020F CDB709		CALL	CONOUT	;ECHO BAD COMMAND
0212 CDE402		CALL	PRINT	
0215 203D204241		DB	' = BAD COMMAND',CR	
0224 C9		RET		
0225 11F501	FOUND:	LXI	D,DEC1	;RETURN ADDRESS
0228 D5		PUSH	D	;PUT IT ON STACK
0229 23		INX	H	

#003 MICROMODEM 100 TERMINAL PROGRAM

022A 5E	MOV	E,M	;GET LOW BYTE OF COMMAND ADR.
022B 23	INX	H	
022C 56	MOV	D,M	;GET HIGH BYTE
022D EB	XCHG		;ADDRESS TO HL
022E E9	PCHL		;CALL ROUTINE

;THIS ROUTINE GETS CHARACTERS FROM THE CONSOLE
; AND PUTS THEM IN A BUFFER. RUBOUT WILL DELETE
; THE LAST CHARACTER TYPED. CONTROL U WILL KILL
; THE WHOLE LINE. THE BUFFER IS 64 CHARACTERS
; LONG.

022F 217C10	FILBUF:	LXI	H,BUF	
0232 0600		MVI	B,0	;CHARACTER COUNTER
0234 CDA109	FIL1:	CALL	CONIN	;GET ONE
0237 FE7F		CPI	7FH	;IS IT A RUBOUT?
0239 C24B02	FIL2:	JNZ	FIL3	;JUMP IF NOT
023C 78		MOV	A,B	
023D B7		ORA	A	;SEE IF BUFFER EMPTY
023E CA2F02		JZ	FILBUF	
0241 2B		DCX	H	
0242 05		DCR	B	;BACK UP EVERYTHING
0243 0E5F		MVI	C,5FH	;BACK ARROW CHARACTER
0245 CDB709		CALL	CONOUT	
0248 C33402		JMP	FIL1	
024B FE15	FIL3:	CPI	15H	;CONTROL U?
024D C25A02		JNZ	FIL4	
0250 0E23		MVI	C,'#'	
0252 CDB709		CALL	CONOUT	;ECHO #
0255 CDDF02		CALL	CRLF	
0258 AF		XRA	A	
0259 C9		RET		;RETURN A=0
025A FE0D	FIL4:	CPI	CR	;CARRIAGE RETURN
025C C26502		JNZ	FIL5	
025F 77		MOV	M,A	;PUT IT IN BUFFER
0260 78		MOV	A,B	;GET COUNT
0261 CDDF02		CALL	CRLF	
0264 C9		RET		
0265 CD7D02	FIL5:	CALL	UCASE	;CONVERT TO UPPER CASE
0268 77		MOV	M,A	;PUT IT IN MEMORY
0269 4F		MOV	C,A	
026A 3E40		MVI	A,64	;MAX. LENGTH OF BUFFER
026C B8		CMP	B	
026D C27502		JNZ	FIL6	;JUMP IF NOT FULL
0270 0E23		MVI	C,'#'	
0272 C37702		JMP	FIL7	
0275 23	FIL6:	INX	H	
0276 04		INR	B	;ADVANCE POINTER AND COUNTER
0277 CDB709	FIL7:	CALL	CONOUT	;ECHO CHARACTER
027A C33402		JMP	FIL1	

;LOWER TO UPPER CASE CONVERSION ROUTINE.

027D FE60	UCASE:	CPI	60H	
027F D8		RC		;RETURN IF ALREADY UPPER CASE
0280 D620		SUI	20H	;ELSE CONVERT TO UPPER
0282 C9		RET		

;THIS ROUTINE GETS THE NEXT CHARACTER FROM THE BUFFER.
;IT RETURNS A=0 IF A COMMA OR SPACE IS ENCOUNTERED.

0283 2A3010	NEXT:	LHLD	BUFPNT	;GET ADDRESS OF BUFFER
0286 7E		MOV	A,M	;GET A BYTE
0287 23		INX	H	
0288 223010		SHLD	BUFPNT	;INCREMENT AND SAVE POINTER
028B FE20		CPI	20H	;SPACE?
028D CA9D02		JZ	DELM	
0290 FE2C		CPI	','	;COMMA?
0292 CA9D02		JZ	DELM	
0295 FE0D		CPI	CR	;CARRIAGE RETURN?
0297 C0		RNZ		;RETURN IF NOT
0298 2B		DCX	H	
0299 223010		SHLD	BUFPNT	
029C C9		RET		
029D AF	DELM:	XRA	A	
029E C9		RET		

;THIS ROUTINE ADVANCES THE BUFFER POINTER TO THE
;NEXT COMMAND OR DIGIT STRING.
;IF NO MORE CHARACTERS WERE FOUND IT WILL RETURN
;WITH A=0. OTHERWISE A=1

029F CD8302	NXTCHR:	CALL	NEXT	
02A2 0E00		MVI	C,0	
02A4 FE0D		CPI	CR	;TEST FOR END OF BUFFER
02A6 CAB502		JZ	NXT1	
02A9 B7		ORA	A	;TEST FOR DELIMITER
02AA CA9F02		JZ	NXTCHR	;JUMP IF SPACE OR COMMA
02AD 0C		INR	C	;C = 1
02AE 2A3010		LHLD	BUFPNT	;GET BUFFER POINTER
02B1 2B		DCX	H	;BACK UP ONE
02B2 223010		SHLD	BUFPNT	;STORE IT
02B5 79	NXT1:	MOV	A,C	;A=0 NONE FOUND
02B6 C9		RET		;A=1 CHARACTER FOUND

;GET A HEX DIGIT STRING FROM BUFFER AND
;CONVERT IT TO A 16 BIT BINARY NUMBER IN DE.

02B7 210000	GETHEX:	LXI	H,0	
02BA EB	GH1:	XCHG		;NUMBER TO DE

02BB CD8302		CALL	NEXT	;GET A DIGIT
02BE FE30		CPI	'0'	;SEE IF IT'S HEX
02C0 D8		RC		;RETURN ON FIRST NON HEX CHAR.
02C1 FE47		CPI	'G'	
02C3 D0		RNC		
02C4 FE41		CPI	'A'	
02C6 D2CC02		JNC	GH2	
02C9 FE3A		CPI	::	
02CB D0		RNC		
02CC D630	GH2:	SUI	30H	;REMOVE ASCII BIAS
02CE FE0A		CPI	10	
02D0 DAD502		JC	GH3	;JUMP IF DIGIT 0-9
02D3 D607		SUI	7	;ELSE REMOVE A-F BIAS
02D5 EB	GH3:	XCHG		;NUMBER TO HL
02D6 29		DAD	H	;SHIFT LEFT 4 BITS
02D7 29		DAD	H	
02D8 29		DAD	H	
02D9 29		DAD	H	
02DA 85		ADD	L	;ADD IN THIS DIGIT
02DB 6F		MOV	L,A	
02DC C3BA02		JMP	GH1	

;SEND CARRIAGE RETURN-LINE FEED TO CONSOLE

02DF CDE402	CRLF:	CALL	PRINT	
02E2 0D		DB	CR	
02E3 C9		RET		

;PRINTS A STRING POINTED TO BY CONTENTS OF TOP
; OF STACK. CARRIAGE RET. OR "@" TERMINATES THE STRING.
; "@" WILL PRINT STRING WITH NO CR-LF SEQUENCE AT END.

02E4 E3	PRINT:	XTHL		;TOP OF STACK TO HL
02E5 F5		PUSH	PSW	;SAVE REGISTERS
02E6 C5		PUSH	B	
02E7 7E	PRN1:	MOV	A,M	;GET A CHARACTER
02E8 23		INX	H	
02E9 FE40		CPI	'@'	;END?
02EB CAFF02		JZ	PRN2	;JUMP IF END, NO CRLF
02EE 4F		MOV	C,A	
02EF CDB709		CALL	CONOUT	;PRINT THE CHAR.
02F2 FE0D		CPI	CR	;WAS IT A CARRIAGE RET.?
02F4 C2E702		JNZ	PRN1	;NO, GO BACK FOR MORE
02F7 CDE402		CALL	PRINT	;CALL OURSELF
02FA 0A00000040		DB	LF,0,0,0,'@'	;LINE FEED AND 3 NULLS
02FF C1	PRN2:	POP	B	;RESTORE REGISTERS
0300 F1		POP	PSW	
0301 E3		XTHL		;RETURN ADDRESS TO STACK
0302 C9		RET		

; RETURNS TO USERS OPERATING SYSTEM

0303 CDDF02	QUIT:	CALL	CRLF	
0306 CD330A		CALL	SHSTAT	;GET SWITCH-HOOK STATUS
0309 B7		ORA	A	
030A CA0000		JZ	REBOOT	
030D CDE402		CALL	PRINT	
0310 444F20594F		DB	'DO YOU WANT TO HANG UP FIRST? (Y OR N)@'	
0337 CDA109		CALL	CONIN	
033A CD7D02		CALL	UCASE	
033D 4F		MOV	C,A	
033E CDB709		CALL	CONOUT	
0341 79		MOV	A,C	
0342 FE4E		CPI	'N'	
0344 C25003		JNZ	QUIT1	
0347 CDCD01		CALL	CKRAM	;GET CURRENT RAM CHECKSUM
034A 323A10		STA	CKSUM	;SAVE IT
034D C30000		JMP	REBOOT	;BACK TO CPM
0350 CD7505	QUIT1:	CALL	HANGUP	
0353 C30000		JMP	REBOOT	

;THIS ROUTINE DIALS A PHONE NUMBER THEN JUMPS TO
;THE COMMUNICATION ROUTINE.
;IF NO PHONE NUMBER FOLLOWS THE "D" COMMAND THE
;LAST NUMBER DIALED WILL BE RE-DIALED.

0356 CDE402	DIAL:	CALL	PRINT	
0359 4449414C49		DB	'DIALING-@'	
0362 CDC40A		CALL	DLTONE	;GET A DIAL TONE
0365 CD9F02		CALL	NXTCHR	;FIND PHONE NO. IN BUFFER
0368 B7		ORA	A	
0369 CA7F03		JZ	DLL	;PHONE NUMBER NOT PRESENT
036C 110F10		LXI	D,NMBR-1	;POINT TO PHONE NO. BUFFER
036F CD8302	DL0:	CALL	NEXT	;GET A DIGIT
0372 13		INX	D	;ADVANCE POINTER
0373 12		STAX	D	;PUT IT IN BUFFER
0374 B7		ORA	A	
0375 CA7F03		JZ	DLL	
0378 FE0D		CPI	CR	
037A C26F03		JNZ	DL0	;IF NOT END, LOOP BACK
037D AF		XRA	A	;A=0
037E 12		STAX	D	;ZERO MARKS END OF NUMBER
037F 211010	DL1:	LXI	H,NMBR	;POINT TO NUMBER BUFFER
0382 7E	DL2:	MOV	A,M	;GET A DIGIT
0383 23		INX	H	;ADVANCE POINTER
0384 B7		ORA	A	;TEST FOR END
0385 CA1F04		JZ	COMM	;GO TRY TO COMMUNICATE
0388 4F		MOV	C,A	
0389 CDB709		CALL	CONOUT	;ECHO DIGIT WE'RE DIALING
038C 79		MOV	A,C	
038D 0E28		MVI	C,40	
038F FE2A		CPI	'*'	;2 SECOND DELAY?
0391 F5		PUSH	PSW	
0392 CCA50A		CZ	DELAY	;YES, WAIT 2 SEC.

0395 F1	POP	PSW	
0396 CA8203	JZ	DL2	
0399 FE3A	CPI	3AH	; IGNORE ALL XCEPT DIGITS
039B D28203	JNC	DL2	
039E FE30	CPI	'0'	
03A0 DA8203	JC	DL2	
03A3 4F	MOV	C,A	
03A4 CDD10A	CALL	PULSE	; DIAL THE DIGIT
03A7 C38203	JMP	DL2	; LOOP BACK FOR MORE

;THIS ROUTINE WAITS FOR THE PHONE TO RING.
; IT THEN ANSWERS ON THE FIRST RING, TURNS ON
; THE CARRIER, THEN JUMPS TO "COMM1" AND WAITS
; FOR A RECEIVE CARRIER.

03AA CD8302	ANSWR:	CALL	NEXT	;GET NEXT CHARACTER
03AD FE41		CPI	'A'	;A=ANSWER WITHOUT A RING
03AF CAF603		JZ	ANS2	;IN ANSWER MODE
03B2 FE4F		CPI	'0'	;O=ANSWER WITHOUT A RING
03B4 CA1F04		JZ	COMM	;IN ORIGINATE MODE
03B7 CDE402		CALL	PRINT	;ELSE WAIT FOR RING
03BA 5741495449		DB	'WAITING FOR RING. PRESS ANY KEY TO ABORT.',CR	
03E4 CD050A	ANS1:	CALL	RISTAT	;CHECK FOR PHONE RINGING
03E7 B7		ORA	A	
03E8 C2F603		JNZ	ANS2	;IF YES THEN ANSWER IT
03EB CDAD09		CALL	CONST	;ABORT?
03EE B7		ORA	A	
03EF CAE403		JZ	ANS1	;NO, LOOP BACK
03F2 CDA109		CALL	CONIN	;GET CHARACTER
03F5 C9		RET		;ABORT
03F6 CDE402	ANS2:	CALL	PRINT	
03F9 07414E5357		DB	BELL,'ANSWERING CALL',CR	
0409 0E01		MVI	C,1	
040B CD290A		CALL	SWHOOK	;ANSWER PHONE
040E 3E00		MVI	A,0	;A=0 FOR ANSWER MODE
0410 320310		STA	MFLAG	
0413 4F		MOV	C,A	
0414 CD3D0A		CALL	MODE	;SET TO ANSWER MODE
0417 0E01		MVI	C,1	
0419 CD150A		CALL	TXON	;TURN ON TRANSMIT CARRIER
041C C32B04		JMP	COMM1	

;THIS ROUTINE WAITS FOR A CARRIER THEN GOES INTO
;THE TELETYPE MODE FOR COMMUNICATIONS.

041F CDDF02	COMM:	CALL	CRLF	
0422 3E01		MVI	A,1	;ORIGINATE MODE
0424 320310		STA	MFLAG	;SET TO MODE
0427 4F		MOV	C,A	
0428 CD3D0A		CALL	MODE	
042B 1E1E	COMM1:	MVI	E,30	;SET FOR 30 SECONDS
042D CDE402		CALL	PRINT	

0430 5741495449		DB	'WAITING FOR CARRIER, PRESS ANY KEY TO ABORT.',CR
045D 0E14	CM1:	MVI	C,20 ;FOR 1 SECOND DELAY
045F CDA50A		CALL	DELAY ;WAIT A SECOND
0462 CDFC09		CALL	CDSTAT ;LOOK FOR A CARRIER
0465 B7		ORA	A ;SET FLAGS
0466 C29604		JNZ	TALK
0469 CDAD09		CALL	CONST ;CHECK CONSOLE
046C B7		ORA	A
046D C27404		JNZ	CM2 ;ABORT IF ANY KEY PRESSED
0470 1D		DCR	E ;COUNT SECONDS
0471 C25D04		JNZ	CM1 ;LOOP 30 TIMES
0474 CDE402	CM2:	CALL	PRINT
0477 4E4F204341		DB	'NO CARRIER RECEIVED',BELL,CR
048C CDAD09		CALL	CONST ;CHECK CONSOLE
048F B7		ORA	A
0490 C4A109		CNZ	CONIN ;THROW AWAY CHARACTER
0493 C37505		JMP	HANGUP

;THIS IS THE COMMUNICATIONS LOOP. CHARACTERS FROM THE
;LINE ARE SENT TO THE CONSOLE. CHARACTERS FROM THE
;CONSOLE ARE SENT TO THE PHONE LINE.

0496 CDFC09	TALK:	CALL	CDSTAT
0499 B7		ORA	A
049A CAD104		JZ	TLK2
049D 0E01		MVI	C,1
049F CD150A		CALL	TXON ;TURN ON CARRIER
04A2 CDE402		CALL	PRINT
04A5 434F4E4E45		DB	'CONNECTION ESTABLISHED',CR
04BC CDAD09	TLK1:	CALL	CONST ;CHECK FOR CONSOLE CHAR.
04BF B7		ORA	A
04C0 C4EE04		CNZ	CSEND ;SEND IT IF PRESENT
04C3 CDF709		CALL	RXSTAT ;SEE IF MODEM HAS A CHARN
04C6 B7		ORA	A
04C7 C41005		CNZ	CRECV ;GET IT IF PRESENT
04CA CDFC09		CALL	CDSTAT ;CHECK FOR CARRIER
04CD B7		ORA	A
04CE C2BC04		JNZ	TLK1 ;IF CARRIER, CONTINUE
04D1 CDDF02	TLK2:	CALL	CRLF
04D4 CDE402		CALL	PRINT
04D7 5B2A204C4F		DB	'[* LOST CARRIER *]',BELL,CR
04EB C37505		JMP	HANGUP

;SEND A CHARACTER TO MODEM.
;CONSOLE CHARACTERS ARE CHECKED FOR 2 CONTROL CODES.
;CONTROL A WILL ESCAPE TO THE COMMAND MODE.
;CONTROL B WILL CAUSE A BREAK TO BE TRANSMITTED.
;NOTE THAT CONTROL A OR B CAN'T BE SENT TO THE MODEM.

04EE CDA109	CSEND:	CALL	CONIN ;GET CHAR. FROM CONSOLE
04F1 FE01		CPI	1 ;CONTROL A?
04F3 CADB01		JZ	CMND ;BACK TO COMMAND MODE
04F6 0E03		MVI	C,3 ;PREPARE FOR 150 MS BREAK

04FB F817		CPI	17H	;CONTROL W?
04FA CA510A		JZ	BREAK	;YES, SEND BREAK
04FD 4F		MOV	C,A	
04FE CDE209	XMIT:	CALL	TXCHR	;SEND TO MODEM
0501 3A0310		LDA	MFLAG	;GET MODE 0=ANS 1=ORG
0504 B7		ORA	A	
0505 CAB709		JZ	CONOUT	;ECHO IF ANSWER MODE
0508 3A0210		LDA	DPLX	;GET DUPLEX FLAG 1=FULL
050B B7		ORA	A	
050C CAB709		JZ	CONOUT	;ECHO IF HALF DUPLEX
050F C9		RET		

;RECEIVES CHARACTERS FROM THE MODEM AND SENDS THEM
 ; TO THE CONSOLE. IF IN FULL DUPLEX ANSWER MODE THE
 ; CHARACTERS WILL BE ECHOED BACK TO THE MODEM. IN
 ; ORIGINATE MODE OR HALF DUPLEX CHARACTERS WILL NOT
 ; BE ECHOED BACK.
 ;IT ALSO CALLS THE CAPTURE ROUTINE WHICH WILL PUT
 ;THE RECEIVED CHARACTERS IN THE BUFFER IF IT IS ENABLED.

0510 CDED09		CRECV:	CALL	RXCHR	;GET CHARACTER FROM MODEM
0513 4F			MOV	C,A	
0514 3A3310			LDA	BUGFLAG	;SEE IF WE PRINT IT IN HEX
0517 B7			ORA	A	
0518 CA3205			JZ	REC1	;JUMP IF NOT HEX DISP. MODE
051B CD5305			CALL	PRNHEX	
051E 0E20			MVI	C,20H	;ASCII SPACE
0520 CDB709			CALL	CONOUT	;SPACE BETWEEN HEX NUMBERS
0523 3A3410			LDA	BUGCOUNT	
0526 3D			DCR	A	
0527 323410			STA	BUGCOUNT	
052A E60F			ANI	OFH	
052C CCDF02			CZ	CRLF	
052F C34305			JMP	REC2	
0532 CD0E0A	REC1:		CALL	ERFLG	;GER _T ERROR FLAGS
0535 E601			ANI	1	
0537 CA3C05			JZ	REC3	
053A 0E23			MVI	C,'#'	;# SUBS FOR CHAR. WITH PARITY ERROR
053C 79	REC3:		MOV	A,C	
053D E67F			ANI	7FH	;KILL MSB
053F 4F			MOV	C,A	
0540 CDB709			CALL	CONOUT	;SEND TO CONSOLE
0543 CDFF06	REC2:		CALL	CPBFIL	;ALSO TO CAPTURE BUFFER
0546 3A0310			LDA	MFLAG	;GET MODE 1=ORG 0=ANS
0549 B7			ORA	A	
054A C0			RNZ		;DON'T ECHO TO LINE IF ORIG.
054B 3A0210			LDA	DPLX	;GET DUPLEX FLAG 1=FULL
054E B7			ORA	A	
054F C2E209			JNZ	TXCHR	;ECHO BACK TO SENDER
0552 C9			RET		

;PRINTS INCOMMING CHARACTERS IN HEX WITH THE MODEM STATUS WORD.

0553 C5	PRNHEX:	PUSH B	;CHARACTER IS IN C, SAVE IT
0554 79		MOV A,C	
0555 0F		RRC	
0556 0F		RRC	
0557 0F		RRC	
0558 0F		RRC	
0559 CD6405		CALL PRNH1	
055C C1		POP B	;RESTORE CHARACTER
055D C5		PUSH B	;SAVE AGAIN
055E 79		MOV A,C	
055F CD6405		CALL PRNH1	;PRINT LOW NIBBLE
0562 C1		POP B	
0563 C9		RET	
0564 E60F	PRNH1:	ANI 0FH	;KEEP LOW 4 BITS
0566 C630		ADI 30H	;ASCII BIAS ADDED
0568 4F		MOV C,A	
0569 FE3A		CPI 3AH	
056B DAB709		JC CONOUT	
056E 3E07		MVI A,7	
0570 81		ADD C	;MAKE LETTER A-F
0571 4F		MOV C,A	
0572 C3B709		JMP CONOUT	

;THIS ROUTINE HANGS UP AND TURNS OFF THE TX CARRIER.

0575 0E00	HANGUP:	MVI C,0	
0577 CD150A		CALL TXON	;TRANSMIT CARRIER OFF
057A 0E00		MVI C,0	
057C CD290A		CALL SWHOOK	;GO ON-HOOK
057F CDE402		CALL PRINT	
0582 5B2048554E		DB '[HUNG UP]',BELL,CR	
058F 0E14		MVI C,20	;SET FOR 1 SECOND DELAY
0591 CDA50A		CALL DELAY	;WAIT FOR THINGS TO DISCONNECT
0594 C9		RET	

;***** THE FOLLOWING ROUTINES SET OPTIONS *****

;NOTE THAT MOST DON'T CHECK FOR VALID RANGE OF VARIABLES.
;IT IS POSSIBLE FOR EXAMPLE TO SET THE STOP BITS TO 7 OR 9
;OR OTHER IMPOSSIBLE NUMBER. IN THIS CASE 1 OR 2 STOP BITS
;WOULD ACTUALLY BE SET EVEN THOUGH NO ERROR MESSAGE WAS
;GENERATED.

;THIS ROUTINE LETS THE USER CHANGE THE BAUD RATE.

0595 CDB702	BRATE:	CALL GETHEX	;GET A DIGIT
0598 7B		MOV A,E	

```

0599 FE01      CPI    1          ;110 BAUD?
059B CAB405    JZ     BR110
059E FE03      CPI    3
05A0 C2C505    JNZ    BADBR      ;BAD IF NOT 110 OR 300
05A3 CDE402    CALL   PRINT
05A6 3330302042 DB    '300 BAUD',CR
05AF 0E01      MVI   C,1
05B1 C31F0A    JMP    BAUD      ;SET RATE

```

```

05B4 CDE402    BR110: CALL   PRINT
05B7 3131302042 DB    '110 BAUD',CR
05C0 0E00      MVI   C,0
05C2 C31F0A    JMP    BAUD
05C5 CDE402    BADBR: CALL   PRINT
05C8 4241442042 DB    'BAD BAUD RATE',CR
05D6 C9        RET

```

;LETS USER CHANGE LENGTH OF DATA WORD (5,6,7,8 BITS).

```

15D7 CDB702    LENGTH: CALL   GETHEX      ;GET LENGTH
15DA CDEF05    CALL   PDIGIT      ;PRINT IT
15DD CDE402    CALL   PRINT
15E0 2044415441 DB    ' DATA BITS',CR
15EB 4B        MOV    C,E
15EC C3870A    JMP    WLS       ;SET MODEM BOARD

```

```

15EF 3E30      PDIGIT: MVI   A,30H
15F1 83        ADD    E          ;MAKE NUMBER IN E ASCII
15F2 4F        MOV    C,A
15F3 CDB709    CALL   CONOUT      ;PRINT IT
15F6 C9        RET

```

;SET NUMBER OF STOP BITS (1 OR 2).

```

5F7 CDB702    SBITS: CALL   GETHEX
5FA CDEF05    CALL   PDIGIT
5FD CDE402    CALL   PRINT
600 2053544F50 DB    ' STOP BITS',CR
60B 4B        MOV    C,E
60C C39A0A    JMP    NSTOP      ;SET THE MODEM

```

;SETS FULL DUPLEX MODE (F COMMAND)

```

60F 3E01      FULL:  MVI   A,1
611 320210    STA    DPLX      ;SET FLAG
614 CDE402    CALL   PRINT
617 46554C4C20 DB    'FULL DUPLEX',CR
623 C9        RET

```

;SET HALF DUPLEX MODE (H COMMAND)

```

624 AF        HALF:  XRA   A

```

0625 320210	S'TA	DPLX	;CLEAR FLAG
0628 CDE402	CALL	PRINT	
062B 48414C4620	DB	'HALF DUPLEX',CR	
0637 C9	RET		

;SET PARITY, N=NO PARITY E=EVEN PARITY O=ODD PARITY

0638 CD9F02	PARTYP:	CALL	NXTCHR	;FIND NEXT CHARACTER IN BUFF.
063B CD8302		CALL	NEXT	;GET IT
063E FE4E		CPI	'N'	
0640 CA4E06		JZ	NPAR	
0643 FE45		CPI	'E'	
0645 CA6006		JZ	EPR	
0648 FE4F		CPI	'O'	
064A CA7406		JZ	O PAR	
064D C9		RET		
064E CDE402	NPAR:	CALL	PRINT	
0651 4E4F205041		DB	'NO PARITY',CR	
065B 0E00		MVI	C,0	
065D C36C0A		JMP	PARITY	
0660 CDE402	EPR:	CALL	PRINT	
0663 4556454E20		DB	'EVEN PARITY',CR	
066F 0E02		MVI	C,2	
0671 C36C0A		JMP	PARITY	
0674 CDE402	O PAR:	CALL	PRINT	
0677 4F44442050		DB	'ODD PARITY',CR	
0682 0E01		MVI	C,1	
0684 C36C0A		JMP	PARITY	

;THIS ROUTINE ALLOWS THE USER TO JUMP TO
;AN EXTERNAL PROGRAM AND EXECUTE IT.
;FOR EXAMPLE, IF YOU HAD A ROM MONITOR
;AT F000 HEX, YOU WOULD ENTER THE COMMAND: J F000
;

0687 CD9F02	JUMP:	CALL	NXTCHR	;FIND ADDRESS
068A CDB702		CALL	GETHEX	;CONVERT TO BINARY IN DE
068D EB		XCHG		;ADDRESS TO HL
068E E9		PCHL		;JUMP TO ROUTINE

;THIS ROUTINE SETS UP THE THE CAPTURE FUNCTION
;COMMAND FORMAT: C0 RESETS THE BUFFER POINTER
;AND DISABLES CAPTURE.
;C1 ENABLES CAPTURE AT CURRENT BUFFER ADDRESS
;C2 STOPS CAPTURE AT CURRENT ADDRESS.

CAPTURE:

068F CD9F02		CALL	NXTCHR	;FIND DIGIT
0692 B7		ORA	A	
0693 C8		RZ		;RETURN IF NO ARG.

0694 CD8302	CALL	NEXT	;GET DIGIT	
0697 FE30	CPI	'0'		
0699 CAD406	JZ	RSBUF	;IF ZERO, RESET	
069C FE31	CPI	'1'		
069E CABB06	JZ	STRT	;IF 1 START CAPTURE MODE	
06A1 FE32	CPI	'2'		
06A3 C0	RNZ		;IF 2 STOP CAPTURE	
06A4 AF	XRA	A		
06A5 323210	STA	CPFLAG	;CLEAR CAPTURE FLAG	
06A8 CDE402	CALL	PRINT		
06AB 4341505455	DB	'CAPTURE STOPED',CR		
06BA C9	RET			
06BB 3E01	STRT:	MVI	A,1	
06BD 323210	STA	CPFLAG	;SET CAPTURE FLAG	
06C0 CDE402	CALL	PRINT		
06C3 4341505455	DB	'CAPTURE ENABLED',CR		
06D3 C9	RET			
06D4 21DE10	RSBUF:	LXI	H,CPBUF	;START OF CAPTURE BUFFER
06D7 223610		SHLD	CBUFP	;STORE POINTER
06DA AF		XRA	A	
06DB 323210		STA	CPFLAG	;CLEAR FLAG
06DE 323810		STA	CPCNT	;CLEAR BYTE COUNTER
06E1 323910		STA	CPCNT+1	
06E4 CDE402		CALL	PRINT	
06E7 4341505455		DB	'CAPTURE BUFFER CLEARED',CR	
06FE C9		RET		

;THIS ROUTINE FILLS THE CAPTURE BUFFER WITH CHARACTERS
;FROM THE MODEM IF THE "CPFLAG" IS SET TO A 1.
;THE BUFFER POINTER IS STORED AT "CBUFP".

06FF 3A3210	CPBFIL:	LDA	CPFLAG	;GET FLAG
0702 B7		ORA	A	
0703 C8		RZ		;RETURN IF NOT ENABLED
0704 E5		PUSH	H	;SAVE HL
0705 2A3610		LHLD	CBUFP	;GET BUFFER POINTER
0708 71		MOV	M,C	;PUT CHARACTER IN BUFFER
0709 23		INX	H	;ADVANCE POINTER
070A 3A3510		LDA	MTOP	;TOP OF MEMORY
070D BC		CMP	H	;CHECK FOR "OUT OF MEMORY"
070E CA1D07		JZ	OUTMEM	
0711 223610		SHLD	CBUFP	;SAVE POINTER
0714 2A3810		LHLD	CPCNT	;GET CHARACTER COUNTER
0717 23		INX	H	;INCREMENT IT
0718 223810		SHLD	CPCNT	;STORE IT
071B E1		POP	H	
071C C9		RET		
071D CDDF02	OUTMEM:	CALL	CRLF	
0720 CDE402		CALL	PRINT	
0723 4341505455		DB	'CAPTURE BUFFER FULL',BELL,CR	
0738 AF		XRA	A	
0739 323210		STA	CPFLAG	;DISABLE CAPTURE MODE
073C E1		POP	H	

073D C9

RET

; TYPES THE CAPTURE BUFFER TO THE CONSOLE.

;T WILL TYPE STARTING AT THE BEGINNING
;T FOLLOWED BY A HEX NUMBER WILL CAUSE PRINTING TO
;START AT A POINT SPECIFIED BY THE NUMBER. FOR EXAMPLE
;T 100 WILL START TYPING AT A POINT 100 HEX
;CHARACTERS INTO THE BUFFER. S STARTS
;AND STOPS THE PRINTING. CARRIAGE RETURN ABORTS
;THIS FUNCTION.

073E CDB702	TYPE:	CALL	GETHEX	
0741 21DE10		LXI	H,CPBUF	;STARTING ADDRESS OF BUFFER
0744 19		DAD	D	;ADD USERS COUNT TO STARTING ADR.
0745 3A3810	TY1:	LDA	CPCNT	;SEE IF WE'RE AT END
0748 BB		CMP	E	
0749 C25107		JNZ	TY0	
074C 3A3910		LDA	CPCNT+1	
074F BA		CMP	D	
0750 C8		RZ		;QUIT AT END OF BUFFER
0751 4E	TY0:	MOV	C,M	;GET A CHARACTER
0752 CDB709		CALL	CONOUT	;PRINT IT
0755 CDAD09		CALL	CONST	;CHECK FOR CONSOLE INPUT
0758 B7		ORA	A	
0759 CA7907		JZ	TY2	
075C CDA109		CALL	CONIN	;GET CONSOLE
075F FE0D		CPI	CR	;WANT TO ABORT?
0761 C8		RZ		;IF YES THEN RETURN
0762 FE53		CPI	'S'	;WANT TO STOP?
0764 C27907		JNZ	TY2	
0767 CDAD09	TY3:	CALL	CONST	
076A B7		ORA	A	
076B CA6707		JZ	TY3	;WAIT FOR ANOTHER S
076E CDA109		CALL	CONIN	
0771 FE0D		CPI	CR	
0773 C8		RZ		
0774 FE53		CPI	'S'	
0776 C26707		JNZ	TY3	
0779 23	TY2:	INX	H	;ADVANCE POINTERS
077A 13		INX	D	
077B C34507		JMP	TY1	;LOOP BACK FOR MORE
077E CD8302	DEBUG:	CALL	NEXT	
0781 FE30		CPI	'0'	
0783 CAA407		JZ	DBOFF	
0786 FE31		CPI	'1'	;DEBUG ON?
0788 C0		RNZ		
0789 CDE402		CALL	PRINT	
078C 4445425547		DB	'DEBUG MODE ON',CR	
079A 3E01		MVI	A,1	
079C 323310		STA	BUGFLAG	
079F 3D		DCR	A	

07A0 323410	STA	BUGCOUNT
07A3 C9	RET	
07A4 CDE402	DBOFF:	CALL PRINT
07A7 4445425547	DB	'DEBUG MODE OFF',CR
07B6 AF	XRA	A
07B7 323310	STA	BUGFLAG
07BA C9	RET	

;THIS IS THE COMMAND DECODING TABLE.

;EACH ENTRY IS AN ASCII LETTER FOLLOWED BY AN ADDRESS
;OF THE ROUTINE WHICH IS CALLED TO EXECUTE THAT COMMAND.
;THE END OF THE TABLE IS MARKED WITH A ZERO.

07BB 58	TABLE:	DB	'X'	;EXIT TO CP/M
07BC 0303		DW	QUIT	
07BE 44		DB	'D'	;DIAL A NUMBER
07BF 5603		DW	DIAL	
07C1 41		DB	'A'	;ANSWER CALLS
07C2 AA03		DW	ANSWR	
07C4 47		DB	'G'	;";GOODBYE" HANG UP PHONE
07C5 7505		DW	HANGUP	
07C7 42		DB	'B'	;CHANGE BAUD RATE
07C8 9505		DW	BRATE	
07CA 53		DB	'S'	;SET STOP BITS
07CB F705		DW	SBITS	
07CD 4C		DB	'L'	;SET DATA WORD LENGTH
07CE D705		DW	LENGTH	
07D0 50		DB	'P'	;SET PARITY MODE
07D1 3806		DW	PARTYP	
07D3 46		DB	'F'	;SET FULL DUPLEX
07D4 0F06		DW	FULL	
07D6 48		DB	'H'	;HALF DUPLEX
07D7 2406		DW	HALF	
07D9 4A		DB	'J'	;JUMP TO ADDRESS
07DA 8706		DW	JUMP	
07DC 43		DB	'C'	;CAPTURE
07DD 8F06		DW	CAPTURE	
07DF 54		DB	'T'	;TYPE BUFFER TO CONSOLE
07E0 3E07		DW	TYPE	
07E2 57		DB	'W'	;WRITE CAPTURE BUFFER TO DISK
07E3 0E09		DW	SAVE	
07E5 52		DB	'R'	;READ AND TRANSMIT DISK FILE
07E6 8D08		DW	READ	
07E8 3F		DB	'?'	;SET TO DEBUG MODE
07E9 7E07		DW	DEBUG	
07EB 00		DB	0	;END OF TABLE

;***** OPTIONAL DISK I/O AREA *****

;THESE ROUTINES ALLOW YOU TO SAVE THE CONTENTS OF
;THE CAPTURE BUFFER ON THE DISK. IF YOU DON'T HAVE
;THE CP/M DISK OPERATING SYSTEM THEY WON'T WORK.

;DISK I/O ROUTINES

07EC 11BD10	DELETE:	LXI	D,FCB
07EF 0E13		MVI	C,19
07F1 C30500		JMP	BDOS

07F4 11BD10	MAKE:	LXI	D,FCB
07F7 0E16		MVI	C,22
07F9 C30500		JMP	BDOS

07FC E5	SETDMA:	PUSH	H
07FD 0E1A		MVI	C,26
07FF CD0500		CALL	BDOS
0802 E1		POP	H
0803 C9		RET	

WRITENR:

0804 E5		PUSH	H
0805 11BD10		LXI	D,FCB
0808 0E15		MVI	C,21
080A CD0500		CALL	BDOS
080D E1		POP	H
080E C9		RET	

READNR:

080F E5		PUSH	H
0810 11BD10		LXI	D,FCB
0813 0E14		MVI	C,20
0815 CD0500		CALL	BDOS
0818 E1		POP	H
0819 C9		RET	

081A 11BD10	CLOSE:	LXI	D,FCB
081D 0E10		MVI	C,16
081F C30500		JMP	BDOS

0822 11BD10	OPEN:	LXI	D,FCB
0825 0EOF		MVI	C,15
0827 C30500		JMP	BDOS

;GET NAME OF FILE FROM CONSOLE BUFFER TO FILE CONTROL BLOCK

GETNAME:

082A CD9F02		CALL	NXTCHR	;SET BUFFER POINTER TO FILE NAME
082D B7		ORA	A	;TEST FOR NO FILE NAME
082E C8		RZ		;RETURN IF NONE ENTERED
082F 21BD10		LXI	H,ET	;POINT TO ENTRY TYPE
0832 AF		XRA	A	;ZERO A
0833 060C		MVI	B,12	;LOAD COMPUTER
0835 77	G1:	MOV	M,A	;FILL FCB AREA WITH 0 + 11 SPACES
0836 3E20		MVI	A,20H	;A SPACE
0838 23		INX	H	;BUMP POINTER
0839 05		DCR	B	;COUNT' EM

083A C23508		JNZ	G1	
083D 0608	MVI	B,8		;MAX OF 8 CHARS. IN FILE NAME
083F 11BE10		LXI	D,FNAME	;POINT TO FCB FILE NAME AREA
0842 CD6508		CALL	MVNAM	;MOVE NAME FROM BUFFER TO FCB
0845 FE2E		CPI	'..'	
0847 C25208		JNZ	G2	;IF NO PERIOD THEN NO FILE TYPE
084A 11C610		LXI	D,FTYPE	;POINT TO FILE TYPE AREA
084D 0603		MVI	B,3	;MAX OF 3 CHARS. IN FILE TYPE
084F CD6508		CALL	MVNAM	;MOVE TYPE INTO FCB AREA
0852 21C910	G2:	LXI	H,EX	;FILL REST OF FCB WITH ZEROS
0855 0615		MVI	B,(NR+1)-EX	;COUNTER
0857 3600	GG3:	MVI	M,0	
0859 23		INX	H	
085A 05		DCR	B	
085B C25708		JNZ	GG3	
085E 118000		LXI	D,80H	;SET DMA ADDRESS TO 80H
0861 CDFC07		CALL	SETDMA	
0864 C9		RET		

;MOVES STRINGS FROM CONSOLE BUFFER TO FCB AREA
;DE POINT TO DESTINATION
;B HAS NUMBER OF CHARACTERS TO MOVE

0865 CD8302	MVNAM:	CALL	NEXT	;GET NEXT CHARACTER
0868 FE2E		CPI	'..'	;END OF FILE NAME?
086A C8		RZ		
086B FE0D		CPI	CR	;END OF LINE?
086D C8		RZ		
086E FE00		CPI	0	;DELIMITER?
0870 C8		RZ		
0871 12		STAX	D	;PUT CAHRACTER IN FCB
0872 13		INX	D	;ADVANCE POINTER
0873 05		DCR	B	
0874 C26508		JNZ	MVNAM	;LOOP IF MORE CHARACTERS
0877 C38302		JMP	NEXT	;GET NEXT CHARACTER AND RETURN
087A 21C910		LXI	H,EX	;POINT TO EXTENT AREA OF FCB
087D 0615		MVI	B,(NR+1)-EX	
087F 3600	G3:	MVI	M,0	;FILL REST OF FCB WITH ZERO
0881 23		INX	H	
0882 05		DCR	B	
0883 C27F08		JNZ	G3	
0886 118000		LXI	D,80H	
0889 CDFC07		CALL	SETDMA	
088C C9		RET		

;DISK FILE TRANSMIT ROUTINE

088D CD2A08	READ:	CALL	GETNAME	;GET FILE NAME
0890 CD2208		CALL	OPEN	
0893 FEFF		CPI	255	;OK?
0895 C2A608		JNZ	R1	;JUMP IF OPEN IS OK
0898 CDE402		CALL	PRINT	
089B 4E4F542046		DB	'NOT FOUND',CR	

08A5 C9		RET	
08A6 CD0F08	R1:	CALL READNR	;READ 128 BYTES INTO 80H BUFFER
08A9 CDB508		CALL TXBUF	;TRANSMIT THE BUFFER CONTENTS
08AC FE1A		CPI 1AH	;CONTROL Z (END OF FILE)
08AE C2A608		JNZ R1	
08B1 CD1A08		CALL CLOSE	
08B4 C9		RET	

;TRANSMITS THE CONTENTS OF THE DISK BUFFER

08B5 218000	TXBUF:	LXI H,80H	
08B8 0680		MVI B,128	
08BA 4E	TXB1:	MOV C,M	;GET A CHARACTER
08BB CDFE04		CALL XMIT	;TRANSMIT IT
08BE 79		MOV A,C	
08BF FE1A		CPI 1AH	;END OF FILE?
08C1 C8		RZ	;YES RETURN
08C2 FE0D		CPI CR	;END OF LINE?
08C4 CCE808		CZ WIRPLY	;WAIT FOR POSSIBLE PROMPT
08C7 CDF709		CALL RXSTAT	;SEE IF CHAR. HAS BEEN RECEIVED
08CA B7		ORA A	
08CB C41005		CNZ CRECV	;GET IT AND SEND TO CONSOLE
08CE CDFC09		CALL CDSTAT	;CHECK FOR CARRIER
08D1 B7		ORA A	
08D2 CADF08		JZ ABRT	;ABORT IF NO CARRIER
08D5 CDAD09		CALL CONST	;WANT TO ABORT?
08D8 B7		ORA A	
08D9 CAE208		JZ TXB2	;JUMP IF NOT
08DC CDA109		CALL CONIN	;ABORT ON ANY KEY PRESSED
08DF 3E1A	ABRT:	MVI A,1AH	;FAKE OUT THE CALLING ROUTINE
08E1 C9		RET	
08E2 23	TXB2:	INX H	;BUMP BUFFER POINTER
08E3 05		DCR B	;COUNT BYTES
08E4 C2BA08		JNZ TXB1	
08E7 C9		RET	

;THIS ROUTINE WAITS FOR 150 MS AFTER THE LAST
;CHARACTER IS RECEIVED BY THE MODEM.

08E8 C5	WTRPLY:	PUSH B	
08E9 CDF709		CALL RXSTAT	
08EC B7		ORA A	
08ED C4ED09		CNZ RXCHR	;FLUSH UART
08F0 0603	WTRP1:	MVI B,3	;150 MS
08F2 CDB80A	WTRP2:	CALL STIME	;START TIMER
08F5 CDF709	WTRP3:	CALL RXSTAT	;MODEM CHAR. RECEIVED?
08F8 B7		ORA A	
08F9 F5		PUSH PSW	;SAVE STATUS
08FA C41005		CNZ CRECV	;GET AND SEND TO CONSOLE
08FD F1		POP PSW	;POP FLAGS AGAIN
08FE C2F008		JNZ WTRP1	;IF CHARACTER REC. LOOP BACK
0901 CDBB0A		CALL CKTIME	;TIME UP?
0904 B7		ORA A	
0905 CAF508		JZ WTRP3	;NO, LOOP BACK
0908 05		DCR B	;COUNT LOOPS

0909 C2F208	JNZ	WTRP2	;LOOP IF NOT 150 MS
090C C1	POP	B	;RESTORE BC
090D C9	RET		

;THIS ROUTINE STORES THE CONTENTS OF THE CAPTURE
;BUFFER ON THE DISK.

090E CD2A08	SAVE:	CALL GETNAME	
0911 CDEC07		CALL DELETE	;ERASE OLD FILE OF SAME NAME
0914 CDF407		CALL MAKE	;MAKE NEW FILE
0917 FEFF		CPI 255	
0919 C23309		JNZ S1	
091C CDE402		CALL PRINT	
091F 4E4F204449		DB 'NO DIRECTORY SPACE',CR	
0932 C9		RET	
0933 CD2208	S1:	CALL OPEN	
0936 2A3610		LHLD CBUFP	;CAPTURE BUFFER POINTER
0939 EB		XCHG	;POINTER TO DE
093A 2A3810		LHLD CPCNT	;BUFFER CAHRACTER COUNT
093D 3E1A	S2:	MVI A,1AH	;END OF FILE MARKER
093F 12		STAX D	
0940 13		INX D	
0941 23		INX H	;FILL OUT WITH 1A'S TILL
0942 7D		MOV A,L	;EVEN WITH 128 BYTE BOUNDRY
0943 E67F		ANI 7FH	
0945 C23D09		JNZ S2	
0948 29		DAD H	;SHIFT HL LEFT 1 BIT
0949 CE00		ACI 0	;SHIFT CARRY INTO REG. A
094B 47		MOV B,A	;MSB OF RECORD COUNT TO B
094C 4C		MOV C,H	;LSB OF RECORD COUNT IN C
094D 03		INX B	;ADD 1 MORE
094E 11DE10		LXI D,CPBUF	;CAPTURE BUFFER START ADDRESS
0951 C5	S3:	PUSH B	;SAVE RECORD COUNT
0952 D5		PUSH D	;SAVE BUFFER POINTER
0953 CDFC07		CALL SETDMA	;DMA=BUFFER
0956 CD0408		CALL WRITENR	;WRITE A RECORD TO DISK
0959 B7		ORA A	;CHECK FOR ERROR
095A C28E09		JNZ ERRR	
095D D1		POP D	;GET CAPTURE BUFFER POINTER
095E 218000		LXI H,128	
0961 19		DAD D	;ADVANCE IT 128 BYTES
0962 EB		XCHG	
0963 C1		POP B	;GET RECORD COUNT
0964 0B		DCX B	;COUNT 1
0965 78		MOV A,B	
0966 B1		ORA C	;TEST FOR ZERO
0967 C25109		JNZ S3	;IF NOT ZERO, LOOP BACK
096A 118000		LXI D,80H	;RESET DMA TO 80H
096D CDFC07		CALL SETDMA	
0970 CD1A08		CALL CLOSE	
0973 FEFF		CPI 255	

0975 C2D406	JNZ	RSBUF	;CLEAR CAPTURE BUFFER
0978 CDE402	CALL	PRINT	
097B 43414E4E4F	DB	'CANNOT CLOSE FILE',CR	
098D C9	RET		

098E E1	ERRR:	POP	H
098F E1		POP	H ;CLEAN UP STACK
0990 CDE402		CALL	PRINT
0993 4F5554204F		DB	'OUT OF SPACE',CR
09A0 C9		RET	

;***** CONSOLE I/O AREA FOR CP/M *****

;CONSOLE INPUT
;IT RETURNS THE CHARACTER IN REGISTER A

09A1 E5	CONIN:	PUSH	H
09A2 D5		PUSH	D
09A3 C5		PUSH	B
09A4 CD0A10		CALL	XCONIN
09A7 E67F		ANI	7FH ;KILL MSB
09A9 C1		POP	B
09AA D1		POP	D
09AB E1		POP	H
09AC C9		RET	

;CONSOLE STATUS CHECK
;RETURNS WITH A=0 IF NO CHARACTER TYPED
;OR A=1 IF CHARACTER HAS BEEN TYPED (OR A= NOT ZERO)

09AD E5	CONST:	PUSH	H
09AE D5		PUSH	D
09AF C5		PUSH	B
09B0 CD0710		CALL	XCONST
09B3 C1		POP	B
09B4 D1		POP	D
09B5 E1		POP	H
09B6 C9		RET	

;CONSOLE OUTPUT. CHARACTER TO BE PRINTED MUST BE IN
; REG. C

09B7 E5	CONOUT:	PUSH	H
09B8 D5		PUSH	D
09B9 C5		PUSH	B
09BA CD0D10		CALL	XCONOT
09BD C1		POP	B
09BE D1		POP	D
09BF E1		POP	H
09C0 C9		RET	

;INITIALIZATION ROUTINE FOR USER HARDWARE AND SOFTWARE.
;PUT YOUR OWN SPECIAL INITIALIZATION ROUTINES HERE.

;THIS ROUTINE MOVES THE CP/M CBIOS JUMP TABLE TO
;"JTAB" IN RAM.

09C1 2A0100	INIT:	LHLD	1	;GET ADDRESS OF CBIOS
09C4 110410		LXI	D,JTAB	;DESTINATION ADDRESS
09C7 060C		MVI	B,4*3	;NO. OF BYTES TO MOVE
09C9 7E	MOVE:	MOV	A,M	;GET A BYTE
09CA 12		STAX	D	;MOVE IT
09CB 23		INX	H	;ADVANCE POINTERS
09CC 13		INX	D	
09CD 05		DCR	B	
09CE C2C909		JNZ	MOVE	;COUNT BYTES
09D1 3E01		MVI	A,1	;SPECIAL HARDWARE STUFF
09D3 D384		OUT	84H	
09D5 C9		RET		
	PAGE			;PRINTER TOP OF FORM

;***** MODEM I/O AREA *****

; ALL MODEM I/O AND CONTROL ARE HERE.

; MODEM I/O SYSTEM 5-10-79

; WRITTEN BY DALE A. HEATHERINGTON
; COPYRIGHT 1979 D.C. HAYES ASSOCIATES, INC.

; PORT EQUATES

0080 =	DATA	EQU	80H
0081 =	STATUS	EQU	DATA+1
0081 =	CR1	EQU	DATA+1
0082 =	CR2	EQU	DATA+2
0083 =	CR3	EQU	DATA+3

; BIT FUNCTIONS

; STATUS REGISTER

0001 =	RRF	EQU	1	;RECEIVE REGISTER FULL
0002 =	TRE	EQU	2	;TRANSMITTER HOLDING REGISTER EMPTY
0004 =	PE	EQU	4	;PARITY ERROR
0008 =	FE	EQU	8	;FRAMMING ERROR
0010 =	OE	EQU	10H	;OVERRUN ERROR
0020 =	TMR	EQU	20H	;TIMER STATUS
0040 =	CD	EQU	40H	;CARRIER PRESENT
0080 =	RI	EQU	80H	;NOT RING INDICATOR (LOW TRUE)

;CONTROL REGISTER 1 (CR1)

0001 =	EPE	EQU	1	;EVEN PARITY ENABLE
0002 =	LS1	EQU	2	;WORD LENGTH SELECT BIT 1
0004 =	LS2	EQU	4	;WORD LENGTH SELECT BIT 2
0008 =	SBS	EQU	8	;STOP BITS
0010 =	PI	EQU	10H	;PARITY INHIBIT
0020 =	TMIE	EQU	20H	;TIMER INTERRUPTS ENABLE

;CONTROL REGISTER 2 (CR2)

0001 =	BRS	EQU	1	;BAUD RATE CONTROL
0002 =	TXE	EQU	2	;TRANSMIT CARRIER ENABLE
0004 =	MS	EQU	4	;MODE (0=ANSWER 1=ORIGINATE)
0008 =	BRK	EQU	8	;SEND BREAK
0010 =	ST	EQU	10H	;SELF TEST

```

0020 =      TIE    EQU    20H    ;TRANSMITTER INTERRUPT ENABLE
0040 =      RIE    EQU    40H    ;RECEIVER INTERRUPT ENABLE
0080 =      OH     EQU    80H    ;OFF-HOOK

;CONTROL REGISTER 3 (CR3)

;WRITING ANYTHING TO CR3 STARTS THE 50 MS TIMER.

```

;THIS ROUTINE CLEARS ALL THE CONTROL REGISTERS

```

09D6 AF      RESET: XRA    A      ;ZERO A
09D7 D381    OUT    CRL
09D9 D382    OUT    CR2
09DB 320110   STA    MICR2  ;CLEAR MEMORY IMAGES TOO
09DE 320010   STA    MICR1
09E1 C9      RET

```

;THIS ROUTINE SENDS A BYTE IN REGISTER C TO THE MODEM
;TRANSMITTER. ONLY REGISTER A IS DISTURBED

```

09E2 DB81    TXCHR: IN     STATUS ;GET MODEM STATUS
09E4 E602    ANI     TXE   ;CHECK FOR TRANSMITTER EMPTY
09E6 CAE209   JZ      TXCHR ;LOOP IF NOT
09E9 79      MOV     A,C
09EA D380    OUT    DATA  ;SEND THE BYTE
09EC C9      RET

```

;GETS A BYTE FROM THE MODEM RECEIVER IN REGISTER A

```

09ED DB81    RXCHR: IN     STATUS
09EF E601    ANI     RRF
09F1 CAED09   JZ      RXCHR ;LOOP IF NO CHARACTER REC.
09F4 DB80    IN     DATA
09F6 C9      RET      ;CHARACTER IN A

```

;THIS ROUTINE RETURNS WITH A=1 IF A RECEIVED
;CHARACTER IS WAITING OR A=0 IF NOT.

```

09F7 DB81    RXSTAT: IN     STATUS ;GET MODEM STATUS
09F9 E601    ANI     RRF  ;CHECK RECEIVER FLAG
09FB C9      RET      ;A=1 IF CHARACTER PRESENT

```

;CARRIER STATUS CHECK. A=1 IF CARRIER IS PRESENT

```

09FC DB81    CDSTAT: IN     STATUS
09FE E640    ANI     CD    ;TEST CARRIER DETECT FLAG
0A00 3E00    MVI     A,0  ;ASSUME 0
0A02 C8      RZ
0A03 3C      INR     A    ;MAKE A=1 IF CARRIER PRESENT
0A04 C9      RET

```

;RING INDICATOR STATUS CHECK. A=1 IF PHONE RINGING

0A05 DB81	RISTAT:	IN	STATUS	
0A07 E680		ANI	RI	
0A09 3E01		MVI	A,1	;ASSUME RINGING
0A0B C8		RZ		;RETURN IF IT IS (LOW TRUE BIT)
0A0C 3D		DCR	A	;ELSE MAKE A=0
0A0D C9		RET		

;GET THE ERROR FLAGS. ERROR BITS ARE RETURNED IN REG. A.
;A=0 IF NO ERRORS WERE DETECTED ON LAST CHARACTER RECEIVED.
;BIT 0=PARITY ERROR BIT 1=FRAMMING ERROR
;BIT 2=OVERRUN ERROR

0A0E DB81	ERFLG:	IN	STATUS	
0A10 1F		RAR		;SHIFT BITS RIGHT 2 PLACES
0A11 1F		RAR		
0A12 E607		ANI	7	;KILL UNWANTED BITS
0A14 C9		RET		;LOW 3 BITS ARE ERROR FLAGS

;TRANSMIT CARRIER CONTROL.
;ENTER WITH REG. C=0 FOR CARRIER OFF
;OR REG. C=1 FOR TRANSMIT CARRIER ON

0A15 79	TXON:	MOV	A,C	
0A16 B7		ORA	A	
0A17 3E02		MVI	A,TXE	;PUT TXE BIT IN A
0A19 CA060B		JZ	CLR2	;CLEAR IT IF 0
0A1C C3FC0A		JMP	SET2	;SET IT IF A 1

;SET THE BAUD RATE. C=0 FOR LOW BAUD RATE (110)
; C=1 FOR HIGH BAUD RATE (300)

0A1F 79	BAUD:	MOV	A,C	
0A20 B7		ORA	A	
0A21 3E01		MVI	A,BRS	;BAUD RATE BIT IN A
0A23 CA060B		JZ	CLR2	;RESET BIT IF 0
0A26 C3FC0A		JMP	SET2	;SET IF 1

;GO ON/OFF HOOK. C=0 FOR ON-HOOK (IDLE)
; C=1 FOR OFF-HOOK.

0A29 79	SWHOOK:	MOV	A,C	
0A2A B7		ORA	A	
0A2B 3E80		MVI	A,OH	;SWITCH-HOOK BIT
0A2D CA060B		JZ	CLR2	
0A30 C3FC0A		JMP	SET2	

;GET SWITCH HOOK STATUS.
; A=0 ON HOOK A=1 OFF HOOK

```

0A33 3A0110 SHSTAT: LDA MICR2      ;GET CR2
0A36 E680     ANI OH           ;MASK FOR OFF HOOK
0A38 3E01     MVI A,1        ;A=1
0A3A C0       RNZ             ;RET. IF OFF HOOK A=1
0A3B 3D       DCR A         ;A
0A3C C9       RET             ;ELSE A=0

```

;SET THE MODE. C=0 FOR ANSWER MODE
; C=1 FOR ORIGINATE MODE

```

0A3D 79     MODE:  MOV A,C
0A3E B7     ORA A
0A3F 3E04     MVI A,MS    ;MODE SELECT BIT
0A41 CA060B   JZ CLR2
0A44 C3FC0A   JMP SET2

```

;SET OR CLEAR SELF-TEST MODE.
;C=1 FOR SELF TEST C=0 FOR NORMAL

```

0A47 79     SELFT: MOV A,C
0A48 B7     ORA A
0A49 3E10     MVI A,ST    ;SELF-TEST BIT
0A4B CA060B   JZ CLR2    ;CLEAR IT
0A4E C3FC0A   JMP SET2    ;OR SET IT

```

;SEND A BREAK CONSISTING OF SENDING A SPACE (LOW TONE) FOR
; A NUMBER OF 50 MS INTERVALS SPECIFIED IN THE REG. C.

```

0A51 C5     BREAK: PUSH B      ;SAVE BREAK DURATION VALUE
0A52 0E02     MVI C,2
0A54 CDA50A   CALL DELAY    ;WAIT 100 MS
0A57 C1     POP B          ;RESTORE BREAK DURATION VALUE
0A58 E5     PUSH H
0A59 210110   LXI H,MICR2
0A5C 3E08     MVI A,BRK    ;SET THE BREAK BIT
0A5E B6     ORA M
0A5F D382     OUT CR2
0A61 CDA50A   CALL DELAY    ;C=50 MS INTERVALS TO WAIT
0A64 3E08     MVI A,BRK
0A66 2F     CMA
0A67 A6     ANA M          ;CLEAR BREAK BIT
0A68 D382     OUT CR2    ;WRITE IT TO MODEM
0A6A E1     POP H
0A6B C9     RET

```

;SETS THE PARITY. C=0 FOR NO PARITY
; C=1 FOR ODD PARITY C=2 FOR EVEN PARITY

```

0A6C 79     PARITY: MOV A,C
0A6D B7     ORA A          ;TEST FOR NO PARITY

```

```

0A6E CA820A      JZ      PAROFF
0A71 3E10        MVI     A,PI
0A73 CD1B0B      CALL    CLR1   ;CLEAR PARITY INHIBIT BIT
0A76 79          MOV     A,C
0A77 1F          RAR
0A78 E601        ANI     1
0A7A 3E01        MVI     A,EPE
0A7C CA1B0B      JZ      CLR1   ;CLEAR EPE IF ODD
0A7F C3110B      JMP     SET1   ;SET EPE IF EVEN

0A82 3E10        PAROFF: MVI     A,PI
0A84 C3110B      JMP     SET1   ;INHIBIT PARITY

```

;SELECT WORD LENGTH.

S ;C=NUMBER OF DATA BITS (5,6,7,8)

```

0A87 79          WLS:   MOV     A,C
0A88 D605        SUI     5       ;REMOVE BIAS
0A8A 87          ADD     A
0A8B E606        ANI     6       ;KILL ANY STRAY BITS
0A8D 4F          MOV     C,A   ;SAVE RESULT IN C
0A8E 3A0010      LDA     MICR1 ;GET MEMORY IMAGE
0A91 E6F9        ANI     NOT LS1+LS2 ;CLEAR WORD LENGTH BITS
0A93 B1          ORA     C       ;PUT IN NEW ONES
0A94 320010      STA     MICR1 ;UPDATE MEMORY
0A97 D381        OUT    CR1   ;WRITE TO MODEM
0A99 C9          RET

```

;SET NUMBER OF STOP BITS

;C=STOP BITS (1 OR 2)

```

0A9A 79          NSTOP: MOV     A,C
0A9B D601        SUI     1
0A9D 3E08        MVI     A,SBS ;STOP BIT SELECT BIT
0A9F CA1B0B      JZ      CLR1   ;CLEAR IT
0AA2 C3110B      JMP     SET1   ;ELSE SET IT

```

;DELAY ROUTINE.

;WAITS 50 MS TIMES THE VALUE IN REGISTER C.

```

0AA5 79          DELAY: MOV     A,C
0AA6 B7          ORA     A
0AA7 C8          RZ
0AA8 C5          PUSH    B       ;WAIT ZERO TIME IF C=0
0AA9 D383        DLY1:  OUT    CR3   ;SAVE CONTENTS OF C
0AAB DB81        DLY2:  IN     STATUS ;START TIMER
0AAD E620        ANI     TMR   ;WAIT TILL IT TIMES OUT
0AAF CAAB0A      JZ      DLY2   ;LOOK AT TIMER BIT
0AB2 0D          DCR     C       ;LOOP BACK IF ZERO
0AB3 C2A90A      JNZ    DLY1   ;COUNT DOWN
0AB6 C1          POP     B       ;DO AGAIN IF NOT ZERO
0AB7 C9          RET

```

;STARTS THE 50 MS TIMER

0AB8 D383 STIME: OUT CR3 ;START TIMER
 0ABA C9 RET

;CHECKS THE STATUS OF THE TIMER.
 ; RETURNS WITH A=1 IF TIMED OUT OR A=0 IF NOT.

0ABB DB81	CKTIME: IN	STATUS
0ABD E620	ANI TMR	;MASK IN TIMER BIT
0ABF 3E01	MVI A,1	
0AC1 C0	RNZ	;RET. A=1 IF TIMED OUT
0AC2 3D	DCR A	
0AC3 C9	RET	;RET. A=0 IF TIME NOT UP

;GOES OFF-HOOK AND WAITS FOR A DIAL TONE. SINCE THE
 ;MICROMODEM HAS NO DIAL TONE DETECTOR WE JUST GO
 ;OFF-HOOK, WAIT 2 SECONDS, ASSUME A DIAL TONE IS
 ;PRESENT, THEN RETURN.

0AC4 C5	DLTONE: PUSH	B
0AC5 0E01	MVI C,1	
0AC7 CD290A	CALL SWHOOK	;GO OFF-HOOK
0ACA 0E28	MVI C,40	;40*50MS=2 SECONDS
0ACC CDA50A	CALL DELAY	;WAIT 2 SECONDS
0ACF C1	POP B	;RESTORE BC
0AD0 C9	RET	

;DIAL PULSE ROUTINE. DIALS THE DIGIT IN REGISTER C.
 ;IF C=0 THEN 10 PULSES WILL BE PRODUCED. THE DIGIT IN
 ;THE C REGISTER CAN BE BINARY OR ASCII. AFTER THE
 ;DIGIT IS OUT-PULSED THIS ROUTINE WILL PAUSE FOR 600 MS
 ;FOR INTER-DIGIT SPACING.

0AD1 C5	PULSE: PUSH	B	;SAVE BC
0AD2 79	MOV A,C		
0AD3 060A	MVI B,10		;PRE-LOAD PULSE COUNTER
0AD5 E60F	ANI 0FH		;KILL POSSIBLE ASCII BIAS
0AD7 FE00	CPI 0		;SEE IF WE'RE DOING 10 PULSES
0AD9 CADDOA	JZ PULS1		
0ADC 47	MOV B,A		;PULSE COUNT TO B
0ADD 0E00	PULS1: MVI C,0		;GO ON HOOK
0ADF CD290A	CALL SWHOOK		
0AE2 0E01	MVI C,1		
0AE4 CDA50A	CALL DELAY		;WAIT 50 MS
0AE7 0E01	MVI C,1		
0AE9 CD290A	CALL SWHOOK		;OFF HOOK AGAIN
0AEC 0E01	MVI C,1		
0AEE CDA50A	CALL DELAY		;WAIT 50 MS
0AF1 05	DCR B		;WE MADE 1 PULSE, COUNT IT
0AF2 C2DD0A	JNZ PULS1		;IF NOT ZERO, MAKE SOME MORE

0AF5 0E0B	MVI	C,11	;11*50 MS=550 MS
0AF7 CDA50A	CALL	DELAY	;INTER-DIGIT DELAY
0AFA C1	POP	B	;RESTORE BC REGISTERS
0AFB C9	RET		

;SETS BITS IN CONTROL REGISTER 2.
;ENTER WITH REG. A CONTAINING 1'S WHERE BITS ARE TO BE
;SET.

0AFC E5	SET2:	PUSH	H	;SAVE HL
0AFD 210110		LXI	H,MICR2	
0B00 B6		ORA	M	;OR IN BITS TO BE SET
0B01 77		MOV	M,A	
0B02 D382		OUT	CR2	;SET THE MODEM
0B04 E1		POP	H	
0B05 C9		RET		

;CLEAR BITS IN CONTROL REGISTER 2.
;REG. A HAS 1'S FOR BITS TO BE CLEARED.

0B06 E5	CLR2:	PUSH	H	
0B07 210110		LXI	H,MICR2	;MEMORY IMAGE OF CR2
0B0A 2F		CMA		
0B0B A6		ANA	M	;TURN OFF THE BIT
0B0C 77		MOV	M,A	;UPDATE MEMORY
0B0D D382		OUT	CR2	;WRITE TO CRL. REG. 2
0B0F E1		POP	H	;RESTORE HL
0B10 C9		RET		

;SET BITS IN CONTROL REGISTER 1.
;REG. A HAS 1'S IN BITS TO BE SET.

0B11 E5	SET1:	PUSH	H	
0B12 210010		LXI	H,MICR1	;POINT TO MEMORY IMAGE
0B15 B6		ORA	M	;OR IN THE BITS
0B16 77		MOV	M,A	;UPDATE MEMORY
0B17 D381		OUT	CRL	;WRITE TO MODEM
0B19 E1		POP	H	
0B1A C9		RET		

;CLEAR BITS IN CONTROL REGISTER 1
;REG. A HAS 1'S IN BITS TO BE CLEARED.

0B1B E5	CLR1:	PUSH	H	
0B1C 210010		LXI	H,MICR1	;POINT TO MEMORY IMAGE
0B1F 2F		CMA		;INVERT A
0B20 A6		ANA	M	;CLEAR BITS
0B21 77		MOV	M,A	;UPDATE MEMORY
0B22 D381		OUT	CRL	
0B24 E1		POP	H	
0B25 C9		RET		

;THIS AREA MUST BE R/W MEMORY.

1000	ORG	1000H	;RAM MEMORY AREA ;START OF RAM	
	SOR:			
1000	MICR1:	DS 1	;MEMORY IMAGE OF CONTROL REG. 1	
1001	MICR2:	DS 1	;MEMORY IMAGE OF CONTROL REG. 2	
1002	DPLX:	DS 1	;FULL DUPLEX FLAG 1=FULL 0=HALF	
1003	MFLAG:	DS 1	;0=ANSWER 1=ORIGINATE	
1004	JTAB:	DS 3	;CBIOS JUMP TABLE IS MOVED HERE	
1007	XCONST:	DS 3	;CONSOLE STATUS	
100A	XCONIN:	DS 3	;CONSOLE INPUT	
100D	XCONOT:	DS 3	;CONSOLE OUTPUT	
1010	NMBR:	DS 32	;32 BYTES PHONE NUMBER STORAGE	
1030	BUFPNT:	DS 2	;BUFFER POINTER STORAGE	
1032	CPFLAG:	DS 1	;CAPTURE FLAG 1=ON 0=OFF	
1033	BUGFLAG:	DS 1	;1=DEBUG MODE 0= NORMAL	
1034	BUGCOUNT:	DS 1	;COUNTS HEX BYTES PER LINE	
1035	MTOP:	DS 1	;TOP OF MEMORY (PAGE)	
1036	CBUFP:	DS 2	;CAPTURE BUFFER POINTER	
1038	CPCNT:	DS 2	;CAPTURED CHARACTER COUNTER	
	EOR:		;END OF RAM CHECKED BY CHECKSUM	
103A	CKSUM:	DS 1	;CHECKSUM STORED HERE	
103B				
107B	STACK:	DS 64	;64 BYTES FOR STACK	
107C	BUF:	DS 65	;CONSOLE BUFFER	
			;CPM FILE CONTROL BLOCK	
	FCB:			
10BD	ET:	DS 1	;ENTRY TYPE	
10BE	FNAME:	DS 8	;FILE NAME	
10C6	FTYPE:	DS 3	;FILE TYPE	
10C9	EX:	DS 3	;EXTENT	
10CC	RCC:	DS 1	;RECORD COUNT	
10CD	DM:	DS 16	;DISK MAP	
10DD	NR:	DS 1	;NEXT RECORD	
10DE	CPBUF:	DS 1	;CAPTURE BUFFER	
10DF		END	START	;THATS ALL

TITLE 'REMOTE CONSOLE FOR CP/M AND THE MICROMODEM 100'

;WRITTEN BY DALE HEATHERINGTON

;COPYRIGHT 1979, D.C. HAYES ASSOCIATES, INC.

;THIS PROGRAM ALLOWS THE USER TO IMPLEMENT THE
;MICROMODEM 100 AS AN ADDITIONAL CONSOLE FOR CP/M.
;IT WILL ONLY WORK WITH VERSION 1.4 BECAUSE IT
;DEPENDS ON THE SPECIAL FEATURE WHICH CHECKS THE
;CONSOLE BUFFER FOR A COMMAND JUST AFTER WARM BOOT.
;THE NAME OF THIS PROGRAM MUST BE IN THIS BUFFER SO
;IT WILL EXECUTE EACH TIME CP/M BOOTS UP. THE "INSTALL"
;PROGRAM TAKES CARE OF PUTTING THE NAME IN THE BUFFER.

;
;----- OPERATION -----
;

;WHEN CP/M BOOTS IT LOOKS IN ITS CONSOLE BUFFER. IT
;FINDS "REMOTE" AND LOADS IT. THIS PROGRAM THEN USES
;THE ADDRESS AT LOCATION 6 TO FIND OUT WHERE THE BOTTOM
;OF THE CCP (CONSOLE COMMAND PROCESSOR) IS. IT THEN
;RELOCATES ITSELF 512 BYTES BELOW THE CCP AND CHANGES
;THE ADDRESS AT LOCATION 6 TO INDICATE A NEW TOP OF USER
;MEMORY. IT THEN GETS THE FIRST 5 JUMPS FROM THE CBIOS
;JUMP TABLE AND MOVES THEM INTO ITS OWN MEMORY SPACE.
;THESE JUMPS ARE ALL THE CONSOLE FUNCTIONS. IT THEN
;PUTS JUMPS TO ITS OWN MICROMODEM 100 CONSOLE ROUTINES
;IN THE CBIOS JUMP TABLE. IT THEN RETURNS TO CP/M
;WHICH PUTS UP THE PROMPT A> .

;THE NEW CONSOLE STATUS ROUTINE CHECKS FOR PHONE RINGING
;AND CARRIER DETECT AS WELL AS MODEM CHARACTER RECEIVED.
;IT THEN USES THE OLD CBIOS CONSOLE STATUS VECTOR TO CONTINUE
;ON TO THE CBIOS ROUTINE.

;THE USER OF CP/M AT THE LOCAL CONSOLE WILL NOTICE NO
;DIFFERENCE IN THE OPERATION OF CP/M EXCEPT THAT LESS
;MEMORY WILL BE AVAILABLE FOR TRANSIENT PROGRAMS. ALSO
;"STAT" WILL ALWAYS RETURN 0 K BYTES LEFT FOR SOME
;UNKNOWN REASON. WHEN THE PHONE RINGS IT WILL ANSWER
;AND PUT A CARRIER ON THE LINE. THEN IT WAITS 15 SECONDS
;FOR THE CALLER TO SEND A CARRIER. IT HANGS UP IF NO
;CARRIER IS DETECTED. WHEN IT DETECTS A CARRIER IT
;REBOOTS CP/M SO THE CALLER WILL GET THE PROMPT A> .

;
;IF YOU WANT TO MAKE MODIFICATIONS TO THIS PROGRAM
;MAKE SURE YOU MARK ALL ADDRESS WHICH WILL BE RE-LOCATED
;WITH SOME LABEL AND PUT THAT LABEL IN THE RELOCATION TABLE.
;I USED "RL" FOLLOWED BY A DIGIT FOR LABELS WHOSE SOLE
;PURPOSE WAS TO MARK RELOCATED ADDRESSES.

0005 =	BDOS	EQU	5	;CP/M DOS ENTRY
0080 =	DATA	EQU	80H	;MODEM DATA PORT
0081 =	CCR1	EQU	DATA+1	;CONTROL AND STAT. REGISTER
0082 =	CCR2	EQU	DATA+2	;CONTROL REGISTER #2
0083 =	TIMER	EQU	DATA+3	;STARTS TIMER

;BIT FUNCTIONS

0001 =	EPE	EQU	1	;EVEN PARITY
0002 =	LS1	EQU	2	;LENGTH SELECT
0004 =	LS2	EQU	4	;LENGTH SELECT 2
0008 =	SBS	EQU	8	;STOP BITS
0010 =	PI	EQU	10H	;PARITY INHIBIT
0001 =	RRF	EQU	1	;CHARACTER RECEIVED
0002 =	TRE	EQU	2	;TRANSMITTER EMPTY
0004 =	PE	EQU	4	;PARITY ERROR
0008 =	FE	EQU	8	;FRAMING ERROR
0010 =	OE	EQU	10H	;OVERRUN ERROR
0020 =	TMR	EQU	20H	;TIMER STATUS 1=TIMED OUT
0040 =	CD	EQU	40H	;CARRIER DETECT
0080 =	RI	EQU	80H	;NOT RING DETECT
0001 =	BRS	EQU	1	;BAUD RATE (300)
0002 =	TXE	EQU	2	;TRANSMITTER ON
0004 =	MS	EQU	4	;MODE SELECT (ORIG)
0080 =	OH	EQU	80H	;OFF HOOK

0100 ORG 100H

0100 C30901	JMP	START	
0103 000000	DB	0,0,0	
0106 C30000	XBDOS:	DB	0C3H,0,0 ;BDOS VECTOR PLACED HERE
0109 CD7102	START:	CALL	SIGNON
010C DB81	IN	CCR1	
010E E640	ANI	CD	;LOOK FOR CARRIER DETECT
0110 C4D801	CNZ	ANSBAK	;SIGNON MESSAGE TO MODEM IF CD
0113 2A0600	LHLD	BDOS+1	;GET BASE OF BDOS
0116 1100F6	LXI	D,-0A00H	;LENGTH OF CCP+512
0119 19	DAD	D	
011A EB	XCHG		;BASE OF CCP -512 TO DE
011B 2A0600	LHLD	BDOS+1	
011E E5	PUSH	H	
011F EB	XCHG		
0120 220600	SHLD	BDOS+1	;NEW JUMP VECTOR FOR BDOS

CP/M MACRO ASSEM 2.0 #003 REMOTE CONSOLE FOR CP/M AND THE MICROMODEM 100

PAGE

0123 E1 POP H ;RECOVER OLD VECTOR
0124 220701 SHLD XBDOS+1

;ADD THE RELOCATION CONSTANT TO ALL ADDRESSES IN TABLE

0127 2A0600	LHLD	6	;GET NEW BDOS ENTRY
012A 11FAFF	LXI	D,-6	
012D 19	DAD	D	;SUBTRACT 6
012E 1100FF	LXI	D,-256	
0131 19	DAD	D	
0132 223702	SHLD	OFFSET	;STORE IT
0135 213D02	LXI	H, TABLE	
0138 223902	SHLD	'1:BLPNT	;STORE TABLE POINTER
013B 2A3902	ADD1: LHLD	TBLPNT	;GET POINTER
013E 5E	MOV	E,M	;GET LOW BYTE
013F 23	INX	H	
0140 56	MOV	D,M	;GET HIGH BYTE
0141 7B	MOV	A,E	
0142 B2	ORA	D	;TEST FOR 0 (END OF TABLE)
0143 CA5C01	JZ	MOVIT	
0146 23	INX	H	;INC. POINTER
0147 223902	SHLD	TBLPNT	;SAVE TABLE POINTER
014A EB	XCHG		;ADDRESS TO MODIFY TO HL
014B 23	INX	H	;POINT TO ADDRESS FIELD
014C 5E	MOV	E,M	;GET ADDRESS
014D 23	INX	H	
014E 56	MOV	D,M	
014F E5	PUSH	H	;SAVE POINTER
0150 2A3702	LHLD	OFFSET	;GET OFFSET
0153 19	DAD	D	;ADD IT TO ADDRESS
0154 EB	XCHG		;MODIFIED ADR. BACK TO DE
0155 E1	POP	H	;RECOVER POINTER
0156 72	MOV	M,D	;PUT ADDRESS BACK IN MEM.
0157 2B	DCX	H	
0158 73	MOV	M,E	
0159 C33B01	JMP	ADD1	;LOOP

;MOVE THIS PROGRAM UP UNDER THE CCP

015C 010002	MOVIT: LXI	B,512	
015F 2A3702	LHLD	OFFSET	
0162 110001	LXI	D,256	
0165 19	DAD	D	
0166 223B02	SHLD	SADDR	;RELOCATED STARTING ADDRESS
0169 1A	MV1: LDAX	D	
016A 77	MOV	M,A	
016B 23	INX	H	
016C 13	INX	D	
016D 0B	DCX	B	
016E 79	MOV	A,C	
016F B0	ORA	B	
0170 C26901	JNZ	MV1	;MOVE 512 BYTES
0173 C37601	RLL1: JMP	\$+3	;START EXECUTING RELOCATED CODE

;EXCHANGE THE BIOS JUMP TABLE WITH OUR SPECIAL TABLE.

```

0176 2A0100      LHLD   1      ;GET CBIOS ADDRESS
0179 2B          DCX    H
017A 2B          DCX    H
017B 2B          DCX    H
017C 112802      RL2:   LXI   D,XBOOT
017F 060F          MVI   B,15   ;15 BYTES OF JUMP TABLE TO MOVE
0181 4E          MV3:   MOV   C,M    ;GET A CBIOS BYTE
0182 1A          LDAX   D      ;GET OUR BYTE
0183 77          MOV   M,A    ;PUT OUR BYTE IN CBIOS
0184 79          MOV   A,C
0185 12          STAX   D      ;PUT CBIOS BYTE IN OUR TABLE
0186 13          INX    D
0187 23          INX    H
0188 05          DCR    B
0189 C28101      RL3:   JNZ   MV3   ;LOOP 15 TIMES
018C C9          RET
                                ;BACK TO CPM

018D CD7301      BOOT:  CALL  RL1   ;EXCHANGE JUMP TABLES
0190 2A0100      LHLD   1
0193 2B          DCX    H
0194 2B          DCX    H
0195 2B          DCX    H
0196 E9          PCHL
                                ;DO CPM BOOT

0197 CD7301      WBOOT: CALL  RL1
019A C30000      JMP    0

```

S ;THIS IS THE CONSOLE STATUS CHECK ROUTINE FOR THE
;MODEM. IT ALSO CHECKS FOR CARRIER DETECT AND RINGING.
;WHEN FINISHED IT GOES TO THE ORIGINAL CBIOS ROUTINE.

```

019D DB81        CONST: IN    CCR1   ;CHECK FOR CHAR. IN MODEM
019F E601        ANI    RRF
01A1 3EFF        MVI    A,255
01A3 C0          RNZ
01A4 DB81        IN    CCR1   ;RET. 255 IF TRUE
01A6 E640        ANI    CD
01A8 C2AF01      RL5:   JNZ   CK1
01AB 3E00        MVI    A,0
01AD D382        OUT   CCR2   ;NO CARRIER, HANG UP
01AF DB81        CK1:   IN    CCR1   ;TEST FOR RING
01B1 E680        ANI    RI
01B3 C22E02      RL0:   JNZ   XCONST ;IF NO RING GO TO LOCAL CONSOLE
01B6 3E83        MVI    A,OH+TXE+BRS ;ANSWER THE PHONE
01B8 D382        OUT   CCR2
01BA 3E16        MVI    A,PI+LS1+LS2
01BC D381        OUT   CCR1   ;8 DATA, 1 STOP, NO PARITY
01BE DB80        IN    DATA   ;CLEAR OUT UART
01C0 DB80        IN    DATA
01C2 0696        MVI    B,150  ;WAIT 15 SECONDS FOR CARRIER
01C4 CDE701      RL7:   CALL  WAIT100 ;100 MS WAIT
01C7 DB81        IN    CCR1
01C9 E640        ANI    CD      ;LOOK FOR CARRIER

```

01CB C20000	JNZ	0	;WARM BOOT CP/M
01CE 05	DCR	B	
01CF C2C401	RL9:	JNZ	RL7
01D2 AF		XRA	A
01D3 D382		OUT	CCR2
01D5 C32E02	RL10:	JMP	XCONST

;THIS ROUTINE SENDS THE SIGN ON MESSAGE TO THE MODEM.
;IT IS ONLY CALLED ONCE BEFORE IT IS MOVED AND NEVER
;AGAIN. ITS ADDRESSES ARE NOT RELOCATED.

01D8 217A02	ANSRAK:	LXI	H,MSG	;POINT TO MESSAGE
01DB 7E	ANSB1:	MOV	A,M	;GET CHAR.
01DC FE24		CPI	'\$'	;END?
01DE C8		RZ		;QUIT WHEN DONE
01DF 4F		MOV	C,A	
01E0 CD1D02		CALL	C01	;SEND TO MODEM
01E3 23		INX	H	
01E4 C3DB01		JMP	ANSB1	

;WAIT 100 MS BEFORE RETURNING

01E7 CDEA01	WAIT100:	CALL	WAIT50	
01EA D383	WAIT50:	OUT	TIMER	;START 50 MS TIMER
01EC F5		PUSH	PSW	
01ED DB81	WAL:	IN	CCR1	
01EF E620		ANI	TMR	;IS TIME UP?
01F1 CAED01	RL11:	JZ	WAL	;LOOP IF NOT
01F4 F1		POP	PSW	
01F5 C9		RET		

01F6 CD9D01	CONIN:	CALL	CONST	;SEE IF ANY DATA READY
01F9 B7		ORA	A	
01FA CAF601	RL14:	JZ	CONIN	;NO, WAIT UNTIL IT IS
01FD DB81		IN	CCR1	
01FF E601		ANI	RRF	;FROM MODEM?
0201 CA3102	RL15:	JZ	XCONIN	;NO, MUST BE LOCAL CONSOLE
0204 DB80		IN	DATA	
0206 C9		RET		

;THIS IS THE CONSOLE OUTPUT ROUTINE. FOR THE
;USERS WHO MAY CALL IN WITH PRINTERS IT WILL
;DELAY 100 MS AFTER ALL LINE FEEDS.

0207 79	CONOUT:	MOV	A,C
0208 2F		CMA	
0209 D3FF		OUT	255
020B DB81		IN	CCR1 ; LOOK FOR CARRIER
020D E640		ANI	CD.
020F CA3402	RL12:	JZ	XCONOUT ; BYPASS IF NO CARRIER
0212 CD1D02	RL15:	CALL	CO1 ; OUTPUT THE CHARACTER
0215 FE0A		CPI	0AH ; WAS IT A LINE FEED
0217 CCE701	RL17:	CZ	WAIT100 ; WAIT 100 MS IF LINE FEED
021A C33402	RL6:	JMP	XCONOUT ; OUT TO LOCAL CONSOLE
021D DB81	CO1:	IN	CCR1
021F E602		ANI	TRE
0221 CA1D02	RL13:	JZ	CO1 ; LOOP UNTIL TX EMPTY
0224 79		MOV	A,C ; GET CHARACTER
0225 D380		OUT	DATA ; TO MODEM
0227 C9		RET	

;THESE 5 JUMPS ARE EXCHANGED WITH THE FIRST 5 JUMPS
;IN THE CBIOS JUMP TABLE.

0228 C38D01	XBOOT:	JMP	BOOT
022B C39701	XWBOOT:	JMP	WBOOT
022E C39D01	XCONST:	JMP	CONST
0231 C3F601	XCONIN:	JMP	CONIN
0234 C30702	XCONOUT:	JMP	CONOUT

;SOME STORAGE LOCATIONS

0237	OFFSET:	DS	2
0239	TBLPNT:	DS	2
023B	SADDR:	DS	2

;TABLE OF ADDRESSES TO ADD RELOCATION CONSTANT TO.

023D B3017301	TABLE:	DW	RL0,RL1
0241 7C018901A8		DW	RL2,RL3,RL5,RL6,RL7,RL9,RL10
024F F1010F0221		DW	RL11,RL12,RL13
0255 FA010102		DW	RL14,RL15
0259 12021702		DW	RL16,RL17
025D 8D019701E7		DW	BOOT,WBOOT,WAIT100
0263 F601		DW	CONIN
0265 28022B022E		DW	XBOOT,XWBOOT,XCONST
026B 31023402		DW	XCONIN,XCONOUT
026F 0000		DW	0

;PRINTS SIGN ON MESSAGE. THIS CODE IS NOT RELOCATED

0271 117A02 SIGNON: LXI D,MSG ;POINT TO MESSAGE
0274 0E09 MVI C,9 ;PRINT BUFFER CODE
0276 CD0500 CALL 5 ;CALL BDOS
0279 C9 RET

027A 442E432E20MSG: DB 'D.C. HAYES ASSOCIATES, INC.',0DH,0AH
0297 4D4943524F DB 'MICROMODEM 100 REMOTE CONSOLE VER. 1.0',0DH,0AH,'\$'

02C0 END 100H ;GOOD LUCK

TITLE 'INSTALL OR REMOVE REMOTE CONSOLE'

;THIS PROGRAM WILL INSTALL OR REMOVE
;REMOTE CONSOLE IN 1.4 CP/M.
;NAME: INSTALL.ASM

;WRITTEN BY DALE HEATHERINGTON
;
;COPYRIGHT 1979, D.C. HAYES ASSOCIATES, INC.

;THIS PROGRAM ONLY WORKS WITH VERSION 1.4 CP/M.
;IT LOADS THE FIRST 128 BYTES OF THE CP/M CCP MODULE
;INTO RAM AT 80 HEX. THIS IS ASSUMED TO BE ON TRACK ZERO,
;SECTOR 2. IF THE USER TYPES "I" TO INSTALL REMOTE CONSOLE
;THE PROGRAM WILL INSERT "REMOTE" INTO THE CCP CONSOLE BUFFER
;ALONG WITH IT LENGTH, 6. IT THEN WRITES THIS MODIFIED SECTOR
;OF THE CCP BACK TO THE DISK. "REMOVE" WORKS THE SAME
;EXCEPT THAT IT SETS THE LENGTH TO 0 AND WRITES 6 SPACES TO
;THE CONSOLE BUFFER.
;
; WHEN CP/M WARM BOOTS IT CHECKS THE CONSOLE BUFFER TO SEE
;IF IT HAS ANY THING IN IT. IF IT DOES CP/M READS IT AND
;PERFORMS THE FUNCTION. IN THIS CASE IT WILL LOAD AND EXECUTE
;THE FILE "REMOTE.COM", THE REMOTE CONSOLE PROGRAM.

0100		ORG 100H	
0005 =	BDOS	EQU 5	
0082 =	CR2	EQU 82H	;MICROMODEM 100 CONTROL REGISTER 2
000D =	CR	EQU 0DH	;ASCII CARRAGE RETURN
0100 C33001		JMP	START

;THE CBIOS JUMP TABLE IS MOVED HERE

0103	BOOT:	DS	3
0106	WBOOT:	DS	3
0109	CONST:	DS	3
010C	CONIN:	DS	3
010F	CONOUT:	DS	3
0112	LIST:	DS	3
0115	PUNCH:	DS	3
0118	READER:	DS	3
011B	HOME:	DS	3
011E	SELDSK:	DS	3
0121	SETTRK:	DS	3
0124	SETSEC:	DS	3
0127	SETDMA:	DS	3
012A	READ:	DS	3
012D	WRITE:	DS	3
0130 314F03	START:	LXI	SP,STACK

0133 2A0100	LHLD	I	;GET WARM BOOT ADDRESS
0136 2B	DCX	H	
0137 2B	DCX	H	
0138 2B	DCX	H	
0139 110301	LXI	D,BOOT	;DESTINATION ADDRESS
013C 062D	MVI	B,15*3	;NUMBER OF BYTES TO MOVE
013E CD0101	CALL	MOVE	;MOVE THE CBIOS JUMP TABLE
0141 018000	LXI	B,80H	
0144 CD2701	CALL	SETDMA	;SET DMA ADDRESS TO 80H
0147 0E00	MVI	C,0	
0149 CD2101	CALL	SETTRK	;SET TRACK TO 0
014C 0E02	MVI	C,2	
014E CD2401	CALL	SETSEC	;SET SECTOR TO 2
0151 CD2A01	CALL	READ	;READ IN FIRST SECTOR OF CPM
0154 CD9D01	QQ:	CALL	PRINT
0157 494E535441	DB	'INSTALL OR REMOVE ? (I OR R)',CR	
0174 CD8401	CALL	INPUT	;GET REPLY
0177 FE49	CPI	'I'	
0179 CAD601	JZ	INSTALL	
017C FE52	CPI	'R'	
017E CA0B02	JZ	REMOVE	
0181 C35401	JMP	QQ	

;CONSOLE INPUT ROUTINE

0184 E5	INPUT:	PUSH	H
0185 D5		PUSH	D
0186 C5		PUSH	B
0187 0E01		MVI	C,1
0189 CD0500		CALL	5
018C 7B		MOV	A,E
018D FE60		CPI	60H
018F DA9401		JC	IN1
0192 D620		SUI	20H
0194 C1	IN1:	POP	B
0195 D1		POP	D
0196 E1		POP	H
0197 C9		RET	
0198 CD9D01	CRLF:	CALL	PRINT
019B 0D		DB	CR
019C C9		RET	

;PRINTS ASCII STRINGS POINTED TO BY TOP OF STACK
; TO CONSOLE.

019D E3	PRINT:	XTHL	;GET STRING POINTER
019E F5		PUSH	PSW
019F C5		PUSH	B
01A0 7E	PO1:	MOV	A,M
01A1 23		INX	H
01A2 FE40		CPI	'@'
01A4 CAB0A1		JZ	NOCR
01A7 CDBE01		CALL	COUT

01AA FE0D	CPI	CR ;CARRAGE RET?
01AC CAB201	JZ	THEEND
01AF C3A001	JMP	P01
01B2 CD9D01	THEEND:	CALL PRINT
01B5 0A00000040	DB	0AH,0,0,0,'@'
01BA C1	NOCR:	POP B
01BB F1		POP PSW
01BC E3		XTHL
01BD C9		RET

;CONSOLE OUTPUT ROUTINE

01BE F5	COUT:	PUSH PSW
01BF C5		PUSH B
01C0 D5		PUSH D
01C1 E5		PUSH H
01C2 5F	MOV	E,A
01C3 0E02	MVI	C,2 ;WRITE CONSOLE
01C5 CD0500	CALL	5
01C8 E1	POP	H
01C9 D1	POP	D
01CA C1	POP	B
01CB F1	POP	PSW
01CC C9		RET

;GENERAL PURPOSE MEMORY TO MEMORY BLOCK MOVE ROUTINE
; HL POINT TO THE SOURCE, DE POINT TO THE DESTINATION
; THE B REGISTER HAS THE COUNT.

01CD 7E	MOVE:	MOV A,M
01CE 12		STAX D
01CF 23		INX H
01D0 13		INX D
01D1 05		DCR B
01D2 C2CD01		JNZ MOVE
01D5 C9		RET

;THIS ROUTINE PUTS "REMOTE" INTO THE CCP CONSOLE BUFFER

INSTALL:

01D6 214102	LXI	H,INSTL
01D9 118700	LXI	D,87H
01DC 0607	MVI	B,7
01DE C2CD01	CALL	MOVE
01E1 CD2D01	CALL	WRITE ;WRITE SECTOR TO DISK
01E4 CD9801	CALL	CRLF
01E7 CD9D01	CALL	PRINT
01EA 43502F4D20	DB	'CP/M REMOTE CONSOLE INSTALLED',CR
0208 C30000	JMP	0

;THIS ROUTINE CLEARS THE CCP CONSOLE BUFFER

020B 214802	REMOVE:	LXI	H,REMV
020E 118700		LXI	D,87H
0211 0607		MVI	B,7
0213 CDCD01		CALL	MOVE
0216 CD2D01		CALL	WRITE
0219 CD9801		CALL	CRLF
021C CD9D01		CALL	PRINT
021F 43502F4D20		DB	'CP/M REMOTE CONSOLE REMOVED',CR
023B AF		XRA	A ;ZERO A
023C D382		OUT	CR2 ;MAKE SURE MODEM PHONE LINE IS HUNG UP
023E C30000		JMP	0


;THESE ARE THE STRINGS WHICH ARE PUT IN THE
;CCP CONSOLE BUFFER

0241 0652454D4FINSTL: DB 6,'REMOTE'

0248 0020202020REMV: DB 0,' '

024F DS 256
STACK:

034F END 100H



© 1982 D.C. Hayes Associates, Inc.
 D.C. HAYES ASSOCIATES, INC.
 1000 N.W. 21ST AVENUE
 MIAMI, FLORIDA 33126
 305/634-2222
 2 OF 2
 83 003

