

ATARI®400/800™

ATARI® HOME COMPUTER SYSTEM

**OPERATING SYSTEM
SOURCE LISTING**



A Warner Communications Company 

COPYRIGHT 1982, ATARI, INC.
ALL RIGHTS RESERVED

TO ALL PERSONS RECEIVING THIS DOCUMENT

**Reproduction is forbidden without the specific written permission of
ATARI, INC. Sunnyvale, CA 94086. No right to reproduce this document,
nor the subject matter thereof, is granted unless by written agreement with,
or written permission from the Corporation.**

Every effort has been made to ensure that this manual accurately documents this product of the ATARI Home Computer Division. However, due to the ongoing improvement and update of the computer software and hardware, ATARI, INC. cannot guarantee the accuracy of printed material after the date of publication and disclaims liability for changes, errors, or omissions.

1 ERR LINE ADDR B1 B2 B3 B4
2 6500 ASSEMBLER VER 1.0MR
3
4
5
6
7
8
9

(LIST X
| THIS IS THE MODIFIED SEPTEMBER ATARI 400/800 COMPUTER OPERATING
| SYSTEM LISTING, MODIFIED TO ASSEMBLE ON THE MICROTEC CROSS
| ASSEMBLER
| THIS VERSION IS THE ONE WHICH WAS BURNED INTO ROM.
| THERE IS A RESIDUAL PIECE OF CODE WHICH IS FOR LDEBUG. THIS
| IS AT LOCATION \$9000 WHICH IS NOT IN ROM.
| THIS IS THE REVISION B EPROM VERSION

1 PAGE 1

ERR LINE ADDR B1 B2 B3 B4

6500 ASSEMBLER VER 1. OMR

PAGE 2

10

PAGE
A

COLLEEN OPERATING SYSTEM EQUATE FILE

NTSC/PAL ASSEMBLY FLAG

PALFLG = 0 0 = NTSC 1 = PAL

MODULE ORIGIN TABLE

```

; CHARACTER SET           $E000
; VECTOR TABLE           $E400
; RAM VECTOR INITIAL     $E480
; CENTRAL I/O HANDLE     $E4A6
; INTERRUPT HANDLER      $E6D5
; SERIAL I/O DRIVER       $E944
; DISK HANDLER            $EDEA
; PRINTER HANDLER         $EE78
; CASSETTE HANDLER        $EF41
; MONITOR/POWER UP M       $FOE3
; KEYBOARD/DISPLAY H       $F3E4
; KBDORG = E000
; VECTBL = E400
; VCTABL = E480
; CIIDORG = E4A6
; INTORG = E6D5
; SIIDORG = E944
; DSKORG = $EDEA
; PRNDRG = $EE78
; CASORG = $EF41
; MONDRG = $FOE3
; KBDDRG = $F3E4

```

333

VECTOR TABLE
HANDLER ENTRY POINTS ARE CALLED OUT IN THE FOLLOWING VECTOR TABLE. THESE ARE THE ADDRESSES MINUS ONE.

```

; EXAMPLE FOR EDITOR
E400    OPEN
        2     CLOSE
        4     GET
        6     PUT
        8     STATUS
        A     SPECIAL
        C     JUMP TO POWER ON INITIALIZATION ROUTINE
        E     NOT USED

```

```

EDITOR      = $E400 ; EDITOR
SCREEN     = $E410 ; TELEVISION SCREEN
KEYBDV    = $E420 ; KEYBOARD
PRINTER   = $E430 ; PRINTER

```

JUMP VECTOR TABLE

ERR LINE	ADDR	B1	B2	B3	B4
64					
65	E450				
66	E453				
67	E456				
68	E459				
69	E45C				
70	E45F				
71	E462				
72	E465				
73	E468				
74	E46B				
75	E46E				
76	E471				
77	E474				
78	E477				
79	E47A				
80	E47D				
81					
82					
83					
84					
85					
86					
87					
88	0003				
89	0005				
90	0007				
91	0009				
92	000B				
93	000C				
94	000D				
95	000E				
96					
97					
98	0011				
99	0012				
100	0020				
101	0021				
102	0022				
103	0023				
104	0024				
105	0025				
106	0026				
107	00FF				
108					
109					
110					
111	0001				
112	0002				
113	0004				
114	0008				
115	000C				
116	0010				
117	0022				

```

; TO VARIOUS ENTRY POINTS IN THE OPERATING SYSTEM.

DISKIV    = $E450      ; DISK INITIALIZATION
DSKINV   = $E453      ; DISK INTERFACE
CIOV     = $E456      ; CENTRAL INPUT OUTPUT
SIOV     = $E459      ; SERIAL INPUT OUTPUT
SETVBV   = $E45C      ; SET SYSTEM TIMERS ROM
SYSVBV   = $E45F      ; SYSTEM VERTICAL BLANK
XITVBV   = $E462      ; EXIT VERTICAL BLANK
SIOINV   = $E465      ; SERIAL INPUT OUTPUT
SENDEV   = $E468      ; SEND ENABLE ROUTINE
INTINV   = $E46B      ; INTERRUPT HANDLER IN
CIOINV   = $E46E      ; CENTRAL INPUT OUTPUT
BLKBVDV = $E471      ; BLACKBOARD MODE
WARMSV   = $E474      ; WARM START ENTRY POI
MARDSV   = $E477      ; COLD START ENTRY POI
RBLQKV   = $E47A      ; CASSETTE READ BLOCK
CSOPIV   = $E47D      ; CASSETTE OPEN FOR IN

;
; OPERATING SYSTEM EQUATES

; COMMAND CODES FOR IOCB
OPEN     = 3          ; OPEN FOR INPUT/OUTPUT
GETREC   = 5          ; GET RECORD (TEXT)
GETCHR   = 7          ; GET CHARACTER(S)
PUTREC   = 9          ; PUT RECORD (TEXT)
PUTCHR   = $B          ; PUT CHARACTER(S)
CLOSE    = $C          ; CLOSE DEVICE
STATIS   = $D          ; STATUS REQUEST
SPECIL   = $E          ; BEGINNING OF SPECIAL

; SPECIAL ENTRY COMMANDS
DRAWLN  = $11         ; DRAW LINE
FILLIN   = $12         ; DRAW LINE WITH RIGHT
RENAME   = $20         ; RENAME DISK FILE
DELETE   = $21         ; DELETE DISK FILE
FORMAT   = $22         ; FORMAT
LOCKFL  = $23         ; LOCK FILE TO READ ON
UNLOCK  = $24         ; UNLOCK LOCKED FILE
POINT   = $25         ; POINT SECTOR
NOTE    = $26         ; NOTE SECTOR
IOCFRE  = $FF         ; IOCB "FREE"

; AUX1 EQUATES
; (0) INDICATES WHICH DEVICES USE BIT
APPEND  = $1          ; OPEN FOR WRITE APPEND
DIRECT  = $2          ; OPEN FOR DIRECTORY A
OPNIN   = $4          ; OPEN FOR INPUT (ALL)
OPNOT   = $8          ; OPEN FOR OUTPUT (ALL)
OPNIN+OPNOT = $10      ; OPEN FOR INPUT AND OUTPUT
OPNINO  = $10         ; OPEN FOR MIXED MODE
OPMDM2D = $10         ; OPEN FOR MIXED MODE

```

```

PAGE 3
$5500 ASSEMBLER VER 1.0.MR

; ENTRY POINTS IN THE OPERATING SYSTEM.

; $E450          ; DISK INITIALIZATION
; $E453          ; DISK INTERFACE
; $E456          ; CENTRAL INPUT OUTPUT ROUTINE
; $E459          ; SERIAL INPUT OUTPUT ROUTINE
; $E45C          ; SET SYSTEM TIMERS ROUTINE
; $E45F          ; SYSTEM VERTICAL BLANK CALCULATIONS
; $E462          ; EXIT VERTICAL BLANK CALCULATIONS
; $E465          ; SERIAL INPUT OUTPUT INITIALIZATION
; $E468          ; SEND ENABLE ROUTINE
; $E46B          ; INTERRUPT HANDLER INITIALIZATION
; $E46E          ; CENTRAL INPUT OUTPUT INITIALIZATION
; $E471          ; BLACKBOARD MODE
; $E474          ; WARM START ENTRY POINT
; $E477          ; COLD START ENTRY POINT
; $E47A          ; CASSETTE READ BLOCK ENTRY POINT VECTOR
; $E47D          ; CASSETTE OPEN FOR INPUT VECTOR

; EM EQUATES

FOR IDCB
    3          ; OPEN FOR INPUT/OUTPUT
    5          ; GET RECORD (TEXT)
    7          ; GET CHARACTER(S)
    9          ; PUT RECORD (TEXT)
    $B          ; PUT CHARACTER(S)
    $C          ; CLOSE DEVICE
    $D          ; STATUS REQUEST
    $E          ; BEGINNING OF SPECIAL ENTRY COMMANDS

COMMANDS
    $11         ; DRAW LINE
    $12         ; DRAW LINE WITH RIGHT FILL
    $20         ; RENAME DISK FILE
    $21         ; DELETE DISK FILE
    $22         ; FORMAT
    $23         ; LOCK FILE TO READ ONLY
    $24         ; UNLOCK LOCKED FILE
    $25         ; POINT SECTOR
    $26         ; NOTE SECTOR
    $FF         ; IOC8 "FREE"

; WHICH DEVICES USE BIT
    $1          ; OPEN FOR WRITE APPEND (D), OR SCREEN READ
    $2          ; OPEN FOR DIRECTORY ACCESS (D)
    $4          ; OPEN FOR INPUT (ALL DEVICES)
    $8          ; OPEN FOR OUTPUT (ALL DEVICES)
    $0FFN+OPNOT ; OPEN FOR INPUT AND OUTPUT (ALL DEVICES)
    $10         ; OPEN FOR MIXED MODE (E,S)

```

ERR LINE ADDR B1 B2 B3 B4

6500 ASSEMBLER VER 1.0MR

PAGE 4

```

118
119      ; DEVICE NAMES
120      SCREDT = 'E          ; SCREEN EDITOR (R/W)
121      KBD    = 'K          ; KEYBOARD (R ONLY)
122      DISPLAY = 'S         ; SCREEN DISPLAY (R/W)
123      PRINTR = 'P         ; PRINTER (W ONLY)
124      CASSET = 'C         ; CASSETTE
125      MODEM = 'M         ; MODEM
126      DISK   = 'D         ; DISK (R/W)
127
128      ; SYSTEM EOL (CARRIAGE RETURN)
129      CR    = '$9B
130
131
132
133      ; OPERATING SYSTEM STATUS CODES
134      0001
135
136      0080
137      0081
138      0082
139      0083
140      0084
141      0085
142      0086
143      0087
144      0088
145      0089
146      008A
147      008B
148      008C
149      00BD
150      00BE
151      00BF
152
153      0090
154      0091
155      0092
156      0093
157
158
159
160
161
162
163
164
165      0000
166
167
168
169      0002
170      0004
171      0006

; PAGE ZERO RAM ASSIGNMENTS
; LINZBS: .RES 2      ; LINBUG RAM (WILL BE REPLACED BY MONITOR RAM)

; THESE LOCATIONS ARE NOT CLEARED
; CASINI: .RES 2      ; CASSETTE INIT LOCATION
; RAMLD: .RES 2        ; RAM POINTER FOR MEMORY TEST
; TRAMSZ: .RES 1        ; TEMPORARY REGISTER FOR RAM SIZE

```

ERR LINE	ADDR	B1	B2	B3	B4
172	0007				
173	174	0010			
174	175	0008			
175	176	0009			
176	177	0004			
177	178	000C			
178	179	000E			
179	180				
180	181				
181	182				
182	183	0010			
183	184	0011			
184	185	0012			
185	186				
186	187	0015			
187	188				
188	189	0017			
189	190				
190	191	0018			
191	192	001A			
192	193				
193	194	001C			
194	195	001D			
195	196	001E			
196	197	001F			
197	198				
198	199	0020			
199	200	0010			
200	201	0080			
201	202	0020			
202	203	0020			
203	204	0021			
204	205	0022			
205	206	0023			
206	207	0024			
207	208	0025			
208	209	0026			
209	210	0027			
210	211	0028			
211	212	0029			
212	213	002A			
213	214	002B			
214	215	002C			
215	216	002E			
216	217	002F			
217	218				
218	219	0030			
219	220	0031			
220	221	0032			
221	222	0033			
222	223	0034			
223	224	0035			
224	225	0036			

```

PAGE
6500 ASSEMBLER VER 1.0MR
1 ; RAM TEST DATA REGISTER

COLDSTART ONLY
1   1 ; WARM START FLAG
1   1 ; SUCCESSFUL BOOT FLAG
2   2 ; DISK SOFTWARE START VECTOR
2   2 ; DISK SOFTWARE INIT ADDRESS
2   2 ; APPLICATIONS MEMORY HI LIMIT

COLD OR WARM START
1   ; INTERRUPT HANDLER
1   ; SYSTEM MASK FOR POKEY IRQ ENABLE
1   ; BREAK KEY FLAG
3   3 ; REAL TIME CLOCK (IN 16 MSEC UNITS)

2   2 ; INDIRECT BUFFER ADDRESS REGISTER

1   ; COMMAND FOR VECTOR

2   2 ; DISK FILE MANAGER POINTER
2   ; DISK UTILITIES POINTER

1   ; PRINTER TIME OUT REGISTER
1   ; PRINT BUFFER POINTER
1   ; PRINT BUFFER SIZE
1   ; TEMPORARY REGISTER

16  ; ZERO PAGE I/O CONTROL BLOCK
8*IOCBSZ ; NUMBER OF BYTES PER IOCB
           ; LENGTH OF THE IOCB AREA

1   ; HANDLER INDEX NUMBER (FF = IOCB FREE)
1   ; DEVICE NUMBER (DRIVE NUMBER)
1   ; COMMAND CODE
1   ; STATUS OF LAST IOCB ACTION
1   ; BUFFER ADDRESS LOW BYTE
1   ; PUT BYTE ROUTINE ADDRESS - 1
1   ; BUFFER LENGTH LOW BYTE
1   ; AUXILIARY INFORMATION FIRST BYTE

1   4 ; TWO SPARE BYTES (CIO LOCAL USE)
     ; IOCB NUMBER X 16
     ; CHARACTER BYTE FOR CURRENT OPERATION

1   ; INTERNAL STATUS STORAGE
1   ; CHECKSUM (SINGLE BYTE SUM WITH CARRY)
1   ; POINTER TO DATA BUFFER (LO BYTE)
1   ; POINTER TO DATA BUFFER (HI BYTE)
1   ; NEXT BYTE PAST END OF THE DATA BUFFER
1   ; NEXT BYTE PAST END OF THE DATA BUFFER
1   ; NUMBER OF COMMAND FRAME RETRIES

```

ERR LINE	ADDR	B1	B2	B3	B4
226	0037				
227	0038	DRETRY:	.RES	1	; NUMBER OF DEVICE RETRIES
228	0039	BUFRFL:	.RES	1	; DATA BUFFER FULL FLAG
229	003A	RECVDN:	.RES	1	; RECEIVE DONE FLAG
230	003B	XMTDNN:	.RES	1	; TRANSMISSION DONE FLAG
231	003C	CHKSNT:	.RES	1	; CHECKSUM SENT FLAG
232	233	NOCKSM:	.RES	1	; NO CHECKSUM FOLLOWS DATA FLAG
234	003D				
235	003E	BPTR:	.RES	1	
236	003F	FTYPE:	.RES	1	
237	0040	FE0F:	.RES	1	
238	0041	FREQ:	.RES	1	
239	0042	SOUNDR:	.RES	1	; NOISY I/O FLAG. (ZERO IS QUIET)
240		CRITIC:	.RES	1	; DEFINES CRITICAL SECTION (CRITICAL IF NON-Z)
241	0043	FMSZPG:	.RES	7	; DISK FILE MANAGER SYSTEM ZERO PAGE
242	243				
244	004A	CKEY:	.RES	1	; FLAG SET WHEN GAME START PRESSED
245	004B	CASSBT:	.RES	1	; CASSETTE BOOT FLAG
246	004C	DSTAT:	.RES	1	; DISPLAY STATUS
247	248				
248	004D	ATTRACT:	.RES	1	; ATTRACT FLAG
249	004E	DRKMSK:	.RES	1	; DARK ATTRACT MASK
250	004F	COLRSH:	.RES	1	; ATTRACT COLOR SHIFTER (EOR'ED WITH PLAYFIELD
251	252				
252	0002	LEDGE	=	2	; LMARGIN'S VALUE AT COLD START
253	0027	REDGE	=	39	; RMARGIN'S VALUE AT COLD START
254	0050	TMPCHR:	.RES	1	
255	0051	HOLD1:	.RES	1	
256	0052	LMARGIN:	.RES	1	; LEFT MARGIN (SET TO 1 AT POWER ON)
257	0053	RMARGIN:	.RES	1	; RIGHT MARGIN (SET TO 38 AT POWER ON)
258	0054	ROWCRS:	.RES	1	; CURSOR COUNTERS
259	0055	COLCRS:	.RES	2	
260	0057	DINDEX:	.RES	1	
261	0058	SAVMSCL:	.RES	2	
262	005A	OLDROW:	.RES	1	
263	005B	OLDCOL:	.RES	2	
264	005D	OLDCHR:	.RES	1	
265	005E	OLDADR:	.RES	2	
266	0060	NEWROW:	.RES	1	; POINT DRAW GOES TO
267	0061	NEWCOL:	.RES	2	
268	0063	LOGCOL:	.RES	1	; POINTS AT COLUMN IN LOGICAL LINE
269	0064	ADRES:	.RES	2	
270	0066	MLTTMP:	.RES	2	
271	0066	OPNTP:	=	MLTTMP	; FIRST BYTE IS USED IN OPEN AS TEMP
272	0068	SAVADR:	.RES	2	
273	006A	RAMTOP:	.RES	1	; RAM SIZE DEFINED BY POWER ON LOGIC
274	006B	BUFCNT:	.RES	1	; BUFFER COUNT
275	006C	BUFSTR:	.RES	2	; EDITOR GETCH POINTER
276	006E	BITMSK:	.RES	1	; BIT MASK
277	006F	SHFAMT:	.RES	1	
278	0070	ROWAC:	.RES	2	
279	0072	COLAC:	.RES	2	

ERR LINE	ADDR	B1	B2	B3	B4
280	0074				
281	0076	ENDPT:	.RES	2	
282	0077	DELTAR:	.RES	1	
283	0079	DELTAC:	.RES	2	
284	007A	ROWINC:	.RES	1	
285	007B	COLINC:	.RES	1	
286	007C	SWPFLG:	.RES	1	
287	007D	HOLDCH:	.RES	1	
288	007E	INSDAT:	.RES	1	
289		COUNTR:	.RES	2	
290					
291					
292					
293					
294					
295					
296					
297					
298					
299					
300					
301					
302					
303					
304					
305					
306					
307					
308					
309					
310	0200	INTABS	==*		
311	0200	VDSLST:	.RES	2	
312	0202	VPRCED:	.RES	2	
313	0204	VINTER:	.RES	2	
314	0206	VBREAK:	.RES	2	
315	0208	VKEYBD:	.RES	2	
316	020A	VSERIN:	.RES	2	
317	020C	VSEOR:	.RES	2	
318	020E	VSEROC:	.RES	2	
319	0210	VIMR1:	.RES	2	
320	0212	VIMR2:	.RES	2	
321	0214	VIMR4:	.RES	2	
322	0216	VIMIRG:	.RES	2	
323	0218	CDTMV1:	.RES	2	
324	021A	CDTMV2:	.RES	2	
325	021C	CDTMV3:	.RES	2	
326	021E	CDTMV4:	.RES	2	
327	0220	CDTMV5:	.RES	2	
328	0222	VVBLKI:	.RES	2	
329	0224	VVBLKD:	.RES	2	
330	0226	CDTMA1:	.RES	2	
331	0228	CDTMA2:	.RES	2	
332	022A	CDTMF3:	.RES	1	
333	022B	SRTIMR:	.RES	1	

ERR LINE ADDR B1 B2 B3 B4

6500 ASSEMBLER VER 1.0MR

8
PAGE

ERR LINE	ADDR	B1	B2	B3	B4
388	02B1				
389	02B2				
390	02B3				
391	02B4				
392	02B5				
393	02B6				
394	02B7				
395					
396	02B8				
397	02B9				
398	02BA				
399	02BB				
400	02BC				
401					
402	02BE				
403					
404					
405					
406					
407	02B0				
408	02B1				
409	02B3				
410	02B4				
411	02B6				
412	02B7				
413	02B9D				
414	029E				
415	029F				
416	02A0				
417	02A1				
418	02A2				
419	02A3				
420	02B2				
421	02B6				
422	02B7				
423	02B8				
424	02B9				
425	02BB				
426	02BC				
427	02BD				
428	02BE				
429	02BF				
430					
431					
432	02C0				
433	02C1				
434	02C2				
435	02C3				
436	02C4				
437	02C5				
438	02C6				
439	02C7				
440	02CB				
441					

ERR LINE ADDR B1 B2 B3 B4

6500 ASSEMBLER VER 1.0MB

PAGE 10

ERR LINE	ADDR	B1	B2	B3	B4
496	502	0312			
497	503	0314			
498	504	0315			
499	505	0316			
500	506	0317			
501	507	0318			
502	508	0319			
503	509				
510	511	031A			
511	512	0021			
512	513				
513	514				
514	515				
515	516				
516	517	0340			
517	518	0341			
518	519	0342			
519	520	0343			
520	521	0344			
521	522	0345			
522	523	0346			
523	524	0347			
524	525	0348			
525	526	0349			
526	527	034A			
527	528	034B			
528	529	034C			
529	530	0350			
530	531	0350			
531	532	03C0			
532	533	03C0			
533	534	03EB			
534	535	03EB			
535	536				
536	537				
537	538				
538	539				
539	540				
540	541				
541	542				
542	543				
543	544				
544	545				
545	546				
546	547				
547	548				
548	549				

6500 ASSEMBLER VER 1. OMR

PAGE 11

```

; INITIAL TIMER VALUE
; ADDITION CORRECTION
; CASSETTE MODE WHEN SET
; FINAL TIMER VALUE. THESE TWO TIMER VALUES

; ARE USED TO COMPUTE INTERVAL FOR BAUD RATE
; TEMP1: .RES 2 ; TEMPORARY STORAGE REGISTER
; TEMP2: .RES 1 ; TEMPORARY STORAGE REGISTER
; TEMP3: .RES 1 ; TEMPORARY STORAGE REGISTER
; SAVIO: .RES 1 ; SAVE SERIAL IN DATA PORT
; TIMFLG: .RES 1 ; TIME OUT FLAG FOR BAUD RATE CORRECTION
; STACKP: .RES 1 ; SIO STACK POINTER SAVE CELL
; TSTAT: .RES 1 ; TEMPORARY STATUS HOLDER

;
; HATABS: .RES = 38 ; HANDLER ADDRESS TABLE
; MAXDEV = **-HATABS-5 ; MAXIMUM HANDLER ADDRESS INDEX

;
; NOTE : THE ENTIRE IOCB DEFINITIONS HAVE BEEN MODIFIED

; IOCB: .ORG * ; I/O CONTROL BLOCKS
; ICHID: .RES 1 ; HANDLER INDEX NUMBER (FF = IOCB FREE)
; ICDNO: .RES 1 ; DEVICE NUMBER (DRIVE NUMBER)
; ICCOM: .RES 1 ; COMMAND CODE
; ICSTA: .RES 1 ; STATUS OF LAST IOCB ACTION
; ICBAL: .RES 1 ; BUFFER ADDRESS LOW BYTE
; ICBAH: .RES 1 ; PUT BYTE ROUTINE ADDRESS - 1
; ICPTL: .RES 1 ; BUFFER LENGTH LOW BYTE
; ICPTH: .RES 1 ; AUXILIARY INFORMATION FIRST BYTE
; ICBLL: .RES 1 ; FOUR SPARE BYTES
; ICBHL: .RES 1 ; MAXIOC-IOCBSZ
; ICAX1: .RES 1 ; PRINTER BUFFER
; ICAX2: .RES 1 ; SPARE BYTES

;
; PAGE FOUR RAM ASSIGNMENTS
; CASSBUF: .RES 131 ; CASSETTE BUFFER
; USER AREA STARTS HERE AND GOES TO END OF PAGE FIVE
; USAREA: .RES 128 ; SPARE

```

550

551

552

553

554

555

556

557

558

559

560

561

562

563

564

565

566

567

568

569

570

571

572 0006

573

574

DB00

575

DBE6

576

D9AA

577

DA60

578

D9D2

580

DA60

581

DA66

582

DADB

583

DB28

584

DB89

585

DDBD

586

DD9B

587

DD9C

588

DDA7

589

DDAB

590

DDB6

591

DD40

592

593

594

595

DDCO

596

DDCC

597

DECD

598

DED1

599

LOG10

600

BDB1

601

BD73

602

BE43

603

BEB1

PAGE FIVE RAM ASSIGNMENTS

PAGE FIVE IS RESERVED AS A USER WORK SPACE

NOTE: SEE FLOATING POINT SUBROUTINE AREA FOR PAGE FIVE CELLS

PAGE SIX RAM ASSIGNMENTS

PAGE SIX IS RESERVED AS A USER'S USER WORK SPACE

FLOATING POINT SUBROUTINES

```

FPREC = 6          ; FLOATING PT PRECISION (# OF BYTES)
; IF CARRY USED THEN CARRY CLEAR => NO ERROR, CARR
; ASCII-->FLOATING POINT (FP)
; INBUFF+CIX --> FRO, CIX, CARRY
; FP --> ASCII1 FRO--> LBUFF (INBUFF)
; INTEGER FRO --> FP
; FP --> INBUFF (LSB, MSB) IN FRO, FRO+1-->FRO
; 0-$FFFF (INBUFF) FRO <- FR1 , CARRY
; FRO <- FRO - FR1 , CARRY
; FRO <- FRO + FR1 , CARRY
; FRO <- FRO * FR1 , CARRY
; FRO <- FRO / FR1 , CARRY
; FLOATING LOAD REG0 FRO <- (X, Y)
; DD8D " " FRO <- (FLPTR)
; DD98 " " REG1 FR1 <- (X, Y)
; DD9C " " FR1 <- (FLPTR)
; FLOATING STORE REG0 (X, Y) <- FRO
; DDAB " " (FLPTR) <- FRO
; FR1 <- FRO
; FRO <- P(Z) = SUM(I=N TO 0) (A(I)*Z**I) CARR
; INPUT: (X, Y) = A(N), A(N-1)...A(0) --> PLYARG
; ACC = # OF COEFFICIENTS = DEGREE+1
; FRO = Z
; E**FRO = EXP10(FRO * LDG10(E)) CARRY
; FRO <- 10**FRO CARRY
; FRO <- LN(FRO) = LDG10(FRO)/LDG10(E) CARRY
; FRO <- LOG10 (FRO) CARRY
; THE FOLLOWING ARE IN BASIC CARTRIDGE:
; SIN = $DBB1 ; FRO <- SIN(FRO) DEGFLG=0 =>RADS, 6=>DEG. CA
; COS = $BD73 ; FRO <- COS(FRO) CARRY
; ATAN = $BE43 ; FRO <- ATAN(FRO) CARRY
; SQR = $BEB1 ; FRO <- SQUAREROOT(FRO) CARRY

```

ERR LINE	ADDR	B1	B2	B3	B4
604					
605	00D4				
606	00D4				
607	00DA				
608	00E0				
609	00E6				
610	00EC				
611	00ED				
612	00EE				
613	00EF				
614	00FO				
615	00F1				
616	00F2				
617	00F3				
618	00F5				
619	00F7				
620	00F9				
621	00FB				
622	00FB				
623	0000				
624	0006				
625	00FC				
626	00FE				
627					
628					
629					
630	057E				
631	057F				
632	0580				
633	05E0				
634	05E6				
635	05EC				
636	05E6				
637	05EC				
638	05FF				
639					
640					
641					
642					
643					
644					
645					
646					
647					
648					
649					
650	D200				
651	D200				
652	D201				
653	D202				
654	D203				
655	D204				
656	D205				
657	D206				

```

        ; VBLANK ACTIV
        ; POTO-->PADDI
        ; POT1-->PADDI
        ; POT2-->PADDI
        ; POT3-->PADDI
        ; POT4-->PADDI
        ; POT5-->PADDI
        ; POT6-->PADDI

$D200    POKEY+0   ; FP REGO
          POKEY+1   ; FP REG1
          POKEY+2   ; FP SPARE
          POKEY+3   ; VALUE OF E
          POKEY+4   ; SIGN OF #
          POKEY+5   ; SIGN OF EXP
          POKEY+6   ; 1ST CHAR FL
          POKEY+7   ; # OF DIGITS
          POKEY+8   ; CURRENT INFR
          POKEY+9   ; POINTS TO U

        ; O=RADIANS,
        ; INDICATES R
        ; INDICATES D
        ; POINTS TO U

        ; LBUFF PREFIX
        ; LBUFF PREFIX
        ; LINE BUFFER
        ; POLYNOMIAL
        ; PLYARG+$60
        ; FPSCR+FPREC
        ; FPSCR
        ; FPSCR
        ; END OF LBUF

MNEMONICS

```

ERR	LINE	ADDR	B1	B2	B3	B4
	658	D207	POT7	i POT7-->PADDL7		
	659	D208	ALLPOT	; ???		
	660	D209	KBCODE			
	661	D20A	RANDOM	= POKEY+10		
	662	D20B	POTGO	= POKEY+11		
	663	D20D	SERIN	= POKEY+13		
	664	D20E	IRGST	= POKEY+14		
	665	D20F	SKSTAT	= POKEY+15		
	666	D200	AUDF1	= POKEY+0		
	667	D201	AUDC1	= POKEY+1		
	668	D202	AUDF2	= POKEY+2		
	669	D203	AUDC2	= POKEY+3		
	670	D204	AUDF3	= POKEY+4		
	671	D205	AUDC3	= POKEY+5		
	672	D206	AUDF4	= POKEY+6		
	673	D207	AUDC4	= POKEY+7		
	674	D208	AUDCTL	; NONE		
	675	D209	STIMER	= POKEY+8		
	676	D20A	SKRES	= POKEY+9		
	677	D20D	SEROUT	= POKEY+10		
	678	D20E	IRGEN	= POKEY+13		
	679	D20F	SKCTL	= POKEY+14		
	680			= POKEY+15		
	681	D000	CTIA	\$D000		
	682	D000	HP0SP0	CTIA+0		
	683	D001	HP0SP1	CTIA+1		
	684	D002	HP0SP2	CTIA+2		
	685	D003	HP0SP3	CTIA+3		
	686	D004	HP0SM0	CTIA+4		
	687	D005	HP0SM1	CTIA+5		
	688	D006	HP0SM2	CTIA+6		
	689	D007	HP0SM3	CTIA+7		
	690	D008	SIZEP0	CTIA+8		
	691	D009	SIZEP1	CTIA+9		
	692	D00A	SIZEP2	CTIA+10		
	693	D00B	SIZEP3	CTIA+11		
	694	D00C	SIZEM	CTIA+12		
	695	D00D	GRAFP0	CTIA+13		
	696	D00E	GRAFP1	CTIA+14		
	697	D00F	GRAFP2	CTIA+15		
	698	D010	GRAFP3	CTIA+16		
	699	D011	GRAFM	CTIA+17		
	700	D012	COLPM0	CTIA+18		
	701	D013	COLPM1	CTIA+19		
	702	D014	COLPM2	CTIA+20		
	703	D015	COLPM3	CTIA+21		
	704	D016	COLPFO	CTIA+22		
	705	D017	COLPF1	CTIA+23		
	706	D018	COLPF2	CTIA+24		
	707	D019	COLPF3	CTIA+25		
	708	D01A	COLBK	CTIA+26		
	709	D01B	PRIOR	CTIA+27		
	710	D01C	VDELAY	CTIA+28		
	711	D01D	GRACTL	CTIA+29		

POT7-->PADDL7
 i POKEY+7
 ; ???

POKEY+8
 POKEY+9
 POKEY+10
 RANDOM = POKEY+11 ; STROBED

POKEY+11
 POKEY+13
 POKEY+14
 POKEY+15
 POKEY+0
 POKEY+1
 POKEY+2
 POKEY+3
 POKEY+4
 POKEY+5
 POKEY+6
 POKEY+7
 POKEY+8 ; NONE

POKEY+9
 POKEY+10
 POKEY+13
 POKEY+14
 POKEY+15 ; NONE

SKRES<--[S10]
 SEROUT<--[S10]
 SEROUT<-->IRGEN (AFFECTED BY OPEN S: OR E:)
 POKMSK-->IRGEN
 SSKCTL-->SKCTL ; (ON OPEN S: OR E:)

AUDCTL<--[S10]

VBLANK ACTION: DESCRIPTION:

HP0SP0 CTIA+0
 HP0SP1 CTIA+1
 HP0SP2 CTIA+2
 HP0SP3 CTIA+3
 HP0SM0 CTIA+4
 HP0SM1 CTIA+5
 HP0SM2 CTIA+6
 HP0SM3 CTIA+7
 SIZEP0 CTIA+8
 SIZEP1 CTIA+9
 SIZEP2 CTIA+10
 SIZEP3 CTIA+11
 SIZEM CTIA+12
 GRAFP0 CTIA+13
 GRAFP1 CTIA+14
 GRAFP2 CTIA+15
 GRAFP3 CTIA+16
 GRAFM CTIA+17
 COLPM0 CTIA+18
 COLPM1 CTIA+19
 COLPM2 CTIA+20
 COLPM3 CTIA+21
 COLPFO CTIA+22
 COLPF1 CTIA+23
 COLPF2 CTIA+24
 COLPF3 CTIA+25
 COLBK CTIA+26
 PRIOR CTIA+27
 VDELAY CTIA+28
 GRACTL CTIA+29

6500 ASSEMBLER VER 1.0.MR

PAGE 15

	HITCLR	CONSL	CONSOL	TURN OFF SPEAKER
712	D01E	CTIA+30	; \$08-->CONSOL	
713	D01F	CTIA+31		
714	D000	CTIA+0		
715	D001	CTIA+1		
716	D002	CTIA+2		
717	D003	CTIA+3		
718	D004	CTIA+4		
719	D005	CTIA+5		
720	D006	CTIA+6		
721	D007	CTIA+7		
722	D008	CTIA+8		
723	D009	CTIA+9		
724	D00A	CTIA+10		
725	D00B	CTIA+11		
726	D00C	CTIA+12		
727	D00D	CTIA+13		
728	D00E	CTIA+14		
729	D00F	CTIA+15		
730	D010	CTIA+16	; TRIGO-->STRIGO	
731	D011	CTIA+17	; TRIG1-->STRIG1	
732	D012	CTIA+18	; TRIG2-->STRIG2	
733	D013	CTIA+19	; TRIG3-->STRIG3	
734				
735	D400	\$D400	; VBLANK ACTION	DESCRIPTION
736	D400	ANTIC+0	; DMACTL<--SDMCTL	ON OPEN S:: OR E:
737	D401	ANTIC+1	; CHACTL<--CHACT	ON OPEN S:: OR E:
738	D402	ANTIC+2	; DLISTL<--SDLSTL	ON OPEN S:: OR E:
739	D403	ANTIC+3	; DLISTH<--SDLSTH	ON OPEN S:: OR E:
740	D404	ANTIC+4		
741	D405	ANTIC+5		
742	D407	ANTIC+7		
743	D409	ANTIC+9	; CHBASE<--CHBAS	ON AND [SETVBBV]
744	D40A	ANTIC+10		
745	D40B	ANTIC+11		
746	D40C	ANTIC+12		
747	D40D	ANTIC+13		
748	D40E	ANTIC+14	; NMEN<--40 POWER	DESCRIPTION
749	D40F	ANTIC+15	; STROBED	X-Y CONTROLLERS
750	D40F	ANTIC+15		X-Y CONTROLLERS
751	D300	\$D300		PACTL<--3C [INIT]
752	D300	PIA+0	; PORTA-->STICKO, 1	PACTL<--3C [INIT]
753	D301	PIA+1	; PORTB-->STICK2, 3	PACTL<--3C [INIT]
754	D302	PIA+2	; NONE	PACTL<--3C [INIT]
755	D303	PIA+3	; NONE	PACTL<--3C [INIT]
756				
757				
758				

ERR LINE	ADDR	B1	B2	B3	B4
760					
761					
762					
763					
764	0030				
765	003A				
766	009B				

6500 ASSEMBLER VER 1. OMR

PAGE 16

```
; PAGE
; LIST
; TITLE    'CENTRAL INPUT/OUTPUT (C10) 2-7-79'
;          'UPATED BY AL MILLER 3-9-79
;          ',0           ; ASCII ZERO
;          '$3A          ; ASCII COLON
;          '$9B          ; END OF RECORD
;
; ASCZER = 
; COLCN = 
; EOL   =
```

ERR LINE ADDR B1 B2 B3 B4 CENTRAL INPUT/OUTPUT (CIO) 2-7-79

PAGE 17

```
767
768
769
770    E456    4C C4 E4          ; CIO JUMP VECTOR FOR USERS
          *=C10V      JMP   C10      ; GO TO CIO
771
772
773
774    E46E    4C A6 E4          ; CIO INIT JUMP VECTOR FOR POWER UP
          *=C10INV     JMP   C10INT   ; GO TO INIT
775
776
777
778
779
780
781
782
783
784
785
786    E4A6    A2 00          ; CIO INITIALIZATION (CALLED BY MONITOR AT POWER UP)
          *0
787    E4AB    A9 FF          ; CIOINT: LDX #0      ; SET ALL IOCBS TO FREE
          9D 40 03      ; CIO11: LDA *IOCFRE   ; BY SETTING HANDLER ID '$=FFF
788    E4AA    A9 CO          ; STA ICHID,X
          9D 46 03      ; LDA #ERTNL    ; POINT PUT TO ERROR ROUTINE
789    E4AD    A9 CO          ; STA ICPTL,X
          9D 46 03      ; LDA #ERTNH    ; STA ICPTH,X
790    E4AF    A9 E4          ; STA ICPTH,X
          9D 47 03      ; TXA
791    E4B2    A9 E4          ; CLC
          9D 47 03      ; ADC #IOCBSZ   ; BUMP INDEX BY SIZE
792    E4B4    8A
793    E4B7    18
794    E4B8    18
795    E4B9    69 10          ; TAX
          69 10          ; CMP #MAXIOC  ; DONE?
796    E4BB    AA
          80             ; BCC C10I1   ; NO
797    E4BC    90 E8          ; RTS       ; YES, RETURN
798    E4BE    90 E8
799    E4C0    60
800
801    E4C0    E4CO          ; ERROR ROUTINE FOR ILLEGAL PUT
          *=*-1
802
803    00E4    00CO          ; ERRTNH =ERTN/256
          00CO
804
805    E4C1    A0 B5          ; ERRTNL =(-ERTNH)*256+ERRTN
          A0 B5      ; LDY #NOTOPN , IOC B NOT OPEN
806    E4C3    60
          RTS
```

ERR LINE	ADDR	B1	B2	B3	B4
807					PAGE
808					; CID LOCAL RAM USES SPARE BYTES IN ZERO PAGE IOCB)
809	002C				ENTVEC = ICSPRZ
810					; CIO MAIN ROUTINE
811					; CIO INTERFACES BETWEEN USER AND INPUT/OUTPUT DE
812					CIO: STA CIOCHR ; SAVE POSSIBLE OUTPUT CHARACTER
813					STX ICIDNO ; SAVE IOCB NUMBER * N
814					; CHECK FOR LEGAL IOCB
815	E4C4	85	2F		TXA #FF ; IS IOCB MULTIPLE OF 16?
816	E4C6	86	2E		AND BNE CIERR1 ; NO, ERROR
817					CPX #MAXIOCB ; IS INDEX TOO LARGE?
818					BCC IOC1 ; NO
819	E4CB	8A			; INVALID IOCB NUMBER -- RETURN ERROR
820	E4C9	29	0F		CIERR1: LDY #BADIOC ; ERROR CODE
821	E4CB	DO	04		JMP CIRTN1 ; RETURN
822	E4CD	EO	80		; MOVE USER IOCB TO ZERO PAGE
823	E4CF	90	05		IOC1: LDY #0 ; USER IOCB
824					IOCIA: LDA IOCBA,X ; TO ZERO PAGE
825					STA IOCBA,Y
826	E4D1	A0	86		INX INY ; 12 BYTES
827	E4D3	4C	1B	E6	CPY #12 ; 12 BYTES
828					BCC IOC1A
829					; COMPUTE CID INTERNAL VECTOR FOR COMMAND
830	E4D6	A0	00		LDY #INVALID ; ASSUME INVALID CODE
831	E4DB	BD	40	03	LDA ICCOMZ ; COMMAND CODE TO INDEX
832	E4DB	99	20	00	#OPEN ; IS COMMAND LEGAL?
833	E4DE	E8			CMP CIERR4 ; NO
834	E4DF	C8			BCC TAY
835	E4EO	CO	0C		; MOVE COMMAND TO ZERO BASE FOR INDEX
836	E4E2	90	F4		CPY #SPECIL ; IS COMMAND SPECIAL?
837					BCC IOC2 ; NO
838					LDY #SPECIL ; YES, SET SPECIAL OFFSET INDEX
839	E4E4	A0	84		STY ICCOMT ; SAVE COMMAND FOR VECTOR
840	E4E6	A5	22		COMTAB-3, Y ; GET VECTOR OFFSET FROM TABLE
841	E4EB	C9	03		BEQ CIOPEN ; GD IF OPEN COMMAND
842	E4EA	90	25		CMP #2 ; IS IT CLOSE?
843	E4EC	AB			BEQ CICLOS ; YES
844					CMP #B ; IS IT STATUS OR SPECIAL?
845					BCS CISTSP ; YES
846	E4ED	CO	0E		CMP #4 ; IS IT READ?
847	E4EF	90	02		BEG CIREAD ; YES
848	E4F1	A0	0E		BEG CIWRIT ; ELSE, MUST BE WRITE
849	E4F3	B4	17		
850	E4F5	B9	C6	E6	
851	E4FB	F0	0F		
852	E4FA	C9	02		
853	E4FC	F0	35		
854	E4FE	C9	08		
855	E500	BO	4C		
856	E502	C9	04		
857	E504	F0	63		
858	E506	4C	C9	E5	

ERR LINE	ADDR	B1	B2	B3	B4
					CENTRAL INPUT/OUTPUT (CIO) 2-7-79
					PAGE 18
807					.PAGE
808					; CID LOCAL RAM USES SPARE BYTES IN ZERO PAGE IOCB)
809	002C				ENTVEC = ICSPRZ
810					; CIO MAIN ROUTINE
811					; CIO INTERFACES BETWEEN USER AND INPUT/OUTPUT DE
812					CIO: STA CIOCHR ; SAVE POSSIBLE OUTPUT CHARACTER
813					STX ICIDNO ; SAVE IOCB NUMBER * N
814					; CHECK FOR LEGAL IOCB
815	E4C4	85	2F		TXA #FF ; IS IOCB MULTIPLE OF 16?
816	E4C6	86	2E		AND BNE CIERR1 ; NO, ERROR
817					CPX #MAXIOCB ; IS INDEX TOO LARGE?
818					BCC IOC1 ; NO
819	E4CB	8A			; INVALID IOCB NUMBER -- RETURN ERROR
820	E4C9	29	0F		CIERR1: LDY #BADIOC ; ERROR CODE
821	E4CB	DO	04		JMP CIRTN1 ; RETURN
822	E4CD	EO	80		; MOVE USER IOCB TO ZERO PAGE
823	E4CF	90	05		IOC1: LDY #0 ; USER IOCB
824					IOCIA: LDA IOCBA,X ; TO ZERO PAGE
825					STA IOCBA,Y
826	E4D1	A0	86		INX INY ; 12 BYTES
827	E4D3	4C	1B	E6	CPY #12 ; 12 BYTES
828					BCC IOC1A
829					; COMPUTE CID INTERNAL VECTOR FOR COMMAND
830	E4D6	A0	00		LDY #INVALID ; ASSUME INVALID CODE
831	E4DB	BD	40	03	LDA ICCOMZ ; COMMAND CODE TO INDEX
832	E4DB	99	20	00	#OPEN ; IS COMMAND LEGAL?
833	E4DE	E8			CMP CIERR4 ; NO
834	E4DF	C8			BCC TAY
835	E4EO	CO	0C		; MOVE COMMAND TO ZERO BASE FOR INDEX
836	E4E2	90	F4		CPY #SPECIL ; IS COMMAND SPECIAL?
837					BCC IOC2 ; NO
838					LDY #SPECIL ; YES, SET SPECIAL OFFSET INDEX
839	E4E4	A0	84		STY ICCOMT ; SAVE COMMAND FOR VECTOR
840	E4E6	A5	22		COMTAB-3, Y ; GET VECTOR OFFSET FROM TABLE
841	E4EB	C9	03		BEQ CIOPEN ; GD IF OPEN COMMAND
842	E4EA	90	25		CMP #2 ; IS IT CLOSE?
843	E4EC	AB			BEQ CICLOS ; YES
844					CMP #B ; IS IT STATUS OR SPECIAL?
845					BCS CISTSP ; YES
846	E4ED	CO	0E		CMP #4 ; IS IT READ?
847	E4EF	90	02		BEG CIREAD ; YES
848	E4F1	A0	0E		BEG CIWRIT ; ELSE, MUST BE WRITE
849	E4F3	B4	17		
850	E4F5	B9	C6	E6	
851	E4FB	F0	0F		
852	E4FA	C9	02		
853	E4FC	F0	35		
854	E4FE	C9	08		
855	E500	BO	4C		
856	E502	C9	04		
857	E504	F0	63		
858	E506	4C	C9	E5	

ERR LINE	ADDR	B1	B2	B3	B4	CENTRAL INPUT/OUTPUT (CIO) 2-7-79
859						PAGE
860						PAGE
861						PAGE
862						PAGE
863						PAGE
864	E509	A5	20			PAGE
865	E50B	C9	FF			PAGE
866	E50D	F0	05			PAGE
867						PAGE
868						PAGE
869	E50F	AO	B1			PAGE
870	E511	4C	1B	E6		PAGE
871						PAGE
872						PAGE
873	E514	20	9E	E6		PAGE
874	E517	BO	F8			PAGE
875						PAGE
876						PAGE
877						PAGE
878						PAGE
879	E519	20	3D	E6		PAGE
880	E51C	BO	F3			PAGE
881						PAGE
882						PAGE
883	E51E	20	89	E6		PAGE
884						PAGE
885						PAGE
886	E521	A9	0B			PAGE
887	E523	B5	17			PAGE
888	E525	20	3D	E6		PAGE
889	E528	A5	2C			PAGE
890	E52A	B5	26			PAGE
891	E52C	A5	2D			PAGE
892	E52E	B5	27			PAGE
893	E530	4C	1D	E6		PAGE

```

; OPEN COMMAND
; FIND DEVICE HANDLER IN HANDLER ADDRESS TABLE
; CIOPEN: LDA ICHIDZ      ; GET HANDLER ID
;           CMP *IDCFRE    ; IS THIS IOCB CLOSED?
;           BEQ IOC6
;
;   ; ERROR -- IOCB ALREADY OPEN
;   CIERR3: LDY #PRVOPN   ; ERROR CODE
;             JMP CIRTN1   ; RETURN
;
;   ; GO FIND DEVICE
;   IOC6: JSR DEVSRC     ; CALL DEVICE SEARCH
;         BCS CIERR4    ; GD IF DEVICE NOT FOUND
;
;   ; DEVICE FOUND, INITIALIZE IOCB FOR OPEN
;   ; COMPUTE HANDLER ENTRY POINT
;   IOC7: JSR COMENT     ; GO IF ERROR IN COMPUTE
;         BCS CIERR4    ; GO IF ERROR IN COMPUTE
;
;   ; GO TO HANDLER FOR INITIALIZATION
;   ; GDHAND : USE INDIRECT JUMP
;   ; STORE PUT BYTE ADDRESS-1 INTO IOCB
;   ; SIMULATE PUT CHARACTER
;   LDA *PUTCHR
;   STA ICCOMT
;   JSR COMENT
;   LDA ICSPRZ
;   STA ICPTLZ
;   LDA ICSPRZ+1
;   STA ICPTHZ
;   JMP CIRTN2
;
```

PAGE 19

ERR LINE

CENTRAL INPUT/OUTPUT (CIO) 2-7-79

PAGE 20

ADDR B1 B2 B3 B4

PAGE

```
894
895
896
897 E533 A0 01 ; CLOSE COMMAND #SUCCESS ; ASSUME GOOD CLOSE
898 E535 84 23 ; CICLOS: LDY ICSTAZ ; COMPUTE HANDLER ENTRY POINT
899 E537 20 3D E6 ; STY COMENT ; GO IF ERROR IN COMPUTE
900 E53A B0 03 ; BCS CICL02 ; GO TO HANDLER TO CLOSE DEVICE
901 E53C 20 89 E6 ; JSR GOHAND ; GET IOCB "FREE" VALUE
902 E53F A9 FF ; CICL02: LDA #IOCFRE ; SET HANDLER ID
903 E541 85 20 ; STA ICHIDZ
904 E543 A9 E4 ; LDA #ERRTNH
905 E545 85 27 ; STA ICP1HZ
906 E547 A9 CO ; LDA #ERRTNL
907 E549 85 26 ; STA ICPTLZ
908 E54B 4C 1D E6 ; JMP CIRTN2 ; RETURN
910
911
912 ; STATUS AND SPECIAL REQUESTS
913 E54E A5 20 ; DO IMPLIED OPEN IF NECESSARY AND GO TO DEVICE
914 E550 C9 FF ; CISTSP: LDA ICHIDZ ; IS THERE A HANDLER ID?
915 E552 DO 05 ; CMP #IOCFRE
916 E557 BO B8 ; BNE CIST1 ; YES
917
918 E554 20 9E E6 ; IOCB IS FREE, DO IMPLIED OPEN
919 E555 20 3D E6 ; JSR DEVSRC ; FIND DEVICE IN TABLE
920 E557 BO B8 ; BCS CIERR4 ; GO IF ERROR IN COMPUTE
921
922 E559 20 3D E6 ; COMPUTE AND GO TO ENTRY POINT IN HANDLER
923 E55C 20 89 E6 ; CIST1: JSR COMENT ; COMPUTER HANDLER ENTRY VECTOR
924 E55F A6 2E ; JSR GDHAND ; GO TO HANDLER
925
926 E55F A6 2E ; RESTORE HANDLER INDEX (DO IMPLIED CLOSE)
927 E561 BD 40 03 ; LDX ICIDNO ; IOCB INDEX
928 E564 B5 20 ; LDA ICHIDZ,X ; GET ORIGINAL HANDLER ID
929 E566 4C 1D E6 ; STA CIRTN2 ; RESTORE ZERO PAGE
930
931
```

ERR LINE ADDR B1 B2 B3 B4

CENTRAL INPUT/OUTPUT (CIO) 2-7-79

PAGE 21

```

931          . PAGE
932          ; READ -- DO GET COMMANDS
933          CIREAD: LDA    ICCMZ      ; GET COMMAND BYTE
934          E569   A5 22           ; IS THIS READ LEGAL?
935          E56B   25 2A           ; YES
936          E56D   D0 05           ;
937          ; ILLEGAL READ -- IOCB OPENED FOR WRITE ONLY
938          ; CIREAD: LDA    ICAX1Z    ; GET COMMAND BYTE
939          E56F   A0 83           ; IS THIS READ LEGAL?
940          E571   4C 1B E6           ; YES
941          ; COMPUTE AND CHECK ENTRY POINT
942          ; CIREAD: JSR    COMENT    ; COMPUTE ENTRY POINT
943          E574   20 3D E6           ; GO IF ERROR IN COMPUTE
944          E577   B0 F8           ;
945          ; GET RECORD OR CHARACTERS
946          ; CIREAD: LDA    ICBLIZ    ; IS BUFFER LENGTH ZERO?
947          E579   A5 2B           ; NO
948          E57B   05 29           ; NO
949          E57D   D0 08           ; NO
950          E57F   20 89 E6           ; NO
951          E582   B5 2F           ; NO
952          E584   4C 1D E6           ; NO
953          ; LOOP TO FILL BUFFER OR END RECORD
954          ; CIREAD: JSR    GOHAND    ; GO TO HANDLER TO GET BYTE
955          E587   20 89 E6           ; SAVE BYTE
956          E58A   85 2F           ; END TRANSFER IF ERROR
957          E58C   30 35           ; #0
958          E58E   A0 00           ; NO
959          E590   91 24           ; (ICBALZ),Y
960          E592   20 70 E6           ; PUT BYTE IN USER BUFFER
961          E595   A5 22           ; INCBFP
962          E597   29 02           ; INCREMENT BUFFER POINTER
963          E599   D0 0C           ; GET COMMAND CODE
964          ; IS IT GET RECORD?
965          ; CHECK FOR EOL ON TEXT RECORDS
966          E59B   A5 2F           ; GET BYTE
967          E59D   C9 9B           ; IS IT AN EOL?
968          E59F   D0 06           ; NO
969          E5A1   20 63 E6           ; DECBFL
970          E5A4   4C C3 E5           ; YES, DECREMENT BUFFER LENGTH
971          ; END TRANSFER
972          ; CHECK BUFFER FULL
973          E5A7   20 63 E6           ; DECBFL
974          E5AA   D0 DB           ; CONTINUE IF NON ZERO

```

ERR LINE ADDR B1 B2 B3 B4

CENTRAL INPUT/OUTPUT (C10) 2-7-79

PAGE 22

975

.PAGE

```
; BUFFER FULL, RECORD NOT ENDED
; DISCARD BYTES UNTIL END OF RECORD
RCI2: LDA ICCMZ          ; GET COMMAND BYTE
      AND #2             ; IS IT GET CHARACTER?
      BNE RCI4           ; YES, END TRANSFER

; LOOP TO WAIT FOR EOL
RCI6: JSR GDHAND         ; GET BYTE FROM HANDLER
      STA CIDCHR        ; SAVE CHARACTER
      BMI RCI4           ; GO IF ERROR

; TEXT RECORD, WAIT FOR EOL
; GET GOT BYTE
; IS IT EOL?
; NO, CONTINUE
RCI7: LDA CIDCHR         ; GET GOT BYTE
      CMP #EOL           ; IS IT EOL?
      BNE RCI6           ; NO, CONTINUE

; END OF RECORD, BUFFER FULL -- SEND TRUNCATED RECORD MESSAGE
RCI11: LDA #TRNRCD        ; ERROR CODE
       STA ICSTAZ         ; STORE IN IOCB

; TRANSFER DONE
RCI14: JSR SUBBFL         ; SET FINAL BUFFER LENGTH
      JMP CIRTN2          ; RETURN
```

ERR LINE	ADDR	B1	B2	B3	B4	CENTRAL INPUT/OUTPUT (CID) 2-7-79	PAGE
1000						. PAGE	
1001						; WRITE -- DO PUT COMMANDS	
1002	E5C9	A5	22			CIWRIT: LDA IC00MZ ; GET COMMAND BYTE	
1003	E5CB	25	2A			AND ICAX1Z ; IS THIS WRITE LEGAL?	
1004	E5CD	DO	05			BNE WC11A ; YES	
1005						i ; ILLEGAL WRITE -- DEVICE OPENED FOR READ ONLY	
1006						WC11B: LDY #RDONLY ; ERROR CODE	
1007						JMP CIRTN1 ; RETURN	
1008	E5CF	A0	87			i ; COMPUTE AND CHECK ENTRY POINT	
1009	E5D1	4C	1B	E6		WC11A: JSR COMENT ; COMPUTE HANDLER ENTRY POINT	
1010						BCS WC11B ; GO IF ERROR IN COMPUTE	
1011						i ; PUT RECORD OR CHARACTERS	
1012	E5D4	20	3D	E6		LDA ICBL1Z ; IS BUFFER LENGTH ZERO?	
1013	E5D7	BO	F8			ORA ICBL1Z+1 ; NO	
1014						BNE WC13 ; GET CHARACTER	
1015						LDA CI0CHR ; SET BUFFER LENGTH=1	
1016	E5D9	A5	2B			INC ICBL1Z ; THEN JUST TRANSFER ONE BYTE	
1017	E5DB	05	29			BNE WC14 ; THEN JUST TRANSFER ONE BYTE	
1018	E5DD	DO	06			i ; LOOP TO TRANSFER BYTES FROM BUFFER TO HANDLER	
1019	E5DF	A5	2F			WC13: LDY #0 ; GET BYTE FROM BUFFER	
1020	E5E1	E6	2B			LDA ICBAL1Z,Y ; SAVE	
1021	E5E3	DO	06			STA CI0CHR ; GO PUT BYTE	
1022						WCI4: JSR GDHAND ; END IF ERROR	
1023						BMI WC15 ; INCREMENT BUFFER POINTER	
1024	E5E5	A0	00			JSR INCBF1	
1025	E5E7	B1	24			i ; CHECK FOR TEXT RECORD	
1026	E5E9	85	2F			LDA IC00MZ ; GET COMMAND BYTE	
1027	E5EB	20	89	E6		AND #2 ; IS IT PUT RECORD?	
1028	E5EE	30	25			BNE WC11 ; NO	
1029	E5F0	20	70	E6		i ; TEXT RECORD -- CHECK FOR EDL TRANSFER	
1030						LDA CI0CHR ; GET LAST CHARACTER	
1031						CMP #EOL ; IS IT AN EOL?	
1032	E5F3	A5	22			BNE WC11 ; NO	
1033	E5F5	29	02			JSR DECBFL ; DECREMENT BUFFER LENGTH	
1034	E5F7	DO	OC			JMP WC15 ; END TRANSFER	
1035						i ; CHECK FOR BUFFER EMPTY	
1036						WC11: JSR DECBFL ; DECREMENT BUFFER LENGTH	
1037	E5F9	A5	2F			BNE WC13 ; CONTINUE IF NON ZERO	
1038	E5FB	C9	9B				
1039	E5FD	DO	06				
1040	E5FF	20	63	E6			
1041	E602	4C	15	E6			
1042							
1043	E605	20	63	E6			
1044	E608	DO	DB				
1045							

ERR LINE ADDR B1 B2 B3 B4

CENTRAL INPUT/OUTPUT (CIO) 2-7-79

PAGE 24

```
1046          . PAGE  
1047          ;  
1048          ; BUFFER EMPTY, RECORD NOT FILLED  
1049          ; CHECK TYPE OF TRANSFER  
1050          E60A    A5 22      WC12:   LDA     IC0DM2    ; GET COMMAND CODE  
1051          E60C    29 02      AND     #2        ; IS IT PUT CHARACTER?  
1052          E60E    DO 05      BNE     WC15      ; YES, END TRANSFER  
1053          ;  
1054          ; PUT RECORD (TEXT), BUFFER EMPTY, SEND EOL  
1055          E610    A9 9B      LDA     #EOL      ;  
1056          E612    20 89 E6    JSR     GOHAND    ; GO TO HANDLER  
1057          ;  
1058          ; END PUT TRANSFER  
1059          E615    20 77 E6    WC15:   JSR     SUBBFL    ; SET ACTUAL PUT BUFFER LENGTH  
1060          E618    4C 1D E6    JMP     CIRTN2    ; RETURN
```

ERR	LINE	ADDR	B1	B2	B3	B4	CENTRAL INPUT/OUTPUT (CIO) 2-7-79
1061							. PAGE
1062							i CIO RETURNS
1063							; RETURNS WITH Y=STATUS
1064		E61B	84	23			CIRTN1: STY ICSTAZ ; SAVE STATUS
1065							i RETURNS WITH STATUS STORED IN ICSTAZ
1066							; MOVE IOCB IN ZERO PAGE BACK TO USER AREA
1067							CIRTN2: LDY ICIDND ; GET IOCB INDEX
1068		E61D	A4	2E			LDA ICBAL,Y
1069		E61F	B9	44	03		STA ICBALZ ; RESTORE USER BUFFER POINTER
1070		E61F	B9	44	03		LDA ICBALH,Y
1071		E622	B5	24			STA ICBALZ
1072		E624	B9	45	03		STA ICBALH,Z
1073		E627	B5	25			LDX #0 ; LOOP COUNT AND INDEX
1074		E629	A2	00			LDA IOCBAS,X ; ZERO PAGE
1075		E62B	B5	20			LDX IOCB,Y ; TO USER AREA
1076		E62D	99	40	03		STA INX
1077		E630	E8				INY
1078		E631	CB				CPX #12 ; 12 BYTES
1079		E632	E0	0C			BCC CIRT3
1080		E634	90	F5			i RESTORE A, X, %Y
1081							; GET LAST CHARACTER
1082							LDA CIOCHR
1083		E636	A5	2F			LDX ICIDND ; IOCB INDEX
1084		E638	A6	2E			LDY ICSTAZ ; GET STATUS AND SET FLAGS
1085		E63A	A4	23			RTS ; RETURN TO USER
1086		E63C	60				

ERR LINE

CENTRAL INPUT/OUTPUT (CIO) 2-7-79

PAGE 26

1087
10881089
1090

1091

1092

1093 E63D A4 20

1094 E63F C0 22

1095 E641 90 04

1096

1097

1098 E643 A0 B5

1099 E645 BO 1B

1100

1101 E647 B9 1B 03

1102 E64A B5 2C

1103 E64C B9 1C 03

1104 E64F B5 2D

1105 E651 A4 17

1106 E653 B9 C6 E6

1107 E655 A8

1108 E657 B1 2C

1109 E659 AA

1110 E65A C8

1111 E65B B1 2C

1112 E65D 85 2D

1113 E65F 86 2C

1114 E661 18

1115 E662 60

1116

1117

1118

1119

1120 E663 C6 28

1121 E665 A5 28

1122 E667 C9 FF

1123 E669 D0 Q2

1124 E66B C6 29

1125 E66D 05 29

1126 E66F 60

1127

1128

1129

1130 E670 E6 24

1131 E672 D0 02

1132 E674 E6 25

1133 E676 60

1134

1135

1136

1137 E677 A6 2E

1138 E679 38

1139 E67A BD 48 03

1140

1141

1142

1143

1144

1145

1146

1147

1148

1149

1150

1151

1152

1153

1154

1155

1156

1157

1158

1159

1160

1161

1162

1163

1164

1165

1166

1167

1168

1169

1170

1171

1172

1173

1174

1175

1176

1177

1178

1179

1180

1181

1182

1183

1184

1185

1186

1187

1188

1189

1190

1191

1192

1193

1194

1195

1196

1197

1198

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

1199

ERR LINE ADDR B1 B2 B3 B4 CENTRAL INPUT/OUTPUT (CIO) 2-7-79

1141	E67D	E5 28		SBC ICBLLZ ; SUBTRACT FINAL LOW BYTE
1142	E67F	B5 28		STA ICBLLZ ; AND SAVE BACK
1143	E6B1	BD 49	03	LDA ICBLH, X ; GET HI BYTE
1144	E6B4	E5 29		SBC ICBLLZ+1
1145	E6B6	B5 29		STA ICBLHZ
1146	E6B8	60		RTS
1147				
1148				; GOHAND -- GO INDIRECT TO A DEVICE HANDLER
1149				; Y= STATUS ON RETURN, N FLAG=1 IF ERROR ON RETURN
1150				; GOHAND: LDY #FNCNOT ; PREPARE NO FUNCTION STATUS FOR HANDLER RTS
1151	E6B9	A0 92		JSR CIJUMP ; USE THE INDIRECT JUMP
1152	E6BB	20 93	E6	STY ICSTAZ ; SAVE STATUS
1153	E6BE	84 23		CPY #0 ; AND SET N FLAG
1154	E6B0	C0 00		RTS
1155	E6B2	60		
1156				; INDIRECT JUMP TO HANDLER BY PAUL'S METHOD
1157				; CIJUMP: TAX ; SAVE A
1158	E693	AA		LDA ICSPRZ+1 ; GET JUMP ADDRESS HI BYTE
1159	E694	A5 2D		PHA ; PUT ON STACK
1160	E696	48		LDA ICSPRZ ; GET JUMP ADDRESS LO BYTE
1161	E697	A5 2C		PHA ; PUT ON STACK
1162	E699	48		TXA ; RESTORE A
1163	E69A	8A		LDX ICIDNO ; GET IOCBL INDEX
1164	E69B	A6 2E		RTS ; GO TO HANDLER INDIRECTLY
1165	E69D	60		

ERR LINE

CENTRAL INPUT/OUTPUT (CIO) 2-7-79

PAGE

28

```

1166          . PAGE
1167          ; DEVSRC -- DEVICE SEARCH, FIND DEVICE IN HANDLER ADDRESS TABLE
1168          ; 
1169          ; LOOP TO FIND DEVICE
1170          DEVSRC: LDY #0          ; GET DEVICE NAME FROM USER
1171          E69E  A0 00          (ICBALZ), Y
1172          E6A0  B1 24          CIERR2
1173          F0 0C          BEQ #MAXDEV
1174          E6A2  A0 21          LDY HATABS, Y
1175          E6A4  D9 1A 03          DEVS1: CMP DEVS2
1176          E6A6  F0 0A          BEQ YES
1177          E6A8  BB          DEY
1178          E6AC  BB          DEY
1179          E6AD  BB          DEY
1180          E6AE  10 F6          BPL DEVS1      ; CONTINUE FOR ALL DEVICES
1181          ; NO DEVICE FOUND, DECLARE NON-EXISTENT DEVICE ERROR
1182          E6B0  A0 82          CIERR2: LDY #NONDEV
1183          E6B0  A0 82          SEC           ; ERROR CODE
1184          E6B2  38          SEC           ; SHOW ERROR
1185          E6B3  B0 13          BCS           ; AND RETURN
1186          ; FOUND DEVICE, SET ICHID, ICNDN, AND INIT DEVICE
1187          E6B5  98          DEVS2: TYA ICHIDZ      ; SAVE HANDLER INDEX
1188          E6B6  85 20          STA ICHIDZ
1189          E6B6  85 20          SEC
1190          E6B8  38          SEC
1191          E6B9  A0 01          SEC
1192          E6BB  B1 24          #1
1193          E6BD  E9 30          LDY (ICBALZ), Y      ; GET DEVICE NUMBER (DRIVE NUMBER)
1194          E6BF  C9 0A          SBC #ASCZERO        ; SUBTRACT ASCII ZERO
1195          E6C1  90 02          CMP #$A           ; IS NUMBER IN RANGE?
1196          E6C3  A9 01          BCC DEVS3
1197          E6C5  85 21          DEVS3: STA ICNDNZ
1198          E6C7  18          CLC           ; ND, DEFAULT TO ONE
1199          ; RETURN
1200          E6CB  60          DEVS4: RTS

```

ERR LINE	ADDR	B1	B2	B3	B4	CENTRAL INPUT/OUTPUT (CIO) 2-7-79	
1202						.PAGE	
1203							
1204							
1205							
1206							
1207							
1208	E6C9	00	04	04	04		
1209	E6CD	04	06	06	06		
1210	E6D1	06	02	08	0A		
1211							
1212	022F					LENGTH	=*-CIDINT
1213	E6D5					CRNTP1	=*
1214						*=\$14	
1215	0014	00				CIOSPR:	.BYTE INTORG-CRNTP1 ; ^GCIO1 IS TOO LONG

PAGE 29

CENTRAL INPUT/OUTPUT (CIO) 2-7-79

```

1216          TITLE 'INTERRUPT HANDLER'
1217          !LIVES ON DK1:INTVH.SRC
1218          SRTIM2 = 6                                ; SECOND REPEAT INTERVAL
1219          0006
1220
1221          ; THIS IS TO MAKE DOS 2 WORK WHICH USED AN ABSOLUTE ADDRESS
1222
1223          *=$E912
1224          E912  4C ED E8
1225          JMP   SETVBL
1226          *SETVBL
1227          E45C  4C ED E8
1228          E45F  4C AE E7
1229          E462  4C OS E9
1230          *INTINV
1231          E46B  4C D5 E6
1232          *VCTABL+INTABS-VDSLST
1233          i
1234          E480  90 E7
1235          E482  8F E7
1236          E484  8F E7
1237          E486  8F E7
1238
1239          E488  B
1240          E490  8F E7
1241          E492  8F E7
1242          E494  8F E7
1243          E496  06 E7
1244          E498  00 00 00
1245          E49C  00 00 00
1246          E4A0  00 00
1247          E4A2  AE E7
1248          E4A4  05 E9
1249
1250          *=$900C
1251
1252          900C A9 E6
1253          900E 8D F9 FF
1254          9011 A9 F3
1255          9013 8D FB FF
1256          9016 A9 E7
1257          9018 8D FB FF
1258          901B A9 91
1259          901D 8D FA FF
1260          9020 60
1261
1262          LDA   #PIRGH
1263          STA   $FFFF9
1264          LDA   #PIRQL
1265          STA   $FFFF8
1266          LDA   #PNMIH
1267          STA   $FFFFB
1268          LDA   #PNMIL
1269          STA   $FFFFA
1270
1271          ; SET UP RAM VECTORS FOR LINBUG VEC

```

ERR LINE	ADDR	B1	B2	B3	B4	INTERRUPT HANDLER
1261						.PAGE
1262						; IRQ HANDLER
1263						; JUMP THRU IMMEDIATE IRQ VECTOR, WHICH ORDINARILY POINTS TO
1264						; SYSTEM IRQ: DETERMINE & CLEAR CAUSE, JUMP THRU SOFTWARE VECTOR.
1265						
1266						
1267						
1268						
1269	E6D5	A9	40			*=INTORG ; VBL ON BUF DLIST OFF***FOR NOW***
1270	E6D7	BD	OE	D4		IHINIT: LDA ##40 ; NMEN
1271	E6DA	A9	3B		STA NMEN	
1272	E6DC	BD	02	D3	LDA ##3B ; PACTL	
1273	E6DF	BD	03	D3	STA PACTL	
1274	E6E2	A9	00		LDA #0 ; MAKE ALL INPUTS	
1275	E6E4	BD	00	D3	STA PORTA	
1276	E6E7	BD	01	D3	STA PORTB	
1277	E6EA	A9	3C		STA PORTB	
1278	E6EC	BD	02	D3	LDA ##3C ; BACK TO PORTS	
1279	E6EF	BD	03	D3	STA PACTL	
1280	E6F2	60			STA PBCTL	
1281	E6F3	6C	16	02	RTS (VIMIRQ)	
1282	E6F6	80			JMP CMPTAB: BYTE \$00 ; BREAK KEY	
1283	E6F7	40			BYTE \$40 ; KEY STROKE	
1284	E6F8	04			BYTE \$04 ; TIMER 4	
1285	E6F9	02			BYTE \$02 ; TIMER 2	
1286	E6FA	01			BYTE \$01 ; TIMER 1	
1287	E6FB	08			BYTE \$08 ; SERIAL OUT COMPLETE	
1288	E6FC	10			BYTE \$10 ; SERIAL OUT READY	
1289	E6FD	20			BYTE \$20 ; SERIAL IN READY	
1290	E6FE					
1291						
1292	E6FE	36			; THIS IS A TABLE OF OFFSETS INTO PAGE 2. THEY POINT TO	
1293	E6FF	08			ADRTAB: BYTE BRKKY-INTABS	
1294	E700	14			BYTE VKEYBD-INTABS	
1295	E701	12			BYTE VTIMR4-INTABS	
1296	E702	10			BYTE VTIMR2-INTABS	
1297	E703	0E			BYTE VTIMR1-INTABS	
1298	E704	0C			BYTE VSERDC-INTABS	
1299	E705	0A			BYTE VSEROR-INTABS	
1300	E706				BYTE VSERIN-INTABS	
1301	E706	48				
1302	E707	AD	OE	D2	SYIRQ: PHA IRGST ; SAVE ACCUMULATOR	
1303	E70A	29	20		AND ##20 ; CHECK FOR SERIAL IN	
1304	E70C	DO	OD		BNE SYIRQ2 ; MASK ALL OTHERS	
1305	E70E	A9	DF		LDA ##DF ; MASK ALL OTHERS	
1306	E710	BD	OE	D2	STA IRGEN	
1307	E713	A5	10		LDA POKMSK	
1308	E715	BD	OE	D2	STA IRGEN	
1309	E718	6C	0A	02	JMP (VSERIN) ; PUT X INTO ACC	
1310	E71B	8A			SYIRQ2: TXA ; SAVE X ONTO STACK	
1311	E71C	48			PHA LDX ##6 ; START WITH SIX OFFSET	
1312	E71D	A2	06		LDA CMPTAB, X ; LOAD MASK	
1313	E71F	BD	F6	E6	LOOPM: CPX #5 ; CHECK TO SEE IF COMPLETE IS SET	
1314	E722	EO	05			

ERR LINE	ADDR	B1	B2	B3	B4	INTERRUPT HANDLER		PAGE	32
1315	E724	DO	04			BNE	LOOPM2	; IS THIS INTERRUPT ENABLED?	
1316	E726	25	10			AND	POKMSK		
1317	E728	FO	05			BEQ	LL	; IS IT THE INTERRUPT?	
1318	E72A	2C	0E	D2		LOOPM2:	BIT		
1319	E72D	FO	06			BEG	JMP		
1320	E72F	CA				DEX	LL:		
1321	E730	10	ED			BPL	LOOPM	; NO DEC X AND TRY NEXT MASK	
1322	E732	4C	62	E7		JMP	SYIRGB	; IF NOT NEG GOTO LOOPM	
1323	E735	49	FF			EDR	#\$FF	; DONE BUT NO INTERRUPT	
1324	E737	BD	0E	D2		STA	IRGEN	; COMPLEMENT MASK	
1325	E73A	A5	10			LDA	POKMSK	; ENABLE ALL OTHERS	
1326	E73C	BD	0E	D2		STA	IRGEN	; GET POKE MASK	
1327	E73F	BD	FE	E6		LDA	ADRTAB,X	; ENABLE THOSE IN POKE MASK	
1328	E742	AA				TAX			
1329	E743	BD	00	02		LDA	INTABS,X	; GET ADDRESS LOW PART	
1330	E746	BD	BC	02		STA	JVECK	; PUT IN VECTOR	
1331	E749	BD	01	02		LDA	INTABS+1,X	; GET ADDRESS HIGH PART	
1332	E74C	BD	BD	02		STA	JVECK+1	; PUT IN VECTOR HIGH PART	
1333	E74F	68				PLA		; PULL X REGISTER FROM STACK	
1334	E750	AA				TAX			
1335	E751	6C	8C	02		JMP	(JVECK)	; PUT IT INTO X	
1336	E754	A9	00			LDA	#0	; JUMP TO THE PROPER ROUTINE	
1337	E756	B5	11			STA	BRKEY	; BREAK KEY ROUTINE	
1338	E758	BD	FF	02		STA	SSFLAG	; SET BREAK KEY FLAG	
1339	E75B	BD	FO	02		STA	CRSINH	; START/STOP FLAG	
1340	E75E	85	4D			STA	ATRACT	; CURSOR INHIBIT	
1341	E760	68				PLA		; TURN OFF ATTRACT MODE	
1342	E761	40				RTI			
1343	E762	68				SYIRQ8:	PLA	; EXIT FROM INT	
1344	E763	AA				TAX			
1345	E764	2C	02	D3		BIT		; PROCEED ***I GUESS***	
1346	E767	10	06			BPL	SYIRQ9	; CLEAR INT STATUS BIT	
1347	E769	AD	00	D3		LDA	PORTA	; (VPRCD)	
1348	E76C	6C	02	02		JMP	PBCTL	; INTERRUPT ***I GUESS***	
1349	E76F	2C	03	D3		BIT	SYIRGA	; SYIRGA	
1350	E772	10	06			BPL	PORTB	; PORTB	
1351	E774	AD	01	D3		LDA	(VINTER)	; CLEAR INT STATUS	
1352	E777	6C	04	02		JMP	SYIRQA:	; VINTER	
1353	E77A	68				PLA	JVECK		
1354	E77B	BD	8C	02		STA			
1355	E77E	68				PLA			
1356	E77F	48				PHA		; B BIT OF P REGISTER	
1357	E780	29	10			AND	#\$10		
1358	E782	FO	07			BEG	SYRT12		
1359	E784	AD	BC	02		LDA	JVECK		
1360	E787	48				PHA			
1361	E788	6C	06	02		JMP	(VBREAK)		
1362	E78B	AD	BC	02		LDA	JVECK		
1363	E78E	48				PHA			
1364	E78F	68				SYIRQB:	PLA		
1365	E790	40				SYRT1:	RTI	; UNIDENTIFIED INTERRUPT, JUST RETURN.	

ERR LINE	ADDR	B1	B2	B3	B4	INTERRUPT HANDLER	PAGE	PAGE
1366						; PAGE		
1367						; NMI HANDLER		
1368								
1369						; DETERMINE CAUSE AND JUMP THRU VECTOR		
1370								
1371	E791	2C	0F	D4				
1372	E794	10	03			PNMI: BIT NMIST		
1373	E796	6C	00	02		PNMI1: BPL PNMI1		
1374	E799	48				JMP (VDSLST)		
1375	E79A	AD	0F	D4		PNMI1: PHA NMIST		
1376	E79D	29	20			LDA NMIST		
1377	E79F	F0	03			AND #\$20		
1378	E7A1	4C	74	E4		BEQ *+5		
1379	E7A4	8A				JMP WARMU		
1380	E7A5	48				TXA		
1381	E7A6	98				PHA		
1382	E7A7	48				TYA		
1383	E7A8	8D	0F	D4		PHA		
1384	E7AB	6C	22	02		STA NMIRE		
1385						JMP (VVBK1)		
						; RESET INTERRUPT STATUS		
						; JUMP THRU VECTOR		

ERR	LINE	ADDR	B1	B2	B3	B4	PAGE	INTERRUPT HANDLER
1386								
1387								
1388								
1389								
1390								
1391								
1392								
1393	E7AE	E6 14						
1394	E7BO	DO 08						
1395	E7B2	E6 4D						
1396	E7B4	E6 13						
1397	E7B6	DO 02						
1398	E7BB	E6 12						
1399	E7BA	A9 FE						
1400	E7BC	A2 00						
1401	E7BE	A4 4D						
1402	E7C0	10 06						
1403	E7C2	85 4D						
1404	E7C4	A6 13						
1405	E7C6	A9 F6						
1406	E7CB	B5 4E						
1407	E7CA	86 4F						
1408	E7CC	A2 00						
1409	E7CE	20 DO E8						
1410	E7D1	DO 03						
1411	E7D3	20 CA E8						
1412	E7D6	A5 42						
1413	E7DB	DO 08						
1414	E7DA	BA						
1415	E7DB	BD 04 01						
1416	E7DE	29 04						
1417	E7EO	F0 03						
1418	E7E2	4C 05 E9						
1419	E7E5	AD OD D4						
1420	E7E8	BD 35 02						
1421	E7EB	AD OC D4						
1422	E7EE	BD 34 02						
1423	E7F1	AD 31 02						
1424	E7F4	BD 03 D4						
1425	E7F7	AD 30 02						
1426	E7FA	BD 02 D4						
1427	E7FD	AD 2F 02						
1428	E800	BD 00 D4						
1429	E803	AD 6F 02						
1430	E806	BD CO 02						
1431	E809	A2 08						
1432	E80B	8E 01 F DO						
1433	E80E	5B						
1434	E80F	BD CO 02						
1435	E812	45 4F						
1436	E814	25 4E						
1437	E816	9D 12 DO						
1438	E819	CA						
1439	E81A	10 F2						

```

1440 E81C AD F4 02 LDA CHBAS
1441 E81F BD 09 D4 STA CHBASE
1442 E822 AD F3 02 LDA CHACT
1443 E825 BD 01 D4 STA CHACTL
1444 E82B A2 02 LDX #2 ; POINT TO TIMER 2
1445 E82A 20 DO E8 JSR DCTIMR
1446 E82D DO 03 BNE SYSVB4 ; IF DIDNT GO ZERO
1447 E82F 20 CD E8 JSR JTMR2 ; GO JUMP TO TIMER2 ROUTINE
1448 E832 A2 02 SYSVB4: LDX #2 ; RESTORE X
1449 E834 E8 SYSVBB: INX
1450 E835 EB INX
1451 E836 BD 18 02 LDA CDTMV1,X
1452 E839 1D 19 02 DRA CDTMV1+1,X
1453 E83C F0 06 BEQ SYSVBA ; DECREMENT AND SET FLAG IF NONZERO
1454 E83E 20 DO E8 JSR DCTIMR
1455 E841 9D 26 02 STA CDTMF3-4,X
1456 E844 EO 08 SYSVBA: CPX #$B ; SEE IF DONE ALL 3
1457 E846 DO EC ; CHECK DEBOUNCE COUNTER
1458 E848 AD OF D2 LDA SKSTAT
1459 E84B 29 04 AND $$04 ; KEY DOWN BIT
1460 E84D F0 08 BEQ SYVBB6A ; IF KEY DOWN
1461 E84F AD F1 02 ; KEY UP SO COUNT IT
1462 E852 F0 03 LDA KEYDEL ; KEY DELAY COUNTER
1463 E854 CE F1 02 BEQ SYVBB6A ; IF COUNTED DOWN ALREADY
1464 E855 AD 2B 02 DEC KEYDEL ; COUNT IT
1465 E857 AD 2B 02 ; CHECK SOFTWARE REPEAT TIMER
1466 E85A F0 17 SYSVBB6A: LDA SRTIMR ; DOESN'T COUNT
1467 E85C AD 0F D2 BEQ SYSVBB7 ; CHECK KEY DOWN BIT
1468 E85F 29 04 LDA SKSTAT
1469 E861 DO 60 AND $$04 ; BRANCH IF NO LONGER DOWN
1470 E863 CE 2B 02 BNE SRTIMR ; COUNT FRAME OF KEY DOWN
1471 E866 DO 0B DEC BNE SRTIMR ; BRANCH IF NOT RUN OUT
1472 E86D AD 09 D2 ; TIMER RAN OUT - RESET AND SIMULATE KEYBOARD IRQ
1473 E870 BD FC 02 STA #SRTIM2 ; TIMER VALUE
1474 E873 A9 06 STA SRTIMR ; SET TIMER
1475 E87B A0 01 STA KBCODE ; GET THE KEY
1476 E87C A2 03 STA CH ; PUT INTO CH
1477 E877 B9 00 D3 ; READ GAME CONTROLLERS
1478 E87A 4A SYSVBB7: LDY #1
1479 E87E 9D 7B 02 STLOOP: LDA PORTA,Y
1480 E881 CA LSR A ; STORE JOYSTICK
1481 E882 B9 00 D3 LDA PORTA,Y
1482 E885 29 OF AND #$F ; STORE JOYSTICK
1483 E887 9D 7B 02 STA STICKO,X ; STORE JOYSTICK
1484 E888 CA DEX
1485 E889 4A LSR A
1486 E88D 4A LSR A
1487 E88E 4A LSR A
1488 E88F CA STA STICKO,X ; STORE JOYSTICK
1489 E890 4A LSR A
1490 E895 4A STA STICKO,X ; STORE JOYSTICK
1491 E897 4A DEX
1492 E89A CA DEY
1493 E89B 88

```

```

1494 EBBBC 10 E9          ; BPL      STLOOP
1495           i
1496 EBBE A2 03          ; STRL:   LDX    #3
1497 EBB90 BD 10 D0        ; LDA     TRIGO, X
1498 EBB93 9D 84 02        ; STA     STRIGO, X
1499 EBB96 BD 00 D2        ; LDA     POTO, X
1500 EBB99 9D 70 02        ; STA     PADDL0, X
1501 EBB9C BD 04 D2        ; STA     POT4, X
1502 EBB9F 9D 74 02        ; STA     PADDL4, X
1503 EBA2 CA              ; DEX
1504 EBA3 10 EB              ; BPL   STRL
1505 EBA5 8D 0B D2        ; STA   POTGO ; START POTS FOR NEXT TIME
1506           i
1507 EBA8 A2 06          ; LDX    #6
1508 EBA9 A0 03          ; LDY    #3
1509 EBAAC B9 78 02       ; PTRLP: LDA   STICKO, Y ; TRANSFER BITS FROM JOYSTICKS
1510 EBAF 4A              ; LSR   A ; TO PADDLE TRIGGERS
1511 EBB0 4A              ; LSR   A
1512 EBB1 4A              ; LSR   A
1513 EBB2 9D 7D 02       ; STA   PTRIG1, X
1514 EBB5 A9 00          ; LDA   #0
1515 EBB7 2A              ; ROL   A
1516 EBB8 9D 7C 02       ; STA   PTRIGO, X
1517 EBBB CA              ; DEX
1518 EBBC CA              ; DEX
1519 EBBDD BB             ; DEY
1520 EBBE 10 EC             ; BPL   PTRLP
1521           i
1522 EBC0 6C 24 02       ; SV7H   (VBLKD) ; GO TO DEFERRED VBLANK ROUTINE
1523 00EB                 ; =      SYSVB7/256
1524 0073                 ; SV7L   (-256)*SV7H+SYSVB7
1525 EBC3 A9 00          ; LDA   #0
1526 EBC5 BD 2B 02       ; STA   SRTIMR ; ZERO TIMER
1527 EBCB F0 A9          ; BEQ   SYSVB7 ; UNCOND
1528 EBCA 6C 26 02       ; JTMR1: JMP  (CDTMA1)
1529 EBCD 6C 28 02       ; JTMR2: JMP  (CDTMA2)
1530           i
1531           i
1532           i
1533           i
1534           i
1535 EBD0 BC 18 02       ; DCTIMR: LDY  CDTMV1, X ; LD BYTE
1536 EBD3 D0 08          ; BNE  DCTIMI ; NONZERO, GO DEC IT
1537 EBD5 BC 19 02       ; LDY  CDTMV1+1, X ; SEE IF BOTH ZERO
1538 EBD8 F0 10          ; BEQ  DCTXF ; YES, EXIT NONZERO
1539 EBDAA DE 19 02      ; DEC  CDTMV1+1, X ; DEC HI BYTE
1540 EBDDE DE 18 02      ; DEC  CDTMV1, X ; DEC LO BYTE
1541 EBE0 DO 08          ; BNE  DCTXF
1542 EBE2 BC 19 02       ; LDY  CDTMV1+1, X
1543 EBE5 D0 03          ; BNE  DCTXF ; WENT ZERO, RETURN ZERO
1544 EBE7 A9 00          ; LDA   #0
1545 EBE9 60              ; RTS
1546 EBEA A9 FF          ; DCTXF: LDA   #$FF ; RETURN NONZERO
1547 EBECC               ; RTS

```

ERR LINE ADDR B1 B2 B3 B4 INTERRUPT HANDLER

37

PAGE

ERR LINE ADDR B1 B2 B3 B4

INTERRUPT HANDLER

PAGE 38

1585 TITLE 'SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)'
1586 COLLEEN OPERATING SYSTEM
1587 SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)
1588 WITH SOFTWARE BAUD RATE CORRECTION ON CASSETTE
1589
1590
1591
1592 AL MILLER 3-APR-79
1593
1594
1595
1596 THIS MODULE HAS ONE ENTRY POINT. IT IS CALLED BY THE DEVICE
1597 HANDLERS. IT INTERPRETS A PREVIOUSLY ESTABLISHED DEVICE CONTROL
1598 BLOCK (STORED IN GLOBAL RAM) TO ISSUE COMMANDS
1599 TO THE SERIAL BUS TO CONTROL TRANSMITTING AND RECEIVING DATA.
1600
1601
1602
1603

ERR LINE	ADDR	B1	B2	B3	B4	SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)	PAGE
1604							39
1605							
1606							
1607	0030						
1608							
1609							
1610	0060						
1611							
1612							
1613							
1614							
1615	0052						
1616	0057						
1617							
1618							
1619							
1620							
1621							
1622							
1623							
1624	0053						
1625	004E						
1626	0044						
1627	0050						
1628							
1629							
1630							
1631							
1632	0041						
1633	004E						
1634	0043						
1635	0045						
1636							
1637							
1638							
1639							
1640	0028						
1641	0000						
1642	00CC						
1643	0005						
1644	0005						
1645	0007						
1646							
1647							
1648							
1649							
1650	,						
1651							
1652							
1653							
1654	00B4						
1655	007B						
1656	000F						
1657	000A						

EQUATES PAGE

; DCD DEVICE BUS ID NUMBERS
 FLOPPY = \$30
 PRINTR = \$40
 CASSET = \$60
 CASET = \$60
;

; BUS COMMANDS

READ = 'R
 WRITE = 'W
 STATIS = 'S
 FORMAT = '!
;

; COMMAND AUX BYTES

SIDWAY = 'S
 NORMAL = 'N
 DOUBLE = 'D
 PLOT = 'P
;

; BUS RESPONSES

ACK = 'A
 NACK = 'N
 COMPLT = 'C
 ERROR = 'E
;

; MISCELLANEOUS EQUATES

B192LO = \$28
 B192HI = \$00
 B600LO = \$CC
 B600HI = \$05
 HITONE = \$05
 LOTONE = \$07
;
 .IF PAFLGL
 WIRGLO = 150
 RIRGLO = 100
 WSTRG = 13
 RSIRG = 8
.ENDIF
;

PAFLGL
 .IF
 WIRGLO = 180
 RIRGLO = 120
 WSTRG = 15
 RSIRG = 10
;

PAFLG-1
 .IF
 WIRGLO = 180
 RIRGLO = 120
 WSTRG = 15
 RSIRG = 10
;

ERR LINE

ADDR B1 B2 B3 B4

PAGE 40

S10 (SERIAL BUS INPUT/OUTPUT CONTROLLER)

```

1658          .ENDIF
WIRGHI = 0
RIRGHI = 0
;
NCOML0 = $34 ;PIA COMMAND TO LOWER NOT COMMAND LINE
NCOMH1 = $3C ;PIA COMMAND TO RAISE NOT COMMAND LINE
MOTRGD = $34 ;PIA COMMAND TO TURN ON CASSETTE MOTOR
MOTRST = $3C ;PIA COMMAND TO TURN OFF MOTOR
;
TEMPHI = TEMP/256 ;ADDRESS OF TEMP CELL (HI BYTE)
TEMPLO = (-256)*TEMPHI+TEMP ;(LO BYTE)
CBUFHI = CDEVIC/256 ;ADDRESS OF COMMAND BUFFER (HI BYTE)
CBUFL0 = (-256)*CBUFHI+CDEVIC ;(LO BYTE)
;
CRETRI = 13 ;NUMBER OF COMMAND FRAME RETRIES
DRETRI = 1 ;NUMBER OF DEVICE RETRIES
CTIMLD = 2 ;COMMAND FRAME ACK TIME OUT (LO BYTE)
CTIMHI = 0 ;COMMAND FRAME ACK TIME OUT (HI BYTE)
;
JTADRH = JTIMER/256 ;HI BYTE OF JUMP TIMER ROUTINE ADDR
(-256)*JTADRH+JTIMER ;"MOVED TO LINE 1428" "M"
;
JTADRL =
;
;
```

ERR LINE ADDR B1 B2 B3 B4

SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)

PAGE 41

1681 :PAGE
1682 :SIO
1683 :
1684 :
1685 E459 4C 59 E9 :SIOV
1686 E465 4C 44 E9 :SIOV SIO ; SIO ENTRY POINT
1687 :SIOINV
1688 E466 4C 44 E9 :SIOINT SIOINT ; SIO INITIALIZATION ENTRY POINT
1689 E467 4C F2 EB :SENDDEV
1690 E468 4C F2 EB :SENDEV
1691 E469 4C F2 EB :SENDEN
1692 E46A 0F EB :VCTABL-INTABS+VSERIN
1693 E46B 90 EA :WORD ISRSIR ; VSERIN
1694 E46C CF EA :WORD ISRODN ; VSEROR
1695 E46D 0F EB :WORD ISRTD ; VSEROV
1696 E46E 90 EA :
1697 E46F CF EA :
1698 E470 0F EB :
1699 E471 90 EA :
1700 E472 CF EA :
1701 E473 0F EB :
1702 E474 90 EA :
1703 E475 CF EA :
1704 E476 0F EB :
1705 E477 90 EA :
1706 E478 CF EA :
1707 E479 0F EB :
1708 E47A 90 EA :
1709 E47B CF EA :
1710 E47C 0F EB :
1711 E47D 90 EA :
1712 E47E CF EA :
1713 E47F 0F EB :
1714 E480 90 EA :
1715 E481 CF EA :
1716 E482 0F EB :
1717 E483 90 EA :
1718 E484 CF EA :
1719 E485 0F EB :
1720 E486 90 EA :
1721 E487 CF EA :
1722 E488 0F EB :
1723 E489 90 EA :
1724 E48A CF EA :
1725 E48B 0F EB :
1726 E48C 90 EA :
1727 E48D CF EA :
1728 E48E 0F EB :
1729 E48F 90 EA :
1730 E490 CF EA :
1731 E491 0F EB :
1732 E492 90 EA :
1733 E493 CF EA :
1734 E494 0F EB :
1735 E495 90 EA :
1736 E496 CF EA :
1737 E497 0F EB :
1738 E498 90 EA :
1739 E499 CF EA :
1740 E49A 0F EB :
1741 E49B 90 EA :
1742 E49C CF EA :
1743 E49D 0F EB :
1744 E49E 90 EA :
1745 E49F CF EA :
1746 E4A0 0F EB :
1747 E4A1 90 EA :
1748 E4A2 CF EA :
1749 E4A3 0F EB :
1750 E4A4 90 EA :
1751 E4A5 CF EA :
1752 E4A6 0F EB :
1753 E4A7 90 EA :
1754 E4A8 CF EA :
1755 E4A9 0F EB :
1756 E4AA 90 EA :
1757 E4AB CF EA :
1758 E4AC 0F EB :
1759 E4AD 90 EA :
1760 E4AE CF EA :
1761 E4AF 0F EB :
1762 E4B0 90 EA :
1763 E4B1 CF EA :
1764 E4B2 0F EB :
1765 E4B3 90 EA :
1766 E4B4 CF EA :
1767 E4B5 0F EB :
1768 E4B6 90 EA :
1769 E4B7 CF EA :
1770 E4B8 0F EB :
1771 E4B9 90 EA :
1772 E4BA CF EA :
1773 E4Bc 0F EB :
1774 E4Bd 90 EA :
1775 E4Bf CF EA :
1776 E4C0 0F EB :
1777 E4C1 90 EA :
1778 E4C2 CF EA :
1779 E4C3 0F EB :
1780 E4C4 90 EA :
1781 E4C5 CF EA :
1782 E4C6 0F EB :
1783 E4C7 90 EA :
1784 E4C8 CF EA :
1785 E4C9 0F EB :
1786 E4CA 90 EA :
1787 E4CB CF EA :
1788 E4CD 0F EB :
1789 E4CE 90 EA :
1790 E4CF CF EA :
1791 E4D0 0F EB :
1792 E4D1 90 EA :
1793 E4D2 CF EA :
1794 E4D3 0F EB :
1795 E4D4 90 EA :
1796 E4D5 CF EA :
1797 E4D6 0F EB :
1798 E4D7 90 EA :
1799 E4D8 CF EA :
1800 E4D9 0F EB :
1801 E4DA 90 EA :
1802 E4DB CF EA :
1803 E4DC 0F EB :
1804 E4DD 90 EA :
1805 E4DE CF EA :
1806 E4DF 0F EB :
1807 E4E0 90 EA :
1808 E4E1 CF EA :
1809 E4E2 0F EB :
1810 E4E3 90 EA :
1811 E4E4 CF EA :
1812 E4E5 0F EB :
1813 E4E6 90 EA :
1814 E4E7 CF EA :
1815 E4E8 0F EB :
1816 E4E9 90 EA :
1817 E4EA CF EA :
1818 E4EB 0F EB :
1819 E4EC 90 EA :
1820 E4ED CF EA :
1821 E4EF 0F EB :
1822 E4F0 90 EA :
1823 E4F1 CF EA :
1824 E4F2 0F EB :
1825 E4F3 90 EA :
1826 E4F4 CF EA :
1827 E4F5 0F EB :
1828 E4F6 90 EA :
1829 E4F7 CF EA :
1830 E4F8 0F EB :
1831 E4F9 90 EA :
1832 E4FA CF EA :
1833 E4FB 0F EB :
1834 E4FC 90 EA :
1835 E4FD CF EA :
1836 E4FE 0F EB :
1837 E4FF 90 EA :
1838 E400 CF EA :
1839 E401 0F EB :
1840 E402 90 EA :
1841 E403 CF EA :
1842 E404 0F EB :
1843 E405 90 EA :
1844 E406 CF EA :
1845 E407 0F EB :
1846 E408 90 EA :
1847 E409 CF EA :
1848 E40A 0F EB :
1849 E40B 90 EA :
1850 E40C CF EA :
1851 E40D 0F EB :
1852 E40E 90 EA :
1853 E40F CF EA :
1854 E410 0F EB :
1855 E411 90 EA :
1856 E412 CF EA :
1857 E413 0F EB :
1858 E414 90 EA :
1859 E415 CF EA :
1860 E416 0F EB :
1861 E417 90 EA :
1862 E418 CF EA :
1863 E419 0F EB :
1864 E41A 90 EA :
1865 E41B CF EA :
1866 E41C 0F EB :
1867 E41D 90 EA :
1868 E41E CF EA :
1869 E41F 0F EB :
1870 E420 90 EA :
1871 E421 CF EA :
1872 E422 0F EB :
1873 E423 90 EA :
1874 E424 CF EA :
1875 E425 0F EB :
1876 E426 90 EA :
1877 E427 CF EA :
1878 E428 0F EB :
1879 E429 90 EA :
1880 E42A CF EA :
1881 E42B 0F EB :
1882 E42C 90 EA :
1883 E42D CF EA :
1884 E42E 0F EB :
1885 E42F 90 EA :
1886 E430 CF EA :
1887 E431 0F EB :
1888 E432 90 EA :
1889 E433 CF EA :
1890 E434 0F EB :
1891 E435 90 EA :
1892 E436 CF EA :
1893 E437 0F EB :
1894 E438 90 EA :
1895 E439 CF EA :
1896 E43A 0F EB :
1897 E43B 90 EA :
1898 E43C CF EA :
1899 E43D 0F EB :
1900 E43E 90 EA :
1901 E43F CF EA :
1902 E440 0F EB :
1903 E441 90 EA :
1904 E442 CF EA :
1905 E443 0F EB :
1906 E444 90 EA :
1907 E445 CF EA :
1908 E446 0F EB :
1909 E447 90 EA :
1910 E448 CF EA :
1911 E449 0F EB :
1912 E44A 90 EA :
1913 E44B CF EA :
1914 E44C 0F EB :
1915 E44D 90 EA :
1916 E44E CF EA :
1917 E44F 0F EB :
1918 E450 90 EA :
1919 E451 CF EA :
1920 E452 0F EB :
1921 E453 90 EA :
1922 E454 CF EA :
1923 E455 0F EB :
1924 E456 90 EA :
1925 E457 CF EA :
1926 E458 0F EB :
1927 E459 BA :
1928 E45A BE 18 03 :SIO:
1929 E45B A9 01 :TSX STACKP
1930 E45C 85 42 :STA #1
1931 E45D AD 00 03 :LDA CRITIC
1932 E45E C9 60 :DDEVIC
1933 E45F DO 03 :CMP #CASET
1934 E460 4C 80 EB :BNE NOTCST
1935 E461 90 EA :JMP CASENT
1936 E462 CF EA :
1937 E463 0F EB :
1938 E464 90 EA :
1939 E465 CF EA :
1940 E466 0F EB :
1941 E467 90 EA :
1942 E468 CF EA :
1943 E469 0F EB :
1944 E46A 90 EA :
1945 E46B CF EA :
1946 E46C 0F EB :
1947 E46D 90 EA :
1948 E46E CF EA :
1949 E46F 0F EB :
1950 E470 90 EA :
1951 E471 CF EA :
1952 E472 0F EB :
1953 E473 90 EA :
1954 E474 CF EA :
1955 E475 0F EB :
1956 E476 90 EA :
1957 E477 CF EA :
1958 E478 0F EB :
1959 E479 90 EA :
1960 E47A CF EA :
1961 E47B 0F EB :
1962 E47C 90 EA :
1963 E47D CF EA :
1964 E47E 0F EB :
1965 E47F 90 EA :
1966 E480 CF EA :
1967 E481 0F EB :
1968 E482 90 EA :
1969 E483 CF EA :
1970 E484 0F EB :
1971 E485 90 EA :
1972 E486 CF EA :
1973 E487 0F EB :
1974 E488 90 EA :
1975 E489 CF EA :
1976 E48A 0F EB :
1977 E48B 90 EA :
1978 E48C CF EA :
1979 E48D 0F EB :
1980 E48E 90 EA :
1981 E48F CF EA :
1982 E490 0F EB :
1983 E491 90 EA :
1984 E492 CF EA :
1985 E493 0F EB :
1986 E494 90 EA :
1987 E495 CF EA :
1988 E496 0F EB :
1989 E497 90 EA :
1990 E498 CF EA :
1991 E499 0F EB :
1992 E49A 90 EA :
1993 E49B CF EA :
1994 E49C 0F EB :
1995 E49D 90 EA :
1996 E49E CF EA :
1997 E49F 0F EB :
1998 E4A0 90 EA :
1999 E4A1 CF EA :
2000 E4A2 0F EB :
2001 E4A3 90 EA :
2002 E4A4 CF EA :
2003 E4A5 0F EB :
2004 E4A6 90 EA :
2005 E4A7 CF EA :
2006 E4A8 0F EB :
2007 E4A9 90 EA :
2008 E4AA CF EA :
2009 E4AB 0F EB :
2010 E4AC 90 EA :
2011 E4AD CF EA :
2012 E4AE 0F EB :
2013 E4AF 90 EA :
2014 E4B0 CF EA :
2015 E4B1 0F EB :
2016 E4B2 90 EA :
2017 E4B3 CF EA :
2018 E4B4 0F EB :
2019 E4B5 90 EA :
2020 E4B6 CF EA :
2021 E4B7 0F EB :
2022 E4B8 90 EA :
2023 E4B9 CF EA :
2024 E4B0 0F EB :
2025 E4B1 90 EA :
2026 E4B2 CF EA :
2027 E4B3 0F EB :
2028 E4B4 90 EA :
2029 E4B5 CF EA :
2030 E4B6 0F EB :
2031 E4B7 90 EA :
2032 E4B8 CF EA :
2033 E4B9 0F EB :
2034 E4B0 90 EA :
2035 E4B1 CF EA :
2036 E4B2 0F EB :
2037 E4B3 90 EA :
2038 E4B4 CF EA :
2039 E4B5 0F EB :
2040 E4B6 90 EA :
2041 E4B7 CF EA :
2042 E4B8 0F EB :
2043 E4B9 90 EA :
2044 E4B0 CF EA :
2045 E4B1 0F EB :
2046 E4B2 90 EA :
2047 E4B3 CF EA :
2048 E4B4 0F EB :
2049 E4B5 90 EA :
2050 E4B6 CF EA :
2051 E4B7 0F EB :
2052 E4B8 90 EA :
2053 E4B9 CF EA :
2054 E4B0 0F EB :
2055 E4B1 90 EA :
2056 E4B2 CF EA :
2057 E4B3 0F EB :
2058 E4B4 90 EA :
2059 E4B5 CF EA :
2060 E4B6 0F EB :
2061 E4B7 90 EA :
2062 E4B8 CF EA :
2063 E4B9 0F EB :
2064 E4B0 90 EA :
2065 E4B1 CF EA :
2066 E4B2 0F EB :
2067 E4B3 90 EA :
2068 E4B4 CF EA :
2069 E4B5 0F EB :
2070 E4B6 90 EA :
2071 E4B7 CF EA :
2072 E4B8 0F EB :
2073 E4B9 90 EA :
2074 E4B0 CF EA :
2075 E4B1 0F EB :
2076 E4B2 90 EA :
2077 E4B3 CF EA :
2078 E4B4 0F EB :
2079 E4B5 90 EA :
2080 E4B6 CF EA :
2081 E4B7 0F EB :
2082 E4B8 90 EA :
2083 E4B9 CF EA :
2084 E4B0 0F EB :
2085 E4B1 90 EA :
2086 E4B2 CF EA :
2087 E4B3 0F EB :
2088 E4B4 90 EA :
2089 E4B5 CF EA :
2090 E4B6 0F EB :
2091 E4B7 90 EA :
2092 E4B8 CF EA :
2093 E4B9 0F EB :
2094 E4B0 90 EA :
2095 E4B1 CF EA :
2096 E4B2 0F EB :
2097 E4B3 90 EA :
2098 E4B4 CF EA :
2099 E4B5 0F EB :
2100 E4B6 90 EA :
2101 E4B7 CF EA :
2102 E4B8 0F EB :
2103 E4B9 90 EA :
2104 E4B0 CF EA :
2105 E4B1 0F EB :
2106 E4B2 90 EA :
2107 E4B3 CF EA :
2108 E4B4 0F EB :
2109 E4B5 90 EA :
2110 E4B6 CF EA :
2111 E4B7 0F EB :
2112 E4B8 90 EA :
2113 E4B9 CF EA :
2114 E4B0 0F EB :
2115 E4B1 90 EA :
2116 E4B2 CF EA :
2117 E4B3 0F EB :
2118 E4B4 90 EA :
2119 E4B5 CF EA :
2120 E4B6 0F EB :
2121 E4B7 90 EA :
2122 E4B8 CF EA :
2123 E4B9 0F EB :
2124 E4B0 90 EA :
2125 E4B1 CF EA :
2126 E4B2 0F EB :
2127 E4B3 90 EA :
2128 E4B4 CF EA :
2129 E4B5 0F EB :
2130 E4B6 90 EA :
2131 E4B7 CF EA :
2132 E4B8 0F EB :
2133 E4B9 90 EA :
2134 E4B0 CF EA :
2135 E4B1 0F EB :
2136 E4B2 90 EA :
2137 E4B3 CF EA :
2138 E4B4 0F EB :
2139 E4B5 90 EA :
2140 E4B6 CF EA :
2141 E4B7 0F EB :
2142 E4B8 90 EA :
2143 E4B9 CF EA :
2144 E4B0 0F EB :
2145 E4B1 90 EA :
2146 E4B2 CF EA :
2147 E4B3 0F EB :
2148 E4B4 90 EA :
2149 E4B5 CF EA :
2150 E4B6 0F EB :
2151 E4B7 90 EA :
2152 E4B8 CF EA :
2153 E4B9 0F EB :
2154 E4B0 90 EA :
2155 E4B1 CF EA :
2156 E4B2 0F EB :
2157 E4B3 90 EA :
2158 E4B4 CF EA :
2159 E4B5 0F EB :
2160 E4B6 90 EA :
2161 E4B7 CF EA :
2162 E4B8 0F EB :
2163 E4B9 90 EA :
2164 E4B0 CF EA :
2165 E4B1 0F EB :
2166 E4B2 90 EA :
2167 E4B3 CF EA :
2168 E4B4 0F EB :
2169 E4B5 90 EA :
2170 E4B6 CF EA :
2171 E4B7 0F EB :
2172 E4B8 90 EA :
2173 E4B9 CF EA :
2174 E4B0 0F EB :
2175 E4B1 90 EA :
2176 E4B2 CF EA :
2177 E4B3 0F EB :
2178 E4B4 90 EA :
2179 E4B5 CF EA :
2180 E4B6 0F EB :
2181 E4B7 90 EA :
2182 E4B8 CF EA :
2183 E4B9 0F EB :
2184 E4B0 90 EA :
2185 E4B1 CF EA :
2186 E4B2 0F EB :
2187 E4B3 90 EA :
2188 E4B4 CF EA :
2189 E4B5 0F EB :
2190 E4B6 90 EA :
2191 E4B7 CF EA :
2192 E4B8 0F EB :
2193 E4B9 90 EA :
2194 E4B0 CF EA :
2195 E4B1 0F EB :
2196 E4B2 90 EA :
2197 E4B3 CF EA :
2198 E4B4 0F EB :
2199 E4B5 90 EA :
2200 E4B6 CF EA :
2201 E4B7 0F EB :
2202 E4B8 90 EA :
2203 E4B9 CF EA :
2204 E4B0 0F EB :
2205 E4B1 90 EA :
2206 E4B2 CF EA :
2207 E4B3 0F EB :
2208 E4B4 90 EA :
2209 E4B5 CF EA :
2210 E4B6 0F EB :
2211 E4B7 90 EA :
2212 E4B8 CF EA :
2213 E4B9 0F EB :
2214 E4B0 90 EA :
2215 E4B1 CF EA :
2216 E4B2 0F EB :
2217 E4B3 90 EA :
2218 E4B4 CF EA :
2219 E4B5 0F EB :
2220 E4B6 90 EA :
2221 E4B7 CF EA :
2222 E4B8 0F EB :
2223 E4B9 90 EA :
2224 E4B0 CF EA :
2225 E4B1 0F EB :
2226 E4B2 90 EA :
2227 E4B3 CF EA :
2228 E4B4 0F EB :
2229 E4B5 90 EA :
2230 E4B6 CF EA :
2231 E4B7 0F EB :
2232 E4B8 90 EA :
2233 E4B9 CF EA :
2234 E4B0 0F EB :
2235 E4B1 90 EA :
2236 E4B2 CF EA :
2237 E4B3 0F EB :
2238 E4B4 90 EA :
2239 E4B5 CF EA :
2240 E4B6 0F EB :
2241 E4B7 90 EA :
2242 E4B8 CF EA :
2243 E4B9 0F EB :
2244 E4B0 90 EA :
2245 E4B1 CF EA :
2246 E4B2 0F EB :
2247 E4B3 90 EA :
2248 E4B4 CF EA :
2249 E4B5 0F EB :
2250 E4B6 90 EA :
2251 E4B7 CF EA :
2252 E4B8 0F EB :
2253 E4B9 90 EA :
2254 E4B0 CF EA :
2255 E4B1 0F EB :
2256 E4B2 90 EA :
2257 E4B3 CF EA :
2258 E4B4 0F EB :
2259 E4B5 90 EA :
2260 E4B6 CF EA :
2261 E4B7 0F EB :
2262 E4B8 90 EA :
2263 E4B9 CF EA :
2264 E4B0 0F EB :
2265 E4B1 90 EA :
2266 E4B2 CF EA :
2267 E4B3 0F EB :
2268 E4B4 90 EA :
2269 E4B5 CF EA :
2270 E4B6 0F EB :
2271 E4B7 90 EA :
2272 E4B8 CF EA :
2273 E4B9 0F EB :
2274 E4B0 90 EA :
2275 E4B1 CF EA :
2276 E4B2 0F EB :
2277 E4B3 90 EA :
2278 E4B4 CF EA :
2279 E4B5 0F EB :
2280 E4B6 90 EA :
2281 E4B7 CF EA :
2282 E4B8 0F EB :
2283 E4B9 90 EA :
2284 E4B0 CF EA :
2285 E4B1 0F EB :
2286 E4B2 90 EA :
2287 E4B3 CF EA :
2288 E4B4 0F EB :
2289 E4B5 90 EA :
2290 E4B6 CF EA :
2291 E4B7 0F EB :
2292 E4B8 90 EA :
2293 E4B9 CF EA :
2294 E4B0 0F EB :
2295 E4B1 90 EA :
2296 E4B2 CF EA :
2297 E4B3 0F EB :
2298 E4B4 90 EA :
2299 E4B5 CF EA :
2300 E4B6 0F EB :
2301 E4B7 90 EA :
2302 E4B8 CF EA :
2303 E4B9 0F EB :
2304 E4B0 90 EA :
2305 E4B1 CF EA :
2306 E4B2 0F EB :
2307 E4B3 90 EA :
2308 E4B4 CF EA :
2309 E4B5 0F EB :
2310 E4B6 90 EA :
2311 E4B7 CF EA :
2312 E4B8 0F EB :
2313 E4B9 90 EA :
2314 E4B0 CF EA :
2315 E4B1 0F EB :
2316 E4B2 90 EA :
2317 E4B3 CF EA :
2318 E4B4 0F EB :
2319 E4B5 90 EA :
2320 E4B6 CF EA :
2321 E4B7 0F EB :
2322 E4B8 90 EA :
2323 E4B9 CF EA :
2324 E4B0 0F EB :
2325 E4B1 90 EA :
2326 E4B2 CF EA :
2327 E4B3 0F EB :
2328 E4B4 90 EA :
2329 E4B5 CF EA :
2330 E4B6 0F EB :
2331 E4B7 90 EA :
2332 E4B8 CF EA :
2333 E4B9 0F EB :
2334 E4B0 90 EA :
2335 E4B1 CF EA :
2336 E4B2 0F EB :
2337 E4B3 90 EA :
2338 E4B4 CF EA :
2339 E4B5 0F EB :
2340 E4B6 90 EA :
2341 E4B7 CF EA :
2342 E4B8 0F EB :
2343 E4B9 90 EA :
2344 E4B0 CF EA :
2345 E4B1 0F EB :
2346 E4B2 90 EA :
2347 E4B3 CF EA :
2348 E4B4 0F EB :
2349 E4B5 90 EA :
2350 E4B6 CF EA :
2351 E4B7 0F EB :
2352 E4B8 90 EA :
2353 E4B9 CF EA :
2354 E4B0 0F EB :
2355 E4B1 90 EA :
2356 E4B2 CF EA :
2357 E4B3 0F EB :
2358 E4B4 90 EA :
2359 E4B5 CF EA :
2360 E4B6 0F EB :
2361 E4B7 90 EA :
2362 E4B8 CF EA :
2363 E4B9 0F EB :
2364 E4B0 90 EA :
2365 E4B1 CF EA :
2366 E4B2 0F EB :
2367 E4B3 90 EA :
2368 E4B4 CF EA :
2369 E4B5 0F EB :
2370 E4B6 90 EA :
2371 E4B7 CF EA :
2372 E4B8 0F EB :
2373 E4B9 90 EA :
2374 E4B0 CF EA :
2375 E4B1 0F EB :
2376 E4B2 90 EA :
2377 E4B3 CF EA :
2378 E4B4 0F EB :
2379 E4B5 90 EA :
2380 E4B6 CF EA :
2381 E4B7 0F EB :
2382 E4B8 90 EA :
2383 E4B9 CF EA :
2384 E4B0 0F EB :
2385 E4B1 90 EA :
2386 E4B2 CF EA :
2387 E4B3 0F EB :
2388 E4B4 90 EA :
2389 E4B5 CF EA :
2390 E4B6 0F EB :
2391 E4B7 90 EA :
2392 E4B8 CF EA :
2393 E4B9 0F EB :
2394 E4B0 90 EA :
2395 E4B1 CF EA :
2396 E4B2 0F EB :
2397 E4B3 90 EA :
2398 E4B4 CF EA :
2399 E4B5 0F EB :
2400 E4B6 90 EA :
2401 E4B7 CF EA :
2402 E4B8 0F EB :
2403 E4B9 90 EA :
2404 E4B0 CF EA :
2405 E4B1 0F EB :
2406 E4B2 90 EA :
2407 E4B3 CF EA :
2408 E4B4 0F EB :
2409 E4B5 90 EA :
2410 E4B6 CF EA :
2411

```

1735 ; ALL DEVICES EXCEPT CASSETTE ARE INTELLIGENT
1736
1737 NOTCST: LDA #O
1738 E96B A9 00
1739 E96D BD 0F 03 ; INIT CASSETTE FLAG TO NO CASSETTE
1740
1741 E970 A9 01
1742 E972 85 37 ; SET NUMBER OF DEVICE RETRIES
1743 E974 A9 0D ; SET NUMBER OF COMMAND FRAME RETRIES
1744 E976 85 36
1745
1746 ; SEND A COMMAND FRAME
1747 E978 A9 28 ; SET BAUD RATE TO 19200
1748 E97A BD 04 D2
1749 E97D A9 00
1750 E97F BD 06 D2
1751
1752 ; COMFRM: LDA #B192L0
1753 E982 18 ; SET UP COMMAND BUFFER
1754 E983 AD 00 03
1755 E986 6D 01 03
1756 E989 69 FF ; SUBTRACT 1
1757 E98B BD 3A 02 ; SET BUS ID NUMBER
1758
1759 E98E AD 02 03
1760 E991 BD 3B 02 ; SET BUS COMMAND
1761
1762 E994 AD 0A 03 ; STORE COMMAND FRAME AUX BYTES 1 AND 2
1763 E997 BD 3C 02
1764 E99A AD 0B 03
1765 E99D BD 3D 02
1766
1767 E9A0 18 ; SET BUFFER POINTER TO COMMAND FRAME BUFFER
1768 E9A1 A9 3A
1769 E9A3 85 32 ; AND BUFFER END ADDRESS
1770 E9A5 69 04 ;#4
1771 E9A7 85 34
1772 E9A9 A9 02
1773 E9AB 85 33
1774 E9AD 85 35
1775
1776 E9AF A9 34 ; DONE SETTING UP BUFFER POINTER
1777 E9B1 BD 03 D3 ; LOWER NOT COMMAND LINE
1778
1779 E9B4 20 8A EC ; SENDIN
1780
1781 E9B7 AD 3F 02 ; SEND THE COMMAND FRAME TO A SMART DEVICE
1782 E9BA DO 03 ; ERRFLG
1783
1784 E9BC 98 ; BADCOM
1785 E9BD DO 07 ; BRANCH IF AN ERROR RECEIVED
1786
1787 ; ACKREC
1788 E9BF C6 36 ; BRANCH IF ACK RECEIVED
1789 ; RETRY
1790 ; A NACK OR TIME OUT OCCURED

```

ERR LINE	ADDR	B1 B2 B3 B4	S10 (SERIAL BUS INPUT/OUTPUT CONTROLLER)			PAGE
1789	E9C1	10 B5	i	BPL	COMFRM	; SO BRANCH IF ANY RETRIES LEFT
1790	E9C3	4C 06 EA	i	JMP	DERR1	; OTHERWISE, JUMP TO RETURN SECTION
1792			i			
1793	E9C6	AD 03 03	i	ACKREC: LDA	DSTATS	; ACK WAS RECEIVED
1794	E9C9	10 OC	i	BPL	WATCOM	; BRANCH TO WAIT FOR COMPLETE ,
1795			i			
1796			i			
1797			i			
1798			i			
1799			i			
1800			i			
1801	E9CB	A9 OD	i	LDA	#CRETRI	; SET NUMBER OF RETRIES
1802	E9CD	85 36	i	STA	CRETRY	
1803			i			
1804			i			
1805	E9CF	20 6A EB	i	JSR	LDPNTR	; LOAD BUFFER POINTER WITH DCB INFORMATION
1806			i			
1807	E9D2	20 8A EC	i	JSR	SENDIN	; GO SEND THE DATA FRAME TO A SMART DEVICE
1808			i			
1809	E9D5	F0 EB	i	BEG	BADCOM	; BRANCH IF BAD
1810			i			
1811			i			
1812			i			
1813			i			
1814	E9D7	20 75 EC	i	WATCOM: JSR	STTMOT	; SET DDEVICE TIME OUT VALUES IN Y, X
1815			i			
1816			i			
1817	E9DA	A9 00	i	LDA	#\$00	
1818	E9DC	8D 3F 02	i	STA	ERRFLG	; CLEAR ERROR FLAG
1819			i			
1820	E9DF	20 9B EC	i	JSR	WAITER	; SET UP TIMER AND WAIT
1821	E9E2	F0 12	i	BEG	DERR	; BRANCH IF TIME OUT
1822			i			
1823			i			
1824			i			
1825	E9E4	2C 03 03	i	BIT	DSTATS	
1826	E9E7	70 07	i	BVS	MODATA	; BRANCH IF MORRE DATA FOLLOWS
1827			i			
1828			i			
1829	E9E9	AD 3F 02	i	LDA	ERRFLG	
1830	E9EC	DO 18	i	BNE	DERR1	; BRANCH IF AN ERROR OCCURRED
1831	E9EE	F0 1D	i	BEG	RETURN	; OTHERWISE RETURN
1832			i			
1833			i			
1834			i			
1835			i			
1836			i			
1837	E9F0	20 6A EB	i	MODATA: JSR	LDPNTR	; LOAD BUFFER POINTER WITH DCB INFORMATION
1838			i			
1839			i			
1840	E9F3	20 EO EA	i	JSR	RECEIV	; GO RECEIVE A DATA FRAME
1841			i			
1842	E9F6	AD 3F 02	i	DERR: LDA	ERRFLG	

SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)

ERR LINE ADDR B1 B2 B3 B4

1843	E9F9	F0 05		BEG	NOTERR	; BRANCH IF NO ERROR PRECEEDED DATA
1844	E9FB	AD 19 03		LDA STA	TSTAT STATUS	; GET TEMP STATUS ; STORE IN REAL STATUS
1845	E9FE	85 30				
1846	E9FE					
1847						
1848	EA00	A5 30		NOTERR: LDA CMP BEQ	STATUS #SUCCS RETURN	; BRANCH IF COMPLETELY SUCCESSFUL
1849	EA00	C9 01				
1850	EA02	F0 07		DERR1: DEC BMI	DRETRY RETURN	; BRANCH IF OUT OF DEVICE RETRIES
1851	EA04					
1852						
1853	EA06	C6 37				
1854	EA08	30 03				
1855						
1856	EA0A	4C 74 E9		JMP COMMND	COMMAND	; OTHERWISE, ONE MORE TIME
1857						
1858						
1859						
1860	EA0D	20 5F EC		RETURN: JSR SENDDS	SENDDS #0 CRITIC STATUS	; DISABLE POKEY INTERRUPTS
1861	EA10	A9 00				
1862	EA10					
1863	EA12	85 42				
1864	EA14	A4 30				
1865	EA16	8C 03 03				
1866	EA19	60				
1867						
1868						
1869						
1870						
1871						
1872						
1873						
1874						
1875	EA1A	A9 00		WAITS FOR COMPLETE OR ACK		
1876	EA1C	8D 3F 02				
1877						
1878						
1879	EA1F	18		WAITS FOR Y=\$FF IF SUCCESSFUL, Y=\$00 IF NOT		
1880	EA20	A9 3E				
1881	EA22	85 32				
1882	EA24	69 01				
1883	EA26	85 34				
1884	EA28	A9 02				
1885	EA2A	85 33				
1886	EA2C	85 35				
1887						
1888	EA2E	A9 FF				
1889	EA30	85 3C				
1890						
1891	EA32	20 E0 EA				
1892						
1893	EA35	A0 FF				
1894	EA37	A5 30				
1895	EA39	C9 01				
1896	EA3B	DO 19				

; WAIT SUBROUTINE

; WAITS FOR COMPLETE OR ACK

; RETURNS Y=\$FF IF SUCCESSFUL, Y=\$00 IF NOT

WAIT: LDA STA #\$00 ERFLG ; CLEAR ERROR FLAG

CLC LDA #TEMPLO BUFRLO

STA ADC #1 ; LOAD BUFFER POINTER WITH ADDRESS

STA BFENLO ; OF TEMPORARY RAM CELL

LDA #TEMPPHI STA BUFRHI

STA BFENHI ; ALSO SET BUFFER END +1 ADDRESS

STA BFENHI ; DONE LOADING POINTER

LDA #FFF STA NOCKSM ; SET NO CHECKSUM FOLLOWS DATA FLAG

JSR RECEIV ; GO RECEIVE A BYTE

LDY #\$FF ; ASSUME SUCCESS

LDA CMP NWOK

BNE ; BRANCH IF IT DID NOT WORK OK

ERR LINE ADDR B1 B2 B3 B4 S10 (SERIAL BUS INPUT/OUTPUT CONTROLLER)

PAGE 45

```

1897
1898
1899
1900
1901 EA3D AD 3E 02      ; MAKE SURE THE BYTE SUCCESSFULLY RECEIVED
1902 EA40 C9 41      ; WAS ACTUALLY AN ACK OR COMPLETE
1903 EA42 F0 21      ; GOOD
1904 EA44 C9 43      ; #COMPLT
1905 EA46 F0 1D      ; GOOD

1906          ; TEMP
1907 EA48 C9 45      ; #ACK
1908 EA4A DO 06      ; BEQ
1909          ; GOOD
1910 EA4C A9 90      ; #COMPLT
1911 EA4E B5 30      ; BEQ
1912 EA50 DO 04      ; GOOD

1913          ; BRANCH IF DEVICE DID NOT SEND BACK
1914 EA52 A9 BB      ; ERROR CODE
1915 EA54 B5 30      ; NOTDER: LDA #DNACK
1916          ; STATUS
1917 EA56 A5 30      ; STA STATUS
1918 EA58 C9 8A      ; CMP #TIMOUT
1919 EASA F0 07      ; BEQ BAD
1920          ; BRANCH IF TIME OUT
1921 EA5C A9 FF      ; LDA STATUS
1922 EA5E BD 3F 02      ; STA ERRFLG
1923 EA61 DO 02      ; BNE GOOD
1924          ; SET SOME ERROR FLAG
1925 EA63 A0 00      ; BAD: LDY #0
1926          ; RETURN WITH OUT SETTING Y = 0
1927 EA65 A5 30      ; GOOD: LDA STATUS
1928 EA67 BD 19 03      ; STA TSTAT
1929 EA6A 60          ; RTS
1930          ; RETURN

1931          ; OTHERWISE SET NACK STATUS
1932          ; STATUS
1933          ; #TIMOUT
1934          ; BAD
1935          ; STATUS
1936          ; TSTAT
1937          ; RTS
1938          ; RETURN

1939          ; SEND SUBROUTINE
1940 EA6B A9 01      ; SEND: LDA #SUCCES
1941 EA6D B5 30      ; STA STATUS
1942          ; ASSUME SUCCESS
1943 EA6F 20 F2 EB      ; JSR SENDEN
1944          ; ENABLE SENDING
1945 EA72 A0 00      ; LDY #0
1946 EA74 84 31      ; STY CHKSUM
1947 EA76 84 3B      ; STY CHKSNT
1948 EA78 84 3A      ; STY XMTDON
1949          ; CLEAR CHECK SUM
1950          ; TRANSMISSION DONE FLAG

```

ERR LINE	ADDR	B1	B2	B3	B4	SID (SERIAL BUS INPUT/OUTPUT CONTROLLER)	PAGE
1951	EA7A	B1	32			LDA (BUFRLO), Y ;PUT FIRST BYTE FROM BUFFER	46
1952	EA7C	BD	OD	D2		SEROUT ;INTO THE SERIAL OUTPUT REGISTER	
1953							
1954							
1955	EA7F	85	31			STA CHKSUM ;PUT IT IN CHECKSUM	
1956							
1957	EAB1	A5	11			NOTDON: LDA BRKEY	
1958	EAB3	DO	03			BNE NTBRKO	
1959	EAB5	4C	A0	ED		JMP BROKE	
1960						; JUMP IF BREAK KEY PRESSED	
1961	EABB	A5	3A			NTBRKO: LDA XMTDON	
1962	EABA	FO	F5			BEG NOTDON	
1963						;LOOP UNTIL TRANSMISSION IS DONE	
1964	EABC	20	5F	EC			
1965	EABF	60				JSR SENDDS	
1966						; DISABLE SENDING	
1967						RTS	
1968						; RETURN	
1969							
1970							
1971							
1972							
1973							
1974							
1975	EA90	98				ISRODN: TYA ;SAVE Y REG ON STACK	
1976	EA91	48				PHA	
1977							
1978	EA92	E6	32			INC INC	
1979	EA94	DO	02			BUFRLO NOWRPO	
1980	EA96	E6	33			BUNRHI BUFRHI	
1981						; INCREMENT BUFFER POINTER	
1982	EA98	A5	32				
1983	EAA9	C5	34			NOWRPO: LDA BUFRLO	
1984	EAC9	A5	33			CMP BFENL0	
1985	EAE9	E5	35			LDA BUFRHI	
1986	EAA0	90	1C			SBC BFENHI	
1987						BCC NOTEND	
1988	EAA2	A5	3B				; BRANCH IF NOT PAST END OF BUFFER
1989	EAA4	DO	0B			LDA CHKSNT	
1990						BNE RELONE	
1991	EAA6	A5	31				; BRANCH IF CHECKSUM ALREADY SENT
1992	EAA8	BD	OD	D2		LDA CHKSUM	
1993	EAB8	A9	FF			STA SEROUT	
1994	EAAD	85	3B			LDA #\$FF	
1995	EAAF	DO	09			STA CHKSNT	
1996						BNE CHKDNN	
1997	EAB1	A5	10			RELONE: LDA POKMSK	
1998	EAB3	09	08			ORA #\$08	
1999	EAB5	85	10			STA POKMSK	
2000	EAB7	BD	OE	D2		STA IRGEN	
2001							
2002	EABA	68				CHKDON: PLA	
2003	EABB	A8				TAY	
2004	EABC	68				PLA	
						; RESTORE Y REG	
						; RETURN FROM INTERRUPT	

```

ERR LINE ADDR B1 B2 B3 B4      SIO ( SERIAL BUS INPUT/OUTPUT CONTROLLER )

2005 EABD 40          RTI
2006
2007 EABE A0 00          ;NOTEND: LDY #0
2008 EAC0 B1 32          ;(BUFRLO), Y ;PUT NEXT BYTE FROM
2009 EAC2 BD 0D D2          ;SEROUT ;INTO THE SERIAL
2010
2011 EAC5 18          ;ADD IT TO CHECKSUM
2012 EAC6 65 31          ;CHKSUM
2013 EAC8 69 00          ;#0
2014 EACA 85 31          ;CHKSUM
2015
2016 EACC 4C BA EA          ;CHKDON ;GO RETURN
2017
2018
2019
2020
2021
2022
2023
2024
2025 EACF A5 3B          ;TRANSMIT DONE INTERRUPT SERVICE ROUTINE
2026 EAD1 F0 0B          ;ISRTD: LDA CHKSNT
2027          BEQ FD0EY ;BRANCH IF CHECKSUM
2028
2029 EAD3 85 3A          ;XMTDON ;OTHERWISE SET TRANSMIT
2030 EAD5 A5 10          ;LDA POKMSK
2031 EAD7 29 F7          ;AND #$F7 ;DISABLE TRANSMIT
2032 EAD9 85 10          ;STA POKMSK
2033          STA IRGEN ;IRGEN
2034 EADB 8D 0E D2          ;RETURNS FROM INTERRUPT
2035
2036 EADE 68          ;FD0EY: PLA
2037 EADF 40          ;RTI
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047 EAE0 A9 00          ;RECEIV: LDA #0
2048
2049 EAE2 AC OF 03          ;LDY CASFLG
2050 EAE5 DO 02          ;BNE NOCLR ;BRANCH IF CASSETTE
2051
2052
2053 EAE7 85 31          ;CHKSUM ;CLEAR CHKSUM
2054 EAE9 85 38          ;BUFRL ;BUFFER FULL FLAG
2055 EAEB 85 39          ;RECVDN ;RECEIVE DONE FLAG
2056
2057

```


ERR LINE	ADDR	B1	B2	B3	B4	SID (SERIAL BUS INPUT/OUTPUT CONTROLLER)	PAGE
2113	EB29	AD	OD	D2		i LDA	49
2114	EB2C	C5	31			CMP	
2115	EB2E	FO	04			BEQ	
2116						SRETBN	
2117	EB30	AO	BF			#CHKERR	
2118	EB32	84	30			STATUS	
2119						; SET CHECKSUM ERROR STATUS	
2120	EB34	A9	FF			i SRETRN:	
2121	EB36	85	39			LDA	
2122						#\$FF	
2123	EB38	68				RECVDN	
2124	EB39	AB				; SET RECEIVE DONE FLAG	
2125	EB3A	6B					
2126	EB3B	40					
2127							
2128							
2129							
2130	EB3C	AD	OD	D2		i NOT YET:	
2131	EB3F	AO	00			LDA	
2132						LDY	
2133	EB41	91	32			STA	
2134							
2135	EB43	18				i CLC	
2136	EB44	65	31			ADC	
2137	EB46	69	00			ADC	
2138	EB48	85	31			STA	
2139							
2140	EB4A	E6	32			i INC	
2141	EB4C	DO	02			BUFRLO	
2142	EB4E	E6	33			NTWRP1	
2143						BUFRHI	
2144	EB50	A5	32			i NTWRP1:	
2145	EB52	C5	34			LDA	
2146	EB54	A5	33			CMP	
2147	EB56	E5	35			LDA	
2148	EB58	90	DE			BUFRHI	
2149						BFENHI	
2150	EB5A	A5	3C			SBC	
2151	EB5C	FO	06			BUCC	
2152							
2153	EB5E	A9	00			i LDA	
2154	EB60	85	3C			STA	
2155						NOCKSM	
2156	EB62	FO	DO			; CLEAR NO CHECKSUM FLAG	
2157						i BEQ	
2158	EB64	A9	FF			SRETBN	
2159	EB66	85	38			; GD RETURN AND SET RECEIVE DONE FLAG	
2160						i LDA	
2161						STA	
2162	EB68	DO	CE			#\$FF	
2163						BUFRFL	
2164						; SET BUFFER FULL FLAG	
2165						SUSUAL	
2166						; GO RETURN	

ERR LINE ADDR B1 B2 B3 B4

SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)

PAGE 50

2167
2168
2169
2170 ; LOAD BUFFER POINTER SUBROUTINE
2171 ;
2172 ; LOAD BUFFER POINTER WITH DCB BUFFER INFORMATION
2173 ;
2174 ;
2175 EB6A 18 LDPNTR: CLC DBUFLO
2176 EB6B AD 04 03 STA BUFRLO
2177 EB6E 85 32 ADC DBYTLO
2178 EB70 6D 08 03 STA BFENLO ; ALSO SET BUFFER END + 1 ADDRESS
2179 EB73 85 34 ;
2180 ;
2181 EB75 AD 05 03 LDA DBUFHI
2182 EB78 85 33 STA BUFRHI
2183 EB7A 6D 09 03 ADC DBYTHI
2184 EB7D 85 35 STA BFENHI
2185 ;
2186 EB7F 60 RTS ; RETURN
2187 ;
2188 ;
2189 ;
2190 ;
2191 ;
2192 ;
2193 ;
2194 ;
2195 ; CASSETTE HANDLING CODE
2196 2197 EBB0 AD 03 03 CASENT: LDA DSTATS ; BRANCH IF INPUT FROM CASSETTE
2198 EBB3 10 2E BPL CASRED ;
2199 ;
2200 ;
2201 EBB5 A9 CC ;
2202 EBB5 A9 CC LDA #B60OOL ; SET BAUD RATE TO 600
2203 EBB7 8D 04 D2 STA AUDF3
2204 EBB8 A9 05 LDA #B60OHI
2205 EBB8 BD 06 D2 STA AUDF4
2206 ;
2207 EBBF 20 F2 EB ;
2208 EBB92 A0 OF ;
2209 EBB94 AD 0B 03 LDY #WSIRG
2210 EBB94 A0 OF ; DAUX2
2211 EBB97 30 02 BMI SRTIRO ; BRANCH IF SHORT GAP IS DESIRED
2212 ;
2213 EBB97 A0 B4 ;
2214 EBB9B A2 00 SRTIRO: LDY #WIRGLD
2215 EB9D 20 B9 ED LDX #WIRGHI
2216 ;
2217 EBA0 A9 34 JSR SETVBX
2218 EBA2 8D 02 D3 ;
2219 EBA5 AD 17 03 TIMIT: LDA #MOTRGD
2220 ; PACTL
; TURN ON MOTOR
; LOOP UNTIL DONE

ERR LINE	ADDR	B1	B2	B3	B4	S10 (SERIAL BUS INPUT/OUTPUT CONTROLLER)		PAGE	51
22221	EBA8	DO	FB			BNE	TIMIT		
22222	EBAA	20	6A	EB		JSR	LDPNTR	; LOAD BUFFER POINTER WITH DCB INFORMATION	
22223	EBAA	20	6B	EA		JSR	SEND		
22224	EBAD	20	6B	EA		JSR	SEND	; SEND A BUFFER	
22225	EBAD	20	6C	EB		JMP	CRETNR	; GO RETURN	
22226	EBBO	4C	DF	EB					
22227	EBBO	4C	OD	EA					
22228									
22229									
22230									
22231									
22232	EBB3	A9	FF						
22233	EBB5	8D	0F	03		CASRD:	LDA	#\$FF	
22234	EBB5	8D	0F	03			STA	CASFGL	; SET SET CASSETTE FLAG
22235	EBB8	A0	OA				LDY	#RSIRG	
22236	EBB8	A0	OB	03			LDA	DAUX2	
22237	EBBA	AD	OB	03			BMI	SRTIR1	
22238	EBBD	30	02						; BRANCH IF SHORT GAP IS DESIRED
22239									
22240	EBBF	A0	7B				LDY	#RIRGLD	
22241	EBC1	A2	00			SRTIR1:	LDX	#RIRGHI	
22242	EBC3	20	B9	ED			JSR	SETVBX	
22243									
22244	EBC6	A9	34				LDA	#MOTRGD	
22245	EBCB	BD	02	D3			STA	PACTL	; TURN ON MOTOR
22246									
22247	EBCB	AD	17	03		TIMIT1:	LDA	TIMFLG	
22248	EBCE	DO	FB				BNE	TIMIT1	
22249									
22250	EBDO	20	6A	EB			JSR	LDPNTR	
22251	EBD3	20	75	EC					
22252	EBD3	20	B9	ED			JSR	STTMOT	
22253	EBD6	20	B9	ED				SETVBX	
22254									
22255	EBD9	20	10	ED			JSR	BEGIN	
22256									
22257	EBDC	20	E0	EA			JSR	RECEIV	
22258									
22259	EBDF	AD	OB	03		CRETNR:	LDA	DAUX2	
22260	EBE2	30	05				BMI	SRTIR2	; BRANCH IF DOING SHORT INTER RECORD GAPS
22261									
22262	EBE4	A9	3C				DON'T TURN OFF CASSETTE MOTOR		
22263	EBE6	8D	02	D3			LDA	#MOTRST	
22264							STA	PACTL	
22265	EBE9	4C	OD	EA					; TURN OFF MOTOR
22266									
22267									
22268									
22269									
22270	EBEC	A9	00						
22271	OOEB					JTIMER:	LDA	#\$00	
22272	OOEC					JTADRH	=	JTIMER/256	; HI BYTE OF JUMP TIMER ROUTINE ADDR
22273						JTADR1	=	(-256)*JTADRH+JTIMER	
22274	ESEE	8D	17	03		STA		TIMEFLG	; SET TIME OUT FLAG

ERR LINE

ADDR B1 B2 B3 B4
2275 EBF1 60
2276
2277
2278
2279
2280
2281
2282
2283
2284 EBF2 A9 07
2285 EBF4 2D 32 02
2286 EBF7 09 20
2287 EBF9 AC 00 03
2288 EBFC CO 60
2289 EBFE DO OC
2291
2292 ECO0 09 08
2293
2294 EC02 A0 07
2295 EC04 8C 02 D2
2296 EC07 A0 05
2297 ECO9 8C 00 D2
2298
2299 EC0C BD 32 02
2300 ECOF BD 0F D2
2301
2302 EC12 A9 C7
2303 EC14 25 10
2304 EC16 09 10
2305
2306
2307 EC18 4C 31 EC
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320 EC1B A9 07
2321 EC1D 2D 32 02
2322 EC20 09 10
2323 EC22 BD 32 02
2324 EC25 BD OF D2
2325
2326 EC28 BD OA D2
2327 EC2B A9 C7
2328

SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)

PAGE 52

RTS

; SEND ENABLE SUBROUTINE
SENDEN: LDA #\$07 ; MASK OFF PREVIOUS SERIAL BUS CONTROL BITS
AND SSKCTL
ORA #\$20 ; SET TRANSMIT MODE
LDY DDEVIC
CPY #CASET
BNE NOTCAS ; BRANCH IF NOT CASSETTE
ORA #\$08 ; SET THE FSK OUTPUT BIT
LDY #LOTONE
STY AUDF2
LDY #HITONE
STY AUDF1 ; SET FSK TONE FREQUENCIES
NOTCAS: STA SSKCTL ; STORE NEW VALUE TO SYSTEM MASK
STA SKCTL ; STORE TO ACTUAL REGISTER
LDA #\$C7 ; MASK OFF PREVIOUS SERIAL BUS INTERRUPT BITS
AND POKMSK
ORA #\$10 ; ENABLE OUTPUT DATA NEEDED INTERRUPT
CONTIN : JMP CONTIN ; GO CONTINUE IN RECEIVE ENABLE SUBROUTINE
RECEVEN: LDA #\$07 ; MASK OFF PREVIOUS SERIAL BUS CONTROL BITS
AND SSKCTL
ORA #\$10 ; SET RECEIVE MODE ASYNCH.
STA SSKCTL
STA SKCTL ; STORE NEW VALUE TO SYSTEM MASK
; STORE TO ACTUAL REGISTER
STA SKRES ; RESET SERIAL PORT/KEYBOARD STATUS REGISTER
LDA #\$C7 ; MASK OFF PREVIOUS SERIAL BUS INTERRUPT BITS

ERR LINE	ADDR	B1	B2	B3	B4	SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)		PAGE	53
2329	EC2D	25	10			AND	POKMSK	; ENABLE RECEIVE INTERRUPT	
2330	EC2F	09	20			ORA	#\$20	; STORE NEW VALUE TO SYSTEM MASK	
2331	EC31	85	10			CONTIN:	POKMSK	; STORE TO ACTUAL REGISTER	
2332	EC33	8D	OE	D2		STA	IRGEN		
2333									
2334									
2335	EC36	A9	2B			LDA	#\$28	; CLOCK CH. 3 WITH 1.79 MHZ	
2336	EC38	8D	0B	D2		STA	AUDCTL	; CLOCK CH. 4 WITH CH. 3	
2337									
2338	EC3B	A2	06			LDX	#6	; SET PURE TONES, NO VOLUME	
2339	EC3D	A9	A8			LDA	#\$A8		
2340	EC3F	A4	41			LDY	SDUNDR	; TEST QUIET I/O FLAG	
2341	EC41	DO	02			BNE	NOISE1	; NE IS NORMAL (NOISY)	
2342	EC43	A9	A0			LDA	#\$AO		
2343	EC45	9D	01	D2		NOISE1:	STA	AUDC1,X	
2344	EC48	CA				DEX			
2345	EC49	CA				DEX			
2346	EC4A	10	F9			BPL	NOISE1		
2347									
2348	EC4C	A9	A0			LDA	#\$AO	; TURN OFF SOUND ON CHANNEL 3	
2349	EC4E	BD	05	D2		STA	AUDC3		
2350	EC51	AC	00	03		LDY	DDEVIC		
2351	EC54	CO	60			CPY	#CASET		
2352	EC56	F0	06			BEQ	CAS31	; BRANCH IF CASSETTE IS DESIRED	
2353	EC58	BD	01	D2		STA	AUDC1	; OTHERWISE TURN OFF CHANNELS 1 AND 2	
2354	EC5B	BD	03	D2		STA	AUDC2		
2355									
2356									
2357	EC5E	60				CAS31:	RTS	; RETURN	
2358									
2359									
2360									
2361									
2362									
2363									
2364									
2365									
2366									
2367									
2368								; DISABLE SEND AND DISABLE RECEIVE SUBROUTINES	
2369									
2370	EC5F	EA	A9	C7		SENDDS:	NOP	; MASK OFF SERIAL BUS INTERRUPTS	
2371	EC60	A9	00			RECVDS:	LDA	#\$C7	
2372	EC62	25	10			AND	POKMSK		
2373	EC64	85	10			STA	POKMSK		
2374	EC66	BD	OE	D2		STA	IRGEN		
2375									
2376	EC69	A2	06			LDX	#6		
2377	EC6B	9D	01	D2		LDA	*0		
2378	EC6D	CA				ZERIT:	STA		
2379	EC70	CA				DEX			
2380	EC71	CA				DEX			
2381	EC72	10	F9			BPL	ZERIT	; TURN OFF AUDIO VOLUME	
2382									

ERR LINE ADDR B1 B2 B3 B4

SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)

PAGE 54

```

2383 EC74 60          RTS          ; RETURN

2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396 EC75 AD 06 03      STTMOT: LDA    DTIMLO  ; GET DEVICE TIME OUT IN 1 SECOND INCR
2397 EC7B 6A          ROR    A       ; PUT 6 HI BITS IN X, LO 2 BITS IN Y
2398 EC79 6A          ROR    A
2399 EC7A A8          TAY    i TEMP SAVE
2400 EC7B 3F          AND    #$3F   ; MASK OFF 2 HI BITS
2401 EC7D AA          TAX    i THIS IS HI BYTE OF TIME OUT
2402
2403 EC7E 98          TYA    i RESTORE
2404 EC7F 6A          ROR    A       ; MASK OFF ALL BUT 2 HI BITS
2405 ECB0 29 CO      AND    #$CO   ; THIS IS LO BYTE OF TIME OUT
2406 ECB2 A8          TAY
2407
2408 ECB3 60          RTS
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419 EC84 0F EB      INTTBL: WORD   ISRSIR  ; SERIAL INPUT READY
2420 ECB6 90 EA      WORD   ISRDN  ; OUTPUT DATA NEEDED
2421 ECB8 CF EA      WORD   ISRTD  ; TRANSMISSION DONE
2422
2423 00EB             SIRHI = ISRSIR/256 ; SERIAL INPUT READY ISR ADDRESS
2424 000F             SIRLO = (-256)*SIRHI+ISRSIR
2425 00EA             ODNH1 = ISRDN/256 ; OUTPUT DATA NEEDED ISR ADDRESS
2426 0090             ODNL0 = (-256)*ODNH1+ISRODN
2427 00EA             TDHI = ISRDN/256 ; TRANSMISSION DONE ISR ADDRESS
2428 00CF             TDLO = (-256)*TDHI+ISRTD
2429
2430
2431
2432
2433
2434
2435
2436 ECB8 A2 01      SENDIN: LDX   SEND A DATA FRAME TO AN INTELLIGENT PERIPHERAL SUBROUTINE

```

```

PAGE 55

ERR LINE ADDR B1 B2 B3 B4 SIO ( SERIAL BUS INPUT/OUTPUT CONTROLLER )

2437 ECBC A0 FF DELAYO: LDY #$FF
2438 ECBE B8 DEY
2439 ECBF DO FD BNE DELAY1
2440 EC91 CA DEX
2441 EC92 DO FB BNE DELAYO
2442 EC94 20 6B EA i JSR SEND ; GO SEND THE DATA FRAME
2444 EC97 A0 02 LDY #CTIMLO
2445 EC99 A2 00 LDX #CTIMHI
2446 EC9B 20 B9 ED JSR WAIT ; SET ACK TIME OUT
2447 EC9B 20 B9 ED WAITER: JSR SETVBX
2448 EC9E 20 1A EA i JSR TYA ; WAIT FOR ACK
2449 EC9E 20 1A EA i IF Y=0, A TIME OUT OR NACK OCCURED
2450 EC91 98 i RTS ; RETURN
2451 EC91 98 i
2452 EC92 60 i
2453 EC92 60 i
2454 EC92 60 i
2455 EC92 60 i
2456 EC92 60 i
2457 EC92 60 i
2458 EC92 60 i
2459 EC92 60 i
2460 EC92 60 i
2461 EC92 60 i
2462 EC92 60 i
2463 EC92 60 i
2464 EC92 60 i
2465 EC92 60 i
2466 EC92 60 i
2467 EC93 8D 10 03 COMPUT: STA TIMER2 ; SAVE FINAL TIMER VALUE
2468 EC94 8C 11 03 STA TIMER2+1 ; ADJUST VCOUNT VALUE
2469 EC95 20 04 ED JSR STA ; SAVE ADJUSTED VALUE
2470 EC96 20 04 ED JSR LDA TIMER2
2471 ECAC BD 10 03 STA TIMER1
2472 ECAF AD 0C 03 LDA TIMER1
2473 ECB2 20 04 ED JSR ADJUST ; ADJUST
2474 ECB5 8D 0C 03 STA TIMER1 ; SAVE ADJUSTED TIMER1 VALUE
2475 ECBB AD 10 03 LDA TIMER2
2476 ECBB 38 SEC
2477 ECBE ED 0C 03 STA TIMER1 ; FIND VCOUNT DIFFERENCE
2478 ECBF BD 12 03 STA TEMP1
2479 ECC2 AD 11 03 LDA TIMER2+1
2480 ECC5 38 SEC
2481 ECC6 ED 0D 03 STA TIMER1+1
2482 ECC9 A8 TAY ; FIND VBLANK COUNT DIFFERENCE
2483 ECCB AD 10 03 PALFLG
2484 ECCD 0C 03 LDA #-9C
2485 ECFC 0C 03 CLC
2486 ECFF 0D 03 ADC ; ENDIF
2487 ECC9 A8 LDA #-983
2488 ECCA A9 7D CLC
2489 ECCC 1B HITIMR: LDA
2490 ECCC 1B HITIMR: CLC

```

ERR LINE	ADDR	B1	B2	B3	B4	SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)	PAGE	56
2491	ECCD	69	83			ADC #\$83 ; ACCUMULATE MULTIPLICATION		
2492	ECCF	88				.ENDIF .DEY BPL CLC ADC TEMP1		
2493	ECCD	10	FA			HITMR TAY		; DONE?
2494	ECD0	18				LSR		
2495	ECD2	18				LSR	A	
2496	ECD3	6D	12	03		LSR	A	
2497	ECD6	A8			FINDX:	ASL	A	
2498	ECD7	4A				SEC		
2499	ECD8	4A				SBC	#22	
2500	ECD9	4A				TAX		
2501	ECDA	0A				TYA		
2502	ECDB	38				AND	#7	
2503	ECDC	E9	16			TAY		
2504	ECDE	AA				LDA	#-11	
2505	ECDF	98				DOINTP:	CLC	
2506	ECE0	29	07			ADC	#11	
2507	ECE2	A8				DEY		
2508	ECE3	A9	F5			BPL		
2509	ECE5	18				DOINTP		
2510	ECE6	69	0B			DEC		
2511	ECE8	88				ADDCCR		
2512	ECE9	10	FA			STY		
2513						SEC		
2514	ECEB	A0	00			SBC	#7	
2515	ECED	8C	0E	03		BPL		
2516	ECF0	38				DEC		
2517	ECF1	E9	07			CLC		
2518	ECF3	10	03			ADDCOR		
2519	EFC5	CE	0E	03		POKTAB, X		
2520	EFCB	18				TAY		
2521	EFCF	7D	DO	ED		LDA		
2522	EFCF	A8				ADC		
2523	EFCF	AD	0E	03		POKTAB+1, X		
2524	ED00	7D	D1	ED		RTS		
2525	ED03	60						
2526								
2527								
2528								
2529								
2530								
2531								
2532	ED04	C9	7C			ROUTINE TD ADJUST VCOUNT VALUE		
2533	ED06	30	04			ADJUST: CMP #\$\$7C		
2534	ED08	38				BMI ADJ1		
2535	ED09	E9	7C			SEC		
2536	ED0B	60				SBC #\$\$7C		
2537	ED0C	18				RTS		
2538						CLC		
2539						IF PALFLG		
2540						ADC #\$20		
2541	ED0D	69	07			ENDIF		
2542						IF PALFLG-1		
2543						ADC #\$7		
2544	ED0F	60				RTS		

ERR LINE ADDR B1 B2 B3 B4 SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)

PAGE 57

SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)

PAGE 57

ERR LINE ADDR B1 B2 B3 B4

SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER) PAGE 58

```

2599 ED60 A4 14 LDY RTCLK+2 ; READ TIMER LO & HI BYTES
2600 ED62 20 A3 EC JSR COMPUTE ; NO, COMPUTE BAUD RATE
2601 ED65 BC EE 02 STA CBAUDL ; SET BAUD RATE INTO RAM CELLS
2602 ED68 BD EF 02 STA CBAUDH ; #9
2603 ED6B A0 09 LDY #9 ; SET BIT COUNTER FOR 9 BITS
2604 ED6D DO CC BNE COUNT

2605 LDY GOREAD: LDA CBAUDL ; SET POKEY FREQ REGS FOR BAUD RATE
2606 ED6F AD EE 02 STA AUDF3
2607 ED72 8D 04 D2 STA CBAUDH ; INIT. POKEY SERIAL PORT
2608 ED75 AD EF 02 STA AUDF4 ; #0
2609 ED78 8D 06 D2 STA SKSTAT ; SET POKEY FREQ REGS FOR BAUD RATE
2610 ED7B A9 00 LDA #55 ; INIT. POKEY SERIAL PORT
2611 ED7D 8D 0F D2 STA SKSTAT ; STORE CHECKSUM FOR 2 BYTES OF '$AA'
2612 ED80 AD 32 02 STA SKSTAT ; INIT. POKEY SERIAL PORT
2613 ED83 BD 0F D2 STA #55 ; STORE CHECKSUM FOR 2 BYTES OF '$AA'
2614 ED86 A9 55 LDA (BUFRLO), Y ; STORE '$55' AS FIRST RCV. BUFFER
2615 ED88 91 32 STA INY
2616 ED8A C8 STA (BUFRLO), Y ; STORE CHECKSUM FOR 2 BYTES OF '$AA'
2617 ED8B 91 32 STA #55
2618 ED8D A9 AA STA CHKSUM ; STORE CHECKSUM FOR 2 BYTES OF '$AA'
2619 EDBF 85 31 STA CLC
2620 ED91 1B STA BUFRLO ; CLR
2621 ED92 A5 32 LDA #2 ; RETURN
2622 ED94 69 02 ADC STA BUFRLO ; TURN OFF MOTOR
2623 ED96 85 32 STA BUFRHI ; RAISE NOT COMMAND LINE
2624 ED98 A5 33 LDA #0 ; RETURN
2625 ED9A 69 00 ADC STA BUFRHI ; INCR. BUFFER POINTER BY 1
2626 ED9C 85 33 CLI
2627 ED9E 58 RTS
2628 ED9F 60

2629 LDY BROKE: JSR SENDS ; BREAK KEY WAS PRESSED, SO PREPARE
2630 2631 EDAO 20 5F EC ; TO RETURN
2632 EDAO A9 3C #MOTRST
2633 EDAO 8D 02 D3 STA PACTL
2634 EDAO 8D 03 D3 STA PBCTL
2635 EDAO A9 80 #BRKABT ; STORE BREAK ABORT STATUS CODE
2636 EDAO 85 30 STA STATUS
2637 EDAO AE 18 03 ; RESTORE STACK POINTER
2638 EDAD 9A ; RESTORE STACK POINTER
2639 EDAF DEC BRKKEY ; SET BREAK KEY FLAG TO NONZERO
2640 EDAF 4C 0D EA ; ALLOW IRQ'S
2641 EDB2 58 ; GO RETURN
2642 EDB3 C6 11 ; STORE TIME OUT ROUTINE ADDRESS
2643 EDB5 58 ; STORE TIME OUT ROUTINE ADDRESS
2644 EDB6 4C 0D EA ; STORE TIME OUT ROUTINE ADDRESS
2645 EDB7 58 ; STORE TIME OUT ROUTINE ADDRESS
2646 EDB8 4C 0D EA ; STORE TIME OUT ROUTINE ADDRESS
2647 EDB9 A9 EC ; STORE TIME OUT ROUTINE ADDRESS
2648 EDBA 58 ; STORE TIME OUT ROUTINE ADDRESS
2649 EDBB 58 ; STORE TIME OUT ROUTINE ADDRESS
2650 EDBC 58 ; STORE TIME OUT ROUTINE ADDRESS
2651 EDBD 58 ; STORE TIME OUT ROUTINE ADDRESS
2652 EDBE 58 ; STORE TIME OUT ROUTINE ADDRESS
2653 EDBF 58 ; STORE TIME OUT ROUTINE ADDRESS

```

ERR LINE	ADDR	B1	B2	B3	B4	S10 (SERIAL BUS INPUT/OUTPUT CONTROLLER)			PAGE	59
2653	EDBB	8D	26	02		STA	CDTMA1			
2654	EDBE	A9	EB			LDA	#JTAZRH			
2655	EDCO	8D	27	02		STA	CDTMA1+1			
2656										
2657	EDC3	A9	01			LDA	#1	; SET FOR TIMER 1		
2658										
2659	EDC5	78				SEI		; THE SETVBL ROUTINE NEEDS THIS TO CUT SHORT		
2660	EDC6	20	5C	E4		JSR		; ANY VBLANKS THAT OCCUR		
2661	EDC9	A9	01			LDA	#1	; SET FOR TIMER 1		
2662	EDCB	8D	17	03		STA		; SET FLAG TO NOT TIMED OUT		
2663	EDCE	5B				CLI				
2664	EDCF	60				RTS				
2665										
2666										
2667										
2668										
2669										
2670										
2671								'VCOUNT' INTERVAL TIMER MEASUREMENT -- TO -- POKEY FREQ REG VALUE		
2672										
2673										
2674										
2675										
2676										
2677								THE VALUES STORED IN THE TABLE ARE 'AUDF+7'.		
2678										
2679								THE FOLLOWING FORMULAS WERE USED TO DETERMINE THE TABLE VALUES:		
2680								F OUT= F IN/(2*(AUDF+M)) , WHERE F IN=1.78979 MHZ. & M=7		
2681										
2682								FROM THIS WAS DERIVED THE FORMULA USED TO COMPUTE THE		
2683								TABLE VALUES BASED ON A MEASUREMENT OF THE PERIOD BY		
2684								AN INTERVAL OF THE 'VCOUNT' TIMER.		
2685										
2686								AUDF+7=(11.365167)*T OUT, WHERE T OUT=# OF COUNTS		
2687								(127 USEC. RESOLUTION) OF 'VCOUNT' FOR 1		
2688								CHARACTER TIME (10 BIT TIMES).		
2689										
2690										
2691										
2692										
2693										
2694								AUDF+7	BAUD RATE	VCOUNT INTERVAL
2695										
2696										
2697										
2698										
2699	EDD0	E8	03			WORD	\$27C			56
2700	EDD2	43	04			WORD	\$2D7			64
2701	EDD4	9E	04			WORD	\$332			72
2702	EDD6	F9	04			WORD	\$38D			80
2703	EDD8	54	05			WORD	\$3E8			88
2704	EDDA	AF	05			WORD	\$443			96
2705	EDDC	DA	06			WORD	\$49E			104
2706	EDDE	65	06			WORD	\$4F9			112
						WORD	\$554			120
						WORD	\$5AF			128
						WORD	\$60A			136
						WORD	\$665			144
						WORD	\$547			

ERR LINE ADDR B1 B2 B3 B4 SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER) PAGE 60

```

2707 EDE0 C0 06 WORD $6C0   / 518
2708 EDE2 1A 07 WORD $71A   / 492
2709 EDE4 75 07 WORD $775   / 469
2710 EDE6 D0 07 WORD $7D0   / 447
2711                   WORD $82B   / 428
2712                   WORD $886   / 410
2713                   WORD $8E1   / 394
2714                   WORD $93C   / 379
2715                   WORD $997   / 365
2716                   WORD $9F2   / 352
2717                   WORD $A4D   / 339
2718                   WORD $AA8   / 328
2719                   WORD $B03   / 318
2720
2721
2722
2723
2724
2725 EDE8 CRNTP3 =*      *****
2726          *= $14      SIOSPR: BYTE DSKORG-CRNTP3 ; ^GSIDL IS TOO LONG
2727 0014 02

```

ERR LINE ADDR B1 B2 B3 B4

SIO (SERIAL BUS INPUT/OUTPUT CONTROLLER)

PAGE 61

2728
2729 TITLE 'DISK **** DISKP. SRC *** 3/9/79 **** 4:00:00 P.M.
2730
2731
2732
2733
2734
2735
2736 0002 DVSTAT/256
2737 00EA (-256)*STATVH+DVSTAT ; STATUS POINTER
2738
2739
2740
2741
2742
2743
2744 0031 CONSTANT EQUATES
2745 0050 DISKID = \$31 ; SERIAL BUS DISK I.D.
2746 PUTSEC = \$50 ; DISK PUT SECTOR DCB COMMAND
2747 READ = \$52 ; DISK GET SECTOR DCB COMMAND
2748 WRITE = \$57 ; DISK PUT SECTOR WITH READ CHECK DCB COMMAND
2749 STATIC = \$53 ; DISK STATUS DCB COMMAND
2750 FOMAT = \$21 ; DISK FORMAT DCB COMMAND !!!!! ***
2751 NODAT = 0 ; SIO COMMAND FOR "NO DATA" OPERATION
2752 GETDAT = \$40 ; SIO COMMAND FOR "DATA FROM DEVICE"
2753 PUTDAT = \$80 ; SIO COMMAND FOR "DATA TO DEVICE"
2754
2755 VECTORS
2756
2757 *=E450
2758
2759 E450 4C EA ED ; JMP DINIT
2760 E453 4C FO ED ; JMP DSKIF ; DISK INIT VECTOR
2761
2762
2763
2764
2765
2766
2767
2768
2769
2770
2771
2772
2773
2774
2775
2776
2777
2778
2779
2780
2781

CONSTANTS
*=DSKORG

***** DISK INTERFACE ROUTINE STARTS HERE *****

ERR LINE

ADDR DISK **** DISKP. SRC ***** 3/9/79 ***** 4:00:00 PAGE 62

```

2782
2783
2784
2785
2786      ; DISK INTERFACE INITIALIZATION ROUTINE
2787      ; DINIT: LDA #160      ; SET INITIAL DISK TIMEOUT TO 160 SEC
2788      EDEA A9 A0      DSKTIM
2789      EDEC BD 46 02      RTS
2790      EDEF 60
2791
2792
2793
2794      ; DISK INTERFACE ENTRY POINT
2795      ; DSKIF: LDA #DISKID      ; SET SERIAL BUS I.D IN DCB
2796      EDF0 A9 31      DDEVIC
2797      EDF2 BD 00 03      DSKTIM
2798      EDF5 AD 46 02      DCOMND
2799      EDF8 AE 02 03      #FORMAT
2800      EDFB E0 21      PUTDTO
2801      EDFD F0 02      BEQ
2802      EDFF A9 07      LDA
2803      EEE1 BD 06 03      STA
2804      EEE4 A2 40      LDX
2805      EEE6 A0 80      LDY
2806      EEE8 AD 02 03      LDA
2807      EEEB C9 57      CMP
2808      EEE0 DO 02      BNE
2809      EEEF A2 80      LDX
2810      EEI1 C9 53      CKSTC
2811      EEI3 DO OC      #PUTDAT
2812      EEI5 A9 EA      #STATC
2813      EEI7 BD 04 03      PUTCNT
2814      EEIA A9 02      LDA
2815      EEIC BD 05 03      #STATVH
2816      EE1F AO 04      STA
2817      EE21 BE 03 03      LDY
2818      EE24 BC 08 03      DSTATS
2819      EE27 A9 00      STX
2820      EE29 BD 09 03      DBYTLD
2821      EE2C 20 59 E4      LDA
2822      EE2F 10 01      STA
2823      EE31 60          JSR
2824      EE32 AD 02 03      BPL
2825      EE35 C9 53      RTS
2826      EE37 DO 0A          LDA
2827      EE39 20 6D EE      JSR
2828      EE3C A0 02          LDY
2829      EE3E B1 15          CMP
2830      EE40 BD 46 02      BNE
2831      EE43 AD 02 03      PUTBC
2832      EE46 C9 21          STA
2833      EE48 DO 1F          LDA
2834      EE4A 20 6D EE      #FORMAT
2835      EE4D A0 FE          #COMND
                                ; READ DISK TIMEOUT VALUE BYTE OF STATUS
                                ; PUT IT IN DISK TIMEOUT REG.
#2
                                ; WAS COMMAND A FORMAT COMMAND?
                                ; YES, PUT BUFFER ADDR INTO TEMP REG
                                ; SET BUFFER POINTER

```


ERR LINE

ADDR

B1 B2 B3 B4

DISK

***** DISKP. SRC ***** 3/9/79 ***** 4:00:00

PAGE

2877
2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2890

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

/

PAGE

***** DISKP. SRC ***** 3/9/79 ***** 4:00:00 PAGE P

PRINTER HANDLER ENTRY POINTS

*=\$E430

WORD PHOPEN-1 ;PRINTER HANDLER OPEN
WORD PHCLOSE-1 ;PH CLOSE
WORD BADST-1 ;PH READ
WORD PHWRIT-1 ;PH WRITE
WORD PHSTAT-1 ;PH STATUS
WORD BADST-1 ;PH SPECIAL
JMP PHINIT ;PH INIT
BYTE 0 ;ROM FILLER

*=PRNORG

PRINTER HANDLER INITIALIZATION ROUTINE

PRINTER ***** PRINTP. SRC ***** 3/9/79 ***** 4: 00

ERR LINE ADDR B1 B2 B3 B4

```

2931 EE78 A9 1E          PHINIT: LDA      #30      ; SET UP INITIAL PRINTER TIMEOUT OF 30 SEC.
2932 EE7A 85 1C          STA      PTIMOT
2933 EE7C 60              RTS

2936          ; PRINTER HANDLER CONSTANTS
2937          ; PHSTLO: WORD    DVSTAT      ; STATUS BUFFER POINTER
2938          ; PHCHLO: WORD    PRNBUF      ; CHAR. BUFFER POINTER
2939          ; *****
2940          ; PRINTER HANDLER ROUTINES
2941          ; *****
2942          ; *****
2943          ; *****
2944          ; *****
2945          ; *****
2946          ; *****
2947          ; *****
2948          ; *****
2949          ; *****
2950          ; *****
2951          ; *****
2952          ; *****
2953          ; *****
2954          ; *****
2955          ; *****
2956          ; *****
2957          ; *****
2958          ; *****
2959          ; *****
2960          ; *****
2961          ; *****
2962          ; *****
2963          ; *****
2964          ; *****
2965          ; *****
2966          ; *****
2967          ; *****
2968          ; *****
2969          ; *****
2970          ; *****
2971          ; *****
2972          ; *****
2973          ; *****
2974          ; *****
2975          ; *****
2976          ; *****
2977          ; *****
2978          ; *****
2979          ; *****
2980          ; *****
2981          ; *****
2982          ; *****
2983          ; *****
2984          ; *****

```

PRINTER HANDLER STATUS ROUTINE

```

PHSTAT: LDA      #4      ; SET BUFFER SIZE TO 4 BYTES
        STA      PBUFSZ
        LDY      PHSTLO
        LDY      PHSTLO+1      ; SET POINTER TO STATUS BUFFER
        LDA      #STATC      ; SET COMMAND TO "STATUS"
        STA      DCOMND      ; SET STATUS COMMAND
        STA      DAUX1       ; GO SETUP DCB
        JSR      SETDCB      ; SEND STATUS COMMAND
        JSR      SIOV         ; GO IF ERROR
        BMI      BADST        ; YES, PUT STATUS INTO GLOBAL BUFFER.
        JSR      PHPUT
        RTS

```

PRINTER HANDLER OPEN ROUTINE

```

PHOPEN: JSR      PHSTAT      ; DO STATUS COMMAND TO SIO
        LDA      #0      ; CLEAR PRINT BUFFER POINTER
        STA      PBPNTR
        RTS

```

PRINTER HANDLER WRITE ROUTINE

```

PHWRIT: STA      PTMP      ; SAVE ACCUM
        JSR      PRMODE     ; GO DETERMINE PRINT MODE
        LDX

```

```

ERR LINE ADDR B1 B2 B3 B4 PRINTER ***** PRINTP. SRC ***** 3/9/79 ***** 4:00 PAGE 66

```

ERR LINE	ADDR	B1	B2	B3	B4	PRINTER	***** PRINTP. SRC *****	3/9/79 *****	4:00	PAGE
3039	EEF3	BD	01	03		STA	DUNIT	; SET UNIT NUMBER TO 1		67
3040	EEF6	A9	80			LDA	##\$80	; DEVICE WILL EXPECT DATA		
3041	EEFB	AE	02	03		LDX	DCOMMND			
3042	EEFB	EO	53			CPX	#STATC			
3043	EEFD	DO	02			BNE	PSIOC			
3044	EEFF	A9	40			LDA	##\$40	; EXPECT DATA FROM DEVICE		
3045	EF01	BD	03	03		PSIQC:	STA	; SET SIO MODE COMMAND.		
3046	EF04	A5	1E			LDA	DSTATS			
3047	EF06	BD	0B	03		STA	PBUFSZ			
3048	EF09	A9	00			DBYTLO				
3049	EF0B	BD	09	03		LDA	#0			
3050	EF0E	A5	1C			STA	DBYTHI			
3051	EF10	BD	06	03		LDA	PTIMOT			
3052	EF13	60				STA	DTIMLD			
3053						RTS				
3054										
3055										
3057										
3058										
3059	EF14	AD	EC	02		PUTP:	LDA	DVSTAT+2		
3060	EF17	85	1C			STA	PTIMOT			
3061	EF19	60				RTS				
3062										
3063										
3064										
3065										
3066										
3067										
3068										
3069	EF1A	A0	57			PRMODE:	LDY	#WRITEC		
3070	EF1C	A5	2B			CMDODE:	LDA	ICAX2Z		
3071	EF1E	C9	4E			CMP	#N			
3072	EF20	DO	04			BNE	CDUBL	; PRINT NORMAL ?		
3073	EF22	A2	28			LDX	#NBUSFSZ			
3074	EF24	DO	0E			BNE	SETBSZ			
3075	EF26	C9	44			CMP	#D			
3076	EF28	DO	04			BNE	CSIDE	; PRINT DOUBLE?		
3077	EF2A	A2	14			LDX	#DBUSFSZ			
3078	EF2C	DO	06			BNE	SETBSZ			
3079	EF2E	C9	53			CMP	*S	; PRINT SIDEWAYS ?		
3080	EF30	DO	0B			BNE	GOERR	; IF NOT, GO TO ERROR ROUTINE		
3081	EF32	42	1D			LDX	#SBUSFSZ	; YES, SET SIDEWAYS BUFFER SIZE		
3082	EF34	B6	1E			SETBSZ:	STX	PBUFSZ		
3083	EF36	BC	02	03		STY	DCOMND	; STORE PRINT BUFFER SIZE		
3084	EF39	BD	0A	03		STA	DAUX1	; STORE DCB COMMAND		
3085	EF3C	60				RTS		; STORE DCB AUX1 PRINT MODE		
3086	EF3D	A9	4E			GOERR:	LDA	#N		
3087	EF3F	DO	DD			BNE	CMODE			
3088										
3089										
3090										
3091										

; SPARE BYTE OR MODULE TOO LONG FLAG

ERR LINE	ADDR	B1	B2	B3	B4	PRINTER	***** PRINTP. SRC *****	3/9/79	*****	4:00	PAGE
3099						PAGE	'CASSET HANDLER 3/12 (DK1: CASCV)'				
3100	0003					TITLE	CBUFH = CASBUF/256				
3101						CBUFL =	(-256)*CBUFH+CASBUF				
3102	00FD					SRSTA =	\$40 ; SIO READ STATUS				
3103	0040					SWSTA =	\$B0 ; SIO WRITE STATUS				
3104	00B0					MOTRGD =	\$34				
3105						MOTRST =	\$3C				
3106						;					
3107						;					
3108	00FC					DTA =	\$FC ; DATA RECORD TYPE BYTE				
3109						DT1 =	\$FA ; LAST DATA RECORD				
3110	00FA					EDT =	\$FE ; END OF TAPE				
3111	00FE					HDR =	\$FB ; HEADER				
3112	00FB					TONE1 =	2 ; CHANGE TO RECORD MODE TONE				
3113	0002					TONE2 =	1 ; PRESS PLAY TONE				
3114	0001					;					
3115						;					
3116						;					
3117						;					
3118	E440	4B	EF	2A	FO	;					
3119		E444	D5	EF	OF						
3120		E444	D5	EF	OF						
3121	E448	27	FO	4A	EF						
3122	E44C	4C	41	EF							
3123	E44F	00									
3124						;					
3125						;					
3126						;					
3127						;	USED IN MONITP FOR CASSETTE BOOT				
3128						;					
3129	E47A	4C	E9	EF		;	*=RBLOKV				
3130						;	JMP RBLCK				
3131						;					
3132	E47D	4C	5D	EF		;	*=CSOPIV				
3133						;	JMP OPINP				
3134						;					
3135						;					
3136						;	*=CASORG				
3137						;					
3138						;	INIT ROUTINE				
3139						;					
3140	EF41	A9	CC	02		INIT:	LDA #\$CC				
3141	EF43	BD	EE	02			STA CBAUDL				
3142							LDA #\$05				
3143	EF46	A9	05				STA CBAUDH	; SET CASSSET BAUD RATE TO 600			
3144	EF48	BD	EF	02				; THATS ALL FOLKS			
3145						SPECIAL:	RTS				
3146	EF4B	60									

```

3147          .PAGE
3148          ; OPEN FUNCTION - WITH NO TIMING ADJUST
3149          ; OPENC:    LDA     ICAX2Z      ; GET AX2
3150          ;           STA     FTYPE      ; SAVE IT FOR FUTURE REFERENCE
3151          EF4C  A5 2B      LDA     ICAX1Z      ; IN AND OUT BITS
3152          EF4E  B5 3E      LDA     AND      #$OC
3153          EF50  A5 2A      LDA     #$04
3154          EF52  29 0C      CMP     BEQ      CMP   #$08
3155          EF54  C9 04      CMP     BEQ      CMP   #$0B
3156          EF56  F0 05      CMP     BEQ      CMP   #$0D
3157          EF58  C9 08      CMP     BEQ      CMP   #$0E
3158          EF5A  F0 39      CMP     BEQ      CMP   #$0F
3159          EF5C  60          CMP     BEQ      CMP   #$10
3160          EF5D  A9 00      OPINP:  RTS      ; IF ALREADY OPEN, RETURN LEAVING STATUS=$84
3161          EF5F  8D 89 02      OPINP:  LDA     #0
3162          EF62  85 3F      WMODE:  STA     WMODE      ; SET READ MODE
3163          EF64  A9 01      SFH:    STA     FE0F      ; NO EOF YET
3164          EF66  20 58  F0      SFH:    LDA     #TONE2      ; TONE FOR PRESS PLAY
3165          EF69  30 24      SFH:    JSR     BEEP      ; GO BEEP
3166          EF6B  A9 34      SFH:    BMI     OPNRTN      ; IF ERROR DURING BEEP
3167          EF6D  8D 02  D3      SFH:    LDA     #MOTRGD      ; TURN MOTOR ON
3168          SFH:    STA     PACTL      ; IF
3169          SFH:    LDY     PALFLG      ; PALFLG
3170          SFH:    LDX     #$E0      ; #$E0
3171          SFH:    LDX     #1
3172          SFH:    IF     PALFLG-1      ; 5-31-79 9 SEC READ LEADER
3173          EF70  A0 40      LDY     #$40
3174          EF72  A2 02      LDY     #2
3175          SFH:    ENDIF
3176          EF74  A9 03      LDA     #3
3177          EF76  BD 2A 02      LDA     CDTMF3      ; SET UP VBLANK TIMER
3178          EF79  20 5C  E4      JSR     SETVBV      ; CDTMF3
3179          EF7C  AD 2A 02      LDA     WAITTM      ; WAIT FOR MOTOR TO COME UP TO SPEED
3180          EF7F  DO FB      BNE     WAITTM      ; NEXT BYTE=NO BYTES IN BUFFER
3181          EF81  A9 80      LDA     #$80
3182          EF83  B5 3D      STA     BPTR      ; BLIM
3183          EF85  BD  BA 02      STA     BLIM      ; OPEN OK
3184          EF88  4C  D3  EF      JMP     OPOK      ; OPEN OK
3185          SFH:    IF     OPEN FOR OUTPUT
3186          SFH:    PBRK:  LDY     #BRKABT      ; BREAK KEY ABORT STATUS
3187          EF8B  A0 80      DEC     BRKKEY      ; RESET BREAK KEY
3188          EF8D  C6 11      OPNRTN: LDA     #O      ; CLEAR WRITE MODE FLAG
3189          EF8F  A9 00      STA     WMODE      ; AND EXIT.
3190          SFH:    RTS
3191          EF91  8D 89 02      SFH:    LDA     #$80
3192          EF94  60          SFH:    STA     WMODE      ; SET WRITE MODE
3193          SFH:    OPOUT: LDA     #TONE1      ; TELL USER TO TURN ON RECORD MODE
3194          EF95  A9 80      STA     BEEP      ; IF ERROR DURING BEEP
3195          EF97  8D 89 02      STA     OPNRTN      ; SET BAUD RATE
3196          EF9A  A9 02      JSR     BMI      ; WHICH SEEKS TO BE NECESSARY
3197          EF9C  20 5B  F0      STA     #$CC
3198          EF9F  30  EE      STA     AUDF3      ; WHICH SEEKS TO BE NECESSARY
3199          EFA1  A9  CC      STA
3200          EFA3  8D  04  D2      STA

```

```

3201 EFA6 A9 05          LDA    #$05      ; FOR SOME OBSCURE REASON
3202 EFA8 8D 06 D2       STA    AUDF4
3203 EFB0 A9 60          LDA    #$60
3204 Efad BD 00 03       STA    DDEVIC
3205 EFB0 20 68 E4       JSR    SENDEV
3206 EFB3 A7 34          LDA    #MOTRG0
3207 EFB5 8D 02 D3       STA    PACTL
3208 EFB8 A9 03          LDA    #3
3209                           IF PALFLG
3210                           LDX    #$3
3211                           LDY    #$CO
3212                           ENDIF
3213                           IF PALFLG-1
3214 EFBA A2 04          LDX    #4
3215 EFB0 A0 80          LDY    $$80
3216                           ENDIF
3217 EFB8 20 5C E4       JSR    SETBV
3218 EFC1 A9 FF          LDA    $$FF
3219 EFC3 8D 2A 02       STA    CDTMF3
3220 EFC6 A5 11          WDLR: LDA    BRKKEY
3221 EFCB F0 C1          BEQ    PBRK
3222 EFCA AD 2A 02       LDA    CDTMF3
3223 EFC0 D0 F7          BNE    WDLR
3224 EFCF A9 00          LDA    #O
3225 EFD1 85 3D          STA    BPTR
3226 EFD3 A0 01          DPOK: #SUCSES
3227 EFD5 60             LDY    RTS

```

CASSET HANDLER 3/12 (DK1: CASCV)

PAGE 72

PAGE

PAGE 72

PAGE

```

32228 .PAGE
32229
32330
32331
32332 EFD6 A5 3F ; GET BYTE
32333 EFD8 30 33 ; GET BYTE
32334 EFDA A6 3D ; GET BYTE
32335 EFDC EC 8A 02 ; GET BYTE
32336 EFDF F0 08 ; GET BYTE
32337 EFE1 BD 00 04 ; GET BYTE
32338 EFE4 E6 3D ; GET BYTE
32339 EFE6 A0 01 ; GET BYTE
32440 EFE8 60 ; GET BYTE
32441 EFE9 A9 52 ; GET BYTE
32442 EFEF B0 95 ; GET BYTE
32443 EFEF 98 ; GET BYTE
32444 EFEF 30 F7 ; GET BYTE
32445 EFFF A9 00 ; GET BYTE
32446 EFFF 85 3D ; GET BYTE
32447 EFFF A2 80 ; GET BYTE
32448 EFFF AD FF 03 ; GET BYTE
32449 EFFA C9 FE ; GET BYTE
32500 EFFF F0 0D ; GET BYTE
32511 EFFE C9 FA ; GET BYTE
32522 F000 D0 03 ; GET BYTE
32533 F002 AE 7F 04 ; GET BYTE
32544 F005 9E 8A 02 ; GET BYTE
32555 F008 4C D6 EF ; GET BYTE
32566 F00B C6 3F ; GET BYTE
32577 F00D A0 88 ; GET BYTE
32588 F00F ; GET BYTE

; IF AT EOF ALREADY
; RETURN EOF STATUS
; BUFFER POINTER
; IF END OF BUFFER
; READ ANOTHER BLOCK
; RBLOK
; BEQ
; LDA CASBUF+3, X
; INC
; LDY RTS
; #R
; JSR SIOSB
; TYA BMI
; LDA #O
; STA BPTR
; LDX #$B0
; LDA CASBUF+2
; #EDT
; BEQ ATEOF
; CMP
; BNE NLR
; LDX CASBUF+130
; BLIN
; JMP STX
; DEC ATEOF
; LDY ISEOF
; RTS

; IF EOF STATUS
; SET FEOF
; #EOFERR
; ENDFILE STATUS
;
```

ERR	LINE	ADDR	B1	B2	B3	B4	CASSET HANDLER 3/12 (DK1: CASCV)	PAGE
3259							. PAGE	
3260							; PUT BYTE TO BUFFER	
3261							; PBYTE: LDX BPTR CASBUF+3, X ; BUFFER POINTER	
3262		F010	A6	3D			STA INC LDY CPX BEQ RTS	; STORE CHAR AWAY ; BUMP POINTER ;OK STATUS ;IF BUFFER FULL
3263		F012	9D	00	04			*+3
3264		F015	E6	3D				
3265		F017	A0	01				
3266		F019	E0	7F				
3267		F01B	F0	01				
3268		F01D	60					
3269		F01E	A9	FC				
3270		F020	20	D2	F0			
3271		F023	A9	00				
3272		F025	B5	3D				
3273		F027	60					
3274								
3275								

ERR LINE	ADDR	B1	B2	B3	B4	CASSET HANDLER 3/12 (DK1: CASCV)
3276						PAGE
3277						PAGE
3278						STATUS - RETURN STATUS INFO THRU DVSTAT
3279						STATUS: LDY RTS #SUCCES
3280	F02B	A0	01			
3281	F02A	60				

ERR LINE ADDR B1 B2 B3 B4 CASSET HANDLER 3/12 (DK1: CASCY)

PAGE 75

CASSET HANDLER 3/12 (DK1: CASCV)

```

32822 . PAGE
32823
32824 ; CLOSE
32825 ; CLOSE
32826 F02B AD 89 02 ; SEE IF WRITING
32827 F02E 30 08 ; GO CLOSE FOR WRITE
32828 ; CLOSE FOR READ - FLAG CLOSED
32829 F030 A0 01 ; SUCCES
32830 A9 3C ; MOTRST
32831 F032 BD 02 ; STOP THE MOTOR IN CASE WAS SHORT IRG MODE
32832 D3 ; PACTL
32833 F034 BD 02 ; STA
32834 F037 60 ; RTS
32835 F038 A6 3D ; LDX
32836 F03A FO 0A ; BEQ
32837 F03C BE 0F ; STX
32838 F03F A9 FA ; CASBUF+130
32839 04 ; DT1
32840 F041 20 D2 ; REC TYPE
32841 F042 F0 ; WS1OSB
32842 F043 EC ; WRITE OUT USER BUFFER
32843 F044 30 EC ; GD IF ERROR
32844 F045 7F ; ZERO BUFFER
32845 F046 A2 7F ; LDX #127
32846 F047 A9 00 ; LDA #0
32847 F048 9D 00 ; STA CASBUF+3, X
32848 F049 04 ; DEX
32849 F04A F04B CA ; BPL ZTBUF
32850 F04C 10 FA ; #EOT
32851 F04D F04E 10 FA ; LDA #EOT
32852 F04F A9 FE ; JSR WS1OSB
32853 F050 20 D2 ; JMP FCAX
32854 F051 4C 32 ; WRITE EOT RECORD
32855 F052 20 D2 ; FLAG CLOSED AND EXIT
32856 F053 F054 4C 32 ; FCAX
32857 F055 F056 4C 32 ; FCAX

```

```

ERR LINE ADDR B1 B2 B3 B4      PAGE
3307
3308
3309
3310
3311
3312
3313
3314 F05B 85 40      ; SUBROUTINES
3315 F05A A5 14      ; BEEP - GENERATE TONE ON KEYBOARD SPEAKER
3316 F05C 18          ; ON ENTRY A= FREQ
3317
3318
3319
3320
3321 F05D 69 1E      ; BEEP: STA BEEP1: LDA RTCLK+2 ; CURRENT CLOCK
3322
3323 F05F AA          ; ON ENTRY A= FREQ
3324 F060 A9 FF      ; IF ADC #25
3325 F062 BD 1F DO    ; CLC PALFLG
3326 F065 A9 00      ; ADC #25
3327 F067 A0 F0      ; ENDIF
3328 F069 88          ; IF ADC #30
3329 F06A D0 FD      ; TAX ; 1 SEC TONE
3330 F06C BD 1F DO    ; ENDIF
3331 F06F A0 F0      ; TAX
3332 F071 BB          ; LDA ##FF
3333 F072 D0 FD      ; STA CONSO
3334 F074 E4 14      ; LD A #O
3335 F076 D0 E8      ; LDY ##FO
3336 F078 C6 40      ; DEY
3337 F07A F0 OB      ; BNE *-1
3338 F07C 8A          ; STA CONSO
3339 F07D 18          ; LDY ##FO
3340
3341
3342
3343 F07E 69 0A      ; DEY
3344
3345
3346 F080 AA          ; TAX
3347 F081 E4 14      ; CPX RTCLK+2
3348 F083 D0 FC      ; BNE *-2
3349 F085 F0 D3      ; BEQ BEEP1
3350 F087 20 BC F0    ; WFAK: JSR WFAK1
3351 F08A 98          ; TYA
3352 F08B 60          ; RTS
3353 F08C AD 25 E4    ; WFAK1: LDA KEYBDV+5
3354 F08F 48          ; PHA
3355 F090 AD 24 E4    ; LDA KEYBDV+4
3356 F093 48          ; PHA
3357 F094 60          ; RTS
3358
3359
3360
; SIOSB - CALL SID ON SYSTEM BUFFER
;
```

```

ERR LINE ADDR B1 B2 B3 B4 CASSSET HANDLER 3/12 (DK1:GCASCV) PAGE 77
(
 3361 F095 BD 02 03 SIOSB: STA DCOMND ; SAVE COMMAND
 3362 F098 A9 00 LDA #0 ; SET BUFFER LENGTH
 3363 F09A BD 09 03 STA DBYTHI
 3364 F09D A9 83 LDA #131
 3365 F09F BD 08 03 STA DBYTLO
 3366 FOA2 A9 03 LDA #CBUFH
 3367 FOA4 BD 05 03 STA DBUFHI
 3368 FOA7 A9 FD LDA #CBUFL
 3369 FOA9 BD 04 03 STA DBUFLO
 3370 FOAC A9 60 CSIO: LDA #$60 ; CASSET PSEUDO DEVICE
 3371 FOAE BD 00 03 STA DDEVIC
 3372 FOB1 A9 00 LDA #0
 3373 FOB3 BD 01 03 STA DUNIT
 3374 FOB6 A9 23 LDA #35 ; DEVICE TIMEOUT (5/30/79)
 3375 FOBB BD 06 03 STA DTIML0
 3376 FOBB AD 02 03 LDA DCOMND
 3377 FOBE AO 40 LDY #SRSTA
 3378 FOC0 C9 52 CMP #'R
 3379 FOC2 F0 02 BEQ **+4
 3380 FOC4 A0 B0 LDY #SWSTA
 3381 FOC6 BC 03 03 STY DSTATS
 3382 FOC9 A5 3E LDA FTYPE
 3383 FOCA BD 0B 03 STA DAUX2
 3384 FOCE 20 59 E4 JSR SIOV
 3385 FOD1 60 RTS
 3386
 3387 ; WSIDSB - WRITE SIO SYSTEM BUFFER
 3388
 3389 F0D2 BD FF 03 WSIOSB: STA CASBUF+2 ; STORE TYPE BYTE
 3390 F0D5 A9 55 LDA #$55
 3391 F0D7 BD FD 03 STA CASBUF+0
 3392 F0DA BD FE 03 STA CASBUF+1
 3393 F0DD A9 57 LDA #'W ; WRITE
 3394 F0DF 20 95 F0 JSR SIOSB ; CALL SIO ON SYSTEM BUFFER
 3395 FOE2 60 RTS AND ; RETURN
 3396 FOE3 CRNTP6 ==* MONORG-CRNTP6 ; ^GCASCV IS TOO LONG
 3397 0014 00 CASSPR: .BYTE *=+$14
 3398

```

```

3399
3400
3401
3402
3403
3404
3405    0009
3406    0007
3407    000B
3408    0000
3409    0000
3410    0007
3411
3412
3413
3414
3415    0000
3416    007D
3417    0092
3418    0088
3419    0000
3420
3421    0004
3422    0000
3423
3424
3425
3426
3427
3428
3429
3430
3431
3432
3433
3434
3435    BFFA
3436    BFFC
3437    BFFD
3438    BFFE
3439
3440
3441
3442
3443
3444
3445
3446
3447
3448
3449
3450
3451
3452

; CONSTANT EQUATES

PUTTXT = $9          ; "PUT TEXT RECORD" CIO COMMAND CODE
GETCAR = $7          ; "GET CHARACTER" CIO COMMAND CODE
PUTCAR = $B          ; "PUT CHARACTER" CIO COMMAND CODE
INIMLL = $00          ; INITIAL MEM LO LOW BYTE
INIMLH = $07          ; INITIAL MEM LO HIGH BYTE
GOOD = $1            ; GOOD STATUS CODE
WRITE = $57          ; WRITE COMMAND
READ = $52          ; READ COMMAND
STATC = $53          ; STATUS COMMAND
SEX = $0              ; SCREEN EDITOR I/O CB INDEX
CLS = $7D            ; CLEAR SCREEN CODE
CTRLC = $92          ; KEYBOARD CODE FOR 'CONTROL C'
EOF = $88            ; CASSETTE END OF FILE CODE
LIRG = $0              ; LONG IRG TYPE CODE

BUFFH = (CASBUFH+3)/256
BUFFL = (-256)*BUFFH+CASBUFL+3 ; BUFFER POINTER

; THE FOLLOWING EQUATES ARE IN THE CARTRIDGE ADDRESS SPACE.

; "B" CARTRIDGE ADDR'S ARE 8000-9FFF (36K CONFIG. ONLY)
; "A" CART. ADDR'S ARE A000-BFFF (36K CONFIG. ONLY)
; "A" CART. ADDR'S ARE B000-BFFF (48K CONFIG. ONLY)

*==$BFFA
CARTCS: .RES 2          ; CARTRIDGE COLD START ADDRESS.
CART:   .RES 1          ; CARTRIDGE AVAILABLE FLAG BYTE.
CARTFG: .RES 1          ; CARTRIDGE FLAG BYTE. BIT 0=FLAG1,
CARTAD: .RES 2          ; 2-BYTE CARTRIDGE START VECTOR

; CARTRIDGE FLAG ACTION DEFINITIONS

BIT      ACTION IF SET
7       SPECIAL -- DON'T POWER-UP, JUST RUN CARTRIDGE
6-3     NONE
2       RUN CARTRIDGE
1       NONE
0       BOOT DOS

```

ERR LINE ADDR B1 B2 B3 B4 MONITOR ***** MONITP. SRC ***** 3/9/79 ***** 4:00 PAGE 79

3453 *****
3454 NOTE
3455 *****
3456 1. IF BIT2 IS 0, GOTO BLACKBOARD MODE.
3457 2. IF BIT0 SET, THE DISK WILL BE BOOTTED BEFORE ANY
3458 OTHER ACTION.
3459
3460
3461
3462
3463
3464
3465
3466
3467
3468 POWER-UP VECTOR
3469
3470
3471 *****
3472 *=\$FFFFC
3473
3474 PVECT WORD PWRUP
3475 *****
3476
3477
3478
3479
3480
3481
3482
3483 ENTRY POINT VECTOR
3484
3485 E471 4C 23 F2 JMP SIGNON ; BLACK BOARD VECTOR
3486
3487
3488
3489 E474 4C 1B F1 JMP RESET ; WARM START VECTOR
3490
3491 *=COLDSV
3492
3493 E477 4C 25 F1 JMP PWRUP ; COLD START VECTOR (9000 FOR RAM VECTOR WRIT
3494
3495 9000 20 0C 90 *=\$9000
3496 JSR \$900C
3497 9003 4C 25 F1 JMP PWRUP ; (TO HANDLE RAM VECTOR WRITING)
3498 9006 20 0C 90 JSR \$900C
3499 9009 4C 1B F1 JMP RESET
3500
3501
3502
3503
3504
3505
3506 *=MONORG

ERR LINE	ADDR	B1	B2	B3	B4	MONITOR	***** MMONITP. SRCC *****	3/9/79	*****	4: 00	PAGE	80
3507												
3508												
3509	FOE3	50										
3510	FOE4	30	E4									
3511	FOE4	43										
3512	FOE6											
3513	FOE7	40	E4									
3514	FOE9	45										
3515	FOEA	00	E4									
3516	FOEC	53										
3517	FOED	10	E4									
3518	FOEF	4B										
3519	FOFO	20	E4									
3520												
3521												
3522												
3523												
3524												
3525												
3526												
3527	F0F2	7D	41	54	41							
3528	F0F6	52	49	20	43							
3529	FOFA	4F	4D	50	55							
3530	FOFE	54	45	52	20							
3531	F102	2D	20	4D	45							
3532	F106	4D	4F	20	50							
3533	F10A	41	44	9B								
3534												
3535	00F0											
3536	00F2											
3537												
3538	000E											
3539	F10D	42	4F	4F	54							
3540	F111	20	45	52	52							
3541	F115	4F	52	9B								
3542												
3543	OOF1											
3544	OODD											
3545												
3546												
3547												
3548												
3549												
3550	F118	45	3A	9B								
3551												
3552												
3553	OOF1											
3554	001B											
3555	F11B											
3556												
3557												
3558												
3559												
3560												

; Handler Table Entries

; TBLLEN = IDENT-TBLENT-1 Handler Table Length. "MOVED TO LINE 8"

; **** PRINT MESSAGES ****

; IDENT = CLS, 'ATARI COMPUTER - MEMO PAD', CR

; IDENTL = IDENT/256
; (-256)*IDENT+IDENT , SYSTEM I. D. MSG POINTER

; TBLLEN = IDENT-TBLENT-1 , Handler Table Length

; DERR5: .BYTE 'BOOT ERROR', CR

; DERRH = DERR5/256
; (-256)*DERRH+DERR5 , DISK ERROR MSG POINTER

; DERRL = DERRL/256
; (-256)*DERRL+DERRL , SCREEN EDITOR OPEN POINTER

; Device/Filename Specifications

; OPNEDT: .BYTE 'E', CR ; "OPEN SCREEN EDITOR" DEVICE SPEC.

; OPNH = OPNEDT/256
; OPNL = (-256)*OPNH+OPNEDT , SCREEN EDITOR OPEN POINTER

; ****

ERR LINE

ADDR B1 B2 B3 B4 MONITOR ***** MDNITP. SRC ***** 3/9/79 ***** 4:00 PAGE 82

```

3615 F16A DO F7 BNE ZOSRM2
3616 F16C A2 10 LDX #INTZBS
3617 F16E 95 00 ZOSRM3: STA O, X ; CLEAR ZERO PAGE LOCATIONS INTZBS-7F
3618 F170 E8 INX
3619 F171 10 FB BPL ZOSRM3

3620
3621 F173 A9 02 ; ESTABLISH SCREEN MARGINS
3622 F175 B5 52 ESTSCM: LDA #LEDGE
3623 F177 A9 27 STA LMARGN
3624 F180 9D 02 LDA #REDGE
3625 F179 85 53 STA RMARGN

3626
3627 ; MOVE VECTOR TABLE FROM ROM TO RAM
3628 OPSYS: LDX #$25
3629 MOVVEC: LDA VCTABL, X ; ROM TABLE
3630 F17D BD 80 E4 STA INTABS, X ; TO RAM
3631 F180 9D 00 02 DEX
3632 F183 CA BPL MOVVEC
3633 F184 10 F7 JSR OSRAM ; DO D.S. RAM SETUP
3634 F186 20 BA F2 CLI ; ENABLE IRQ INTERRUPTS

3635 F189 5B
3636
3637 ; LINK HANDLERS
3638
3639
3640 F18A A2 0E LDX #TBLEN
3641 F18C BD E3 F0 NXENT: LDA TBLEN, X ; READ HANDLER TABLE ENTRY
3642 F18F 9D 1A 03 STA HATABS, X ; PUT IN TABLE
3643 F192 CA BPL NXENT ; DONE WITH ALL ENTRIES?
3644 F193 10 F7
3645
3646
3647
3648
3649 ; INTERROGATE CARTRIDGE ADDR. SPACE TO SEE WHICH CARTRIDGES THERE ARE
3650
3651 F195 A2 00 LDX #0
3652 F197 86 07 STX TSTDAT ; CLEAR "B" CART. FLAG
3653 F199 B6 06 STX TRAMSZ ; CLEAR "A" CART. FLAG
3654 F19B AE E4 02 LDX RAMSIZ
3655 F19E E0 90 CPX #$90 ; RAM IN "B" CART. SLOT?
3656 F1A0 B0 0A BCS ENDBCK ; NO,
3657 F1A2 AD FC 9F LDA CART-$2000 ; CART. PLUGGED INTO "B" SLOT?
3658 F1A5 D0 05 BNE ENDBCK ; YES, SET "B" CART. FLAG
3660 F1A7 E6 07 INC TSTDAT ; INITAILIZE CARTRIDGE "B"
3661 F1A9 20 3C F2 JSR CBINI
3662
3663 F1AC AE E4 02 ENDBCK: LDX RAMSIZ
3664 F1AF EO BO CPX #$EO ; RAM IN "A" CART. SLOT?
3665 F1B1 B0 OA ENDACK ; NO,
3666 F1B3 AE FC BF CART ; CART. PLUGGED INTO "A" SLOT?
3667 F1B6 DO 05 BNE ENDACK ; YES, SET "A" CART. FLAG
3668 F1B8 E6 06 INC TRAMSZ

```

ERR LINE	ADDR	B1	B2	B3	B4	MONITOR	***** MONITP.SRC *****	3/9/79	*****	4: 00	PAGE	83	
3669	F1BA	20	39	F2		JSR	CAINI	; INITIALIZE CARTRIDGE 'A'					
3670													
3671													
3672													
3673	F1BD	49	03			ENDACK:	LDA #3	#SEX					
3674	F1BF	A2	00				LDX	ICCOM, X					
3675	F1C1	9D	42	03			STA	#OPNL					
3676	F1C4	A9	18				LDA	ICBAL, X					
3677	F1C6	9D	44	03			STA	#DPNH					
3678	F1C9	A9	F1				LDA	ICBAH, X					
3679	F1CB	9D	45	03			STA	#\$C					
3680	F1CE	A9	OC				LDA	ICAX1, X					
3681	F1DO	9D	4A	03			STA	CIOV					
3682	F1D3	20	56	E4			JSR						
3683													
3684	F1D6	10	03				BPL	SCRNOK					
3685	F1D8	4C	25	F1			JMP	PWRUP					
3686	F1DB	EB					INX						
3687	F1DC	DO	FD				BNE	SCRNOK					
3688	F1DE	CB					INY						
3689	F1DF	10	FA				BPL	SCRNOK					
3690													
3691													
3692													
3693	F1E1	20	B2	F3			DO CASSETTE BOOT	CSBOOT					
3694							JSR						
3695													
3696	F1E4	A5	06										
3697	F1E6	05	07				LDA	TSTMSZ					
3698	F1E8	F0	12				ORA	TSTDAT					
3699	F1EA	A5	06				BEG	NO_CART					
3700	F1EC	F0	03				LDA	TRAMSZ					
3701	F1EE	AD	FD	BF			BEG	NDA1					
3702	F1F1	A6	07				LDA	CARTFG					
3703	F1F3	F0	03				NOA1:	TSTDAT					
3704	F1F5	OD	FD	9F			LDX	"B" CART?					
3705	F1F8	29	01				BEG	NOB1					
3706	F1FA	F0	03				ORA	CARTFG-\$2000					
3707							NOB1:	#1					
3708							AND	DOES EITHER CART WANT BOOT?					
3709	F1FC	20	CF	F2			BEG	NOB0DT					
3710													
3711													
3712													
3713	F1FF	A9	00										
3714	F201	8D	44	02			NOBOOT:	LDA \$0					
3715	F204	A5	06					STA	COLDST				
3716	F206	F0	0A					LDA	TRAMSZ				
3717	F208	AD	FD	BF				BEG	NDA2				
3718	F20B	29	04					AND	#4				
3719	F20D	F0	03					BEG	CARTFG				
3720	F20F	6C	FA	BF				DOES IT WANT TO RUN?					
3721	F212	A5	07					NOA2:	JMP (CARTRGS)				
3722	F214	F0	0A					LDA TSTDAT					
								BEG	NOCAR2				

ERR LINE

PAGE 84

ERR LINE	ADDR	B1	B2	B3	B4	MONITOR	***** MONITP.SRC *****	3/9/79 ****	4: 00
3723	F216	AD	FD	9F		LDA	CARTFG-\$2000 ; GET "B" MODE FLAG		
3724	F219	29	04			AND #4	; DOES IT WANT TO RUN?		
3725	F21B	F0	DF			BEQ NDCART	; NO		
3726	F21D	6C	FA	9F		JMP (CARTCS-\$2000)	; RUN "B" CARTRIDGE		
3727									
3728									
3729	F220	6C	04	00					
3730									
3731									
3732	F223	A2	F2						
3733	F225	A0	F0						
3734	F227	20	85	F3					
3735									
3736									
3737									
3738									
3739	F22A	20	30	F2					
3740	F22D	4C	2A	F2		BLACKBOARD ROUTINE			
3741	F230	AD	05	E4		BLKKB: JSR BLKKB2	; "JSR EGETCH"		
3742	F233	48				JMP BLACKB	; FOREVER		
3743	F234	AD	04	E4		BLKB2: LDA EDITRV+5	; HIGH BYTE		
3744	F237	48				PHA			
3745	F238	60				EDITRV+4 LDA	; LOW BYTE		
3746						PHA			
3747						RTS			
3748									
3749	F239	6C	FE	BF					
3750	F23C	6C	FE	9F					
3751									

MONITOR ***** MONITP.SRC ***** 3/9/79 **** 4: 00

LDA CARTFG-\$2000 ; GET "B" MODE FLAG
AND #4 ; DOES IT WANT TO RUN?
BEQ NDCART ; NO
JMP (CARTCS-\$2000) ; RUN "B" CARTRIDGE

; NO CARTRIDGES, OR NEITHER WANTS TO RUN,
; SO GO TO DOSVEC (DDOS, CASSETTE, OR BLACKBOARD)
NDCAR2: JMP (DOSVEC)

; PRINT SIGN-ON MESSAGE
SIGNON: LDX #IDENTL
LDY #IDENTH
JSR PUTLIN ; GO PUT SIGN-ON MSG ON SCREEN

; BLACKBOARD ROUTINE

BLKKB: JSR BLKKB2 ; "JSR EGETCH"
JMP BLACKB ; FOREVER
BLKB2: LDA EDITRV+5 ; HIGH BYTE

PHA

EDITRV+4 LDA ; LOW BYTE

PHA

RTS ; SIMULATES "JMP (EDITRV)"

; CARTRIDGE INITIALIZATION INDIRECT JUMPS

CAINI: JMP (CARTAD)
CBINI: JMP (CARTAD-\$2000)

ERR LINE	ADDR	B1	B2	B3	B4	PAGE
3752						MONITOR **** MONITP. SRC ***** 3/9/79 *** 4:00
3753						PAGE
3754						85
3755						
3756						
3757						
3758						
3759						
3760						
3761						
3762						
3763						
3764						
3765						
3766						
3767						
3768						
3769						
3770						
3771						
3772						
3773						
3774						
3775						
3776						
3777						
3778						
3779						
3780	F23F	AD	FC	BF		
3781	F242	DO	13			
3782	F242	EE	FC	BF		
3783	F244	AD	FC	BF		
3784	F247	DO	OB			
3785	F24A	AD	FD	BF		
3786	F24C	10	03			
3787	F24F	6C	FE	BF		
3788	F251					
3789						
3790						
3791						
3792	F254	CE	FC	BF		
3793	F257	A0	00			
3794	F259	84	05			
3795	F259	A9	10			
3796	F25B	85	06			
3797	F25D	B1	05			
3798	F25F	49	FF			
3799	F261	91	05			
3800	F263	D1	05			
3801	F265	DO	0D			
3802	F267	49	FF			
3803	F269	91	05			
3804	F26B	A5	06			
3805						

S U B R O U T I N E S

3806 F26F 18 CLC ADC #\$10 ; INCR. RAM POINTER BY 4K.
 3807 F270 69 10 STA TRAMSZ
 3808 F272 85 06 BNE HOWMCH ; GO FIND HOW MUCH RAM.
 3809 F274 D0 E9 ENDRAM: RTS

3810 F276 60 ;
 3811 ;
 3812 ;
 3813 ;
 3814 ;
 3815 ;
 3816 ;
 3817 ;
 3818 F277 A9 00 HARDI: LDA #0

3819 F279 AA CLRCHP: TAX
 3820 F27A 9D 00 DO STA \$D000, X
 3821 F27D 9D 00 D4 STA \$D400, X
 3822 F280 9D 00 D2 STA \$D200, X
 3823 F283 9D 00 D3 STA \$D300, X
 3824 F286 E8 INX
 3825 F287 D0 F1 BNE CLRCHP
 3826 F289 60 RTS

3827 ; O. S. RAM SETUP

3828 ; OSRAM: DEC BRKKY ; TURN OFF BREAK KEY FLAG
 3829 ; OSRAM: LDA #.LOW.BRKKY2
 3830 F28A C6 11 LDA BRKKY
 3831 F2BC A9 54 STA #.HIGH.BRKKY2
 3832 F2BE BD 36 02 STA BRKKY+1
 3833 F291 A9 E7 STA TRAMSZ ; READ RAM SIZE IN TEMP. REG.
 3834 F293 BD 37 02 STA RAMSIZ ; SAVE IT IN RAM SIZE.
 3835 F293 BD 37 02 STA MEMTOP+1 ; INIT. MEMTOP ADDR HI BYTE
 3836 F296 A5 06 STA MEMTOP #0 ; INIT. MEMTOP ADDR LO BYTE
 3837 F298 BD E4 02 STA MEMTOP LDA #INIMLL
 3838 F29B BD E6 02 STA MEMLO STA #INIMLH
 3839 F29E A9 00 STA MEMLO+1 ; INITIALIZE MEMLO ADDR VECTOR
 3840 F2A0 BD E5 02 STA EDITOR INIT.
 3841 F2A3 A9 00 STA SCREEN INIT.
 3842 F2A5 BD E7 02 STA KEYBOARD INIT.
 3843 F2AB A9 07 STA PRINTER INIT.
 3844 F2AA BD E8 02 STA CASSETTE INIT.
 3845 F2AD 20 0C E4 STA CIO INIT.
 3846 F2B0 20 1C E4 STA SIO INIT.
 3847 F2B3 20 2C E4 STA INTINV INIT.
 3848 F2B6 20 3C E4 STA CDNSDL
 3849 F2B9 20 4C E4 STA AND #\$1
 3850 F2BC 20 6E E4 STA BNE NOKEY
 3851 F2BF 20 65 E4 STA INC
 3852 F2C2 20 6B E4 STA RTS
 3853 F2C5 AD 1F DO STA ; GAME START KEY DEPRESSED?
 3854 F2C8 29 01 STA ; YES, SET KEY FLAG.
 3855 F2CA D0 02
 3856 F2CC E6 4A
 3857 F2CE 60 ;
 3858 ;
 3859 ;

ERR LINE	ADDR	B1	B2	B3	B4	MONITOR	***** MONITP. SRC *****	3/9/79	*****	4: 00	PAGE	87	
3860		; DO BOOT OF DISK											
3861	F2CF	A5	08			BOOT:	LDA	WARMST					
3862	F2D1	FO	0A				BEG	NOARM					
3863	F2D3	A5	09				LDA	BOOT?					
3864	F2D5	29	01				AND	#1					
3865	F2D7	FO	03				BEG	NOINIT					
3866	F2D9	20	7E	F3			JSR	DINI					
3867	F2DC	60				NOINIT:	RTS						
3868	F2DD	A9	01			NOWARM:	LDA	#1					
3869	F2DF	8D	01	03			STA	DUNIT					
3870	F2E2	A9	53				LDA	#STATC					
3871	F2E4	BD	02	03			STA	DCOMND					
3872	F2E7	20	53	E4			STA	DSKINV					
3873	F2EA	10	01				JSR	DOBOOT					
3874	F2EC	60					BPL						
3875							RTS						
3876													
3877	F2ED	A9	00			DOBOOT:	LDA	*0					
3878	F2EF	8D	0B	03			STA	DAUX2					
3879	F2F2	A9	01				LDA	#1					
3880	F2F4	8D	0A	03			STA	DAUX1					
3881	F2F7	A9	00				LDA	#BUFL					
3882	F2F9	8D	04	03			STA	DBUFLO					
3883	F2FC	A9	04				LDA	#BUFFH					
3884	F2FE	BD	05	03			STA	DBUFHI					
3885	F301	20	9D	F3		SECT1:	JSR	GETSEC					
3886	F304	10	08				BPL	ALLSEC					
3887	F306	20	B1	F3			JSR	DSKRDE					
3888	F309	A5	4B				LDA	CASSBT					
3889	F30B	FO	E0				BEG	DOBOOT					
3890	F30D	60					RTS						
3891	F30E	A2	03			ALLSEC:	LDX	RDBYTE:	LDA				
3892	F310	BD	00	04			CASBUF+3, X						
3893	F313	9D	40	02			DFLAGS, X						
3894	F316	CA					DEX						
3895	F317	10	F7				BPL						
3896	F319	AD	42	02			RDBYTE						
3897	F31C	B5	04				BOOTAD						
3898	F31E	AD	43	02			STA	RAML0					
3899	F321	B5	05				LDA	BOOTAD+1					
3900	F323	AD	04	04			STA	RAML0+1					
3901	F326	B5	0C				LDA	CASBUF+7					
3902	F328	AD	05	04			STA	DOSINI					
3903	F32B	B5	0D				LDA	CASBUF+8					
3904	F32D	A0	7F				STA	DOSINI+1					
3905	F32F	B9	00	04			MVBUF:	#\$7F					
3906	F332	91	04				LDY	CASBUF+3, Y					
3907	F334	BB					STA	(RAML0), Y					
3908	F335	10	F8				DEY						
3909	F337	18					BPL	MVNXB					
3910	F338	A5	04				CLC						
3911	F33A	69	80				LDA	RAML0					
3912	F33C	B5	04				ADC	#\$BO					
3913	F33E	A5	05				STA	RAML0					
							LDA	RAML0+1					

ERR LINE	ADDR	B1	B2	B3	B4	MONITOR	***** MONITP. SRC ***** 3/9/79 ***** 4: 00	PAGE
3914	F340	69	00			ADC #0	; INCR BOOT LOADER BUFFER POINTER.	88
3915	F342	85	05			STA RAMLO+1	; DEC # OF SECTORS.	
3916	F344	CE	41	02		DEC DBSECT	; MORE SECTORS ?	
3917	F347	F0	11			BEG ENBOOT	; YES, INCR SECTOR #	
3918	F349	EE	0A	03		INC DAUX1	; GO GET SECTOR.	
3919	F34C	20	9D	F3		JSR GETSEC	; STATUS O.K. ?	
3920	F34F	10	DC			BPL MVBUFF	; NO, GO PRINT DISK READ ERROR	
3921	F351	20	81	F3		JSR DSKRDE		
3922	F354	A5	4B			LDA CASSBT		
3923	F356	DO	AE			BNE BADDSK		
3924	F358	FO	F2			BEQ SECTX		
3925	F35A	A5	4B			CASSBT		
3926	F35C	FO	03			XBOOT	; CASSETTE BOOT ?	
3927	F35E	20	9D	F3		BEQ GETSEC	; YES, GET EOF RECORD, BUT DON'T USE IT.	
3928	F361	20	6C	F3		JSR BLOAD	; GO EXECUTE BOOT LOADER	
3929	F364	BO	A0			BCS BADDSK	; IF BAD BOOT, DO IT OVER AGAIN	
3930	F366	20	7E	F3		JSR DINI	; GO INIT. SOFTWARE	
3931	F369	E6	09			INC BOOT?	; SHOW BOOT SUCCESS	
3932	F36B	60				RTS		
3933	F36C	18				CLC		
3934	F36D	AD	42	02		LDA BDOTAD		
3935	F370	69	06			ADC #6		
3936	F372	B5	04			STA RAMLO		
3937	F374	AD	43	02		LDA BDOTAD+1		
3938	F377	69	00			ADC #0		
3939	F379	B5	05			STA RAMLO+1	; PUT START ADDR OF BOOTLOADER INTO RAM	
3940	F37B	6C	04	00		(RAMLO)		
3941	F37E	6C	0C	00		JMP (DOSINI)		
3942								
3943								
3944								
3945								
3946								
3947								
3948	F381	A2	0D			DISPLAY DISK READ ERROR MSG		
3949	F383	A0	F1			DSKRDE: LDX #DERRL		
3950						LDY #DERRH		
3951								
3952								
3953								
3954								
3955								
3956								
3957								
3958	F385	8A				PUTLN: TXA LDX #\$SEX		
3959	F386	A2	00			STA ICBAL, X		
3960	F388	9D	44	03				
3961	F38B	9B						
3962	F38C	9D	45	03				
3963	F38F	A9	09					
3964	F391	9D	42	03				
3965	F394	A9	FF					
3966	F396	9D	48	03				
3967	F399	20	56	E4				

ERR LINE

DISPLAY HANDLER -- 10-30-78 -- DISPLC

PAGE 92

ADDR B1 B2 B3 B4

PAGE

*=EDITRV

i ; SCREEN EDITOR HANDLER ENTRY POINT
EDITOR: WORD EDOPEN-1
WORD RETUR1-1 ; (CLOSE)
WORD EGETCH-1
WORD EDUTCH-1
WORD RETUR1-1 ; (STATUS)
WORD NOFUNC-1 ; (SPECIAL)
JMP PWRONA
.BYTE 0 ; ROM FILLER BYTE
i ; SCREENV
i ; DISPLAY HANDLER ENTRY POINT
DISPLA: WORD DOPEN-1
WORD RETUR1-1 ; (CLOSE)
WORD GETCH-1
WORD DUTCH-1
WORD RETUR1-1 ; (STATUS)
WORD DRAW-1 ; (SPECIAL)
WORD NOFUNC-1 ; (SPECIAL)
JMP PWRONA
.BYTE 0 ; ROM FILLER BYTE
i ; KEYBDV
i ; KEYBOARD HANDLER ENTRY POINT
KBDHND: WORD RETUR1-1
WORD RETUR1-1 ; (CLOSE)
WORD KGETCH-1 ; (DUTCH)
WORD RETUR1-1 ; (STATUS)
WORD NOFUNC-1 ; (SPECIAL)
JMP PWRONA
.BYTE 0 ; ROM FILLER BYTE
i ; INTERRUPT VECTOR TABLE ENTRY
*=VCTABL-INTABS+KEYBD
.WORD PIRG5 ; KEYBOARD IRQ INTERRUPT VECTOR

4036
4037
4038
4039
4040
4041
4042
E400 FB F3
E402 33 F6
E403 3D F6
E404 A3 F6
E405 33 F6
E406 3C F6
E407 4C E4 F3
E408 00
E409
E410 F5 F3
E412 33 F6
E414 92 F5
E416 B6 F5
E418 33 F6
E41A FB FC
E41C 4C E4 F3
E41F 00
E420 33 F6
E422 33 F6
E424 E1 F6
E426 3C F6
E428 33 F6
E42A 3C F6
E42C 4C E4 F3
E42F 00
E430
E432 BE FF

```
40B3          *=KBDORG
40B4
40B5          F3E4  A9 FF  02      ; PWRDN: LDA    #$FF
40B6          F3E6  BD FC  02      STA    CH
40B7          F3E9  AD E6  02      LDA    MEMTOP+1
40B8          F3EC  29 F0          AND    #$FO
40B9          F3EE  85 6A          STA    RAMTOP
4090          F3F0  A9 40          LDA    #$40
4091          F3F2  8D BE  02      STA    SHFLOK
4092          F3F5  60            RTS
4093          F3F5  F3F5          ; POWER ON COMPLETED
```

ERR LINE ADDR B1 B2 B3 B4

DISPLAY HANDLER -- 10-30-78 -- DISPLC

PAGE 94

```
4094
4095
4096
4097
4098
4099 F3F6 A5 2B ; BEGIN DISPLAY HANDLER OPEN PROCESSING
4100 F3F8 29 OF
4101 F3FA DO 08
4102 F3FC A5 2A
4103 F3FE 29 OF
4104 F400 85 2A
4105 F402 A9 00
4106 F404 85 57
4107 F406 A9 E0
4108 F408 BD F4 02
4109 F40B A9 02
4110 F40D 8D F3 02
4111 F410 BD 2F 02
4112 F413 A9 01
4113 F415 85 4C
4114 F417 A9 CO
4115 F419 05 10
4116 F41B 85 10
4117 F41D BD OE D2
4118 F420 A9 00
4119 F422 BD 93 02
4120 F425 85 64
4121 F427 85 7B
4122 F429 BD F0 02
4123 F42C AO OE
4124 F42E A9 01
4125 F430 99 A3 02
4126 F433 8B
4127 F434 10 FA
4128 F436 A2 04
4129 F438 BD C1 FE
4130 F43B 9D C4 02
4131 F43E CA
4132 F43F 10 F7
4133 F441 A4 6A
4134 F443 8B
4135 F444 8C 95 02
4136 F447 A9 60
4137 F449 BD 94 02
4138 F44C A6 57
4139 F44E BD 69 FE
4140 F451 DO 04
4141 F453 A9 91
4142 F455 85 4C
4143 F457 85 51
4144 F459 A5 6A
4145 F45B 85 65
4146 F45D BC 45 FE
4147 F460 A9 2B

; DOPEN: LDA ICAX2Z ; GET AUX 2 BYTE
        AND #$F
        BNE OPNCOM ; IF MODE ZERO, CLEAR ICAX1Z
        LDA ICAX1Z ; CLEAR "CLR INHIBIT" AND "MXD MODE" BITS
        AND #$F
        STA ICAX1Z
        STA #O
        LDA DINDEX
        STA OPNCOM: ; INITIALIZE GLOBAL VBLANK RAM
        LDA #$EO
        STA CHBAS
        LDA #2
        STA CHACT
        STA SDMCTL ; TURN OFF DMA NEXT VBLANK
        STA #SUCCES
        STA DSTAT
        STA #$CO
        STA ORA
        STA POKMSK
        STA IRGEN
        LDA #O
        STA TINDEX ; TEXT INDEX MUST ALWAYS BE 0
        STA ADDRESS
        STA SWPFLG
        STA CRSINH ; TURN CURSOR ON AT OPEN
        STA #14 ; CLEAR TAB STOPS
        LDY #1 ; INIT TAB STOPS TO EVERY B CHARACTERS
        LDA TABMAP:Y
        DEY
        CLRTBS: STA CLRRTBS: ; LOAD COLOR REGISTERS
        BPL #4
        LDX DOPENB: ; DO TXTMSC=$2C40 (IF MEMTOP=30000)
        LDA COLRTB,X
        STA COLORO,X
        DEX
        BPL DOPENB
        LDY RAMTOP
        DEY
        STY TXTMSC+1
        LDA #60
        STA DINDEX
        LDX ANCDNV,X ; CONVERT IT TO ANTIC CODE
        STA DOPENA ; IF ZERO, IT IS ILLEGAL
        BNE #BADMOD
        STA DSTAT
        STA HOLD1
        LDA RAMTOP ; SET UP AN INDIRECT POINTER
        STA ADDRESS+1 ; ALLOCATE N BLOCKS OF 40 BYTES
        LDY #40
        DOPENI: LDA
```

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER	-- 10-30-78 --	DISPLC	PAGE	95
4148	F462	20	21	F9		JSR DBSUB				
4149	F465	88				DEY				
4150	F466	DO	F8			BNE DOPEN1				
4151	F46B	AD	6F	02		LDA GPRIOR		; CLEAR GTIA MODES		
4152	F46B	29	3F			AND #\$3F				
4153	F46D	85	67			STA OPNTMP+1				
4154	F46F	AB				TAY				
4155	F470	EO	08			CPX #8		; TEST IF 320X1		
4156	F472	90	17			BCC NOTB8				
4157	F474	BA				TXA				
4158	F475	6A				ROR A				
4159	F476	6A				ROR A				
4160	F477	6A				ROR A				
4161	F478	29	CO			AND #\$CO		; NOW 2 TOP BITS		
4162	F47A	05	67			ORA OPNTMP+1				
4163	F47C	A8				TAY				
4164	F47D	A9	10			LDA #16		; SUBTRACT 16 MORE FOR PAGE BOUNDARY		
4165	F47F	20	21	F9		JSR DBSUB				
4166	F482	E0	0B			CXP #11		; TEST MODE 11		
4167	F484	DO	05			BNE NOTB8		; IF MODE = 11		
4168	F486	A9	06			#6		; PUT GTIA LUM VALUE INTO BACKGROUND REGISTER		
4169	F488	BD	CB	02		LDA COLOR4				
4170	F48B	BC	6F	02	NOTB:	STY GPRIOR				
4171	F48E	A5	64			LDA ADDRESS				
4172	F490	85	58			STA SAVMSC				
4173	F492	A5	65			LDA ADDRESS+1				
4174	F494	85	59			STA SAVMSC+1				
4175	F496	AD	OB	D4	VBBWAIT:	LDA VCOUNT		; WAIT FOR NEXT VBLANK BEFORE MESSING		
4176	F499	C9	7A			CMP #\$7A		; WITH THE DISPLAY LIST		
4177	F49B	DO	F9			BNE VBWAIT				
4178	F49D	20	1F	F9		JSR DBDEC		; START PUTTING DISPLAY LIST RIGHT UNDER RAM		
4179	F4A0	BD	75	FE		LDA PAGEFB_X		; TEST IF DISPLAY LIST WILL BE IN TROUBLE		
4180	F4A3	FO	06			BEG NOMOD		; OF CROSSING A 256 BYTE PAGE BOUNDARY		
4181	F4A5	A9	FF			LDA #\$FF		; IF SO, DROP DOWN A PAGE		
4182	F4A7	85	64			STA ADDRESS				
4183	F4A9	C6	65			DEC ADDRESS+1				
4184	F4AB	A5	64			STA SAVADR				
4185	F4AD	85	68			ADDRESS+1				
4186	F4AF	A5	65			STA SAVADR+1				
4187	F4B1	85	69			DBDDEC		; (DOUBLE BYTE DOUBLE DECREMENT)		
4188	F4B3	20	13	F9		LDA #\$41		; (ANTIC) WAIT FOR VBLANK AND JMP TO TOP		
4189	F4B6	A9	41			STORE OPNTMP				
4190	F4B8	20	17	F9		STX #24		; INITIALIZE BOTSCR		
4191	F4BB	86	66			LDA BOTSCR				
4192	F4BD	A9	18			LDA DINDEX		; DISALLOW MIXED MODE IF MODE. GE. 9		
4193	F4BF	BD	BF	02		CMP #9				
4194	F4C2	A5	57			BCS NOTMXD				
4195	F4C4	C9	09			LDA ICAX1Z				
4196	F4C6	BO	2D			AND #\$10				
4197	F4CB	A5	2A			BEG NOTMXD				
4198	F4CA	29	10			LDA #4				
4199	F4CC	FO	27			STA BOTSCR				
4200	F4CE	A9	04							
4201	F4D0	BD	BF	02						

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER	-- 10-30-78 --	DISPLC	PAGE
4202	F4D3	A2	02			DOPEN2: LDX #2		; ADD 4 LINES OF TEXT AT BOTTOM OF SCREEN	96
4203	F4D5	A9	02			LDA \$2			
4204	F4D7	20	17	F9		JSR STORE			
4205	F4DA	CA				DEX			
4206	F4DB	10	F8			BPL DOPEN2			
4207	F4DD	A4	6A			LDY RAMTOP		; RELOAD MSC FOR TEXT	
4208	F4DF	BB				DEY			
4209	F4E0	98				TYA			
4210	F4E1	20	17	F9		STORE			
4211	F4E4	A9	60			LDA \$\$60			
4212	F4E6	20	17	F9		JSR STORE			
4213	F4E9	A9	42			LDA \$\$42			
4214	F4EB	20	17	F9		JSR STORE			
4215	F4EE	18				CLC			
4216	F4EF	A9	OC			LDA #MXDMDE-NUMDLE		; POINT X AT MIXED MODE TABLE	
4217	F4F1	65	66			ADC OPNTMP			
4218	F4F3	85	66			STA OPNTMP			
4219	F4F5	A4	66			LDY OPNTMP			
4220	F4F7	BE	51	FE		LDX NUMDLE,Y			
4221	F4FA	A5	51			HOLD1 STORE			
4222	F4FC	20	17	F9					
4223	F4FF	CA				JSR DEX			
4224	F500	DO	F8			BNE DOPEN3			
4225	F502	A5	57			LDA DINDEX			
4226	F504	C9	08			CMP #8			
4227	F506	90	1C			BCC DOPENS			
4228	F508	A2	5D			LDX #93		; GET REMAINING NUMBER OF DLE'S	
4229	F50A	A5	6A			LDA RAMTOP		; STORE N DLE'S	
4230	F50C	3B				SEC			
4231	F50D	E9	10			SBC ##10			
4232	F50F	20	17	F9		JSR STORE			
4233	F512	A9	00			LDA #0			
4234	F514	20	17	F9		JSR STORE			
4235	F517	A9	4F			LDA \$\$4F			
4236	F519	20	17	F9		JSR STORE			
4237	F51C	A5	51			DOPEN4: LDA HOLD1			
4238	F51E	20	17	F9		JSR STORE			
4239	F521	CA				DEX			
4240	F522	DO	F8			BNE DOPEN4			
4241	F524	A5	59			LDA SAVMSC+1		; POLISH OFF DISPLAY LIST	
4242	F526	20	17	F9		JSR STORE			
4243	F529	A5	58			LDA SAVMSC			
4244	F52B	20	17	F9		JSR STORE			
4245	F52E	A5	51			LDA HOLD1			
4246	F530	09	40			ORA ##40			
4247	F532	20	17	F9		JSR STORE			
4248	F535	A9	70			LDA ##70			
4249	F537	20	17	F9		JSR STORE			
4250	F53A	A9	70			LDA ##70			
4251	F53C	20	17	F9		JSR STORE			
4252	F53F	A5	64			LDA ADDRESS			
4253	F541	8D	30	02		STA SDLSTL			
4254	F544	A5	65			LDA ADDRESS+1			
4255	F546	BD	31	02		STA SDLSTL+1			

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER -- 10-30-78 --	DISPLC	PAGE	97
42256	F549	A9	70			LDA #\$70 ; ADD LAST BLANK LINE ENTRY			
42257	F54B	20	17	F9		JSR STORE ; POSITION ADDRESS=SDLSTL-1			
42258	F54E	A5	64			LDA ADDRESS			
42259	F550	BD	E5	02		STA MEMTOP			
42260	F553	A5	65			LDA ADDRESS+1			
42261	F555	BD	E6	02		STA MEMTOP+1			
42262	F558	A5	68			LDA MEMSTL+1			
42263	F55A	B5	64			LDA SAYADR			
42264	F55C	A5	69			STA ADDRESS			
42265	F55E	B5	65			LDA SAVADR+1			
42266	F560	AD	31	02		STA ADDRESS+1			
42267	F563	20	17	F9		LDA SDLSTL+1			
42268	F566	AD	30	02		LDA DSTAT			
42269	F569	20	17	F9		LDA DOPEN9			
42270	F56C	A5	4C			JSR STORE			
42271	F56E	10	07			LDA SDLSTL			
42272	F570	48				JSR STORE			
42273	F571	20	FC	F3		LDA DSTAT			
42274	F574	68				JSR DOPEN9			
42275	F575	A8				JSR PHA			
42276	F576	60				JSR OPEN			
42277	F577	A5	2A		DOPEN9:	LDA ICAX1Z			
42278	F579	29	20		AND #\$20				
42279	F57B	DO	0B		BNE DOPEN7				
42280	F57D	20	B9	F7	JSR CLRSCR				
42281	F580	8D	90	02	STA TXTRW				
42282	F583	A5	52		LDA LMARGIN				
42283	F585	BD	91	02	STA TXTCOL				
42284	F58B	A9	22		DOPEN7:	LDA #\$22			
42285	F58A	OD	2F	02	ORA SDMCTL				
42286	F58D	BD	2F	02	STA SDMCTL				
42287	F590	4C	21	F6	JMP RETUR2				
42288					;				
42289	F593	20	96	FA	GETCH:	JSR RANGE			
42291	F596	20	A2	F5	JSR GETPLT				
42292	F599	20	32	FB	JSR INATAC				
42293	F59C	20	D4	F9	JSR INCRSB				
42294	F59F	4C	34	F6	JMP RETUR1				
42295	F5A2	20	47	F9	GETPLT:	JSR CONVRT			
42296	F5A5	B1	64		LDA (ADDRESS), Y				
42297	F5A7	2D	A0	02	AND DMASK				
42298	F5AA	46	6F		LSR SHFMFT				
42299	F5AC	BO	03		BCS SHIFT1				
43000	F5AE	4A			LSR A				
43001	F5AF	10	F9		BPL SHIFTD				
43002	F5B1	BD	FA	02	SHIFT1:	STA CHAR			
43003	F5B4	C9	00		CMP #0				
43004	F5B6	60			RTS				
43005					;				
43006					;				
43007	F5B7	BD	FB	02	OUTCH:	STA ATACHR			
43008	F5BA	20	96	FA	JSR RANGE				

```

4310 F5BD AD FB 02           ; TEST FOR CLEAR SCREEN
4311 F5C0 C9 7D             JSR ATACHR
4312 F5C0 DO 06             CMP #CLRCOD
4313 F5C2 DO 06             BNE OUTCHE
4314 F5C4 20 B9 F7           JSR CLRSR
4315 F5C7 4C 21 F6           JMP RETUR2
4316 F5CA AD FB 02           OUTCHE: LDA ATACHR
4317 F5CD C9 9B             CMP #CR
4318 F5CF DO 06             BNE OUTCHB
4319 F5D1 20 30 FA           JSR DDCRWS
4320 F5D4 4C 21 F6           OUTCHE: JMP RETUR2
4321 F5D7 20 E0 F5           JSR OUTPLT
4322 F5DA 20 DB F9           JSR INCRSR
4323 F5DD 4C 21 F6           JMP RETUR2
4324
4325 F5E0 AD FF 02           ; ****LLOOP HERE IF START/STOP FLAG IS NON-0
4326 F5E3 DO FB             OUTPLT: LDA SSFLAG
4327 F5E5 A2 02             BNE OUTPLT
4328 F5E7 B5 54             LDX #2
4329 F5E9 95 5A             CRLLOOP: LDA ROWCRS, X
4330 F5EB CA                STA OLDRDW, X
4331 F5F1 AB                DEX
4332 F5F2 2A                BPL CRLLOOP
4333 F5F3 2A                LDA ATACHR
4334 F5F4 2A                TAY ; CONVERT ATASCII(ATACHR) TO INTERNAL(CHAR)
4335 F5F5 2A                ROL A ; SAVE CURSOR LOCATION FOR DRAW LINE TO DRAW
4336 F5F6 29 03             ROL A
4337 F5F7 AA                ROL A
4338 F5F8 9B                ROL A
4339 F5F9 9F                ROL A
4340 F5FA 1D F6 FE           AND #3
4341 F5FB 8D FA 02           AND
4342 F5FC 20 47 F9           ORA TAINT, X
4343 F5FD 1D F6 FE           OUTCH2: STA CHAR
4344 F5FF 8D FA 02           JSR CONVRT
4345 F602 AD FA 02           LDA CHAR
4346 F605 46 6F             SHIFTU: LSR SHFAMT
4347 F608 BO 04             BCS SHIFT2
4348 F60A 0A                ASL A
4349 F60C 4C 0B F6             SHIFTU: JMP SHIFTU
4350 F60D 2D A0 02           AND DMASK
4351 F610 85 50             STA TMPCHR
4352 F613 AD A0 02           LDA DMASK
4353 F615 49 FF             EOR #$FF
4354 F618 31 64             AND (ADDRESS), Y
4355 F61A 05 50             ORA TMPCHR
4356 F61C 91 64             STA (ADDRESS), Y
4357 F61E 60
4358 F620
4359
4360 F621 20 A2 F5           RETUR2: JSR GETPLT
4361 F624 B5 SD             STA OLDCHR
4362 F626 A6 57             LDX DINDEX
4363

```

; DO CURSOR ON THE WAY OUT
; GRAPHICS HAVE INVISIBLE CURSOR

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER	-- 10-30-78 --	DISPLC	PAGE
4364	F628	DO	0A			BNE	RETUR1		99
4365	F62A	AE	FO	02		LDX	CRSINH	; TEST CURSOR INHIBIT	
4366	F62D	DO	05			BNE	RETUR1		
4367	F62F	49	80			EOR	#\$80	; TOGGLE MSB	
4368	F631	20	FF	F5		JSR	QUTCH2	; DISPLAY IT	
4369	F634	A4	4C			RETUR1:	LDY	DSTAT	
4370	F636	A9	01				LDA	#SUCCES	
4371	F638	85	4C			DSTAT	STA	; SET STATUS= SUCCESSFUL COMPLETION	
4372	F63A	AD	FB	02			LDA	ATACHR	; PUT ATTACHR IN AC FOR RETURN TO CIO
4373	F63D	60				NOFUNC:	RTS	; (NON-EXISTENT FUNCTION RETURN POINT)	
4374									
4375									
4376									
4377									
4378									

; END OF DISPLAY HANDLER

ERR LINE

DISPLAY HANDLER -- 10-30-78 -- DISPLC

PAGE 100

4379
43804381
4382

ERR LINE	ADDR	B1	B2	B3	B4	PAGE
4383	F63E	20	B3	FC		
4384	F641	20	88	FA		
4385	F644	A5	6B			
4386	F646	DO	34			
4387	F648	A5	54			
4388	F64A	85	6C			
4389	F64C	A5	55			
4390	F64E	85	6D			
4391	F650	20	E2	F6		
4392	F653	84	4C			
4393	F655	AD	FB	02		
4394	F658	C9	9B			
4395	F65A	F0	12			
4396	F65C	20	AD	F6		
4397	F65F	20	B3	FC		
4398	F662	A5	63			
4399	F664	C9	71			
4400	F666	DO	03			
4401	F668	20	OA	F9		
4402	F66B	4C	50	F6		
4403	F66E	20	EE	FA		
4404	F671	20	00	FC		
4405	F674	A5	6C			
4406	F676	B5	54			
4407	F678	A5	6D			
4408	F67A	85	55			
4409	F67C	A5	6B			
4410	F680	C6	6B			
4411	F682	FO	0D			
4412	F684	A5	4C			
4413	F686	30	FB			
4414	F688	20	93	F5		
4415	F68B	BD	FB	02		
4416	F68E	4C	B3	FC		
4417	F691	20	30	FA		
4418	F694	A9	9B			
4419	F696	BD	FB	02		
4420	F699	20	21	F6		
4421	F69C	84	4C			
4422	F69E	4C	B3	FC		
4423	F6A1	6C	64	00		
4424	F6A4	8D	FB	02		
4425	F6A7	20	B3	FC		
4426	F6AA	20	E4	FA		
4427	F6AD	20	8D	FC		
4428	F6AE					
4429	F6AF					
4430	F6B0					
4431	F6B1					
4432	F6B2					

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER	-- 10-30-78 --	DISPLC	PAGE
4433	F6B3	F0	09			EDUTC6:	BEG	EDUTC5	101
4434	F6B5	OE	A2	02			ASL	ESCFLG	
4435	F6B8	20	CA	F5			JMP	OUTCHE	
4436	F6BB	4C	B3	FC		ERETN:	DSPFLG	; AND RETURN THROUGH RETUR1	
4437	F6BE	AD	FE	02		EDUTC5:	LDA	ESCFLG	
4438	F6C1	0D	A2	02			ORA	EDUTC6	
4439	F6C4	DO	EF				BNE	ESCFLG	
4440	F6C6	OE	A2	02			ASL		
4441	F6C9	E8					INX		
4442	F6CA	BD	C6	FE			LDA	CNTRLS,X	
4443	F6CD	B5	64				STA		
4444	F6CF	BD	C7	FE			LDA	ADRESS	
4445	F6D2	85	65				ADR	CNTRLS+1,X	
4446	F6D4	20	A1	F6			STA	GET HIGH BYTE	
4447	F6D7	20	21	F6			JSR	JSR IND	
4448	F6DA	4C	B3	FC			JSR	RETUR2	
4449							JMP	SWAP	
4450									
4451									
4452									
4453									
4454									
4455									
4456									
4457									
4458									
4459									
4460									
4461	F6DD	A9	FF			KGETC2:	LDA	#\$FF	
4462	F6DF	BD	FC	02			STA	CH	
4463	F6E2	A5	2A			KGETCH:	LDA	ICAX1Z	
4464	F6E4	4A					STA	A	
4465	F6E5	B0	62				LSR		
4466	F6E7	A9	B0				BCS	GETOUT	
4467	F6E9	A6	11				LDA	#BRKABT	
4468	F6EB	F0	58				LDX	BRKKEY	
4469	F6ED	AD	FC	02			BEQ	K7	
4470	F6F0	C9	FF				LDA	CH	
4471	F6F2	F0	EE				CMP	#\$FF	
4472	F6F4	B5	7C				KGETCH	HOLDCH	
4473	F6F6	A2	FF				BEQ	#\$FF	
4474	F6FB	BE	FC	02			LDX	LDX	
4475	F6FB	20	D8	FC			STX	CH	
4476	F6FE	AA					JSR	CLICK	
4477	F6FF	E0	CO			KGETC3:	TAX		
4478	F701	90	02				CPX	#\$CO	
4479	F703	A2	03				BCC	ASCC01	
4480	F705	BD	FE	FE			LDX	#3	
4481	F708	BD	FB	02			LDA	ATASCII,X	
4482	F70B	C9	80				STA	ATTACHR	
4483	F70D	F0	CE				CMP	#\$BO	
4484	F70F	C9	B1				BEG	KGETC2	
4485	F711	DO	OB				CMP	#\$B1	
4486	F713	AD	B6	02			BNE	KGETC1	
							LDA	INVFLG	

```

4487 F716 49 80 EOR ##$B0
4488 F718 8D B6 02 STA INVFLG
4489 F71B 4C DD F6 JMP KGETC2
4490 F71E C9 B2 KGETC1: CMP ##$B2
4491 F720 D0 07 BNE K1 ; DONT RETURN A VALUE
4492 F722 A9 00 LDA #0 ; CAPS/LOWER
4493 F724 8D BE 02 STA SHFLOK
4494 F727 F0 B4 BEQ KGETC2 ; CLEAR SHFLOK
4495 F729 C9 B3 CMP ##$B3 ; SHIFT CAPS/LOWER
4496 F72B DO 07 BNE K2
4497 F72D A9 40 LDA ##$40 ; SHIFT BIT
4498 F72F 8D BE 02 STA SHFLOK
4499 F732 DO A9 BNE K3 ; CNTL CAPS/LOWER
4500 F734 C9 B4 CMP ##$B4
4501 F736 DO 07 BNE K3 ; CNTL BIT
4502 F738 A9 80 LDA ##$80
4503 F73A 8D BE 02 STA SHFLOK
4504 F73D DO 9E BNE KGETC2
4505 F73F C9 85 CMP ##$85 ; DO EOF
4506 F741 DO OA BNE K5
4507 F743 A9 88 LDA #EOFERR
4508 F745 85 4C STA DSTAT
4509 F747 85 11 STA BRKEY
4510 F749 A9 9B GETOUT: LDA #CR
4511 F74B DO 26 BNE KB ; (UNCONDITIONAL)
4512 F74D A5 7C LDA HOLDCH ; PROCESS SHIFT LOCKS
4513 F74F C9 40 CMP ##$40 ; REGULAR SHIFT AND CONTROL TAKE PRECEDENCE
4514 F751 B0 15 BCS K5 ; OVER LOCK
4515 F753 AD FB 02 LDA ATACHR ; TEST FOR ALPHA
4516 F756 C9 61 CMP ##$61 ; LOWER CASE A
4517 F758 90 0E BCC K5 ; NOT ALPHA IF LT
4518 F75A C9 7B CMP ##$7B ; LOWER CASE Z+1
4519 F75C B0 QA K5 ; NOT ALPHA IF GE
4520 F75E AD BE 02 LDA SHFLOK ; DO SHIFT/CONTROL LOCK
4521 F761 F0 05 BEQ K5 ; IF NO LOCK, DONT RE-DO IT
4522 F763 05 7C HDLDCH
4523 F765 4C FE F6 ORA
4524 F768 20 BD FC JMP KGETC3
4525 F76B F0 09 TSTCTL
4526 F76D AD FB 02 JSR K4 ; DO RETRY
4527 F770 4D B6 02 BEQ K4 ; DONT INVERT MSB OF CONTROL CHARACTERS
4528 F773 BD FB 02 STA ATACHR
4529 F776 4C 34 F6 JMP RETUR1 ; ALL DONE
4530 ; 4531

```

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER -- 10-30-78 -- DISPLC	PAGE	PAGE 103
4532						.PAGE		
4533						; CONTROL CHARACTER PROCESSORS		
4534						ESCAPE: LDA #\$\$BO ; SET ESCAPE FLAG		
4535						STA ESCFLG		
4536	F779	A9	B0		02	RTS		
4537	F77B	BD	A2	02		CRSRUP: DEC	ROWCRS	
4538	F77E	60				BPL	COMRET	
4539	F77F	C6	54			LDX BOTSCR	WRAPAROUND	
4540	F781	10	06			DEX		
4541	F783	AE	BF	02		UPDNCM: STX ; CONVERT ROW AND COL TO LOGCOL AND RETURN		
4542	F786	CA				COMRET: JMP STRBEG		
4543	F787	B6	54			CRSRDN: INC ROWCRS		
4544	F789	4C	5C	FC		LDA ROWCRS		
4545	F793	90	F4			CMP BOTSCR		
4546	F79C	E6	54			BCC COMRET		
4547	F79E	A5	54			#O LDX		
4548	F79F	CD	BF	02		BEQ UPDNCM		
4549	F799	CD	BF	02		DEC COLCRS		
4550	F795	A2	00			LDA COLCRS		
4551	F797	FO	EE			BMI CRSRL1		
4552	F799	C6	55			CMP LMARGIN		
4553	F79B	A5	55			LDA COMRE1		
4554	F79D	30	04			CMP RMARGIN		
4555	F79F	C5	52			LDA COLCRS		
4556	F7A1	B0	04			BEQ DOLCOL		
4557	F7A3	A5	53			LDA COLCRS		
4558	F7A5	B5	55			CMP RMARGIN		
4559	F7A7	4C	DD	FB		BCC COMRE1		
4560	F7AA	E6	55			BEQ COMRE1		
4561	F7AC	A5	55			LDA LMARGIN		
4562	F7AE	C5	53			CMP LFRTCM		
4563	F7B0	90	F5			BCC PUTMSC		
4564	F7B2	F0	F3			BEQ #O LDY		
4565	F7B4	A5	52			TYA (ADDRESS), Y		
4566	F7B6	4C	57			CLRSC2: STA INY		
4567	F7B9	20	F3	FC		INY CLRSC2		
4568	F7BC	A0	00			BNB INC		
4569	F7BE	98				LDX ADDRESS+1		
4570	F7BF	91	64			CPX RAMTOP		
						BCC CLRSC2		
4571	F7C1	C8				INC ADDRESS+1		
4572	F7C2	DO	FB			LDA CLRSC2		
4573	F7C4	E6	65			HOME: JSR #\$\$FF	CLEAN UP LOGICAL LINE BIT MAP	
4574	F7C6	A6	65			STA LOGMAP, Y	; (Y IS ZERO AFTER CLRSC2 LOOP)	
4575	F7CB	E4	6A			LDA INY		
4576	F7CA	90	F3			CPY #4 CLRSC3		
4577	F7CC	A9	FF			BCC CDLCR		
4578	F7CE	99	B2	02		INC LOGCOL		
4579	F7D1	C8				STA BUFSTR+1		
4580	F7D2	CO	04			LDA #O		
4581	F7D4	90	F8					
4582	F7D6	20	E4	FC				
4583	F7D9	B5	63					
4584	F7DB	85	6D					
4585	F7DD	A9	00					

```

4586 F7DF 85 54 STA ROWCRS
4587 F7E1 85 56 STA COLCRS+1
4588 F7E3 85 6C STA BUFSTR
4589 F7E5 60 RTS

4590 F7E6 A5 63 ; BS: LDA LOGCOL
4591 F7E8 C5 52 ; BS: CMP LMARGIN
4592 F7EA F0 21 ; BSA: BEQ BS1
4593 F7EC A5 55 ; BSA: LDA CDLCRS
4594 F7EE C5 52 ; BSA: CMP LMARGIN
4595 F7F0 D0 03 ; BNE BS3
4596 F7F2 20 73 FC ; NO
4597 F7F4 20 99 F7 ; YES, SEE IF LINE SHOULD BE DELETED
4598 F7F5 20 99 F7 ; BS3: JSR DELTIM
4599 F7F8 A5 55 ; JSR CRSLRF
4600 F7FA C5 53 ; LDA COLCRS
4601 F7FC D0 07 ; CMP RMARGIN
4602 F7FE A5 54 ; BNE BS2
4603 F800 F0 03 ; LDA RDWCRS
4604 F802 20 7F F7 ; BEQ BS2
4605 F805 A9 20 ; JSR CRSRUP
4606 F807 BD FB 02 ; LDA ##20
4607 F80A 20 EO F5 ; ATACHR
4608 F80D 4C DD FB ; OUTPLT
4609 F810 20 AA F7 ; DOLCOL
4610 F813 A5 55 ; TAB: JSR CRSSRT
4611 F815 C5 52 ; LDA COLCRS
4612 F817 DO 0A ; LMARGIN
4613 F819 20 34 FA ; CMP BNE
4614 F81C 20 20 FB ; JMP DOCR
4615 F81F 90 02 ; JSR LOGGET
4616 F821 B0 07 ; BCC TAB1
4617 F823 A5 63 ; BCS TAB2
4618 F825 20 25 FB ; TAB1: LDA LOGCOL
4619 F828 90 E6 ; JSR BITGET
4620 F82A 4C DD FB ; BCC DDLCOL
4621 F82D A5 63 ; TAB2: JMP LOGCOL
4622 F82F 4C 06 FB ; SETTAB: LDA BITSET
4623 F832 A5 63 ; CLR TAB: LDA LOGCOL
4624 F834 4C 12 FB ; JMP BITCLR
4625 F837 20 9D FC ; INSCR: JSR PHACRS
4626 F83A 20 A2 F5 ; GETPLT STA INSDAT
4627 F83D 85 7D ; STA #O
4628 F83F A9 00 ; LDA SCRFLG
4629 F841 BD BB 02 ; STA DUTCH2
4630 F844 20 FF F5 ; INSCH4: JSR LOGCOL
4631 F847 A5 63 ; LDA PHA
4632 F849 48 ; JSR INCRSA
4633 F84A 20 DC F9 ; PLA
4634 F84D 6B ; CMP LOGCOL
4635 F84E C5 63 ; BCS INSCH3
4636 F850 B0 OC ; LDA INSDAT
4637 F852 A5 7D ; JSR PHA
4638 F854 48 ; GETPLT
4639 F855 20 A2 F5

```

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER	-- 10-30-78 --	DISPLC	PAGE
4640	F858	85	7D			STA	INSDAT		105
4641	F85A	6B				PLA			
4642	F85B	4C	44	FB		JMP	INSCH4		
4643	F85E	20	A8	FC		INSCH3:	PLACRS		
4644	F861	CE	BB	02		INSCH6:	SCRFLG		
4645	F864	30	04			DEC	INSCHS		
4646	F866	C6	54			BMI	ROWCRS		
4647	F86B	DO	F7			DEC	INSCH6		
4648	F86A	4C	DD	FB		BNE	DOLCOL		
4649						JMP			
4650						DELCHR:	PHACRS		
4651	FB6D	20	9D	FC		JSR	CONVRT		
4652	F870	20	47	F9		DELCH1:	JSR		
4653	F873	A5	64			LDA	ADDRESS		
4654	F875	85	68			STA	SAVADR		
4655	F877	A5	65			LDA	ADDRESS+1		
4656	F879	85	69			STA	SAVADR+1		
4657	F87B	A5	63			LDA	LOGCOL		
4658	F87D	4B				PHA			
4659	F87E	20	D4	F9		JSR	INCRSB		
4660	F8B1	6B				PLA			
4661	F8B2	C5	63			CMP	LOGCOL		
4662	F8B4	B0	10			BCS	DELCH2		
4663	F8B6	A5	54			LDA	ROWCRS		
4664	F8B8	CD	BF	02		CMP	BOTSZR		
4665	F8BB	B0	09			BCS	DELCH2		
4666	F8BD	20	A2	F5		JSR	GETPLT		
4667	F890	A0	00			#0			
4668	F892	91	68			LDY			
4669	F894	F0	DA			STA	(SAVADR), Y		
4670	F896	A0	00			BEG	DELCH1		
4671	F898	98				DELCH2:	LDY		
4672	F899	91	68			TYA			
4673	F89B	20	68	FC		STA	(SAVADR), Y		
4674	FB9E	20	AB	FC		JSR	DELTAIA		
4675	F8A1	4C	DD	FB		JMP	PLACRS		
4676	F8A4	38				INSLIN:	DOLCOL		
4677	F8A5	20	7B	FB		SEC			
4678	F8AB	A5	52			INSLIA:	EXTEND		
4679	F8AA	85	55			JSR	LMARGIN		
4680	FBAC	20	47	F9		STA	COLCRS		
4681	F8AF	A5	64			JSR	CONVRT		
4682	F8B1	85	6B			LDA	ADDRESS		
4683	FBB3	1B				STA	FRMADR		
4684	FBB4	69	2B			CLC			
4685	FBB6	85	66			ADC	#40		
4686	FBBB	A5	65			STA	TOADR		
4687	FBB4	85	69			LDA	ADDRESS+1		
4688	FBBC	69	00			STA	FRMADR+1		
4689	FBBE	85	67			LDX	#0		
4690	FBC0	A6	54			CPX	TOADR+1		
4691	FBC2	E0	17			BEG	ROWCRS		
4692	FBC4	F0	08			INSL12	#23		
4693	FBC6	20	4E	FB		JSR	MOVLIN		

ERR LINE	ADDR	B1	B2	B3	B4	
4694	FBC9	E8				INX #23
4695	FBCA	E0 17				CPX INSLI1
4696	FBCC	DO F8				BNE CLRIN
4697	FBCE	20 9B FB				INSLI2: JSR DOLCOL
4698	FBD1	4C DD FB				JMP DOLCOL
4699	FBD4	20 DD FB				DELLIN: JSR DOLCOL
4700	FBD7	A4 51				DELLIA: LDY HOLD1
4701	FBD9	84 54				STY ROWCRS
4702	FBDB	A4 54				DELLIB: LDY ROWCRS
4703	F8DD	98				DELLII: TYA
4704	F8DE	38				SEC LOGGET
4705	F8DF	20 23 FB				JSR LOGGET
4706	F8E2	08				PHP
4707	F8E3	98				TYA
4708	F8E4	18				CLC
4709	F8E5	69 78				ADC #120
4710	F8E7	28	04	FB		PLP
4711	F8E8	20	04	FB		BITPUT
4712	F8EB	CB				INY
4713	FBEC	CO 18				CPY #24
4714	F8EE	DO ED				BNE DELLI1
4715	F8F0	AD B4 02				LDGMAP+2
4716	F8F3	09 01				LDA SET LSB
4717	F8F5	BD B4 02				ORA #1
4718	F8FB	A5 52				STA LOGMAP+2
4719	F8FA	B5 55				LMARGIN
4720	F8FC	20 47 F9				CDLCRS
4721	F8FF	20 B7 FB				CONVRT
4722	F902	20 20 FB				SCROLL1
4723						JSR LOGGET
4724	F905	90 D4				; IS IT A NEW LOG LINE?
4725	F907	4C DD FB				BCC DELLIB
4726	F90A	A0 20				JMP DOLCOL
4727	F90C	20 DB FC				LDY #\$20
4728	F90F	88				JSR CLICK
4729	F910	10 FA				DEY DEY
4730	F912	60				BPL RTS

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER -- 10-30-78 --	DISPLC	PAGE
4731						.PAGE		107
4732								
4733								
4734								
4735								
4736								
4737								
4738								
4739								
4740	F913	A9	02					
4741	F915	DO	0A					
4742								
4743								
4744	F917	A4	4C					
4745	F919	30	2B					
4746	F91B	A0	00					
4747	F91D	91	64					
4748								
4749								
4750								
4751	F91F	A9	01					
4752	F921	8D	9E	02				
4753	F924	A5	4C					
4754	F926	30	1E					
4755	F928	A5	64					
4756	F92A	38						
4757	F92B	ED	9E	02				
4758	F92E	B5	64					
4759	F930	BO	02					
4760	F932	C6	65					
4761	F934	A5	0F					
4762	F936	C5	65					
4763	F938	90	0C					
4764	F93A	DO	06					
4765	F93C	A5	0E					
4766	F93E	C5	64					
4767	F940	90	04					
4768	F942	A9	93					
4769	F944	85	4C					
4770	F946	60						
4771								
4772								
4773								
4774								
4775	F947	A5	54					
4776	F949	48						
4777	F94A	A5	55					
4778	F94C	48						
4779	F94D	A5	56					
4780	F94F	48						
4781	F950	20	F3	FC				
4782	F953	A5	54					
4783	F955	85	66					

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER -- 10-30-78 --	DISPLC	PAGE
4731								107
4732								
4733								
4734								
4735								
4736								
4737								
4738								
4739								
4740	F913	A9	02					
4741	F915	DO	0A					
4742								
4743								
4744	F917	A4	4C					
4745	F919	30	2B					
4746	F91B	A0	00					
4747	F91D	91	64					
4748								
4749								
4750								
4751	F91F	A9	01					
4752	F921	8D	9E	02				
4753	F924	A5	4C					
4754	F926	30	1E					
4755	F928	A5	64					
4756	F92A	38						
4757	F92B	ED	9E	02				
4758	F92E	B5	64					
4759	F930	BO	02					
4760	F932	C6	65					
4761	F934	A5	0F					
4762	F936	C5	65					
4763	F938	90	0C					
4764	F93A	DO	06					
4765	F93C	A5	0E					
4766	F93E	C5	64					
4767	F940	90	04					
4768	F942	A9	93					
4769	F944	85	4C					
4770	F946	60						
4771								
4772								
4773								
4774								
4775	F947	A5	54					
4776	F949	48						
4777	F94A	A5	55					
4778	F94C	48						
4779	F94D	A5	56					
4780	F94F	48						
4781	F950	20	F3	FC				
4782	F953	A5	54					
4783	F955	85	66					

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER -- 10-30-78 --	DISPLC	PAGE
4731								107
4732								
4733								
4734								
4735								
4736								
4737								
4738								
4739								
4740	F913	A9	02					
4741	F915	DO	0A					
4742								
4743								
4744	F917	A4	4C					
4745	F919	30	2B					
4746	F91B	A0	00					
4747	F91D	91	64					
4748								
4749								
4750								
4751	F91F	A9	01					
4752	F921	8D	9E	02				
4753	F924	A5	4C					
4754	F926	30	1E					
4755	F928	A5	64					
4756	F92A	38						
4757	F92B	ED	9E	02				
4758	F92E	B5	64					
4759	F930	BO	02					
4760	F932	C6	65					
4761	F934	A5	0F					
4762	F936	C5	65					
4763	F938	90	0C					
4764	F93A	DO	06					
4765	F93C	A5	0E					
4766	F93E	C5	64					
4767	F940	90	04					
4768	F942	A9	93					
4769	F944	85	4C					
4770	F946	60						
4771								
4772								
4773								
4774								
4775	F947	A5	54					
4776	F949	48						
4777	F94A	A5	55					
4778	F94C	48						
4779	F94D	A5	56					
4780	F94F	48						
4781	F950	20	F3	FC				
4782	F953	A5	54					
4783	F955	85	66					

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER -- 10-30-78 --	DISPLC	PAGE
4731								107
4732								
4733								
4734								
4735								
4736								
4737								
4738								
4739								
4740	F913	A9	02					
4741	F915	DO	0A					
4742								
4743								
4744	F917	A4	4C					
4745	F919	30	2B					
4746	F91B	A0	00					
4747	F91D	91	64					
4748								
4749								
4750								
4751	F91F	A9	01					
4752	F921	8D	9E	02				
4753	F924	A5	4C					
4754	F926	30	1E					
4755	F928	A5	64					
4756	F92A	38						
4757	F92B	ED	9E	02				
4758	F92E	B5	64					
4759	F930	BO	02					
4760	F932	C6	65					
4761	F934	A5	0F					
4762	F936	C5	65					
4763	F938	90	0C					
4764	F93A	DO	06					
4765	F93C	A5	0E					
4766	F93E	C5	64					
4767	F940	90	04					
4768	F942	A9	93					
4769	F944	85	4C					
4770	F946	60						
4771								
4772								
4773								
4774								
4775	F947	A5	54					
4776	F949	48						
4777	F94A	A5	55					
4778	F94C	48						
4779	F94D	A5	56					
4780	F94F	48						
4781	F950	20	F3	FC				
4782	F953	A5	54					
4783	F955	85	66					
4784	F957							

ERR LINE

DISPLAY HANDLER -- 10-30-78 -- DISPLC

PAGE 108

```

4785 F957 A9 00          LDA #0
4786 F959 85 67          STA MLTTMP+1
4787 F95B A5 66          LDA MLTTMP
4788 F95D 0A              ASL A           ; QUICK XB
4789 F95E 26 67          ROL MLTTMP+1
4790 F960 85 51          STA HOLD1      ; (SAVE 2X VALUE)
4791 F962 A4 67          LDY MLTTMP+1
4792 F964 BC 9F 02        STY HOLD2      ; " "
4793 F967 0A              ASL A           ; "
4794 F968 26 67          ROL MLTTMP+1
4795 F96A 0A              ASL A           ; ADD IN 2X
4796 F96B 26 67          ROL MLTTMP+1
4797 F96D 18              CLC             ; ADD IN 2X
4798 F96E 65 51          ADC HOLD1
4799 F970 85 66          STA MLTTMP
4800 F972 A5 67          LDA MLTTMP+1
4801 F974 6D 9F 02        ADC HOLD2
4802 F977 85 67          STA MLTTMP+1
4803 F979 A6 57          LDX INDEX      ; NOW SHIFT MLTTMP LEFT DHLINE TIMES TO FINIS
4804 F97B BC 81 FE        LDY DHLINE, X ; MULTIPLY
4805 F97E 88              CONVR1: DEY ; LOOP N TIMES
4806 F97F 30 07          BMI CONVR2
4807 F981 06 66          ASL MLTTMP
4808 F983 26 67          ROL MLTTMP+1
4809 F985 4C 7E F9        CONVR2: LDY DIV2TB, X ; NOW DIVIDE HCRSR TO ACCOUNT FOR PARTIAL BYT
4810 F988 BC A5 FE        FEE          COLCRS
4811 F98B A5 55          LDA #7          ; * TRICKY *
4812 F98D A2 07          LDX
4813 F98F BB              CONVR3: DEY
4814 F990 30 0A          BMI CONVR4
4815 F992 CA              DEX
4816 F993 46 56          LSR COLCRS+1
4817 F995 6A              ROR A           ; SAVE LOW BITS FOR MASK
4818 F996 6E A1 02        ROR TMPLBT
4819 F999 4C 8F F9        CONVR4: INC CONVR3 ; SO Y IS ZERO UPON RETURN FROM THIS ROUTINE
4820 F99C CB              CLC MLTTMP
4821 F99D 18              ADC STA MLTTMP
4822 F99E 65 66          BCC CONVR5
4823 F9AO 85 66          INC MLTTMP+1
4824 F9A2 90 02          CLC TMPLBT      ; * TRICKY * ; SLIDE A "1" UP AGAINST LOW BITS (CONTINUE T
4825 F9A4 E6 67          SEC
4826 F9A6 38              CONVR5: SEC
4827 F9A7 6E A1 02        CONVR6: RDR CLC ; AND FINISH SHIFT SO LOW BITS ARE
4828 F9AA 18              DEX
4829 F9AB CA              BPL CONVR6
4830 F9AC 10 F9              LDX TMPLBT
4831 F9AE AE A1 02        LDA MLTTMP
4832 F9B1 A5 66          CLC ; RIGHT JUSTIFIED.
4833 F9B3 18              ADC ; TMPLBT IS NOW THE INDEX INTO DMASKTB
4834 F9B4 65 64          STA ; PREPARE FOR RETURN
4835 F9B6 85 64          ADDRESS
4836 F9BB 85 5E          ADDRESS
4837 F9BA A5 67          STA OLDADR
4838 F9BC 65 65          LDA MLTTMP+1
                                ADC ADDRESS+1

```

ERR LINE

DISPLAY HANDLER -- 10-30-78 -- DISPLC

PAGE 109

```

4839 F9BE 85 65 STA ADDRESS+1
4840 F9CO 85 5F STA OLDADR+1
4841 F9C2 BD B1 FE LDA DMASKT, X
4842 F9C5 BD A0 02 STA DMASK
4843 F9C8 85 6F STA SHFAMT
4844 F9CA 68 PLA COLCRS+1
4845 F9CB 85 56 STA COLCRS
4846 F9CD 68 PLA COLCRS
4847 F9CE 85 55 STA COLCRS
4848 F9DD 68 PLA ROWCRS
4849 F9D1 85 54 STA RTS
4850 F9D3 60

; INCREMENT CURSOR AND DETECT BOTH END OF LINE AND END OF SCREEN

4851
4852
4853
4854
4855
4856
4857
4858
4859
4860
4861
4862
4863
4864
4865
4866
4867
4868
4869
4870
4871
4872
4873
4874
4875
4876
4877
4878
4879
4880
4881
4882
4883
4884
4885
4886
4887
4888
4889
4890
4891
4892 F9D4 49 00 INCRSB: LDA #0 ; NON-EXTEND ENTRY POINT
F9D6 F0 02 BEG INCRSC: LDA ##9B ; SPECIAL CASE ELIMINATOR
F9D8 A9 9B INCRS: STA INSDAT ; (INSCHR ENTRY POINT)
F9DA 85 7D INCRSA: INC LOGCOL
F9DC E6 63 INC COLCRS
F9DE E6 55 BNE INCRS2 ; DO HIGH BYTE
F9E0 DO 02 INC COLCRS+1 ; TEST END OF LINE
F9E2 E6 56 INC COLCRS
F9E4 A5 55 INCRS2: LDA DINDEX ; TEST TABLED VALUE FOR ALL SCREEN MODES
F9E6 A6 57 LDX COLUMN, X ; DO CR IF EQUAL
F9EB DD 8D FEEQ INC2A ; MODE 0?
F9EB F0 0B CMP #0 ; IF NOT, JUST RETURN
F9ED E0 00 CPX INCRS3 ; TEST AGAINST RMARGN
F9EF DO 06 BNE INCRS3 ; EQUAL IS OK
F9F1 C5 53 CMP INCRS3 ; IF GREATER THAN, DO CR
F9F3 F0 02 BEQ INC2A
F9F5 B0 01 BCS INC2A
F9F7 60 RTS
F9FB E0 0B INC2A: CRX #8 ; CHECK MODE
F9FA 90 04 BCC DDCR1 ; NOT 320X1 SO DO IT
F9FC A5 56 LDA COLCRS+1 ; TEST MSD
F9FE F0 F7 BEQ INCRS3 ; ONLY AT 64 SO DON'T DO IT
FA00 A5 57 DOCR1: LDA DINDEX ; DON'T MESS WITH LOGMAP IF NO MODE ZERO
FA02 DO 30 BNE DDCR
FA04 A5 63 LDA LOGCOL
FA06 C9 51 CMP #81 ; TEST LINE OVERRUN
FA08 90 0A BCC DOCR1B ; IF LESS THAN 81 IT IS DEFINITELY NOT LINE 3
FA0A A5 7D INSDAT
FA0C F0 26 BEQ DOCR ; ONLY DO LOG LINE OVERFLOW IF INSDAT <> 0
FA0E 20 30 FA JSR DDCRWS ; LOG LINE OVERFLOW IS SPECIAL CASE
FA11 4C 77 FA JMP INCRS1 ; RETURN
FA14 20 34 FA DOCR1B: JSR DOCR ; GET IT OVER WITH
FA0A A5 54 LDA ROWCRS
FA17 A5 54 CLC
FA19 18 ADC #120 ; TEST LOGICAL LINE BIT MAP
FA1A 69 78 JSR BITGET
FA1C 20 25 FB BCC DOCR1A ; DON'T EXTEND IF OVERRUN IS INTO MIDDLE OF L
FA1F 90 0B LDA INSDAT ; DON'T EXTEND IF INSDAT IS ZERO
FA21 A5 7D

```

ERR LINE

DISPLAY HANDLER -- 10-30-78 -- DISPLC

PAGE 110

ADDR	B1	B2	B3	B4	DISPLC
4893	FA23	F0	04		BEQ DOCR1A ; (INSCR SPECIAL CASE) CLC ; INSERT "0" INTO BIT MAP
4894	FA25	18			JSR INSLIA ; CONVERT ROW AND COL TO LOGCOL AND RETURN
4895	FA26	20	A5	F8	DOLCOL #0 ; DOCR WITHOUT SCROLL
4896	FA29	4C	DD	FB	DOCSR1 ; (UNCONDITIONAL)
4897	FA2C	A9	00		DOCRWS: LDA ##A9B ; DOCR WITH SCROLLING (NORMAL MODE)
4898	FA2E	F0	02		DOSCR1: STA INSDAT ; PLACE COLCRS AT LEFT EDGE
4899	FA30	A9	9B		DOCR: JSR COLCR ; PLACE COLCRS+1
4900	FA32	85	7D		LDA #0 ; ROWCRS
4901	FA34	20	E4	FC	STA COLCRS+1 ; INDEX
4902	FA37	A9	00		INC LDX #24 ; SET UP SCROLL LOOP COUNTER
4903	FA39	85	56		BIT SWPFLG ; BRANCH IF NORMAL
4904	FA3B	E6	54		DOCR2: BPL #4 ;
4905	FA3D	A6	57		LDY TYA ; (UNCONDITIONAL) DOCR2A: BNE NOROWS, X ; GET NO OF ROWS
4906	FA3F	A0	18		DOCR2B: CMP ROWCRS ; INCRS1
4907	FA41	24	7B		BNE INCRS1 ; DON'T SCROLL IF MODE <> 0
4908	FA43	10	05		DOCSR1: INSDAT INCRS1 ; OR IF INSDAT = 0
4909	FA45	A0	04		DOCR2: BEQ INSDAT ; IF INSDAT <> \$9B THEN ROLL IN A 0
4910	FA47	98			LDY #7B ; TO EXTEND BOTTOM LOGICAL LINE
4911	FA48	DO	03		DOCR2A: BNE HOLD3 ;
4912	FA4A	BD	99	FE	DOCR2B: CMP HOLD3 ; SCROLL
4913	FA4D	C5	54		INC INCRS1 ; SCRFLG
4914	FA4F	DO	26		DEC BUFSR ; ROWS MOVE UP SO BUFSTR SHOULD TOO
4915	FA51	BC	9D	02	DEC HOLD3 ; LOGMAP
4916	FA54	8A			SEC BPL ; FOR PARTIAL LINES, ROLL IN A "1"
4917	FA55	DO	20		DEC LDA ; AGAIN IF PARTIAL LOGICAL LINE
4918	FA57	A5	7D		SEC STA ; PLACE CURSOR AT NEW LINE NEAR THE BOTTOM
4919	FA59	F0	1C		SEC JMP DOLCOL ; COLVERT ROW AND COL TO LOGCOL AND RETURN
4920	FA5B	C9	9B		
4921	FA5D	38			
4922	FA5E	F0	01		
4923	FA5E	F0	01		
4924	FA60	18			
4925	FA61	20	AC	FB	DOCR4B: JSR SCROLL ; LOOP BACK TO HERE IF >1 SCROLLS
4926	FA64	EE	BB	02	INC SCRFLG ; ROWS MOVE UP SO BUFSTR SHOULD TOO
4927	FA67	C6	6C		DEC HOLD3 ;
4928	FA69	CE	9D	02	DEC LDA ; LOGMAP
4929	FA6C	AD	B2	02	SEC BPL ; FOR PARTIAL LINES, ROLL IN A "1"
4930	FA6F	38			DEC LDA ; AGAIN IF PARTIAL LOGICAL LINE
4931	FA70	10	EF		SEC STA ; PLACE CURSOR AT NEW LINE NEAR THE BOTTOM
4932	FA72	AD	9D	02	SEC JMP DOLCOL ; COLVERT ROW AND COL TO LOGCOL AND RETURN
4933	FA75	B5	54		
4934	FA77	4C	DD	FB	
4935					
4936					
4937					
4938					
4939	FA7A	3B			SUBEND: SEC LDA ; ROWAC, X
4940	FA7B	B5	70		SBC ENDPT ; ENDPT
4941	FA7D	E5	74		STA RDWAC, X
4942	FA7F	95	70		LDA RDWAC+1, X
4943	FAB1	B5	71		SBC ENDPT+1 ; ENDPT+1
4944	FAB3	E5	75		STA RDWAC+1, X
4945	FAB5	95	71		RTS
4946	FAB7	60			

ERR LINE ADDR B1 B2 B3 B4

DISPLAY HANDLER -- 10-30-78 -- DISPLC

PAGE 111

```

4947
4948
4949 ; RANGE: DO CURSOR RANGE TEST. IF ERROR, POP STACK TWICE AND JMP RETURN
4950 ; (ERANGE IS EDITOR ENTRY POINT AND TEST IF EDITOR IS OPEN.
4951 ; IF IT ISN'T IT OPENS THE EDITOR AND CONTINUES)
4952
4953 FAB8 AD BF 02
4954 FABB C9 04
4955 FABD F0 07
4956 FABF A5 57
4957 FA91 F0 03
4958 FA93 20 FC F3
4959 FA96 A9 27
4960 FA98 C5 53
4961 FA9A B0 02
4962 FA9C B5 53
4963 FA9E A6 57
4964 FAA0 BD 99 FE
4965 FAA3 C5 54
4966 FAA5 90 2A
4967 FAA7 F0 2B
4968 FAA9 E0 0B
4969 FAAB D0 0A
4970 FAAD A5 56
4971 FAAF F0 13
4972 FAB1 C9 01
4973 FAB3 D0 1C
4974 FAB5 F0 04
4975 FAB7 A5 56
4976 FAB9 D0 16
4977 FABB BD BD FE
4978 FABE C5 55
4979 FAC0 90 0F
4980 FAC2 F0 OD
4981 FAC4 A9 01
4982 FAC6 85 4C
4983 FAC8 A9 80
4984 FACA A6 11
4985 FACC 85 11
4986 FACE F0 06
4987 FADO 60
4988 FAD1 20 D6 F7
4989 FAD4 A9 8D
4990 FAD6 85 4C
4991 FADB 68
4992 FAD9 68
4993 FADA A5 7B
4994 FADC 10 03
4995 FADE 20 B9 FC
4996 FAE1 4C 34 F6
4997
4998
4999 5000

; IF BOTSCR=4
; THEN IT IS IN MIXED MODE AND OK
; IF MODE = 0
; THEN IT IS IN EDITOR MODE AND OK
; IF NOT, OPEN EDITOR
; **** RANGE CHECK RMARGN ***** SET UP AC
; **** RANGE CHECK RMARGN ***** COMPARE
; **** RANGE CHECK RMARGN ***** BRANCH GE
; **** RANGE CHECK RMARGN ***** BAD SD STORE
; CHECK ROWS
; <ERROR IF TABLE. GE. ROWCRS>
; RNGERR
; RNGERR
; BEQ
; CPX #B
; CHECK FOR 320X1
; BNE RANGE1
; SPECIAL CASE IT
; LDA COLCRS+1
; BEQ RNGOK
; IF HIGH BYTE IS 0, COL IS OK
; CMP #1
; IF >1, BAD
; BNE RANGE2
; BEQ. LDA COLCRS+1
; FOR OTHERS, NON-ZERO HIGH BYTE IS BAD
; BNE RNGERR
; COLUMN, X
; CMP COLCRS
; BCC RNGERR
; BEQ RNGERR
; CHECK LOW BYTE
; SET STATUS OK
; PREPARE BREAK ABORT STATUS
; #BRKABT
; BRKKEY
; LDX BRKKEY
; STA BRKKEY
; STA RNGER2
; BEQ RNGOK
; DSTAT
; #CRSROR
; LDA DSTAT
; #CRSROR
; LDA DSTAT
; HOME
; #CRSROR
; LDA DSTAT
; RTS
; RNGERR: JSR PLA
; RNGER2: STA PLA
; RNGER1: PLA
; SWPFLG
; RETUR3
; BPL SWAPA
; JSR RETUR1
; JMP RETUR1

; ON RANGE ERROR, BRING CURSOR BACK
; SHOW CURSOR OVERRANGE ERROR
; RESTORE STACK (THIS ROUTINE IS ALWAYS 1 LEV
; AWAY FROM RETURN TO CIO)
; IF SWAPPED, SWAP BACK
; AND DONT DO RETUR1
; RETURN TO CIO

; OFFCRS: RESTORE OLD DATA UNDER CURSOR SO IT CAN BE MOVED

```

ERR LINE ADDR B1 B2 B3 B4

DISPLAY HANDLER -- 10-30-78 -- DISPLC

PAGE 112

ERR LINE ADDR B1 B2 B3 B4 DISPLAY HANDLER -- 10-30-78 -- DISPLC

```

5055 FB23 69 78              L02GET: ADC #120
5056 FB25 20 EB FA              BITGET: JSR BITCON
5057 FB28 18              CLC
5058 FB29 BD A3 02              LDA TABMAP, X
5059 FB2C 25 6E              AND BITMSK
5060 FB2E F0 01              BEQ BITGE1
5061 FB30 38              SEC
5062 FB31 60              BITGE1: RTS
5063              ;
5064              ;
5065              ;
5066              ;
5067              ; INATAC: INTERNAL(CHAR) TO ATASCII(ATACHR) CONVERSION
5068 FB32 AD FA 02              INATAC: LDA CHAR
5069 FB35 A4 57              LDY DINDEX ; IF GRAPHICS MODES
5070 FB37 C0 03              CPY #3
5071 FB39 BO OF              BCS INATA1 ; THEN DON'T CHANGE CHAR
5072 FB3B 2A              ROL A
5073 FB3B 2A              ROL A
5074 FB3C 2A              ROL A
5075 FB3D 2A              ROL A
5076 FB3E 2A              ROL A
5077 FB3F 29 03              AND #3
5078 FB41 AA              TAX
5079 FB42 AD FA 02              LDA CHAR
5080 FB45 29 9F              AND $$9F
5081 FB47 1D FA FE              ORA INTATA, X
5082 FB4A 8D FB 02              INATA1: STA ATACHR
5083 FB4D 60              RTS
5084              ;
5085              ;
5086              ;
5087              ; MOVLIN: MOVE 40 BYTES AT FRMADR TO TOADR SAVING OLD TOADR
5088              ; DATA IN THE LINBUF. THEN MAKE NEXT FRMADR
5089              ; BE AT LINBUF FOR NEXT TRANSFER & TOADR=TOADR+40
5090              ; MOVLIN: LDA #LINBUF/256 ; SET UP ADDRESS=LINBUF=$247
5091 FB4E A9 02              STA ADDRESS+1
5092 FB50 85 65              LDA #LINBUF. AND. $FF
5093 FB52 A9 47              STA ADDRESS
5094 FB54 85 64              LDY #39
5095 FB56 A0 27              MOVLIN1: LDA (TOADR), Y ; SAVE TO DATA
5096 FB58 B1 66              STA TMPCHR
5097 FB5A 85 50              LDA (FRMADR), Y ; STORE DATA
5098 FB5C B1 68              STA (TOADR), Y
5099 FB5E 91 66              STA TMPCHR
5100 FB60 A5 50              LDA (ADRESS), Y
5101 FB62 91 64              STA DEY
5102 FB64 88              DEY
5103 FB65 10 F1              BPL MOVLIN1
5104 FB67 A5 65              LDA ADDRESS+1 ; SET UP FRMADR=LAST LINE
5105 FB69 85 69              STA FRMADR+1
5106 FB6B A5 64              LDA ADDRESS
5107 FB6D B5 68              STA FRMADR
5108 FB6F 18              CLC ; ADD 40 TO TOADR

```

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER -- 10-30-78 --	DISPLC
5109	FB70	A5	66			LDA TOADR	
5110	FB72	69	28			ADC #40	
5111	FB74	85	66			STA TOADR	
5112	FB76	90	02			MOVL12 BCC	
5113	FB78	E6	67			INC TOADR+1	
5114	FB7A	60				MOVL12: RTS	
5115							
5116							
5117							
5118							
5119							
5120	FB7B	08				EXTEND: PHP ; SAVE CARRY	
5121	FB7C	A0	17			EXTEN1: LDY #23	
5122	FB7E	98				EXTEN1: TYA JSR LDIGET	
5123	FB7F	20	22	FB			
5124	FB82	08					
5125	FB83	98					
5126	FB84	18					
5127	FB85	69	79				
5128	FB87	28					
5129	FB88	20	04	FB			
5130	FB8B	88					
5131	FB8C	30	04			EXTEN3: DEY BMI EXTE4	
5132	FBBE	C4	54			ROWCRS CPY ROWCRS	
5133	FB90	BO	EC			EXTEN1: BCS LDA ROWCRS	
5134	FB92	A5	54			EXTEN4: CLC ADC #120	
5135	FB94	18					
5136	FB95	69	78				
5137	FB97	28					
5138	FB98	4C	04	FB			
5139							
5140							
5141							
5142							
5143	FB9B	A5	52			CLRLIN: CLEAR LINE CURSOR IS ON	
5144	FB9D	85	55			CLRLIN: LDA LMARGIN	
5145	FB9F	20	47	F9		STA COLCRS	
5146	FBA2	A0	27			JSR CONVRT	
5147	FBA4	A9	00			LDY #39	
5148	FBA6	91	64			LDA #0	
5149	FBA8	88				CLRLI1: STA (ADDRESS), Y	
5150	FBA9	10	FB			DEY BPL CLRLL1	
5151	FBAB	60				RTS	
5152							
5153							
5154							
5155							
5156							
5157							
5158							
5159	FBAC	20	FA	FA		SCROLL: JSR BITROL	
5160	FBAF	A5	58			STA SAVMSC	
5161	FBB1	B5	64			STA ADDRESS	
5162	FBBC	A5	59			STA SAVMSC+1	

DISPLAY HANDLER -- 10-30-78 -- DISPLC

ERR LINE ADDR B1 B2 B3 B4

```

5163 FBB5 85 65 STA ADDRESS+1
5164 FBB7 A0 28 LDY #40 ;LOOP
5165 FBB9 B1 64 LDA (ADDRESS),Y
5166 FBBD A6 6A LDX RAMTOP ;TEST FOR LAST LINE
5167 FBBD CA DEX
5168 FBBE E4 65 CPX ADDRESS+1
5169 FBC0 D0 08 BNE SCROL2
5170 FBC2 A2 D7 LDX #$D7
5171 FBC4 E4 64 CPX ADDRESS
5172 FBC6 B0 02 BCS SCROL2
5173 FBCB A9 00 LDA #0 ;YES SO STORE ZERO DATA FOR THIS ENTIRE LINE
5174 FBCC A0 00 LDY #0
5175 FBCC 91 64 STA (ADDRESS),Y
5176 FBCE E6 64 INC ADDRESS
5177 FBDO D0 E5 BNE SCROL1
5178 FBD2 E6 65 INC ADDRESS+1
5179 FBD4 A5 65 LDA ADDRESS+1
5180 FBD6 C5 6A CMP RAMTOP
5181 FBDB D0 DD BNE SCROL1
5182 FBDA 4C DD FB JMP DOLCOL ;AND RETURN
5183
5184
5185 ;DOLCOL: DO LOGICAL COLUMN FROM BITMAP AND COLCRS
5186
5187 FBDD A9 00 ;START WITH ZERO
5188 FBDF 85 63 LDA #0 LOGCOL
5189 FBE1 A5 54 STA RDWCRS
5190 FBE3 85 51 LDA HLDI1 ;ADD IN ROW COMPONENT
5191 FBE5 A5 51 DOLCOL1: LDA HLDI1
5192 FBE7 20 22 FB JSR LOIGET ;FOUND BEGINNING OF LINE
5193 FBEA B0 OC BCS DOLCOL2 ;ADD 40 AND LOOK BACK ONE
5194 FBEC A5 63 LDA LOGCOL
5195 FBEE 18 CLC
5196 FBEF 69 28 ADC #40
5197 FBF1 85 63 STA LOGCOL
5198 FBF3 C6 51 DEC HLDI1 ;UP ONE LINE
5199 FBFS 4C E5 FB JMP DOLCOL1
5200 FBFB 18 ;ADD IN COLCRS
5201 FBFF9 A5 63 DOLCOL2: GLC
5202 FBFB 65 55 LDA LOGCOL
5203 FBFD 85 63 ADC COLCRS
5204 FBFF 60 STA LOGCOL
5205
5206
5207 ;DOBUCF: COMPUTE BUFFER COUNT AS THE NUMBER OF BYTES FROM
5208 ;BUFSTR TO END OF LOGICAL LINE WITH TRAILING SPACES REMOVED
5209
5210 ;DOBUCF: JSR PHACRS
5211 FC00 20 9D FC LDA LOGCOL
5212 FC03 A5 63 PHA
5213 FC05 48 LDA BUFSTR
5214 FC06 A5 6C STA RDWCRS
5215 FC08 85 54 LDA BUFSTR+1
5216 FC0A A5 6D

```

DISPLAY HANDLER -- 10-30-78 -- DISPLC PAGE 116

ERR LINE ADDR B1 B2 B3 B4

```

FCOC B5 55 STA LDA #1
5218 FCOE A9 01 STA LDA #23 ; NORMAL
5219 FC10 85 6B STA LDX SWPFLG ; IF SWAPPED, ROW 3 IS THE LAST LINE ON SCREE
5220 FC12 A2 17 DOBUF1: LDX BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5221 FC14 A5 7B DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5222 FC16 10 02 DOBUF1: LDX BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5223 FC18 A2 03 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5224 FC1A E4 54 DOBUF1: LDX BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5225 FC1C D0 00 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5226 FC1E A5 55 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5227 FC20 C5 53 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5228 FC22 D0 05 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5229 FC24 E6 6B DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5230 FC26 4C 39 FC DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5231 FC29 20 D4 F9 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5232 FC2C E6 6B DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5233 FC2E A5 63 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5234 FC30 C5 52 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5235 FC32 D0 DE DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5236 FC34 C6 54 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5237 FC36 20 99 F7 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5238 FC39 20 A2 F5 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5239 FC3C D0 17 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5240 FC3E C6 6B DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5241 FC40 A5 63 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5242 FC42 C5 52 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5243 FC44 F0 0F DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5244 FC46 20 99 F7 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5245 FC49 A5 55 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5246 FC4B C5 53 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5247 FC4D D0 02 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5248 FC4F C6 54 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5249 FC51 A5 6B DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5250 FC53 D0 E4 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5251 FC55 68 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5252 FC56 85 63 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5253 FC58 20 AB FC DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5254 FC5B 60 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5255 5255 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5256 5256 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5257 5257 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5258 5258 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5259 5259 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5260 5260 DOBUF1: LDA BPL #3 ; TEST IF CRSR IS AT LAST SCREEN POSITION
5261 FC5C 20 DD FB STRBEG: JSR DOLCOL
5262 FC5F A5 51 STRBEG: JSR HOLD1
5263 FC61 85 6C STRBEG: JSR BUFSTR
5264 FC63 A5 52 STRBEG: JSR LMARGIN
5265 FC65 85 6D STRBEG: JSR BUFSTR+1
5266 FC67 60 RTS
5267 5267 RTS
5268 5268 RTS
5269 5269 RTS

```

ERR LINE ADDR B1 B2 B3 B4

DISPLAY HANDLER -- 10-30-78 -- DISPLC

PAGE 117

```

5271          ; DELTIM: TIME TO DELETE A LINE IF IT IS EMPTY AND AN EXTENSION
5272          ; DELTIA: LDA LOGCOL,LMARGIN ; IF LOGCOL<LMARGIN
5273          ;           CMP LMARGIN ; THEN DONT MOVE UP ONE
5274          ;           BNE DELTIB ; LINE BEFORE TESTING DELTIM
5275          ;           DEC ROWCRS
5276          ;           DOLCOL
5277          ;           TEST FOR EXTENSION
5278          ;           DELTIB: JSR LOGCOL
5279          ;           DELTIM: LDA LMARGIN
5280          ;           FC75 C5 52           CMP LMARGIN
5281          ;           FC77 F0 13           BEQ DELTIB
5282          ;           FC79 20 47 F9           JSR CONVRT
5283          ;           FC7C A5 53           LDA RMARGIN
5284          ;           FC7E 38           SEC LMARGIN
5285          ;           FC7F E5 52           SBC
5286          ;           FC81 A8           TAY (ADDRESS),Y
5287          ;           FC82 B1 64           DELTII: LDA BNE DELTIB
5288          ;           FC84 D0 06           DEY
5289          ;           FC86 88           BPL DELTII
5290          ;           FC87 10 F9           DELTII: JMP DELLIB
5291          ;           FC89 4C DB FB           DELTIB: RTS
5292          ;           FC8C 60           ;
5293          ;           ;
5294          ;           ;
5295          ;           ;
5296          ;           ;
5297          ;           ;
5298          ;           FC8D A2 2D           TSTCTL: LDX TSTCTL1: LDA #45 CNTRLS,X
5299          ;           FCBF BD C6 FE           CMP ATACHR
5300          ;           FC92 CD FB 02           BEQ TSTCTL2
5301          ;           FC95 F0 05           DEX
5302          ;           FC97 CA           DEX
5303          ;           FC98 CA           DEX
5304          ;           FC99 CA           DEX
5305          ;           FC9A 10 F3           BPL TSTCTL1
5306          ;           FC9C 60           RTS
5307          ;           ;
5308          ;           ;
5309          ;           ;
5310          ;           ;
5311          ;           FC9D A2 02           PHACRS: LDX PHACR1: LDA #2 ROWCRS,X
5312          ;           FC9F B5 54           STA TMPROW,X
5313          ;           FCA1 9D BB 02           DEX
5314          ;           FCA4 CA           BPL PHACR1
5315          ;           FCA5 10 FB           RTS
5316          ;           FCA7 60           ;
5317          ;           ;
5318          ;           ;
5319          ;           ;
5320          ;           ;
5321          ;           FCAB A2 02           PLACRS: LDX PLACR1: LDA #2 TMPROW,X
5322          ;           FCAA BD BB 02           STA ROWCRS,X
5323          ;           FCAD 95 54           ;
5324          ;           ;

```

ERR LINE	ADDR	B1	B2	B3	B4
5325	FCAF	CA			
5326	FCB0	10	F8		
5327	FCB2	60			
5328					
5329					
5330					
5331					
5332					
5333	FCB3	20	B9	FC	
5334	FCB6	4C	34	F6	
5335	FCB9	AD	BF	02	
5336	FCBC	C9	18		
5337	FCBE	F0	17		
5338	FCC0	A2	OB		
5339	FCC2	B5	54		
5340	FCC4	4B			
5341	FCC5	BD	90	02	
5342	FCC8	95	54		
5343	FCCA	68			
5344	FCCB	9D	90	02	
5345	FCCE	CA			
5346	FCCF	10	F1		
5347	FCD1	A5	7B		
5348	FCD3	49	FF		
5349	FCD5	85	7B		
5350	FCD7	60			
5351					
5352					
5353					
5354					
5355	FCDB	A2	7F		
5356	FCDA	BE	1F	DO	
5357	FCDD	8E	OA	D4	
5358	FCE0	CA			
5359	FCE1	10	F7		
5360	FCE3	60			
5361					
5362					
5363					
5364					
5365	FCE4	A9	00		
5366	FCE6	A6	7B		
5367	FCEB	DO	04		
5368	FCEA	A6	57		
5369	FCEC	DO	02		
5370	FCEE	A5	52		
5371	FCFO	85	55		
5372	FCF2	60			
5373					
5374					
5375					
5376	FCF3	A5	58		
5377	FCF5	85	64		

```

PAGE 118

DISPLAY HANDLER -- 10-30-78 -- DISPLC

DEX      PLACR1
BPL      RTS
RTS

; SWAP: IF MIXED MODE, SWAP TEXT CURSORS WITH REGULAR CURSORS
; SWAP: JSR SWAPA RETUR1 ; THIS ENTRY POINT DOES RETUR1
SWAPA:  JMP BOTSCR
        LDA #24
        CMP BEQ SWAP3
        LDX #11
        LDA RDWCRS, X
        PHA
        LDA TXTROW, X
        STA ROWCRS, X
        PLA
        TXTROW, X
        STA DEX
        BPL SWAP1
        LDA SWPFLG
        EOR #$FF
        STA SWPFLG
        RTS

SWAP3:  RTS

; CLICK: MAKE CLICK THROUGH KEYBOARD SPEAKER
; CLICK: LDX #$7F
; CLICK1: STX CONSOL
;          STX WSYNC
;          DEX
;          BPL CLICK1
;          RTS

; COLOR: PUTS EITHER O OR LMARGIN INTO COLCRS BASED ON MODE AND SWPFLG
; COLOR: LDA #0
;        LDX SWPFLG
;        BNE COLCR1
;        LDX DINDEX
;        BNE COLCR2
;        LDA LMARGIN
;        STA COLCRS
;        RTS

; PUTMSC: PUT SAVMSC INTO ADDRESS
; PUTMSC: LDA SAVMSC
;          STA ADDRESS

```

ERR	LINE	ADDR	B1	B2	B3	B4
5379	FCF7	A5	59			
5380	FCF9	B5	65			
5381	FCFB	60				
5382						

DISPLAY	HANDLER	-- 10-30-78 --	DISPLC
LDA	SAVMSG+1		
STA			
RTS	ADRESS+1		

PAGE 119

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER -- 10-30-78 -- DISPLC	PAGE
5383						. PAGE	
5384							
5385							
5386							
5387	FCFC	A2	00				
5388	FCFE	A5	22				
5389	FDO0	C9	11				
5390	FDO2	FO	08				
5391	FDO4	C9	12				
5392	FDO6	FO	03				
5393	FDO8	A0	84				
5394	FDOA	60					
5395	FDOB	EB					
5396	FDOC	BE	B7	02			
5397	FDOF	A5	54				
5398	FD11	B5	60				
5399	FD13	A5	55				
5400	FD15	B5	61				
5401	FD17	A5	56				
5402	FD19	B5	62				
5403	FD1B	A9	01				
5404	FD1D	B5	79				
5405	FD1F	B5	74				
5406	FD21	38					
5407	FD22	A5	60				
5408	FD24	E5	5A				
5409	FD26	B5	76				
5410	FD28	BO	0D				
5411	FD2A	A9	FF				
5412	FD2C	B5	79				
5413	FD2E	A5	76				
5414	FD30	49	FF				
5415	FD32	18					
5416	FD33	69	01				
5417	FD35	B5	76				
5418	FD37	38					
5419	FD38	A5	61				
5420	FD3A	E5	5B				
5421	FD3C						

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER -- 10-30-78 --	DISPLC	PAGE
5437	FD5A	E6	78			INC	DEL TAC+1	121
5438	FD5C	A2	02			LDX #2	; ZERO RAM FOR DRAW LOOP	
5439	FD5E	A0	00			LDY #0		
5440	FD60	B4	73			STY COLAC+1		
5441	FD62	98				DRAW3A: TYA		
5442	FD63	95	70			STA ROWAC, X		
5443	FD65	B5	5A			LDA OLDRW, X		
5444	FD67	95	54			STA ROWCRS, X		
5445	FD69	CA				DEX		
5446	FD6A	10	F6			BPL DRAW3A		
5447	FD6C	A5	77			LDA DELTAC		
5448						STA COUNTR		
5449						ENDPT INX		
5450	FD6E	EB				TAY		
5451	FD6F	AB				LDA DELTAC+1		
5452	FD70	A5	7B			COUNTR+1		
5453	FD72	B5	7F			ENDPT+1		
5454	FD74	B5	75			DRAW3 ; AUTOMATICALLY LARGER IF MSD>0		
5455	FD76	DO	OB			BNE DELTAC		
5456	FD78	A5	77			LDA CMP		
5457	FD7A	C5	76			BCS DRAW3		
5458	FD7C	BO	05			LDA DELTAR		
5459	FD7E	A5	76			LDX #2		
5460	FD80	A2	02			TAY		
5461	FD82	AB				DRAW3: TYA		
5462	FD83	98				STA COUNTR		
5463	FD84	B5	7E			ENDPT STA PHA		
5464	FD86	B5	74			ENDPT+1 LDA LSR		
5465	FD88				A INTO CARRY			
5466	FD89	A5	75			PLA ROR A		
5467	FD8B	4A				ROWAC, X TEST ZERO		
5468	FD8C	6B				COUNTR+1 ORA COUNTR+1		
5469	FD8D	6A				BNE DRAW11		
5470	FD8E	95	70			JMP DRAW10		
5471	FD90	A5	7E			ADD ROW TO ROWAC (PLOT LOOP)		
5472	FD92	05	7F					
5473	FD94	DO	03					
5474	FD96	4C	42	FE				
5475	FD99	1B						
5476	FD9A	A5	70					
5477	FD9C	65	76					
5478	FD9E	B5	70					
5479	FDAO	90	02					
5480	FDA2	E6	71					
5481	FDA4	A5	71			DRAW5: INC ROWAC+1		
5482	FDA6	C5	75			LDA ENDPT+1		
5483	FDB8	90	14			CMP DRAW6		
5484	FDBA	DO	06			BCC BNE DRAW5A		
5485	FDAC	A5	70			LDA ROWAC		
5486	FDAE	C5	74			CMP ENDPT		
5487	FDB0	90	0C			BCC DRAW6		
5488	FDB2	18				CLC LDA ADC		
5489	FDB3	A5	54			ROWCRS ROWINC		
5490	FDB5	65	79					

ERR LINE	ADDR	B1	B2	B3	B4	STA	ROWCRS	COMMENT
5491	FDB7	85	54			LDX #0		; AND SUBTRACT ENDPT FROM ROWAC
5492	FDB9	A2	00			JSR SUBEND		; DO SAME FOR COLUMN (DOUBLE BYTE ADD)
5493	FDBB	20	7A	FA		CLC	CDLAC	; ADD
5494	FDBE	18				LDA	DEL TAC	
5495	FDBF	A5	72			ADC	COLAC	
5496	FDC1	65	77			STA	COLAC	
5497	FDC3	85	72			LDA	COLAC+1	
5498	FDC5	A5	73			ADC	DELTAC+1	
5499	FDC7	65	78			STA	COLAC+1	
5500	FDC9	85	73			CMP	ENDPT+1	
5501	FDCB	C5	75			BCC	DRAWB	
5502	FDCD	90	27			BNE	DRAWA6	
5503	FDCF	DO	06			LDA	COLAC	
5504	FDD1	A5	72			CMP	ENDPT	
5505	FDD3	C5	74			BCC	DRAWB	
5506	FDD5	90	1F			BIT	COLINC	
5507	FDD7	24	7A			BPL	DRAWB	
5508	FDD9	10	10			DEC	COLCRS	
5509	FDDB	C6	55			LDA	COLCRS	
5510	FDDD	A5	55			CMF		
5511	FDDF	C9	FF			BNE	DRAW7	
5512	FDE1	DO	OE			LDA	COLCRS+1	
5513	FDE3	A5	56			BEQ	DRAW7	
5514	FDE5	FO	0A			DEC	COLCRS+1	
5515	FDE7	C6	56			BPL	DRAW7	
5516	FDE9	10	06			INC	COLCRS	
5517	FDEB	E6	55			BNE	DRAW7	
5518	FDED	DO	02			INC	COLCRS	
5519	FDEF	E6	56			INC	COLCRS+1	
5520	FDF1	A2	02			LDX #2		
5521	FDF3	20	7A	FA		JSR SUBEND		
5522	FDF6	20	96	FA		JSR DRAWB:	RANGE	
5523	FDF9	20	E0	F5		JSR OUTPLT		; PLOT POINT
5524	FDFC	AD	B7	C2		LDA FILFLG		; TEST RIGHT FILL
5525	FDFF	F0	2F			BEG DRAW9		
5526	FE01	20	9D	FC		JSR PHACRS		
5527	FE04	AD	FB	02		LDA ATACHR		
5528	FE07	BD	BC	02		STA HOLD4		
5529	FE0A	A5	54			ROWCRS PHA		
5530	FE0C	4B				JSR INCRA		
5531	FE0D	20	DC	F9		PLA		
5532	FE10	68				STA ROWCRS RANGE		
5533	FE11	85	54			DRAW8C: JSR GETPLT		
5534	FE13	20	96	FA		STA BNE DRAWBB		
5535	FE16	20	A2	F5		LDA FILDAT STA ATACHR		
5536	FE19	DO	OC			STA JSR OUTPLT		
5537	FE1B	AD	FD	02		JMP DRAWBA		
5538	FE1E	BD	FB	02		LDA HOLD4 STA ATACHR		
5539	FE21	20	E0	F5		STA JSR OUTPLT		
5540	FE24	4C	OA	FE		JMP DRAWBA		
5541	FE27	AD	BC	02		LDA HOLD4 STA ATACHR		
5542	FE2A	BD	FB	02		JSR SEC PLACRS		
5543	FE2D	20	AB	FC				
5544	FE30	38						

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER	-- 10-30-7B --	DISPLC
5545	FE31	A5	7E			LDA	COUNTR	
5546	FE33	E9	01			SBC	#1	
5547	FE35	B5	7E			STA	COUNTR	
5548	FE37	A5	7F			LDA	COUNTR+1	
5549	FE39	E9	00			SBC	#0	
5550	FE3B	B5	7F			STA	COUNTR+1	
5551	FE3D	30	03			BMI	DRAW10	
5552	FE3F	4C	90	FD		JMP	DRAW4A	
5553	FE42	4C	34	F6		DRAW10:	RETUR1	

```

5554 PAGE
5555
5556
5557
5558
5559
5560
5561
5562
5563
5564
5565
5566
5567
5568
5569
5570
5571
5572
5573
5574
5575
5576
5577
5578
5579
5580
5581
5582
5583
5584
5585
5586
5587
5588
5589
5590
5591
5592
5593
5594
5595
5596
5597
5598
5599
5600
5601
5602
5603
5604
5605
5606

; TABLES
; MEMORY ALLOCATION
; ALOCAT: .BYTE 24,16,10,10,2B,52,100,196,196,196,196
; NUMDLE: .BYTE 23,23,11,23,47,47,95,95,97,97,97,97
; MXDMDE: .BYTE 19,19,9,19,39,39,79,79,65,65,65 ; (EXT OF NUMDLE)

; NUMBER OF DISPLAY LIST ENTRIES

; ANTIC CODE FROM INTERNAL MODE CONVERSION TABLE

INTERNAL      ANTIC CODE      DESCRIPTION
0              2               40X2XB CHARACTERS
1              6               "   "
2              7               20X5XB   "
3              8               20X5X16  "
4              9               40X4XB GRAPHICS
5              A               80X2X4   "
6              B               80X4X4   "
7              D               160X2X2  "
8              F               160X4X2  "
9              SAME AS 8 BUT GTIA 'LUM' MODE
10             SAME AS 8 BUT GTIA 'COL/LUM REGISTER' MODE
11             SAME AS 8 BUT GTIA 'COLOR' MODE

ANCONV: .BYTE 2,6,7,8,9,$A,$B,$D,$F,$F ; ZEROS FOR RANGE TEST IN
; PAGE TABLE TELLS WHICH DISPLAY LISTS ARE IN DANGER OF
; CROSSING A 256 BYTE PAGE BOUNDARY
PAGETB: .BYTE 0,0,0,0,0,0,1,1,1,1,1
; THIS IS THE NUMBER OF LEFT SHIFTS NEEDED TO MULTIPLY
; COLCRS BY 10,20, OR 40. (ROWCRS*10)/(2**DHLINE)

```

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY HANDLER	-- 10-30-78 --	DISPLC	PAGE
5608	FEB1	02	01	01	00	DHLINE:	. BYTE	2,1,1,0,0,1,1,2,2,2,2,2	125
5609	FEB5	00	01	01	02				
5610	FEB9	02	02	02	02				
5611						COLUMN:	NUMBER OF COLUMNS		
5612						COLUMN:	. BYTE	40,20,20,40,80,80,160,160,64,80,80 ; MODE 8 IS SPECIAL	
5613									
5614									
5615	FE8D	28	14	14	28				
5616	FE91	50	50	A0	A0				
5617	FE95	40	50	50	50				
5618									
5619									
5620									
5621						NROWS:	NUMBER OF ROWS		
5622						NROWS:	. BYTE	24,24,12,24,48,96,96,192,192,192,192	
5623	FE99	18	18	0C	18				
5624	FE9D	30	30	60	60				
5625	FEA1	CO	CO	CO	CO				
5626									
5627									
5628									
5629									
5630						DIV2TB:	HOW MANY RIGHT SHIFTS FOR HCRSR FOR PARTIAL BYTE MODES		
5631						NROWS:	. BYTE	0,0,0,2,3,2,3,1,1,1	
5632						DIV2TB:	. BYTE		
5633	FEA5	00	00	00	02				
5634	FEA9	03	02	03	02				
5635	FEAD	03	01	01	01				
5636									
5637						DMASKT:	DISPLAY MASK TABLE		
5638						DMASKT:	. BYTE	\$00,\$FF,\$F0,\$0F	
5639	FEB1	00	FF	F0	0F	DMASKT:	. BYTE	\$CO,\$30,\$OC,\$03	
5640	FEB5	CO	30	0C	03				
5641						MASKTB:	BIT MASK.	(ALSD PART OF DMASKTB! DO NOT SEPARATE)	
5642						MASKTB:	. BYTE	\$B0,\$40,\$20,\$10,\$08,\$04,\$02,\$01	
5643									
5644	FEB9	80	40	20	10				
5645	FE8D	08	04	02	01				
5646									
5647									
5648									
5649									
5650	FEC1	28	CA	94	46	COLRTB:	. BYTE	\$28,\$CA,\$94,\$46,\$00	
5651	FEC5	00							
5652									
5653									
5654									
5655									
5656									
5657						CNTRLS:	CONTROL CODES AND THEIR DISPLACEMENTS INTO THE		
5658						CNTRLS:	CONTROL CHARACTER PROCESSORS		
5659									
5660	FEC6	1B				CNTRLS:	. BYTE	\$1B	
5661	FEC7	79	F7			CNTRLS:	. WORD	ESCAPE	

ERR LINE	ADDR	B1	B2	B3	B4	DISPLAY	HANDLER	-- 10-30-78 --	DISPLC	PAGE
5716	FF16	34	80	33	36		.BYTE	\$34, \$80, \$33, \$36, \$1B, \$35, \$32, \$31		
5717	FF1A	1B	35	32	31					
5718	FF1E	2C	20	2E	6E		.BYTE	\$2C, \$20, \$2E, \$6E, \$80, \$6D, \$2F, \$81		
5719	FF1E	2C	20	2E	6E					
5720	FF22	80	6D	2F	81					
5721	FF26	72	80	65	79		.BYTE	\$72, \$80, \$65, \$79, \$7F, \$74, \$77, \$71		
5722	FF2A	7F	74	77	71					
5723	FF2E	39	80	30	37		.BYTE	\$39, \$80, \$30, \$37, \$7E, \$38, \$3C, \$3E		
5724	FF2E	7E	38	3C	3E					
5725	FF32	66	68	64	80		.BYTE	\$66, \$68, \$64, \$80, \$82, \$67, \$73, \$61		
5726	FF36	82	67	73	61					
5727	FF3A									
5728	FF3E									
5729	FF3E	4C	4A	3A	80		.BYTE	\$4C, \$4A, \$3A, \$80, \$80, \$4B, \$5C, \$5E ; UPPER CASE		
5730	FF3E	80	4B	5C	5E					
5731	FF42	4F	80	50	55		.BYTE	\$4F, \$80, \$50, \$55, \$9B, \$49, \$5F, \$7C		
5732	FF46	9B	49	5F	7C					
5733	FF4A									
5734	FF4E	56	80	43	80		.BYTE	\$56, \$80, \$43, \$80, \$80, \$42, \$58, \$5A		
5735	FF4E	80	42	58	5A					
5736	FF52	24	80	23	26		.BYTE	\$24, \$80, \$23, \$26, \$1B, \$25, \$22, \$21		
5737	FF56	1B	25	22	21					
5738	FF5A									
5739	FF5E									
5740	FF5E	5B	20	5D	4E		.BYTE	\$5B, \$20, \$5D, \$4E, \$80, \$4D, \$3F, \$81		
5741	FF62	80	4D	3F	81					
5742	FF66	52	80	45	59		.BYTE	\$52, \$80, \$45, \$59, \$9F, \$54, \$57, \$51		
5743	FF6A	9F	54	57	51					
5744	FF6E									
5745	FF6E	28	80	29	27		.BYTE	\$28, \$80, \$29, \$27, \$9C, \$40, \$7D, \$9D		
5746	FF72	9C	40	7D	9D					
5747	FF76	46	48	44	80		.BYTE	\$46, \$4B, \$44, \$80, \$83, \$47, \$53, \$41		
5748	FF7A	83	47	53	41					
5749	FF7E									
5750	FF7E	OC	0A	7B	80		.BYTE	\$0C, \$0A, \$7B, \$80, \$80, \$0B, \$1E, \$1F ; CONTROL		
5751	FF7E	80	0B	1E	1F					
5752	FF82	OF	80	10	15		.BYTE	\$0F, \$80, \$10, \$15, \$9B, \$09, \$1C, \$1D		
5753	FF86	9B	09	1C	1D					
5754	FF8A									
5755	FF8E									
5756	FFBE	16	80	03	80		.BYTE	\$16, \$80, \$03, \$80, \$80, \$02, \$1B, \$1A		
5757	FF92	80	02	1B	1A					
5758	FF96	80	80	85	80		.BYTE	\$80, \$80, \$85, \$80, \$1B, \$80, \$FD, \$80		
5759	FF9A	1B	80	FD	80					
5760	FF9E									
5761	FF9E	00	20	60	OE		.BYTE	\$00, \$20, \$60, \$0E, \$80, \$OD, \$80, \$B1		
5762	FFA2	80	0D	80	81					
5763	FFA6	12	80	05	19		.BYTE	\$12, \$80, \$05, \$19, \$9E, \$14, \$17, \$11		
5764	FFAA	9E	14	17	11					
5765	FFAE									
5766	FFAE	80	80	80	80		.BYTE	\$80, \$80, \$80, \$FE, \$80, \$7D, \$FF		
5767	FFB2	FE	80	7D	FF					
5768	FFB6	06	08	04	80		.BYTE	\$06, \$08, \$04, \$80, \$84, \$07, \$13, \$01		
5769	FFBA	84	07	13	01					

ERR LINE ADDR B1 B2 B3 B4

DISPLAY HANDLER -- 10-30-78 -- DISPLC

PAGE 128

```
5770          ;  
5771          ;  
5772          ;  
5773          ;  
5774          ;  
5775  FFB E  AD 09 D2  LDA KBCODE  
      FFC 1  CD F2 02  CMP CH1    ; TEST AGAINST LAST KEY PRESSED  
5776  FFC 4  DO 05  BNE PIRG3   ; IF NOT, GO PROCESS KEY  
      FFC 6  AD F1 02  LDA KEYDEL  ; IF KEY DELAY BYTE > 0  
5777  FFC 9  DO 20  BNE PIRG4   ; IGNORE KEY AS BOUNCE  
      FFC B  AD 09 D2  LDA KBCODE  ; RESTORE AC  
5780  FFC E  C9 9F  CMP #CNTL1  ; TEST CONTROL 1 (SSFLAG)  
5781  FFD 0  DO 0A  BNE PIRG1   ;  
5782  FFD 2  AD FF 02  LDA SSFLAG  
5783  FFD 5  49 FF  EOR #$FF  
5784  FFD 7  BD FF 02  STA SSFLAG  
5785  FFD A  B0 0F  BCS PIRQ4   ; (UNCONDITIONAL) MAKE ^1 INVISIBLE  
5786  FFD C  BD FC 02  STA CH  
5787  FFD F  BD F2 02  STA CH1  ;  
5788  FFE 2  A9 03  LDA #3    ; INITIALIZE KEY DELAY FOR DEBOUNCE  
5789  FFE 4  BD F1 02  STA KEYDEL ; CLEAR COLOR SHIFT BYTE  
5790  FFE 7  A9 00  LDA #0    ;  
5791  FFE 9  B5 4D  STA ATTRACT  
5792  FFE B  A9 30  LDA ##$30  
5793  FFE D  BD 2B 02  STA SRTMR  
5794  FFF 0  68    PLA  
5795  FFF 1  40    RTI  
5796          ;  
5797          ;  
5798          ;  
5799  FFF 2  FF FF FF  .BYTE $FFF, $FFF, $FFF, $FFF, $FFF  
5800  FFF 6  FF FF  ;  
5801          ;  
5802  FFF 8  =* CRNTPC  ==*$14  
5803          ;  
5804  0014  00    KBDSPR: .BYTE $FFF-$CRNTPC ; ^GDISPLC IS TOO LONG  
5805  0015          ; END
```

ASSEMBLY ERRORS = 0

CROSS REFERENCE

LABEL	VALUE	REFERENCE
ACK	0041	-1632 1902
ACKREC	E9C6	1785 -1794
ADDCOR	030E	-498 2515
ADJ1	EDOC	2533 -2537
ADJUST	ED04	2470 2473 -2532
ADRESS	0064	-269 4120 4145 4171 4173 4182 4183 4184
ADR TAB	E6FE	4186 4252 4254 4258 4260 4263 4265 4296
AFP	D800	-574
ALLPOT	D20B	-659
ALLSEC	F30E	3886 -3891
ALDCAT	FE45	4146 -5562
ANCONV	FE69	4139 -5593
ANTIC	D400	-735 736 737 738 740 741 742
APPEND	0001	-111 -179 4761 4765
APPMHI	000E	4478 -4480
ASCC01	F705	-764 1193
ASCZER	0030	-469 4308 4311 4316 4333 4372 4394 4417
ATACHR	02FB	4421 4428 4481 4515 4526 4528 4606 5082
ATAINT	FEF6	5300 5527 5538 5542
ATAN	BE43	-602 -699
ATASCI	FEFE	4480 -5709
ATEDF	F00B	3250 -3256
ATTRACT	004D	-248 1340 1395 1401 1403 5792
AUDC1	D201	-667 2343 2353 2378
AUDC2	D203	-669 2354
AUDC3	D205	-671 2349
AUDC4	D207	-673
AUDCTL	D208	-674 2336
AUDF1	D200	-666 2297
AUDF2	D202	-668 2295
AUDF3	D204	-670 1749 2203 2607 3200
AUDF4	D206	-672 1751 2205 2609 3202
B192HI	0000	-1641 1750
B192LO	0028	-1640 1748
B600HI	0005	-1643 2204
B600LO	00CC	-1642 2202
BAD	EA63	1919 -1925
BADCOM	E9BF	1782 -1788 1809
BADDISK	F306	-3887 3923 3929
BADIOC	00B6	-142 826

BADMOD	0091	-154	4141	2914	2963	-2965
BADST	EE9E	2914	2917	2963	-2965	
BEEP	F05B	3164	3197	-3314		
BEEP1	F05A	-3315	3349			
BEGIN	ED10	2255	-2558	2570		
BELL	F90A	4402	-4726	5687		
BELL1	F90C	-4727	4729			
BFENHI	0035	-224	1774	1886	1985	2147
BFENLO	0034	-223	1771	1883	1983	2145
BITCLR	FB12	4624	5038	-5046		
BITCON	FAEB	-5019	5040	5046	5056	
BITGE1	FB31	5060	-5062			
BITGET	FB25	4618	4890	-5056		
BITMSK	006E	-276	5023	5042	5047	5059
BITPUT	FB04	4711	-5038	5129	5138	
BITROL	FAFA	-5032	5159			
BITSET	FB06	4622	-5040			
BLACKB	F22A	-3740	3741			
BLFILL	EEC1	2992	-2995	3015		
BLIM	028A	-398	3183	3235	3254	
BLKB2	F230	3740	-3742			
BLKBDV	E471	-77	3483	3601	3603	
BLQAD	F36C	3928	-3933			
BOOT	F2CF	3710	-3862			
BOOTAD	0242	-360	3896	3998	3934	3937
BOOT?	0009	-176	3864	3931	3991	4007
BOTSCR	02BF	-429	4193	4201	4542	4548
BPTR	003D	-234	3182	3225	3234	3246
BRKABT	0080	-136	2637	3188	4466	4953
BRKKEY	0011	-184	1337	1957	2064	5335
BRKKY	0236	-136	2637	3188	4466	4953
BRKKY2	E754	-1336	3832	3834	3833	3835
BROKE	EDAO	1959	2066	2560	2580	2643
BS	F7E6	-4591	5673			
BS1	FB0D	4593	-4608			
BS2	F805	4601	4603	-4605		
BS3	F7F5	4596	-4598			
BSA	F7EC	-4594				
BUFADR	0015	-187	2829	2838	2842	2863
BUFCNT	006B	-274	4386	4410	4412	5229
BUFFH	0004	-3421	3422	3883		
BUFFL	0000	-3422	3881			
BUFFUL	EECB	2989	-3000			
BUFRFL	0038	-227	2054	2111	2160	
BUFRHI	0033	-222	1773	1885	1980	1984
BUFRLO	0032	2624	2626	1881	1951	1978
BUFSTR	006C	-275	4389	4391	4406	4408

CAINI	F239	3669	-3750	3666	3781	3783	3784	3793
CART	BFFC	-3436	3658	3666	3781	3783	3784	3793
CARTAD	BFFE	-3438	3750	3751	3788			
CARTCS	BFFA	-3435	3720	3726				
CARTFG	BFFD	-3437	3702	3705	3717	3723	3786	
CAS31	EC5E	2352	-2357					
CASBUF	03FD	-545	3101	3102	3237	3248	3253	3295
		3301	3389	3392	3392	3421	3422	3900
		3902	3902					
CASENT	EBB0	1734	-2197					
CASET	0060	-1611	1732	2289	2351			
CASETV	E440	-59	3118	3513	3849			
CASFLLG	030F	-499	1739	2050	2234			
CASINI	0002	-169	4009	4011	4014			
CASORG	EF41	-30	3097	3136				
CASRED	EBB3	2198	-2233					
CASSBT	004B	-245	3888	3922	3925	3975	4001	4005
CASSET	0043	-124						
CASSPR	0014	-398						
CAUX1	023C	-351	1763					
CAUX2	023D	-352	1765					
CBAUDH	02EF	-457	2602	2608	3144			
CBADL	02EE	-456	2601	2606	3142			
CBINI	F23C	3661	-3751					
CBUFH	0003	-3101	3102	3366				
CBUFH1	0002	-1669	1670	1772				
CBUFL	00FD	-3102	3368					
CBUFLD	003A	-1670	1768					
CCOMND	023B	-350	1760					
CDEVIC	023A	-349	1669	1670	1757			
CDTMA1	0226	-330	1528	2653	2655			
CDTMA2	022B	-331	1529					
CDTMF3	022A	-332	1455	3177	3219	3222		
CDTMF4	022C	-334						
CDTMF5	022E	-336						
CDTMV1	021B	-323	1451	1452	1535	1537	1540	1542
		1564	1566					
CDTMV2	021A	-324						
CDTMV3	021C	-325						
CDTMV4	021E	-326						
CDTMV5	0220	-327						
CDUBL	EF26	3072	-3075					
CH	02FC	-470	1478	4087	4462	4469	4474	5787
CH1	02F2	-461	5776	5788				
CHACT	02F3	-463	1442	4110				
CHACTL	D401	-737	1443					
CHAR	02FA	-468	4302	4344	4346	5069	5079	
CHBAS	02F4	-464	1440	4108				
CHBASE	D409	-743	1441					
CHKDON	EABA	1995	-2002	2017				
CHKERR	00BF	-151	2118					
CHKSNT	003B	-230	1947	1988	1994	2026		
CHKSUM	0031	-220	1946	1955	1991	2013	2015	2115

CHKTIM	EAF9	2136	2138	2619
CHRORG	E000	-2064	2071	-22
CICL02	E53F	901	-903	
CICLOS	E533	853	-898	
CJERR1	E4D1	821	-826	
CJERR2	E6B0	1173	-1183	
CJERR3	E50F	-869		
CJERR4	E511	842	-870	
CJUMP	E693	1152	-1158	
CINI	F3E1	3994	-4014	
CIO	E4C4	771	-815	
CIOCHR	002F	-217	815	
CIOINT	E4AB	-787	798	
CIDINV	E4A6	775	-786	
CIOORG	E4A6	-76	774	
CIOOPEN	E509	-25	783	
CIOSPR	0014	851	-864	
CIOV	E456	-1215		
CIREAD	E569	-68	770	
CIRT3	E62B	857	-934	
CIRTN1	E61B	-1075	1080	
CIRTN2	E61D	827	-870	
CIST1	E559	893	909	
CISTSP	E54E	916	-923	
CIWRT	E5C9	855	-914	
CIX	00F2	858	-1003	
CKEY	004A	-616		
CKSTC	EE11	-244	3683	
CLICK	FCDB	2808	-3967	
CLICK1	FCDA	4475	-2810	
CLOSE	000C	-5356	4727	
CLOSEC	F02B	-5359	-5355	
CLRCHP	F27A	3119	-3286	
CLRCOD	007D	-3820	3825	
CLRL11	FBA6	-4030	4312	
CLRLIN	FB9B	-5149	5151	
CLRRAM	F140	-4597	-5144	
CLRSC2	F7BF	-3591	3594	
CLRSC3	F7CE	-4570	4572	
CLRSCR	F7B9	-4578	4581	
CLRTAB	F832	-4280	4314	
CLRTBS	F430	-4623	5683	
CLS	007D	-4125	4127	
CLWRT	F03B	-3416	3527	
CMODE	EF1E	-3287	-3293	
CMPTAB	E6F6	-3071	3087	
CNTL1	009F	-1282	1313	
CNTRLS	FEC6	-4031	5781	
COLAC	0072	4442	4444	
COLBK	D01A	-279	5440	
		-708	5497	
			5500	5504

COLCR	FCE4	4582	4901	-5365
COLCR1	FCEE	5367	-5370	
COLCR2	FCFO	5369	-5371	
COLCRS	0055	-259	4390	4409
		4594	4599	4409
		4811	4816	4845
		4903	4970	4975
		5245	5371	5400
		5517	5519	5402
		-361	3565	3606
		3606	3714	
COLDST	0244	0245	0255	-437
COLDSV	E477	02C5	02C6	-438
COLINC	007A	02C6	02C7	-439
COLDN	003A	02CB	02CB	-440
COLDRO	02C4	02C4	02C4	-436
COLOR1	02C5	02C5	02C5	-437
COLOR2	02C6	02C6	02C6	-438
COLOR3	02C7	02C7	02C7	-439
COLOR4	02CB	02CB	02CB	-440
COLPFO	D016	COLPF1	D017	-704
		COLPF2	D018	-705
		COLPF3	D019	-706
		COLPMO	D012	-707
		COLPM1	D013	-700
		COLPM2	D014	-701
		COLPM3	D015	-702
		CDLRSH	004F	-703
		COLRTB	FEC1	-704
		COLUMN	FE8D	-705
COM1	E647	COM2	E662	-705
		COM3	E63D	-706
		COMFRM	E978	-707
		COMMAND	E974	-708
		COMPLT	0043	-709
		COMPUT	ECA3	-710
		COMRE1	F7A7	-711
		COMRET	F789	-712
		COMTAB	E6C9	-713
		CONSOL	DO1F	-714
		CONTIN	EC31	-715
		CONVR1	F97E	-716
		CONVR2	F98B	-717
		CONVR3	F98F	-718
		CONVR4	F99C	-719
		CONVR5	F9A6	-720
		CONVR6	F9A7	-721
		CONVRT	F947	-722
		COS	BD73	-723
		COUNT	ED3B	-724
		COUNTR	007E	-725
CR	009B			-129

GRETRI	000D	4510	-1672	1743	1802
CRETRN	EBDF		2227	-2259	
CRETRY	0036		-225	1744	1788
CRITIC	0042		-239	1412	1729
CRLOOP	F5E7		-4329	4332	1863
CRNTP1	E6D5		-1213	1215	
CRNTP2	E90B		-1582	1584	
CRNTP3	EDE8		-2725	2727	
CRNTP4	EE78		-2872	2875	
CRNTP5	EF41		-3093	3097	
CRNTP6	F0E3		-3396	3398	
CRNTP7	F3E4		-4020	4023	
CRNTPC	FFF8		-5802	5804	
CRSINH	02F0		-459	1339	4122
CRSRDN	F78C		-4546	5665	
CRSRL1	F7A3		-4554	-4557	
CRSRLF	F799		-4552	4598	5237
CRSRDR	00BD		-149	4989	5244
CRSRRT	F7AA		-4560	4609	5667
CRSRUP	F77F		-4540	4604	5663
CSB00T	F3B2		3694	-3989	
CSBOT2	F3C0		3990	-3997	
CSIDE	EF2E		3076	-3079	
CS10	FOAC		-3370		
CSOPIV	E47D		-81	3132	4002
CSTAT	0288		-396		
CTIA	D000		-681	682	683
			689	690	691
			697	698	699
			705	706	707
			713	714	715
			721	722	723
			729	730	731
					733
CTIMHI	0000		-1675	2446	
CTIMLO	0002		-1674	2445	
CTRLC	0092		-3417		
D	0044		-2901	3075	
DAUX1	030A		-494	1762	2960
DAUX2	030B		-495	1764	2210
DBDDEC	F913		4188	-4740	
DBDEC	F91F		4178	-4751	
DBSECT	0241		-359	3916	
DBSUB	F921		4148	4165	4741
DBSUB1	F934		4759	-4761	-4752
DBUFHI	0305		-489	2181	2815
DBUFLO	0304		-489	2176	2813
DBUFSZ	0014		-2894	3077	2864
DBYTHI	0309		-493	2183	2820
DBYTLO	0308		-492	2178	2818
DCB	0300		-483		2848
DCOMND	0302		-486	1759	2799
	3083		3361	3376	2806
					2824
					3872
					3979
					2959
					3041

DCTIM1	E8DD	1536	-1540		
DCTIMR	E8D0	1409	1445	1454	-1535
DCTXF	E8EA	1538	1541	1543	-1546
DDEVIC	0300	-484	1731	1754	2288
		3371		2350	2797
DECBF1	E66D	1124	-1126		
DECBF1	E663	969	973	1040	1044
DECBFL	00FB	-621			-1121
DEGFLG					
DEGDN	0006	-624			
DELAY0	ECBC	-2437	2441		
DELAY1	ECBE	-2438	2439		
DELCH1	F870	-4652	4669		
DELCH2	FB96	4662	4665	-4670	
DELCHR	FB6D	-4651	5689		
DELETE	0021	-101			
DELLI1	F8DD	-4703	4714		
DELLI2	FBFB	-4718			
DELLIA	F8D7	-4700			
DELLIB	FBDB	-4702	4724	5291	
DELLIN	F8D4	-4699	5679		
DELTAC	0077	-282	5422	5425	5431
					5434
DELTAR	0076	5437	5447	5452	5456
DELT11	FC82	-281	5410	5414	5418
DELT12	FC89	-5287	5290		
DELT13	FCBC	-5291			
DELTIA	FC68	5281	5288	-5292	
DELTIB	FC70	4673	-5274		
DELTIM	FC73	5276	-5278		
DERR	E9F6	4597	-5279		
DERR1	EA06	1821	-1842		
DERR5	F10D	1791	1830	-1853	
DERRH	00F1	-3539	3543	3544	
DERRL	000D	-3543	3544	3948	
DERRR	0090	-3544	3948		
DEVS1	E6A6	-153	1910		
DEVS2	E6B5	-1175	1180		
DEVS3	E6C5	1176	-1188		
DEVS4	E6C8	1195	-1197		
DEVSRC	E69E	1185	-1201		
DFLAGS	0240	873	919	-1171	
DHLINE	FEB1	-358	3893		
DIGRT	00F1	-615	4804	-5609	
DINDEX	0057	-260	4106	4138	4194
					4225
DINI	F37E	4877	4905	4956	4963
DINIT	EDEA	3867	3930	-3941	
DIRECT	0002	2759	-2788		
DISK	0044	-112			
DISKID	0031	-126			
DISKIV	E450	-2744	2796		
DISKM	F3A4	-66			
DISPLA	E410	3976	-3978		
		-4056			

DISPLAY	-122	
DIV2TB	4810	-5633
DLISTH	FEA5	
DLISTL	D403	-739
DMACTL	D402	1424
DMASK	D400	-738
DMASKT	02A0	1426
DOBUJA	FEB1	-736
DOBUJA	00BB	1428
DOB1	FC1A	-416
DOBOOT	F2ED	4297
DOBUF1	FC29	4351
DOBUF2	FC12	4841
DOBUF3	FC39	-5640
DOBUF4	FC51	-147
DOBUFC	FC55	1914
DOCR1	FC00	5222
DOCR1A	FA34	-5224
DOCR1B	FA00	3874
DOCR2	FA29	-3877
DOCR2A	FA14	3889
DOCR2B	FA4A	5225
DOCR4B	FA4D	5228
DOCRWS	FA61	-5231
DOINTP	FA30	5220
DOLC01	ECE5	5235
DOLC02	FBE5	5230
DOLCOL	FBFB	5247
DOPEN	FBDD	5239
DOPEN1	FA3D	5243
DOPEN2	FA44	4405
DOPEN3	FA4D	-5251
DOPEN4	FA61	4908
DOPEN5	FA30	-4912
DOPEN6	ECE5	4911
DOPEN7	FBE5	-4913
DOPEN8	FBFB	4923
DOPEN9	FBDD	-4925
DOPENA	F3FB	4931
DOSINI	F460	4919
DOSS	F4D5	-4934
DOSVEC	F577	4934
DOUBLE	F51C	-4956
DRAW	F524	4956
DRAW1	F58B	-4966
DRAW10	F43B	4967
DRAW11	F577	-4977
DRAW2	F457	4978
DRAW3	000C	-4984
DRAW3A	F6AD	4984
DRAW4	000A	-4993
DRAW4A	0044	4993
DRAW4B	FCFC	-4996
DRAW5	FD37	4996
DRAW5A	FE42	-5000
DRAW5B	FD99	5001
DRAW5C	FD5C	-5002
DRAW5D	FD83	5003
DRAW5E	FD62	-5004
DRAW5F	FD90	5005
DRAW5G	FDA4	-5006

DRAW5A	FDB2	5484	-5488
DRAW6	FDBE	5483	5487
DRAW6A	FDD7	5503	-5507
DRAW6B	FDEB	5508	-5517
DRAW7	FDF1	5512	5514
DRAW8	FDF6	5502	5506
DRAW8A	FE0A	-5529	5540
DRAW8B	FE27	5536	-5541
DRAWBC	FE13	-5534	
DRAW9	FE30	5525	-5544
DRAWA	FDOC	5391	-5397
DRAWB	FD0B	5393	-5396
DRAWLN	0011	-98	
DRETRI	0001	-1673	1741
DRETRY	0037	-226	1742
DRKMSK	004E	-249	1406
DSKFMS	0018	-191	
DSKIF	EDFO	2760	-2796
DSKINV	E453	-67	3873
DSKORG	EDEA	-28	2727
DSKRDE	F3B1	3887	3921
DSKSPPR	0014	-2875	-3948
DSKTIM	0246	-365	2789
DSKUTL	001A	-192	
DSPFLG	02FE	-472	4437
DSTAT	004C	-246	4113
DSTATS	0303	4423	4508
DT1	00FA	-487	1794
DATA	00FC	3381	
DTIML0	0306	-3110	3251
DUNIT	0301	-3109	3271
DUNUSE	0307	-490	2396
DVSTAT	02EA	-485	1755
EDITOR	E400	-491	
EDITRV	E400	-455	2736
EEXP	00ED	-4043	
EGETC1	F650	-55	3515
EGETC2	F66E	-611	
EGETC3	F67C	-4392	4403
EGETCS	F691	4396	-4404
EGETC6	F66B	4387	-4410
EGETC7	F680	4411	4413
EGETCH	F63E	-4412	-4419
ENBDOT	F35A	4401	-4403
ENDACK	F1BD	-4412	4415
ENDBCK	F1AC	4045	-4384
ENDDIF	EE69	3917	-3925
ENDPT	0074	3665	3667
ENDRAM	F276	3657	-3663
ENINTP	ECEB	2833	-2851
		-280	4941
		5501	5505
		3802	-3810
		-2514	

F257	3782	-3794		
ENSPEC	3785	3787	-3793	
ENTVEC	002C	-810		
EOF	008B	-3418	-144	3257
EOFERR	008B	-766	967	990
EDL	009B	4043	-4102	4273
EOPEN	F3FC	-3111	3249	4958
EDT	00FE	4433	-4437	3304
EDUTCS	F4BE	4434	4439	
EDUTC6	F6B5	-4434	4439	
EDUTCH	F6A4	4046	-4428	
ERANGE	FABB	43B5	4430	-4953
ERETN	F6BB	-4436		
ERRFLG	023F	-356	1781	1818
ERROR	0045	-1635	1907	
ERRTN	E4C0	-802	803	804
ERRTNH	00E4	791	-803	804
ERRTNL	00CO	789	-804	907
ESCAPE	F779	-4537	5661	
ESCFLG	02A2	-418	4434	4438
ESIGN	00EF	-613		4440
ESTSCM	F173	3607	-3622	
EXP	DDCO	-595		
EXP10	DDCC	-596		
EXTEN1	FB7E	-5122	5133	
EXTEN3	FB8B	-5130		
EXTEN4	FB92	5131	-5134	
EXTEND	FB7B	4677	-5120	
FADD	DA66	-581		
FASC	D8E6	-576		
FCAX	F032	-3290	3298	3306
FCHRFL	00F0	-614		
FDIV	DB2B	-583		
FEDF	003F	-236	3162	3232
FILDAT	02FD	-471	5537	
FILFLG	02B7	-422	5397	5524
FILLBF	EEC3	-2996	2999	
FILLIN	0012	-99		
FINDX	ECD6	-2497		
FLDOP	DDBD	-585		
FLDOR	DD89	-584		
FLD1P	DD9C	-587		
FLD1R	DD98	-586		
FLOPPY	0030	-1608		
FLPTR	00FC	-625		
FMOVE	DDB6	-590		
FMSZPG	0043	-241		
FMTD	EE4A	-2834		
FMUL	DADB	-582		
FNCNOT	0092	-155	1151	
FORMAT	0021	-2749	2800	2832
FOOEY	EADE	2027	-2036	
FORMAT	0022	-102		

FPI	D9D2	-579	634	635
FPREC	0006	-572	634	635
FPSCR	05E6	-634	635	636
FPTCR1	05EC	-635	637	
FPTCR2	00FE	-626		
FRO	00D4	-606		
FR1	00E0	-608		
FR2	00E6	-609		
FRE	00DA	-607		
FREQ	0040	-237	3314	3336
FRMADR	0068	-4033	4682	5098
FRMERR	008C	-148	2102	
FRX	00EC	-610		
FSCR	05E6	-636		
FSCR1	05EC	-637		
FSTOP	DDAB	-589		
FSTOR	DDA7	-588		
FSUB	DA60	-580		
FTYPE	003E	-235	3152	3382
GBX	EFE8	-3240	3244	4000
GBYTE	EFD6	3119	-3232	3255
GETCAR	0007	-3407		
GETCH	F593	4058	-4290	4416
GETCHR	0007	-90		
GETDAT	0040	-2751	2804	
GETOUT	F749	4465	-4510	
GETPLT	F5A2	4291	-4295	
GETREC	0005	-89		
GETSEC	F39D	3885	3919	-3975
GLBABS	02E0	-447		
GOBACK	EB09	-2072		
GOERR	EF3D	30B0	-3086	
GOHAND	E689	883	902	
GOOD	EA65	1903	1905	1923
GOODST	EE32	2B22	-2B24	-1927
GOON	EB64	2151	-2159	
GOREAD	ED6F	2597	-2606	
GPRIOR	026F	-369	1429	4151
GRACTL	D01D	-711		4170
GRAFM	D011	-699		
GRAFP0	D00D	-695		
GRAFP1	D00E	-696		
GRAFP2	D00F	-697		
GRAFP3	D010	-698		
HARDI	F277	3583	-3818	
HATABS	031A	-512	513	1102
HDR	00FB	-3112		1104
HITCLR	D01E	-712		1175
HITIMR	ECCC	-2490	2494	3642
HITONE	0005	-1644	2296	
HOLD1	0051	-255	4143	4221
		5190	5191	5262
			5198	4798

HOLD2	029F	-415	4792	4801		
HOLD3	029D	-413	4915	4928	4932	
HOLD4	02BC	-426	5528	5541		
HOLD5	02BD	-427				
HOLDCH	007C	-286	4472	4512	4522	
HOME	F7D6	-4582	4988			
HOWMCH	F25F	-3798	3809			
HPOSMO	D004	-686				
HPOSMS1	D005	-687				
HPOSMS2	D006	-688				
HPOSMS3	D007	-689				
HPOSPO	D000	-682				
HPOSPI	D001	-683				
HPOSPP2	D002	-684				
HPOSPP3	D003	-685				
HSCROL	D404	-740				
ICAX1	034A	-528	3682			
ICAX1Z	002A	-213	935	1004	3153	4102
		4463				
ICAX2	034B	-529				
ICAX2Z	002B	-214	3070	3151	4099	
ICBAH	0345	-523	1072	3680	3962	
ICBAHZ	0025	-208	1073			
ICBAL	0344	-522	1070	3678	3960	
ICBALZ	0024	-207	959	1025	1071	1133
ICBLH	0349	-527	1143			
ICBLHZ	0029	-212	1145			
ICBLL	0348	-526	1140	3966		
ICBLLZ	002B	-211	947	948	1016	1017
		1125	1126	1141	1142	1144
ICCOM	0342	-520	3676	3964		
ICCOMT	0017	-189	849	887	1106	
ICCOMZ	0022	-205	840	934	961	979
		5389				
ICDNO	0341	-519				
ICDNOZ	0021	-204	1197			
ICHID	0340	-518	788	928		
ICHIDZ	0020	-203	864	904	914	929
ICIDNO	002E	-216	816	927	1069	1084
ICPTH	0347	-525	792			
ICPTHZ	0027	-210	892	906		
ICPTL	0346	-524	790			
ICPTLZ	0026	-209	890	908		
ICSPR	034C	-530				
ICSPRZ	002C	-215	216	217	810	889
		1109	1112	1113	1114	1159
ICSTA	0343	-521				
ICSTAZ	0023	-206	899	995	1065	1153
IDENT	F0F2	-3527	3535	3536	3538	
IDENTH	00F0	-3535	3536	3734		
IDENTL	00F2	-3536	3733			
IFP	D9AA	-577				
IINIT	E6D5	1230	-1269			

IMASK	02BB	-399	5072	-5082
INATA1	FB4A	5072	-5082	
INATAC	FB32	4292	-5069	
INBUFF	00F3	-617		
INC2A	F9FB	4866	4871	-4873
INCBF1	E676	1132	-1134	
INCBFP	E670	960	1029	-1131
INCRS1	FA77	4885	4914	4917
INCRS2	F9E4	4861	-4863	
INCRS3	F9F7	4868	4870	-4872
INCRSA	F9DC	4633	-4859	5531
INCRSB	F9D4	4293	4659	-4855
INCRSC	F9DA	4856	-4858	
INCRSR	F9DB	4322	-4857	
INIMLH	0007	-3410	3843	
INIMLL	0000	-3409	3841	
INIT	EF41	3122	-3141	
INSCH1	F852	-4637		
INSCH3	F85E	4636	-4643	
INSCH4	F844	-4630	4642	
INSCH5	F86A	4645	-4648	
INSCH6	F861	-4644	4647	
INSCHR	F837	-4625	5691	
INSCLR	0020	-117		
INSDAT	007D	-287	4627	4637
INSLI1	F8C6	4918		
INSLI2	F8CE	-4693	4696	
INSLIA	F8A5	4692	-4697	
INSLIN	F8A4	-4677	4895	
INTABS	0200	-4676	5681	
INTATA	FEFA	-310	1232	1292
INTEMP	022D	1298	1299	1293
INTINV	E46B	-335	1557	1563
INTORG	E6D5	-75	1229	3852
INTSPR	0014	-26	1215	1268
INTTBL	ECB4	-1584		
INTZBS	0010	-2419		
INVFLG	02B6	-182	3616	
IOC1	E4D6	-421	4486	4488
IOC1A	E4DB	823	-830	4527
IOC2	E4F3	-831	836	
IOC6	E514	847	-849	
IOC7	E519	866	-873	
IOCB	0340	-879		
IOCBAS	0020	-517	831	1076
IOCBSZ	0010	-202	832	1075
IDCFRE	00FF	-200	201	795
IRQEN	D20E	-107	787	865
IRGST	D20E	-678	1306	903
ISEDF	FOOD	2374	4117	915
		-664	1302	1318
		3233	-3257	2000
				2034
				2332

ISRODN	EA90	1697	-1975	2420	2425	2426
ISRSIR	EBOF	1696	-2091	2419	2423	2424
ISR TD	EACF	1698	-2026	2421	2421	2428
JMPP	E735	1319	-1323			
JSR IND	F6A1	-4426	4446			
JTADRH	00EB	-2272	2273	2654		
JTADR L	00EC	-2273	2652			
JTIMER	Ebec	-2271	2272	2273		
JTMR1	EBCA	1411	-1528			
JTMR2	EBCD	1447	-1529			
JVECK	02BC	-400	1330	1332	1335	1354
K1	F729	4491	-4495			
K2	F734	4496	-4500			
K3	F73F	4501	-4505			
K4	F776	4525	-4529			
K5	F768	4514	4517	4519	4521	-4524
K6	F74D	4506	-4512			
K7	F745	4468	-4508			
K8	F773	4511	-4528			
KBCODE	D209	-660	1477	5775	5780	
KBD	004B	-121				
KBDHND	E420	-4070				
KBDORG	F3E4	-32	4023	4084		
KBDSPR	0014	-5804				
KEYBDV	E420	-57	3353	3355	3519	3847
KEYDEL	02F1	-460	1463	1465	5778	5790
KGETC1	F71E	4485	-4490			
KGETC2	F6DD	-4461	4483	4489	4494	4499
KGETC3	F6FE	-4476	4523			
KGETCH	F6E2	4072	4392	-4463	4471	
LBFEND	05FF	-638				
LBPR1	057E	-630				
LBPR2	057F	-631				
LBUFF	0580	-632	633			
LDPNTR	EB6A	1805	1838	-2175	2223	2250
LEDGE	0002	-252	3622			
LENGTH	022F	-1212				
LFRTCM	F7A5	-4558	4566			
LINBUF	0247	-367	5091	5093		
LINZBS	0000	-166				
LIRG	0000	-3419				
LL	E72F	1317	-1320			
LMARGN	0052	-256	3623	4282	4565	4595
LOG1	FB22	4678	4718	5144	5234	5264
LOG2	FB23	4705	-5055			
LOCKFL	0023	-103				
LOG	DECD	-597				
LOG10	DED1	-598				
LOGCOL	0063	-268	4399	4583	4591	4617
	5201	4635	4657	4661	4859	4879
		5203	5212	5233	5241	5252
					5274	5279

LOGGET	FB20	4614	4722	-5053
LOGMAP	02B2	-420	4578	4715
LOOPM	E71F	-1313	1321	
LOOPM2	E72A	1315	-1318	
LOTONE	0007	-1645	2294	
LPENH	0234	-343	1422	
LPENV	0235	-344	1420	
MOPF	D000	-714		
MOPL	D008	-722		
M1PF	D001	-715		
M1PL	D009	-723		
M2PF	D002	-716		
M2PL	D00A	-724		
M3PF	D003	-717		
M3PL	D00B	-725		
MASKTB	FE89	5022	-5645	
MAXDEV	0021	-513	1094	1174
MAXIOC	0080	-201	797	822
MEMLO	02E7	-453	3842	3844
MEMORY	M 0000	0		
MEMTOP	02E5	-452	3838	3840
MLTTMP	0066	-270	271	4034
MODATA	E9FO	4794	4796	4799
MODEM	004D	-125	4800	4802
MONORG	F0E3	-31	3398	3503
MONSPR	0014	-4023		
MOTRGD	0034	-1664	2217	2244
MOTRST	003C	-1665	1706	2262
MOVLI1	FB58	-5096	5103	
MOVLI2	FB7A	5112	-5114	
MOVLIN	FB4E	4693	-5091	
MOVVEC	F17D	-3630	3633	
MVBUFF	F32D	-3904	3920	
MVNXB	F32F	-3905	3908	
MXDMDE	FE5D	4216	-5572	
MXDMOD	0010	-116		
N	004E	-2900	3071	3086
NACK	004E	-1633		
NARG	0000	0		
NBUFSZ	002B	-2893	3073	
NCOMHI	003C	-1663	1709	2062
NCOMLO	0034	-1662	1776	
NEWCOL	0061	-267	5401	5403
NEWROW	NLR	005	3252	-3254
NMIEN	D40E	-748	1270	
NMIRES	D40F	-749	1384	
NMIST	D40F	-750	1372	1376
NOA1	F1F1	3701	-3703	
NOA2	F212	3716	3719	-3721
NOB1	F1F8	3704	-3706	

F1FF	NOBOOT	3707	-3713
F220	NOCAR2	3722	-3730
F1FC	NDCART	3699	-3710
003C	NDCKSM	-231	3725
EAE9	NDCLR	2051	1889
F3BF	NOCSB2	3993	2150
F3E0	NDCSBT	3998	2154
0000	NODAT	-4012	
F63D	NDFUNC	-2750	
F2DC	NOINIT	4048	
EC45	NOISE1	4073	
F2CE	NOKEY	3866	
F4AB	NOMOD	-2343	
00B2	NONDEV	3855	
NORMAL	004E	-3857	
NOROWS	FE99	4180	
NDSCR1	FA32	-4184	
NOSCR1	FA2C	-138	
NOTB	F4BB	-1625	
NOTCAS	EC0C	1183	
NOTCST	E96B	4184	
NOTDER	EA52	-1908	
NOTDON	EAB1	-1957	
NOTE	0026	1962	
NOTEND	EABE	-106	
NOTERR	EA00	1986	
NOTMXD	F4F5	-2008	
NOTOPN	0085	1843	
NOTYET	EB3C	-1849	
NOWARM	F2DD	4196	
NOWRPO	EA98	-2299	
NSIGN	00EE	1733	
NTBRKO	EAB8	-1738	
NTBRK1	EB00	1908	
NTBRK2	ED17	-1914	
NTFRAM	EB1D	1908	
NTVRN	EB25	-1962	
NTWRP1	EB50	-106	
NUMDLE	FE51	1986	
NVALID	0084	-1979	
NWDK	EA56	-1982	
NXTENT	F18C	-1986	
ODNH1	00EA	-1996	
ODNL0	0090	-1996	
OFFCRS	FAE4	-1996	
OKTMR	ED1F	-1996	
OKTMR	ED48	-1996	
OLDADR	005E	-1996	
OLDCHR	005D	-1996	
OLDCOL	005B	-1996	
OLDROW	005A	-1996	
OPEN	0003	-1996	
OPENC	EF4C	-1996	

OPINP	EF5D	3133	3156	-3160
OPNCOM	F404	4101	-4106	
OPNEDT	F118	-3551	3553	3554
OPNERR	F453	-4141		
OPNH	00F1	-3553	3554	3679
OPNIN	0004	-113	115	
OPNIND	000C	-115		
OPNL	0018	-3554	3677	
OPNOT	0008	-114	115	
OPNOUT	0002	-2892		
OPNRNT	EFBF	3165	-3190	3198
OPNTMP	0066	-271	4153	4162
OPOK	EFD3	3184	-3226	
OPOUT	EF95	3158	-3194	
OPSYS	F17B	-3629		
OSRAM	F2BA	3634	-3B31	
OUTCH	F5B7	4059	-4308	
OUTCH2	F5FF	-4344	4368	4630
OUTCHA	F5BD	-4311		
OUTCHB	F5D7	4318	-4321	
OUTCHE	F5CA	4313	-4316	4435
OUTPLT	F5E0	4321	-4326	4607
OVERRUN	008E	-150	2108	
POPF	D004	-718		
POL	D00C	-726		
P1PF	D005	-719		
P1PL	D00D	-727		
P2PF	D006	-720		
P2PL	D00E	-728		
P3PF	D007	-721		
P3PL	D00F	-729		
PACTL	D302	-754	1272	1345
PADDL0	0270	2634	3167	3207
PADDL1	0271	-371	1500	
PADDL2	0272	-372		
PADDL3	0273	-373		
PADDL4	0274	-374		
PADDL5	0275	-375	1502	
PADDL6	0276	-376		
PADDL7	0277	-377		
PAGETB	FE75	4179	-5601	
PALFLG	0000	-17	1647	1653
PBPNT	D303	3172	3209	3213
PBRK	001D	-755	1273	1279
PBUFSZ	EF8B	-3188	3221	
PBYTE	001E	-196	2955	2990
PCOLR0	F010	3119	-3263	
PCOLR1	02C0	-432	1434	
PCOLR2	02C1	-433		
PCOLR3	02C3	-434		
		-435		

PDEVN	-2896	3036
PENH	-746	1421
PENV	-747	1419
PHACR1	-5313	5316
PHACRS	FC9D	4651
PHCHLO	EE7F	-2940
PHCLDS	EEDC	3002
PHINIT	EE78	2913
PHOPEN	EE9F	-3013
PHPUT	EF14	2918
PHSTAT	EE81	-2932
PHSTLD	EE7D	2915
FHWRT	EEA7	-2972
PIA	D300	-751
PIRG	E6F3	-1281
FIRQ1	FFDC	2916
FIRQ2	FFF0	-2954
FIRQ3	FFCB	2939
FIRQ4	FFEB	2957
FIRQ5	FFB5	2972
FIRGH	00E6	2982
FIRQL	00F3	2982
FILCR1	FCAA	2992
FILCRS	FCA8	2994
FLOT	0050	2995
PLUS	ECF8	2996
FLYARG	05E0	2997
FLYEVL	DD40	2998
PMBASE	D407	2999
PNMI	E791	2999
PNMII1	E799	2999
PNMIIH	00E7	2999
PNMIL	0091	2999
POINT	0025	2999
POKEY	D200	2999
POKMSK	0010	2999
POKTAB	EDDO	2999
PORTA	D300	2999
PORTB	D301	2999
POTO	D200	2999
POT1	D201	2999
POT2	D202	2999
POT3	D203	2999
POT4	D204	2999
POTS	D205	2999
POT6	D206	2999
POT7	D207	2999
POTGO	D208	2999
PRINTR	0050	2999

PRINTV	E430	-58	3511	3B4B
PRIOR	D01B	-709	1430	
PRMODE	EF1A	2983	3013	-3069
PRNBUF	03C0	-533	2940	2986
PRNDRG	EE78	-29	2875	2925
PRNSPR	0014	-3097		
PRVOPN	0081	-137	869	
PSIOC	EF01	3043	-3045	
PTEMP	001F	-197	2982	2985
PTIMOT	001C	-194	2933	3050
PTRIGO	027C	-383	1516	3060
PTRIG1	027D	-384	1513	
PTRIG2	027E	-385		
PTRIG3	027F	-386		
PTRIG4	0280	-387		
PTRIG5	0281	-388		
PTRIG6	0282	-389		
PTRIG7	0283	-390		
PTRLPLP	EBAC	-1509	1520	
PUTADR	EE6D	2827	2834	-2862
PUTBC	EE43	2826	-2831	
PUTCAR	000B	-3408		
PUTCHR	000B	-92	886	
PUTCNT	EE21	2811	-2817	
PUTDAT	0080	-2752	2809	
PUTDDTO	EE01	2801	-2803	
PUTLIN	F385	3735	-3958	
PUTMSC	FCF3	4567	4782	-5377
PUTREC	0009	-91		
PUTSEC	0050	-2745		
PUTTXT	0009	-3406	3963	
PWRDNA	F3E4	4049	4062	-4086
PWRUP	F125	3493	3497	3566
PWRUP1	F128	3568	-3578	3686
RADFLG	00FB	-622		
RADON	0000	-623		
RAMLO	0004	-170	3589	3591
		3800	3804	3897
		3913	3915	3936
		3939	3940	
RAMSIZ	02E4	-451	3655	3663
RAMTOP	006A	-273	4090	4133
		5180	4144	4207
			4229	4575
			5166	
RANDOM	D20A	-661		
RANGE	F496	4290	4309	4955
RANGE1	FAB7	4969	-4975	
RANGE2	FABB	4974	-4977	
RANGE3	FA9E	4961	-4963	
RBL0K	EFE9	3130	3236	-3241
RBL0KV	E47A	-80	3129	3977
RCI1	E5A7	963	968	-973
RCI11	E5BF	-994		
RCI1A	E574	936	-943	
RCI1B	E571	-940	944	

RCI2	E5AC	-979	949	-955	974	981	986	-998
RCI3	E5B7	957	970	981	986			
RCI4	E5C3	-984	991					
RCI6	E5B2	-2838	2845					
RDBAD	EE51	-3892	3895					
RDBYTE	F310	-143	1008					
RDONLY	0087	-1616	3978					
READ	0052	-253	3624					
RECEIV	EAE0	1840	1891	-2048	2257			
RECVDN	0039	-228	2055	2070	2122			
RECVDS	EC60	-2371						
RECVEN	EC1B	2061	-2320					
REDGE	0027	-1989	-1997					
RELONE	EAB1	-100						
RENAME	0020	3489	3499	-3564				
RESET	F11B	4044	4047	4057	4060	4070	4074	4294
RETUR1	F634	4364	4366	-4369	4529	4996	5334	5553
RETUR2	F621	4287	4315	4320	4323	-4361	4422	4447
RETUR3	FAE1	4994	-4996					
RETURN	EA0D	1831	1851	1854	-1861	2265	2646	
RIRGHI	0000	-1660	2241					
RIRGLO	0078	-1655	2240					
RMARGN	0053	-257	3625	4557	4562	4600	4869	4962
RNGER1	FADB	-4991						
RNGER2	FAD6	4986	-4990					
RNGERR	FAD1	4966	4967	4973	4976	4979	4980	-4988
RNGDK	FAC4	4971	-4981					
ROWAC	0070	-278	4940	4942	4943	4945	5442	5470
RDWCRS	0054	5478	5480	5481	5485			
		-258	4329	4388	4407	4540	4544	4546
		4586	4602	4646	4663	4690	4701	4702
		4783	4849	4887	4904	4913	4933	4965
		5132	5134	5189	5215	5224	5248	5277
		5313	5324	5339	5342	5398	5444	5491
ROWINC	0079	5529	5533					
RRETRN	EBOE	-283	5405	5413	5490			
RSIRG	000A	-1657	2236					
RTCLDK	0012	-185	1393	1396	1398	1404	2573	2599
S	0053	3334	3347					
SAVADR	0068	-2902	3079					
SAVID	0316	4668	4672					
SAVMSC	0058	-505	2571	2590	2592			
SBUF SZ	001D	5379						
SCDL LP	E80E	-2B95	3081					
SCREDIT	0045	-1433	1439					
SCRENV	E410	-120						
SCRFLG	02BB	-56	3517	3846	4052			
		-425	4629	4644	4926			

0093	-156	4768
SCRNOK	F1DB	3685
SCROL1	FBB7	4721
SCROL2	FBCA	5169
SCROLL	FBAC	4925
SDLSTH	0231	-339
SDLSTL	0230	-338
SDMCTL	022F	-337
SECT1	F301	-3BBS5
SECTX	F34C	4003
SEND	EA6B	-3919
SENDDS	EC5F	3924
SENDEN	EBF2	-1940
SENDEV	E468	2225
SENIN	ECBA	1861
SERIN	D20D	1964
SEROUT	D20D	-663
SETBSZ	EF34	1943
SETDCB	EEE6	-74
SETLOP	E8F7	1943
SETTAB	FB2D	1692
SETVBL	E8ED	2207
SETVBV	E45C	-663
SETVBX	E8F9	2207
SEX	0000	2114
SFH	EF64	-677
SHFAMT	006F	2131
SHFLOK	02BE	1952
SHIFT1	F5B1	1992
SHIFT2	F610	2010
SHIFTD	F5AA	2010
SHIFTU	F608	3074
SIDWAY	0053	3078
SIGNON	F223	-3082
SIN	BD81	2961
SIO	E959	3004
SIOINT	E944	-3034
SIOINV	E465	2443
SIDORG	E944	-1940
SIDSBS	F095	2225
SIOSPR	0014	2225
SIOV	E459	2207
SIRHI	00EB	2207
SIRLD	000F	2207
SIZEM	DOOC	2207
SIZEPO	DOOB	2207
SIZEP1	DOO9	2207
SIZEP2	DOOA	2207
SIZEP3	DOOB	2207
SKCTL	D20F	2207
SKRS	D20A	2207
SKSTAT	D20F	2207
OUNDRL	0041	2207

SPACE	0020	-2899	2995
SPECIA	EF4B	3119	-3145
SPECIL	000E	-95	846
SPECL	F23F	3582	-3781
SGR	BEB1	-603	
SRETRN	EB34	2116	-2121
SRSTA	0040	-3103	3377
SRTIM2	0006	-1219	1475
SRTIMR	022B	-333	1467
SRTIRO	EB9B	2211	-2214
SRTIR1	EBC1	2238	-2241
SRTIR2	EBE9	2260	-2265
SSFLAG	02FF	-473	1338
SSKCTL	0232	-340	1714
STACK	S 0000	0	
STACKP	0318	-507	1727
STATC	0053	-2748	2810
STATIS	000D	-94	
STATUS	F028	3119	-3280
STATUS	0030	-219	1846
STATVH	0002	1927	1941
STATVL	00EA	-2736	2737
STICKO	0278	-675	2812
STICK1	0279	-379	1487
STICK2	027A	-380	1491
STICK3	027B	-382	1509
STIMER	D209	-382	
STLOOP	E877	-1482	1494
STORE	F917	4190	4204
STORE1	F91D	4210	4214
STRBEG	FC5C	4234	4244
STRERR	F942	4236	4242
STRIGO	0284	4267	4269
STRIG1	0285	-4269	-4745
STRIG2	0286	-4748	
STRIG3	0287	4545	-5261
STRL	E890	4764	-4768
STROK	F946	4793	-4796
STMOT	EC75	1815	2252
SUBBFL	E677	998	1059
SUBEND	FA7A	-4939	5493
SUBTMP	029E	-414	4752
SUCSES	0001	-134	898
SUSUAL	EB38	3226	3239
SV7H	00EB	-1523	1524
SV7L	0073	-1524	
SWAP	FCB3	4384	4398
SWAP1	FCC2	-5339	5346
SWAP3	FCD7	5337	-5350

SHAPA	FCB9	4995	5333	-5335
SWPFLG	007B	-285	4121	4907
SWSTA	0080	-3104	3380	5221
SYIRQ	E706	1243	-1301	5347
SYIRQ2	E71B	1304	-1310	5349
SYIRQB	E762	1322	-1343	5366
SYIRQB9	E76F	1346	-1349	
SYIRQA	E77A	1350	-1353	
SYIRQB	E78F	1235	1236	1237
SYRT1	E790	1234	-1365	1240
SYRT12	E7B8	1358	-1362	1241
SYSVBL	E7BA	1394	1397	-1399
SYSVBL1	E7D6	1410	-1412	
SYSVBL2	E7E5	1417	-1419	
SYSVBL3	E832	1446	-1448	
SYSVBL4	E832	1471	-1525	
SYSVBL5	E833	1468	1473	-1480
SYSVBL6	E834	1453	-1456	1523
SYSVBL7	E873	1457	-1449	1524
SYSVBA	E844	1227	1247	-1393
SYSVBB	E834	-71		
SYVBL	E857	1461	1464	-1467
SYVBL6A	E85F	-4609	4619	5675
TAB	FB10	4612	4615	-4617
TAB1	FB23	4616	-4620	
TAB2	FB2A	-419	4125	5041
TABMAP	02A3	-3510	3538	3641
TBLENT	F0E3	-3538	3640	
TBLLEN	000E	-2427	2428	
TDHI	00EA	-2428		
TDLO	00CF	-354	1667	1668
TEMP	023E	-502	2478	2496
TEMP1	0312	-503		
TEMP2	0314	-504	2578	2596
TEMP3	0315	-1667	1668	1884
TEMPHI	0002	-1668	1880	
TEMPLO	003E	-497	2472	2474
TIMER1	030C	-500	2468	2469
TIMER2	0310	-506	2068	2220
TIMFLG	0317	-2220	2221	
TIMIT	EBA5	-22247	2248	
TIMIT1	EBCB	-146	1918	2073
TIMOUT	008A	-409	4119	
TINDEX	0293	-254	4352	4356
TMPCHR	0050	-424	4818	4827
TMPCOL	02B9	-417	5314	5323
TMPLBT	02A1	-423		
TMPROW	02BB	-412		
TMPX1	029C	-4034	4685	4689
TOADR	0066	-3113	3196	5096
TONE1	0002	-3114	3163	5109
TONE2	EBOA	2069	-2073	5111
TOUT	ED44	2566	-2585	5113
TOUT1				

TRAMSZ	0006		-171	3597	3654	3668	3697	3700	3715	3797
TRIGO	D010		3B05	3808	3B36					
TRIG1	D011		-730	1497						
TRIG2	D012		-732							
TRIG3	D013		-733							
TRNRCD	0089		-145	994						
TSTAT	0319		-508	1845	1928					
TSTCTL	FC8F		-5299	5305						
TSTCTL	FC9C		5301	-5306						
TSTDAT	FCBD		4432	4524	-5298					
TSTDAT	0007		-172	3653	3660	3698	3703	3721		
TWICE	EE4F		-2836	2840						
TXTCOL	0291		-408	4283						
TXTMSC	0294		-410	4135	4137					
TXTTOLD	0296		-411							
TXTTROW	0290		-407	4281	5341	5344				
UNL-DCK	0024		-104							
UPDNCM	F787		-4544	4551						
USAAREA	0480		-548							
UBATRA	E7C8		1402	-1406						
VBREAK	0206		-314	1361						
VBNWAIT	F496		-4175	4177						
VCOUNT	D40B		-745	2572	2598	4175				
VCTABL	E480		-24	1232	1694	3630	4081			
VDELAY	D01C		-710							
VDSSLST	0200		-311	1232	1374					
VECTBL	E400		-23							
VIMIRQ	0216		-322	1281						
VINTER	0204		-313	1352						
VKEYBD	0208		-315	1293	4081					
VPRCED	0202		-312	1348						
VSCROL	D405		-741							
VSERIN	020A		-316	1299	1309	1694				
VSEROC	020E		-318	1297						
VSEPOR	020C		-317	1298						
VTIMR1	0210		-319	1296						
VTIMR2	0212		-320	1295						
VTIMR4	0214		-321	1294						
VVBLKD	0224		-329	1522						
VVBLKI	0222		-328	1385						
WAIT	EA1A		-1876	2449						
WAITER	EC9B		1820	-2447						
WAITTM	EF7C		-3179	3180						
WARMST	0008		-175	3578	3584	3588	3862	3989		
WARMSV	E474		-78	1379	3487					
WATCOM	E9D7		1795	-1815						
WC11	E605		1034	1039	-1044					
WC11A	E5D4		1005	-1012						
WC11B	E5D1		-1009	1013						
WC12	E60A		-1050							
WC13	E5E5		1018	-1024	1045					
WC14	E5EB		1021	-1027						

WC15	E615	1028	1041	1052	-1059
WDLR	EFC6	-3220	3223		
WFAK	F0B7	3337	-3350		
WFAK1	F0BC	3350	-3353		
WFL	F060	-3324	3335		
WIRGHI	0000	-1659	2214		
WIRGLO	0084	-1654	2213		
WMODE	0289	-397	3161	3195	3286
WOK	EA3D	-1901			
WRITE	0057	-1617	2807		
WRITEC	0057	-2898	3069		
WRONLY	0083	-139	939		
WSIDSB	F0D2	3272	3297	3305	-3389
WSIRG	000F	-1656	2209		
WSYNC	D40A	-744	1560	5357	
WTLR	F046	3294	-3299		
XBOOT	F361	3926	-3928		
XITVBL	E905	1228	1248	1418	-1571
XITVBV	E462	-72			
XMTDON	003A	-229	1948	1961	2029
XXIT	E7E2	1413	-1418		
ZERIT	EC6D	-2378	2381		
ZERORM	F138	-3587			
ZIOCB	0020	-199			
ZOSRAM	F160	3585	-3610		
ZOSRM2	F163	-3612	3615		
ZOSRM3	F16E	-3617	3619		
ZTBUF	F04A	-3301	3303		
ZTEMP1	00F5	-618			
ZTEMP3	00F9	-620			
ZTEMP4	00F7	-619			

