Innovative Hardware Accelerator Architecture for FPGA-Based General-Purpose RISC Microprocessors

Appendix B

Author: Dr. Ehsan Ali ehssan.aali@gmail.com Assumption University of Thailand Last update: 1st May 2024

Listing 1: FFT Cooley-Tukey Algorithm in C++

```
void fft(CArray& x)
  // DFT
  unsigned int N = x.size(), k = N, n;
double thetaT = 3.14159265358979323846264338328L / N;
  Complex phiT = Complex(cos(thetaT), -sin(thetaT)), T;
  while (k > 1)
    n = k;
    k >>= 1;
    phiT = phiT * phiT;
    T = 1.0L;
    for (unsigned int l = 0; l < k; l++)
      for (unsigned int a = 1; a < N; a += n)</pre>
        unsigned int b = a + k;
        Complex t = x[a] - x[b];
        x[a] += x[b];
        x[b] = t * T;
      T *= phiT;
    }
  // Decimate
  unsigned int m = (unsigned int) log2(N);
  for (unsigned int a = 0; a < N; a++)
    unsigned int b = a;
    // Reverse bits
    b = (((b \& 0xaaaaaaaaa) >> 1) | ((b \& 0x55555555) << 1));
    b = (((b \& 0xcccccc) >> 2) | ((b \& 0x333333333) << 2));
    b = (((b \& 0xf0f0f0f0f)) >> 4) | ((b \& 0x0f0f0f0f) << 4));
    b = (((b \& 0xff00ff00) >> 8) | ((b \& 0x00ff00ff) << 8));
    b = ((b >> 16) | (b << 16)) >> (32 - m);
    if (b > a)
      Complex t = x[a];
      x[a] = x[b];
      x[b] = t;
 }
```

FFT in C/C++:

We write an FFT algorithm (shown in Listing 1) in C++ and compile and link it by issuing:

\$ clang -lm -lstdc++ fft.cpp -o fft

To cross-compile for ARM using LLVM we need:

- 1. A libc. Good choices for that for baremetal are: newlib or musl.
- 2. **Builtins**. In LLVM, that is provided in the compiler-rt module.
- 3. For C++ we need 3 things:
 - a. **abi library** like LLVM libcxxabi. There are also libsupc++, and libcxxrt.
 - b. An **unwinder** like LLVM libunwind.
 - c. A C++ standard library like LLVM libcxx.

For compiling LLVM, we can investigate the project's configuration options using:

\$ cmake -LAH | awk '{if(f)print} /-- Cache values/{f=1}'
\$ ccmake ../lvm

A home brew formula exists at : https://github.com/eblot/homebrew-armeabi To get a C compiler for Cortex-M0 we first build LLVM itself:

\$ cmake -G Ninja ../Ilvm -DCMAKE_BUILD_TYPE=Debug -DLLVM_ENABLE_PROJECTS="clang;clang-tools-extra;lld;lldb" - DLLVM_ENABLE_SPHINX=False -DLLVM_INCLUDE_TESTS=False -DLLVM_TARGET_ARCH=ARM - DLLVM_TARGETS_TO_BUILD=ARM -DLLVM_INSTALL_UTILS=ON -DLLVM_DEFAULT_TARGET_TRIPLE=arm-none-eabi - DCMAKE_CROSSCOMPILING=ON -DLLDB_USE_SYSTEM_DEBUGSERVER=ON -DCMAKE_INSTALL_PREFIX=/home/esi/arm-none-eabi -DBUILD_SHARED_LIBS=ON -DLLVM_BUILD_DOCS=OFF -DLLVM_ENABLE_BINDINGS=OFF - DLLVM_ENABLE_DOXYGEN=OFF

We then build *newlib* (Some patched need to be applied):

 $\label{lem:control_c$

\$ make \& make -j1 install;

After that we build *compiler-rt*:

\$ cmake -G Ninja ../compiler-rt -DCMAKE_INSTALL_PREFIX=/home/esi/arm-none-eabi/armv6m-none-eabi -DCMAKE TRY COMPILE TARGET TYPE=STATIC LIBRARY - DCMAKE SYSTEM PROCESSOR=arm -DCMAKE SYSTEM NAME=Generic -DCMAKE CROSSCOMPILING=ON -DCMAKE CXX COMPILER FORCED=TRUE -DCMAKE BUILD TYPE=Debug -DCMAKE C COMPILER=/home/esi/arm-none-eabi/bin/clang DCMAKE CXX COMPILER=/home/esi/arm-none-eabi/bin/clang++ -DCMAKE LINKER=/home/esi/arm-none-eabi/bin/clang-DCMAKE AR=/home/esi/arm-none-eabi/bin/llvm-ar -DCMAKE RANLIB=/home/esi/arm-none-eabi/bin/llvm-ranlib -DCMAKE_C_COMPILER_TARGET=armv6m-none-eabi -DCMAKE_ASM_COMPILER_TARGET=armv6m-none-eabi DCMAKE SYSROOT=/home/esi/arm-none-eabi/armv6m-none-eabi/-DCMAKE SYSROOT LINK=/home/esi/arm-none-eabi/armv6m-none-eabi/-DCMAKE SYSROOT LINK=/home/esi/arm-none-eabi/armv6m-none-eabi/-DCMAKE SYSROOT LINK=/home/esi/arm-none-eabi/-DCMAKE SYSROOT LINK= $none-eabi'-DCMAKE_C_FLAGS="--target=armv6m-none-eabi-mcpu=cortex-m\overline{0}-mthumb-mabi=aapcs-fshort-enums-mfloat-abi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=aapcs-fshort-enums-mfloat-abi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=aapcs-fshort-enums-mfloat-abi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=aapcs-fshort-enums-mfloat-abi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=aapcs-fshort-enums-mfloat-abi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=aapcs-fshort-enums-mfloat-abi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=aapcs-fshort-enums-mfloat-abi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=aapcs-fshort-enums-mfloat-abi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=aapcs-fshort-enums-mfloat-abi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=aapcs-fshort-enums-mfloat-abi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=soft-mcpu=cortex-m\overline{0}-mthumb-mabi=soft-mcpu=cortex-mcpu=cor$ g -Os -ffunction-sections -fdata-sections -fno-stack-protector -fvisibility=hidden -Wno-unused-command-line-argument" -DCMAKE ASM FLAGS="--target=armv6m-none-eabi -mcpu=cortex-m0 -mthumb -mabi=aapcs -fshort-enums -mfloat-abi=soft -g -Os ffunction-sections -fdata-sections -fno-stack-protector -fvisibility=hidden -Wno-unused-command-line-argument" DCMAKE CXX FLAGS="--target=armv6m-none-eabi -mcpu=cortex-m0 -mthumb -mabi=aapcs -fshort-enums -mfloat-abi=soft -g -Os ffunction-sections -fdata-sections -fno-stack-protector -fvisibility=hidden -Wno-unused-command-line-argument" -DCMAKE EXE LINKER FLAGS=-L/home/esi/arm-none-eabi/lib -DLLVM CONFIG PATH=/home/esi/arm-none-eabi/bin/llvm-config -DLLVM DEFAULT TARGET TRIPLE=armv6m-none-eabi -DLLVM TARGETS TO BUILD=ARM -DLLVM ENABLE PIC=OFF -DCOMPILER RT OS DIR=baremetal -DCOMPILER RT BUILD BUILTINS=ON -DCOMPILER RT BUILD SANITIZERS=OFF -DCOMPILER RT BUILD XRAY=OFF-DCOMPILER RT BUILD LIBFUZZER=OFF-DCOMPILER RT BUILD PROFILE=OFF-DCOMPILER_RT_BAREMETAL_BUILD=ON -DCOMPILER_RT_DEFAULT_TARGET_ONLY=ON -DCOMPILER RT INCLUDE TESTS=OFF -DCOMPILER RT USE LIBCXX=ON -DUNIX=1

The above steps provide us *libclang_rt.builtins-armv6m.a* and *libc.a* in /home/esi/arm-none-eabi/armv6m none-eabi/lib.

When we compile files for Cortex-M0 we must set /home/esi/arm-none-eabi/armv6m-none-eabi as the *sysroot*.

We now can compile C programs for ARM Cortex-M0 by issuing:

\$ /home/esi/arm-none-eabi/bin/clang fft.c --sysroot=/home/esi/arm-none-eabi/armv6m-none-eabi --target=armv6m-none-eabi - mcpu=cortex-m0 -mthumb -mabi=aapcs -fshort-enums -mfloat-abi=soft -g -Os -ffunction-sections -fdata-sections -fno-stack-protector -fvisibility=hidden -Wno-unused-command-line-argument -L/home/esi/arm-none-eabi/armv6m-none-eabi/lib -o fft

We then compile *libcxx*:

\$ cmake -G Ninja ../libcxx -DCMAKE_INSTALL_PREFIX=/home/esi/arm-none-eabi/armv6m-none-eabi -DCMAKE TRY COMPILE TARGET TYPE=STATIC LIBRARY -DCMAKE SYSTEM PROCESSOR=arm -DCMAKE_SYSTEM_NAME=Generic -DCMAKE_CROSSCOMPILING=ON -DCMAKE_CXX_COMPILER_FORCED=TRUE -DCMAKE BUILD TYPE=Debug -DCMAKE C COMPILER=/home/esi/arm-none-eabi/bin/clang -DCMAKE CXX COMPILER=/home/esi/arm-none-eabi/bin/clang++ -DCMAKE LINKER=/home/esi/arm-none-eabi/bin/clang -DCMAKE C COMPILER AR=/home/esi/arm-none-eabi/bin/llvm-ar -DCMAKE C COMPILER RANLIB=/home/esi/arm-noneeabi/bin/llvm-ranlib -DCMAKE_CXX_COMPILER_AR=/home/esi/arm-none-eabi/bin/llvm-ar -DCMAKE CXX COMPILER RANLIB=/home/esi/arm-none-eabi/bin/llvm-ranlib -DCMAKE C COMPILER TARGET=armv6m-noneeabi -DCMAKE CXX COMPILER TARGET=armv6m-none-eabi -DCMAKE SYSROOT=/home/esi/arm-none-eabi/armv6m-none-eabi/ -DCMAKE SYSROOT LINK=/home/esi/arm-none-eabi/armv6m-none-eabi/ -DCMAKE C FLAGS="--target=armv6m-none-eabimcpu=cortex-m0 -mthumb -mabi=aapcs -fshort-enums -mfloat-abi=soft -g -Os -ffunction-sections -fdata-sections -fno-stack-protector fvisibility=hidden -fno-use-cxa-atexit -Wno-unused-command-line-argument -D LIBUNWIND IS BAREMETAL=1 D GNU SOURCE=1 -D POSIX TIMERS=1 -D LIBCPP HAS NO LIBRARY ALIGNED ALLOCATION -I/home/esi/arm-noneeabi/armv6m-none-eabi/include" -DCMAKE CXX FLAGS="--target=armv6m-none-eabi -mcpu=cortex-m0 -mthumb -mabi=aapcs -fshortenums -mfloat-abi=soft -g -Os -ffunction-sections -fdata-sections -fno-stack-protector -fvisibility=hidden -fno-use-cxa-atexit -Wno-unusedcommand-line-argument -D LIBUNWIND IS BAREMETAL=1 -D GNU SOURCE=1 -D POSIX TIMERS=1 -D LIBCPP HAS NO LIBRARY ALIGNED ALLOCATION -I/home/esi/arm-none-eabi/armv6m-none-eabi/include" -DCMAKE EXE LINKER FLAGS="-L/home/esi/arm-none-eabi/lib/" -DLLVM CONFIG PATH=/home/esi/arm-none-eabi/lib/" -DLLVM CONFIG PATH=/home/esi/ none-eabi/bin/llvm-config -DLLVM_TARGETS TO BUILD=ARM -DLLVM_ENABLE_PIC=OFF -DLIBCXX ENABLE ASSERTIONS=OFF -DLIBCXX ENABLE SHARED=OFF -DLIBCXX ENABLE FILESYSTEM=OFF -DLIBCXX_ENABLE_THREADS=OFF -DLIBCXX_ENABLE MONOTONIC CLOCK=OFF -DLIBCXX_ENABLE_ABI_LINKER_SCRIPT=OFF-DLIBCXX_ENABLE_EXPERIMENTAL_LIBRARY=ON -DLIBCXX INCLUDE TESTS=OFF-DLIBCXX INCLUDE BENCHMARKS=OFF-DLIBCXX USE COMPILER RT=ON-DLIBCXX CXX ABI-libcxxabi -DLIBCXX CXX ABI INCLUDE PATHS=/home/esi/workspace/llvm-project/libcxxabi/include -DLIBCXXABI ENABLE STATIC UNWINDER=ON -DLIBCXXABI_USE_LLVM_UNWINDER=ON -DUNIX=1 -DLIBCXX TARGET TRIPLE=armv6m-none-eabi -DLIBCXX SYSROOT=/home/esi/arm-none-eabi/armv6m-none-eabi

Then we compile *libunwind*:

\$ cmake -G Ninia ../libunwind -DCMAKE INSTALL PREFIX=/home/esi/arm-none-eabi/armv6m-none-eabi DCMAKE TRY COMPILE TARGET TYPE=STATIC LIBRARY -DCMAKE SYSTEM PROCESSOR=arm -DCMAKE SYSTEM NAME=Generic -DCMAKE CROSSCOMPILING=ON -DCMAKE CXX COMPILER FORCED=TRUE -DCMAKE_BUILD_TYPE=Debug -DCMAKE_C_COMPILER=/home/esi/arm-none-eabi/bin/clang DCMAKE CXX COMPILER=/home/esi/arm-none-eabi/bin/clang++ -DCMAKE LINKER=/home/esi/arm-none-eabi/bin/clang-DCMAKE AR=/home/esi/arm-none-eabi/bin/llvm-ar -DCMAKE RANLIB=/home/esi/arm-none-eabi/bin/llvm-ranlib -DCMAKE C COMPILER TARGET=armv6m-none-eabi -DCMAKE CXX COMPILER TARGET=armv6m-none-eabi -DCMAKE SYSROOT=/home/esi/arm-none-eabi/armv6m-none-eabi/-DCMAKE SYSROOT LINK=/home/esi/arm-none-eabi/armv6m-none-eabi/armv6m-none-eabi/armv6m-none-eabi/-DCMAKE SYSROOT LINK=/home/esi/arm-none-eabi/armv6m-none-eabi/-DCMAKE SYSROOT LINK=/home/esi/arm-none-eabi/armv6m-none-eabi/-DCMAKE SYSROOT LINK=/home/esi/arm-none-eabi/armv6m-none-eabi/-DCMAKE SYSROOT LINK=/home/esi/arm-none-eabi/-DCMAKE SYSROOT LINK=/home/esi/arm-none-eab none-eabi/-DCMAKE C FLAGS="--target=armv6m-none-eabi -mcpu=cortex-m0 -mthumb -mabi=aapcs -fshort-enums -mfloat-abi=soft -g -Os -ffunction-sections -fdata-sections -fno-stack-protector -fvisibility=hidden -fno-use-cxa-atexit -Wno-unused-command-line-argument -D_LIBUNWIND_IS_BAREMETAL=1 -D_GNU_SOURCE=1 -D_POSIX_TIMERS=1 - D_LIBCPP_HAS_NO_LIBRARY_ALIGNED_ALLOCATION -I/home/esi/arm-none-eabi/armv6m-none-eabi/include -D LIBCPP HAS NO THREADS=1" -DCMAKE CXX FLAGS="--target=armv6m-none-eabi -mcpu=cortex-m0 -mthumb -mabi=aapcs fshort-enums -mfloat-abi=soft -g -Os -ffunction-sections -fdata-sections -fno-stack-protector -fvisibility=hidden -fno-use-exa-atexit -Wnounused-command-line-argument -D LIBUNWIND IS BAREMETAL=1 -D GNU SOURCE=1 -D POSIX TIMERS=1 D LIBCPP HAS NO LIBRARY ALIGNED ALLOCATION -I/home/esi/arm-none-eabi/armv6m-none-eabi/include -D LIBCPP HAS NO THREADS=1" -DCMAKE EXE LINKER FLAGS="-L/home/esi/arm-none-eabi/armv6m-none-eabi/lib/" -DLLVM_CONFIG_PATH=/home/esi/arm-none-eabi/bin/llvm-config -DLLVM_ENABLE_PIC=OFF -DLIBUNWIND ENABLE ASSERTIONS=OFF -DLIBUNWIND ENABLE PEDANTIC=ON -DLIBUNWIND ENABLE SHARED=OFF -DLIBUNWIND ENABLE THREADS=OFF -DLLVM ENABLE LIBCXX=TRUE -DUNIX=1

Then we compile libexxabi:

```
$ cmake -G Ninja ../libcxxabi -DCMAKE INSTALL PREFIX=/home/esi/arm-none-eabi/armv6m-none-eabi
DCMAKE_TRY_COMPILE_TARGET_TYPE=STATIC_LIBRARY -DCMAKE_SYSTEM_PROCESSOR=arm -
DCMAKE SYSTEM NAME=Generic -DCMAKE CROSSCOMPILING=ON -
DCMAKE CXX COMPILER FORCED=TRUE -DCMAKE BUILD TYPE=Debug -
DCMAKE C COMPILER=/home/esi/arm-none-eabi/bin/clang -DCMAKE CXX COMPILER=/home/esi/arm-none-
eabi/bin/clang++ -DCMAKE LINKER=/home/esi/arm-none-eabi/bin/clang -DCMAKE AR=/home/esi/arm-none-eabi/bin/llvm-
ar -DCMAKE RANLIB=/home/esi/arm-none-eabi/bin/llvm-ranlib -DCMAKE C COMPILER TARGET=armv6m-none-eabi -
DCMAKE CXX COMPILER TARGET=armv6m-none-eabi -DCMAKE SYSROOT=/home/esi/arm-none-eabi/armv6m-none-
eabi/-DCMAKE SYSROOT LINK=/home/esi/arm-none-eabi/armv6m-none-eabi/-DCMAKE C FLAGS="--target=armv6m-none-eabi/-DCMAKE C FLAGS=armv6m-none-eabi/-DCMAKE C FLAGS=arm
none-eabi -mcpu=cortex-m0 -mthumb -mabi=aapcs -fshort-enums -mfloat-abi=soft -g -Os -ffunction-sections -fdata-sections -
fno-stack-protector -fvisibility=hidden -fno-use-cxa-atexit -Wno-unused-command-line-argument -
D LIBUNWIND IS BAREMETAL=1 -D GNU SOURCE=1 -D POSIX TIMERS=1 -
D LIBCPP HAS NO LIBRARY ALIGNED ALLOCATION -I/home/esi/arm-none-eabi/armv6m-none-eabi/include" -
D\overline{C}MAKE\_CXX\_FLAGS="--target=armv6m-none-eabi-mcpu=cortex-m0-mthumb-mabi=aapcs-fshort-enums-mfloat-abi=soft
-g -Os -ffunction-sections -fdata-sections -fno-stack-protector -fvisibility=hidden -fno-use-cxa-atexit -Wno-unused-command-
line-argument -D LIBUNWIND IS BAREMETAL=1 -D GNU SOURCE=1 -D POSIX TIMERS=1 -
D LIBCPP HAS NO LIBRARY ALIGNED ALLOCATION -I/home/esi/arm-none-eabi/armv6m-none-eabi/include" -
DCMAKE EXE LINKER FLAGS="-L/home/esi/arm-none-eabi/armv6m-none-eabi/lib/" -
DLLVM CONFIG PATH=/home/esi/arm-none-eabi/bin/llvm-config -DLLVM ENABLE PIC=OFF -
DLIBCXXABI_ENABLE_ASSERTIONS=OFF -DLIBCXXABI_ENABLE_STATIC_UNWINDER=ON -
DLIBCXXABI USE COMPILER RT=ON-DLIBCXXABI ENABLE THREADS=OFF-
DLIBCXXABI ENABLE SHARED=OFF-DLIBCXXABI BAREMETAL=ON-
DLIBCXXABI_USE_LLVM_UNWINDER=ON -DLIBCXXABI_SILENT_TERMINATE=ON -
DLIBCXXABI INCLUDE TESTS=OFF -DLIBCXXABI LIBCXX SRC DIRS=/home/esi/workspace/llvm-project/libcxx -
DLIBCXXABI LIBUNWIND LINK FLAGS="-L/home/esi/arm-none-eabi/armv6m-none-eabi/lib" -
DLIBCXXABI_LIBCXX_PATH=/home/esi/workspace/llvm-project/libcxx -
DLIBCXXABI LIBCXX INCLUDES=/home/esi/arm-none-eabi/armv6m-none-eabi/include/c++/v1 -DUNIX=1 -
DLIBCXXABI SYSROOT=/home/esi/arm-none-eabi/armv6m-none-eabi -DLIBCXXABI TARGET TRIPLE=armv6m-none-
eabi -DLIBCXXABI LIBUNWIND PATH=/home/esi/arm-none-eabi/armv6m-none-eabi/lib
```

We finally compile fft.c:

\$ /home/esi/arm-none-eabi/bin/clang fft.c --sysroot=/home/esi/arm-none-eabi/armv6m-none-eabi --target=armv6m-none-eabi -mcpu=cortex-m0 -mthumb -mabi=aapcs -fshort-enums -mfloat-abi=soft -g -Os -ffunction-sections -fdata-sections -fno-stack-protector -fvisibility=hidden -Wno-unused-command-line-argument -L/home/esi/arm-none-eabi/armv6m-none-eabi/lib