## How to set up networking on your Raspberry Pi

```
Hi Emma.
Please use following IPs:
                B8:27:EB:80:28:23
130.246.77.141 apple pi
130.246.77.142 blueberry_pi B8:27:EB:48:D3:F9
                  B8:27:EB:65:3F:B6
130.246.77.143 cherry_pi
130.246.77.144 dragon fruit pi B8:27:EB:3C:2F:0B
Cheers,
Suleman
On your (Ethernet connected) Windows PC, get the IP address of your router
C:\>ipconfig | findstr /i "Gateway"
  Default Gateway . . . . . . . :
  Default Gateway . . . . . . :
  Default Gateway . . . . . . . : 130.246.76.254
  Default Gateway . . . . . . . :
And the DNS servers
C:\>ipconfig /all
Windows IP Configuration
Ethernet adapter Ethernet:
  Connection-specific DNS Suffix . : esc.rl.ac.uk
  Description . . . . . . . . : Intel(R) Ethernet Connection (3)
I218-LM
  Physical Address. . . . . . . . 84-7B-EB-37-AF-48
  DHCP Enabled. . . . . . . . . . Yes
  Autoconfiguration Enabled . . . . : Yes
  Link-local IPv6 Address . . . . .
fe80::19de:9a42:c29:12c8%11(Preferred)
  Lease Obtained. . . . . . . . . . . . . . . 24 April 2017 09:42:24
  Default Gateway . . . . . . . : 130.246.76.254
  DHCPv6 IAID . . . . . . . . . : 159677419
  DHCPv6 Client DUID. . . . . . . : 00-01-00-01-1F-72-C8-12-84-7B-EB-
37-AF-48
  130.246.72.21
  Primary WINS Server . . . . . : 130.246.132.69
  Secondary WINS Server . . . . : 130.246.74.27
  NetBIOS over Tcpip. . . . . . : Enabled
```

## And then on your Raspberry pi:

pi@raspberrypi:~\$ sudo nano /etc/dhcpcd.conf

## Add these lines:

interface eth0
static ip\_address=[IP Address provided for your pi by Suleman]/22
static routers=[IP address of your router - mine was 130.246.8.13]
static domain\_name\_servers=[IP address of DNS server - mine was
130.246.8.13]

\*\*\* The "/22" at the end of the second line is important – it tells the pi about the subnet mask used by the local network. \*\*\*

Save and reboot Pi