


Remote Controller -

Functional Description of iMON RSC Button Setup









#	Button Name	Function
1	App. Exit	Close the active foreground application
		Same function as the keyboard shortcut [Alt]+[F4]
2	Power Off	Turn off the PC.
		This button must be pressed longer than 1 second to turn off
		the PC.
3	Screen Saver	Run screensaver if system's screensaver is assigned.
4	Timer	Run timer setup screen.
		To turn off the PC or set the alarm in the certain time assigned
		by timer setup.



#	Button Name	Function
5	0 ~ 9	Not Pre-Defined.
		To define the function of each button for custom setup.





#	Button Name	Function
6	Desktop	Toggle 'show desktop / restore all'
		To toggle between to minimize all windows on the desktop
		and to restore all the minimized windows on the desktop
		Same function as the keyboard shortcut [Window Logo]+[D]
7	Max/Res	Toggle 'maximize window / restore to previous size.'
		To toggle between to maximize and to restore of the active
		foreground window's size
8.	Esc	Same function as the keyboard [Esc] key
9	Window Logo	Same as the keyboard [Window Logo] key
10	Menu	Display pop-up menu
		Same function as the keyboard [Menu] key located on the
		right side of right [Window logo] key
11	App. Launcher	Run 'iMON Application Launcher'
		To see all the applications that are registered with iMON.



10	Damiaada	Dury (All Times Combined Militardous Colombia)
12	Barricade	Run 'All Time Control Window Selector'
		To Switch on and off of the 'All-time Control Mode' or to
		select the application which would be controlled under 'All-
		time Control Mode'
13	Task Switcher	Run 'iMON Task Switcher'
		Same function as the keyboard shortcut [Alt]+[Tab]
		To show current running applications and select the
		application to be active
14	Back Space	Same function as the keyboard [Back Space] key
15	Mouse/Keyboard	Toggle the 'Joystick' operation mode of iMON RSC
		To toggle the mode of the Joystick between Mouse mode
		and Keyboard mode
16	Space	Same function as the keyboard [Spacebar] key
17	Shift Tab	Same function as the keyboard shortcut [Shift]+[Tab]
18	Tab	Same function as the keyboard [Tab] key
19	L. Click	Same function as the left click of a mouse
20	Drag & Drop	Same function as the Drag and Drop function of a mouse.
		Push this button at the position to start drag and move to
		the wanted position, and then push again to drop.
21	R. Click	Same function as the right click of a mouse
22	Joystick	1. Mouse mode
		: Control a mouse cursor by moving Joystick and double-
		click of mouse by pressing Joystick knob like a button.
		2. Keyboard mode:
		: Same function as four directional keyboard arrow keys by
		moving stick and same function as [Enter] key by pressing
		Joystick knob like a button.
23	Mute	Mute system volume.
24	VOL -	Turn system volume up
25	VOL +	Turn system volume down





#	Button Name	Function
26	Play	Play current media file in the multimedia application.
27	Pause	Pause current media file in the multimedia application
28	Open	Run 'Open File' dialog window in the multimedia application
29	Prev.	Play previous media file in the multimedia application.
30	Next	Play next media file in the multimedia application.
31	Stop	Stop playing in the multimedia application.
32	REW	Rewind current playing in the multimedia application.
33	F.FWD	Fast forward current playing in the multimedia application.
34	Full Screen	Make full screen mode in the multimedia application.

iMON Manager can use an ordinary remote controller for home appliance, rather than dedicated iMON RSC, for various functions. You can use these remote controllers to control multimedia programs – music and video playback – conveniently as you control your ordinary home electronic appliance. However, ordinary remote controller may result relatively slower response than iMON RSC because they are designed to prevent any interference between different IR signals.