
WIRELESS POWER HUB PRODUCTS **Combination User Manual**



* What is Wireless Power Hub Products?





Safety Precautions

Please follow the rules outlined in this guide closely to ensure your safety and flawless operation

- Be caution of any edge, uneven surfaces, metal parts, accessories or packaging to prevent possible injury or damage Take note that this product should not be placed in your mouth.
- Do not modify repair or dismantle the product Doing so may result in fire, electric shock, a complete breakdown of the product, etc. and will void the warranty.
- Do not use this product in locations with high temperatures or high humidity levels, Ideally, the product should be used in a location free of excessive
- If you keep at low and high-temperature conditions, products can reduce the performance and battery life.
- Do not touch this product when your hands are wet,
- Do not use any kind of liquid to clean the product. Keep in mind that the surface of the product should only be wiped with a clean dry cloth
- Do not use this product in a location with strong magnetic fields
- Refrain from dropping the product or bumping it against other
- Be careful not to let children or pets bite or suck the device.
- Do not store the product near or in a heater, microwaves. hot cooking equipment, or high-pressure containers,
- You must use the supplied or an approved product from the manufacturer, Using unauthorized battery charger can not be guaranteed to be stable for production use

Bluetooth Speaker B100S

Product Specification

Name of equipment Wireless Devices of Wireless Data Communication Sysem

I ine item Bluetooth Speaker Standard Certification KC WPC B/T CF FCC KC Verification Code MSIP-CMM-hs2-HSWP-B100S

Bluetooth Version Bluetooth 40 Operating Distance maximum 10M Output maximum 3W (Mono)

Working time 5hr

Charging Wireless DLC (DC 5V / 1A)

Battery Capacity 820mAh Color White Black Red Size / Weight 66mm x 63mm / 112a

* The operating distance may vary depending on the surrounding environment,

LED Scenarios

LED OCERIANOS		
Operating Mode	LED Description	
Stand by	Red flashing	
Power on	Red on	
Pairing	Pink flashing	
Call to connect	Red flashing quickly	
Music play/Calls	Red on	
Low battery	Pink on	
Battery chaging	Blue on	
Full chage	Returns to the operating mode	

How to charge


DLC Charging



. Using micro USB cable can be charged from a laptop, PC and adaptor.

Wireless Chaging

Wireless charging products of Hansol Technics HSWP-C100T B100T



- Place the devices properly on the wireless charging pad,
- (The speaker does not show a separate LED.)

This may cause a malfunction,

Top / Bottom

Overview

Front / Back

Left / Light

1. Why can not produce the sound?

Check whether the speaker is turned on if the music is playing, the state of the music player, In addition, check the volume is set too low key if the pair is connected correctly.

Play / Temporarily Stop Non-slip O-ring

2. Why do speakers off automatically?

While the power is turned on when the state of the speaker and the speaker Bluetooth devices that are not connected to the speakers do not work more than five minutes goes into sleep mode. To disable sleep mode, press and hold the Play / Pause button or the volume control buttons. After entering power-saving mode after about 18 hours, the speaker will automatically power-off state. After the power is turned off after the power is turned on again, please use the Bluetooth device to connect

3. When did you play music because the noise is occurring?

This noise may occur depending on the phone model and source files. The appropriate volume of this unit is 60 to 70%,

4. Why is the sound 'ttu-ttu' lead from the speakers?

When out of the range of the Bluetooth connection, you will hear a sound to find the Bluetooth, Once let back into range within 10 minutes, the speaker is automatically connected, after 10 minutes, you mush reconnect the Bluetooth.

5. Why can i not charged the speaker?

High-temperature conditions to protect the battery, the low temperature will not charge the battery. Please retry the charge in normal room temperature.

* If the above method is also not be the speaker is activated, Please moving the button from OFF to ON

Disposal of Electrical and Electronic Equipment



USB Charger Terminals

VOLUME

· '--' Press at length

· '+' Press at length

: Next Sona

: Previous Sona

Mic

OFF / ON / PAIRING

(Call: Hands free)

This symbol indicates that all electrical and electronic equipment included with this product should not be treated as household waste. Instead, it should be left at the appropriate collection point. for the recycling of electronic equipment. By ensuring the product is disposed of correctly, you are helping to prevent negative consequences for the environment and human health. To recycle this product please contact your local city office household waste disposal service or where you purchased the product

FFC compliance statement

to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference
- that may cause undesired operation.

This device complies with part 15 of the FCC Rules. Operation is subject

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generations uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation, If this equipment doescause harmful interference to radio or television reception, Which can be determined be turning the equipment off and on the user is encouraged to try to correct the interference by one or more of the following measures,

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician the help.

larranty Service

If your product is an initial failure

- . If the initial failure is confirmed within 10 days of purchase. Please bring a copy of your purchase receipt and get exchange dealer,
- · You may lose your receipt or packaging or product damage is treated as a product A/S instead of the exchange and return of the product according to the manufacturer A/S regulations it is not possible to this exchange dealer.

Products A/S Regulations

- . The free warranty period for this product is 12 months from the date of purchase
- In the case of damage due to customer's fault during the warranty period. Hansol Technics A/S is treated as paid in accordance with the regulations may be charged for the repairs.

A/S handling of shipping costs: The shipping cost occurs as follows depending on the elapsed time after the purchase, the cost of shipping

the product if you use a vehicle other than a quick delivery service, etc. is wholly the responsibility of the customer.

within 3 months from date of purchase	companies pay
3 months to 12 months	each customer and the company paid 509
more than 12 months	customer pay

In the case of domestic products sold abroad by domestic ship A/S round-trip transportation costs are borne by the customer basis,

The following cases are also handled paid within the warranty period,

If the failure by the negligence and carelessness of use occurs. . If you disassemble or modify the product for purposes other than the

- purpose of normal use, . In the case of damage or failure due to shock
- In the case of corrosion due to flooding and debris contamination . In the case of failure due to misuse, such as peripheral devices that
- are not provided
- . If the negligence of the other users recognized

Bluetooth Speaker

B100S | User Manual

- * Please charge the device when the first time you use
- * Because the wireless equipment that propagation interference potential and services related to safety of life can not.

How to use Power on



 If you move to the middle button of the product are LED lights on the front speakers and turn on the power.

⚠ Do not move forcefully on the power button

2. Bluetooth Pairing







- . Place the mobile phone and the speakers in the near distance, If you move toward the pairing button of the product are pink
- When you press the search button to activate the Bluetooth settings menu on iOS and Android. 'B100S' will be found.

LED flashes and enters the bluetooth pairing mode,

- When you click on 'B100S', pairing is complete. (The speaker are connected to a mobile phone and media audio)
- ⚠ If you want to pair with another device, please terminate. the connection with the current paired devices. Then, please repeat the above steps. The state already paired is not possibly the pairing with other devices,

3. Using

⟨ Listen to music ⟩

When you play a song on the music player on vour device, you can still enjoy a good quality of music speakers.


⟨ Hands-free Speakerphone ⟩

You can make a call while a call is connected via Bluetooth Speaker.



- Hands-free transition: When a call comes in during music playback, click the Play / Pause button to answer the call, When the call is completed, click the button again to play music,
- Volume Control: You can adjust the volume of the speaker to the volume control buttons on the phone.
- · Call termination and origination cancel: Press one of the Play / Pause button, calls will end the call. When an outgoing call is canceled briefly press the Play / Pause button,
- To reject an incoming call : Press very long the Play / Pause when a call came is rejected.

(Redial) In the standby mode, the speakers connected to the mobile phone the Play / Pause button is pressed for about one second will redial,



- It takes about 3 hours to fully charged in a discharged battery,
- This power can be charged even if the product is turned off,
- At the same time, do not charge DLC and Wireless.



Dual Wireless Charging Pad

B100T User Manual

* This product is intended for use primarily as home as for family use(B class) electromagnetic wave compatibiliwer. you can use in all areas



Bluetooth Lighting

User Manual

* Make sure to charge until the light on the wireless charger. (If the lights is not turn on within 1 hours, please contact the customer service center)

* Because the wireless equipment that propagation interference potential and services related to safety of life can not.

Safety Precautions

Please follow the rules outlined in this guide closely to ensure your safety and flawless operation.

- Do not use damaged power cords or plugs, or loose electrical sockets
- Do not touch the power cord with wet hands or disconnect. the charger by pulling the cord
- Do not bend or damage the power cord.
- Do not store your device with metal objects, such as coins. kevs, and necklaces. It may cause overheat or malfunction.
- Leave the product in a dry place free from moisture
- · Moisture or liquid components can damage the components and circuitry of the product.
- If wet do not turn on the power then remove the moisture. with a dry towel contact our customer Center
- Do not drop or cause an impact to the charger or the device
- · Store your device only on flat surfaces
- · If your device falls, it may be damaged.
- Do not use your device for a while if the device is overheated.
- · Prolonged exposure of your skin to an overheated device may cause low-temperature burn symptoms, such as red spots and pigmentation.
- Be careful not to let children or pets bite or suck the device
- Do not disassemble, modify, or repair your device
- · Any changes or modifications to your device can void your manufacturer's warranty, If your device needs servicing, please contact our customer center

Safety Precautions

Please follow the rules outlined in the guide closely to ensure your safety and flawless operation

- Be cautions of and edge, uneven surfaces, metal parts. accessories or packaging to prevent possible injury or damage, Take note that this product should not be placed in our mouth.
- Do not modify, repair or dismantle the product. Doing so may result in fire, electric shock, complete breakdown of the product. etc and will void the warranty
- Do not use this product in locations with high temperatures or high humidity levels, Ideally, the product should be used in a location free of excessive.
- If you keep at low and higt-temperature conditions, products can reduce the performance and battery life.
- Do not use any kind of liquid to clean the product, Keep in mind that the surface of the product should only be wiped with a clean dry cloth.
- Do not use this product in location with strong magnetic fiels.
- Refrain from dropping the product or bumping it against other
- Be careful not to let children or pets bite or suck the device
- Do not store the product near or in heater, microwaves. hot cooking equipment, or high pressure containers,
- You must use the supplied or and approved product from the manufacturer, Using unauthorized charger can not be guaranteed to be stable for production use,

Product Specification

Dual Wireless Charging Pad B100T

Name of equipment Weak Electric Filed Strength

Radio Equipment

Line item Wireless Charging Device KC. WPC. CE. FCC Standard Certification


MSIP-RMM-hs2-HSWP-B100T KC Verification Code WPC 1.1

Technical Standard


+19V DC/0.85A Input Voltage 110~205kHz Frequency

Size / Weight 206mm x 95mm x 10mm / 175a

Position Guide




Place the devices properly on the Wireless Charging Pad



Jsing the Wireless Charging Pad

1 Connect the Wireless Charging Pad and adaptor and plug the charger into and electric socket.



To save energy, unplug the charger when not in use,

- . The charger does not have a power switch so you must unplug the charger from the electric socket when not in use to avoid wasting power. The device should remain close to the electric socket while charging,
- The wireless Charging Pad's indicator light flashes differently depending on its status
- For more information about the indicator lights see below If the indicator light is not working properly, reconnect the charger to the Wireless Charging Pad

2. Place the devices on the Wireless Charging Pad

. You can charge two products at the same time,



Wireless charging products of Hansol Technics

Bluetooth | Bluetooth | SIXTY°C Speaker Lighting Tumbler

* In case of mobile phone

- Wireless charging only module—only cover, mobile phone. built-in wireless charging module works to be built mobile
- Special cover and a dedicated wireless charging module. can be purchased separately from the Internet
- ↑ This product is WPC Qi certified, so any product attached with a WPC (Wireless Power Consortium) Qi logo are compatible regardless of manufacturer
- 3. When the devices fully charged, disconnect the charger from the Wireless Charging Pad or use a cradle,
- ♠ Do not store your device with metal objects, such as coins, kevs, and necklaces, It may cause overheat or

Product Specification

Bluetooth Lighting B100L

Name of equipment Wireless Devices of

Wireless Data Communication System

Bluetooth Lighting Line item Standard Certification KC, WPC, B/T, CE, FCC

KC Verification Code MSIP-CMM-hs2-HSWP-B100L LED Brightness 0.2W

Size/ Weight 66mm x 61,5mm / 64,5g Battery Capacity 500mAh

Working time min 5hr

Android devices more than OS 4.2 more than Bluetooth 4.0 Requirements

Product ON / OFF

Overview

· Once tilting action



- A separate switch is not present. Please slowly tilt 90 degrees to turn on the lights,
- · Please charge the light does not turn on the lights degree tilt, Then, try tilting action, If the lights are not turn on, please contact the customer service center.

Product Color mode

 The first tilt: Lighting ON, White Color Mode (100%) The second tilt: Lighting ON, White Color Mode (30%)

 The third tilt: Auto Color Change Mode (Color changes due to the free combination of RGB color)

• The fourth tilt : Lighting OFF

* If you search for 'Aribitrarily Lighting' on Google Play (play.google.com) comes a detailed description of the application.

How to charge

. B100L is a wireless charging lighting only.

reless Charging Products of Hansol Technics HSWP-C100T B100T



 Any product attached with a WPC (Wireless Power Consortium) Qi logo are compatible regardless of manufacturer,

Narrantly

Model Date of Purchase Serial No. Warranty period Add Customer Name Add Store Name

This product is passed strict quality control and inspection. If a fault occurs, we will guarantee this warranty information,

This warranty does not reissue, so please keep it.

· Please contact your Customer Service Center for inquiries, Customer Service Center: 1800-0310



Rev. 0.1.2