# User Operating Manual DR710

Manufacturer:

**Shenzhen Crave Communication Co.,LTD** 

Address

3rd Floor, 8th Block, Dongfangming Industry Park, 33rd Baoan District, Shenzhen

## Contents

ntents		2 -
Brief	introduction for MID product	1
1.1	Diagram for MID complete machine	1
1.2	Introduction to accessories of MID	2
Quic	k start	3
2.1	Key function	3
2.2	Homepage interface	3
2.3	Access to application program	4
2.4	Character input	5
Conn	nection Establishment	7
3.1	WIFI Connection	7
3.2	Bluetooth Connection	8
Trou	bleshooting	9
	Brief 1.1 1.2 Quic 2.1 2.2 2.3 2.4 Conr 3.1 3.2	Brief introduction for MID product  1.1 Diagram for MID complete machine  1.2 Introduction to accessories of MID.  Quick start

# 1 Brief introduction for MID product

## 1.1 Diagram for MID complete machine

front view:





Figure 1-1

#### underside view:



Figure 1-2

## 1.2 Introduction to accessories of MID

### **Packing list**

The following articles are included in your packing box of MID:

- Complete machine of MID
- Power adaptor
- USB connecting line
- User's manual

# 2 Quick start

## **2.1** Key function

#### **Descriptions for key function:**

Power key	Press this key for a long time to start up
	• Under starting up state, press this key for a long time to pop up
	shutdown option
	Under starting up state, press this key to close the screen
	• Under starting up state or when breakdown appears, press the
	power key for 7 seconds to make your device enter into shutdown
	state
Volume key	Press it can increase or decrease machine volume

## 2.2 Homepage interface

All application programs on the machine will be displayed on the main menu screen. You may use application program, shortcut and user-defined mode to set wallpape of your homepage interface




Figure 2-1

## **2.3** Access to application program

#### How to visit aplication program of MID:

- 1. Please click application program menu. As shown in Figure 3-5.
- 2. Select the application program you want to visit.
- 3. If you want to exit the program interface, press the return key to the last interface, or press the homepage key to return homepage interface directly.

APPS




Figure 2-2

## **2.4** Character input

#### Use screen keyboard

When you start the program or select text edit box needing to input characters or numbers, screen keyboard will show. The following input methods are provided for the keyboard to select.

- 1. Android keyboard
- 2. Input method of a third party (user can install them by himself)

#### Select the input method you need to use

According to presetting, MID will display Android keyboard when you want to inut characters.

- 1. Press menu key in homepage interface, then click **setting**.
- 2. Click language and keyboard.

- 3. All of the input methods already installed on your MID will be listed in the text setting region.
- 4. Select the input method you want..

#### Use and switch input method

- 1. In the character input interface, click keyboard icon under the status bar, until popping up of editing text menu.
- 2. Select input method you need.



1	Switch input capital and small letters
2	Switch character input mode and symbol/figure input mode
3	Click to insert space
4	Click to execute carriage return
5	Click and press on to delete characters on the left of the cursor

## **3** Connection Establishment

#### **3.1** WIFI Connection

Your MID can be connected onto Wi-Fi network to connect the operation:

- 1. On the homepage interface, click and select the meun key and pop up the meun setting;
- 2. Click and select the **System Setting**;
- 3. Click Wi-Fi and open wi-fi switch;
- 4. After openingWi-Fi, the searched Wi-Fi network can be scanned automatically from the equipment in the windows on the right.
- 5. Select the Wi-Fi network required to be connected, if the password is added, pop up the password input windows and input the corresponding password.
- 6. Click the Connection




Figure 3-1

## 3.2 Bluetooth Connection

#### **Application of bluetooth** (Figure 3-2)

- 1. Setting procedure of entering into bluetooth: set -> bluetooth set, open the bluetooth equipment
- 2. Name of equipment: you can randomly change the name of bluetooth for your MID by pressing **Menu key**.
- Detectability: open this function by clicking the place for name of bluetooth, which
  indicates that your MID bluetooth can be searched by other bluetooth equipments, this
  default time for this opening is of 120 seconds.
- 4. Scan and look for equipment: you can detect the equipment desired to be connected by utilizing this function.
- 5. Bluetooth: after employing the scan to look for the equipment, all bluetooth equipments searched by your MID can display under this function.




Figure 3-2

## 4 Troubleshooting

#### 1. slow initial boot for MID

After system upgrade of MID, initial boot needs installation of the pre-installed software applications, and for about 2-3 minutes, it runs faster.

#### 2. MID can not be connected to WIFI

- Ensure that the wireless router providing the network services works properly.
- Ensure the MID and the wireless router are kept with certain distance, and between which no wall or other obstacles exist.
- Ensure the user name and the password are correct

#### 3. MID feels hot

When multiple applications are running at the same time, or the screen is adjusted to the brightest, or it is recharging, this situation is normal.

#### 4. System is disordered and does not work properly

Installation of some third-party applications may lead to system failure, and you can press the reset button to reset the system.

#### 5. Unable to create e-mail or regist applications

- Ensure your network is properly connected to the Internet.
- Ensure the e-mail is set up correctly.
- Ensure your system time and the local time are consistent.

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - -- Consult the dealer or an experienced radio/TV technician for help.
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.