

## ROCK LIGHT KIT TERIOR






You have now successfully installed your new lighting system and are ready to customize if using the LED INNOV APP. Please see the "Info" tab on your LED INNOV APP for important tips and instructions.

9

### INSTALLATION INSTRUCTIONS: **OPTIONAL HARDWIRE KIT**

- Open the package and find the direct wire harness. (included)
- he circuit chosen must be able to supply 3 Amps. Run the wires toward a 12V power source. (For example, a fuse box or light switch)
- source that is switched (like a running light) so the light strips will light only when the vehicle ignition is Connect the (+) red wire to a (+) positive power
- Or you can connect the red (+) positive wire to a circuit with constant power and add your own switch to turn it on and off. The LED INNOVATION APP also includes a master ON/OFF switch.
- Connect the black (-) negative wire to any clean, metal ground. 5
- Tuck and secure all wires.



- Never use the LED Innovation App while driving & obey all traffic laws.
  - regulations in your state, county and/or municipality regarding installation and use of this product. This product is not DOT Approved.

    Do not install any accessory near or on airbags and This product is intended solely for the purpose of decorative or off-road use. Check laws and/or

    - moving parts. Keep all wires and lighting units away never obstruct the driver's view. Do not install this product or run its wires near any
      - from excessively hot areas. 12 Volt use only. Product designed to draw up to 2.8 Amps.

It is recommended that you download the App, connect and test your LED lighting kit before installation and read all instructions carefully.

Begin by laying out your new lighting system under the vehicle. Place your rock lights where you'd like to install them and set the 12V trailer connector or 12V

while making sure you leave enough wire to reach both the rock lights and 12V power input. If you need more wire length, use LED INNOVATION item number 23914. 4 Extension Cord 2PK, sold

Next, choose a mounting location for the control box

direct wire where you will install them.

separately. Clean the control box installation surface thoroughly with alcohol and allow to dry before



smartphone!

To learn more about







Google Play

App



the rock lights in place. Depending upon where you choose to install the rock lights, you may need to drill a 3/4" hole to run your wires. Run your wires from

Use the included 20mm screws to secure

1/16" bit.

To install your rock lights, drill a pilot hole using a

included two-sided tape and screws (if desired).

Install your control box using the

installation

each rock light to the control box and connect them.

fuck and secure all wires with cable ties.

socket. Tuck and secure all wires. Alternatively, you

may use the 12V hardwire option. (Follow the instructions on the next page)

Insert the 12V trailer wiring harness into your trailer

Start your vehicle. Open your LED INNOV APP and choose to connect to the "EXT HUB" 1 channel

system. Mobile phone must be within Bluetooth range. (Approximately 30 feet of the control box)

Model: 23915

FCC ID: 2ADMQ-23915-23916

# ONE YEAR WARRANTY

ship occurs, call Custom Accessories customer service at material and workmanship for a period of one year from the date of purchase. If a defect in material or workman-We guarantee this product to be free of defects in (800) 962-6676 for instructions on how to have it eplaced or repaired free of charge.

# PROVIDED FOR ANY/ALL REPLACED OR REPAIRED PROOF OF PURCHASE OR RECEIPTS MUST BE

workmanship such as, for example, normal wear and tear product back to Custom Accessories is at the consumer's expense. Custom Accessories, Inc. limits its liability only or damage resulting from an accident. Shipment of any consequential damages to other property. Some states specific legal rights and you may also have other rights product that is not the result of a defect in materials or This guarantee does not cover normal damage to the do not allow the exclusion or limitation of incidental or to the replacement of its products, not incidental or consequential damages. This guarantee gives you which vary from state to state.

For FCC matters please contact:

Custom Accessories Inc., 5900 Ami Drive, Richmond, IL 60071


FCC RF Radiation Exposure Statement

requirement. The device can be used in portable exposure condition The device has been evaluated to meet general RF exposure

Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Operation is subject to the following two conditions: (1) this device may not cause harmful interference, This device complies with Part 15 of the FCC Rules. radio or television reception, which can be

- Increase the separation between the equipment Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operated in conjunction with any other antenna or product. This equipment complies with FCC radiation CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the ransmitter



To replace fuse, remove fuse and replace with like amperage. Para cambiar el fusible, saque el fusible y reemplácelo con uno de amperaje similar