

Tech4Kids Inc - Graphic Design

Product: STORYTIME THEATER PROJECTOR	T4K Item#: -
Item: IM	T4K North America Barcode: -
License: -	
Langurage: 1L	EAN bar code: -
Date: 2015-06-26	(Not printed here)

13. Why I can't download the app?

- a. Make sure you are connected to the internet and disconnected from the projector network

14. When I open the app, why isn't anything happening with the projector?

- a. You need to change your "WIFI" Settings to connect to the projector

15. I have the App open and the projector is connected, why can't I play the story?

- a. Have you activated your Press n Play Character on the Tablet Screen?
- b. Is your tablet responding to the Press n Play Character? If not you may need to enter the code labeled on the back of the Press n Play Character
- c. Have you downloaded the story content from the App store? You need to do this first before the Press n Play Character can activate the story automatically
- i. To do this, you must connect to the internet and download from the app store

16. My Projector seems to be frozen, what can I do?

- a. Slide the Switch on the bottom to the off position for 20 seconds then back to on.
- b. You should also restart the App at the same time.

17. The story animation and swiping controls are not stable or seem to jump around. How do I fix that?

- a. This usually happens when the tablet is moving out of range of the projector or there is some external interference affecting the streaming content.
- i. Solution: Move the tablet closer to the projector.

18. I am touching the screen with the Press n Play character but nothing is happening. What can I do?

- a. You may not have downloaded the story yet from the app. Remember, you must NOT be connected to the projector network, and you must be connected to the internet to download a story for the first time.

19. Why does the projector time out and go to sleep?

- a. Your 3G connection may be running, in which case it means there is no "WIFI" and projector will time out and go to sleep. Disconnect your 3G.
- b. You may have walked out of range of the projector. In this case, the projector will go to sleep.
- c. Your smart device may have powered down or gone to sleep. If this happens in the middle of a story, the projector will sleep and then shut down. You should power up your smart device again.
- d. The app may have crashed on your device. You will need to restart the app and the projector.

20. For further troubleshooting information, please visit www.story-time-theater.com.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada License-exempt RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Caution: To maintain compliance with the FCC's RF exposure guidelines, place the projector at least 20cm from nearby persons. Please retain this information.

Hereby, TECH4KIDS INC., declares that this [Story Time Theatre] is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at www.tech4kids.com



MADE IN CHINA
MANUFACTURED BY:
TECH4KIDS INC.
#28 1200 AEROWOOD DRIVE,
MISSISSAUGA, ON L4W 2S7, CANADA
1-800-359-6088 | www.tech4kids.com
Follow us on [Facebook](#) | [Twitter](#)

€ 0359
Download Free App on tablet before you begin!



V2 1L
WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

Storytime Theater Projector Set - Up Instructions:**1. Tutorials on Set Up Procedures and Troubleshooting**

- a. Before unboxing the projector and downloading the app, we encourage you to visit www.story-time-theater.com. Here you can view video tutorials that explain how to set up the projector, the app, and how to start watching your favorite stories. There is also information on troubleshooting to help with any potential issues you may have.

2. Tech4Kids Storytime Theater App Set Up:

Important Note: You must first do a one-time connection to the internet to download the app onto your device before connecting your projector for the first time. First download the "Tech4Kids Storytime Theater App" (instructions below in 2b).

- a. You will need to download the "Tech4Kids Storytime Theater App" in order to play stories and project them onto your wall or ceiling. The Storytime Theater app is available for free in either the App Store (IOS) or Google Play (Android). Please go to your respective store and search for "Tech4Kids Storytime Theater App" for a free download.
- Note that there are other story time apps, so to ensure you have found the correct app you can search the key word "Tech4Kids". Alternatively, you can follow the link below that is appropriate to your device:

- i. ios.story-time-theater.com
- ii. android.story-time-theater.com

- b. To learn about how to navigate the App to play your favorite stories, follow the "In App Tutorial" that will automatically load the first time you launch the "Tech4Kids Storytime Theater App".

- c. Once you have downloaded the app, the next step is to select and download a story either with your Press n Play character or by purchasing it online. Once you have done this, you will always be able to access a downloaded story without having to connect to the internet.



Important Note: Note that not all devices may work with the Storytime Theater Press n Play Characters. Please go to www.story-time-theater.com to find a list of devices that are supported.

3. Downloading Stories:


- a. Once you have downloaded the app and have watched the tutorial, you can download stories one of two ways:

- 1. Use the Press n Play Character by holding the black edges at the base of the figures and making contact with the rubber pads on the bottom of the Press n Play on the area of the screen that states "Unlock your Adventure Here".
- 2. Digital download. If your smart device does not support the Press n Play figures, you can still purchase digital stories activating the Grown Up's area in the app.


Important Note: Problems using the Press n Play Character: If you have a device that does not support the Press n Play Characters to launch a story, you can still download a story. There is a unique code on the back of each Press n Play Character. If your device is not supported, after you attempt to tap the Press n Play Character on to your screen multiple times and it does not download a story, a visual prompt will appear. The device will switch to a code entering screen and a notice will prompt you to enter the code from the back of your Press n Play Character. This will then unlock and download the story for you.

**5. Installing Batteries:**


- a. On the bottom of the projector you will see the battery door as shown
- b. Using a small philips head screwdriver, remove the battery door
- c. Insert 4 "C" batteries as shown
- d. Replace the battery door

**6. Powering Up the Projector:**

- a. On the bottom side you will see the Slide Switch, move the slider into the "ON" position located at the top position.




- b. Place the projector back down onto its base
- c. Press the "WIFI" button on the back of the projector for 2 seconds to turn the projector to "ON" (indicator lights will illuminate)



- d. The following indicators will alert you that the projector is in the "ON" mode:

- i. The Storytime logo with "Network Name" will be projected (Note* This is the network name you will select in 7.b below in your "WIFI" settings so that you can stream your stories to the projector.)
- ii. The edge light on the projector will glow

**7. Connecting to your Device:**

NOTE The steps required to connect your smart device to the projector will vary depending on your device. For this example we will focus on "IOS" set up. For full instructions please visit our website at www.story-time-theater.com/setup

- a. Go to your smart device's "WIFI" control settings
- b. There will be a network name in the list called: "StoryTime_???(the ?? will be the 2 digit "WIFI connection number" described in step 6.d.i.)



- c. Connect to the Network using the default password "12345678"


8. Successful Connection:

A successful connection will be indicated in two ways:


- a. When the loading screen is updated with the "WIFI" and checkmark icons as shown below

**9. Press n Play Night Light:**

- a. Once you have unlocked a story with a Press n Play Character, place the Press n Play Character in the cradle on the side of your projector and the Press n Play character will glow a soft blue color that can be used as a night light. See illustration to the right:

**10. Projector Signals and Warnings:**


- a. **Low Battery Signal:**
 - i. Low Battery symbol will be a flashing overlay on the bottom of the projected screen, per the diagram to the right
 - ii. Edge Light will blink on and off

**b. Losing Projector Connection**

- i. If the projector connection to the smart device is disconnected then:
 - 1. The Projector "WIFI" Symbol will flash on the back of the projector
 - 2. "WIFI" symbol will be flashing on the bottom of the projected screen, per the diagram to the right

**c. Sleep Mode (power saving mode)**

- i. After not receiving any additional instructions or new streaming data for approx 3 minutes, the projector will go into sleep mode:
 - 1. The Sleep symbol will be a flashing overlay for 10 seconds on the bottom of the projected screen, per the diagram to the right.
 - 2. The Edge Light will continue to pulse slowly for 3 more min while the "WIFI" connection remains active waiting for additional instructions

**d. Note***

- Any new instruction from smart device will resume story play back.

Troubleshooting Tips:**11. Why won't my projector turn on?**

- a. Check the following:
 - i. Batteries:
 - 1. Make sure that the batteries are good and have been inserted correctly as shown in the diagram 5.c
 - ii. On Switch:
 - 1. Make sure that the switch on the bottom is set to the "ON" symbol
 - 2. Make sure to Hold the button for 2 seconds to turn on

**12. Why can't I find the App in the app store?**

- a. Make sure you are searching for the "Tech4Kids Storytime Theater App". The icon looks like this:
- b. You can also search the key word "Tech4Kids".
- c. Alternatively, you can follow the link below that is appropriate to your device:
 - i. ios.story-time-theater.com
 - ii. android.story-time-theater.com