

Manual



SKU:M003

Caution: To use this device correctly, please read this manual

For German, French language user manual, please download from our website: www.tecknet.co.uk Sorry for the inconvenience

System Requirements
To use this mouse, your computer must meet the following hardware requirements and run one of the operating systems listed below.

PC with a Pentium processor or equivalent AMD processors
 USB 2.0

Operation System
• Windows2000,2003,XP,Vista,Win7,Win8,Win8.1.

Note: The scroll wheel only works under the operating systems listed above. If you use the mouse under a different operating system, the mouse may either not work or lose its enhanced features and function as a standard five-button mouse only.

Supplied with the Product

- 1 × Cordless Mouse
 1 × USB Nano Receiver
 1 × User Manual
- 1 × Warranty Card

5-Button MouseThe mouse is featured with five buttons and one scroll wheel as

- shown in below picture. Left Click Button
- Right Click Button
 Scroll Wheel
 DPI Switch Button
- Froward Button
 Backward Button
 Low Battery Indicator

DPI Switch Button Scroll Wheel Right Click Button

Left Click Button ♠ Low Battery Indicator

Low Power Capacity Indication

The mouse is equipped with low power capacity indicator, When the battery power capacity indicator. When the battery power gets low during use, the Low Power Capacity Indicator on the top - left of the mouse will flash. Please replace the battery. Note: we recommend you use AAA alkaline drycell batter which supplies longer battery life.



Reconnection
There is a connection code for this Mouse. High temperatures, electro-magnetic fields or vibration may influence the code signal and

electro-magnetic fields or vioration may influence the code signal and the Mouse any need to be reconnected.

Both Mouse and Nann Receiver have a built-in code and one Mouse can be connected to one receive, or severial Mice to one Nano Receive. The Mouse and Nano Receiver may need to be reconnected if subjected to high temperature, electro magnetic fields or strong

- 1. Ensure the battery voltage is correct; if the voltage is low, replace the
- batteries.

 2 Press the right button and middle button (under the scroll wheel) simultaneously (Do not release both buttons until you have completed step 3);
 3. Plug the USB Nano receiver into a free USB port of your computer
- within 15 seconds.
 4. Then release both buttons.

Attention

To maximize battery life, it is recommended you use the mouse on

- 1. To maximize battery life, it is recommended you use the mouse on a white or light coloured surface.
 2. If not used the mouse will drop into activate the mouse, seconds, press any key or scroll wheel to activate the mouse, seconds press any key or scroll wheel to activate the mouse.
 3. If a considerable the mouse to fail temporarily.
 4. The mouse might not work smoothly on certain types of surface, such as smooth, dark, black, reflective and 3D mouse pads surfaces, such as smooth, dark, black, reflective and 3D mouse pads surface, such as iron, aluminium or copper, shield the radio frequency transmission and may slow down the mouse cursorresponse time or cause
- and may slow down me mouse current some may slow down me mouse current some first of the first some first some
- 4

- Note on Handling Batteries

 Keep batteries out of the reach of children.

 Replace old or weak batteries promptly.

 Remove the batteries if the mouse is not going to be used.

Safety Measures

• Keep the mouse away from young children,

• Any attempt to disassemble, adjust or repair the mouse may result in exposure and other safety hazards.

Specifications
Button Count: 5 button Count: 50 button Counting Counting

tance: up to 15m

- Troubleshooting
 What do I do If the mouse does not work?
 Wake sure that the polarity of the batteries is correct. The positive
 (+) and negative (-) markings in the battery must match the positive
 (+) and negative (-) markings in the battery housing.

- Make sure the batteries are not discharged.
 Please try to remove the batteries, and reinstall the batteries again.
 Verify that your computer's power management features is turned off.
 Check that the Nano receiver's USB connector is firmly attached to the USB port of your computer

The USB Nano receiver is recognized by Windows (Windows2000, 2003, XP, Vista, Win7, Win8, Win8.1) but the cursor does not move.

- Check whether the low power indicator on the top of the mouse lights up. If the sensor lights up. It is likely that the batteries are discharged, Please replace them.
 If replacing the batteries does not help, it is likely that the mouse is not one of the please by recompetion and exame that the mouse is within the optimal operational working distance (1.5m) from its USB Nano receiver.


18-Month Battery Life
The mouse consumes little power and offers a long battery life of up to 18 months without changing battery. However please note that the actual battery life may vary based on user and computing conditions.

Install the Batteries
The RF 2.4GHZ optical mouse uses two AAA battery (Battery is not included).

- Open the battery cover.
 Insert the batteries into the compartment, ensuring they correspond
- Insert the batteries into the compartment, ensuring they correspond
 with the polarity marking.
 Replace the battery cover.
 Switch on the mouse by adjusting the power switch underneath the
 mouse. The red LED of the power indicator at the top of the mouse
 will flash.

Note: Make sure that the polarity of the batteries is correct. The positive (+) and negative (-) ends of each battery must match the positive (+) and negative (-) markings in the battery housing.





Connecting the Receiver
Take out USB Nano receiver and plug it into a free USB port in your computer. The Plug & Play function of your system will detect that a new device has been connected and install it automatically.









USB Nano Receiver

The receiver can be removed and stored in the battery compartment while not in use.





- Intelligent Power Saving (IPS)
 The mouse is equipped with Intelligent Power Saving (IPS) function.

 When the USB Nano receiver is disconnected or the PC is switched off, the mouse will be switched off automatically for the purpose of

- off, the mouse will be switched off automatically for the purpose of opwer-saving.

 When your mouse is not operated for 3 seconds, it will automatically drop to the first level of IPS. To wake the mouse, click any button.

 When your mouse is not operated for 10 seconds, it will automatically drop to the second level of IPS. To wake the mouse, click any button.

 When your mouse is not operated for 8 minutes, it will automatically drop to the third level of IPS, e.g., sleep model, To wake the mouse, click any button.

DPI Switch

The mouse supports 2000DPI, 1500DPI and 1000DPI. To switch to

3

- The mouse supports 2000DPI, 1500DPI and 1000D either setting, press the DPI button.

 The default setting is 1000DPI.
 Short press the DPI button on the top of the mouse once to switch from 1000DPI to 1500DPI.
 mouse once again to switch from 1500DPI to 2000DPI.
 Short press the DPI button on the top of the mouse once again to switch from 2000DPI to 1000DPI.



DPI Switch

When I use the mouse, other 2.4G Cordless devices work more slowly or fail temporarily — what should I do?

The mouse has I6 channels to prevent interference. However the mouse may cause interference with any cordless, radio-based device that operates at 4/20HzHz - 2450MHz, such as 2.4G telephone, 2.4G obaty monitors, 2.4G cordless routers and toys. To reduce interference, move the mouse's receiver and the base unit of the affected device as far away from each other as possible, alternatively try to change the 2.4G frequency of the affected devices.

- What do I do if the response time of the mouse is slow or the mouse intermittently stops working?

 Ensure that the mouse is within the opier and restart your PC.

 Increase the distance between the Nano receiver and the base units of other cordless devices.

 Turn off any cordless device and their base units that are near the mouse Nano receiver.
- mouse Nano receiver.

 If you are using the mouse on a metal surface, move the mouse and the receiver to a non-metallic surface. Metals, such as iron, aluminium or copper, shield the radio frequency transmission and may slow down the mouse presenter's response time or cause the mouse to fall temporarily.

I can not use the mouse while another cordless mouse is in use

Reset the identification code, See "Reconnection"

Disclaimer

Every effort has been made to ensure that the information and procedures in this guide are accurate and complete, no liability can be accepted for any errors or omissions and we reserve the right to make any changes without further notice to any products mentioned herein.

Warranty
We warrant that product from authorized distributors will meet the applicable product specifications and be free from all defects in design, assembly, material and workmanship. Please contact TeckNate retailers, or visit our website for more information about the product.

TECKNET

M003 WIRELESS MOUSE

TECKNET P.O. Box 122 Liverpool L9 7WQ www.tecknet.co.ul

REVISIONS				TOLERANCE		SIGNATURES	DATE		
REV.	DWG NO:	DATE BY		0.1-1	± 0.02	QC:		深圳市友联创科技有限公司	
ν0	M003说明书	2015.5.5	严寅亮		± 0.2	Purchase:			
VO		2015.5.5) 奥冗			Manager:			
						UK:		ITEM	M003说明书
				SCALE		UNIT		1120	141002 68-91 13
						mm		DESCRIPTION	PACKAGE

FCC Information and Copyright

pursuant to part 15 of the FCC Rules. This equipment has been tested and found to comply with the limits for a Class B digital device,

installation. This equipment generates, These limits are designed to provide reasonable protection against harmful interference in a residential

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

installation. If this equipment does to radio communications. However, there is no guarantee that interference will not occur in a particular

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is
- —Consult the dealer or an experienced radio/TV technician for help.

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference, and
- cause undesired operation. (2) this device must accept any interference received, including interference that may

void the user's authority to operate the equipment. changes or modifications not expressly approved by the party responsible for compliance could