

RADIO CONTROLLED VEHICLES

OPERATING INSTRUCTIONS:

BATTERY REQUIREMENTS (BATTERIES NOT INCLUDE.)

Vehicle: 3X AAA Batteries
Transmitter: 2X AA Batteries

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or experienced radio/TV technician for help

ATTENTION PARENTS:


It is recommended that this Toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired be repaired or replaced


HOW TO INSTALL BATTERIES IN VEHICLE:

- 1. Push the ON/OFF Switch to the OFF position.
- 2. Open the Battery Cover.
- Insert the 3 "AAA" Batteries into the Battery Compartment. (See Diagram #1)
- 4. Replace Battery Cover.

NOTE: REMOVE BATTERIES AFTER YOU HAVE FINISHED USING YOUR VEHICLE.

DIAGRAM #1





PERFORMANCE TIPS:

- * Use fresh Alkaline Batteries.
- * Do not drive through water
- * For best performance, do not operate on slick surfaces. Concrete, asphalt and short carpet are the recommended driving surfaces.
- * Be sure to rest Vehicle for 30 minutes after every 15 minutes of operation.
- * Electrical, CB interference, Mobile Phone, Air Conditioning, Elevators and Steel Girders in building will affect the Vehicle operation.
- * Do not leave the Vehicle or Transmitter near a source of heat or under direct Sunlight for long periods of time.
- * Make sure ON/OFF Switch on your Vehicle is "OFF" when not in use.
- * Remove the Batteries from the Vehicle and Transmitter when not in use.

HOW TO INSTALL BATTERY IN TRANSMITTER:

- 1. Push the ON/OFF Switch to the OFF position.
- 2. Open the Battery Cover.
- 3. Insert the 2"AA" Batteries into the battery compartment. (See Diagram #2)
- 4. Replace Battery Cover.

USING YOUR VEHICLE:

- 1. Turn power switch to 'ON' position.
- 2. Use Controller to operate vehicle.
- 3. After operation, turn off car and remove batteries.