Test report No. : 10936450H-A-R1
Page : 68 of 71
Issued date : January 7, 2016
Revised date : January 12, 2016
FCC ID : VPYLB1FS

APPENDIX 3: Photographs of test setup

Conducted Emission




Photo 1



Photo 2

UL Japan, Inc. Ise EMC Lab.

4383-326 Asama-cho, Ise-shi, Mie-ken 516-0021 JAPAN

Telephone: +81 596 24 8999 Facsimile: +81 596 24 8124

Test report No. : 10936450H-A-R1
Page : 69 of 71
Issued date : January 7, 2016
Revised date : January 12, 2016
FCC ID : VPYLB1FS

Radiated Spurious Emission




Photo 1




Photo 2


4383-326 Asama-cho, Ise-shi, Mie-ken 516-0021 JAPAN

Telephone: +81 596 24 8999 Facsimile: +81 596 24 8124


: 10936450H-A-R1 Test report No. Page : 70 of 71 **Issued date** : January 7, 2016 : January 12, 2016 : VPYLB1FS Revised date FCC ID

Worst Case Position Module (Horizontal: X-axis/ Vertical: X-axis)


X-axis



Y-axis



Z-axis



4383-326 Asama-cho, Ise-shi, Mie-ken 516-0021 JAPAN

Telephone: +81 596 24 8999 Facsimile : +81 596 24 8124


Test report No. : 10936450H-A-R1
Page : 71 of 71
Issued date : January 7, 2016
Revised date : January 12, 2016
FCC ID : VPYLB1FS

Worst Case Position


Antenna

Above 1GHz (Horizontal: Y-axis/ Vertical: Y-axis) Below 1GHz (Horizontal: X-axis/ Vertical: X-axis)


X-axis



Y-axis



Z-axis



End of Report

4383-326 Asama-cho, Ise-shi, Mie-ken 516-0021 JAPAN

Telephone: +81 596 24 8999 Facsimile: +81 596 24 8124