WKCC-KPDBU Programming Instruction

LEARN

Guardian Door Opener

①

② Enter 1-6digits code ③

OK

Flashes

🔊 x2

Fig.1

WKCC transmits remote codes to garage door opener via radio frequency (RF), codes will be stored in the door opener.

To Add Personal Codes:

1. Press the "LEARN" button on the rear control panel, "OK" LED will glow and beep. The unit is ready to accept a transmitter in the next 30 seconds as shown in Fig.1.

2. Enter 1 - 6 digit(s) personal code on the Keyless Entry within 30 seconds and press/release "ENTER" button. "OK" LED will flash and beep twice indicating personal code is stored in memory.

Up to 20 personal codes (including 1-button transmitters) can be added to the opener by repeating the above procedures.

If more than 20 personal codes are stored in the opener memory, the previously stored one from the very beginning will be replaced, i.e. the 21st transmitter replaces the 1st stored one.

Operation:

To access the door, enter a pre-stored personal code and press "ENTER" to transmit code, and within 20s, "ENTER" button can be used to stop or reverse the door.

If the code is entered incorrectly, correction can be made by pressing "ENTER" to reset and re-enter code.

When dark, "ENTER" may be pressed in advance to turn on back light.

Removing ALL Personal Code(s):

To remove ALL personal code(s) and/or transmitters from memory, press and hold the "LEARN" button for 5 seconds. "OK" LED will flash and beep, indicating ALL codes/ transmitters have been removed from the opener.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies FCC Rules for HOME OR OFFICE USE. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WKCC-KPDBU

Fig.2