



AIRCRAFT
MAINTENANCE MANUAL

OIL FILTER IMPENDING BY-PASS VISUAL INDICATOR - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. This section gives the procedure to remove/install the oil-filter impending-bypass visual indicator.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
79-37-02-000-801-A	OIL-FILTER IMPENDING-BYPASS VISUAL ALL INDICATOR - REMOVAL	
79-37-02-400-801-A	OIL-FILTER IMPENDING-BYPASS VISUAL ALL INDICATOR - INSTALLATION	



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 79-37-02-000-801-A

EFFECTIVITY: ALL

2. OIL-FILTER IMPENDING-BYPASS VISUAL INDICATOR - REMOVAL

A. General

- (1) To remove the oil-filter impending-bypass visual indicator, obey the instructions in Rolls-Royce MM CSP 34022.

B. References

REFERENCE	DESIGNATION
AMM MPP 71-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 71-12-01-000-801-A/400	ENGINE LOWER COWLING - OPENING

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413	Lower Cowling	LH Engine
423	Lower Cowling	RH Engine

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Work Stand	To get access to the engine	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Engine

I. Preparation

SUBTASK 841-002-A

WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN AMM MPP 71-00-00/200 TO PREVENT INJURY TO THE PERSONS AND DAMAGE TO THE MATERIAL.

- (1) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them.



AIRCRAFT
MAINTENANCE MANUAL

- START 1/2.

- (2) Put the work stand in the work area.
- (3) Open the lower cowling ([AMM TASK 71-12-01-000-801-A/400](#)).

J. Removal

SUBTASK 020-002-A

- (1) Remove the oil-filter impending-bypass visual indicator. Refer to the last revision of Rolls-Royce MM CSP 34022.



AIRCRAFT
MAINTENANCE MANUAL

TASK 79-37-02-400-801-A

EFFECTIVITY: ALL

3. OIL-FILTER IMPENDING-BYPASS VISUAL INDICATOR - INSTALLATION

A. General

- (1) To install the oil-filter impending-bypass visual indicator, obey the instructions in Rolls-Royce MM CSP 34022.

B. References

REFERENCE	DESIGNATION
AMM TASK 71-12-01-400-801-A/400	ENGINE LOWER COWLING - CLOSING

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413	Lower Cowling	LH Engine
423	Lower Cowling	RH Engine

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Work Stand	To get access to the engine	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Engine

I. Installation

SUBTASK 420-002-A

- (1) Install the oil-filter impending-bypass visual indicator. Refer to the last revision of Rolls-Royce MM CSP 34022.

J. Follow-on

SUBTASK 842-002-A

- (1) Close the lower cowling ([AMM TASK 71-12-01-400-801-A/400](#)).



AIRCRAFT
MAINTENANCE MANUAL

- (2) Remove the work stand.
- (3) On the circuit breaker panel, close the circuit breakers below and remove the DO-NOT-CLOSE tag from them.
 - START 1/2.
- (4) Refer to the Rolls-Royce MM CSP 34022 to do the related check procedures after an engine LRU maintenance procedure, as applicable.

