



AIRCRAFT  
MAINTENANCE MANUAL

OIL FILTER ACTUAL BY-PASS VISUAL INDICATOR - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. This section gives the procedure to remove/install the oil-filter actual-bypass visual indicator.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
79-37-03-000-801-A	OIL-FILTER ACTUAL-BYPASS VISUAL INDICATOR - REMOVAL	ALL
79-37-03-400-801-A	OIL-FILTER ACTUAL-BYPASS VISUAL INDICATOR - INSTALLATION	ALL



EMB145 – EMB135

AIRCRAFT  
MAINTENANCE MANUAL

TASK 79-37-03-000-801-A

EFFECTIVITY: ALL

2. OIL-FILTER ACTUAL-BYPASS VISUAL INDICATOR - REMOVAL

A. General

- (1) To remove the oil-filter actual-bypass visual indicator, obey the instructions given in Rolls-Royce MM CSP 34022.

B. References

REFERENCE	DESIGNATION
AMM MPP 71-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 71-12-01-000-801-A/400	ENGINE LOWER COWLING - OPENING
Rolls-Royce MM CSP 34022	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413	Lower Cowling	LH Engine
423	Lower Cowling	RH Engine

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To get access to the engine	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Engine

I. Preparation

SUBTASK 841-002-A

**WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN AMM MPP 71-00-00/200 TO PREVENT INJURY TO THE PERSONS AND DAMAGE TO THE MATERIAL.**



## AIRCRAFT MAINTENANCE MANUAL

- (1) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them.
  - START 1/2.
- (2) Put the workstand in the work area.
- (3) Open the lower cowling ( [AMM TASK 71-12-01-000-801-A/400](#)).

### J. Removal

#### SUBTASK 020-002-A

- (1) Remove the oil-filter actual-bypass visual indicator. Refer to the latest revision of Rolls-Royce MM CSP 34022.



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

TASK 79-37-03-400-801-A

EFFECTIVITY: ALL

3. OIL-FILTER ACTUAL-BYPASS VISUAL INDICATOR - INSTALLATION

A. General

- (1) To install the oil-filter actual-bypass visual indicator, obey the instructions given in Rolls-Royce MM CSP 34022.

B. References

REFERENCE	DESIGNATION
AMM TASK 71-12-01-400-801-A/400	ENGINE LOWER COWLING - CLOSING
Rolls-Royce MM CSP 34022	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413	Lower Cowling	LH Engine
423	Lower Cowling	RH Engine

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To get access to the engine	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Engine

I. Installation

SUBTASK 420-002-A

- (1) Install the oil-filter actual-bypass visual indicator. Refer to the latest revision of Rolls-Royce MM CSP 34022.



AIRCRAFT  
MAINTENANCE MANUAL

J. Follow-on

SUBTASK 842-002-A

- (1) Close the lower cowling ( [AMM TASK 71-12-01-400-801-A/400](#)).
- (2) Remove the workstand.
- (3) On the circuit breaker panel, close the circuit breakers below and remove the DO-NOT-CLOSE tag from them.
  - START 1/2.
- (4) Refer to the Rolls-Royce MM CSP 34022 to do the related check procedures after an engine LRU maintenance procedure, as applicable.

