

**SPARTAN6 STARTER KIT** 

# Spartan6 Starter Kit User Manual



Download all Source code from following link


https://github.com/fpgatechsolution/Spartan6-starter-kit

info@fpgasolution.com, Mobile: 9665889991 WWW.FPGASOLUTION.COM

### Key Features:

- Spartan6-XC6SLX9\_TQ144FPGA
  - ➤ Up to 102 user-I/O pins
  - > TQ-144 package

## Key components:




- > BUZZER
- > RGB LED

#### **BOARD POWERING**

The **SPARTAN6 STARTER KIT** can work on USB power you can also connect external 5VDc. supply. When **JP2** jumper is placed in 2 & 3 power is used from USB connector. When **JP2** jumper is placed in 1 & 2 power is used from external power adaptor

Use external 5V/2A supply whenever you are using steeper or dc motor.



#### LED's and DIP Switches Interface

The **SPARTAN6 STARTER KIT** board has 8 individual LED & 8 slide switches. A LED is assigned to each I/O to indicate its data status when I/O is configured as output. DIP switch is used to provide digital input (i.e. logic 0 and logic 1).


## Pin Assignment (UCF Location) for IOs:

Slide Switch	XC6SLX9	Active
SW0	P5	LOW
SW1	P9	LOW
SW2	P11	LOW
SW3	P14	LOW
SW4	P16	LOW
SW5	P17	LOW
SW6	P23	LOW
SW7	P24	LOW

LED	XC6SLX9	Active
TL1	P26	HIGH
TL2	P22	HIGH
TL3	P21	HIGH
TL4	P15	HIGH
TL5	P12	HIGH
TL6	P10	HIGH
TL7	P8	HIGH
TL8	P2	HIGH

#### **LCD** Interface

The **SPARTAN6 STARTER KIT** includes 2 lines by 16 characters LCD (liquid crystal display) Module. The dot matrix LCD displays alphanumeric characters, numbers and symbols. For displaying characters, numbers and symbol, user needs to send 8-bit ASCII value on data pins (Data0-Data8). The user can control the LCD display by controlling control lines (RS, EN) and sending command codes on data pins. All the functions required for controlling LCD backlight are provided internally on board. Internal refresh is provided by the controller. The Interface details of the LCD display are as shown in following figure



LCD	XC6SLX9
LCD_D1	P137
LCD_D2	P134
LCD_D3	P133
LCD_D4	P132
LCD_D5	P131
LCD_D6	P127
LCD_D7	P126
LCD_RS	P140
LCD_EN	P139

## Seven segments Interface

The SPARTAN6 STARTER KIT board includes 4common anode seven segment display

seven segments	XC6SLX9
SIG_A	P119
SIG_B	P118
SIG_C	P117
SIG_D	P120
SIG_E	P121
SIG_F	P124
SIG_G	P123
SIG_PD	P116
SEL_DISP1	P114
SEL_DISP2	P111
SEL_DISP3	P115
SEL_DISP4	P112

#### **Pushbuttons Interface**


The **SPARTAN6 STARTER KIT** board has 4 individual pushbuttons for input purpose. The pushbuttons are read as 0 when pushed. They are read as 1 in normal (Unpressed) condition. Pushbuttons are labeled as SW1 TO SW4.

## Pin Assignment (UCF Location) for Pushbuttons:

Signal Name	XC6SLX9	Active
SW1	P105	LOW
SW2	P101	LOW
SW3	P98	LOW
SW4	P39	LOW


#### **ADC Interface**

The **SPARTAN6 STARTER KIT** board includes an ADC MCP3004. The ADC has 4 analog input channels. The channels are selected by setting the address pins of ADC. The analog input to all channels is given by external circuit through relimate pins. The other controlling signals of ADC are interfaced with FPGA board as shown in following figure. VREF is connected to 3.3V, so analog voltage input rang of all channel is 0 to 3.3V.



Interfacing of ADC with FPGA

## Pin assignment (UCF Location) for ADC:




Signal Name	XC6SLX9
CLK	P70
CS	P99
DIN	P65
DOUT	P64

- Development Boards
- PCB Designing
- > Industrial Training
- > Industrial Projects




#### **DAC Interface**

The **SPARTAN6 STARTER KIT** board includes 8-bit 4 channels, digital-to-analog converter (DACs) DAC084S085. DAC allows easy interface to most popular microprocessor buses and output ports. DAC works on 3.3V. The following figure shows the interfacing diagram of DAC with FPGA Board. VREF is connected to 3.3V, so analog voltage output rang of all channel is 0 to 3.3V.




## Pin Assignment (UCF Location) DAC084S085:



Signal Name	XC6SLX9
CS	P100
CLK	P70
DIN	P65

#### **USB** Interface

The **SPARTAN6 STARTER KIT** board have USB interface using device FT2232HL from FTDI. This act as USB to UART converter so that Communication with FPGA can accomplished by USB port.





## Pin Assignment (UCF Location) for USB interface:

Signal Name	XC6SLX9
USB_Rx	P102
USB TX	P104


#### **Clock Sources**

The **SPARTAN6 STARTER KIT** supports clock input sources which are listed below. The board includes an on-board 12 MHz clock oscillator

Signal Name	XC6SLX9
Clock	
12Mhz	P95

#### **Buzzer**


The SPARTAN6 STARTER KIT has a buzzer interface



Signal Name	XC6SLX9
Buzzer	P94

### **RGB-LED**

#### The SPARTAN6 STARTER KIT has a RGB LED




Signal Name	XC6SLX9
R	P1
G	P6
В	P7

#### **Motor control**

On this board you can control either steeper motor or Dc motor at a time

Use external 5V/2A supply whenever you are using steeper or dc motor.

Connect steeper motor as shown in following fig



Signal Name	XC6SLX9
М0	P143
M1	P444
M2	P141
М3	P142

## FREE INPUT OUTPUT

The **SPARTAN6 STARTER KIT** board has seven free input output connectors. Each connector have 8 input output pins, 3.3V Dc pin and GND pin.

Name	Signal Name	XCS6LX9- TQG144	ı	Name	Signal Name	XCS6L TQG14
<b>J</b> 9	J3_1	P43		144	J5_1	P67
	J3_2	P41			J5_2	P66
	J3_3	P45			J5_3	P75
	J3_4	P44			J5_4	P74
	J3_5	P47			J5_5	P79
	J3_6	P46		J11	J5_6	P78
	J3_7	P50			J5_7	P81
	J3_8	P45			J5_8	P80
	J3_9	GND			J5_9	GNE
	J3_10	+3.3V		J5_10	+3.3	
J10	J4_1	P55		J12	J6_1	P82
	J4_2	P51			J6_2	P83
	J4_3	P57			J6_3	P84
	J4_4	P56			J6_4	P85
	J4_5	P59			J6_5	P88
	J4_6	P58			J6_6	P87
	J4_7	P62		J6_7	P93	
	J4_8	P61			J6_8	P92
	J4_9	GND			J9_9	GNE
	J5_10	+3.3V			J6_10	+3.3

Name	Signal Name	Signal Name	XCS6LX9- TQG144
	J8_1	J6_1	P29
	J8_2	J6_2	P27
	J8_3	J6_3	P32
J8	J8_4	J6_4	P30
&	J8_5	J6_5	P34
	J8_6	J6_6	P33
J6	J8_7	J6_7	P40
	J8_8	J6_8	P35
	J8_9	J6_9	GND
	J8_10	J6_10	+3.3V

