	Robot Movement						
Action		How Much?	Python Code	Parameters			
Drive Straight	+distance -distance	Distance	r.robot.straight(distance)	distance: Distance to travel (mm), robot runs at default speed example - r.robot.straight(100) - Goes straight forward 100 mm			
Drive Straight or Curved	+speed -turn -speed +turn -speed +turn -speed -turn	Time	r.robot.drive(speed,turn_rate) wait(time) r.robot.stop()	speed: Speed of the robot (mm/s) turn_rate: Turn rate of the robot (deg/s) 0 = Straight time: How long to drive (mSec) Drives the robot at set speed either straight or while turning r.robot.drive(200, 20) - Drive robot slowly forward while turning gently to right			
Curve	+radius -degrees -radius -radius -degrees -radius -degreees +degreees	Distance	r.robot.arc(radius, degrees)	radius: Radius of the circle (mm) distance: Distance to drive along the circle (mm) Drives center of wheels over specified radius circle for degrees of arc r.robot.arc(50, 180) - drives robot halfway around tight circle			
Tank Turn	Fangle Hangle	Angle	r.robot.turn(angle)	angle: Angle of the turn (deg) r.robot.turn(-90) - Make robot spin 90 degrees to the left			
Attachment Motors							
Side		How Much?	Python Code	Parameters			
Left		Time	r.lam.run_time(speed,time)	speed: Speed of the motor (deg/s) time: Duration of motor running (mSec) r.lam.run_time(1000, 500) - runs lam (left attachment motor) clockwise fast for 0.5 seconds			
Left		Angle	r.lam.run_angle(speed,angle)	speed: Speed of the motor (deg/s) angle: Angle by which the motor should rotate (deg) r.ram.run_angle(500, 45) - runs ram (right attachment motor) clockwise at half speed for 45 degrees			
				Ispeed: Speed of the motor (deg/s)			
Left		Target Angle	r.lam.run_target(speed,target_angle)	speed: Speed of the motor (deg/s) target_angle: Angle in degrees that the motor should rotate to, angle is zero when marks on motor hub and body are aligned. Motor angles can be reset by program, see "Motors with rotation sensors"  I lam run_target(20060) - runs lam to 60 degrees counter-clockwise from reference mark on			
Left Left		Target Angle	r.lam.run_target(speed,target_angle) r.lam.run_until_stalled(speed,duty_limit=stall_power)	target_angle: Angle in degrees that the motor should rotate to, angle is zero when marks on motor hub and body are aligned. Motor angles can be reset by program, see "Motors with			
				target_angle: Angle in degrees that the motor should rotate to, angle is zero when marks on motor hub and body are aligned. Motor angles can be reset by program, see "Motors with rotation sensors"  r_lam_run_target(20060)runs_lam_to 60 degrees counter-clockwise from reference mark on speed: Speed of the motor (deg/s)  stall_power: What percent power to is considered a stall (0 - 100)  r.ram.run_until_stalled(1000, duty_limit=100) - runs ram clockwise until it pushes hard on			

Other Commands						
Action			Python Code	Parameters		
Pause the Program				time: How long to pause the program (mSec)		
				wait(500) - keeps program from going to next instruction (waiting) for 500 milliseconds = 0.5		
				seconds		
				your_message: Text to be displayed in the console window		
Print to console			print("your_message")	print("Hello World") - prints message Hello World on console display of computer Bluetoothed to		
				bot		
Color Sensor Reflectivity			value = r res reflection()	Value: is set to reflectivity color sensor sees, use "lcs" for left sensor		

Direction - Normally positive is clockwise rotation unless switched in robot.py near line 147

Code on left followed by print(value) will color sensor reflection values from 0 to 99 on console

Medium motors = 1100, Large motors = 1050

value = r.rcs.reflection()

Color Sensor Reflectivity

## **Setting Tire Diameter and Axle Track**

To set values for your robot first measure TIRE\_DIAMETER in millimeters. Second find your AXLE\_TRACK by measuring space between the very center of the wheels in millimeters. Now enter these values in robot.py, you'll find these constants around program line 100. A Spike bot will be about TIRE\_DIAMETER = 56 and AXLE\_TRACK = 82, yours may be different if you use different wheels or spacing of the motors on your bot. The exact procedure for setting your robot's values is found in pybricks help menu, search on "robotics and drive bases", then look about half way down the section for the heading "Measuring and validating the robot dimensions". If you follow this procedure your robot will drive as far and turn as much as you tell it.

