




Cut out the parts, and then carefully follow the assembly instructions.

Tools & **Materials**

- Scissors, utility knife
- Glue stick and wood glue



- Object with pointed tip (dried-up ballpoint pen, stencil pen, etc.)
- Toothpicks
- Tweezers

Tips for **Assembly**

■ Keep track of which part is which by writing each part's number in pencil on the back of the part.



■ Use a dried-up ballpoint pen, stencil pen, or other pointed object and a ruler to score along the fold lines. This will create sharper, neater folds.



- Before gluing, fold and crease along the fold lines and add curves where needed.
- Use a toothpick when applying glue. Thinly applied glue gives a neater finish.
- Use tweezers when picking up and attaching small parts.

Caution



- This paper craft uses scissors, utility knives, glue, and other items and materials which may be dangerous to children. Keep these items and materials out of reach of children while you work.
- Take care not to injure yourself when using scissors, utility knives, and other sharp or pointed objects.

Symbols and Notation



Pattern



Assembly instructions



Part numbers



Mountain fold line (dotted line)



Valley fold line (dotted & dashed line)



Cut line (solid line)



Partial cut line (solid red line)



Cut-out area



Apply glue (red arrow)



Insert (blue arrow) (Do not apply glue)



Add curves




Dots on glue tabs show where and how to glue parts together.

- Glue tab (red dot) Glue one part to another part
- Glue tab (green dot) Glue one place to another on the same part
- Glue tab (blue dot) Glue one part to the reverse of another part
- Glue tab (yellow dot) Glue the reverse of two parts together







Pold along the dotted line, making an angle of about 30°. Right-handed people should make a mountain fold, and left-handed people a valley fold. Right-handed Right-handed Left-handed 30°





3 <How to Hold>

Gently grip the boomerang with your thumb and index finger. Let it rest against the webbing between your thumb and index finger.





<How to Throw>

Bend your elbow and hold the boomerang beside your head. Throw it with a flick of the wrist, so that the boomerang spins forwards. Rather than just throwing as hard as you can, use a snapping action with your wrist to make it spin.

*Make fine adjustments to the angle of the fold, and see if you can make it come back to you!



<Caution>

- *Play with your boomerang in a wide open space where there are no cars or bicycles.
- *Before you throw your boomerang, check that there are no people or animals around.
- *If your boomerang gets stuck somewhere high, don't try to climb up and retrieve it.
- *Young children should be supervised by an adult when playing with this toy.