GMMK Pro Cheatsheet

April 8, 2022

Shortcuts

Key Combo	Function
Capslock	Hold = numpad; Double tap = numpad toggle
L+R Shift	Capitalize next word
Left Shift	Double press = Capslock
Shift + Backspace	Insert
F13	Home
Fn + PGUP	Home
Fn + PGDN	End
Fn + Winkey	Windows key locked out (for gaming)
Fn + N	Numlock (system)
Fn + I	Scroll Lock
Fn + U	Print Screen
Fn + P	Pause
Fn + \	Bootloader mode

Function Key Row

ranetion key kow		
Key Combo	Function	
Fn + F1	My Computer	
Fn + F2	Open new browser tab	
Fn + F3	Calculator	
Fn + F4	My Music	
Fn + F5	Media Previous track	
Fn + F6	Media Next track	
Fn + F7	Media Play	
Fn + F8	Media Stop	
Fn + F9	Volume Down	
Fn + F10	Volume Up	
Fn + F11	Print Screen	
Fn + F12	Scroll Lock	
Fn + F13	Pause	

RGB Functionality

	-
Fn + - or =	RGB backlight timeout up/down
Fn + Z	RGB night mode (backlight off)
Fn + A or D	RGB hue up/down
Fn + Q or E	RGB saturation up/down
Fn + W or S	RGB value (brightness) up/down
Fn + Up or Down	RGB effect next/previous
Fn + Left or Right	RGB animation slower/faster
Fn + Home	RGB temporary off

Rotary Encoder

Push	Mute
LShift + Turn	Cycle layers
RShift + Turn	PgUp/PgDn
LCtrl + Turn	Navigate prev/next word
RCtrl + Turn	RGB hue up/down
LAlt-Turn	Media prev/next track