


# GPSTAR

## Proton Pack & Neutrona Wand



### Operational Guide







Neutrona Wand renders courtesy of Luis Peña

## Operational Guide - Table of Contents

- [Standard Features](#)
- [Optional Features](#)
- [Toggle Operation Modes](#)
- [Firing Modes](#)
- [Neutrona Wand Menu System](#)
- [Additional Resources](#)

## Standard Features

- The switch underneath the Ion Arm can turn the Proton Pack on or off.
- You can run the pack without the Cyclotron Lid attached.
- The volume for the pack and wand can be controlled via the Crank Generator knob.
  - Clockwise to raise volume, counter-clockwise to lower it.
- When the ribbon cable is disconnected it will activate the alarm mode and degrade the Cyclotron spin.
- The Proton Pack can run without a wand, though it can only be activated via the switch under the Ion Arm.
- Vibration switch in the Cyclotron switch plate enables or disables the vibration motors for both the Proton Pack and Neutrona Wand.
- 1984/Afterlife year switch in the Cyclotron switch plate changes the Proton Pack and Neutrona Wand from 1984 to Afterlife modes.
- The Proton Pack vibrates only while firing. This can be changed to vibrate at all times or entirely disabled.  
Vibration can be enabled or disabled by the vibration toggle switch in the Proton Pack. Vibration settings can be toggled via the Neutrona Wand menu system or the advanced user configuration settings.
- The Neutrona Wand vibrates only while firing. This can be changed to vibrate at all times or entirely disabled.  
Vibration can be enabled or disabled by the vibration toggle switch in the Proton Pack. Vibration settings can be toggled via the wand menu system or the advanced user configuration settings.
- Single (centered) LED per Cyclotron lens for 1984/1989 modes by default.
  - This can be toggled back to 3 LEDs per Cyclotron lens via the Neturona Wand menu system.
- The Power Cell, Cyclotron and other lighting on the Proton Pack can have the brightness independently adjusted.
- 1989 sound effects mode is available on the pack, it can be accessed from the Neutrona Wand menu systems or set with the advanced user configuration settings.
- Super Hero and Mode Original system operation modes.
- Menu system with the ability to customise various settings for both your Proton Pack and Neutrona Wand.
- Up to 5 different power levels as indicated on the Neutrona Wand bargraph.
  - The Neutrona Wand can be configured within the menu system to adjust the overheat settings. When not set to overheat, you can fire continuously.
  - The Proton Pack can also be configured within the Neutrona Wand menu system to adjust the duration of smoke effects (for each power level), which smoke effects are activated (for each power level), use of overheating smoke effects (for each power level), or whether smoke is enabled or disabled entirely (for each power level). Default settings: The Neutrona Wand will fire forever on power levels level 1 through 4 and overheat on power level 5.
- The Proton Pack will emit smoke effects during longer firing (Default setting: enabled). This can be configured from the Neutrona Wand menu system.


## Optional Features

- Support for changing Cyclotron direction and to enable/disable smoke effects.
- Support for smoke effects with dedicated fans for the Booster Tube and N-Filter.
  - See the [Smoke Effects](#) addendum for more information.
- Additional Lights available for the Cyclotron panel, internal "cake" Cyclotron, and Power Cell.
  - Automatically switches to internal "cake" Cyclotron, if implemented (optional).
  - This supports a 35-LED RGB ring light (by default) to be installed in the "cake". Other size LED rings or LED setups are supported in the configuration settings.
- Video game colours supported if using RGB-supported LEDs for the Cyclotron Lid, internal "cake" Cyclotron and Power Cell.
- Support for the Attenuator add-on device. See the [Attenuator](#) addendum for more information.
- Support for additional lights such as the wand hat lights and wand barrel end LED strobe.
  - When adding the Hat1 light a New Barrel Wing Button can also be added.
- Serial connection and power for a 28-segment bargraph support (to replace the stock 5-LED bargraph).



Location of optional hardware for Neutrona Wand, requires advanced modifications.

## Top Dial Behaviour




- The top dial on the top of the gun box changes the power mode of the wand, affecting the intensity of the stream effects, indicated by increasing or decreasing the bargraph lights (just as the stock wand did).
  - Clockwise to raise power/volume, counter-clockwise to lower these values.
- There are 5 wand power levels in Super Hero mode and 4 in Mode Original.
- For lower power levels, the proton stream is more red. On higher power levels, the stream will appear more yellow.
- This dial will be used to navigate the menu systems and adjust volume in certain cases (see "Wand Settings Menu System" section).

**Tip:** When music is playing while the pack and wand are turned off, you can use the Top Dial on the top of the Neutrona Wand to easily access the independent music volume control.

Refer to the [Loading The Audio Files](#) for more information on loading additional music tracks.

## Toggle Operation Modes

There are two modes available which replicate movie or prop-accurate behaviors of the available toggle switches. These system modes can be altered via an [EEPROM menu](#) and will affect the startup sequence for your Proton Pack and Neutrona Wand.



## Super Hero Mode Operation Guide

**Super Hero:** This is the default operation mode based primarily on the 2021 film.

### Activate Toggle

- Activate toggle on the gun box turns on both the Proton Pack and Neutrona wand.
  - The switch under the Proton Pack's Ion Arm does not need to be engaged for this to work. The switch under the Ion Arm will turn the cyclotron on.
- The lever switch near the gunbox acts as a safety switch and it must be pulled to extend the barrel before firing.
- Right-hand toggles (Bottom and Top) affect the vent light and additional sound effects.
  - The Neutrona Wand will not fire unless these switches are turned on.
  - **Boot-Up Errors:** If you attempt to boot up your Neutrona Wand while the top toggle switch is on, the Neutrona Wand will boot into a error mode. Turn the top toggle switch off and restart your Neutrona Wand to boot normally. **This is the default behaviour**, though this feature can be disabled in Neutrona Wand Config EEPROM Menu.
- While firing, the default bargraph animations slide/split the bargraph in half and scroll up and down simultaneously.

### Right-Hand Toggle Switch Behaviour




- While in 1984/1989 theme modes:
  - Bottom toggle switch turns on the vent light and plays the wand power up sound.
  - Top toggle switch plays a single beep sound.
- While in Afterlife theme mode:
  - Bottom toggle switch turns on the vent light and the wand plays a ramp up sound.
  - Top toggle switch turns on the looping beeping sounds.

## Original (Prop) Mode Operation Guide

**Mode Original:** This mode reflects original production documentation from 1984 on how the Proton Pack and Neutrona Wand operate together. Other variation differences are the bargraph animations, Neturona Wand sound effects and power levels.

- There are 4 power levels in mode original. When the Neutrona Wand is in stand by mode (see toggle switch behaviours below), the bargraph settles on the first level.
- The switch under the Ion Arm on the Proton Pack must be switched on. This gives power to the entire system. The slo-blo light on the Neutrona Wand will turn solid red to indicate power to the system.
- While firing, the default bargraph animations slide the bargraph up and down small increments to indicate the instability and power of the proton stream.

### Right-Hand Toggle Switch Behaviours



- The bottom toggle will put the Neutrona Wand into standby mode. The slo-blo LED will begin to blink, and the vent lights will turn on.
- The top toggle turns on the bargraph. It will ramp up and back down to the lowest level setting.

### Activate Toggle

- Activate toggle on the gun box turns on the cyclotron of the Proton Pack. To activate the cyclotron, all the right hand toggle switches on the Neutrona Wand must be activated.
  - The Cyclotron will not turn on unless all the toggle switches on the Neutrona Wand are activated and the Ion Arm switch on the Pack is in the ON position.
- The lever switch near the gunbox acts as a safety switch and it must be pulled to extend the barrel before firing.

# Firing Modes

## Video Game Mode (Default)



**Barrel Wing Button**

- Pressing the Barrel Wing Button while you are already throwing a Proton Stream with the Intensify button will initiate "Cross the Streams".
- The Barrel Wing Button at the end of the Neutrona Wand switches between these available firing modes while the wand is active and not throwing a stream:
  1. Proton Stream (Default)
  2. Slime Blower
  3. Stasis Stream
  4. Meson Collider
  5. <sup>1</sup> Spectral (Rainbow)
  6. <sup>2</sup> Spectral (Holiday)
  7. <sup>3</sup> Spectral (Custom)
  8. Manual Venting Mode (Manual vent your Proton Pack)
  9. Special: Setting 6 is a settings menu system (see "Wand Settings Menu System" section below).


<sup>1</sup> Spectral Mode (Rainbow) is a firing mode which gives a RAINBOW effect. If your Proton Pack has RGB LEDs, they will change to match.

<sup>2</sup> Spectral (Holiday) is a firing mode which gives a RED/GREEN effect. If your Proton Pack has RGB LEDs, it will match these colours.

<sup>3</sup> Spectral (Custom) is a user defined colour mode. You can independently adjust the Neutrona Wand Barrel, Power Cell, Cyclotron and Inner Cyclotron colours directly from the EEPROM LED Menu system. The default colours are purple.

 **Note:** Spectral modes are disabled by default but can be enabled from the EEPROM Menu or flashed directly to the Neutrona Wand board. They take advantage of RGB coloured LED add-ons if installed.

## Manual Venting Mode




- When in manual venting mode, the Slo-Blo LED and the Orange LED on the front of the wand body will blink to indicate that you are in the manual venting mode. Press Intensify on the wand to manually vent your Proton Pack. (All the toggle and safety switches on the wand must be activated).

### Alternate Firing Modes: Cross The Streams (CTS) / Cross The Streams Mix (CTS Mix)

- The Barrel Wing Button at the end of the wand acts as a alternate fire mode button. When Cross The Streams is enabled, Video Game Modes are disabled and you will only have the Proton Stream.
- The overheat features can only be triggered when holding the alternate fire mode button (Barrel Wing Button) when Cross The Streams mode is enabled.
- Pressing both the Intensify and Barrel Wing Button at the same time enables the "Cross the Streams" (CTS) audio and visual effects. Releasing one of the 2 firing buttons will continue these effects.
  - With Cross The Streams Mix, you need to hold both the Intensify and Barrel Wing Button at the same time. Releasing the Barrel Wing Button will end crossing the streams but continue firing a regular proton stream, and releasing Intensify will end firing completely.

To enable Cross The Streams (CTS) or Cross The Streams Mix (CTS Mix) mode by default, you can set this setting from the Wand Settings Menu System.

## Neutrona Wand Menu System



### Entering The Menu System

There are 2 ways to enter the Menu System.

- When the Neutrona Wand is in Video Game Mode and powered on, cycle through the various modes with the **Barrel Wing Button** until you reach the Menu System.
- While the Neutrona Wand and Proton Pack are powered down, press the **Barrel Wing Button**.

## Navigation

Use the Top Dial on the top of the wand to navigate up and down through the menu system.



When you are in the settings menu system the bargraph's 5 LEDs begin flashing (or 5 distinct segments when using the 28-segment bargraph). All other functions of the wand (such as firing) are temporarily disabled while in the menu system. There are 5 different menu settings, which are indicated by bargraph LED segments 1 through 5 (from bottom to top) with menu level 5 being the default upon entering this mode. For example in navigation, when 1 LED (or bargraph segment) is flashing/displayed that means you are on menu 1.

## Actions

Changes are made by pressing either the `Intensify` button on the gun box or the `Barrel Wing Button` at the end of the wand.

**Menu Level 1**

Option	Purpose	Intensify Button	Barrel Wing Button
5	Music Track Looping	Enable/disable looping of current track <sup>1</sup>	Exit the menu system <sup>2</sup>
4	Proton Pack Light Dimming	(Intensify + Top Dial) Increases/Decreases the Proton Pack device LED brightness	Toggles between Power Cell, Cyclotron, or Inner Cyclotron devices
3	Music & Effects Volume	(Intensify + Top Dial) Increases/Decreases Music Volume	(Barrel Wing Button + Top Dial) Increases/Decreases Effects Volume
2	Switch Music Track	Cycle forward in music queue	Cycle backwards in music queue
1	Play or Stop Music / System Mute	Start/stop playing of music	Mute the Proton Pack and Neutrona Wand or revert back to the previous volume <sup>3</sup>

<sup>1</sup> Note that the LED/segment #5 will stay solid when the single-track loop is enabled while in the top menu system; it will blink on/off when looping is disabled.


<sup>2</sup> When you navigate back to the Option 5 while in Video Game Mode and press the Barrel Wing Button, the wand will return the proton stream mode (accompanied by an audio cue to indicate this return to firing readiness). When in CTS mode this will exit the menu and allow the wand to be powered on. Note that music will continue to play (and advance/loop) even when the pack and wand are turned off.

<sup>3</sup> Note that the LED/segment #1 will stay solid when the Proton Pack and Neutrona Wand volume is muted.

## Menu Level 2

 **Note:** The Neutrona Wand Menu Level 2 can only be reached while Cyclotron is turned off in Proton Pack.

To access the Menu Level 2, use the **Top Dial** on the top of the wand to move down and past option 1 on Menu Level 1. When you reach the next menu level, the Slo-Blo LED will light up to indicate this menu state and also audio cues from the system.



Option	Purpose	Intensify Button	Barrel Wing Button
5	Firing Mode Selection	Cycle through VG/CTS operation modes <sup>4</sup>	Cycle through VG color modes <sup>5</sup>
4	Smoke/Overheat Toggles	Enable/Disable Smoke Effects	Enable/Disable Overheating
3	Cyclotron LED Control	Change Cyclotron Rotation	Toggle between 1 (centered) or 3 LEDs in the Cyclotron Lid for 1984/1989 modes
2	Vibration Settings	Enable/Disable Proton Pack vibration or vibration during firing	Enable/Disable Neutrona Wand vibration or vibration during firing
1	Year Mode Selection	Cycle through Afterlife (2021), 1984, or 1989 modes	Enable/Disable the Proton Stream impact sound effects

<sup>4</sup> Switch between Video Game and Cross the Streams (CTS) operation modes. Note that the LED/segment #5 will stay solid when CTS is enabled while in the sub menu system. Remember that CTS Mix requires holding down both intensify and the alternate firing button at the same time.

<sup>5</sup> Enables/disables the video game colour modes for the Proton Pack's Power Cell and Cyclotron lights. This only affects the pack when in Video Game mode, not for CTS modes, and offers the following states:

- Disable all the video game colours (Power Cell remains blue, Cyclotron remains red).
- Enable only the Power Cell LEDs to change colors (requires RGB Power Cell such as that offered by Frutto Technology).
- Enable only the Cyclotron LEDs to change colors (requires RGB replacement such as a Neopixel ring).
- Enable both the Power Cell and Cyclotron to use video game colours.

To exit the menu system, navigate to the top menu in Option 5 (Slo-blo LED is no longer illuminated) and press the Barrel Wing Button. A small beep will be heard when transitioning between the top and sub menu levels.

## Additional Resources

### EEPROM Menu Guide


Please view the [supplemental operation guide for EEPROM menus](#) which can be used to alter hardware configurations and to set user preferences which will persist across battery power-down events.

### PDF Operational Guide

(Direct Download link) [gpstar Operational Guide \[pdf\]](#)

## Video Demos

Video Demo: [Features and Menu Walkthrough](#) (YouTube, July 2023)



Wand Menu Settings Video Demo: [Proton Pack Wand Menu Settings Video Demo](#) (YouTube)



## Disclaimer

This community-driven project is independent and not affiliated with, endorsed by, or sponsored by Hasbro Inc., Ghost Corps, or Sony Pictures. Hasbro Inc. does not endorse or support this project, and any views or opinions expressed within the project are those of the individual contributors and not necessarily those of Hasbro Inc.

Participants in this project should be aware that it is entirely separate from any official activities or initiatives of Hasbro Inc.. Any use of Hasbro Inc.'s name or its products within this project is purely for informative purposes and does not imply any form of partnership, endorsement, or association with Hasbro Inc.

Individuals involved in this project are responsible for their own actions, and Hasbro Inc. bears no responsibility for the content, decisions, or outcomes related to this community-driven effort.

By participating in this project, individuals acknowledge that it is an independent initiative and that Hasbro Inc. is not responsible for the project's development, management, or outcomes.

This disclaimer is subject to change, and individuals are encouraged to check for updates regularly.