EXPERIMENT - 1.4

Breathing led with nRF dev Board

What will you learn from this module:

Blink external led using nRF development kit.

Requirements:


- > nRF connect desktop software.
- > nRF Command line tools.
- Visual studio code.
- USB cable.
- > nRF 52832 board.
- LED's.

Prerequisites:


- ➤ Basic knowledge of C/C++
- ➤ Basic knowledge of communication protocol.
- Basic project setup.


Setup and Configuration:


➤ Open VS Code and go to browse sample and search WS2812.




Click on create new build configuration here you can change the board version, if you are using nRF 52832 then you can change from there for another version like nRF52833 etc.








- ➤ Go to source file, inside source file > Application > src > main.c .
- > click on main.c file and you will see the code will appear on your vs code.



To configure prj.conf go to the Config files > Kconfig > prj.conf as shown in figure




➤ For configure WS2812 led you need to enable i2s in overlay files Config files > device tree > overlay as shown in the figure.

```
★ File Edit Selection View Go …
                                                                                                                                                                              👫 nrf52dk_nrf52832.dts 🎉 nrf52dk_nrf52832-pinctrl.dtsi 🐧 nrf52dk_nrf52832.overlay 🐧 nrf52dk_nrf52832.overlay X 🗘 prj.conf
      NRF CONNECT
      Manage west workspace v2.4.2
                                                                                                                                       4
     V APPLICATIONS
0
                                           i2s_led: &i2s0 {
    status = "okay";
    pinctrl-0 = <&i2s0 default alt>;
    pinctrl-names = "default";
        build nRF52 DK NRF52832
     ∨ LED_WS2812 build


∨ ☐ Config files

                                               led_strip: ws2812 {
    compatible = "worldsemi,ws2812-i2s";
       > ∰ Kconfig
       ✓ ¾ Devicetree
                                                  nrf52dk_nrf52832.d
     > NRF52DK NRF52832
                                                  reset-delay = <500>;
      ♣ Debua
     ച്ച് Devicetree Overla
```

- Run the build configuration again.
- Then flash the code in nRF dev kit.



❖ PIN CONFIGURATION OF WS2812 LED WITH THE BOARD



OUTPUT

A "breathing LED" is a phenomenon where an LED's brightness smoothly changes from dark to bright and back to dark, continuing to do so and giving the illusion of led "breathing".

