آشنایی با زبان AVR C تبدیل انواع داده

Dr. Aref Karimiafshar A.karimiafshar@ec.iut.ac.ir



BCD Code

- BCD (Binary coded decimal) number system
 - Binary representation of 0 to 9
 - Because in everyday life we use the digits 0 to 9
- BCD
 - Unpacked BCD
 - Packed BCD

Digit	BCD
0	0000
1	0001
2	0010
3	0011
4	0100
5	0101
6	0110
7	0111
8	1000
9	1001

BCD Code

Unpacked BCD

In unpacked BCD, the lower 4 bits of the number represent the BCD number, and the rest of the bits are 0. For example, "0000 1001" and "0000 0101" are unpacked BCD for 9 and 5, respectively. Unpacked BCD requires 1 byte of memory, or an 8-bit register, to contain it.

Packed BCD

In packed BCD, a single byte has two BCD numbers in it: one in the lower 4 bits, and one in the upper 4 bits. For example, "0101 1001" is packed BCD for 59H. Only 1 byte of memory is needed to store the packed BCD operands. Thus, one reason to use packed BCD is that it is twice as efficient in storing data.

ASCII Numbers

- On ASCII keyboards, when the key "0" is activated
 - "0110000" (30H) is provided to the computer

ASCII and BCD Codes for Digits 0-9

Key	ASCII (hex)	Binary	BCD (unpacked)
0	30	011 0000	0000 0000
1	31	011 0001	0000 0001
2	32	011 0010	0000 0010
3	33	011 0011	0000 0011
4	34	011 0100	0000 0100
5	35	011 0101	0000 0101
6	36	011 0110	0000 0110
7	37	011 0111	0000 0111
8	38	··· 011 1000	0000 1000
9	39	011 1001	0000 1001

Packed BCD to ASCII Conversion

- In many systems, we have RTC (real time clock)
 - The RTC provides
 - The time of day (hour, minute, second)
 - The date (year, month, day)

Continuously and regardless of whether the power is on or off

- This data is provided in packed BCD
 - To be displayed on a device such as LCD
 - It must be in ASCII format
- To convert packed BCD to ASCII
 - First, convert it to unpacked BCD
 - Then, unpacked BCD is tagged with 011 0000 (30H)

Packed BCD	Unpacked BCD	ASCII
29H	02H & 09H	32H & 39H
0010 1001	0000 0010 &	0011 0010 &
	0000 1001	0011 1001

Packed BCD to ASCII Conversion

Write an AVR C program to convert packed BCD 0x29 to ASCII and display the bytes on PORTB and PORTC.

```
#include <avr/io.h>
                                     //standard AVR header
int main(void)
  unsigned char x, y;
  unsigned char mybyte = 0x29;
  DDRB = DDRC = 0xFF;
                                     //make Ports B and C output
                                    //mask upper 4 bits
  x = mybyte & 0x0F;
  PORTB = x + 0x30:
                                     //make it ASCII
  y = mybyte & 0xF0;
                                     //mask lower 4 bits
  y = y >> 4;
                                    //shift it to lower 4 bits
                                     //make it ASCII
  PORTC = y \mid 0x30;
  return 0:
```

ASCII to Packed BCD Conversion

- To convert ASCII to packed BCD
 - First, convert it to unpacked BCD
 - Then, combine it to make packed BCD

Key	ASCII	Unpacked BCD	Packed BCD
4	34	00000100	
7	37	00000111	01000111 which is 47H

ASCII to Packed BCD Conversion

Write an AVR C program to convert ASCII digits of '4' and '7' to packed BCD and display them on PORTB.

```
//standard AVR header
#include <avr/io.h>
int main(void)
  unsigned char bcdbyte;
  unsigned char w = '4';
  unsigned char z = '7';
                              //make Port B an output
  DDRB = 0xFF;
                              //mask 3
  w = w & 0x0F;
                             //shift left to make upper BCD digit
  w = w << 4;
                             //mask 3
  z = z & 0x0F;
                              //combine to make packed BCD
  bcdbyte = w \mid z;
  PORTB = bcdbyte;
  return 0:
```

- To ensure the integrity of data
 - Systems must perform the checksum calculation
- We perform checksum calculation
 - When transmit data from one device to another
 - When save or restore data to a storage device
- The checksum will detect any corruption of data
- Checksum process uses what is called
 - Checksum byte
 - The extra byte that is tagged to the end of a series of bytes of data

- To calculate checksum byte of a series of bytes of data
 - Add the bytes together and drop the carries
 - Take the 2's complement of the total sum. This is the checksum byte, which becomes the last byte of the series
- To perform the checksum operation
 - Add all the bytes, including the checksum byte
 - The result must be zero
 - If it is not zero, one or more bytes of data have been changed

Assume that we have 4 bytes of hexadecimal data: 25H, 62H, 3FH, and 52H.

(a) Find the checksum byte, (b) perform the checksum operation to ensure data integrity, and (c) if the second byte, 62H, has been changed to 22H, show how checksum detects the error.

(a) Find the checksum byte.

```
25H
+ 62H
+ 3FH
+ 52H
1 18H (dropping carry of 1 and taking 2's complement, we get E8H)
```

(b) Perform the checksum operation to ensure data integrity.

```
25H
+ 62H
+ 3FH
+ 52H
+ E8H
2 00H (dropping the carries we get 00, which means data is not corrupted)
```

Assume that we have 4 bytes of hexadecimal data: 25H, 62H, 3FH, and 52H.

- (a) Find the checksum byte, (b) perform the checksum operation to ensure data integrity, and (c) if the second byte, 62H, has been changed to 22H, show how checksum detects the error.
- (c) If the second byte, 62H, has been changed to 22H, show how checksum detects the error.
 - 25H
 - + 22H
 - + 3FH
 - + 52H
 - + E8H
 - 1 COH (dropping the carry, we get COH, which means data is corrupted)

Checksum byte

Write an AVR C program to calculate the checksum byte for the data: 25H, 62H, 3FH, and 52H.

```
//standard AVR header
#include <avr/io.h>
int main(void)
     unsigned char mydata[] = \{0x25,0x62,0x3F,0x52\};
     unsigned char sum = 0;
     unsigned char x;
     unsigned char chksumbyte;
                             //make Port A output
     DDRA = 0xFF;
     DDRB = 0xFF;
                              //make Port B output
                              //make Port C output
     DDRC = 0xFF;
     for (x=0; x<4; x++)
          sum = sum + mydata[x]; //add them together
          PORTB = sum; //issue the sum to PORTB
     chksumbyte = ~sum + 1; //make 2's complement (invert +1)
     PORTC = chksumbyte; //show the checksum byte
     return 0;
```

Checksum byte

Write a C program to perform the checksum operation. If the data is good, send ASCII character 'G' to PORTD. Otherwise, send 'B' to PORTD.

```
#include <avr/io.h>
                                    //standard AVR header
int main (void)
   unsigned char mydata[] = \{0x25,0x62,0x3F,0x52,0xE8\};
   unsigned char chksum = 0;
   unsigned char x;
                                    //make Port D an output
   DDRD = 0xFF:
   for (x=0; x<5; x++)
     if(chksum == 0)
     PORTD = 'G';
   else
      PORTD = 'B':
   return 0:
```

Binary (hex) to decimal and ASCII

The printf function is part of the standard I/O library in C and can do many things including converting data from binary (hex) to decimal, or vice versa. But printf takes a lot of memory space and increases your hex file substantially. For this reason, in systems based on the AVR microcontroller, it is better to know how to write our own conversion function instead of using printf.

One of the most widely used conversions is binary to decimal conversion. In devices such as ADCs (Analog-to-Digital Converters), the data is provided to the microcontroller in binary. In some RTCs, the time and dates are also provided in binary. In order to display binary data, we need to convert it to decimal and then to ASCII. Because the hexadecimal format is a convenient way of representing binary data, we refer to the binary data as hex. The binary data 00–FFH converted to decimal will give us 000 to 255. One way to do that is to divide it by 10 and keep the remainder,

<u>Hex</u>	Quotient	Remainder
FD/0A	19	3 (low digit) LSD
19/0A	2	5 (middle digit)
		2 (high digit) (MSD)

Binary (hex) to decimal and ASCII

Write an AVR C program to convert 11111101 (FD hex) to decimal and display the digits on PORTB, PORTC, and PORTD.

```
//standard AVR header
#include <avr/io.h>
int main(void)
    unsigned char x, binbyte, d1, d2, d3;
    DDRB = DDRC = DDRD =0xFF; //Ports B, C, and D output
                                //binary (hex) byte
    binbvte = 0xFD;
    x = binbyte / 10; //divide by 10
                               //find remainder (LSD)
    d1 = binbyte % 10;
                                 //middle digit
    d2 = x % 10:
                                 //most-significant digit (MSD)
    d3 = x / 10:
    PORTB = d1;
    PORTC = d2;
    PORTD = d3;
    return 0:
```

Data type conversion functions in C

Many compilers have some predefined functions to convert data types. To use these functions, the stdlib.h file should be included.

Notice that these functions may vary in different compilers.

Data Type Conversion Functions in C

Function signature	Description of functions
int atoi(char *str)	Converts the string str to integer.
long atol(char *str)	Converts the string str to long.
void itoa(int n, char *str)	Converts the integer n to characters in string str.
void ltoa(int n, char *str)	Converts the long n to characters in string str.
float atof(char *str)	Converts the characters from string str to float.

Serializing data is a way of sending a byte of data one bit at a time through a single pin of a microcontroller. There are two ways to transfer a byte of data serially:

- 1. Using the serial port. In using the serial port, the programmer has very limited control over the sequence of data transfer.
- 2. The second method of serializing data is to transfer data one bit a time and control the sequence of data and spaces between them. In many new generations of devices such as LCD, ADC, and EEPROM, the serial versions are becoming popular because they take up less space on a printed circuit board. Although we can use standards such as I²C, SPI, and CAN, not all devices support such standards. For this reason we need to be familiar with data serialization using the C language.

Write an AVR C program to send out the value 44H serially one bit at a time via PORTC, pin 3. The LSB should go out first.

```
#include <avr/io.h>
#define serPin 3
int main(void)
    unsigned char conbyte = 0x44;
    unsigned char regALSB;
    unsigned char x;
    regALSB = conbyte;
    DDRC \mid = (1 <  serPin);
   for(x=0;x<8;x++)
         if (regALSB & 0x01)
             PORTC |= (1<<serPin);
        else
            PORTC &= \sim (1 << serPin);
         regALSB = regALSB >> 1;
      return 0:
```

Write an AVR C program to send out the value 44H serially one bit at a time via PORTC, pin 3. The MSB should go out first.

```
#include <avr/io.h>
#define serPin 3
int main (void)
    unsigned char conbyte = 0x44;
    unsigned char regALSB;
    unsigned char x;
    regALSB = conbyte;
    DDRC |= (1<<serPin);
    for(x=0;x<8;x++)
      if (regALSB & 0x80)
           PORTC |= (1<<serPin);
       else
           PORTC &= ~(1<<serPin);
        regALSB = regALSB << 1;
     return 0;
```

Write an AVR C program to bring in a byte of data serially one bit at a time via PORTC, pin 3. The LSB should come in first.

Write an AVR C program to bring in a byte of data serially one bit at a time via PORTC, pin 3. The MSB should come in first.

Flash, RAM and EEPROM memory allocation in C

- Different C compiler
 - May have their built-in functions or directives to access each type of memory
- In codeVision
 - To define a constant variable in Flash
 - Put FLASH directive before it
 - To define a variable in EEPROM
 - Put EEPROM directive in front of it

EEPROM access in C

Write an AVR C program to store 'G' into location 0x005F of EEPROM.

EEPROM access in C

Write an AVR C program to read the content of location 0x005F of EEPROM into PORTB.

پایان

موفق و پیروز باشید