Intro to: Inter-Processor Communications (IPC)

Agenda

- Basic Concepts
- **♦ IPC Services**
- Setup and Examples
- **♦** IPC Transports
- ◆ Lab or Demo

Basic Concepts


- Basic Concepts
- ◆ IPC Services
- Setup and Examples
- **♦** IPC Transports
- Lab or Demo

IPC – Definition

- ◆ IPC = Inter-Processor Communication
- While this definition is rather generic, it really means:

"Transporting data and/or signals between threads of execution"


These threads could be located anywhere:



How would YOU solve this problem?

IPC – Possible Solutions


- How do you transport the data and signal?
 - Manual: Develop your own protocol using device resources
 - Auto: Using existing RTOS/Framework Utilities (i.e., IPC)



What solutions exist in TI's RTOS to perform IPC?


IPC – RTOS/Framework Solutions

- ◆ SAME CorePac: TI's RTOS (SYS/BIOS) supports several services for inter-thread communication (e.g. semaphores, queues, mailboxes, etc.).
- DIFFERENT CorePac: The IPC framework supports communications between CorePacs via several transports.
- DIFFERENT DEVICE: IPC transports can also be implemented between devices.
- KEY: Same IPC APIs can be used for local or remote communications.



IPC – Transports

- Current IPC implementation uses several transports:
 - CorePac → CorePac (Shared Memory Model, Multicore Navigator)
 - Device → Device (Serial Rapid I/O)
- Chosen at configuration; <u>Same code</u> regardless of thread location.




IPC Services

- Basic Concepts
- IPC Services
 - Message Queue
 - Notify
 - Data Passing
 - Support Utilities
- Setup and Examples
- **♦** IPC Transports
- Lab or Demo

IPC Services

- ◆ The IPC package is a set of APIs
- MessageQ uses the modules below ...
- But each module can also be used independently.



IPC Services – Message Queue

- Basic Concepts
- IPC Services
 - Message Queue
 - Notify
 - Data Passing
 - Support Utilities
- Setup and Examples
- **♦** IPC Transports
- Lab or Demo

MessageQ – Highest Layer API

- SINGLE reader, multiple WRITERS model (READER owns queue/mailbox)
- Supports structured sending/receiving of variable-length messages, which can include (pointers to) data
- Uses all of the IPC services layers along with IPC Configuration & Initialization
- ◆ APIs do not change if the message is between two threads:
 - On the same core
 - On two different cores
 - On two different devices
- APIs do NOT change based on transport only the CFG (init) code
 - Shared memory
 - Multicore Navigator
 - SRIO

MessageQ and Messages

- Q How does the writer connect with the reader queue?
 - A MultiProc and name server keep track of queue names and core IDs.
- Q What do we mean when we refer to structured messages with variable size?
 - A Each message has a standard header and data. The header specifies the size of payload.
- Q How and where are messages allocated?
 - A List utility provides a double-link list mechanism. The actual allocation of the memory is done by HeapMP, SharedRegion, and ListMP.
- Q If there are multiple writers, how does the system prevent race conditions (e.g., two writers attempting to allocate the same memory)?
 - A GateMP provides hardware semaphore API to prevent race conditions.
- Q What facilitates the moving of a message to the receiver queue?
 - A This is done by Notify API using the transport layer.
- Q Does the application need to configure all these modules?
 - A No. Most of the configuration is done by the system. More details later.

Using MessageQ (1/3)

CorePac 2 - READER



MessageQ_create("myQ", *synchronizer);
MessageQ_get("myQ", &msg, timeout);

- MessageQ transactions <u>begin</u> with <u>READER</u> creating a MessageQ.
- READER's attempt to get a message results in a block (unless timeout was specified), since no messages are in the queue yet.

What happens next?

Using MessageQ (2/3)

CorePac 1 - WRITER

CorePac 2 - READER

MessageQ_open ("myQ", ...); msg = MessageQ_alloc (heap, size,...); "myQ" MessageQ_put("myQ", msg, ...); Heap

MessageQ_create("myQ", ...); MessageQ_get("myQ", &msg...);

- WRITER begins by opening MessageQ created by READER.
- WRITER gets a message block from a heap and fills it, as desired.
- WRITER puts the message into the MessageQ.

How does the READER get unblocked?


Using MessageQ (3/3)

CorePac 1 - WRITER CorePac 2 - READER MessageQ_open ("myQ", ...); MessageQ_create("myQ", ...); msg = MessageQ_alloc (heap, size,...); "myQ" MessageQ_get("myQ", &msg...); MessageQ_put("myQ", msg, ...); *** PROCESS MSG *** MessageQ_close("myQ", ...); - MessageQ_free("myQ", ...); MessageQ_delete("myQ", ...); Heap

- Once WRITER puts msg in MessageQ, READER is unblocked.
- ◆ READER can now read/process the received message.
- READER frees message back to Heap.
- ◆ READER can optionally delete the created MessageQ, if desired.

MessageQ – Configuration

- All API calls use the MessageQ module in IPC.
- User must also configure MultiProc and SharedRegion modules.
- All other configuration/setup is performed automatically by MessageQ.



MessageQ – Miscellaneous Notes

- O/S independent:
 - If one CorePac is running LINUX and using SysLink, the API calls do not change.
 - SysLink is runtime software that provides connectivity between processors (running Linux, SYSBIOS, etc.)
- Messages can be allocated statically or dynamically.
- Timeouts are allowed when a task receives a message.
- User can specify three priority levels:
 - Normal
 - High
 - Urgent

More Information About MessageQ

All structures and function descriptions can be found within the release:


\ipc_U_ZZ_YY_XX\docs\doxygen\html_message_q_8h.html

IPC Services - Notify

- Basic Concepts
- IPC Services
 - Message Queue
 - Notify
 - Data Passing
 - Support Utilities
- Setup and Examples
- **♦** IPC Transports
- Lab or Demo

Using Notify – Concepts

- In addition to moving MessageQ messages, Notify:
 - Can be used independently of MessageQ
 - Is a simpler form of IPC communication
 - Is used ONLY with shared memory transport



Notify Model

- Comprised of SENDER and RECEIVER.
- ◆ The SENDER API requires the following information:
 - Destination (SENDER ID is implicit)
 - 16-bit Line ID
 - 32-bit Event ID
 - 32-bit payload (For example, a pointer to message handle)
- ◆ The SENDER API generates an interrupt (an event) in the destination.
- Based on Line ID and Event ID, the RECEIVER schedules a predefined call-back function.

Notify Model

Sender

Receiver

During initialization, link the Event ID and Line ID with call back function.

Void Notify registerEvent(srcId, lineId, eventId, cbFxn, cbArg);

During run time, the Sender sends a notify to the Receiver.

Void Notify_sendEvent(dstId, lineId, eventId, payload, waitClear);

·INTERRUPT·

Based on the Sender's Source ID, Event ID, and Line ID, the call-back function that was registered during initialization is called with the argument payload.

Notify Implementation

- Q How are interrupts generated for shared memory transport?
 - A The IPC hardware registers are a set of 32-bit registers that generate interrupts. There is one register for each core.
- Q How are the notify parameters stored?
 - A List utility provides a double-link list mechanism. The actual allocation of the memory is done by HeapMP, SharedRegion, and ListMP.
- Q How does the notify know to send the message to the correct destination?
 - A MultiProc and name server keep track of the core ID.
- Q Does the application need to configure all these modules?
 - A No. Most of the configuration is done by the system.

Example Callback Function

```
===== cbFxn ======
* This fxn was registered with Notify. It is called when any event is sent to this CPU.
Uint32 recvProcld;
Uint32 seq
void cbFxn(UInt16 procld, UInt16 lineId, UInt32 eventId, UArg arg, UInt32 payload)
  /* The payload is a sequence number. */
  recvProcld = procld;
  seq = payload;
  Semaphore_post(semHandle);
```

More Information About Notify

All structures and function descriptions can be found within the release:

\ipc_U_ZZ_YY_XX\docs\doxygen\html_notify_8h.html

IPC Services - Data Passing

- Basic Concepts
- IPC Services
 - Message Queue
 - Notify
 - Data Passing
 - Support Utilities
- Setup and Examples
- **♦** IPC Transports
- Lab or Demo

Data Passing Using Shared Memory (1/2)


- When there is a need to allocate memory that is accessible by multiple cores, shared memory is used.
- However, the MPAX register for each core might assign a different logical address to the same physical shared memory address.
- ◆ The Shared Region module provides a translation look-up table that resolves the logical/physical address issue <u>without user</u> intervention.

Data Passing Using Shared Memory (2/2)

- Messages are created and freed, but not necessarily in consecutive order:
 - HeapMP provides a dynamic heap utility that supports create and free based on double link list architecture.
 - ◆ ListMP provides a double link list utility that makes it easy to create and free messages for static memory. It is used by the HeapMP for dynamic cases.
- To protect the above utilities from race conditions (e.g., multiple cores try to create messages at the same time):
 - GateMP provides hardware semaphore protection.
 - GateMP can also be used by non-IPC applications to assign hardware semaphores.


Data Passing – Static

- Data Passing uses a double linked list that can be shared between CorePacs; Linked list is defined STATICALLY.
- ListMP handles address translation and cache coherency.
- GateMP protects read/write accesses.
- ListMP is typically used by MessageQ not by itself.



Data Passing – Dynamic

- Data Passing uses a double linked list that can be shared between CPUs. Linked list is defined DYNAMICALLY (via heap).
- Same as previous, except linked lists are allocated from Heap
- Typically not used alone but as a building block for MessageQ



Data Passing: Additional Transports

- Multicore Navigator
 - Messages are assigned to descriptors.
 - Monolithic descriptors provide a pointer to the message.
- SRIO Type 11 has a TI-developed message protocol that moves data and interrupts between devices.
- Implementation of these transports will be discussed later.

IPC Services – Support Utilities

- Basic Concepts
- IPC Services
 - Message Queue
 - Notify
 - Data Passing
 - Support Utilities
- Setup and Examples
- ◆ IPC Transports
- Lab or Demo

IPC Support Utilities (1/2)

- IPC contains several utilities, most of which do NOT need to be configured by the user.
- Here is a short description of each IPC utility:

IPC

- Initializes IPC subsystems:
 - Applications using IPC must call IPC_start().
 - In the configuration file, setupNotify and setupMessageQ specify whether to set up these IPC modules.

MultiProc

Manages processor IDs and core names

SharedRegion

- Manages shared memory using HeapMemMP allocator
- Handles address translation for shared memory regions

More utilities...

IPC Support Utilities (2/2)

- IPC contains several utilities, most of which do NOT need to be configured by the user.
- Here is a short description of each IPC utility:

ListMP

- Provides linked list in shared memory
- Uses multi-processor gate (GateMP) to prevent collisions on lists

GateMP

 Multi-processor gate that provides local (against other threads on local core) and remote context protection

HeapMemMP

- Traditional heap; Supports variable-sized alloc/free
- All allocations are aligned on cache line boundaries.

Setup and Examples


- Basic Concepts
- ◆ IPC Services
- Setup and Examples
- **♦** IPC Transports
- Lab or Demo

IPC - Tools/Setup Required

- IPC is a package (library) that is installed with the MCSDK.
 Note: Installing IPC independent of MCSDK is strongly discouraged.
- ◆ IPC also requires SYS/BIOS (threading) and XDC tools (packaging) installed with the MCSDK (supported by SYS/BIOS ROV and RTA).


TEXAS INSTRUMENTS

 IPC is supported on the latest KeyStone multicore devices (C667x, C665x), as well as C647x and ARM+DSP devices.



IPC – Examples

- IPC examples are installed along with the MCSDK in the PDK folder.
- Simply import these projects into CCS and analyze them.
- Some users start with this example code and modify as necessary.



IPC Transports

- Basic Concepts
- **◆ IPC Services**
- Setup and Examples
- **♦ IPC Transports**
- ◆ Lab or Demo

IPC Transports – Intro

An IPC TRANSPORT is a ...

"combination of physical H/W and *driver code* that allows two threads to communicate on the same device or across devices."

◆ IPC supports three different transports:

Shared Memory

- This is the default transport.
- Uses on-chip shared memory resources and interrupt lines to signal the availability of data

Multicore Navigator

- Available on all KeyStone SoC devices
- Uses queues and descriptors plus built-in signaling to transmit/receive data and messages between threads

SRIO

- Hardware serial peripheral that connects two or more DEVICES together
- For MessageQ, only the configuration (init) code changes.
 All other code (e.g., put/get) remains unchanged.

Data Passing Using Multicore Navigator

The Multicore Navigator:


- Is an innovative packet-based infrastructure that facilitates data movement and multicore control
- Provides a highly efficient inter-core communication mechanism
- Provides H/W queues and packet DMA that are the basic building blocks for IPC

Examples of required init/CFG code are provided with the MCSDK.

Now consider the Multicore Navigator implementation ...


IPC Transports - Multicore Navigator (1/3)

- MessageQ_alloc allocates a heapMP buffer for the MessageQ_msg from MSMC
- The buffer contains the MessageQ_Header plus the data.
- When MessageQ_Put is called with the MessageQ_msg, it also calls the TransportQmss function NotifyQmss_sendEvent.




IPC Transports – Multicore Navigator (2/3)

- The TransportQmss function NotifyQmss_sendEvent
 - gets a descriptor
 - Adds the pointer to the MessageQ_msg (located in MSMC and containing the data) to the descriptor.
 - Qmss_queuePush pushes the descriptor into a queue.




IPC Transports – Multicore Navigator (3/3)

- The Interrupt generator queue calls notifyDriverQmss_isr.
- The ISR schedules a QMSS receive descriptor that sends a message to the queue of Receiver.




IPC Transports – SRIO (1/3)

- The SRIO (Type 11) transport enables MessageQ to send data between tasks, cores and devices via the SRIO IP block.
- Refer to the MCSDK examples for setup code required to use MessageQ over this transport.




IPC Transports – SRIO (2/3)

- From a messageQ standpoint, the SRIO transport works the same as the QMSS transport. At the transport level, it is also somewhat the same.
- The SRIO transport copies the messageQ message into the SRIO data buffer.
- It will then pop a SRIO descriptor and put a pointer to the SRIO data buffer into the descriptor.



IPC Transports – SRIO (3/3)

- The transport then passes the descriptor to the SRIO LLD via the Srio_sockSend API.
- SRIO then sends and receives the buffer via the SRIO PKTDMA.
- ◆ The message is then queued on the Receiver side.



Configure the Transport Layer

- Most of the transport changes are in the CFG file.
- ◆ The XDC tools build the configuration and initialization code. User involvement is only in changing the CFG file.
- Some additional include and initialization is needed in the code.

Now consider the differences between shared memory and Navigator transport from the application perspective ...

Configuration: Shared Memory CFG File

Configuration: Navigator CFG File

```
var MessageQ = xdc.useModule('ti.sdo.ipc.MessageQ');
var Ipc
                            = xdc.useModule('ti.sdo.ipc.Ipc');
var TransportQmss = xdc.useModule('ti.transport.ipc.qmss.transports.TransportQmss');
/* use IPC over QMSS */
MessageQ.SetupTransportProxy = xdc.useModule(Settings.getMessageQSetupDelegate());
var TransportQmssSetup =
   xdc.useModule('ti.transport.ipc.qmss.transports.TransportQmssSetup');
MessageQ.SetupTransportProxy = TransportQmssSetup;
TransportQmssSetup.descMemRegion = 0;
Program.global.descriptorMemRegion = TransportQmssSetup.descMemRegion;
Program.global.numDescriptors = 8192;
Program.global.descriptorSize = cacheLineSize; // multiple of cache line size
TransportQmss.numDescriptors = Program.global.numDescriptors;
TransportQmss.descriptorIsInSharedMem = true;
TransportQmss.descriptorSize = Program.global.descriptorSize;
```

Configuration: SRIO CFG File

```
var MessageQ = xdc.useModule('ti.sdo.ipc.MessageQ');
var Ipc = xdc.useModule('ti.sdo.ipc.Ipc');
var TransportSrio = xdc.useModule('ti.transport.ipc.srio.transports.TransportSrio');
/* use IPC over SRIO */
MessageQ.SetupTransportProxy = xdc.useModule(Settings.getMessageQSetupDelegate());
var TransportSrioSetup =
   xdc.useModule('ti.transport.ipc.srio.transports.TransportSrioSetup');
MessageQ.SetupTransportProxy = TransportSrioSetup;
TransportSrioSetup.messageQHeapId = 1; /* Sized specifically to handle receive side packets.
                                        * Heap should
                                        * not be used by any other application or module */
TransportSrioSetup.descMemRegion = 0;
TransportSrioSetup.numRxDescBuffs = 256; /* Should be sized large enough so that multiple
                                           * packets can be gueued on receive side and still
                                           * have buffs available for incoming packets */
```

Configuration: Navigator Initialization (1/2)

Additional Include:

```
/* QMSS LLD*/
#include <ti/drv/qmss/qmss_drv.h>
#include <ti/drv/qmss/qmss_firmware.h>

/* CPPI LLD */
#include <ti/drv/cppi/cppi_drv.h>

#include <ti/transport/ipc/examples/common/bench_common.h>

#include <ti/transport/ipc/qmss/transports/TransportQmss.h>
```

Configuration: Navigator Initialization (2/2)

Add an initialization routine:

```
Int main(Int argc, Char* argv[])
{
  if (selfId == 0)
    /* QMSS, and CPPI system wide initializations are run on
      * this core */
   result = systemInit();
    if (result != 0)
    System printf("Error (%d) while initializing QMSS\n", result);
//
    Note that systemInit is provided by TI
```

TEXAS INSTRUMENTS

IPC Transport Details

Throughput (Mb/second)

Message Size (Bytes)	Shared Memory	Multicore Navigator	SRIO	
48	23.8	34.6	4.1	
256	125.8	184.4	21.2	
1024	503.2	737.4	-	

Benchmark Details

- IPC Benchmark Examples from MCSDK
- CPU Clock 1 GHz
- Header Size- 32 bytes
- SRIO Loopback Mode
- Messages allocated up front

IPC Transport Pros/Cons

	PROS	CONS
Shared Memory	 Simplest to Implement Moderate Throughput 	 Single Device Only Requires Notify module and API call if doorbell required Possible contention with other tasks using the same shared memory.
Multicore Navigator	 Highest Throughput Dedicated resources Consumes least CPU cycles Interrupt generated when data is available 	• Single Device Only
SRIO	•Can be used across devices	• Lowest Throughput

Lab/Demo

- Basic Concepts
- **◆ IPC Services**
- Setup and Examples
- **◆ IPC Transports**
- ◆ Lab or Demo

