

#### AN204780

# F<sup>2</sup>MC-16FX Family, Stepper Motor Controller

This application note describes the functionality and usage of the SMCs.

## **Contents**

1 Int	roduction1		2.3	Code	5
2 Ste	epper Motor1	3	Add	litional Information	10
2.1	Stepper Motor physics1	4	Doc	cument History	11
2.2	Control Theory3				

## 1 Introduction

The MB96380 Series of MCUs features Stepper Motor Controllers (SMC). The function and usage of the SMCs is explained in this application note. For a full understanding, the functioning of a Stepper Motor is considered.


# 2 Stepper Motor

The SMC can easily be used for very smooth movement of a stepper motor as for example an indication application. Therefore the physical characteristics and properties have to be well known and understood.

## 2.1 Stepper Motor physics

For operation it might be useful to have a small introduction, what happens with the physics. In this explanation, we will use a simple replacement model for the stepper motor as a replacement circuitry. It represents the rotor as one bipolar magnet and two coils which are arranged perpendicular to each other as the stator (Figure 1).

Figure 1. Replacement circuit for Stepper Motor




To meet the necessities of a really smooth movement, we have to insure that the torque moment is constant while the whole movement is performed. The preparation of this is done by adding the single coil components in a geometrical manner to a constant result (Figure 2).

Normally to realize this, we use sine and cosine components for each coil. Therefore, with this model, we can position the rotor in each random position with the same torque moment.




Figure 2. Torque Moment calculation



For a movement, we have to perform a follow up of positions between a Start and a Stop position. While controlling usual stepper motors as real stepping devices, this is done with a step by step method (Figure 3). So, the movement has constant speed while moving. That is not suitable for smooth movement, e.g. if the motor arrives at the stop position it stops then abruptly.

Figure 3: Without filter, with 1st order LP filter, and with 2nd order LP filter



To improve this, a low-pass filter is used. The low-pass filter solves the problem at the stop point (Figure 3). Nevertheless, the same problem exists at the starting point. To solve this, we use a second order low-pass filter. The second order low-pass filter solves the problem at the start point (Figure 3), but it sets up the necessities of a maximum Speed and a max. Acceleration, which depends on the way of the movement.

Otherwise the motor itself has a physically given maximum speed and acceleration. To insure that the required properties do not overtake the given physics, we use an acceleration and velocity clipper. This clipper must be integrated into the 2nd order LP-filter, which must equalize the clipped edges.

The realization of a second order low-pass filter can be done by simply combining two stages of a 1st order LP-Filter. The 1st order LP-Filter can be performed by a simple mathematical formula like this:

$$PT1_{i} = \frac{Xin_{i} + (PT1_{i-1} * n)}{n+1}$$

$$PT2_{i} = \frac{PT1_{i} + (PT2_{i-1} * n)}{n+1}$$



## 2.2 Control Theory

To implement the required 2<sup>nd</sup> order LP-filter in a way to get a fast calculation of it, it is useful to perform

- 1. Y1st\_new= (((Y1st\_old<<n) -Y1st\_old) +Xin\_new) >>n
- 2. Y2nd\_new= (((Y2nd\_old<<n) -Y2nd\_old) +Y1st\_new) >>n

This way, only two shift operations and two subtractions have to be performed. This saves CPU Duty cycles.

This operation has to be performed repetitively in a given time. The difference between the new output value at this time and the last output value at the last time is the velocity. So the actual speed of the requested movement can be evaluated by a simple subtraction.

If we store the actual speed in a memory cell, we can subtract the actual speed from the speed of the last time. The result is the actual acceleration. The physical units are as follows:

$$V_{act} = \frac{\left| PT2_{i} - PT2_{i-1} \right|}{t_{2} - t_{1}} \quad \text{ And } \quad a_{act} = \frac{\left| V_{i} - V_{i-1} \right|}{t_{2} - t_{1}}$$

Or more suitable for programming:

phi\_1 - phi\_2 = d\_phi

t1 - t2 = d t

velo = d\_phi / d\_t

 $acc = (d_phi1 - d_phi2) / ((d_t) * (d_t)) ; same as dphi^2 / dt^2$ 

To clip them at a given moment, we have to check whether they reach the limits.

velo new = Y2nd new - Y2nd old

For sample we compare them to given constants. If they are beyond the limit, we replace the new output value with substitutes from the physical evaluation.

velo\_new = Y2nd\_new - Y2nd\_old

if (velo\_new - velo\_old) > max.acceleration.constant then

max.Velo.actual = velo\_old + max.acc.constant

else

max.velo.actual = max.velo.constant

endif

if velo\_new > max.velo.actual then

Y2nd\_new = Y2nd\_old + max.velo.actual

Endif


By using these equations a few hundred times per second (repetitively time is only a few milliseconds), we will succeed to earn a smooth movement of our pointer in this application.



In practical use, the damping value n should be in the range of 3.6, because of the characteristics of the 2nd order LP-filter.

As an example, we can use lookup tables to cover the line switching at the output pins for the motor. Herewith a sample of an output functions for the stepper motor macro which uses a 128 micro steps per quadrant sine and cosine lookup table. Otherwise, the given pre-set value for this function is normalized to 256 micro steps per quadrant. Therefore, we can easily change The resolution for a given application from 0..7 Bits per quadrant, simply by changing the shift operation for normalizing and fetching the sine / cosine tables with the necessary length.

CPU\_Pin : PWM2Mx  $\rightarrow$  + Coil\_B ( - COS ) CPU\_Pin : PWM2Px  $\rightarrow$  + Coil\_B ( + COS ) CPU\_Pin : PWM1Px  $\rightarrow$  + Coil\_A ( + SIN ) CPU\_Pin : PWM1Mx  $\rightarrow$  - Coil\_A ( - SIN )





#### 2.3 Code

Now we can realize this as a simple output function:

```
/* sin/cos Lookup table for microstepping */
unsigned char const SMC_TAB_CS[129]={
         0, 3, 6, 9, 13, 16, 19, 22,
        25, 28, 31, 34, 37, 41, 44, 47,
        50, 53, 56, 59, 62, 65, 68, 71,
        74, 77, 80, 83, 86, 89, 92, 95,
        98,100,103,106,109,112,115,117,
       120,123,126,128,131,134,136,139,
       142,144,147,149,152,154,157,159,
        162,164,167,169,171,174,176,178,
       180,183,185,187,189,191,193,195,
       197,199,201,203,205,207,208,210,
        212,214,215,217,219,220,222,223,
        225,226,228,229,231,232,233,234,
        236, 237, 238, 239, 240, 241, 242, 243,
        244,245,246,247,247,248,249,249,
        250, 251, 251, 252, 252, 253, 253, 253,
        254, 254, 254, 255, 255, 255, 255, 255,
        255 };
/* Lookup tables for quadrant management */
unsigned char const smc_quad_a[4]={0x02, 0x10, 0x10, 0x02};
unsigned char const smc_quad_b[4] = \{0x50, 0x50, 0x42, 0x42\};
void
       smc_out(int ustp) {
       int q,d,smc_a,smc_b;
                              /* some squeeze intermediate memories
       q=((ustp>>8) \& 3); /* normalise the over all granulation
                                   to 1024 microsteps per polpair change
        d=((ustp>>1) & 127);
                              /* normalise the inner granulation
                                   to 512 microsteps per polpair change
                                   so that the Bit0 of ustp is don't care! */
                              /* preload of sin component
       smc_a=SMC_TAB_CS[d];
       smc_b=SMC_TAB_CS[128-d];/* preload of cos component
                                    note the trick with the enlarged table,
                                    which can be used in reverse order
                               /* decide where to go whatever
        if ((q & 1)==1) {
                               /* set up the sin value for coil A
                PWC10=smc_a;
                PWC20=smc_b;
                                /* set up the cos value for coil B
                               /* otherwise change the signs
        else {
                              /* set up the cos value for coil A
                PWC10=smc_b;
                PWC20=smc_a;
                                /* set up the sin value for coil B
                              /* startover with the resource operation
/* arming the signal for coil A
/* arming the signal for coil B
       PWC0=0xE8;
       PWS10=smc_quad_a[q];
       PWS20=smc_quad_b[q];
}
```


This output driver routine is hopefully a balanced finish between minimized memory requirements and clear viewing of coding effects.


Herewith an example of a 2<sup>nd</sup> order low-pass filter interrupts service routine to support the output function for the Stepper motor.



```
void
       smc__lpf(void) {
                                             /* this tiny calculation should be done
                                             in a less part of a millisecond
       smc_old=smc_new;
                                             /* yesterdays future is passed today */
        /* first order low pass filter */
       *((int *)&smc_clc1+1)=smc_inp;
                                             /* normalise input value
       smc_clc1=(smc_clc1>>smc_dn);
       smc_clc2=(smc_pt1-(smc_pt1>>smc_dn));
       smc_pt1=smc_clc2+smc_clc1;
       /* second order low pass filter */
       smc_clc2=(smc_pt2-(smc_pt2>>smc_dn));
       smc_pt2=smc_clc2+(smc_pt1>>smc_dn);
       smc_new=*((int *)&smc_pt2+1);
                                           /* new output value
```

This 2<sup>nd</sup> order Low pass filter will work in the following manner:







Therefore, we have to use a simple acceleration and velocity clipper to support the 2nd order low-pass filter.

```
void
       smc_avclip(void) {
                                           /* limiting to the given physical values*/
       * /
               /* correction, because of velocity violation */
              smc_new=smc_old-smc_vmax; /* set up new velocity smc_clcl=-smc_vmax; /* memorise new velocity
                                            /* memorise new velocity
               *((int *)&smc_pt2+1)=smc_new; /* set up new output value
       if ( smc_clc1 > smc_vmax ) {
                                           /* test for reverse move
               /* correction, because of velocity violation
              *((int *)&smc_pt2+1)=smc_new; /* set up new output value
                                            /* actual acceleration
       smc_acc=(smc_clc1-smc_velo);
       if ( smc_acc < -smc_amax ) {</pre>
                                           /* test for acceleration
               /* correction, because of acceleration violation
              smc_clc1=smc_velo-smc_amax;  /* set up new velocity
smc_new=smc_old+smc_clc1;  /* recalculate output value
              *((int *)&smc_pt2+1)=smc_new; /* set up new output value
                                           /* test for deceleration
       if ( smc_acc > smc_amax ) {
               /* correction, because of acceleration violation
              smc_clc1=smc_velo+smc_amax; /* set up new velocity
smc_new=smc_old+smc_clc1; /* recalculate output value
              *((int *)&smc_pt2+1)=smc_new; /* set up new output value
       smc_acc =smc_clc1-smc_velo;
smc_velo=smc_clc1;
                                           /* memorisation for debugging
                                           /* memorisation for next cycle
}
```

This sample code is running in a special interrupt service routine, which should be called every few milliseconds.



Let us also assume that a potentiometer is connected to one of the ADC channel. The actual position of the rotor of potentiometer is converted into a digital data. These digital data are used as a controlling parameter for displacement of a pointer which is connected to stepper motor.

```
void adc_init(void)
         DDR05_D0 = 0;
        ADER1 = 0 \times 01;
ADECR = 0 \times 00;
                                   /* P05_0
        ADCS_MD = 0x01; /* Select single mode 2
ADCS_STS = 0x00; /* Select software trigger
ADSR_ST = 0x06; /* Sampling time 3us @ 16Mhz
ADSR_CT = 0x05; /* Sampling time 8.3us @ 16Mhz
         return;
      -----*/
int adc_sample(int chn)
         int.
                 i,y;
         ADSR_ANS = chn;
         ADSR_ANE = chn;
         y=0;
         while ((ADCSH & 0x80) != 0);
         for (i=0; i<4; i++)</pre>
                  ADCSH=0x82;
                  while ((ADCSH & 0x80) != 0);
                  y=y+ADCR;
         return (y);
void smc_init(unsigned int x) /* set up all neccesary CPU resources */
 /* initialise cpu output port for the motor */
        DDR10=0xFF; /* assign pins as output PHDR10 = 0xFF;
         PHDR10 = 0xFF;
         PWEC4 = 0x03;
 /* initialise low pass filters
         smc_inp=0; /* clear target position
         smc_pt1=0; smc_pt2=0; /* clear actual position smc_new=0; smc_old=0; /* clear actual outputs
 /* initialise variables for physical limits */
 smc_dn= 4; /* set up damping grade
smc_vmax=100; /* set up velocity limit
smc_amax= 5; /* set up acceleration limit
/* initialise reload timer 1 */
 TMRLR1 = x/2;  /* set reload value in [us]
TMCSR1 = 0x81B;  /* prescaler 2us at 16MHz
```



```
#define PWC PWC4
#define PWCA PWC14
#define PWCB PWC24
#define PWSA PWS14
#define PWSB PWS24
/*----- Global Variables -----*/
long smc_pt1, smc_pt2, smc_clc1, smc_clc2;
     smc_inp, smc_new, smc_old, smc_velo, smc_acc;
int smc_dn, smc_vmax, smc_amax;
unsigned int count;
/* main program :
unsigned char i = 0;
                    /* for support timing control
 InitIrqLevels();
__set_il(7);
                  /* init IRQ Controller
                    /* allow all levels
 adc_init();
 DDR09 = 0xFF;
  for (smc_inp = 0xD000; smc_inp > 0; smc_inp--)
  smc_out(smc_inp);
  for (delay=0; delay < 20; delay++)</pre>
    __asm("\tNOP");
 ___EI();
                    /* global enable interrupts
 while(1)
                    /* for ever
```

Above example is prepared for SK-96380-120PMT board.

The appropriate output lines of the stepper motor controller are assigned to high power output stages, which have the capability to drive up to 30 mA, so that small stepper motors can be driven in direct manner, and bigger ones can be driven easily by connecting a power bridge to these pins.



# **3** Additional Information

Information about Cypress Microcontrollers can be found on the following Internet page:

http://www.cypress.com/cypress-microcontrollers



# 4 Document History

Document Title: AN204780 - F2MC-16FX Family, Stepper Motor Controller

Document Number:002-04780

Revision	ECN	Orig. of Change	Submission Date	Description of Change
**	-	NOFL	06/11/2006	Initial release, based on spectrum article of JMe
			09/24/2007	Updated Example
			09/28/2007	Updated Code formatting
*A	5080654	NOFL	04/26/2016	Migrated Spansion Application Note MCU-AN-300231-E-V12 to Cypress format



# **Worldwide Sales and Design Support**

Cypress maintains a worldwide network of offices, solution centers, manufacturer's representatives, and distributors. To find the office closest to you, visit us at Cypress Locations.

#### **Products**

ARM® Cortex® Microcontrollers cypress.com/arm

Automotive cypress.com/automotive

Clocks & Buffers cypress.com/clocks

Interface cypress.com/interface

Lighting & Power Control cypress.com/powerpsoc

Memory cypress.com/memory

PSoC cypress.com/psoc

Touch Sensing cypress.com/touch
USB Controllers cypress.com/usb

Wireless/RF cypress.com/wireless

## PSoC® Solutions

cypress.com/psoc

PSoC 1 | PSoC 3 | PSoC 4 | PSoC 5LP

# **Cypress Developer Community**

Community | Forums | Blogs | Video | Training

## **Technical Support**

cypress.com/support

PSoC is a registered trademark and PSoC Creator is a trademark of Cypress Semiconductor Corp. All other trademarks or registered trademarks referenced herein are the property of their respective owners.



Cypress Semiconductor 198 Champion Court San Jose, CA 95134-1709 Phone : 408-943-2600 Fax : 408-943-4730 Website : www.cypress.com

© Cypress Semiconductor Corporation, 2006-2016. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you under its copyright rights in the Software, a personal, non-exclusive, nontransferable license (without the right to sublicense) (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units. Cypress also grants you a personal, non-exclusive, nontransferable, license (without the right to sublicense) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely to the minimum extent that is necessary for you to exercise your rights under the copyright license granted in the previous sentence. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system could cause personal injury, death, or property damage ("Unintended Uses"). A critical component is any component of a device or system whose failure to perform can be reasonably expected to cause the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and Company shall and hereby does release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. Company shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of Cypress products.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.