

http://dk3red.homepage.t-online.de/de/s3 02.htm http://dk3red.homepage.t-online.de/de/s3.htm https://wiki.oevsv.at/wiki/Abk%C3%BCrzungen https://www.modellskipper.de/Maritimes/Abkuerzungen Abschnitt A/Index https://www.qsl.net/dk5ke/abk.html https://wiki.edu.vn/wiki18/2021/01/26/abkurzungen-fur-morsecodes-wikipedia/ https://en.wikipedia.org/wiki/Morse_code_abbreviations Variable Note ID: print_symbols Value: True **Note:** permitte... frequencies QT GUI Msg CheckBox International Morse code is composed of five elements: **ID:** checkbox_print_symbols Label: Print Symbols * short mark, dot or dit or () or (.): "dit duration" is one time unit long = 1 tau state - - - inpair * long mark, dash or dah or (______) or (_): three time units long = 3 tau **Default Value:** False * element-space (^) between the marks within a character: one time unit long = 1 tau Initial State: Unchecked

* letter-space: three time units long = 3 tau Checked: True * word-space: seven time units long (formerly five) = 7 tau Unchecked: False enable printing received symbols in the console QT GUI Range QT GUI Range of GNURadio Companion ID: short_mark **ID:** long mark Label: long_mark Label: short_mark Variable Default Value: 270 Default Value: 810 **Start:** 200 **ID:** print 1duration **Stop:** 1.6k Value: False Step: 1 QT GUI Msg CheckBox QT GUI Range QT GUI Range QT GUI Range ID: checkbox_print_1duration **ID:** letter_space ID: element_space **ID:** word_space Label: Print durations of ON Label: element_space Label: letter_space **Label:** word_space **Default Value:** False Initial State: Unchecked **Default Value: 270 Default Value: 81** Default Value: 1.89 Checked: True **Start:** 200 Start: 800 **Stop:** 1.6k Stop: 8k Unchecked: False Step: 1 Step: 1 enable printing the duration of ON signal in the console of GNURadio Companion **QT GUI Label** ID: label1 Label: Note: Pl...s- checked) Variable **Default Value:** ID: print_0duration Value: False QT GUI Label ID: label2 QT GUI Msg CheckBox Label: Note: Pl...CII symbols **ID:** check_box_print_0duration Label: Print durations of OFF **Default Value: Default Value:** False Initial State: Unchecked

Note

Note: Morse Ab...Translation)

several (mostly German) websites on Morse code and acronyms

ID: checkbox_print_symbols
Label: Print Symbols
Default Value: False
Initial State: Unchecked
Checked: True
Unchecked: False
enable printing received
symbols in the console
of GNURadio Companion

Variable
ID: print_lduration
Label: Print durations of ON
Default Value: False
Initial State: Unchecked
Checked: True
Unchecked: False

OT GUI Msg CheckBox
ID: checkbox_print_lduration
Label: Print durations of ON
Default Value: False
Initial State: Unchecked
Checked: True
Unchecked: False

Parity

Message Pair to Var
Variable: print_lduration
write to variable

Write to variable

Write to variable

False

OT GUI Msg CheckBox
ID: check_box_print_Oduration
Value: False

OT GUI Msg CheckBox
ID: check_box_print_Oduration
Label: Print durations of OFF
Default Value: False
Initial State: Unchecked
Checked: True
Unchecked: False

Message Pair to Var
Variable: print_lduration
write to variable

Message Pair to Var
Variable: print_lduration
write to variable:

Message Pair to Var
Variable: print_lduration
write to variable:

Parity Variable: print_oduration
Value: False

OT GUI Msg CheckBox
ID: check_box_print_Oduration
Label: Print durations of OFF
Default Value: False

Initial State: Unchecked
Checked: True
Unchecked: False

enable printing the duration

of OFF signal in the console

of GNURadio Companion