Table of Contents

In	Introduction	
	Supported Hardware	1.1.1
	Supported Software	1.1.2
Fi	ixtures	1.2
	Adding Fixtures	1.2.1
	Resetting Fixture Channel Values	1.2.2
	Channels	1.2.3
	Settings	1.2.4

Welcome to the Tonalite v2 Documentation!

This book will show you how to get started using Tonalite to create great lighting quickly and easily.

Who is Tonalite for?

Tonalite is for smaller theater venues who need a wireless lighting control system. It is designed to work with industry standard hardware, and it is meant to be as easy to use as possible.

What is Tonalite meant to do?

Tonalite is meant to control lighting rigs wirelessly from any deivce on the network such as a phone or tablet. This allows the operator to control lighting while moving throughout the theater. You can still use it with a wired connection in case of connection issues.

Supported Hardware

Tonalite supports any E1.31 (sACN) or uDMX to DMX 512 network interface.


Supported Software

It is possible to visualize your lighting using external software that supports the E1.31 (sACN) protocol. Below is a list of some visualizers that work with Tonalite.

Software	Manufacturer
Capture	Capture Visualisation AB
ShowDesigner	Martin
Realizzer	Realizzer
Vision	Vectorworks, Inc.


Using Fixtures

Any production uses a number of different lighting fixtures. Tonalite allows you to control each one individually and set the values of each of its channels separately. You can access the fixtures in the Fixtures tab of the interface.



Adding Fixtures

Add a fixture using the green Add Fixture button on the top of the Fixtures tab. This will open a modal that shows the available fixture profiles and allows you to set a starting DMX address for the fixture. Each channel's DMX address is based off of the starting DMX address. If the fixture has three channels and the starting DMX address is 1, the channels will be mapped to addresses 1, 2, and 3.



To select a fixture profile, click on it in the list, and a new fixture will be created based on this profile.




Resetting Fixture Channel Values

r ou can re	eset the values of e	every fixture's channels using one button. To do so, click the red Reset values button on the to	p or the
Fixtures	tab. You will be a	e asked to make sure you actually want to reset all values because this will cause a blackout in r	nost
cases.			

Updating Fixture Channels

Each of a fixture's channels can be controlled individually. To access the fixture channels page, click on the appropriate fixture in the fixtures view.



Changing Fixture Settings