



*Everything's possible.*

# CANopen Communication

## Reference Manual

### DP and DZ series Drives



# Preface

*ADVANCED* Motion Controls constantly strives to improve all of its products. We review the information in this document regularly and we welcome any suggestions for improvement. We reserve the right to modify equipment and documentation without prior notice.

For the most recent software, the latest revisions of this manual, and copies of compliance and declarations of conformity, visit the company's website at [www.a-m-c.com](http://www.a-m-c.com). Otherwise, contact the company directly at:

*ADVANCED* Motion Controls • 3805 Calle Tecate Camarillo, CA • 93012-5068 USA

## Agency Compliances

The company holds original documents for the following:

- UL 508c, file number E140173
- Electromagnetic Compatibility, EMC Directive - 2004/108/EC  
EN61000-6-2:2005  
EN61000-6-4:2007
- Electrical Safety, Low Voltage Directive - 2006/95/EC  
EN 60204-1:2006
- Reduction of Hazardous Substances (RoHS), 2011/65/EU

## Trademarks

*ADVANCED* Motion Controls™, the combined isosceles trapezoid/right triangle logo, **DIGIFLEX®**, **DIGIFLEX® Performance™** and DriveWare™ are either registered trademarks or trademarks of *ADVANCED* Motion Controls in the United States and/or other countries. All other trademarks are the property of their respective owners.

## Related Documentation

- Product datasheet specific for your drive, available for download at [www.a-m-c.com](http://www.a-m-c.com).

## Attention Symbols

The following symbols are used throughout this document to draw attention to important operating information, special instructions, and cautionary warnings. The section below outlines the overall directive of each symbol and what type of information the accompanying text is relaying.



Note

Note - Pertinent information that clarifies a process, operation, or ease-of-use preparations regarding the product.



Notice

Notice - Required instruction necessary to ensure successful completion of a task or procedure.



Caution

Caution - Instructs and directs you to avoid damaging equipment.



Warning

Warning - Instructs and directs you to avoid harming yourself.



DANGER

Danger - Presents information you must heed to avoid serious injury or death.

## Revision History

Document ID	Revision #	Date	Changes
MNCMCNRF-01	1.0	2/17/2006	First Draft
MNCMCNRF-02	3.1	10/11/2006	<ul style="list-style-type: none"> <li>- Corrected values in the diagram for NMT state transitions between Operational and Pre-operational</li> <li>- Updated description for 2039.0Ah</li> </ul>
MNCMCNRF-03	4.0	3/26/2007	<ul style="list-style-type: none"> <li>- Updated page numbers, formatting</li> <li>- Added sub-indices 0Dh-10h for object 2058h</li> <li>- Changed sub-indices names for object 2058h and 205Ah</li> <li>- Corrected sub-indices numbers 4Ah-51h for 205Ah</li> <li>- Added sub-indices 52h-56h for object 205Ah</li> <li>- Updated names and descriptions for object 205Bh</li> <li>- Updated description information for object 2010h</li> <li>- Updated Home Offset description for object 607Ch</li> <li>- Updated PVT position segment end point information in table 21</li> <li>- Added bit 6 to 201D.01h - PVT buffer executing bit</li> <li>- Added PVT description stating COB-IDs are unique</li> <li>- Corrected typo in PVT Buffer Clearing section</li> <li>- Corrected typo in COB-ID value section</li> <li>- Removed, renamed, re-numbering, and added to sub-indices of object 2068h</li> <li>- Also changed names and sub-indices numbering for 2046h, 2065h, 2066h, 2067h</li> <li>- Readjusted sub-indices numbers 17h-1Eh for object 2034h</li> <li>- Added Phase Detect Control to object 2034h-</li> <li>- Added Start-up Phase Detect Configuration to object 2008h</li> <li>- Added Positive Stop Enabled, Negative Stop Enabled, Positive Torque Enabled, Negative Torque Enabled, and External Brake Active to Drive Bridge Status (object 2002.01h)</li> <li>- Removed Apply Brake from Drive System Status 2 (object 2002.05h)</li> <li>- Added Commanded Positive Limit and Commanded Negative Limit to Drive System Status 3 (object 2002.06h)</li> <li>- Added Commanded Positive Limit and Commanded Negative Limit to Event Actions (object 2065h and its tables)</li> <li>- Values 12 and 15 removed from Event Action Values Definition of 2065h (Table 5)</li> <li>- Added Serial Encoder Type table for object 2032.07h</li> <li>- Added PVT Quick Status (object 200Ch)</li> </ul>
MNCMCNRF-04	4.2	6/21/2007	<ul style="list-style-type: none"> <li>- Added object 2001.02: Control Parameters-Virtual Output Control</li> <li>- Added Deadband Input Value (object 2015h)</li> <li>- Added Deadband Parameters (object 203Dh)</li> <li>- Removed 2021.01h and changed the sub-index of External Thermal Sense Value from 2021.02h to 2021.01h</li> <li>- Removed 2054.01h and 2054.02h and changed the sub-indices of External Analog Temperature [Disable / Enable] Level from [2054.03h / 2054.04h] to [2054.01h / 2054.02h]</li> <li>- Added Velocity Loop Integrator Decay Rate (2036.07h)</li> <li>- Added Velocity Loop Integrator Decay Active Window (2037.07h)</li> <li>- Added Position Loop Integrator Decay Rate (2038.07h)</li> <li>- Added Position Loop Integrator Decay Active Window (2039.0Bh)</li> <li>- Added mode-specific Profiler slope sub-indices to 203Ch</li> <li>- Added Capture Values (2019h)</li> <li>- Added Capture Configuration Parameters (2043h)</li> <li>- Added sub-indices 05h-08h to object 2045h</li> <li>- Added Control Loop Configuration Parameters (20D0h)</li> </ul>
MNCMCNRF-05	4.6.4	10/10/2007	<ul style="list-style-type: none"> <li>- Added Heartbeat protocol description</li> <li>- Added Consumer Heartbeat Time (1016h)</li> <li>- Added Producer Heartbeat Time (1017h)</li> <li>- Corrected PVT velocity unit to counts/second</li> <li>- Added sub-indices to Digital Input Parameters (2058h)</li> <li>- Updated PDO Transmission Types</li> <li>- Added Drive Control sub-index (2001.01h)</li> <li>- Corrected scaling factors for drive units (Appendix A)</li> <li>- Added custom modes (FF) to mode of operation objects 6060 and 6061</li> <li>- Added new Inhibit Motion ControlWord table to Comm Manual</li> <li>- Updated description for sub-index 2039.07h</li> <li>- Added Phase Offset sub-index (2034.28h)</li> <li>- Added Fault Log Counter (2028h)</li> </ul>

Document ID	Revision #	Date	Changes
MNCMCNRF-06	5.4.2	6/20/2008	<ul style="list-style-type: none"> <li>- Updated PDO transmission descriptions</li> <li>- Updated description for Status Word bit 10 - Target Reached</li> <li>- Added Time Stamp Settings (20EBh)</li> <li>- Added Node Functionality Settings (20E6.0Ch)</li> <li>- Updated description for 26<sup>th</sup> Transmit PDO Mapping Parameter (1A19h)</li> <li>- Added Control Loop Configuration Parameters (20D0.23h)-(20D0.2Eh)</li> <li>- Modified Serial Encoder Type (2032.07h)</li> <li>- Added Encoder Emulation Divide by Enum (2032.0Ch)</li> <li>- Added Sin/Cos Error Window (2032.0Dh)</li> <li>- Changed "Inhibit Bridge" references to "Disable Bridge"</li> <li>- Changed "Dynamic Brake" references to "Auxiliary Disable"</li> <li>- Removed Digital Output Mask: User Dynamic Brake (205A.1Dh)</li> <li>- Shifted Digital Output Mask sub-indices 205A.1Eh-205A.56h up to 205A.1Dh-205A.55h</li> <li>- Updated description for Event Response Time Parameters (2064h)</li> <li>- Removed Event Action: User Dynamic Brake (2065.2Eh)</li> <li>- Shifted Event Action sub-indices 2065.2Fh-2065.31h up to 2065.2Eh-2065.30h</li> <li>- Updated Event Action Options table</li> <li>- Removed Event Recovery Time: Log Entry Missed (2066.03h)</li> <li>- Shifted Event Recovery Time sub-indices 2066.04h-2066.22h up to 2066.03h-2066.21h</li> <li>- Removed Programmable Status Mask: User Dynamic Brake (205B.1Ch)</li> <li>- Shifted Programmable Status Mask sub-indices 205B.1Dh-205B.55h up to 205B.1Ch-205B.54h</li> <li>- Updated Control Parameters table</li> <li>- Updated Drive Status bit-field definitions table</li> <li>- Changed "Auxiliary Input Values" to "Gearing Values" (201Ch)</li> <li>- Added Present Gear Input Counts (201C.02h)</li> <li>- Added Present Gear Output Counts (201C.03h)</li> <li>- Added Auxiliary Encoder Value (201Eh)</li> <li>- Removed Log Counter: User Dynamic Brake (2028.1Bh)</li> <li>- Shifted Log Counter sub-indices 2028.1Ch-2028.34h up to 2028.1Bh-2028.33h</li> <li>- Updated DA3 acceleration scaling factor</li> </ul>
MNCMCNRF-07	5.8.5	2/2/2009	<ul style="list-style-type: none"> <li>- Added Event Recovery Time: Log Entry Missed (object 2066.03h)</li> <li>- Shifted 2066h: Event Recovery Time Parameters sub-indices 2066.03h-2066.21h up to 2066.04h-2066.22h</li> <li>- Updated PVT Messages End of Motion description and Tables 1.70 and 1.71</li> <li>- Updated 1A17h: 24th Transmit PDO Mapping Parameter description</li> <li>- Added sub-indices 2032.0Eh-2032.10h to 2032h: Feedback Sensor Parameters</li> <li>- Added object 201Bh: PWM and Direction Input Values</li> <li>- Added Stop Deceleration Limit - Velocity Mode (object 2062.04h)</li> <li>- Updated Stop Deceleration Limit - Position Mode (object 2062.03h)</li> <li>- Added Programmable Status Mask: Gain Set 1 Active (object 205B.55h)</li> <li>- Added Digital Output Mask: Gain Set 1 Active (object 205A.56h)</li> <li>- Updated Heartbeat section with sample message structure</li> </ul>
MNCMCNRF-08	5.14.0	7/16/2009	<ul style="list-style-type: none"> <li>- Added Appendix B - Current Limiting Algorithm section</li> <li>- Added objects 20D8.2Ah and 20D8.2Bh</li> <li>- Shifted 20E6h: CANopen Parameters sub-index from 20E6.0Ch to 20E6.06h</li> <li>- Updated PVT Example</li> <li>- Changed object 60C4.04h data range to Unsigned16</li> <li>- Shifted object 1017.01h to 1017.00h</li> <li>- Changed object 1017.00h data range to Unsigned16</li> <li>- Added additional modes of operation to 6060h: Modes Of Operation</li> <li>- Added object 60B2h: Current Offset</li> <li>- Added objects 2054.03h, 2054.04h, and 2054.05h to 2054h: Drive Temperature Parameters</li> <li>- Added objects 2021.02h to 2021h: Drive Temperature Values</li> </ul>
MNCMCNRF-09	5.16.3	2/18/2010	<ul style="list-style-type: none"> <li>- Updated object 6060h: Modes Of Operation</li> <li>- Added 1Vp-p Sin/Cos Encoder Motor Over Speed conversion example to Appendix</li> <li>- Added 60C2h: Interpolation Time Period</li> <li>- Added 1010h: Store Drive Parameters</li> <li>- Added 1011h: Restore Drive Parameters</li> <li>- Updated 2009h: Load EEPROM Values</li> <li>- Updated 200Ah: AMC Store Drive Parameters</li> </ul>

Document ID	Revision #	Date	Changes
MNCMCNRF-10	5.16.4	-	<ul style="list-style-type: none"> <li>- Added object <a href="#">60B1h: Velocity Offset</a></li> <li>- Updated object <a href="#">60B2h: Current Offset</a></li> <li>- Added object <a href="#">2005h: Serial Interface Configuration</a></li> <li>- Added object <a href="#">606Eh: Velocity Window Time</a></li> <li>- Added object <a href="#">6066h: Position Following Error Time Out</a></li> <li>- Updated sub-index 2036.02h of object <a href="#">2036h: Velocity Loop Control Parameters</a></li> <li>- Added object <a href="#">6086h: Motion Profile Type</a></li> <li>- Added object <a href="#">6088h: Torque Profile Type</a></li> </ul>
MNCMCNRF-11	5.16.9	11/2011	<ul style="list-style-type: none"> <li>- Updated <a href="#">2058h: Digital Input Parameters</a></li> <li>- Changed Watchdog Comm Channel Error reporting time to 10 cycles</li> </ul>
MNCMCNRF-12	7.0	8/2012	<ul style="list-style-type: none"> <li>- Added object <a href="#">1419h: 26th Receive PDO Mapping Parameter</a></li> <li>- Added sub-indices <a href="#">2010.12h</a> and <a href="#">2010.13h</a> in <a href="#">2010h: Current Values</a></li> <li>- Added sub-indices <a href="#">2011.06h</a> and <a href="#">2011.07h</a> in <a href="#">2011h: Velocity Values</a></li> <li>- Added sub-indices <a href="#">2012.05h</a>, <a href="#">2012.06h</a>, and <a href="#">2012.07h</a> in <a href="#">2012h: Position Values</a></li> <li>- Added sub-index <a href="#">201E.02h</a> in <a href="#">201Eh: Auxiliary Encoder Value</a></li> <li>- Added sub-index <a href="#">2034.29h</a> in <a href="#">2034h: Current Loop &amp; Commutation Control Parameters</a></li> <li>- Updated sub-indices <a href="#">203C.01h</a> to <a href="#">203C.0Eh</a> in <a href="#">203Ch: Command Limiter Parameters</a></li> <li>- Updated definition for <math>K_{MS}</math> in <a href="#">Table A.2 on page 284</a></li> <li>- Updated sub-indices <a href="#">203D.01h</a> to <a href="#">203D.06h</a> in <a href="#">203Dh: Deadband Parameters</a></li> <li>- Added object <a href="#">203Eh: Jog Parameters</a></li> <li>- Added unit type DA4 to <a href="#">Table A.1 on page 283</a></li> <li>- Updated sub-indices <a href="#">2044.01h</a> to <a href="#">2044.10h</a> in <a href="#">2044h: Analog Input Parameters</a></li> <li>- Updated sub-indices <a href="#">2046.01h</a> to <a href="#">2046.04h</a> in <a href="#">2046h: Auxiliary Input Parameters</a></li> <li>- Added sub-indices <a href="#">2058.1Dh</a> to <a href="#">2058.21h</a> in <a href="#">2058h: Digital Input Parameters</a></li> <li>- Added sub-index <a href="#">2062.05h</a> to <a href="#">2062h: Braking/Stop General Properties</a></li> <li>- Updated sub-index <a href="#">2032.08h</a> in <a href="#">2032h: Feedback Sensor Parameters</a></li> <li>- Added object <a href="#">20C8h: Motion Engine Configuration</a></li> <li>- Added object <a href="#">20C9h: Motion Engine Control</a></li> <li>- Added object <a href="#">2029h: Motion Engine Status</a></li> <li>- Added sub-index <a href="#">201A.05h</a> to <a href="#">201Ah: Analog Input Values</a></li> </ul>
MNCMCNRF-13	7.1	6/2013	<ul style="list-style-type: none"> <li>- Added sub-indices <a href="#">205A.61h</a>, <a href="#">205A.62h</a>, and <a href="#">205A.63h</a> in <a href="#">205Ah: Digital Output Parameters</a></li> <li>- Added sub-index <a href="#">205B.60h</a> in <a href="#">205Bh: Programmable Status Parameters</a></li> <li>- Updated object <a href="#">203Eh: Jog Parameters</a></li> <li>- Added sub-index <a href="#">2058.22h</a> in <a href="#">2058h: Digital Input Parameters</a></li> <li>- Added sub-index <a href="#">20E6.01</a> in <a href="#">20E6h: CANopen Parameters</a></li> <li>- Added object <a href="#">20ECh: NMT State</a></li> <li>- Added object <a href="#">20CAh: Dynamic Index Data</a></li> <li>- Added unit type DA5 to <a href="#">Table A.1 on page 283</a></li> <li>- Added conversion constant <math>K_{DS}</math> in <a href="#">Table A.2 on page 284</a></li> </ul>

© 2013 ADVANCED Motion Controls. All rights reserved.



# Contents

## 1 Communication Manual 1

1.1 Introduction .....	1
1.1.1 Purpose of this manual .....	1
1.1.2 Differences between this manual and DS301 & DS402 .....	1
1.2 CANopen Objects .....	2
1.2.1 Types of CANopen Objects .....	2
Communication Objects 1000h – 1FFFh .....	2
Manufacturer Specific Objects 2000h – 5FFFh .....	2
Standard Servo Drive Objects 6000h – 9FFFh .....	2
1.2.2 CANopen Object Data .....	2
1.3 CANopen Message Structure .....	3
1.3.1 The Arbitration Field .....	3
COB-ID .....	4
RTR Bit .....	4
Node-ID .....	4
1.3.2 The Data Field .....	4
Little Endian Format .....	4
1.3.3 CAN Bus Traffic Concerns .....	5
1.4 CANopen Messages .....	5
1.4.1 NMT Messages .....	5
Boot-Up State .....	6
Pre-Operational State .....	6
Operational State .....	7
Stopped State .....	7
NMT Message Examples .....	7
1.4.2 NMT Error Control .....	7
Node Guarding .....	7
Life Guarding .....	7
Node Guard / Life Guard Example .....	9

---

Heartbeat .....	9
1.4.3 BOOT-UP Message .....	11
Boot-Up Example .....	11
1.4.4 SYNC Message .....	12
SYNC Message Example .....	12
1.4.5 EMERGENCY Messages .....	13
EMERGENCY Error Codes .....	13
EMERGENCY Message Examples .....	14
1.4.6 TIME STAMP Message .....	14
TIME STAMP Example .....	14
1.5 SDO vs. PDO Messages .....	15
1.5.1 SDO Messages .....	15
Expedited SDO Messages .....	16
Segmented SDO Messages .....	16
SDO Abort Transfer Messages .....	21
SDO Read and Write Examples .....	23
1.5.2 PDO Messages .....	25
Transmit Process Data Objects (TPDO) .....	25
Receive Process Data Objects (RPDO) .....	25
PDO Configuration .....	25
Communication Parameter Object .....	27
Mapping Parameter Object .....	28
RTR bit and TPDOs .....	29
AMC PDO Assignment and Mapping .....	29
AMC Asynchronous Transmission Events .....	29
PDO Message Examples .....	31
PDO Mappable Objects .....	33
1.6 Control State Machine .....	35
1.6.1 State Machine Overview .....	35
1.6.2 Drive States .....	36
1.6.3 ControlWord (6040h) .....	38
1.6.4 StatusWord (6041h) .....	39
1.7 Homing .....	40
1.7.1 Home Offset .....	40
1.7.2 Homing Speeds .....	40
1.7.3 Homing Acceleration .....	40
1.7.4 Homing Methods .....	40
Method 1: Homing on the Negative Limit Switch .....	42
Method 2: Homing on the Positive Limit Switch .....	42
Methods 3 and 4: Homing on the Positive Home Switch .....	43
Methods 5 and 6: Homing on the Negative Home Switch .....	43

---

Methods 7-14: Homing on the Home Switch .....	44
Methods 17-30: Homing without an Index Pulse .....	46
Methods 33 and 34: Homing on the Index Pulse .....	46
Method 35 .....	46
Homing Example .....	47
1.8 Modes of Operation .....	48
1.8.1 Profile Modes .....	49
Profile Position Mode: (L3 from Figure 1.15) .....	49
Profile Velocity Mode: (L2 from Figure 1.15) .....	50
Profile Current Mode: (L1 from Figure 1.15) .....	51
1.8.2 Homing Mode: (L4 from Figure 1.15) .....	51
1.8.3 PVT (Interpolated Position Mode): (L4 from Figure 1.15) .....	51
1.8.4 Cyclic Synchronous Modes .....	51
Cyclic Synchronous Position Mode .....	52
Cyclic Synchronous Velocity Mode .....	53
Cyclic Synchronous Current Mode .....	53
1.8.5 Custom Defined Modes Of Operation .....	54
1.9 PVT Mode .....	54
1.9.1 PVT Overview .....	54
1.9.2 PVT Messages .....	56
Enable PVT .....	56
Mode Selection .....	56
Configuration .....	56
PVT Message Protocol .....	57
Clear Buffer .....	57
End of Motion .....	57
Start Motion .....	58
Stop Motion .....	58
1.9.3 PVT Status .....	59
1.9.4 Buffer Characteristics .....	59
Error Messages .....	59
1.9.5 PVT Example .....	60
1.10 Connecting to an AMC CANopen Drive .....	66
1.10.1 RS-232 Interface Setup .....	66
1.10.2 CAN Interface Setup .....	66
Node Addressing .....	66
Baud Rate Selection .....	66
Termination Setting .....	66
1.11 Hardware Requirements .....	66
1.11.1 CAN Card .....	66
1.11.2 API .....	67

1.11.3 Mating Connector .....	67
1.11.4 Wiring .....	67
CAN_H, CAN_L, CAN_GND (Pins 7,2,3) .....	68
CAN_V+ (Pin 9) .....	68
CAN SHIELD (Pin 5) .....	68
Proper Cable Shielding .....	68
CAN_TERM (Pin 8) .....	68

## **2 Object Dictionary**

69

2.1 Dictionary Table Format .....	69
2.2 Configuration Objects .....	70
2.2.1 Administrative Objects .....	70
1010h: Store Drive Parameters .....	70
1011h: Restore Drive Parameters .....	71
2009h: Load EEPROM Values .....	72
200Ah: AMC Store Drive Parameters .....	72
2.3 Communication Settings .....	73
2.3.1 General Settings .....	73
1000h: Device Type .....	73
100Bh: Stored Node-ID .....	73
2100h: Stored Bus Speed .....	73
100Ch: Guard Time .....	73
100Dh: Life Time Factor .....	74
1016h: Consumer Heartbeat Time .....	74
1017h: Producer Heartbeat Time .....	74
1018h: Identity Object .....	74
20E6h: CANopen Parameters .....	75
20EBh: Time Stamp Settings .....	75
2111h: SDO Size Indication .....	76
2005h: Serial Interface Configuration .....	77
2.3.2 PDO Configuration .....	77
1400h: 1st Receive PDO Communication Parameter .....	77
1600h: 1st Receive PDO Mapping Parameter .....	78
1401h: 2nd Receive PDO Communication Parameter .....	78
1601h: 2nd Receive PDO Mapping Parameter .....	78
1402h: 3rd Receive PDO Communication Parameter .....	79
1602h: 3rd Receive PDO Mapping Parameter .....	79
1403h: 4th Receive PDO Communication Parameter .....	80

1603h: 4th Receive PDO Mapping Parameter .....	80
1404h: 5th Receive PDO Communication Parameter .....	80
1604h: 5th Receive PDO Mapping Parameter .....	81
1414h: 21st Receive PDO Communication Parameter .....	81
1614h: 21st Receive PDO Mapping Parameter .....	82
1415h: 22nd Receive PDO Communication Parameter .....	82
1615h: 22nd Receive PDO Mapping Parameter .....	82
1416h: 23rd Receive PDO Communication Parameter .....	83
1616h: 23rd Receive PDO Mapping Parameter .....	83
1417h: 24th Receive PDO Communication Parameter .....	83
1617h: 24th Receive PDO Mapping Parameter .....	84
1419h: 26th Receive PDO Mapping Parameter .....	84
1800h: 1st Transmit PDO Communication Parameter .....	84
1A00h: 1st Transmit PDO Mapping Parameter .....	85
1802h: 3rd Transmit PDO Communication Parameter .....	85
1A02h: 3rd Transmit PDO Mapping Parameter .....	86
1803h: 4th Transmit PDO Communication Parameter .....	86
1A03h: 4th Transmit PDO Mapping Parameter .....	86
1804h: 5th Transmit PDO Communication Parameter .....	87
1A04h: 5th Transmit PDO Mapping Parameter .....	87
1814h: 21st Transmit PDO Communication Parameter .....	88
1A14h: 21st Transmit PDO Mapping Parameter .....	88
1815h: 22nd Transmit PDO Communication Parameter .....	88
1A15h: 22nd Transmit PDO Mapping Parameter .....	89
1816h: 23rd Transmit PDO Communication Parameter .....	89
1A16h: 23rd Transmit PDO Mapping Parameter .....	90
1817h: 24th Transmit PDO Communication Parameter .....	90
1A17h: 24th Transmit PDO Mapping Parameter .....	90
1818h: 25th Transmit PDO Communication Parameter .....	90
1A18h: 25th Transmit PDO Mapping Parameter .....	91
1819h: 26th Transmit PDO Communication Parameter .....	91
1A19h: 26th Transmit PDO Mapping Parameter .....	92
2120h: TPDO Timer1 Cycle Time .....	95
2121h: TPDO Timer1 Assigned TPDOs .....	95
2122h: TPDO Timer1 Next Processing Time .....	96
2123h: TPDO Timer2 Cycle Time .....	96
2124h: TPDO Timer2 Assigned TPDOs .....	96
2125h: TPDO Timer2 Next Processing Time .....	96
2130h: TPDO Value-Changed Object ID .....	97
2131h: TPDO Value-Changed Delta Value .....	97
2132h: TPDO Value-Changed Assigned TPDOs .....	97

2133h: TPDO Value-Changed Object Last Value .....	98
2140h: TPDO Bits-Changed_1 Object ID .....	98
2141h: TPDO Bits-Changed_1 Object Bit Mask .....	98
2142h: TPDO Bits-Changed_1 Assigned TPDOs .....	98
2143h: TPDO Bits-Changed_1 Object Last Value .....	99
2144h: TPDO Bits-Changed_2 Object ID .....	99
2145h: TPDO Bits-Changed_2 Object Bit Mask .....	99
2146h: TPDO Bits-Changed_2 Assigned TPDOs .....	99
2147h: TPDO Bits-Changed_2 Object Last Value .....	100
2150h: TPDO Value-Reached Object ID .....	100
2151h: TPDO Value-Reached .....	100
2152h: TPDO Value-Reached Assigned TPDOs .....	100
2153h: TPDO Value-Reached Direction .....	101
<b>2.4 Drive Configuration .....</b>	<b>101</b>
<b>    2.4.1 Motion Control Profile .....</b>	<b>101</b>
20D0h: Control Loop Configuration Parameters .....	101
2032h: Feedback Sensor Parameters .....	101
2046h: Auxiliary Input Parameters .....	105
2034h: Current Loop & Commutation Control Parameters ..	105
2036h: Velocity Loop Control Parameters .....	113
2037h: Velocity Limits .....	115
2038h: Position Loop Control Parameters .....	117
2039h: Position Limits .....	119
6065h: Position Following Error Window .....	121
6066h: Position Following Error Time Out .....	121
60F4h: Position Following Error Actual Value .....	122
6098h: Homing Method .....	122
6099h: Homing Speeds .....	122
609Ah: Homing Acceleration .....	122
607Ch: Home Offset .....	123
203Ah: Homing Configuration Parameters .....	123
2048h: PVT Parameters .....	124
6086h: Motion Profile Type .....	124
6088h: Torque Profile Type .....	124
203Ch: Command Limiter Parameters .....	124
60C2h: Interpolation Time Period .....	127
<b>    2.4.2 Hardware Profile .....</b>	<b>128</b>
200Bh: Stored User Parameters .....	128
2008h: Drive Initialization Parameters .....	128
20C8h: Motion Engine Configuration .....	129
2033h: User Voltage Protection Parameters .....	129

---

2054h: Drive Temperature Parameters .....	131
2043h: Capture Configuration Parameters .....	132
2058h: Digital Input Parameters .....	135
205Ah: Digital Output Parameters .....	141
2044h: Analog Input Parameters .....	158
203Dh: Deadband Parameters .....	166
203Eh: Jog Parameters .....	168
205Ch: Analog Output Parameters .....	169
2062h: Braking/Stop General Properties .....	170
2064h: Event Response Time Parameters .....	171
2065h: Event Action Parameters .....	178
2066h: Event Recovery Time Parameters .....	190
2067h: Event Time-Out Window Parameters .....	196
2068h: Event Maximum Recoveries Parameters .....	204
205Bh: Programmable Status Parameters .....	214
208Ch: Product Information .....	231
208Dh: Firmware Information .....	231
20D8h: Power Board Information .....	232
<b>2.5 Drive Operation Objects .....</b>	<b>237</b>
<b>2.5.1 Control Objects .....</b>	<b>237</b>
6040h: ControlWord .....	237
2001h: Control Parameters .....	238
6060h: Modes Of Operation .....	241
<b>2.5.2 Command Objects .....</b>	<b>241</b>
6071h: Target Current .....	241
60FFh: Target Velocity .....	241
607Ah: Target Position .....	242
60B1h: Velocity Offset .....	242
60B2h: Current Offset .....	242
2045h: Interface Inputs .....	242
<b>2.5.3 Motion Engine Command Objects .....</b>	<b>244</b>
20C9h: Motion Engine Control .....	244
20CAh: Dynamic Index Data .....	244
<b>2.5.4 Monitor Objects .....</b>	<b>247</b>
6041h: StatusWord .....	247
20ECh: NMT State .....	248
2002h: Drive Status .....	248
2003h: Drive Status History .....	251
2029h: Motion Engine Status .....	252
6061h: Modes Of Operation Display .....	254
200Eh: Feedback Sensor Values .....	254

---

2027h: Feedback Hardware Diagnostics .....	255
201Ch: Gearing Values .....	257
201Eh: Auxiliary Encoder Value .....	257
6077h: Actual Current .....	258
2010h: Current Values .....	258
606Bh: Velocity Demand .....	261
606Ch: Actual Velocity .....	262
606Dh: Velocity Window .....	262
606Eh: Velocity Window Time .....	262
6069h: Velocity Sensor Actual Value .....	262
2011h: Velocity Values .....	263
6064h: Actual Position .....	264
2012h: Position Values .....	264
200Ch: PVT Quick Status .....	266
201Dh: PVT Status Values .....	266
60C1h: Interpolation Data Record .....	267
2014h: Command Limiter Input .....	267
200Fh: Power Bridge Values .....	267
2021h: Drive Temperature Values .....	268
2019h: Capture Values .....	269
2023h: Digital Input Values .....	270
2024h: Digital Output Values .....	271
201Ah: Analog Input Values .....	271
2015h: Deadband Input Value .....	272
201Bh: PWM and Direction Input Values .....	272
2025h: Analog Output Values .....	273
2028h: Fault Log Counter .....	273

**A****Appendix****283**


---

A.1 Appendix A - Units .....	283
A.1.1 Conversion Example 1 .....	284
A.1.2 Conversion Example 2 .....	284
A.1.3 Conversion Example 3 .....	285
A.2 Appendix B - Current Limiting Algorithm .....	286
A.2.1 Time-Based Peak Current Limiting .....	287
A.2.2 Time-Based Non-Peak Current Limiting .....	288
A.2.3 Time-Based Current Recovery .....	289
A.2.4 Charge-Based Peak Current Limiting .....	290

---

A.2.5 Charge-Based Non-Peak Current Limiting .....	291
A.2.6 Charge-Based Current Recovery .....	292
A.2.7 RMS Current Scaling .....	293

# 1

# Communication Manual

## 1.1 Introduction

### 1.1.1 Purpose of this manual

This manual will provide all information necessary to communicate with and operate *ADVANCED Motion Controls*' CANopen drives. Further information regarding the physical CAN layer and CANopen protocol is attainable through the DS402 and DS301 documentation.

The CAN interface for *ADVANCED Motion Controls*' digital drives follows the CiA DS301 communications profile and the CiA DS402 device profile (device profile for drives and motion control). CiA (CAN in Automation) is the non-profit organization that governs the CANopen standard. They can be contacted at <http://www.can-cia.org>.

CANopen is an open standard embedded machine control protocol. CAN is a serial communication interface. The CANopen protocol is developed for the CAN physical layer. In this document, CAN is reserved for physical layer descriptions, while CANopen refers to the communication protocol.

### 1.1.2 Differences between this manual and DS301 & DS402

This manual provides all information necessary to properly communicate with the drive via the CANopen interface. The DS301 and DS402 documents are complimentary and can be used if more detailed information is required on specific standard CANopen features.

## 1.2 CANopen Objects

Every AMC CANopen drive function is defined by groups of objects. An object is roughly equivalent to a memory location that holds a value. The values stored in the drive's objects are used to perform the drive functions (current loop, velocity loop, position loop, I/O functions).

The drive has a unique object for every parameter that needs to be stored or used. Access to the objects varies depending on what the object is used for. Objects may be writable, readable, or both. Some objects are state dependant such that they may only be written to if the drive is in a certain state (e.g. disabled state). The list of objects that AMC CANopen servo drives use is found in the ["Object Dictionary" on page 69](#). Each table in the object dictionary describes the important information regarding that object including: object index, sub-indices, units, and accessibility.

Each object is accessible with a 16-bit address called the object index. Some objects contain sub components with 8-bit addresses called sub-indices. Reading and writing to objects is accomplished via CANopen Messages. Specific types of messages are designed to access specific objects. Details about CANopen message types are found in ["CANopen Messages" on page 5](#).

### 1.2.1 Types of CANopen Objects

There are 3 main object categories:

**Communication Objects 1000h – 1FFFh** These objects relate to CANopen communication; more specifically, they relate to objects defined by the DS301 communication profile. Objects in this range are used to configure CANopen messages (see ["CANopen Message Structure" on page 3](#)) and general CANopen network settings (e.g. network watchdog).

**Manufacturer Specific Objects 2000h – 5FFFh** These objects are manufacturer specific. Detailed information about the AMC manufacturer specific objects can be found in the ["Object Dictionary" on page 69](#).

**Standard Servo Drive Objects 6000h – 9FFFh** These objects are the standardized device profile objects. Objects in this range relate to the device profile of the CANopen device. The applicable device profile for AMC CANopen drives is DS402 (CANopen profile for servo drives). Other device profiles exist also, but they are not discussed here; examples include: DS401 (CANopen profile for I/O modules), and DS405 (CANopen profile for PLC). Detailed information about AMC supported DS402 objects can be found in the ["Object Dictionary" on page 69](#).

### 1.2.2 CANopen Object Data


Every CANopen object index - and sub-index if available - is an address pointer to a data location. The 16-bit index and 8-bit sub index make it effectively a 24-bit address space. The data type can be any type typically found in digital systems, such as 8-bit, 16-bit, 32-bit, or string. The data type can also be a record (in the case of an index with sub-indices), with

multiple record entries, and each entry can be of the above mentioned data type. Nested records are not allowed.

## 1.3 CANopen Message Structure

CANopen messages exchange information between the CANopen host (master) and the CANopen nodes (slave). When collecting information, a host may either poll, or simply wait, for important messages in the network. Although the host may gather information through “polling” (i.e. the host continuously requesting information updates from each node), a more effective method is to exchange information in an interrupt driven fashion (i.e. information is exchanged only when there is new information available). Both mechanisms are possible within the CANopen framework, but the interrupt driven exchange method requires much less overhead, thus allowing higher data throughput. Most messages either read or write data to objects contained in the network nodes. There are 8 types of messages used in a CANopen system. Each message type gets a detailed explanation in CANopen Messages. Regardless of message type, the general structure of a CANopen message is the same. CANopen messages fit within one CAN frame where there are only two parts of the CAN frame the user needs to access, namely the Arbitration, and Data fields. All other fields are automatically configured by the CAN hardware.

**FIGURE 1.1** CANopen frame bit sequence



### 1.3.1 The Arbitration Field

The values in the arbitration field set the priority of the message. The closer the value is to 0h, the higher the priority of the message. Higher priority messages will dominate, or take precedence, over other messages on the CAN bus. Arbitration of the CAN bus is done at the CAN hardware level, thus ensuring that the highest priority message is transmitted first. CANopen message priority is determined by the message COB-ID bits and the RTR (Remote Transmit Request) bit. Within the CANopen framework, there are 7 COB-ID ranges. One COB-ID range is used twice, resulting in 8 message types. Each message type is described in detail in CANopen Messages.

**TABLE 1.1** Arbitration field values.

Arbitration Field		Data Field							
COB-ID	RTR	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
11-bit Identifier	1 or 0	xx	xx	xx	xx	xx	xx	xx	xx

**COB-ID** Every CANopen message has a unique COB-ID that identifies the message type and in case of node specific messages, the node number. [Table 1.2](#) contains the COB-ID or COB-ID range for each message type. In the case of a range of COB-IDs, the actual COB-ID for a message will depend on which node receives or transmits the message. These COB-IDs begin with a base number (assigned in CiA's DS301 specification) and the addition of the NODE-ID completes the COB-ID. If the COB-ID field base is 600h, for example, a COB-ID of 605h pertains to a message (of type SDO as per table 2 below) to/from node 5 in the CANopen network. Each message type is described in detail in CANopen Messages.

**TABLE 1.2** CANopen message types

Message Type	Description	COB-ID
NMT	Network Management (broadcast)	0h
NMT Error Control	Network management error control	701h – 77Fh
BOOT-UP	Boot-Up message	701h – 77Fh
SYNC	Synchronization message (broadcast)	80h
EMERGENCY	Emergency messages	81h - FFh
TIME STAMP	Time stamp (broadcast)	100h
PDO	Process Data Objects	181h - 57Fh
SDO	Service Data Objects	581h – 67Fh

**RTR Bit** The remote transmission request (RTR) bit is used in some specific cases when the host would like to request information from a node. In particular, the RTR bit is used for node guard and TPDO requests. With the exception of these two cases, the RTR bit is always set to 0.

**Node-ID** Every node on the CANopen network must have a unique node-ID, between 1 and 127. Node 0 is always considered the host. See the hardware manual for configuration of the drive node-ID.

### 1.3.2 The Data Field

The content of the Data field depends on the CANopen message type. Detailed information about the CANopen message data is found under the appropriate message type in “CANopen Messages” on page 5 while details on each object are found in the “Object Dictionary” on page 69.

**Little Endian Format** Numerical data larger than 1 byte must be organized into “Little Endian” format. This means that the data is broken into its individual bytes and sent Least-Significant-

Byte-First. The 24-bit number 102315h, for example, must be transmitted LSB (Least Significant Byte) first as 15h 23h 10h (as shown in [Table 1.3](#) below).

**TABLE 1.3** Sending 102315h in Little Endian format

Arbitration Field		Data Field							
COB-ID	RTR	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
AAAh	X	15h	23h	10h	00h	00h	00h	00h	00h

### 1.3.3 CAN Bus Traffic Concerns


It is best to keep the network idle for at least 50% of the time (50% bus load). Busload will depend on CAN bus bit rate and CANopen message rates.

## 1.4 CANopen Messages

AMC CANopen drives support 8 message types. Each message type fits within the defined structure of a CAN frame. The data field of each message type can vary, but all messages require the arbitration field to be populated with the appropriate COB-ID. NMT service, SYNC, and TIME STAMP messages have fixed COB-ID's while the other message types use a range of values.

### 1.4.1 NMT Messages

**FIGURE 1.2** Communication State Machine Operation



Every CANopen device contains an internal Network Management server that communicates with an external NMT master. One device in a network, generally the host, may act as the NMT master. Through NMT messages, each CANopen device's network management server controls state changes within its built-in Communication State Machine. This is independent from each node's operational state machine, which is device dependant and described in Control State Machine. It is important to distinguish a CANopen device's operational state machine from its Communication State Machine. CANopen sensors and I/O modules, for example, have completely different operational state machines than servo drives. The Communication State Machine in all CANopen devices, however, is identical as specified by the DS301.

NMT messages have the highest priority. The 5 NMT messages that control the Communication State Machine each contain 2 data bytes that identify the node number and a command to that node's state machine. [Table 1.5](#) shows the 5 NMT messages supported by AMC, and [Table 1.4](#) shows the correct message construction for sending these messages.

**TABLE 1.4** NMT message construction

Arbitration Field		Data Field							
COB-ID	RTR	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
000h	0	See <a href="#">Table 1.5</a>	See <a href="#">Table 1.5</a>	These bytes not sent					

**TABLE 1.5** NMT messages supported by AMC CANopen servo drives.

NMT Message	COB-ID	Data Bytes		Description
		1	2	
Start Remote Node	0	01h	Node-ID*	Sets the CANopen communication state machine on the designated node to Operational.
Stop Remote Node	0	02h	Node-ID*	Sets the CANopen communication state machine on the designated node to Stopped.
Pre-Operational State	0	80h	Node-ID*	Sets the CANopen communication state machine on the designated node to Pre-Operational. In the pre-operational state, only NMT and SDO messages are allowed.
Reset Node	0	81h	Node-ID*	Resets the designated node (same as power cycle). Results in a Boot Up message sent by the node.
Reset Communication	0	82h	Node-ID*	Resets CANopen communication state machine on the designated node. Results in a Boot Up message sent by the node.

\*Node-ID = Drive address (1...7Fh)

**Boot-Up State** Upon power-up, each drive initializes by going through the Reset Node and Reset Communication states. If the initialization process succeeds, the drive sends out a Boot-Up message and goes into the Pre-Operational state.

**Pre-Operational State** Communication is limited to all message types except PDO messages.

In this state, the NMT master can command the communication state machine to enter any of the states listed in [Table 1.9](#) below. Generally, the host keeps a node in pre-operational state during setup and configuration.

**Operational State** Enables all message types including PDO messages. In this state, the NMT master can command the communication state machine to enter any of the states listed in [Table 1.5](#).

**Stopped State** Disables all message types except NMT messages; Node Guarding / Life Guarding (see below) remains active.

### NMT Message Examples

**TABLE 1.6** NMT Message Examples

COB-ID	Number of Bytes	Message / Data	Description
000	2	80 01	Host: NMT Host commands node 1 into Pre-Operational state
000	2	01 01	Host: NMT Host commands node 1 into Operational state
000	2	02 01	Host: NMT Host commands node 1 into Pre-Operational state
000	2	81 01	Host: NMT Host commands a Reset to Node 1
701	1	00	Node 1 response: Cycles through the standard boot-up states stopping in the Pre-operational state. The control state machine is also reset. This is the same as a power cycle
000	2	82 01	Host: NMT Host commands Communication Reset
701	1	00	Node 1 response: Cycles through the standard boot-up states stopping in the Pre-operational state. The control state machine does not reset and retains full motion control.

### 1.4.2 NMT Error Control

AMC CANopen drives support Node Guarding, Life Guarding, and Heartbeat protocol as NMT error controls.

**Node Guarding** The NMT Master can monitor the communication status of each node using the Node Guarding protocol. During node guarding, a drive is polled periodically and is expected to respond with its communication state within a pre-defined time frame. Acceptable states are shown in [Table 1.9](#). Note that responses indicating an acceptable state will alternate between two different values due to a toggle bit in the returned value. If there is no response, or an unacceptable state occurs, the NMT master reports an error to its host application. The Node Guard message is sent at time intervals, determined by the Guard Time (object 100Ch). The NMT slave (node) must reply to this message before the end of this time interval. [Table 1.7](#) and [Table 1.8](#) show the message format for an NMT master request and the correct NMT slave response. Note that the slave always responds with a toggle bit in byte 1, therefore the response will toggle between the two values shown in [Table 1.9](#).

**Life Guarding** Similarly, the NMT slave monitors the status of the NMT master (Life Guarding). This event utilizes the Guard Time (object 100Ch) and Life Time Factor (object 100Dh) to determine a “Lifetime” for each NMT slave (Lifetime = Guard Time X Life Time Factor). If a node does not receive a Node Guard message within its Lifetime, the node assumes communication with the host is lost and triggers a communication error event. Each node may have a different Lifetime.

**TABLE 1.7** NMT master Node Guard request (host to node).


Arbitration Field		Data Field							
COB-ID	RTR	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
700h + Node-ID	1	These bytes not sent							

**TABLE 1.8** NMT slave Node Guard reply (node to host).

Arbitration Field		Data Field							
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	
700h + Node-ID	See Table 1.9	These bytes not sent							

**TABLE 1.9** Acceptable NMT slave return values.

Return Value	Communication Status
4h or 84h	STOPPED
5h or 85h	OPERATIONAL
7Fh or FFh	PRE-OPERATIONAL

**FIGURE 1.3** Guard Time and Life Time

**Example of Guard Time and Life Time.** The first grey arrow represents an NMT request from the master and the second black arrow represents an NMT response from the slave. In this case, the Life Time is a factor of 3X greater than the Guard Time.

**Node Guard / Life Guard Example** In this example, NMT messages are used to transition the Communication states of the drive while NodeGuarding is active. The shaded rows indicate how the node will respond to a given host command.

**TABLE 1.10** Node Guard/ Life Guard Example

COB-ID	Number of Bytes	Message / Data	Description
701	0	RTR set	Host sends first node guard message within GuardTime
701	1	04	Node replies in STOP state
701	0	RTR set	Host sends next node guard message within GuardTime
701	1	84	Node replies in STOP state, Toggle Bit alternates
701	0	RTR set	Host sends next node guard message within GuardTime
701	1	04	Node replies in STOP state, Toggle Bit alternates
000	2	80 01	NMT host changes node communication state machine to Pre-Operational
701	0	RTR set	Host sends next node guard message within GuardTime
701	1	FF	Node replies in PRE-Operational state, Toggle Bit alternates
701	0	RTR set	Host sends next node guard message within GuardTime
701	1	7F	Node replies in PRE-Operational state, Toggle Bit alternates
000	2	01 01	NMT host changes node communication state machine to Operational
701	1	RTR set	Host sends next node guard message within GuardTime
701	0	85	Node replies in Operational state, Toggle Bit alternates
701	1	RTR set	Host sends next node guard message within GuardTime
701	0	05	Node replies in Operational state, Toggle Bit alternates

**Heartbeat** The heartbeat error control method uses a producer to generate a periodic message.

One or more consumer devices on the network listen for this message. If the producer fails to generate a message within a specified time frame, the consumer acts accordingly. Any drive on the network can be configured to be a producer or a consumer. The producer heartbeat time (object 1017h) represents the time between successive heartbeat messages. It can be any integer value between 1 and 65535. When set to zero, the producer heartbeat is disabled. The consumer heartbeat time (object 1016h) represents the time in which the consumer should expect to receive a heartbeat message. If a heartbeat is not detected within this time frame, the drive will flag a communication error. The action taken during a communication error is configurable. The consumer heartbeat time can be any integer value between 1 and 65535. When set to zero, the consumer heartbeat detection is disabled. See [Table 1.11](#) below for the bit assignment definitions.

**TABLE 1.11** Consumer Heartbeat Time (Object 1016) bit descriptions

Bits 31 – 24	Bits 23 – 16	Bits 15 – 0
Reserved (value: 0x 00h)	Producer Node-ID	Heartbeat Time

Generally, when a host sends a heartbeat message to a node, the message sent is this:

COB-ID	Number of Bytes	Message / Data
700	1	00

However, a drive can be set as a consumer to use any node ID, so the message could be made to look like this:

COB-ID	Number of Bytes	Message / Data
702	1	00

When a drive is set to produce a heartbeat, the byte echoed out is the NMT state of the drive. The possible NMT states are:

Message / Data	NMT State
0 (0 hex)	Bootup
4 (4 hex)	Stopped
5 (5 hex)	Operational
127 (7F hex)	Pre-operational

**TABLE 1.12** Heartbeat Example 1 - set up node 3 to consume heartbeats every 2 seconds

COB-ID	Number of Bytes	Message / Data	Description
603	8	22 16 10 01 D0 07 00 00	set consumer time for 2sec (0x1016)
700	1	00	heartbeat message from host
			no response is seen from drive

**TABLE 1.13** Heartbeat Example 2 - set up node 3 to produce heartbeats every 3 seconds

COB-ID	Number of Bytes	Message / Data	Description
603	8	22 17 10 01 B8 0B 00 00	set producer time for 3sec (0x1017)
583	8	60 17 10 01 00 00 00 00	
703	1	7F	heartbeats from drive (pre-operational state)
703	1	7F	
703	1	7F	

**TABLE 1.14** Heartbeat Example 3 - set up node 2 to consume heartbeats from node 3

COB-ID	Number of Bytes	Message / Data	Description
602	8	22 16 10 01 D0 07 03 00	set up consumer time for 2sec and node ID 3
602	8	22 17 10 01 00 00 00 00	
603	8	22 17 10 01 E8 03 00 00	set producer time for 1sec (0x1017)
583	8	60 17 10 01 00 00 00 00	
703	1	7F	node 3 sends out heartbeats
703	1	7F	
			no response is seen from node #2

### 1.4.3 BOOT-UP Message

The drive transmits a boot-up message after power up, communication reset, or application reset events. The CANopen master can monitor the drive and report an error if no boot-up message was received. The boot-up message of an AMC CANopen drive uses the same COB-ID as a Node Guard reply.

**TABLE 1.15** Boot-up message from AMC CANopen drives.

Arbitration Field	Data Field								
	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	
700h + Node-ID	00	These bytes not sent							

**Boot-Up Example** These are messages sent from three drives powered up in random order.  
Data is always 00h for boot up messages.

**TABLE 1.16** Boot-up Example

COB-ID	Number of Bytes	Message / Data	Description
701	1	00	Node 1 boots up
703	1	00	Node 3 boots up
702	1	00	Node 2 boots up

#### 1.4.4 SYNC Message

The SYNC message serves as a network “trigger” and is used to coordinate events across multiple CANopen nodes. For example, the CANopen host may need to obtain the actual motor position at a specific time, for several nodes. An AMC CANopen drive can be pre-configured to read and broadcast its actual position the instant a SYNC message is received. SYNC messages carry no data. AMC drives receive SYNC messages, but cannot produce them. For more information on the SYNC message, see (DS301).

**TABLE 1.17** Sync message format (host to node).

Arbitration Field		Data Field							
COB-ID	RTR	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
80h	0	These bytes not sent							

**SYNC Message Example** In this example PDO1 (1800.02h) is configured to report the StatusWord every second Sync message the host broadcasts. This example starts with the host setting Node 1 into the Operational state so PDOs may be processed by the drive.

**TABLE 1.18** SYNC Message Example

COB-ID	Number of Bytes	Message / Data	Description
000	2	01 01	Host: NMT command puts Node 1 into Operational state.
80	0	None	Host: 1 <sup>st</sup> Sync message
80	0	None	Host: 2 <sup>nd</sup> Sync message
231	2	60 06	Node 1 response: PDO1 (1A00.01h) sends data containing StatusWord
80	0	None	Host: 3 <sup>rd</sup> Sync message
80	0	None	Host: 4 <sup>th</sup> Sync message
231	2	60 06	Node 1 response: PDO1 (1A00.01h) sends data containing StatusWord

## 1.4.5 EMERGENCY Messages

EMERGENCY messages are sent by the CANopen nodes to provide important status information to the CANopen host controller. An emergency object is transmitted only once per error event by the drive, and uses the same COB-ID as the sync message plus the node ID. AMC servo drives utilize EMERGENCY messages to indicate PVT buffer status information to the CANopen host controller. The following tables describe the error codes supported by AMC CANopen drives.

**TABLE 1.19** Emergency Object Data

Arbitration Field	Data Field							
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
80h + Node-ID	00	00	00	Error Code. See ( <a href="#">Table 1.20</a> ).	See ( <a href="#">Table 1.20</a> )			

### EMERGENCY Error Codes

**TABLE 1.20** Emergency Error Codes supported by AMC CANopen drives.

Error Code	Description	Bytes 5 – 8																		
00h	PVT Sequence Counter Error	Required counter value																		
01h	PVT Cannot be started	Internal use only																		
02h	PVT Buffer Underflow	0h																		
80h - FFh	RPDO Cannot be Processed  Bit Definitions are defined as follows when Bit 7 = 1  Bits 4 - 6 = Subtract 1 from the value read in these bits to get the Sub-index of the RPDO Mapping Parameter that caused the error. Bits 0 - 3 = Error Description Values (1h - 7h) where:  <table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>RPDO cannot be processed</td> </tr> <tr> <td>1</td> <td>General Error</td> </tr> <tr> <td>2</td> <td>Object does not exist</td> </tr> <tr> <td>3</td> <td>Not writable or Not readable</td> </tr> <tr> <td>4</td> <td>Access unsupported in present state</td> </tr> <tr> <td>5</td> <td>Not enough space in the PDO for object data</td> </tr> <tr> <td>6</td> <td>Data integrity error</td> </tr> <tr> <td>7</td> <td>Internal write error</td> </tr> </tbody> </table>	Value	Description	0	RPDO cannot be processed	1	General Error	2	Object does not exist	3	Not writable or Not readable	4	Access unsupported in present state	5	Not enough space in the PDO for object data	6	Data integrity error	7	Internal write error	COB-ID of RPDO
Value	Description																			
0	RPDO cannot be processed																			
1	General Error																			
2	Object does not exist																			
3	Not writable or Not readable																			
4	Access unsupported in present state																			
5	Not enough space in the PDO for object data																			
6	Data integrity error																			
7	Internal write error																			

**EMERGENCY Message Examples** These examples demonstrate several emergency messages and what the data will look like coming from the drive.

**TABLE 1.21** EMERGENCY Message Examples

COB-ID	Number of Bytes	Message / Data	Description
81	8	00 00 00 00 03 00 00 00	The 3 <sup>rd</sup> counter value was skipped when filling the PVT buffer of Node 1.
83	8	00 00 00 01 00 00 00 00	PVT cannot be started on node 3. It happens to be in the wrong state here.
81	8	00 00 00 84 01 05 00 00	84 indicates an RPDO that cannot be processed because access is not supported in the present state. 0501 indicates the COB-ID of the RPDO. This message occurred because write access to the drive was disabled before attempting to write.

#### 1.4.6 TIME STAMP Message

The TIME STAMP message provides a “global clock” for all the nodes on the CANopen network. The TIME STAMP message data field contains the host controller time. It is used for synchronization between nodes. This can be very important for applications that require long-term time synchronization.

Each drive uses not only the time data contained in the time stamp messages, but also the time between each time stamp message to synchronize to both host timing and frequency. If there is jitter in the host’s time stamp messages, there will be some jitter in the drive timing.

The data field uses a 6 byte “Time Of Day” field defined in CiA’s DS301. Time Of Day contains two components: the number of milliseconds after midnight (4 bytes), and the present day since January 1, 1984 (2 bytes).

**TABLE 1.22** Time stamp message data.

Arbitration Field		Data Field							
COB-ID	RTR	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
100h	0	Time, after Midnight in Milliseconds (LSB first)				Current day since 01/01/84		N/A	N/A

#### Time Stamp Tips

- Once activated, time stamps can only be turned off with a drive-reset or CAN NMT reset message.
- A communications error will be flagged in the drive if time between time stamps exceeds  $2^{31} \mu\text{s}$  (about 35 minutes).
- Time stamps may occur non-periodically.
- The drive will not detect a missing time stamp.

**TIME STAMP Example** This example starts the drive at midnight on the 1<sup>st</sup> day of January 1984 as dictated by the CiA’s DS301. Generally the current time and day would be filled in and sent

automatically. AMC CANopen servo drives do not respond to time stamps with messages, therefore there is no node response shown.

**TABLE 1.23**

<b>COB-ID</b>	<b>Number of Bytes</b>	<b>Message / Data</b>	<b>Description</b>
100	8	00 00 00 00 00 00 00 00	Very first timestamp Resets timers on all nodes to the value contained in bytes 1 – 6
Wait 500 ms			
100	8	F4 01 00 00 00 00 00 00	Broadcast message reporting time is now 500 ms later
Wait 500 ms			
100	8	E8 03 00 00 00 00 00 00	Broadcast message reporting time is now 500 ms later
Wait 500 ms			
100	8	DC 05 00 00 00 00 00 00	Broadcast message reporting time is now 500 ms later
Wait 500 ms			
100	8	D0 07 00 00 00 00 00 00	Broadcast message reporting time is now 500 ms later
Wait 500 ms			
100	8	C4 09 00 00 00 00 00 00	Broadcast message reporting time is now 500 ms later
Wait 500 ms			
100	8	B8 0B 00 00 00 00 00 00	Broadcast message reporting time is now 500 ms later

## 1.5 SDO vs. PDO Messages

There are two methods for reading and writing data to objects: Service Data Object (SDO) and Process Data Object (PDO) messages. An SDO consists of an outgoing message from host to node, possibly some intermediate messages between host and node, and a reply message from node to host; this is referred to as confirmed messaging. A PDO consists of a single unconfirmed message that requires less bus traffic relative to its SDO counterpart. Although PDOs make more efficient use of the CAN bus than do SDOs, PDO messages must be configured prior to using (see [PDO Configuration](#)). Furthermore, PDOs are restricted to the transmission of no more than 8 bytes whereas there is no limitation to the number of bytes SDOs can transfer. SDO messages may be used any time but are generally used before actual drive operation for set-up and configuration. PDO messages are generally used during drive operation, such as for setting target commands.

### 1.5.1 SDO Messages

AMC CANopen servo drives support read and write SDO messages that can be divided into 4 categories:

- Reading objects that contain 4 or less data bytes (expedited read)
- Writing to objects that contain 4 or less data bytes (expedited write)
- Reading objects that contain more than 4 data bytes (segmented read)
- Writing to objects that contain more than 4 data bytes (segmented write)

The first data byte in the Data field, called the ‘command’ byte, is used to determine any of the above possible cases. Then, depending upon the particular case, the next 3 bytes may be used to specify an object index with 4 bytes left for object data or all 7 remaining bytes may be used purely for object data. It is important to distinguish between the data bytes of the Data field and the data bytes of an object. The data bytes of the Data field are the 8 bytes of a CAN frame whereas the object data bytes refer to the information stored in an object. Of the bytes used for object data, only some may be used with the others left empty (equal to zero). For example, if an SDO message is used to read an object with only 2 bytes of information, then only two of the data bytes in the returned message will contain the relevant data while the others will be left equal to zero. However, there may be cases where the relevant data is also equal to zero. In this case, there must be a way to distinguish relevant data bytes from empty data bytes. If the message recipient knows how many bytes to expect, then there is no issue. Otherwise, size indication is needed. Although size indication is specified in DS301 it is also not required. To comply with this, AMC CANopen drives offer an SDO Size Indication object (2111h) for enabling and disabling size indication as defined by DS301.

**Expedited SDO Messages** This is a 1-step process and applies only when reading / writing objects with 4 or less data bytes (e.g. 8-bit, 16-bit, 32-bit data types). Expedited messages are simple read / write commands where the complete set of data is included in the last four bytes of the message (write command), or the last 4 bytes of the reply (read command). Whether the host is reading or writing to a node, the process requires only one command and one reply.

**Segmented SDO Messages** This is a multi-step process that applies when reading / writing messages larger than 4 bytes (e.g. string). Step 1, called “initiation,” is merely handshaking between the host and node. To initialize communication, the host gives a command, and the node responds confirming that it is ready for data exchange. No data is exchanged during the initiation step. The next steps are the actual data exchange. This can include many messages between the host and the node. The command byte, in these steps, contains a “Toggle Bit” and “Last Segment” bit. In these steps, every message the host sends to the drive must alternate the toggle bit (this is done automatically by following the procedures for message construction below). The last segment bit is only set to 1 when the current message contains the last of the data to transfer; this indicates that the process is finished. Only one SDO message can be transmitted at a time. That is, you cannot request an expedited SDO mid-way through a segmented SDO and then continue the segmented SDO.

**TABLE 1.24** Expedited SDO Read (4 or less data bytes)

SDO READ, EXPEDITED (4 or less bytes)									
Step 1a: Host initiates Read command									
Arbitration Field	Data Field								
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	
600h + Node-ID*	40h	Object Index (LSB)	Object Index (MSB)	Sub-Index	Use 00h for all 4 bytes				
Step 1b: Node Replies to host with all data									
Arbitration Field	Data Field								

COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
580h + Node-ID*	42h, 4Fh, 4Bh, or 43h See <a href="#">Table 1.26</a>	Object Index (LSB)	Object Index (MSB)	Sub-Index	Data, LSB first			

\*Node-ID is node address (0...7Fh)

**TABLE 1.25** Host to node Initiate read, more than 4 bytes

SDO READ, SEGMENTED (more than 4 bytes)															
STEP 1a. Host request for data															
Arbitration Field	Data Field														
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8							
600h + Node-ID*	40h	Object Index (LSB)	Object Index (MSB)	Sub-Index	Use 00h for all 4 bytes										
STEP 1b. Node reply, ready to transmit data															
Arbitration Field	Data Field														
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8							
580h + Node-ID*	40h or 41h See <a href="#">Table 1.26</a> STEP 1	Object Index (LSB)	Object Index (MSB)	Sub-Index	00h or Number of bytes to transfer										
STEP 2a. Host confirms, ready for data															
Arbitration Field	Data Field														
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8							
600h + Node-ID*	60h See <a href="#">Table 1.26</a> STEP 2	Use 00h for all 7 bytes													
STEP 2b. Node replies with data															
Arbitration Field	Data Field														
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8							
580h + Node-ID*	See <a href="#">Table 1.26</a> STEP 2	Data, LSB first													

\*Node-ID is node address (0...7Fh)

**TABLE 1.26** READ Command (Byte 1) values and their meaning

<b>Usage</b>	<b>Command Byte values</b>	<b>Meaning</b>
Read SDO Step 1	40h	Always used by host when initiating read process. Does not include size indication. Used by node when replying to hosts' initiate read command, but only when object 2111h = 0 and there are more than 4 bytes to transfer.
	41h	Used by node only when replying to read initiation and there are more than 4 bytes to transfer. Bytes 5 – 8 will indicate number of bytes the node has to transfer (LSB first). Only occurs if object 2111h ≠ 0, otherwise node will reply with 40h instead.
	42h	Used by node when replying to read command with 4 or less data bytes in 5 – 8 (LSB first). Actual number of valid bytes is not indicated. Only occurs if object 2111h = 0.
	4Fh	Used by node when replying to read command with exactly 1 data byte, i.e. reading an 8-bit object. Use only byte 5 (ignore 6 - 8). Only occurs if object 2111h ≠ 0, otherwise node will use 42h.
	4Bh	Used by node when replying to read command with exactly 2 data bytes in bytes 5 and 6, i.e. reading a 16-bit object (ignore 7 and 8). Only occurs if object 2111h ≠ 0, otherwise node will use 42h.
	43h	Used by node when replying to read command with exactly 4 data bytes in bytes 5 – 8, i.e. reading a 32-bit object. Only occurs if object 2111h ≠ 0, otherwise node will use 42h.
Read SDO Step 2 Only data transfers larger than 4 bytes	60h	Used by host. Second step to "Segmented" read process always begins with 60h. Each time the node replies with data, the host must toggle between 60h and 70h. If the host does not toggle between two consecutive messages, the node will abort transfer with 80h.
	70h	Reply from node. Will only occur if host used 60h in the previous command and there is more data to transmit. In this case the host should send another message using 70h in byte 1 and 00h for all other bytes to retrieve more data.
	0h	Reply from node. Will only occur if host used 60h in the previous command and this message contains the last of the data.
	1h	Reply from node. Will only occur if host used 70h in the previous command and there is more data to transmit. In this case the host should send another message using 60h in byte 1 and 00h for all other bytes to retrieve more data.
	10h	Reply from node. Will only occur if host used 70h in the previous command and this message contains the last of the data.
	11h	Reply from node. Will only occur if host used 70h in the previous command and this message contains the last of the data.
	3h, 5h, 7h, 9h, Bh, Dh	Same as 1h except the number of bytes not containing data is specified. 3h if only the last byte contains no data, 5h if only the last two bytes do not contain data, and onwards up to Dh if the last 6 bytes do not contain data. Only occurs if object 2111h ≠ 0, otherwise node will reply with 1h.
	13h, 15h, 17h, 19h, 1Bh, 1Dh	Same as 11h except the number of bytes not containing data is specified. 13h if only the last byte contains no data, 15h if only the last two bytes do not contain data, and onwards up to 1Dh if the last 6 bytes do not contain data. Only occurs if object 2111h ≠ 0, otherwise node will reply with 11h.

**TABLE 1.27** Expedited SDO Write (4 or less data bytes)

SDO WRITE, EXPEDITED (4 or less data bytes)												
Step 1a: Host initiates write command with data												
Arbitration Field	Data Field											
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8				
600h + Node-ID*	22h, 2Fh, 2Bh, or 23h See <a href="#">Table 1.29</a>	Object Index (LSB)	Object Index (MSB)	Sub-Index	Data, LSB first							
Step 1b: Node Replies to host with all data												
Arbitration Field	Data Field											
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8				
580h + Node-ID*	60h See <a href="#">Table 1.29</a>	Object Index (LSB)	Object Index (MSB)	Sub-Index	Ignore							

\*Node-ID is node address (0...7Fh)

**TABLE 1.28** Host to node Initiate write, more than 4 bytes

SDO WRITE, SEGMENTED (more than 4 data bytes)															
STEP 1a. Host initiates data transfer															
Arbitration Field	Data Field														
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8							
600h + Node-ID*	20h or 21h See <a href="#">Table 1.29</a>	Object Index (LSB)	Object Index (MSB)	Sub-Index	00h or Number of bytes to transfer										
STEP 1b. Node reply, ready to accept data															
Arbitration Field	Data Field														
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8							
580h + Node-ID*	60h See <a href="#">Table 1.29</a>	Object Index (LSB)	Object Index (MSB)	Sub-Index	00h										
STEP 2a. Host begins data transfer															
Arbitration Field	Data Field														
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8							
600h + Node-ID*	0h, 1h, 10h, 11h See <a href="#">Table 1.29</a>	Data, LSB first													
STEP 2b. Node replies															
Arbitration Field	Data Field														
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8							
580h + Node-ID*	20h, or 30h See <a href="#">Table 1.29</a>	Ignore													

\*Node-ID is node address (0...7Fh)

**TABLE 1.29** WRITE Command (Byte 1) values and their meaning

Usage	Command Byte values	Meaning
Host Initiates Write SDO more than 4 data bytes	20h	Used by host when initiating a write process of more than 4 data bytes. Total number of bytes is not indicated. Node replies with 60h, confirming that it is ready to receive data.
	21h	Used by host when initiating a write process of more than 4 data bytes. Total number of bytes is indicated using bytes 5 – 8 (LSB first). Node replies with 60h, confirming that it is ready to receive data. Only use if object 2111h ≠ 0, otherwise use 20h.
Host Initiates Write SDO 4 or less data bytes	22h	Used by host when writing 4 or less data bytes. Total number of data bytes not indicated. Node replies with confirmation 60h.
	2Fh	Used by host when writing exactly 1 data byte. Byte 5 contains data. Node replies with confirmation 60h. Only use if object 2111h ≠ 0, otherwise use 22h.
	2Bh	Used by host when writing exactly 2 data bytes. Byte 5 and 6 contain data. Node replies with confirmation 60h. Only use if object 2111h ≠ 0, otherwise use 22h.
	23h	Used by host when writing exactly 4 data bytes. Bytes 5 – 8 contain data. Node replies with confirmation 60h. Only use if object 2111h ≠ 0, otherwise use 22h.
Data transfer commands	60h	Reply from node. 60h only occurs once during the initiate write process, after that each consecutive reply to a message containing data will toggle between 20h and 30h. 20h always occurs first after 60h.
	20h	
	30h	
	00h	Used by host if the nodes previous reply contained 60h or 30h in byte 1 and there is still data left to transmit.
	1h	Used by host if the nodes previous reply contained 60h or 30h in byte 1 and this message contains the last data to transfer.
	10h	Used by host if the nodes previous reply contained 20h in byte 1 and there is still data left to transmit.
	11h	Used by host if the nodes previous reply contained 20h in byte 1 and this message contains the last data to transfer.
	3h, 5h, 7h, 9h, Bh, Dh	Same as 1h except the number of bytes not containing data is specified. 3h if only the last byte contains no data, 5h if only the last two bytes do not contain data, and onwards up to Dh if the last 6 bytes do not contain data. Only use if object 2111h ≠ 0, otherwise use 1h.
	13h, 15h, 17h, 19h, 1Bh, 1Dh	Same as 11h except the number of bytes not containing data is specified. 13h if only the last byte contains no data, 15h if only the last two bytes do not contain data, and onwards up to 1Dh if the last 6 bytes do not contain data. Only use if object 2111h ≠ 0, otherwise use 11h.

**SDO Abort Transfer Messages** When an error occurs during reading or writing an object, the node sends an abort transfer message to the host.

**TABLE 1.30** Node indicates error in communication.

Arbitration Field	Data Field								
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	
580h + Node-ID	80h	ObjectIndex (LSB)	ObjectIndex (MSB)	Sub-Index	See <a href="#">Table 1.31</a> (LSB first)				

**TABLE 1.31** Abort Code Descriptions

<b>Abort Code</b>	<b>Description</b>
0503 0000h	Toggle bit not alternated
0504 0000h	SDO protocol timed out
0504 0001h	Command specifier not valid
0504 0002h	Invalid block size (block mode only, see DS301)
0504 0003h	Invalid sequence number (block mode only, see DS301)
0504 0004h	CRC error (block mode only, see DS301)
0504 0005h	Out of memory
0601 0000h	Unsupported access to an object
0601 0001h	Attempt to read a write only object
0601 0002h	Attempt to write a read only object
0602 0000h	Object does not exist in the object dictionary
0604 0041h	Object cannot be mapped to the PDO
0604 0042h	The number and length of the objects to be mapped would exceed PDO length
0604 0043h	General parameter incompatibility reason
0604 0047h	General internal incompatibility in the device
0606 0000h	Access failed due to a hardware error
0607 0010h	Data type does not match, length of service parameter does not match
0607 0012h	Data type does not match, length of service parameter too high
0607 0013h	Data type does not match, length of service parameter too low
0609 0011h	Sub-index does not exist
0609 0030h	Value range of parameter exceeded (only for write access)
0609 0031h	Value of parameter written too high
0609 0032h	Value of parameter written too low
0609 0036h	Maximum value is less than minimum value
0800 0000h	General error
0800 0020h	Data cannot be transferred or stored to the application
0800 0021h	Data cannot be transferred or stored to the application because of local control
0800 0022h	Data cannot be transferred or stored to the application because of present device state
0800 0023h	Object dictionary dynamic generation fails or no object dictionary is present (object dictionary loads from file and file error occurred)

## SDO Read and Write Examples

### Expedited SDO Read Example

In this example, Size indication (object 2111h) is turned off so that the drive will not indicate, in any message, how many valid bytes are contained in the message. In this case the user is responsible for knowing the message size.

**TABLE 1.32** Expedited SDO Read Example

COB-ID	Number of Bytes	Message / Data	Description
601	8	40 64 60 00 00 00 00 00	Host uses 40 in the command byte (see <a href="#">Table 1.26</a> ) to read object 6064h, the 3 <sup>rd</sup> data byte is zero because this object has no sub-indices and the last 4 data bytes are don't care's when reading
581	8	42 64 60 00 34 33 00 00	Node replies with 42 because size indication is off (see <a href="#">Table 1.26</a> ) and message was received as an expedited data transfer. Bytes 5 – 8 will contain the data from the object. In this case object 6064h (Actual Position) contains 00 00 33 34h (13,108 in decimal).

### Expedited SDO Write Example

In this example, Size indication (object 2111h) is turned off so that the drive will not indicate, in any message, how many valid bytes are contained in the message. When writing data to a node, it is not required for the host to use size indications in the messages to the node. In this case the user is responsible for knowing the message size and for using the command byte 22h.

**TABLE 1.33** Expedited SDO Write Example

COB-ID	Number of Bytes	Message / Data	Description
601	8	22 40 60 00 0F 00 00 00	Host uses 22 in the command byte (see <a href="#">Table 1.29</a> ) to write object 6040h, the 3 <sup>rd</sup> data byte is zero because this object has no sub-indices. The last 4 data bytes contain the data to write to the object.
581	8	60 40 60 00 00 00 00 00	Node replies with 60 (see <a href="#">Table 1.29</a> ) indicating message was received. Bytes 1-3 contain the object index and sub-index. Bytes 4 – 7 will always be zero in this case

### Segmented SDO Read Example

In this example, the firmware version of the drive is read from object 208D.01. Furthermore, it will be assumed that size indication (see object 2111h) is turned on so that the drive will indicate, in any message that contains less than 7 data bytes, how many valid bytes are contained in the message. Node replies to each host message are shaded. When the applicable data bytes from the last 5 shaded rows is concatenated and converted to ASCII, the data reads "ABCDEFG-1.2.3.4".

**TABLE 1.34** Segmented SDO Read Example

COB-ID	Number of Bytes	Message / Data	Description
601	8	40 8D 20 01 00 00 00 00	Host begins data transfer Initialization
581	8	41 8D 20 01 20 00 00 00	Node replies with 41 indicating there are more than 4 bytes to transfer. Bytes 4 – 7 indicate the number of bytes necessary to transfer. In this case 20h = 32 bytes. The drive now waits for the host to begin data transfer confirmation.
601	8	60 00 00 00 00 00 00 00	Host uses 60 to confirm ready for first segment. All other bytes are zero
581	8	00 41 42 43 44 45 46 47	Node responds to host with 00h and 7 data bytes.
601	8	70 00 00 00 00 00 00 00	Host uses 70 to confirm ready for next segment. All other bytes are zero
581	8	10 2D 31 2E 32 2E 33 2E	Node responds to host with 10h and 7 data bytes.
601	8	60 00 00 00 00 00 00 00	Host uses 60 to confirm ready for next segment. All other bytes are zero
581	8	00 34 00 00 00 00 00 00	Node responds to host with 00h and 7 data bytes.
601	8	70 00 00 00 00 00 00 00	Host uses 70 to confirm ready for next segment. All other bytes are zero
581	8	10 00 00 00 00 00 00 00	Node responds to host with 10h and 7 data bytes.
601	8	60 00 00 00 00 00 00 00	Host uses 60 to confirm ready for next segment. All other bytes are zero
581	8	07 00 00 00 00 00 00 00	Node responds to host with 07h and 7 data bytes. The 07h indicates that the last three bytes are to be ignored.

### Segmented SDO Write Example

In this example, Size indication (object 2111h) is turned **on** so that the drive **will indicate**, in any message that contains less than 7 data bytes, how many valid bytes are contained in the message. When writing data to a node, it is not required for the host to use size indications in the messages to the node. Node replies to each host message are shaded. Data must be sent to the node according to each objects required format. See the Object dictionary for more information on writing to a specific object.

**TABLE 1.35** Segmented SDO Write Example

COB-ID	Number of Bytes	Message / Data	Description
601	8	20 0B 20 01 00 00 00 00	Host begins data transfer Initialization
581	8	60 0B 20 01 00 00 00 00	Node replies with 60 confirming message receipt and ready for first segment.
601	8	00 57 69 6C 6C 20 45 6C	Host uses 00 to begin data transfer protocol. Last 7 bytes contain data.
581	8	20 57 69 6C 00 00 00 00	Node responds to host with 20h. Ignore Last 7 bytes
601	8	11 6B 69 6E 73 20 45 6C	Host uses 11 to indicate "Last Segment". Any bytes that are more than an objects length will no be written.

## 1.5.2 PDO Messages

PDO messages exchange information between the host and nodes without the overhead of SDO messages. PDO messages have no reply, (i.e. they are unconfirmed messages) which allows for fast, efficient data transfer of up to 8 bytes. As a result, PDOs are ideal for transferring information during device operation whereas SDOs are generally used for configuring the drive. PDO messages, unlike SDO messages, are configured prior to use. Once configured, PDO messages can be enabled or disabled according to whether or not they are needed. There are two types of PDO messages: a transmit PDO (TPDO) message and a receive PDO (RPDO) message.

**Transmit Process Data Objects (TPDO)** TPDOs are configured to send data from node to host according to a configurable trigger mechanism or when requested by an RTR. Before data is transmitted by a TPDO, it must be configured, and enabled, with the “[Communication Parameter Object](#)” related to that TPDO. TPDOs do not alter any object data; they only read and transmit data to the CAN bus. AMC CANopen drives offer ten different TPDOs (all are disabled by default). Nine have fixed pre-defined configurations and one is available for user specification.


**Receive Process Data Objects (RPDO)** The host uses RPDOs to write data to objects in one or more nodes. Before data is received by an RPDO, it must be configured, and enabled, with a “[Communication Parameter Object](#)” related to that RPDO. Since RPDOs write to object data, it is important to ensure that the data sent is in agreement with the objects mapped to the PDO (PDO object mapping is discussed below). AMC CANopen drives offer nine different RPDOs where all are disabled by default.

**PDO Configuration** Configuration of a particular PDO is accomplished by setting the appropriate PDO “[Communication Parameter Object](#)” and PDO Mapping Parameter object “[Mapping Parameter Object](#)” for that PDO. It is the user’s responsibility to decide which of the PDOs in [Table 1.36](#) are applicable to the application and configure/enable them. As specified by DS301, the PDO Communication Parameter objects are found over the range 1400h-15FFh and 1800h-19FFh for RPDOs and TPDOs, respectively. PDO Mapping Parameter objects are specified over the range 1600h-17FFh and 1A00h-1BFFh for RPDOs and TPDOs, respectively. Although the full range allows for over 500 different RPDOs and TPDOs, only a fraction of that range is needed for AMC CANopen drives. The PDOs used by AMC CANopen drives are given in [Table 1.36](#) along with the names of objects mapped to them. Only one TPDO (26th) can be mapped; all other TPDOs and RPDOs have fixed mapping parameters.

**TABLE 1.36** PDO's

PDO	PDO Communication Parameter	PDO Mapping Parameter	1 <sup>st</sup> Object Mapping	2 <sup>nd</sup> Object Mapping
1 <sup>st</sup> RPDO	1400h	1600h	ControlWord	-
2 <sup>nd</sup> RPDO	1401h	1601h	ControlWord	Modes of Operation
3 <sup>rd</sup> RPDO	1402h	1602h	ControlWord	Target Position
4 <sup>th</sup> RPDO	1403h	1603h	ControlWord	Target Velocity
5 <sup>th</sup> RPDO	1404h	1604h	ControlWord	Target Current
21 <sup>st</sup> RPDO	1414h	1614h	Target Position	-
22 <sup>nd</sup> RPDO	1415h	1615h	Target Velocity	-
23 <sup>rd</sup> RPDO	1416h	1616h	Target Current	-
24 <sup>th</sup> RPDO	1417h	1617h	PVT Buffer	-
1 <sup>st</sup> TPDO	1800h	1A00h	StatusWord	-
3 <sup>rd</sup> TPDO	1802h	1A02h	StatusWord	Actual Position
4 <sup>th</sup> TPDO	1803h	1A03h	StatusWord	Actual Velocity
5 <sup>th</sup> TPDO	1804h	1A04h	StatusWord	Actual Current
21 <sup>st</sup> TPDO	1814h	1A14h	Actual Position	-
22 <sup>nd</sup> TPDO	1815h	1A15h	Actual Velocity	-
23 <sup>rd</sup> TPDO	1816h	1A16h	Actual Current	-
24 <sup>th</sup> TPDO	1817h	1A17h	PVT Buffer Position	-
25 <sup>th</sup> TPDO	1818h	1A18h	Prog. Digital Inputs	-
26 <sup>th</sup> TPDO	1819h	1A19h	Configurable. Contains 8 locations available for mapping objects. (See 1A19.01-1A19.08)	

The relationship between a PDO Mapping parameter and Communication parameter is illustrated in [Figure 1.4](#). The fact that PDO parameter objects are configured prior to any PDO messages being sent is what allows for all eight bytes of the PDO message to be used for data. The overall result is faster, more efficient data transfer and no additional bus usage for confirmation.

**FIGURE 1.4** PDO Configuration Parameters

**Communication Parameter Object** The Communication Parameter object contains information regarding the COB-ID and transmission type of the PDO. The COB-ID and other settings are stored in sub-index 01h while the transmission type is stored in sub-index 02h. For example, the COB-ID of the 1<sup>st</sup> TPDO would be found at sub-index 1800.01h while the transmission type would be defined by sub-index 1800.02h. The details of choosing a COB-ID and setting the transmission type are explained below.

### Setting COB-ID's for each PDO

A unique COB-ID (unique with respect to the entire CANopen network, not just the node) must be assigned to each PDO which will be used over the CAN network. It is the system designer's responsibility to ensure that all PDOs have a unique COB-ID. It is best to assign the COB-IDs in a logical order, with the most important PDOs assigned to the lowest COB-IDs. The range of possible values is 181h-57Fh.

Sub-index 01h of each PDO's Communication Parameter object contains the COB-ID and is a 32-bit data field partitioned into five components as shown in [Table 1.37](#). [Table 1.38](#) summarizes how these partitions are defined and [Table 1.36](#) lists the object index for each PDO's Communication Parameter object.

**TABLE 1.37** PDO COB-ID structure

Bit 31	Bit 30	Bit 29	Bits 28 – 11	Bits 10 – 0
0/1	0/1	0	000000000000000000000000	COB-ID

**TABLE 1.38** COB-ID bit definitions

Bit Number	Value	Description
31(msb)	0	PDO message is enabled and will respond to the assigned trigger mechanism.
	1	PDO message is disabled and will not respond to the assigned trigger mechanism. This is the default state for all PDOs.
30	0	RTR allowed on this PDO.
	1	No RTR allowed on this PDO.
29	0	Use 0 for AMC drives (selects CAN 2.0A).
28-11	0	Use 0 for AMC drives (non-zero values reserved for CAN 2.0B).
10-0 (lsb)	11-bit Identifier	Holds the 11-bit identifier (COB-ID) of the PDO. Use the default value or set-up the priority for each PDO by setting this value closer to the value 181h, which has the highest PDO priority on a CAN network.

### Transmission Type

Sub-index 02h of each PDO's Communication Parameter object is an 8-bit data field that defines the transmission type. Setting the value of this sub-index to an appropriate value, as given in [Table 1.39](#), sets the transmission type. Note that there is a range of valid values for some transmission types. The "asynchronous" transmission type, for example, is set using a value of 254 or 255 (FEh or FFh).

**TABLE 1.39** PDO Transmission Type selection table

PDO Transmission Description			
Value	Transmission Type	TPDO	RPDO
00h	Synchronous Acyclic	PDO is transmitted on the next Sync message following an internal event. In addition, the PDO can be transmitted immediately following an RTR request.	The received data is held until the next Sync message. When the Sync message is received the data is applied
01h - F0h	Synchronous Cyclic	PDO's are transmitted with relation to the Sync object. The number (01h-F0h) represents the number of Sync pulses between consecutive PDO transmissions. In addition, the PDO can be transmitted immediately following an RTR request or internal event.	
F1h - FBh	N/A	Reserved	Reserved
FCh	Synchronous RTR	PDO's are only transmitted following the first Sync message after a remote request or immediately following an internal event.	Reserved
FDh	Asynchronous	PDO's are transmitted immediately following an internal event or RTR request.	Reserved
FEh - FFh			The received data is applied to its mapped objects immediately

**Mapping Parameter Object** The mapping parameter object contains information about each object mapped to a PDO. Each object that is mapped is represented by a sub-index in the Mapping Parameter object. So if, for example, a PDO has  $n$  number of mapped objects then the PDO's mapping parameter object will have sub-indices 1 through  $n$ . Each sub-index contains a 32-bit field partitioned into 3 components as shown in [Table 1.40](#).

**TABLE 1.40** Mapping Parameter bit descriptions

Bits 31 – 16	Bits 15 – 8	Bits 7 – 0
Index	Sub Index	Object Length

The three components that represent a mapped object are described below:

- **Index:** The index of the object mapped to the PDO (zero if no object is mapped).
- **Sub-index:** The sub-index of the mapped object and the location of the data to be transmitted (zero if the object has no sub-indices).
- **Object Length:** The bit length (in hex) of the data to be transmitted. For example, 20h = 32 bits.

By placing information about an object in the Mapping Parameter, that object becomes mapped to the associated PDO. Mapping allows PDOs to know where they should read their data prior to transmission (in the case of TPDOs) or where they should write their data upon reception (in the case of RPDOs). Although DS301 allows up to 64 objects to be mapped to a single PDO, the number that can actually be mapped is ultimately determined by the total amount of the data mapped to the PDO. If, for example, a single object with an 8-byte (64-bit) data length is mapped to a PDO, then no other objects can be mapped to that same PDO since all 8-bytes of the data field will already be consumed. Mapped data is inserted into the data field of the PDO according to the order of mapping. That is, the data from the first mapped object consumes the first available byte (or bytes), and then data from the second mapped object consumes the next available byte (or bytes), and so on until all data bytes have been consumed or there is no more object data to map.

**RTR bit and TPDOs** Once a PDO has been configured and enabled, the host can use the RTR bit to request a TPDO from a node. This supplies the host with a fast and efficient on-demand method of retrieving information from a node. To request a TPDO, the host must send a message with the RTR bit set to 1 and a COB-ID that corresponds to the desired TPDO.

**AMC PDO Assignment and Mapping** AMC CANopen drives support 8 RPDOs and 10 TPDOs, all of which can be assigned to a user-specified COB-ID. All 8 RPDOs are mapped to fixed, pre-defined objects and, as a result, only the Communication Parameter of an RPDO can be changed.

Similarly, all TPDOs, with the exception of TPDO 26, are mapped to fixed pre-defined objects and, again, only their Communication Parameters can be changed. The single exception, TPDO 26, is available for mapping up to 8 user specified application objects. All TPDOs can be assigned user-specified trigger mechanisms based on either timing or object data changes as explained in the following section. Some TPDOs, however, have fixed predefined trigger mechanisms. To know if a TPDO has a predefined trigger, check the description of that TPDO in the Object Dictionary.

**AMC Asynchronous Transmission Events** AMC CANopen drives support 3 basic asynchronous event types:

- Time based: the drive transmits the selected TPDOs when a certain amount of time has elapsed. There are 2 internal timer objects available. Any of the TPDOs can be mapped to either or both timers.
- Value based: the drive monitors a certain object (presumably of a numerical type), and when the object has changed by a certain amount, the selected TPDOs will be transmitted. Two value counters exist, one watches for the mapped object to change by a specified amount, the other watches for the mapped object to reach a specific value. Any of the TPDOs can be mapped to either or both of the Value Counters.

- Bit based: the drive monitors a certain object (presumably of a bit-pattern type), and when a bit in that object changes (from 0 to 1 or 1 to 0), the selected TPDOs will be transmitted. Any of the TPDOs can be mapped to either or both of the Bit Watch processes.

The objects used to configure these asynchronous events, as well as some objects supplied for reading information about these events, are summarized in [Table 1.41](#).

**TABLE 1.41** Asynchronous TPDO Transmission Events

Event Type	Event	Object Name	Object Index	Object Type
Time Based	Timer1	TPDO Timer1 Cycle Time	2120h	Configurable
		TPDO Timer1 Assigned TPDOs	2121h	Configurable
		TPDO Timer1 Next Processing Time	2122h	Informational
	Timer2	TPDO Timer2 Cycle Time	2123h	Configurable
		TPDO Timer2 Assigned TPDOs	2124h	Configurable
		TPDO Timer2 Next Processing Time	2125h	Informational
Value Based	Value-Changed	TPDO Value-Changed Object ID	2130h	Configurable
		TPDO Value-Changed Delta Value	2131h	Configurable
		TPDO Value-Changed Assigned TPDOs	2132h	Configurable
		TPDO Value-Changed Object Last Value	2133h	Informational
	Value-Reached	TPDO Value-Reached Object ID	2150h	Configurable
		TPDO Value-Reached	2151h	Configurable
		TPDO Value-Reached Assigned TPDOs	2152h	Configurable
		TPDO Value-Reached Direction	2153h	Configurable
Bit Based	Bits-Changed1	TPDO Bits-Changed1 Object ID	2140h	Configurable
		TPDO Bits-Changed1 Object Bit Mask	2141h	Configurable
		TPDO Bits-Changed1 Assigned TPDOs	2142h	Configurable
		TPDO Bits-Changed1 Object Last Value	2143h	Informational
	Bits-Changed2	TPDO Bits-Changed1 Object ID	2144h	Configurable
		TPDO Bits-Changed1 Object Bit Mask	2145h	Configurable
		TPDO Bits-Changed1 Assigned TPDOs	2146h	Configurable
		TPDO Bits-Changed1 Object Last Value	2147h	Informational

Please refer to the Object Dictionary section for more details on these objects.

## PDO Message Examples

### PDO Configuration Example

This example demonstrates using expedited SDO messages to configure two PDOs (there is no need to use segmented SDO's in this case because data is less than 4 bytes). Each PDO is enabled, assigned a COB-ID, and the trigger mechanisms set to an arbitrary mechanism.

**TABLE 1.42** PDO Configuration Example

COB-ID	Number of Bytes	Message / Data	Description
601	8	22 01 14 01 81 01 00 00	Writing COB-ID 181 to 2 <sup>nd</sup> RPDO (1401.01). Setting bit 32 here to 0 enables the PDO to be processed
601	8	22 01 14 02 FE 00 00 00	Setting trigger mechanism of 2 <sup>nd</sup> RPDO (1401.02) to respond Immediately upon receipt of data. (See <a href="#">Table 1.39</a> )
601	8	22 14 18 01 85 01 00 00	Writing COB-ID 185 to 21 <sup>st</sup> TPDO (1814.01) Setting bit 32 here to 0 enables the PDO to be processed
601	8	22 14 18 02 01 00 00 00	Setting trigger mechanism of 21 <sup>st</sup> TPDO (1814.01) to respond only upon receipt of a SYNC message. (See <a href="#">Table 1.39</a> )
000	2	01 01	Sending NMT message to start node 1 communication state machine so that PDO messages may be processed.
181	4	06 00 01 00	Using 2 <sup>nd</sup> RPDO to set the drive into Profile Position Mode and the Shutdown control state
181	4	07 00 01 00	Using 2 <sup>nd</sup> RPDO to keep the drive in Profile Position Mode and set the Operation Disabled control state
181	4	0F 00 01 00	Using 2 <sup>nd</sup> RPDO to keep the drive in Profile Position Mode and set the Operational Enabled control state
80	1	00	Start sending SYNC messages to cause the SYNC triggered TPDOs to send data to the host.
185		FF FF FF FF	21 <sup>st</sup> TPDO response to SYNC message containing actual position = -1 counts
80	1	00	Next SYNC message from host
185		02 00 00 00	21 <sup>st</sup> TPDO response to SYNC message containing actual position = 2 counts
80	1	00	Next SYNC message from host
185		05 00 00 00	21 <sup>st</sup> TPDO response to SYNC message containing actual position = 5 counts

### Asynchronous TPDO Transmission Example # 1

This example sets the timer1 event to 1000ms and assigns three TPDOs to transmit on every timer1 event. Prior to this example TPDOs have been assigned valid COB-IDs and are enabled.

**TABLE 1.43** Asynchronous TPDO Transmission Example #1

COB-ID	Number of Bytes	Message / Data	Description
000	2	01 01	Sending NMT message to start node 1 communication state machine so that PDO messages may be processed.
601	8	22 20 21 00 E8 03 00 00	Writing 1000 to object 2120.00. This sets the event timer to 1s intervals
601	8	22 21 21 00 23 00 00 00	Writing to bit-mask such that TPDOs 1, 3, and 22 are assigned to transmit according to the timer object
Wait 1000 ms			
181	2	21 06	1 <sup>st</sup> TPDO transmits after 1 second with it's data
281	6	21 06 FE FF FF FF	3 <sup>rd</sup> TPDO transmits the same time as the 1 <sup>st</sup> TPDO
2C1	4	00 00 00 00	22 <sup>nd</sup> TPDO transmits the same time as the 1 <sup>st</sup> TPDO
601	8	40 22 21 00 00 00 00 00	Host sends SDO message to read 2122.00 for next timer1 event occurrence.
581	8	42 22 21 00 B2 ED 97 02	Node indicates next event occurs at 43511218 ms
Wait 1000 ms			
181	2	21 06	1 <sup>st</sup> TPDO transmits after 1 second with it's data
281	6	21 06 FE FF FF FF	3 <sup>rd</sup> TPDO transmits the same time as the 1 <sup>st</sup> TPDO
2C1	4	00 00 00 00	22 <sup>nd</sup> TPDO transmits the same time as the 1 <sup>st</sup> TPDO
601	8	40 22 21 00 00 00 00 00	Host sends SDO message to read 2122.00 for next timer1 event occurrence.
581	8	42 22 21 00 B2 ED 97 02	Node indicates next event occurs at 43512218 ms
...			
601	8	22 21 21 00 00 00 00 00	Host writes to bit-mask such that no TPDOs are assigned to transmit. This stops the Timer1 event.

## Asynchronous TPDO Transmission Example # 2

This example uses the bit based transmission events to monitor specific bits in the Actual Position object (6064h). Prior to this example TPDOs have been assigned valid COB-IDs and are enabled

**TABLE 1.44** Asynchronous TPDO Transmission Example #2

COB-ID	Number of Bytes	Message / Data	Description
000	2	01 01	Sending NMT message to start node 1 communication state machine so that PDO messages may be processed
601	8	22 40 21 00 00 64 60 00	Writing 60 64 00 to object 2140.00. This sets the Bit-Watch1 event to monitor object 6064h. Byte 8 is always 00
601	8	22 41 21 00 00 02 00 00	Writing the exact bits to watch such that TPDOs will transmit when these/ this bit changes. This example watches bit 10
601	8	22 42 21 00 23 00 00 00	Writing the Bit-mask to assign TPDOs 1, 3, and 22 to transmit on the bit change event
Wait until Bit 10 toggles			
181	2	21 06	1 <sup>st</sup> TPDO transmits after bit 10 toggle
281	6	21 06 FE FF FF FF	3 <sup>rd</sup> TPDO transmits the same time as the 1 <sup>st</sup> TPDO
2C1	4	00 00 00 00	22 <sup>nd</sup> TPDO transmits the same time as the 1 <sup>st</sup> TPDO
601	8	40 43 21 00 00 00 00 00	Host sends SDO message to read 2143.00 for last value of monitored object. This is optional
581	8	42 22 21 00 FE FF FF FF	Node indicates the last value contained -2
Wait until Bit 10 toggles			
181	2	21 02	1 <sup>st</sup> TPDO transmits after bit 10 toggle
281	6	21 02 00 00 00 00	3 <sup>rd</sup> TPDO transmits the same time as the 1 <sup>st</sup> TPDO
2C1	4	4D 34 00 00	22 <sup>nd</sup> TPDO transmits the same time as the 1 <sup>st</sup> TPDO
601	8	40 43 21 00 00 00 00 00	Host sends SDO message to read 2143.00 for last value of monitored object. This is optional
581	8	42 22 21 00 00 00 00 00	Node indicates the last value contained 0
...			
601	8	22 42 21 00 00 00 00 00	Host writes to bit-mask such that no TPDOs are assigned to transmit. This stops the Bit-Watch1 event

**PDO Mappable Objects** Only a subset of objects in the object dictionary may be mapped to a TPDO or RPDO. [Table 1.45](#) lists all PDO mappable objects. Data exchange with objects not listed in the table require an SDO.

**TABLE 1.45** PDO Mappable Objects


Type	Object Index	Sub-Index	Object Name	Mapping Access	PDO Allocation (bits)
Drive Operation	2001	02	User Bits	RPDO/TPDO	16
	6040	00	ControlWord	RPDO/TPDO	16
	6060	00	Modes of Operation	RPDO/TPDO	16
Command Objects	6071	00	Target Current	RPDO/TPDO	16
	607A	00	Target Position	RPDO Only	32
	60B1	00	Velocity Offset	RPDO/TPDO	32
	60B2	00	Torque Offset	RPDO/TPDO	16
	60F4	00	Position Error	TPDO Only	32
	60FF	00	Target Velocity	RPDO/TPDO	32
Monitor Objects	2002	01	Drive Bridge Status	TPDO Only	16
	2002	02	Drive Protection Status	TPDO Only	16
	2002	03	System Protection Status	TPDO Only	16
	2002	04	Drive/System Status 1	TPDO Only	16
	2002	05	Drive/System Status 2	TPDO Only	16
	2002	06	Drive/System Status 3	TPDO Only	16
	2003	01	Drive Bridge Status History	TPDO Only	16
	2003	02	Drive Protection Status History	TPDO Only	16
	2003	03	System Protection Status History	TPDO Only	16
	2003	04	Drive/System Status 1 History	TPDO Only	16
	2003	05	Drive/System Status 2 History	TPDO Only	16
	2003	06	Drive/System Status 3 History	TPDO Only	16
	200F	01	DC Bus Voltage	TPDO Only	16
	2010	02	Current Demand - Torque	TPDO Only	16
	2011	02	Velocity Measured - Post Filter	TPDO Only	32
	2011	05	Velocity Error	TPDO Only	32
	2012	01	Position Measured	TPDO Only	32
	2012	03	Position Demand	TPDO Only	32
	2019	01	Capture 'A' Value	TPDO Only	32
	2019	02	Capture 'B' Value	TPDO Only	32
	2019	03	Capture 'C' Value	TPDO Only	32
	201A	01	Analog Input 1 Value	TPDO Only	16
	201A	02	Analog Input 2 Value	TPDO Only	16
	201A	03	Analog Input 3 Value	TPDO Only	16
	201A	04	Analog Input 4 Value	TPDO Only	16
	201D	01	PVT Status Values	TPDO Only	16
	2021	01	External Thermal Sense Value	TPDO Only	32
	2021	02	Thermistor Resistance	TPDO Only	16
	2023	01	Digital Input Values	TPDO Only	16
	2025	01	Analog Output 1 Value	TPDO Only	16
	2025	02	Analog Output 2 Value	TPDO Only	16
	6041	00	Status Word	TPDO Only	16
	6061	00	Modes of Operation Display	TPDO Only	16
	6064	00	Actual Position	TPDO Only	32
	606B	00	Velocity Demand	TPDO Only	32
	606C	00	Actual Velocity	TPDO Only	32
	6077	00	Actual Current	TPDO Only	16

## 1.6 Control State Machine

### 1.6.1 State Machine Overview

CANopen drives operate based on a control state machine where each state has a defined behavior. The drive can be controlled to transition from one state to another in a particular order using the ControlWord object (6040h). This is a write only object used specifically to transition the drive's control state machine between states. Below is a graphical overview of the state machine. The grey boxes represent the states. The arrows represent the one-way path between states. The small text along the path of the arrow represents the command necessary to make each transition.

**FIGURE 1.5** ControlWord State Machine Block Diagram



Upon power-up, the drive will automatically step through the 'Start' and 'Not Ready to Switch On' states, arriving at the 'Switch On Disabled' state. Further advancement to other states is accomplished by setting the ControlWord (Object index 6040h) to the proper value. The commands that cause the state transitions in the state machine correspond to certain bit

settings within the ControlWord. For example, to transfer from the 'Ready to Switch On' state to the 'Switched On State', one would use the Switch On command, by setting the ControlWord to the appropriate value (and hence bit pattern). The drive state may be queried by using StatusWord (Object index 6041h). If the drive senses a fault, it will automatically move into the Fault state. The ControlWord can once again be used to move from the Fault state to the Switch On Disabled state.

## 1.6.2 Drive States

The following tables provide details on each of the CANopen states supported by AMC drives.

**TABLE 1.46**

Not Ready to Switch On	
Function	Part of drive initialization
Status	Logic Supply has been applied to the drive. The drive is being initialized. Drive functionality is disabled during this time.
Transitions	Transition to 'Switch On Disabled' is automatic when initialization complete.

**TABLE 1.47**

Switch On Disabled	
Function	Drive initialization is complete. If a fatal error exists, the processor executes a Reset Fault command automatically. The drive is still disabled.
Status	Drive parameters have been set up. Only logic supply voltage is necessary at this time. Drive process monitoring may begin.
Transitions	Transition to the <b>Ready to Switch On</b> state is possible by a <i>Shut Down</i> command.

**TABLE 1.48**

Ready to Switch On	
Function	Last state before Bridge enabled
Status	No energy is supplied to the motor. Control loops do not work. The drive function is still disabled. Bus power may be applied.
Transitions	Transition to <b>Operation Disabled (Switched ON)</b> state is possible via the <i>Switch On</i> command. Transition back to the <b>Switch On Disabled</b> state is possible via the <i>Disable Voltage</i> command, or by a <i>Quick Stop</i> command.

**TABLE 1.49**

Operation Disabled (Switched On)	
Function	The bridge is turned on and a mode-dependent zero command is issued.
Status	The control loops are operational. Bus power is applied. The power section is switched on (if not already on). The target signal is not processed. The drive function is disabled.
Transitions	Transition to the <b>Operation Enabled</b> state is possible via the <i>Enable Operation</i> command. Transition back to the <b>Ready to Switch On</b> state is equally possible via the <i>Shut Down</i> command. Transition back to the <b>Switch On Disabled</b> state is possible via the <i>Disable Voltage</i> command or via a <i>Quick Stop</i> command.

**TABLE 1.50**

Operation Enabled	
Function	This is the normal operation state of the drive.
Status	Power is supplied to the motor. Control loops are operational and target signals are processed.
Transitions	A <b>Quick Stop</b> command transfers the drive to the <b>Quick Stop Active</b> state. Transition back to the <b>Ready to Switch On</b> state is possible via the <i>Shut Down</i> command. Transition back to the <b>Switch On Disabled</b> state is possible via the <i>Disable Voltage</i> command or the <i>Drive Enable Input</i> . Transition back to the <b>Operation Disabled</b> state is possible via the <i>Switch On</i> command.

**TABLE 1.51**

Quick Stop Active	
Function	The motor (shaft) is brought to a stop using the Quick Stop Ramp.
Status	Control loops are operational. Power is applied to the motor. The motor shaft is held in position in position mode or zero velocity in velocity mode.
Transitions	Transition back to the Operation Enabled state is possible via the <i>Enable Operation</i> (7) command. Transition back to the Switch On Disabled state is possible via the <i>Disable Voltage</i> (4) command, or via the <i>Drive Enable Input</i> (2) (both include the "Power Disable Delay" process).

**TABLE 1.52**

Fault	
Function	A fault has occurred and has not yet been reset
Status	The power output stage is disabled; no energy is supplied to the motor.
Transitions	Transition to the Switch On Disabled state is possible via the <i>Reset Fault</i> command.

### 1.6.3 ControlWord (6040h)

The following table shows the values used with object 6040h to cause transitions shown in [Figure 1.5](#) above. An example hexadecimal value is provided on the right.

**TABLE 1.53** ControlWord values

State Transition Command	Bit 7	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Example Value
Reset Fault	0→1	X	X	X	X	X	XX 80
Disable Voltage	0	X	X	X	0	X	XX 04
Shutdown	0	X	X	1	1	0	XX 06
Switch On	0	X	0	1	1	1	XX 07
Enable Operation	0	X	1	1	1	1	XX 0F
Quick Stop	0	X	X	0	1	X	XX 02
Begin Homing (Homing mode only)	0	1	1	1	1	1	XX 1F
End Homing (Homing mode only)	0	0	1	1	1	1	XX 0F
0 = OFF, 1 = ON, X = don't care							

**TABLE 1.54** Additional ControlWord values

State Transition Command	Bit 13	Bit 12	Description
Inhibit Negative Motion	X	1	enable <i>commanded</i> * [negative stop OR negative torque inhibit]
Inhibit Positive Motion	1	X	enable <i>commanded</i> * [positive stop OR positive torque inhibit]
0 = disable, 1 = enable, X = don't care,			* see Event Action Configuration command (2065h)

## 1.6.4 StatusWord (6041h)

The StatusWord reports exactly which state the drive is in. [Table 1.55](#) defines each bit in the StatusWord and [Table 1.56](#) shows how to interpret what state the drive is in via the combination of bits 0-3, 5 and 6. Each drive state is described in detail in [“Drive States”](#).

**TABLE 1.55** StatusWord bit descriptions

Bits	Name	Descriptions
0	Ready to Switch On	See <a href="#">Table 1.56</a> to see how this bit relates to the control state machine.
1	Switched On	See <a href="#">Table 1.56</a> to see how this bit relates to the control state machine
2	Operation Enabled	See <a href="#">Table 1.56</a> to see how this bit relates to the control state machine
3	Fault	See <a href="#">Table 1.56</a> to see how this bit relates to the control state machine
4	Voltage Enabled	1 when power is applied to the motor
5	Quick Stop	See <a href="#">Table 1.56</a> to see how this bit relates to the control state machine
6	Switch On disabled	See <a href="#">Table 1.56</a> to see how this bit relates to the control state machine
7	Warning	Object 205B can be used to configure which internal drive events will set this bit.
8	Manufacture specific	Object 205B can be used to configure which internal drive events will set this bit.
9	Remote	1 when the drive is in remote mode.
10	Target Reached	1 Under the following conditions: - Home reached if the Can operational-mode is homing. - Home reached if the Can operational-mode is custom and homing is active. - End of motion in PVT mode. - At command for all other conditions.
11	Internal Limit Active	Object 205B can be used to configure which internal drive events will set this bit.
12	Homing complete	1 when Homing completes, otherwise 0.
13	-	-
14	-	-
15	-	-

**TABLE 1.56** StatusWord drive states

Drive State	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	StatusWord
Not Ready to Switch On	0	X	X	0	0	0	0	xxxx xxxx x0xx 0000
Switch On Disabled	1	X	X	0	0	0	0	xxxx xxxx x1xx 0000
Ready to Switch On	0	1	X	0	0	0	1	xxxx xxxx x01x 0001
Switched On	0	1	X	0	0	1	1	xxxx xxxx x01x 0011
Operation Enabled	0	1	X	0	1	1	1	xxxx xxxx x01x 0111
Fault	0	X	X	1	0	0	0	xxxx xxxx x0xx 1000
Quick Stop Active	0	0	X	0	1	1	1	xxxx xxxx x00x 0111

0 = OFF, 1 = ON, X = don't care

## 1.7 Homing

AMC CANopen drives support a wide variety of homing routines. These routines rely on signals such as limit switch, home switch, and encoder index signals to achieve precise starting positions. Four objects define the offset, speed, acceleration, and the particular homing method used. These objects are listed in the table below.

**TABLE 1.57** Homing Objects

Object Index	Description
607Ch	Home Offset
6099h	Homing Speeds
609Ah	Homing Acceleration
6098h	Homing Method

### 1.7.1 Home Offset

The home offset specifies the difference between the home position and the zero position. The home position is the position of the motor when the home switch or encoder index is toggled during a homing routine. The zero position is the position defined to be zero as seen by the CAN master. If the home offset is set to zero, the home position will be equal to the zero position.

### 1.7.2 Homing Speeds

There are two homing speeds to take into consideration: the speed during the search for home switch, and the speed during the search for the index. Typically, the speed during the search for the home switch is set to be faster than the speed during the search for the index.

### 1.7.3 Homing Acceleration

A single value is used to define the acceleration and deceleration of all moves during the homing routine.

### 1.7.4 Homing Methods



AMC CANopen homing methods depend on the presence of up to three different system components: an index pulse, a home switch, and a limit switch. The simplest homing methods require just one or none of these components, whereas the more complex methods require two or all of these components. All homing methods have been summarized in [Table 1.58](#), along with their necessary components, and have been named according to [DSP402] which states that there are a total of 35 possible homing methods, some of which are reserved and not currently specified.

**TABLE 1.58** Homing Methods Summary

Homing Method	Index Pulse	Home Switch	Limit Switch
Methods 1 & 2	✓		✓
Methods 3 to 6	✓	✓	
Methods 7 to 14	✓	✓	✓
Methods 15 & 16	Reserved		
Methods 17 & 18			✓
Methods 19 to 22		✓	
Methods 23 to 30		✓	✓
Methods 31 & 32	Reserved		
Methods 33 & 34	✓		
Method 35			


Because these homing methods can become fairly complex, they are best described visually. As a result, *homing diagrams* are utilized to illustrate the behavior of each method. Homing diagrams consist of multiple components each of which is described in [Figure 1.6](#).

**FIGURE 1.6** Homing Diagrams

Load and physical limits	
The square near the middle of the illustration shows the load object that is to be moved. The endpoints represent physical limitations or barriers, which the load cannot travel past. The left side is in the negative direction while the right side is in the positive direction.	
Direction of travel	
The vertical line on the right side represents the starting position. The load travels in the direction of the arrow. In the illustration shown, the load begins traveling in the negative direction and then switches directions to move in the positive direction. The circle represents the home position at which point the (actual) measured position is reset to zero. The small section of arrow following the circle represents the distance traveled, past the home position, during deceleration of the load. Lastly, the number in the circle represents the number designated to that particular homing method.	
Index Pulse	
A label in the actual homing diagram will be used to label a switch as either a limit/home switch. As shown, there are only two positions for a switch: high (active) or low (inactive).	
Break	
Represents a break in the diagram. This is used for representing a length of distance too large to properly scale on the diagram.	


**Method 1: Homing on the Negative Limit Switch** This method uses the negative limit switch and index to home the load. If the negative limit switch is off, the motor moves in the negative direction. Once the limit switch toggles, the motor changes direction and moves until the next encoder index. Homing is complete at this point. [Figure 1.7](#) illustrates the homing diagram for this method.

**FIGURE 1.7** Homing on the Negative Limit Switch




**Method 2: Homing on the Positive Limit Switch** This method uses the positive limit switch and index to home the load. If the positive limit switch is off, the motor moves in the positive direction. Once the limit switch toggles, the motor changes direction and moves until the next encoder index. Homing is complete at this point. [Figure 1.8](#) illustrates the homing diagram for this method.

**FIGURE 1.8** Homing on the Positive Limit Switch




**Methods 3 and 4: Homing on the Positive Home Switch** These methods use the positive home switch and index to home the load. The initial direction of movement for a given routine method is dependent on the home switch position. However, the final position is always in the same direction. Homing methods 3 and four perform the same operations, but in opposite directions with opposite home switch polarity. [Figure 1.9](#) illustrates the homing diagram for these methods.

**FIGURE 1.9** Homing on the Positive Home Switch




**Methods 5 and 6: Homing on the Negative Home Switch** This is literally a mirror image of the homing routines used by methods 3 and 4. [Figure 1.10](#) illustrates the homing diagram for these methods.

**FIGURE 1.10** Homing on the Negative Home Switch




**Methods 7-14: Homing on the Home Switch** These methods use all three possible homing components (index pulse, home switch, and limit switch) with the index pulse to the nearest right or left of the home switch always being the sought after home position. Methods 7 to 10 use a positive limit switch and if the starting position is outside the active home switch region the initial direction of travel is always positive. For cases where the starting position is inside the active home switch region the initial direction will depend upon the index pulse being sought after: methods 7 & 8 home towards the left home switch edge so the initial direction will be left, whereas methods 9 & 10 home towards the right home switch edge so the initial direction will be right. Note that the only difference between methods 7 & 8 is that one homes to the index pulse left of the home switch edge whereas the other homes to the index pulse to the right; the same difference holds true for methods 9 & 10. Figure 1.11 illustrates the homing diagram for methods 7 to 10.

FIGURE 1.11




Methods 11 to 14 use a negative limit switch instead of a positive limit switch. As a result, the initial direction will be left, instead of right, whenever the starting point is outside of the active home switch region. Outside of this difference, methods 11 to 14 are identical to methods 7 to 10. [Figure 1.12](#) illustrates the homing diagram for methods 11 to 14.

**FIGURE 1.12**


**Methods 17-30: Homing without an Index Pulse** These homing routines use the same methods as 1 to 14, except the index pulse is not used. Instead, the home position is dependant on the edge of the relevant home or limit switch. To illustrate this difference, Figure 1.13 shows the homing diagram for methods 19 and 20, which are equivalent to methods 3 and 4 without the index pulse.

FIGURE 1.13



**Methods 33 and 34: Homing on the Index Pulse** These homing methods home to the nearest index pulse. Method 33 homes in the negative directions and method 34 homes in the positive direction.

FIGURE 1.14



**Method 35** This homing method requires no index pulse or switches and involves nothing more than setting the current measured position equal to the home position value, which can be accomplished in object [2039.02h "Home Position Value"](#) on page 119.

**Homing Example** This example assumes the drive starts in Shutdown control state and Pre-Operational communication state. The 1<sup>st</sup> PDO is setup to send upon any change in the StatusWord. The 13<sup>th</sup> bit of the StatusWord is the “Homing Complete” bit that will indicate when homing has completed and the drive mode may be changed.

**TABLE 1.59**


COB-ID	Number of Bytes	Message / Data	Description
601	8	22 00 18 01 81 01 00 00	Set 1 <sup>st</sup> PDO COB-ID to 181h
601	8	22 00 18 02 FF 00 00 00	Set 1 <sup>st</sup> PDO Trigger mechanism to “immediate”
601	8	22 7C 60 00 00 00 00 00	Write 0 to home offset object
601	8	22 99 60 01 55 55 00 00	Write 50 RPM to the Search For Home Switch speed
601	8	22 99 60 02 55 55 00 00	Write 50 RPM to the Search For Index Speed
601	8	22 9A 60 00 37 89 41 00	Write 10^5 Cnts/s^2 to Homing Acceleration
601	8	22 98 60 00 22 00 00 00	Set Homing to method 34, “home to index in positive direction”
601	8	22 60 60 00 06 00 00 00	Set the drive in Homing Mode
000	2	01 01	Start communication state machine so PDOs can be processed
601	8	22 40 60 00 07 00 00 00	Set node 1 to Operation Disabled
601	8	22 40 60 00 0F 00 00 00	Set node 1 to Operation Enabled
601	8	22 40 60 00 1F 00 00 00	Start Homing on node 1
Wait for PDO 1 to send a message containing 1 in the 13 <sup>th</sup> bit.			
601	8	22 40 60 00 0F 00 00 00	Stop Homing on node 1
601	8	22 60 60 00 07 00 00 00	Set node 1 in PVT mode

## 1.8 Modes of Operation

AMC CANopen drives close position, velocity, and torque (current) loops that are configurable via the CAN bus. There are 8 modes of operation available with object 6060h. Other modes of operation are achievable using DriveWare. When changing loop configurations using object 6060h, velocity and position loop feedback sources are not touched. This means changing loop configurations assumes the feedback wiring and project parameters are configured properly for both the present loop and the one the drive is moving to.

Follow the formula for Expedited SDO messages in the “SDO” section of this manual when writing to object 6060h. More information on object 6060h is found in the [“Object Dictionary” on page 69](#).

**FIGURE 1.15** Available loop configurations via CANopen messaging.




**TABLE 1.60** Modes of Operation

Modes of Operation
Profile Position Mode
Profile Velocity Mode
Profile Torque Mode (current mode)
Homing Mode
Interpolated Position Mode (PVT)
Cyclic Synchronous Position Mode
Cyclic Synchronous Velocity Mode
Cyclic Synchronous Torque Mode
Custom Configured Modes

## 1.8.1 Profile Modes

In a profile mode of operation, the trajectory is limited by the drive. Profile modes use the command limiter values (object 203C) to limit the maximum command rate. If the host sends a large command step, the drive spreads the demand over some period of time to stay equal to or below the maximum defined rate. The command limiter is configurable to supply up to 4 different slopes depending on the input, as shown in [Figure 1.16](#) below.

**FIGURE 1.16**



**Profile Position Mode: (L3 from Figure 1.15)** The AMC Position control loop is a fully de-coupled PID with velocity and acceleration feedforward terms. In Profile Position Mode, the drive closes three control loops, position, velocity, and current. The velocity loop provides additional “stiffness,” keeping the dynamic position errors minimal because the drive now reacts not only to position errors, but also to velocity errors (which can be interpreted as position error changes). The Command Limiter is enabled in this mode. The Profiler sets limits on the rate of change of the target position command, otherwise called velocity. When commanding point-to-point moves, the velocity between points is limited to the maximum value set in the profiler. When tuning the position loop for profile position mode, proportional gain is typically all that is needed. It is important, however, to start with a stable, yet responsive velocity loop. Feedforward gain can be added to improve tracking performance, if needed. More information on tuning is found in the DriveWare application help files.

The following objects define how the drive will behave in Position mode.

**TABLE 1.61**

<b>Object index</b>	<b>Name</b>	<b>Description</b>
6060h	Modes Of Operation	Sends a request to change the drive's mode of operation.
6061h	Modes of Operation Display	Displays the actual mode of operation.
203Ch	Command Limiter Parameters	Sets the values used by the command limiter to limit the target command.
6086h	Motion Profile Type	Sets profiling to linear ramp. Currently this is fixed and read only.
2038h	Position Loop Control Parameters	Sets the tuning values associated with the position loop
2039h	Position Limits	Sets the trip points for various position events such as Max Measured Position Limit.
2012h	Position Values	Read instantaneous values such as Position demand and Position Target. This object is read only.
6064h	Actual Position	Same as 2012.01h, reads measured position value.
607Ah	Target Position	Sets the target position command.

**Profile Velocity Mode: (L2 from Figure 1.15)** The AMC Velocity control loop is a fully de-coupled PID with an acceleration feedforward term, and a low speed estimator. In Profile Velocity Mode, the drive closes two control loops, velocity, and current. Velocity feedback may be derived from a motor mounted encoder or analog source with a 10V maximum. The low speed estimator is most useful when necessarily tight velocity loops can cause audible noise during low speed moves (less than 1 count per velocity update).

The Command Limiter is enabled in this mode. The Limiter sets limits on the rate of change of the velocity command. When commanding large velocity transients, the resulting acceleration between points is limited to the maximum value set in the profiler.

When tuning the velocity loop it is important to start with a stable, yet responsive current loop. Feedforward gain can be added to improve tracking performance, if needed. More information on tuning is found in the DriveWare help files.

**TABLE 1.62**

<b>Object index</b>	<b>Name</b>	<b>Description</b>
6060h	Modes Of Operation	Sends a request to change the drive's mode of operation.
6061h	Modes of Operation Display	Displays the actual mode of operation.
203Ch	Command Limiter Parameters	Sets the values used by the command limiter to limit the target command.
6086h	Motion Profile Type	Sets profiling to linear ramp. Currently this is fixed and read only.
2037h	Velocity Limits	Sets the trip points for various velocity events such as Over Speed.
2036h	Velocity Loop Control Parameters	Sets the tuning values associated with the velocity loop
2011h	Velocity Values	Read instantaneous values such as Velocity demand and Velocity Target. This object is read only.
6069h	Velocity Sensor Actual Value	Same as 2011.01h, reads pre-filtered measured velocity value.
606Bh	Velocity Demand	Same as 2011.04h, reads Velocity Demand value.
606Ch	Actual Velocity	Same as 2011.02h, reads post-filtered measured velocity value.
60FFh	Target Velocity	Sets the target velocity command.

**Profile Current Mode: (L1 from Figure 1.15)** Presently AMC CANopen servo drives support Profile Current Mode, which is the basic building block of any CANopen servo system. The drive's current loop consists of a PI loop. Because torque is merely a constant Kt multiplied by a magnitude of current, it is the programmer's responsibility to convert current values into torque values in the software environment.

The Command Limiter is enabled in this mode and sets limits on the rate of change of the current command. During a step acceleration command, the change in commanded torque, known as Jerk, is limited to the maximum value set in the profiler.

Tune this loop according to "current loop tuning" instructions in the DriveWare Software Guide. The following objects are used to setup and operate the Current Mode:

**TABLE 1.63**

Object index	Name	Description
6060h	Modes Of Operation	Sends a request to change the drive's mode of operation.
6061h	Modes of Operation Display	Displays the actual mode of operation
203Ch	Command Limiter Parameters	Sets the values used by the command limiter to limit the target command.
6086h	Motion Profile Type	Sets profiling to linear ramp. Currently this is fixed and read only.
2010h	Current Values	Read instantaneous values such as Current Demand and Current Target. This object is read only.
2034h	Current Loop and Commutation Values	Sets the tuning and commutation values associated with the current loop.
6071h	Target Current	Sets the target current command.
6077h	Actual Current	Reads the actual motor current (in case of 3-phase motors, this is a composite, equivalent single phase current).

### 1.8.2 Homing Mode: (L4 from Figure 1.15)


See "[Homing](#)" on page 40 for detailed information about methods and hardware involved in homing.

### 1.8.3 PVT (Interpolated Position Mode): (L4 from Figure 1.15)

PVT mode allows for synchronized multi axis move profiles using interpolated position and velocity. The three control loops, position, velocity, and current, are enabled while the profiler is disabled. The process for setting up and controlling motion using PVT Mode is explained in detail in "[PVT Mode](#)" on page 54.

### 1.8.4 Cyclic Synchronous Modes

Cyclic Synchronous Modes give responsibility of trajectory control to the host. There is no command limiter. Instead, the drive interpolates between command points, defining the rate by dividing the change in command by the interpolation time period (object 60C2). This allows the drive to respond smoothly to each step in command. [Figure 1.17](#) below shows how the drive interpolates different commands, with T representing the interpolation time. In each case, the drive arrives at the commanded value at precisely T seconds after the command changed.

**FIGURE 1.17**

**Cyclic Synchronous Position Mode** In Cyclic Synchronous Position Mode, the drive closes three control loops: position, velocity, and current. The host can send target position, velocity feedforward, and current feedforward values to the drive. This allows for gain compensation in applications with varying loads. The Command Limiter is disabled in this mode, giving the host more control over the motion profile.

The following objects define how the drive will behave in Cyclic Synchronous Position Mode.

Object index	Name	Description
6060h	Modes Of Operation	Sends a request to change the drive's mode of operation.
6061h	Modes of Operation Display	Displays the actual mode of operation.
60B1h	Velocity Offset	Contains the input value for velocity feed forward.
60B2h	Current Offset	Contains the input value for current feed forward.
60C2h	Interpolation Time Period Value	Contains the period used for the linear interpolation algorithm. Used with Cyclic synchronous modes of operation.
2038h	Position Loop Control Parameters	Sets the tuning values associated with the position loop.
2039h	Position Limits	Sets the trip points for various position events such as Max Measured Position Limit.
2012h	Position Values	Reads instantaneous values such as Position demand and Position Target. This object is read only.
6064h	Actual Position	Same as 2012.01h, reads measured position value.
607Ah	Target Position	Sets the target position command.

**Cyclic Synchronous Velocity Mode** In Cyclic Synchronous Velocity Mode, the drive closes the velocity loop around the current loop. The host can send target velocity, velocity offset, and current feedforward values to the drive. This allows for gain compensation in applications with varying loads. The Command Limiter is disabled in this mode, giving the host more control over the motion profile.

The following objects define how the drive will behave in Cyclic Synchronous Velocity Mode.

Object index	Name	Description
6060h	Modes Of Operation	Sends a request to change the drive's mode of operation.
6061h	Modes of Operation Display	Displays the actual mode of operation.
60B1h	Velocity Offset	Contains the input value for velocity feed forward.
60B2h	Current Offset	Contains the input value for current feed forward.
60C2h	Interpolation Time Period Value	Contains the period used for the linear interpolation algorithm. Used with Cyclic synchronous modes of operation.
2036h	Velocity Loop Control Parameters	Sets the tuning values associated with the velocity loop.
2037h	Velocity Limits	Sets the trip points for various velocity events such as Over Speed.
2011h	Velocity Values	Read instantaneous values such as Velocity Demand and Velocity Target. This object is read only.
6069h	Velocity Sensor Actual Value	Same as 2011.01h, reads pre-filtered measured velocity value.
606Bh	Velocity Demand	Same as 2011.04h, reads Velocity Demand value.
606Ch	Actual Velocity	Same as 2011.02h, reads post-filtered measured velocity value.
60FFh	Target Velocity	Sets the target velocity command.

**Cyclic Synchronous Current Mode** In Cyclic Synchronous Current Mode, the drive closes the current loop. The host can send target current and current offset values to the drive. The Command Limiter is disabled in this mode, giving the host more control over the motion profile.

The following objects define how the drive will behave in Cyclic Synchronous Current Mode.

Object index	Name	Description
6060h	Modes Of Operation	Sends a request to change the drive's mode of operation.
6061h	Modes of Operation Display	Displays the actual mode of operation.
60B2h	Current Offset	Contains the input value for current offset.
60C2h	Interpolation Time Period Value	Contains the period used for the linear interpolation algorithm. Used with Cyclic synchronous modes of operation.
2010h	Current Values	Reads instantaneous values such as Current Demand and Current Target. This object is read only.
2034h	Current Loop & Commutation Control Parameters	Sets the tuning values and commutation values associated with the current loop.
6071h	Target Current	Sets the target current command.
6077h	Actual Current	Reads the actual motor current (in case of 3-phase motors, this is a composite, equivalent single phase current)

### 1.8.5 Custom Defined Modes Of Operation

*ADVANCED Motion Controls* digital servo drives provide flexibility beyond the CANopen defined standard modes of operation. For a case where a drive configuration is desired that is not available via object 6060h, contact *ADVANCED Motion Controls* directly for technical support.


## 1.9 PVT Mode

### 1.9.1 PVT Overview

PVT mode is a position data-streaming mode that allows coordinated motion between multiple axes. Arbitrary position and velocity profiles can be executed on each axis. This is achieved via a so-called PVT command. A PVT command contains the position, velocity, and time information of profile segment end points. The servo drive performs a third order interpolation between segment end points. This results in a kind of partial trajectory generation where both host controller and servo drive generate a specific portion of the overall move profile trajectory. The host controller calculates position and velocity of intermittent points on the overall trajectory, while the servo drive interpolates between these intermittent points to ensure smooth motion. The actual position loop is closed within the drive. This reduces the amount of commands that need to be sent from host controller to drive, which is critical in distributed control systems. The number of segments and the time duration of each segment need to be selected based upon required accuracy and network bandwidth.

An arbitrary position profile can be split in multiple consecutive segments as follows:

FIGURE 1.18



Each segment has a start point and an end point. The end point of one segment is the start point of the next segment. Each segment end point (start or end) has a position and velocity value. The segment time can be variable depending on curvature (smaller time for rapidly changing positions).

PVT mode operates through PVT commands. A PVT command is an unconfirmed message (manufacturer specific RPDO 24). The PVT command contains segment end point position and velocity information, and segment time. A 15 level FIFO buffer alleviates host controller timing requirements. The buffer can be cleared and the buffer pointer can be re-positioned. The drive will also send the following PVT related error messages: buffer empty, buffer full, counter error, or message length error. The Time Stamp message can be used to maintain time synchronization of nodes involved in PVT motion.

## 1.9.2 PVT Messages

**Enable PVT** Since PVT commands are PDO messages, RPDO 24 must be enabled for PVT to work.

To enable this PVT Buffer RPDO, configure its PDO Communication Parameter (1417.01h) to set bit 31 to 0 (enable PDO). In addition, the COB-ID for this PDO is selectable. Note that the following example assigns the COB-ID for this node to 531h.

TABLE 1.64

Arbitration Field		Data Field						
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
600h + Node-ID	22	17	14	01	31	05	00	00

**Mode Selection** To use PVT, the drive must be set for PVT Mode through Object 6060h (Modes of Operation). The message may look like this one where it is writing (without size indication) the value 07h for PVT mode into Object 6060h.

TABLE 1.65

Arbitration Field		Data Field						
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
600h + Node-ID	22	60	60	00	07	00	00	00

**Configuration** The following objects are useful for configuring the drive's behaviors in PVT mode. Set digital outputs to indicate PVT status or specify warning messages for minimum number of buffer points. When errors occur in PVT mode, select from multiple event actions to configure the drive to react appropriately.

TABLE 1.66

Object index	Sub-index Range	Name	Description
2048h	01h	PVT Parameters	Specifies the minimum number of buffered PVT end points before a warning message is sent
205Ah	31h – 35h	Digital Output Parameters	Assign digital outputs to indicate specific PVT status
2064h	1Ch – 20h	Fault Response Time Parameters	Sets the wait time before reacting to an occurrence of a PVT event
2065h	1Bh – 1Fh	Fault Event Action Parameters	Selects the event action when a PVT event occurs. Possible event actions include Disable Power Bridge, Dynamic Brake, and many others.
2066h	22h – 26h	Fault Recovery Time Parameters	Sets the amount of time after the cause of the PVT fault no longer exists before drive fault condition is cleared
2067h	1Fh – 23h	Fault Time-Out Window Parameters	Time after drive fault condition is cleared before a new occurrence is considered a new fault
2068h	27h – 2Bh	Fault Maximum Recoveries Parameters	Max number of faults before a permanent action is taken

**PVT Message Protocol** Once the drive is configured, it is ready to receive PVT segment end points into its 15 level FIFO buffer. The construction of the PVT message is made up of the COB-ID and eight data bytes, which are made up of the segment end point position, velocity, segment time, and integrity counter. The COB-ID can be any unique user-selectable value within the range of 181h-57Fh over the entire CANopen network. Note that both the Position and Velocity data bytes (three bytes each) are arranged in Little Endian format.

**TABLE 1.67** PVT message construction

Arbitration Field	Data Field							
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Unique ID: XXXh	(LSB) Position Values (MSB)				(LSB) Velocity Values (MSB)			Time
								Counter

**TABLE 1.68** PVT message description

Data Bytes	Name	Description
Byte 1	Position Segment End Point	The segment end point position is a 24-bit value in counts (absolute or incremental position). The data are entered as hexadecimal, where Byte 3 is the Most Significant Byte (MSB) and Byte 1 is the Least Significant Byte (LSB). For more information refer to " <a href="#">2048h: PVT Parameters</a> " on page 124.
Byte 2		
Byte 3		
Byte 4	Velocity Segment End Point	The segment end point velocity is a 24-bit value in counts per second. The data are entered as hexadecimal, where Byte 6 is the Most Significant Byte (MSB) and Byte 4 is the Least Significant Byte (LSB).
Byte 5		
Byte 6		
Byte 7	Segment Time Duration	Time duration in milliseconds. Minimum 2 (02h) milliseconds for 16kHz drives, 4 (04h) milliseconds for 10kHz drives. Maximum of 255 (FFh) milliseconds.
Byte 8	Integrity Counter	The integrity counter is an incremental counter that starts at zero and wraps around after 255 (FFh). PVT commands with non-consecutive counter values will result in an error message.

**Clear Buffer** If for any reason the PVT buffer should be cleared, writing the value 00h to Object 60C4.06h will remove all the points previously loaded in the buffer. Byte 8, the counter, will need to start at 00 when loading the next buffer point. This will cause the "PVT Buffer Empty" and "PVT Buffer Threshold" drive events to become active.

**TABLE 1.69**

Arbitration Field	Data Field							
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
600h + Node-ID	22	C4	60	06	01	00	00	00

**End of Motion** To end a PVT sequence, first insert a PVT point with a specified position, zero velocity, a specified time duration, and an Integrity Counter value incremented from the previous point. The next PVT point should have the same specified position, but with zero specified for both velocity and time. The Integrity Counter, however, continues to increment. Tables [1.70](#) and [1.71](#) give an example of the last two PVT messages to end the motion sequence.

**TABLE 1.70**

Arbitration Field	Data Field							
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Unique ID: XXXh	P	P	P	00	00	00	T	C

**TABLE 1.71**

Arbitration Field	Data Field							
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Unique ID: XXXh	P	P	P	00	00	00	00	C + 1

**Start Motion** Once there are enough PVT end points in the PVT buffer, motion may begin. With the drive in Operation Enabled state, sending a broadcast message with COB-ID 500h (no data bytes required) will start motion on all axes. Note that this command can be sent as soon as the nodes involved have received at least one PVT command. To ensure smooth motion, new PVT commands must be sent in a timely fashion.



Note that the Zero Velocity event must be active prior to sending the PVT start command, or motion will not occur.

Note

**TABLE 1.72**

Arbitration Field	Data Field							
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
500h	-	-	-	-	-	-	-	-

**Stop Motion** When the drive executes the final PVT end sequence command, motion will stop. However as with any other modes, the ControlWord (Object 6040h) may stop the motion with a state change from the Operation Enabled state, to a disabled state such as Switch On Disabled.

**TABLE 1.73**

Arbitration Field	Data Field							
COB-ID	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
600h + Node-ID	22	40	60	00	04	00	00	00

### 1.9.3 PVT Status

The following objects display the PVT status of the drive.

**TABLE 1.74**

Object index	Sub-index range	Name	Description
2002h	06h	Drive Status	The bits in this sub-index provide status on the PVT buffer
201Dh	01h	PVT Status	Same as bits 0 – 5 of object 2002.06h
201Dh	02h	PVT Points Remaining	Remaining number of points in the buffer to be executed
201Dh	03h	PVT Sequence Number	The current PVT point in the buffer

### 1.9.4 Buffer Characteristics

Object 60C4h is the Interpolation Data Configuration. It provides information regarding the PVT buffer and also allows modifications to the buffer, such as removing all the PVT end points already in the buffer.

**TABLE 1.75**

Object index	Sub-index range	Name	Description
60C4h	01h	Max Buffer Size	Maximum size of PVT buffer
60C4h	02h	Actual Buffer Size	Shows the actual size of the PVT buffer
60C4h	03H	Buffer Organization	Specifies that it is a FIFO buffer
60C4h	04H	Buffer Position	Indicates the position of the buffer
60C4h	05h	Size of Data Record	Indicates the length of a PVT point (8 bytes)
60C4h	06h	Buffer Clear	Clears all segment end points in the PVT buffer

**Error Messages** The drive will generate error messages in PVT mode. The emergency message protocol (COB-ID 80h + Node-ID) is used to transmit the error message. Refer to EMERGENCY Messages for decoding emergency messages.

## 1.9.5 PVT Example

This example shows how to configure and use PVT Mode to command a simple position move with a trapezoidal velocity profile. The motor is commanded from 0 to a position of 80,000 counts in 12 seconds, where the accel and decel is limited to 2500 counts/s and the max velocity during the move is 10,000 counts/s. A scope plot of the move, along with the PVT points is shown as well. This example can be extended to any position trajectory by using different PVT points. SDO size indication is disabled in this example.

### ***Transition to the Switch On Disabled State***

Read 6041.h to verify which state the drive is in.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
601	8	40 41 60 00 00 00 00 00	704	
581	8	42 41 60 00 37 06 00 00	705	1

Write the appropriate data to the Control Word 6040h to place the drive in Switch on Disabled State.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
601	8	22 40 60 00 04 00 00 00	705	0
581	8	60 40 60 00 00 00 00 00	706	1

### ***Configure the 24th RPDO***

First transition the drive into the pre-operational NMT state to allow for PDO configuration.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
000	8	80 01 00 00 00 00 00 00	706	0

The 24th RPDO is used to write PVT points to the PVT buffer. To configure the 24th RPDO, set the COB-ID of the 24th RPDO (COB-ID is 501h in this example) and set bit 31 to 0 to turn the RPDO on.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
601	8	22 17 14 01 01 05 00 00	707	0
581	8	60 17 14 01 00 00 00 00	708	1

### ***Set Mode of Operation to PVT Mode***

Write a 7h to 6060h to put the drive in PVT Mode.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
601	8	22 60 60 00 07 00 00 00	708	0
581	8	60 60 60 00 00 00 00 00	709	1

## **Set Buffer Threshold Warning Level**

A buffer threshold warning will occur when the number of PVT points in the PVT buffer is less than the value in the Buffer Threshold Warning object 2048.01h. The value is 10 (Ah) in this example.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
601	8	22 48 20 01 0A 00 00 00	709	0
581	8	60 48 20 01 00 00 00 00	710	1

## **Configure the 24th PDO**

The 24th PDO is transmitted when a buffer threshold warning occurs, that is when the number of PVT points in the buffer is less than the value in the Buffer Threshold Warning object 2048.01h. The data in the PDO is the number of points currently in the buffer..

To configure the 24th PDO, set the COB-ID of the 24th PDO (COB-ID is 381h in this example) and set bit 31 to 0 to turn the PDO on.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
601	8	22 17 18 01 81 03 00 00	710	0
581	8	60 17 18 01 00 00 00 00	711	1

## **Other PVT Setup**

Transition the drive into the operational NMT state to allow use of PDOs.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
000	8	01 01 00 00 00 00 00 00	711	0

Write a 0 to the PVT Input Method object 2048.02 if the PVT points are absolute. Write a 1 for incremental PVT points. This example uses absolute PVT points.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
601	8	22 48 20 02 00 00 00 00	711	0
581	8	60 48 20 02 00 00 00 00	712	1

Clear the PVT buffer by writing a 0 to the Buffer Clear object 60C4.06h.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
601	8	22 C4 60 06 00 00 00 00	712	0
581	8	60 C4 60 06 00 00 00 00	713	1

## Enable the Drive

The following frames alternately write to the control word and read the Status word until the drive is in the Operation Enabled state.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
601	8	22 40 60 00 06 00 00 00	713	0
581	8	60 40 60 00 00 00 00 00	714	1
601	8	40 41 60 00 00 00 00 00	764	50
581	8	42 41 60 00 21 06 00 00	765	1
601	8	22 40 60 00 0F 00 00 00	815	50
581	8	60 40 60 00 00 00 00 00	816	1

The following message checks to see if the drive is in the fault state.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
601	8	40 41 60 00 00 00 00 00	866	50
581	8	42 41 60 00 37 06 00 00	866	0

## Load the PVT Buffer

The PVT buffer is a FIFO buffer that can contain up to 15 PVT points. The first 15 PVT points are written to the buffer using the 24th RPDO.

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
501	8	4E 00 00 71 02 00 FA 00	866	0
501	8	38 01 00 E2 04 00 FA 01	867	1
501	8	BF 02 00 53 07 00 FA 02	867	0
501	8	E2 04 00 C4 09 00 FA 03	867	0
501	8	A1 07 00 35 0C 00 FA 04	867	0
501	8	FC 0A 00 A6 0E 00 FA 05	867	0
501	8	F4 0E 00 17 11 00 FA 06	867	0
501	8	88 13 00 88 13 00 FA 07	867	0
501	8	B8 18 00 F9 15 00 FA 08	868	1
501	8	84 1E 00 6A 18 00 FA 09	868	0
501	8	ED 24 00 DB 1A 00 FA 0A	868	0
501	8	F2 2B 00 4C 1D 00 FA 0B	868	0
501	8	93 33 00 BD 1F 00 FA 0C	868	0
501	8	D0 3B 00 2E 22 00 FA 0D	868	0
501	8	AA 44 00 9F 24 00 FA 0E	868	0

## Start PVT

COB-ID	# of Bytes	Message / Data	Message Time Stamp (ms)	Time From Previous Message (ms)
500	8	00 00 00 00 00 00 00 00	868	0

The 24th TPDO transmits everytime the number of points in the PVT buffer is less than the buffer threshold warning value. In this example, the buffer threshold is 10 which means when the 10th PVT point is consumed, the 24th TPDO transmits and tells you there are 9 points left in the buffer. When this occurs, we know to send 6 more PVT points to fill the (15 point) buffer. This continues until all of the PVT points are consumed and the PVT stop point is sent.

<b>COB-ID</b>	<b># of Bytes</b>	<b>Message / Data</b>	<b>Message Time Stamp (ms)</b>	<b>Time From Previous Message (ms)</b>
381	4	09 00 00 00	2375	1507
501	8	20 4E 00 10 27 00 FA 0F	2375	0
501	8	E4 57 00 10 27 00 FA 10	2376	1
501	8	A8 61 00 10 27 00 FA 11	2376	0
501	8	6C 6B 00 10 27 00 FA 12	2376	0
501	8	30 75 00 10 27 00 FA 13	2376	0
501	8	F4 7E 00 10 27 00 FA 14	2376	0

<b>COB-ID</b>	<b># of Bytes</b>	<b>Message / Data</b>	<b>Message Time Stamp (ms)</b>	<b>Time From Previous Message (ms)</b>
381	4	09 00 00 00	3875	1499
501	8	B8 88 00 10 27 00 FA 15	3875	0
501	8	7C 92 00 10 27 00 FA 16	3876	1
501	8	40 9C 00 10 27 00 FA 17	3876	0
501	8	04 A6 00 10 27 00 FA 18	3876	0
501	8	C8 AF 00 10 27 00 FA 19	3876	0
501	8	8C B9 00 10 27 00 FA 1A	3876	0

<b>COB-ID</b>	<b># of Bytes</b>	<b>Message / Data</b>	<b>Message Time Stamp (ms)</b>	<b>Time From Previous Message (ms)</b>
381	4	09 00 00 00	5375	1499
501	8	50 C3 00 10 27 00 FA 1B	5376	1
501	8	14 CD 00 10 27 00 FA 1C	5376	0
501	8	D8 D6 00 10 27 00 FA 1D	5376	0
501	8	9C E0 00 10 27 00 FA 1E	5376	0
501	8	60 EA 00 10 27 00 FA 1F	5376	0
501	8	D5 F3 00 9F 24 00 FA 20	5376	0

<b>COB-ID</b>	<b># of Bytes</b>	<b>Message / Data</b>	<b>Message Time Stamp (ms)</b>	<b>Time From Previous Message (ms)</b>
381	4	09 00 00 00	6875	1499
501	8	AF FC 00 2E 22 00 FA 21	6875	0
501	8	EC 04 01 BD 1F 00 FA 22	6875	1
501	8	8E 0C 01 4C 1D 00 FA 23	6875	0
501	8	92 13 01 DB 1A 00 FA 24	6875	0
501	8	FB 19 01 6A 18 00 FA 25	6876	1
501	8	C7 1F 01 F9 15 00 FA 26	6876	0

<b>COB-ID</b>	<b># of Bytes</b>	<b>Message / Data</b>	<b>Message Time Stamp (ms)</b>	<b>Time From Previous Message (ms)</b>
381	4	09 00 00 00	8375	1499
501	8	F8 24 01 88 13 00 FA 27	8375	0
501	8	8B 29 01 17 11 00 FA 28	8375	0
501	8	83 2D 01 A6 0E 00 FA 29	8375	0
501	8	DE 30 01 35 0C 00 FA 2A	8376	1
501	8	9E 33 01 C4 09 00 FA 2B	8376	0
501	8	C0 35 01 53 07 00 FA 2C	8376	0

<b>COB-ID</b>	<b># of Bytes</b>	<b>Message / Data</b>	<b>Message Time Stamp (ms)</b>	<b>Time From Previous Message (ms)</b>
381	4	09 00 00 00	9875	1499
501	8	47 37 01 E2 04 00 FA 2D	9875	0
501	8	31 38 01 71 02 00 FA 2E	9875	0
501	8	80 38 01 00 00 00 FA 2F	9875	0
501 <sup>1</sup>	8	80 38 01 00 00 00 30	9876	1
381 <sup>2</sup>	4	09 00 00 00	10875	999

- 1. PVT stop point
- 2. Buffer threshold warning

### Raw PVT Points


The units for position, velocity, and time are counts, counts/s, and milliseconds, respectively.

<b>#</b>	<b>P</b>	<b>V</b>	<b>T</b>
<b>1</b>	78	625	250
<b>2</b>	312	1250	250
<b>3</b>	703	1875	250
<b>4</b>	1250	2500	250
<b>5</b>	1953	3125	250
<b>6</b>	3812	3750	250
<b>7</b>	3828	4375	250
<b>8</b>	5000	5000	250
<b>9</b>	6328	5625	250
<b>10</b>	7812	6250	250
<b>11</b>	9453	6875	250
<b>12</b>	11250	7500	250
<b>13</b>	13203	8125	250
<b>14</b>	15312	8750	250
<b>15</b>	17578	9375	250
<b>16</b>	20000	10000	250
<b>17</b>	22500	10000	250

<b>#</b>	<b>P</b>	<b>V</b>	<b>T</b>
<b>18</b>	25000	10000	250
<b>19</b>	27500	10000	250
<b>20</b>	30000	10000	250
<b>21</b>	32500	10000	250
<b>22</b>	35000	10000	250
<b>23</b>	37500	10000	250
<b>24</b>	40000	10000	250
<b>25</b>	42500	10000	250
<b>26</b>	45000	10000	250
<b>27</b>	47500	10000	250
<b>28</b>	50000	10000	250
<b>29</b>	52500	10000	250
<b>30</b>	55000	10000	250
<b>31</b>	57500	10000	250
<b>32</b>	60000	10000	250
<b>33</b>	62421	9375	250

<b>#</b>	<b>P</b>	<b>V</b>	<b>T</b>
<b>34</b>	64687	8750	250
<b>35</b>	66796	8125	250
<b>36</b>	68750	7500	250
<b>37</b>	70546	6875	250
<b>38</b>	72187	6250	250
<b>39</b>	73671	5625	250
<b>40</b>	75000	5000	250
<b>41</b>	76171	4375	250
<b>42</b>	77187	3750	250
<b>43</b>	78046	3125	250
<b>44</b>	78750	2500	250
<b>45</b>	79296	1875	250
<b>46</b>	79687	1250	250
<b>47</b>	79921	625	250
<b>48</b>	80000	0	250
<b>49</b>	80000	0	0

### Oscilloscope Plot of PVT Move



## 1.10 Connecting to an AMC CANopen Drive

Connecting to an **ADVANCED Motion Controls**' CANopen drive is possible via two communication interfaces on the drive. One interface is the CANopen communication interface, which is used after the drive is configured for proper operation. The other interface is a RS-232 serial communication interface. This is used when first configuring a drive project file according to the application needs and storing it to the drive's Non Volatile Memory.

### 1.10.1 RS-232 Interface Setup

All that is needed is a standard serial cable connected from the drive RS-232 port to a computer. If the computer does not have a serial port on it, a converter such as USB to RS-232 may be used. Other converters may be used as long as they can operate between 9600 and 115200 baud. Higher baud rates will achieve better performance for the oscilloscope and other various features. Refer to the hardware manual and software configuration manual for more information about connecting to the RS232 interface.

### 1.10.2 CAN Interface Setup

Before communication can occur over a CANopen network, each node on the network must be configured for a specific node address, baud rate, and termination setting.

**Node Addressing** Each node in a CANopen network must have a unique Node-ID. Please refer to the hardware manual and software configuration manual for more information regarding address selection.

**Baud Rate Selection** Each node in a CANopen network (including the host) must operate at the same CAN bus bit rate. Please refer to the hardware manual for information regarding CAN bus baud rate selection.

**Termination Setting** The last node in a CANopen network must provide CAN bus termination. Please refer to the drive manual for information regarding termination options.

## 1.11 Hardware Requirements

### 1.11.1 CAN Card

AMC CANopen drives communicate with any CAN compatible hardware. CAN hardware is readily available from a variety of vendors. PC based CAN controllers are found in several common forms such as parallel-to-CAN, USB-to-CAN, serial-to-CAN or PCI-to-CAN.

Regardless of manufacturer and type, the CAN controller must be installed along with its appropriate software.

## 1.11.2 API

Every CAN controller includes an API (application to programmer interface). This is a library of functions that allows a programmer to utilize the CAN card to communicate with nodes on a CANopen network. Documentation for the CAN card's API will be available from the manufacturer.

## 1.11.3 Mating Connector

AMC CANopen drives use a low-density, male, 9-pin D-SUB mating connector shown in the table below. All of the components can be obtained from Tyco Electronics at [www.tycoelectronics.com](http://www.tycoelectronics.com), or by calling (800-522-6752).

**TABLE 1.76**

Parts Needed	Description	Part Number
D-SUB plug:	Main body, pins not inserted	205204-4
Shell Kit:	Outer shell, metal plated for shielding. Includes strain relief.	748677-1
Pins:	Insert pins for the Plug body. May be purchased loose or on a strip.	Loose: 5-66507-7 Strip: 3-66507-0




## 1.11.4 Wiring

[Table 1.77](#) shows the standard AMC drive CANopen interface connector. Please note that the AMC ZDCR series drives have a different interface layout, refer to the drive's manual for a detailed description. [Figure 1.19](#) shows an example of how the bus for an N node CANopen network should be wired.

**TABLE 1.77**

PIN	NAME	Description	I/O
1	--	Not Connected	NA
2	CAN_L	CAN_L bus line (dominant low)	Input
3	CAN_GND	CAN bus ground	GND
4	--	Not Connected	NA
5	CAN_SHIELD	CAN shield	SHIELD
6	--	Not Connected	NA
7	CAN_H	CAN_H bus line (dominant high)	Input
8	CAN_TERM	Termination. Connect to CAN_H for CAN bus termination via 120 Ohm resistor.	GND
9	CAN_V+	Optional external supply (7.5 – 24 VDC) for communication	Input

**FIGURE 1.19**

**CAN\_H, CAN\_L, CAN\_GND (Pins 7,2,3)** These are a differential pair referenced to signal ground; they are considered the CAN bus.

**CAN\_V+ (Pin 9)** Because the CAN interface can be completely isolated, external power may be required for the communication hardware in the drive. Please refer to the drive hardware manual for information regarding CAN interface isolation. The supply voltage common must connect to the CAN\_GND, pin-3.

**CAN SHIELD (Pin 5)** AMC recommends using shielded cable with shielded twisted pairs. Each twisted pair should have one drain wire that must be terminated on one end only.

**Proper Cable Shielding** Bring all twisted pair shields or drain wires to CAN\_SHIELD, pin-5. Do not connect the shield to anything on the other end of the cable.

Bring outer cable shield to the metal D-SUB connector shell that connects to the AMC drive. Do not connect the outer shield on the other end of the cable.

DO NOT TERMINATE SHIELDS ON BOTH ENDS OF ANY CABLE; DOING SO WILL CREATE GROUND LOOPS AND POSSIBLY CREATE NOISE PROBLEMS!

**CAN\_TERM (Pin 8)** The CAN network must be terminated by a 120 Ohm termination resistors on both ends. Generally the host controller will have the first 120-Ohm termination resistor in the network. The only other node to use a 120-Ohm termination resistor is the last node. Each node should branch from the main cable with the shortest possible stub length. This avoids reflections and transmission line effects in the communication line. If long branches are unavoidable, a termination resistor may be required.

# 2 Object Dictionary

## 2.1 Dictionary Table Format

The object dictionary provides one entry for each existing object. Since objects may or may not have sub-indices, the following convention is used for each entry:

**FIGURE 2.1 Object Table Convention**

2002.01h		Sub Index Name		
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>(15)-1</sup> ]	N/A (SF1)	Read / Write*	No
<b>Description:</b> Detailed description of what this object does and how to use it.				
* This indicates a note about conditions.				

In the example of [Figure 2.1](#) the object index and sub-index is referenced via the dot (.). 2002h is the object index and .01h is the sub-index. Objects without sub-indices will be referenced without the dot (.). Furthermore, each entry has the following attributes:

- Data Type: This field specifies the data type of the object. Data types can be 8-bit, 16-bit, 32-bit, or string.
- Range: This field specifies the usable range of the values this object can contain.
- Units: This field specifies the units that apply to the value stored in this object. If the value contained in this object has no units, the field will contain "N/A". The appropriate physical unit is only supplied if there is a one-to-one relationship between the physical unit and the drive data type or if a generic scaling factor is used. If a generic scaling factor is used, its abbreviation will be supplied in brackets beside the units (as shown in [Figure 2.1](#)). For units that require specific scaling between a physical unit and the drive data type, an abbreviation for a drive unit is supplied. All scaling factors and drive units are described in ["Appendix" on page 283](#) according to their abbreviation.
- Accessibility: This field specifies whether the object can be read or written to. If there is a \* in this box, then the object may only be accessible in certain modes. See the Description box for more information about mode dependencies.
- Stored to NVM: This field specifies whether or not the object can be stored to Non Volatile Memory such that it is recalled on power up.
- Description: This field contains detailed information on the object and what it is used for.

## 2.2 Configuration Objects

Although the following objects are used predominately during drive setup and initialization, they are not restricted to use only during setup. Configuration objects can be divided into the following three categories.

- **Administrative Objects:** These objects are used for administrative operations such as loading or restoring parameters from non-volatile memory.
- **Communication Objects:** These objects determine the CANopen communication settings of the drive.
- **Drive Objects:** These objects define the drive configuration and are largely determined by the DriveWare setup and configuration software. Objects which contain general drive information are also available.

### 2.2.1 Administrative Objects

#### **1010h: Store Drive Parameters**

<b>Store All Parameters</b>																			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>															
Unsigned32	See Table	N/A	Write Only	No															
<b>Description:</b>																			
Allows saving of all parameters in non-volatile memory.																			
<table border="1"> <thead> <tr> <th><b>Key</b></th><th><b>MSB</b></th><th></th><th></th><th><b>LSB</b></th></tr> </thead> <tbody> <tr> <td>ASCII Value</td><td>E</td><td>V</td><td>A</td><td>S</td></tr> <tr> <td>Hex Value</td><td>65</td><td>76</td><td>61</td><td>73</td></tr> </tbody> </table>					<b>Key</b>	<b>MSB</b>			<b>LSB</b>	ASCII Value	E	V	A	S	Hex Value	65	76	61	73
<b>Key</b>	<b>MSB</b>			<b>LSB</b>															
ASCII Value	E	V	A	S															
Hex Value	65	76	61	73															

<b>Store Communication Parameters</b>																			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>															
Unsigned32	See Table	N/A	Write Only	No															
<b>Description:</b>																			
Allows saving of communication related parameters (Index 1000h-1FFFh manufacturer specific communication parameters).																			
<table border="1"> <thead> <tr> <th><b>Key</b></th><th><b>MSB</b></th><th></th><th></th><th><b>LSB</b></th></tr> </thead> <tbody> <tr> <td>ASCII Value</td><td>E</td><td>V</td><td>A</td><td>S</td></tr> <tr> <td>Hex Value</td><td>65</td><td>76</td><td>61</td><td>73</td></tr> </tbody> </table>					<b>Key</b>	<b>MSB</b>			<b>LSB</b>	ASCII Value	E	V	A	S	Hex Value	65	76	61	73
<b>Key</b>	<b>MSB</b>			<b>LSB</b>															
ASCII Value	E	V	A	S															
Hex Value	65	76	61	73															

<b>1010.03h</b>		<b>Store Application Parameters</b>																									
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>		<b>Accessibility</b>	<b>Stored to NVM</b>																						
Unsigned32	See Table	N/A		Write Only	No																						
<b>Description:</b>																											
Allows saving of application related parameters (Index 6000h-9FFFh manufacturer specific application parameters).																											
<table border="1"> <thead> <tr> <th><b>Key</b></th><th><b>MSB</b></th><th></th><th></th><th><b>LSB</b></th><th></th><th></th></tr> </thead> <tbody> <tr> <td>ASCII Value</td><td>E</td><td>V</td><td>A</td><td>S</td><td></td><td></td></tr> <tr> <td>Hex Value</td><td>65</td><td>76</td><td>61</td><td>73</td><td></td><td></td></tr> </tbody> </table>							<b>Key</b>	<b>MSB</b>			<b>LSB</b>			ASCII Value	E	V	A	S			Hex Value	65	76	61	73		
<b>Key</b>	<b>MSB</b>			<b>LSB</b>																							
ASCII Value	E	V	A	S																							
Hex Value	65	76	61	73																							

### **1011h: Restore Drive Parameters**

<b>1011.01h</b>		<b>Restore All Parameters</b>																									
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>		<b>Accessibility</b>	<b>Stored to NVM</b>																						
Unsigned32	See Table	N/A		Write Only	No																						
<b>Description:</b>																											
Loads all default parameters into EEPROM. Requires a drive reset or power cycle before new settings are applied.																											
<table border="1"> <thead> <tr> <th><b>Key</b></th><th><b>MSB</b></th><th></th><th></th><th><b>LSB</b></th><th></th><th></th></tr> </thead> <tbody> <tr> <td>ASCII Value</td><td>D</td><td>A</td><td>O</td><td>L</td><td></td><td></td></tr> <tr> <td>Hex Value</td><td>64</td><td>61</td><td>6F</td><td>6C</td><td></td><td></td></tr> </tbody> </table>							<b>Key</b>	<b>MSB</b>			<b>LSB</b>			ASCII Value	D	A	O	L			Hex Value	64	61	6F	6C		
<b>Key</b>	<b>MSB</b>			<b>LSB</b>																							
ASCII Value	D	A	O	L																							
Hex Value	64	61	6F	6C																							

<b>1011.02h</b>		<b>Restore Communication Parameters</b>																									
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>		<b>Accessibility</b>	<b>Stored to NVM</b>																						
Unsigned32	See Table	N/A		Write Only	No																						
<b>Description:</b>																											
Loads communication related parameters (Index 1000h-1FFFh manufacturer specific communication parameters) into EEPROM. Requires a drive reset or power cycle before new settings are applied.																											
<table border="1"> <thead> <tr> <th><b>Key</b></th><th><b>MSB</b></th><th></th><th></th><th><b>LSB</b></th><th></th><th></th></tr> </thead> <tbody> <tr> <td>ASCII Value</td><td>D</td><td>A</td><td>O</td><td>L</td><td></td><td></td></tr> <tr> <td>Hex Value</td><td>64</td><td>61</td><td>6F</td><td>6C</td><td></td><td></td></tr> </tbody> </table>							<b>Key</b>	<b>MSB</b>			<b>LSB</b>			ASCII Value	D	A	O	L			Hex Value	64	61	6F	6C		
<b>Key</b>	<b>MSB</b>			<b>LSB</b>																							
ASCII Value	D	A	O	L																							
Hex Value	64	61	6F	6C																							

<b>1011.03h</b>		<b>Restore Application Parameters</b>																									
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>		<b>Accessibility</b>	<b>Stored to NVM</b>																						
Unsigned32	See Table	N/A		Write Only	No																						
<b>Description:</b>																											
Loads application related parameters (Index 6000h-9FFFh manufacturer specific application parameters) into EEPROM. Requires a drive reset or power cycle before new settings are applied.																											
<table border="1"> <thead> <tr> <th><b>Key</b></th><th><b>MSB</b></th><th></th><th></th><th><b>LSB</b></th><th></th><th></th></tr> </thead> <tbody> <tr> <td>ASCII Value</td><td>D</td><td>A</td><td>O</td><td>L</td><td></td><td></td></tr> <tr> <td>Hex Value</td><td>64</td><td>61</td><td>6F</td><td>6C</td><td></td><td></td></tr> </tbody> </table>							<b>Key</b>	<b>MSB</b>			<b>LSB</b>			ASCII Value	D	A	O	L			Hex Value	64	61	6F	6C		
<b>Key</b>	<b>MSB</b>			<b>LSB</b>																							
ASCII Value	D	A	O	L																							
Hex Value	64	61	6F	6C																							

**2009h: Load EEPROM Values**

Load EEPROM Values														
Data Type	Data Range	Units	Accessibility	Stored to NVM										
Unsigned32	See Table	N/A	Write Only	No										
<b>Description:</b> Defines which parameters will be loaded from the drive's non-volatile memory to the drive's RAM.														
<table border="1"> <thead> <tr> <th>Key (Hex)</th><th>Description</th></tr> </thead> <tbody> <tr> <td>165B</td><td>Load CANopen communication parameters</td></tr> <tr> <td>1CAE</td><td>Load RS232 communication parameters</td></tr> <tr> <td>7405</td><td>Load non-axis parameters</td></tr> <tr> <td>8137</td><td>Load axis parameters</td></tr> </tbody> </table>					Key (Hex)	Description	165B	Load CANopen communication parameters	1CAE	Load RS232 communication parameters	7405	Load non-axis parameters	8137	Load axis parameters
Key (Hex)	Description													
165B	Load CANopen communication parameters													
1CAE	Load RS232 communication parameters													
7405	Load non-axis parameters													
8137	Load axis parameters													

**200Ah: AMC Store Drive Parameters**

AMC Store Drive Parameters														
Data Type	Data Range	Units	Accessibility	Stored to NVM										
Unsigned16	See Table	N/A	Write Only	Yes										
<b>Description:</b> Defines which parameters will be stored to the drive's non-volatile memory.														
<table border="1"> <thead> <tr> <th>Key (Hex)</th><th>Description</th></tr> </thead> <tbody> <tr> <td>165B</td><td>Store CANopen communication parameters</td></tr> <tr> <td>1CAE</td><td>Store RS232 communication parameters</td></tr> <tr> <td>7405</td><td>Store non-axis parameters</td></tr> <tr> <td>8137</td><td>Store axis parameters</td></tr> </tbody> </table>					Key (Hex)	Description	165B	Store CANopen communication parameters	1CAE	Store RS232 communication parameters	7405	Store non-axis parameters	8137	Store axis parameters
Key (Hex)	Description													
165B	Store CANopen communication parameters													
1CAE	Store RS232 communication parameters													
7405	Store non-axis parameters													
8137	Store axis parameters													

## 2.3 Communication Settings

### 2.3.1 General Settings

#### 1000h: Device Type

Device Type										
Data Type	Data Range	Units	Accessibility	Stored to NVM						
Unsigned32	0 – [2 <sup>(32) – 1</sup> ]	N/A	Read Only	No						
<b>Description:</b>										
Contains information about the device type. This 32-bit object is split into two 16-bit fields. Bits 0-15 describe the device profile and bits 16-31 supply additional optional information about the device. AMC drives fit under device profile number 402 (Drives and Motion Control), which is represented by 0192h in the first 16-bit field. Servo drives are designated by setting the second bit of the second field (bit 17) to 1.										
<table border="1"> <tr> <td>Bit 0-15</td><td>Device Profile Number = 0192h (402 - Drives and Motion Controllers)</td></tr> <tr> <td>Bit 16-23</td><td>Type = 02h (Servo Drive)</td></tr> <tr> <td>Bit 24-31</td><td>Reserved = 00</td></tr> </table>					Bit 0-15	Device Profile Number = 0192h (402 - Drives and Motion Controllers)	Bit 16-23	Type = 02h (Servo Drive)	Bit 24-31	Reserved = 00
Bit 0-15	Device Profile Number = 0192h (402 - Drives and Motion Controllers)									
Bit 16-23	Type = 02h (Servo Drive)									
Bit 24-31	Reserved = 00									

#### 100Bh: Stored Node-ID

Stored Node-ID				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	1 – 127	N/A	Read / Write	Yes
<b>Description:</b>				
Stores the Node-ID assigned to the drive, when hardware settings are set for software addressing.				

#### 2100h: Stored Bus Speed

Stored CANbus Baud Rate				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	See below*	kbps	Read / Write	Yes
<b>Description:</b>				
If the hardware addressing is not used, the drive will default to communicating over the CANbus via the bit rate stored in this object. The default rate is 3E8h (1000). If an invalid number is entered into this object, the drive will reset this value back to the default.				
* The drive will accept these valid baud rates: 1000, 500, 250, 125.				

#### 100Ch: Guard Time

Guard Time				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – [2 <sup>(16) – 1</sup> ]	N/A	Read / Write	Yes
<b>Description:</b>				
Used with object 100Dh (Life Time Factor) to store the guard time in ms and the Life Time Factor. The Life Time Factor multiplied with the guard time gives the lifetime for the Life Guarding Protocol.				

**100Dh: Life Time Factor**

Life Time Factor				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned8	0 – [2 <sup>(8)</sup> –1]	N/A	Read / Write	Yes
<b>Description:</b>				
Used with object 100Ch (Guard Time) to store the guard time in ms and the Life Time Factor. The Life Time Factor multiplied with the guard time gives the lifetime for the Life Guarding Protocol.				

**1016h: Consumer Heartbeat Time**

Consumer Heartbeat Time				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – [2 <sup>(32)</sup> –1]	milliseconds (ms)	Read / Write	No
<b>Description:</b>				
Represents the time in which the consumer should expect to receive a heartbeat message. If a heartbeat is not detected within this time frame, the drive will experience a communication error. The action taken during a communication error is configurable. When set to zero, the consumer heartbeat time function is turned off. For details about the format of this sub-index see “Heartbeat” on page 9.				

**1017h: Producer Heartbeat Time**

Producer Heartbeat Time				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	No
<b>Description:</b>				
Represents the time between successive heartbeat messages. Once assigned to a device, that device will begin sending heartbeat messages. They can be any integer value between 1 and 65535. When set to zero, the producer heartbeat is disabled.				

**1018h: Identity Object**

Vendor ID				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
A unique vendor identifier. Always BDh for AMC drives.				

## 20E6h: CANopen Parameters

20E6.01h	Startup Mode of Operation																									
Data Type	Data Range	Units	Accessibility	Stored to NVM																						
Integer32	0 – [2 <sup>(31)</sup> – 1]	N/A	Read / Write	Yes																						
<b>Description:</b>																										
Contains the initial mode of operation when the drive is powered on. Requires power cycle to activate.																										
<table border="1"> <thead> <tr> <th>Bit</th><th>Assignment (1 = assigned, 0 = not assigned)</th></tr> </thead> <tbody> <tr><td>1</td><td>Profile Position Mode</td></tr> <tr><td>2</td><td>Profile Velocity Mode</td></tr> <tr><td>4</td><td>Profile Torque Mode (current mode)</td></tr> <tr><td>6</td><td>Homing Mode</td></tr> <tr><td>8</td><td>Cyclic Synchronous Position Mode</td></tr> <tr><td>9</td><td>Cyclic Synchronous Velocity Mode</td></tr> <tr><td>A</td><td>Cyclic Synchronous Torque Mode (current mode)</td></tr> <tr><td>9E</td><td>Config 0</td></tr> <tr><td>DE</td><td>Config 1</td></tr> <tr><td>FF</td><td>None (Use active configuration settings)</td></tr> </tbody> </table>					Bit	Assignment (1 = assigned, 0 = not assigned)	1	Profile Position Mode	2	Profile Velocity Mode	4	Profile Torque Mode (current mode)	6	Homing Mode	8	Cyclic Synchronous Position Mode	9	Cyclic Synchronous Velocity Mode	A	Cyclic Synchronous Torque Mode (current mode)	9E	Config 0	DE	Config 1	FF	None (Use active configuration settings)
Bit	Assignment (1 = assigned, 0 = not assigned)																									
1	Profile Position Mode																									
2	Profile Velocity Mode																									
4	Profile Torque Mode (current mode)																									
6	Homing Mode																									
8	Cyclic Synchronous Position Mode																									
9	Cyclic Synchronous Velocity Mode																									
A	Cyclic Synchronous Torque Mode (current mode)																									
9E	Config 0																									
DE	Config 1																									
FF	None (Use active configuration settings)																									

20E6.06h	CAN options											
Data Type	Data Range	Units	Accessibility	Stored to NVM								
Unsigned16	N/A	N/A	Read / Write	No								
<b>Description:</b>												
Configuration settings for CANopen functionality. This is the mechanism to switch COB ID filtering on and off.												
<table border="1"> <thead> <tr> <th>Bit</th><th>Assignment (1 = assigned, 0 = not assigned)</th></tr> </thead> <tbody> <tr><td>0</td><td>State Machine Autosequence - When assigned, the drive will automatically sequence to the enabled state when configured to do so.</td></tr> <tr><td>1</td><td>Inhibit COB ID filtering - When assigned, COB ID filtering will be turned off. It is recommended to leave this bit unassigned.</td></tr> <tr><td>2-15</td><td>Reserved</td></tr> </tbody> </table>					Bit	Assignment (1 = assigned, 0 = not assigned)	0	State Machine Autosequence - When assigned, the drive will automatically sequence to the enabled state when configured to do so.	1	Inhibit COB ID filtering - When assigned, COB ID filtering will be turned off. It is recommended to leave this bit unassigned.	2-15	Reserved
Bit	Assignment (1 = assigned, 0 = not assigned)											
0	State Machine Autosequence - When assigned, the drive will automatically sequence to the enabled state when configured to do so.											
1	Inhibit COB ID filtering - When assigned, COB ID filtering will be turned off. It is recommended to leave this bit unassigned.											
2-15	Reserved											

Note: A reset node or power cycle is needed before the changes will take effect.

## 20EBh: Time Stamp Settings

20EB.01h	CAN Time Stamp Milliseconds			
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – [2 <sup>(32)</sup> – 1]	milliseconds (ms)	Read/Write	No
<b>Description:</b>				
This specifies the initial value of the millisecond timer to be used as an initial time stamp value when the drive is configured to be a time stamp master.				

<b>CAN Time Stamp Days</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read/Write	No
<b>Description:</b>				
This specifies the initial value of the days timer to be used as an initial time stamp value when the drive is configured to be a time stamp master.				

<b>CAN Time Stamp State</b>												
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>								
Unsigned32	N/A	N/A	Read/Write	No								
<b>Description:</b>												
This object specifies whether the drive supplies or receives time stamp messages, or if it is inactive. The default setting is 0. It should be noted that an object cannot be assigned as a CAN Time Stamp Slave (1). Once a node on the bus is set to be a CAN Time Stamp Master (2), then the other objects will be automatically assigned as CAN Time Stamp Slaves (1). The Slaves can then be toggled between Inactive (0) and Slave (1) configurations.												
<table border="1"> <thead> <tr> <th><b>Value</b></th><th><b>Description</b></th></tr> </thead> <tbody> <tr> <td>0</td><td>Inactive</td></tr> <tr> <td>1</td><td>CAN Time Stamp Slave</td></tr> <tr> <td>2</td><td>CAN Time Stamp Master</td></tr> </tbody> </table>					<b>Value</b>	<b>Description</b>	0	Inactive	1	CAN Time Stamp Slave	2	CAN Time Stamp Master
<b>Value</b>	<b>Description</b>											
0	Inactive											
1	CAN Time Stamp Slave											
2	CAN Time Stamp Master											
Note: If the drive acts as a time stamp master, it will begin broadcasting once configured. Each time stamp message will be broadcast approximately once every 75 seconds. The drive will stop broadcasting messages when in the stopped state. The worst-case jitter should be less than 100µs with medium bus traffic (<500µs with heavy traffic). The drive cannot be transitioned directly from Slave to Master or from Master to Slave.												

### 2111h: SDO Size Indication

<b>SDO Size Indication</b>										
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>						
Unsigned16	N/A	N/A	Read / Write	Yes						
<b>Description:</b>										
This object determines if size indications will be used during SDO messaging. See table below for appropriate values and their effects on the drive.										
<table border="1"> <thead> <tr> <th><b>Value</b></th><th><b>Description</b></th></tr> </thead> <tbody> <tr> <td>0</td><td>Drive does not respond with size indications in SDO messages</td></tr> <tr> <td>Anything non-zero</td><td>Drive responds with size indications</td></tr> </tbody> </table>					<b>Value</b>	<b>Description</b>	0	Drive does not respond with size indications in SDO messages	Anything non-zero	Drive responds with size indications
<b>Value</b>	<b>Description</b>									
0	Drive does not respond with size indications in SDO messages									
Anything non-zero	Drive responds with size indications									

### 2005h: Serial Interface Configuration

RS-232 Drive Address				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – 63	N/A	Read/Write	Yes
<b>Description:</b>				
Specifies the RS-232 drive address.				

RS-232 Baud Rate																						
Data Type	Data Range	Units	Accessibility	Stored to NVM																		
Unsigned16	0-7	N/A	Read/Write	Yes																		
<b>Description:</b>																						
An integer value that corresponds to the RS-232 baud rate selection. The recommended baud rate is 115200. If necessary, a baud rate of 9600 can be used to connect to the drive, but the baud rate should be increased prior to commissioning the drive. Use the table below to select the desired baud rate..																						
<table border="1"> <thead> <tr> <th>Value</th><th>Baud Rate (bits/s)</th></tr> </thead> <tbody> <tr> <td>0</td><td>9600</td></tr> <tr> <td>1</td><td>19200</td></tr> <tr> <td>2</td><td>38400</td></tr> <tr> <td>3</td><td>57600</td></tr> <tr> <td>4</td><td>115200</td></tr> <tr> <td>5</td><td>230400</td></tr> <tr> <td>6</td><td>460800</td></tr> <tr> <td>7</td><td>921600</td></tr> </tbody> </table>					Value	Baud Rate (bits/s)	0	9600	1	19200	2	38400	3	57600	4	115200	5	230400	6	460800	7	921600
Value	Baud Rate (bits/s)																					
0	9600																					
1	19200																					
2	38400																					
3	57600																					
4	115200																					
5	230400																					
6	460800																					
7	921600																					

### 2.3.2 PDO Configuration

**1400h: 1<sup>st</sup> Receive PDO Communication Parameter** This PDO is valid in all operating modes. The COB-ID of this PDO can be set to any value. See object 1600h for details about the data transmitted by this PDO.

COB-ID Used By PDO				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see “Setting COB-ID’s for each PDO” on page 27.				

<b>1400.02h</b>				
<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see <a href="#">“Setting COB-ID’s for each PDO” on page 27.</a>				

**1600h: 1<sup>st</sup> Receive PDO Mapping Parameter** This PDO is used to set the state of the drive (ex: ready, not ready, enabled, disabled, etc.). The object mapped to this PDO is fixed and not user selectable. See object 1400h for details on the transmission method.

<b>1600.01h</b>				
<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the ControlWord object (6040h). For details about the format of this sub-index see <a href="#">“Mapping Parameter Object” on page 28.</a>				

**1401h: 2<sup>nd</sup> Receive PDO Communication Parameter** This PDO is valid in all operating modes. The COB-ID of this PDO can be set to any value. See object 1601h for details about the data transmitted by this PDO.

<b>1401.01h</b>				
<b>COB-ID Used By PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see <a href="#">“Setting COB-ID’s for each PDO” on page 27.</a>				

<b>1401.02h</b>				
<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see <a href="#">“Transmission Type” on page 28.</a>				

**1601h: 2<sup>nd</sup> Receive PDO Mapping Parameter** This PDO is used to set both the state of the drive (ex: enabled, disabled, faulted, etc.) and the mode of operation of the drive (ex: torque, velocity, or position modes). The objects mapped to this PDO are fixed and not user selectable. See object 1401h for details on the transmission method.

<b>1601.01h</b>				
<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the ControlWord object (6040h). For details about the format of this sub-index see <a href="#">“Mapping Parameter Object” on page 28.</a>				

<b>PDO Mapping for the 2<sup>nd</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Modes of Operation object (6060h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1402h: 3<sup>rd</sup> Receive PDO Communication Parameter** This PDO is valid in profile position mode only and does not exist in other modes. The COB-ID of this PDO can be set to any value. See object 1602h for details about the data transmitted by this PDO.

<b>COB-ID Used By PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1602h: 3<sup>rd</sup> Receive PDO Mapping Parameter** This PDO is used to set both the state of the drive (ex: enabled, disabled, faulted, etc.) and the target position of the drive. The PDO is only available in profile position mode (see object 6060h for operating modes). The objects mapped to this PDO are fixed and not user selectable. See object 1402h for details on the transmission method.

<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the ControlWord object (6040h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 2<sup>nd</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Target Position object (607Ah). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1403h: 4<sup>th</sup> Receive PDO Communication Parameter** This PDO is valid in profile velocity mode only and does not exist in other modes. The COB-ID of this PDO can be set to any value. See object 1603h for details about the data transmitted by this PDO.

COB-ID Used By PDO				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

Transmission Type				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1603h: 4<sup>th</sup> Receive PDO Mapping Parameter** This PDO is used to set both the state of the drive (ex: enabled, disabled, faulted, etc.) and the target velocity of the drive. The PDO is only available in profile velocity mode (see object 6060h for operating modes). The objects mapped to this PDO are fixed and not user selectable. See object 1403h for details on the transmission method.

PDO Mapping for the 1 <sup>st</sup> Application Object				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the ControlWord object (6040h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

PDO Mapping for the 2 <sup>nd</sup> Application Object				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Target Velocity object (60FFh). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1404h: 5<sup>th</sup> Receive PDO Communication Parameter** This PDO is valid in profile torque mode only and does not exist in other modes. The COB-ID of this PDO can be set to any value. See object 1604h for details about the data transmitted by this PDO.

COB-ID Used By PDO				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1604h: 5<sup>th</sup> Receive PDO Mapping Parameter** This PDO is used to set both the state of the drive (ex: enabled, disabled, faulted, etc.) and the target torque of the drive. The PDO is only available in profile torque mode (see object 6060h for operating modes). The objects mapped to this PDO are fixed and not user selectable. See object 1404h for details on the transmission method.

<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the ControlWord object (6040h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 2<sup>nd</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Target Current object (6071h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1414h: 21<sup>st</sup> Receive PDO Communication Parameter** This PDO is valid in profile position mode only and does not exist in other modes. The COB-ID of this PDO can be set to any value. See object 1614h for details about the data transmitted by this PDO.

<b>COB-ID Used By PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1614h: 21<sup>st</sup> Receive PDO Mapping Parameter** This PDO is used to set the target position of the drive. The PDO is only available in profile position mode (see object 6060h for operating modes). The object mapped to this PDO is fixed and not user selectable. See object 1414h for details on the transmission method.

<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Target Position object (607Ah). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1415h: 22<sup>nd</sup> Receive PDO Communication Parameter** This PDO is valid in profile velocity mode only and does not exist in other modes. The COB-ID of this PDO can be set to any value. See object 1615h for details about the data transmitted by this PDO.

<b>COB-ID Used By PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1615h: 22<sup>nd</sup> Receive PDO Mapping Parameter** This PDO is used to set the target velocity of the drive. The PDO is only available in profile velocity mode (see object 6060h for operating modes). The object mapped to this PDO is fixed and not user selectable. See object 1415h for details on the transmission method.

<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Target Velocity object (60FFh). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1416h: 23<sup>rd</sup> Receive PDO Communication Parameter** This PDO is valid in profile torque mode only and does not exist in other modes. The COB-ID of this PDO can be set to any value. See object 1616h for details about the data transmitted by this PDO.

COB-ID Used By PDO				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

Transmission Type				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1616h: 23<sup>rd</sup> Receive PDO Mapping Parameter** This PDO is used to set the target current of the drive. The PDO is only available in profile torque mode (see object 6060h for operating modes). The object mapped to this PDO is fixed and not user selectable. See object 1416h for details on the transmission method.

PDO Mapping for the 1 <sup>st</sup> Application Object				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Target Current object (6071h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1417h: 24<sup>th</sup> Receive PDO Communication Parameter** This PDO is valid in interpolated position mode (PVT mode) only and does not exist in other modes. The COB-ID of this PDO can be set to any value. See object 1617h for details about the data transmitted by this PDO.

COB-ID Used By PDO				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1617h: 24<sup>th</sup> Receive PDO Mapping Parameter** This PDO is used to send PVT commands (set-points) to the drive. The PDO is only available in interpolated position mode (see object 6060h for operating modes). The object mapped to this PDO is fixed and not user selectable. See object 1417h for details on the transmission method.

<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Interpolation Data Record object (60C1h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1419h: 26<sup>th</sup> Receive PDO Mapping Parameter** This PDO is used to initiate the start of PVT execution. The PDO is only applicable when the mode of operation is interpolated position mode (see object 6060h for operating modes).

<b>COB-ID Used by PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read/Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. It is recommended to use the default value. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 - 255	N/A	Read/Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. It is recommended to use the default value. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1800h: 1<sup>st</sup> Transmit PDO Communication Parameter** This PDO is transmitted upon a user configurable event (see objects 2120h – 2125h, 2130h – 2133h, 2140h – 2147h and 2150h – 2153h), can be transmitted upon a SYNC message or when an RTR is received if the

sub-indices of this object are configured appropriately. See object 1A00h for details about the data transmitted by this PDO.

<b>COB-ID Used By PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1A00h: 1<sup>st</sup> Transmit PDO Mapping Parameter** This PDO transmits drive status information. The object mapped to this PDO is fixed and not user selectable. See object 1800h for details on the transmission method.

<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	0 - 2 <sup>32</sup>	N/A	Read / Write	Yes
<b>Description:</b>				
Maps the StatusWord object (6041h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1802h: 3<sup>rd</sup> Transmit PDO Communication Parameter** This PDO is transmitted upon a user configurable event (see objects 2120h – 2125h, 2130h – 2133h, 2140h – 2147h and 2150h – 2153h), can be transmitted upon a SYNC message or when an RTR is received if the sub-indices of this object are configured appropriately. See object 1A02h for details about the data transmitted by this PDO.

<b>COB-ID Used By PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1A02h: 3<sup>rd</sup> Transmit PDO Mapping Parameter** This PDO transmits drive status information and the actual position value stored in the drive. The objects mapped to this PDO are fixed and not user selectable. See object 1802h for details on the transmission method.

<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the StatusWord object (6041h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 2<sup>nd</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	0 – 255	N/A	Read Only	No
<b>Description:</b>				
Maps the Actual Position Value object (6064h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1803h: 4<sup>th</sup> Transmit PDO Communication Parameter** This PDO is transmitted upon a user configurable event (see objects 2120h – 2125h, 2130h – 2133h, 2140h – 2147h and 2150h – 2153h), can be transmitted upon a SYNC message or when an RTR is received if the sub-indices of this object are configured appropriately. See object 1A03h for details about the data transmitted by this PDO.

<b>COB-ID Used By PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1A03h: 4<sup>th</sup> Transmit PDO Mapping Parameter** This PDO transmits drive status information and the actual velocity value stored in the drive. The objects mapped to this PDO are fixed and not user selectable. See object 1803h for details on the transmission method.

<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the StatusWord object (6041h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 2<sup>nd</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	0 – 255	N/A	Read Only	No
<b>Description:</b>				
Maps the Actual Velocity Value object (606Ch). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1804h: 5<sup>th</sup> Transmit PDO Communication Parameter** This PDO is transmitted upon a user configurable event (see objects 2120h – 2125h, 2130h – 2133h, 2140h – 2147h and 2150h – 2153h), can be transmitted upon a SYNC message or when an RTR is received if the sub-indices of this object are configured appropriately. See object 1A04h for details about the data transmitted by this PDO.

<b>COB-ID Used By PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1A04h: 5<sup>th</sup> Transmit PDO Mapping Parameter** This PDO transmits drive status information and the actual torque value stored in the drive. The objects mapped to this PDO are fixed and not user selectable. See object 1804h for details on the transmission method.

<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the StatusWord object (6041h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 2<sup>nd</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Actual Current Value object (6077h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1814h: 21<sup>st</sup> Transmit PDO Communication Parameter** This PDO is transmitted upon a user configurable event (see objects 2120h – 2125h, 2130h – 2133h, 2140h – 2147h and 2150h – 2153h), can be transmitted upon a SYNC message or when an RTR is received if the sub-indices of this object are configured appropriately. See object 1A14h for details about the data transmitted by this PDO.

<b>COB-ID Used By PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see “ <a href="#">Setting COB-ID’s for each PDO</a> ” on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see “ <a href="#">Transmission Type</a> ” on page 28.				

**1A14h: 21<sup>st</sup> Transmit PDO Mapping Parameter** This PDO transmits the actual position value stored in the drive. The object mapped to this PDO is fixed and not user selectable. See object 1814h for details on the transmission method.

<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Actual Position Value object (6064h). For details about the format of this sub-index see “ <a href="#">Mapping Parameter Object</a> ” on page 28.				

**1815h: 22<sup>nd</sup> Transmit PDO Communication Parameter** This PDO is transmitted upon a user configurable event (see objects 2120h – 2125h, 2130h – 2133h, 2140h – 2147h and 2150h – 2153h), can be transmitted upon a SYNC message or when an RTR is received if the sub-indices of this object are configured appropriately. See object 1A15h for details about the data transmitted by this PDO.

<b>COB-ID Used By PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see “ <a href="#">Setting COB-ID’s for each PDO</a> ” on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see “ <a href="#">Transmission Type</a> ” on page 28.				

**1A15h: 22<sup>nd</sup> Transmit PDO Mapping Parameter** This PDO transmits the actual velocity value stored in the drive. The object mapped to this PDO is fixed and not user selectable. See object 1A15h for details on the transmission method.

<b>PDO Mapping for the 1<sup>st</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Actual Velocity Value object (606Ch). For details about the format of this sub-index see “ <a href="#">Mapping Parameter Object</a> ” on page 28.				

**1816h: 23<sup>rd</sup> Transmit PDO Communication Parameter** This PDO is transmitted upon a user configurable event (see objects 2120h – 2125h, 2130h – 2133h, 2140h – 2147h and 2150h – 2153h), can be transmitted upon a SYNC message or when an RTR is received if the sub-indices of this object are configured appropriately. See object 1A16h for details about the data transmitted by this PDO.

<b>COB-ID Used By PDO</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see “ <a href="#">Setting COB-ID’s for each PDO</a> ” on page 27.				

<b>Transmission Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see “ <a href="#">Transmission Type</a> ” on page 28.				

**1A16h: 23<sup>rd</sup> Transmit PDO Mapping Parameter** This PDO transmits the actual torque value stored in the drive. The object mapped to this PDO is fixed and not user selectable. See object 1816h for details on the transmission method.

PDO Mapping for the 1 <sup>st</sup> Application Object				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Actual Current Value object (6077h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1817h: 24<sup>th</sup> Transmit PDO Communication Parameter** This PDO is applicable to interpolated position mode only (see object 6060h for operating modes) and is transmitted upon a user configurable event (see objects 2120h – 2125h, 2130h – 2133h, 2140h – 2147h and 2150h – 2153h). The PDO can also be transmitted upon a SYNC message or when an RTR is received if the sub-indices of this object are configured appropriately. See object 1A17h for details about the data transmitted by this PDO.

COB-ID Used By PDO				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

Transmission Type				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1A17h: 24<sup>th</sup> Transmit PDO Mapping Parameter** This PDO transmits information about the status of the PVT buffer in the drive. The PDO is only useful when the drive is in interpolated position mode (see object 6060h for operating modes). The object mapped to this PDO is fixed and not user selectable. See object 1817h for details on the transmission method.

PDO Mapping for the 1 <sup>st</sup> Application Object				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Buffer Position of the Interpolation Data Configuration object (60C4.04h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1818h: 25<sup>th</sup> Transmit PDO Communication Parameter** This PDO is applicable to all operating modes (see object 6060h for operating modes) and is transmitted upon a user configurable event (see objects 2120h – 2125h, 2130h – 2133h, 2140h – 2147h and 2150h – 2153h). The PDO can also be transmitted upon a SYNC message or when an RTR is received if

the sub-indices of this object are configured appropriately. See object 1A18h for details about the data transmitted by this PDO.

COB-ID Used By PDO				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

Transmission Type				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1A18h: 25<sup>th</sup> Transmit PDO Mapping Parameter** This PDO transmits information about the status of the programmable and dedicated digital inputs on the drive. The objects mapped to this PDO are fixed and not user selectable. See object 1818h for details on the transmission method.

PDO Mapping for the 1 <sup>st</sup> Application Object				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read Only	No
<b>Description:</b>				
Maps the Digital Input Values object (2023.01h). For details about the format of this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

**1819h: 26<sup>th</sup> Transmit PDO Communication Parameter** This PDO is applicable to all operating modes (see object 6060h for operating modes) and is transmitted upon a user configurable event (see objects 2120h – 2125h, 2130h – 2133h, 2140h – 2147h and 2150h – 2153h). The PDO can also be transmitted upon a SYNC message or when an RTR is received if the sub-indices of this object are configured appropriately. See object 1A19h for details about the data transmitted by this PDO.

COB-ID Used By PDO				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Holds the COB-ID of the PDO as well as other parameters. For details see " <a href="#">Setting COB-ID's for each PDO</a> " on page 27.				

Transmission Type				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned8	0 – 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the way in which the PDO will be transmitted, namely synchronous or asynchronous. For details see " <a href="#">Transmission Type</a> " on page 28.				

**1A19h: 26<sup>th</sup> Transmit PDO Mapping Parameter** This PDO transmits up to 8 user specified objects defined by the sub-indices below. Any object in this object dictionary may be mapped to one of these sub-indices; there is no restriction other than data size. If a large object, such as a 32-byte string, is mapped to TDDO26, it simply will not transmit when triggered. Generally it is most useful to map numerical data to this TPDO.



## Notice

Sub-index 0 (1A19.00h) must reflect the number of configured mapping sub-indices. If sub-index 0 is left at its default value of 0, TPDO26 will not transmit.

The total number of bytes TPDO26 can transmit is 8. If, across all the sub-indices, more than 8 bytes are assigned to transmit, TPDO26 will not transmit.

- Example 1: Map 8 objects to all 8 sub-indices of TPDO26. Each object only has 8 bits of data, therefore the total bytes to transmit = 8. In this case TPDO26 will transmit and the data will appear sub-index 1 = byte 1, sub-index 2 = byte 2 and so on.
- Example 2: Map 2 objects, each a 32-bit object, to sub-indices 1 and 2. In this case TPDO26 will transmit and the data will appear sub-index 1 = bytes 1-4, sub-index 2 = bytes 5-8.
- Example 3: Map 3 objects, two 32-bit objects and one 16-bit object to sub-indices 1, 2, and 3. In this case TPDO26 will not transmit because the total number of bytes assigned to transmit exceeds 8.

See object 1819h for details on setting the transmission method.

PDO Mapping for the 1 <sup>st</sup> Application Object				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Identifies an object that TPDO26 will transmit data from when triggered. It is important to note that TPDO26 only has 8 available data bytes to transmit information with. If sub-indices 1A19.01h through 1A19.08h contain objects such that the total number of bytes to transmit is greater than 8, TPDO26 will not transmit any data.				
To enable this mapping, 1A19.00h must be set to $\geq 1$ .				
For details about formatting data for this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 2<sup>nd</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Identifies an object that TPDO26 will transmit data from when triggered. It is important to note that TPDO26 only has 8 available data bytes to transmit information with. If sub-indices 1A19.01h through 1A19.08h contain objects such that the total number of bytes to transmit is greater than 8, TPDO26 will not transmit any data.				
To enable this mapping, 1A19.00h must be set to $\geq 2$ .				
For details about formatting data for this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 3<sup>rd</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Identifies an object that TPDO26 will transmit data from when triggered. It is important to note that TPDO26 only has 8 available data bytes to transmit information with. If sub-indices 1A19.01h through 1A19.08h contain objects such that the total number of bytes to transmit is greater than 8, TPDO26 will not transmit any data.				
To enable this mapping, 1A19.00h must be set to $\geq 3$ .				
For details about formatting data for this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 4<sup>th</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Identifies an object that TPDO26 will transmit data from when triggered. It is important to note that TPDO26 only has 8 available data bytes to transmit information with. If sub-indices 1A19.01h through 1A19.08h contain objects such that the total number of bytes to transmit is greater than 8, TPDO26 will not transmit any data.				
To enable this mapping, 1A19.00h must be set to $\geq 4$ .				
For details about formatting data for this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 6<sup>th</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Identifies an object that TPDO26 will transmit data from when triggered. It is important to note that TPDO26 only has 8 available data bytes to transmit information with. If sub-indices 1A19.01h through 1A19.08h contain objects such that the total number of bytes to transmit is greater than 8, TPDO26 will not transmit any data.				
To enable this mapping, 1A19.00h must be set to $\geq 5$ .				
For details about formatting data for this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 6<sup>th</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Identifies an object that TPDO26 will transmit data from when triggered. It is important to note that TPDO26 only has 8 available data bytes to transmit information with. If sub-indices 1A19.01h through 1A19.08h contain objects such that the total number of bytes to transmit is greater than 8, TPDO26 will not transmit any data.				
To enable this mapping, 1A19.00h must be set to $\geq 6$ .				
For details about formatting data for this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 7<sup>th</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Identifies an object that TPDO26 will transmit data from when triggered. It is important to note that TPDO26 only has 8 available data bytes to transmit information with. If sub-indices 1A19.01h through 1A19.08h contain objects such that the total number of bytes to transmit is greater than 8, TPDO26 will not transmit any data.				
To enable this mapping, 1A19.00h must be set to $\geq 7$ .				
For details about formatting data for this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

<b>PDO Mapping for the 8<sup>th</sup> Application Object</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Identifies an object that TPDO26 will transmit data from when triggered. It is important to note that TPDO26 only has 8 available data bytes to transmit information with. If sub-indices 1A19.01h through 1A19.08h contain objects such that the total number of bytes to transmit is greater than 8, TPDO26 will not transmit any data.				
To enable this mapping, 1A19.00h must be set to $\geq 8$ .				
For details about formatting data for this sub-index see " <a href="#">Mapping Parameter Object</a> " on page 28.				

### **2120h: PDO Timer1 Cycle Time**

<b>TPDO Timer1 Cycle Time</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	0 – 2 <sup>32</sup>	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
Sets the cycle time of the assigned TPDOs (assigned in object 2121h). If the cycle time is set to 0, the assigned TPDOs will be transmitted continuously.				

### **2121h: PDO Timer1 Assigned TPDOs**

<b>TPDO Timer1 Assigned TPDOs</b>																												
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>																								
Unsigned32	0 – 1FFh	N/A	Read / Write	Yes																								
<b>Description:</b>																												
Assigns TPDOs to Timer1. If this object is set to 0, Timer1 will stop.																												
<table border="1"> <thead> <tr> <th><b>Bit</b></th><th><b>Assignment (1 = assigned, 0 = not assigned)</b></th></tr> </thead> <tbody> <tr><td>0</td><td>TPDO 1</td></tr> <tr><td>1</td><td>TPDO 3</td></tr> <tr><td>2</td><td>TPDO 4</td></tr> <tr><td>3</td><td>TPDO 5</td></tr> <tr><td>4</td><td>TPDO 21</td></tr> <tr><td>5</td><td>TPDO 22</td></tr> <tr><td>6</td><td>TPDO 23</td></tr> <tr><td>7</td><td>TPDO 24</td></tr> <tr><td>8</td><td>TPDO 25</td></tr> <tr><td>9</td><td>TPDO 26</td></tr> <tr><td>10-31</td><td>Reserved</td></tr> </tbody> </table>					<b>Bit</b>	<b>Assignment (1 = assigned, 0 = not assigned)</b>	0	TPDO 1	1	TPDO 3	2	TPDO 4	3	TPDO 5	4	TPDO 21	5	TPDO 22	6	TPDO 23	7	TPDO 24	8	TPDO 25	9	TPDO 26	10-31	Reserved
<b>Bit</b>	<b>Assignment (1 = assigned, 0 = not assigned)</b>																											
0	TPDO 1																											
1	TPDO 3																											
2	TPDO 4																											
3	TPDO 5																											
4	TPDO 21																											
5	TPDO 22																											
6	TPDO 23																											
7	TPDO 24																											
8	TPDO 25																											
9	TPDO 26																											
10-31	Reserved																											

**2122h: PDO Timer1 Next Processing Time**

TPDO Timer1 Next Processing Time				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	milliseconds (ms)	Read	No
<b>Description:</b>				
Contains the time of the next Timer1 event with respect to the total drive run time as seen by the drive.				

**2123h: PDO Timer2 Cycle Time**

TPDO Timer2 Assigned TPDOs				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
Sets the cycle time of the assigned TPDOs for Timer2. If the cycle time is set to 0, the assigned TPDOs will be transmitted continuously.				

**2124h: PDO Timer2 Assigned TPDOs**

TPDO Timer2 Assigned TPDOs																												
Data Type	Data Range	Units	Accessibility	Stored to NVM																								
Unsigned32	0 – 1FFh	N/A	Read / Write	Yes																								
<b>Description:</b>																												
Assigns TPDOs to Timer 2. If this object is set to 0, Timer 2 will stop.																												
<table border="1"> <thead> <tr> <th>Bit</th> <th>Assignment (1 = assigned, 0 = not assigned)</th> </tr> </thead> <tbody> <tr><td>0</td><td>TPDO 1</td></tr> <tr><td>1</td><td>TPDO 3</td></tr> <tr><td>2</td><td>TPDO 4</td></tr> <tr><td>3</td><td>TPDO 5</td></tr> <tr><td>4</td><td>TPDO 21</td></tr> <tr><td>5</td><td>TPDO 22</td></tr> <tr><td>6</td><td>TPDO 23</td></tr> <tr><td>7</td><td>TPDO 24</td></tr> <tr><td>8</td><td>TPDO 25</td></tr> <tr><td>9</td><td>TPDO 26</td></tr> <tr><td>10-31</td><td>Reserved</td></tr> </tbody> </table>					Bit	Assignment (1 = assigned, 0 = not assigned)	0	TPDO 1	1	TPDO 3	2	TPDO 4	3	TPDO 5	4	TPDO 21	5	TPDO 22	6	TPDO 23	7	TPDO 24	8	TPDO 25	9	TPDO 26	10-31	Reserved
Bit	Assignment (1 = assigned, 0 = not assigned)																											
0	TPDO 1																											
1	TPDO 3																											
2	TPDO 4																											
3	TPDO 5																											
4	TPDO 21																											
5	TPDO 22																											
6	TPDO 23																											
7	TPDO 24																											
8	TPDO 25																											
9	TPDO 26																											
10-31	Reserved																											

**2125h: PDO Timer2 Next Processing Time**

TPDO Timer2 Next Processing Time				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	milliseconds (ms)	Read	No
<b>Description:</b>				
Contains the time of the next Timer2 event with respect to the total drive run time as seen by the drive.				

## 2130h: PDO Value-Changed Object ID

TPDO Value-Changed Object ID				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read / Write	No
<b>Description:</b>				
Contains the Object ID of the object to observe continuously. After a user specified value change of this object (set via object 2131h), the assigned TPDOs will be sent (assigned via object 2132h). Use the three objects (2130h, 2131h, 2132h) to monitor any object and send assigned TPDOs after a desired value change. Use the format in the table below to specify the observed object.				
Byte0	Byte1	Byte2	Byte3	
Sub-index	Object Index (LSB)	Object Index (MSB)	Always 0	

## 2131h: PDO Value-Changed Delta Value

TPDO Value-Changed Delta Value				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read / Write	No
<b>Description:</b>				
Sets the amount of change of the observed object (defined by 2130h) that will cause the assigned Transmit PDOs to be sent (assigned via object 2132h). Use the three objects (2130h, 2131h, 2132h) to monitor any object and send assigned TPDOs after a desired value change. Setting this value to zero disables the functionality. The meaning of the value in this object depends on the observed object.				

## 2132h: PDO Value-Changed Assigned TPDOs

TPDO Value-Changed Assigned TPDOs																												
Data Type	Data Range	Units	Accessibility	Stored to NVM																								
Unsigned32	0 – 1FFh	N/A	Read / Write	Yes																								
<b>Description:</b>																												
Assigns TPDOs to Value-Changed event. If this object is set to 0, Timer 1 will stop.																												
<table border="1"> <thead> <tr> <th>Bit</th> <th>Assignment (1 = assigned, 0 = not assigned)</th> </tr> </thead> <tbody> <tr><td>0</td><td>TPDO 1</td></tr> <tr><td>1</td><td>TPDO 3</td></tr> <tr><td>2</td><td>TPDO 4</td></tr> <tr><td>3</td><td>TPDO 5</td></tr> <tr><td>4</td><td>TPDO 21</td></tr> <tr><td>5</td><td>TPDO 22</td></tr> <tr><td>6</td><td>TPDO 23</td></tr> <tr><td>7</td><td>TPDO 24</td></tr> <tr><td>8</td><td>TPDO 25</td></tr> <tr><td>9</td><td>TPDO 26</td></tr> <tr><td>10-31</td><td>Reserved</td></tr> </tbody> </table>					Bit	Assignment (1 = assigned, 0 = not assigned)	0	TPDO 1	1	TPDO 3	2	TPDO 4	3	TPDO 5	4	TPDO 21	5	TPDO 22	6	TPDO 23	7	TPDO 24	8	TPDO 25	9	TPDO 26	10-31	Reserved
Bit	Assignment (1 = assigned, 0 = not assigned)																											
0	TPDO 1																											
1	TPDO 3																											
2	TPDO 4																											
3	TPDO 5																											
4	TPDO 21																											
5	TPDO 22																											
6	TPDO 23																											
7	TPDO 24																											
8	TPDO 25																											
9	TPDO 26																											
10-31	Reserved																											

**2133h: PDO Value-Changed Object Last Value**

TPDO Value-Changed Object Last Value				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read Only	No
<b>Description:</b>				
Consists of the value of the observed object, defined by 2130h, from the last PDO transmission triggered by a Value-Changed event.				

**2140h: PDO Bits-Changed\_1 Object ID**

TPDO Bits-Changed_1 Object ID				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read / Write	Yes
<b>Description:</b>				
Identifies a CANopen object which is observed continuously for bit changing. If the observed bits change, the assigned PDOs will be sent. The observed bits are defined by a bit mask in object 2141h while the assigned PDOs are defined by object 2142h. Use the format in the table below to specify the observed object.				
Byte0	Byte1	Byte2	Byte3	
Sub-index	Object Index (LSB)	Object Index (MSB)	Always 0	

**2141h: PDO Bits-Changed\_1 Object Bit Mask**

TPDO Bits-Changed_1 Object Bit Mask				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read / Write	Yes
<b>Description:</b>				
Bit mask to identify which bits are observed in the object identified in 2140h. If the observed bits change the assigned PDOs are sent. If this variable is set to 0 the identified object will not be observed.				

**2142h: PDO Bits-Changed\_1 Assigned PDOs**

TPDO Bits-Changed_1 Assigned PDOs				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read / Write	Yes
<b>Description:</b>				
Assigns PDOs to Bits-Changed1 event. If this object is set to a value of 0, the object identified in 2140h will not be observed.				
Bit	Assignment (1 = assigned, 0 = not assigned)			
0	PDO 1			
1	PDO 3			
2	PDO 4			
3	PDO 5			
4	PDO 21			
5	PDO 22			
6	PDO 23			
7	PDO 24			
8	PDO 25			
9	PDO 26			
10-31	Reserved			

**2143h: PDO Bits-Changed\_1 Object Last Value**

TPDO Bits-Changed_1 Object Last Value				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read Only	No
<b>Description:</b>				
This object consists of the value of the observed object, defined by 2140h, from the last PDO transmission triggered by a Bits-Changed1 event.				

**2144h: PDO Bits-Changed\_2 Object ID**

TPDO Bits-Changed_2 Object ID				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read / Write	Yes
<b>Description:</b>				
This object is used to identify a CANopen object which is observed continuously for bit changing. If the observed bits change, the assigned PDOs will be sent. The observed bits are defined by a bit mask in object 2145h while the assigned PDOs are defined by object 2146h. Use the format in the table below to specify the observed object.				
Byte0	Byte1	Byte2	Byte3	
Sub-index	Object Index (LSB)	Object Index (MSB)	Always 0	

**2145h: PDO Bits-Changed\_2 Object Bit Mask**

TPDO Bits-Changed_2 Object Bit Mask				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read / Write	Yes
<b>Description:</b>				
This object consists of a bit mask to identify which bits are observed in the object identified in 2140h. If the observed bits change the assigned PDOs are sent. If this variable is set to 0 the identified object will not be observed.				

**2146h: PDO Bits-Changed\_2 Assigned PDOs**

TPDO Bits-Changed_2 Assigned PDOs																												
Data Type	Data Range	Units	Accessibility	Stored to NVM																								
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read / Write	Yes																								
<b>Description:</b>																												
Assigns PDOs to Bits-Changed2 event. If this object is set to a value of 0, the object identified in 2144h will not be observed.																												
<table border="1"> <thead> <tr> <th>Bit</th> <th>Assignment (1 = assigned, 0 = not assigned)</th> </tr> </thead> <tbody> <tr><td>0</td><td> PDO 1</td></tr> <tr><td>1</td><td> PDO 3</td></tr> <tr><td>2</td><td> PDO 4</td></tr> <tr><td>3</td><td> PDO 5</td></tr> <tr><td>4</td><td> PDO 21</td></tr> <tr><td>5</td><td> PDO 22</td></tr> <tr><td>6</td><td> PDO 23</td></tr> <tr><td>7</td><td> PDO 24</td></tr> <tr><td>8</td><td> PDO 25</td></tr> <tr><td>9</td><td> PDO 26</td></tr> <tr><td>10-31</td><td> Reserved</td></tr> </tbody> </table>					Bit	Assignment (1 = assigned, 0 = not assigned)	0	PDO 1	1	PDO 3	2	PDO 4	3	PDO 5	4	PDO 21	5	PDO 22	6	PDO 23	7	PDO 24	8	PDO 25	9	PDO 26	10-31	Reserved
Bit	Assignment (1 = assigned, 0 = not assigned)																											
0	PDO 1																											
1	PDO 3																											
2	PDO 4																											
3	PDO 5																											
4	PDO 21																											
5	PDO 22																											
6	PDO 23																											
7	PDO 24																											
8	PDO 25																											
9	PDO 26																											
10-31	Reserved																											

**2147h: PDO Bits-Changed\_2 Object Last Value**

TPDO Bits-Changed_2 Object Last Value				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read Only	No
<b>Description:</b>				
This object consists of the value of the observed object, defined by 2144h, from the last PDO transmission triggered by a Bits-Changed2 event.				

**2150h: PDO Value-Reached Object ID**

TPDO Value-Reached Object ID				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read / Write	Yes
<b>Description:</b>				
This object is used to identify a CANopen object which is observed continuously for changing. If the value of the observed object reaches a predefined value, the assigned PDOs will be sent. The predefined value is defined in 2151h while the assigned PDOs are defined in 2152h. Use the format in the table below to specify the observed object.				
Byte0	Byte1	Byte2	Byte3	
Sub-index	Object Index (LSB)	Object Index (MSB)	Always 0	

**2151h: PDO Value-Reached**

TPDO Value-Reached				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read / Write	Yes
<b>Description:</b>				
This object consists of a predefined value to compare with the value of an observed object identified in 2150h. If the value of the observed object reaches this value the assigned PDOs are sent.				

**2152h: PDO Value-Reached Assigned PDOs**

TPDO Value-Reached Assigned PDOs																												
Data Type	Data Range	Units	Accessibility	Stored to NVM																								
Unsigned32	0 – 2 <sup>32</sup>	N/A	Read / Write	Yes																								
<b>Description:</b>																												
Assigns PDOs to Value-Reached event. If this object is set to a value of 0, the object identified in 2150h will not be observed.																												
<table border="1"> <thead> <tr> <th>Bit</th> <th>Assignment (1 = assigned, 0 = not assigned)</th> </tr> </thead> <tbody> <tr><td>0</td><td> PDO 1</td></tr> <tr><td>1</td><td> PDO 3</td></tr> <tr><td>2</td><td> PDO 4</td></tr> <tr><td>3</td><td> PDO 5</td></tr> <tr><td>4</td><td> PDO 21</td></tr> <tr><td>5</td><td> PDO 22</td></tr> <tr><td>6</td><td> PDO 23</td></tr> <tr><td>7</td><td> PDO 24</td></tr> <tr><td>8</td><td> PDO 25</td></tr> <tr><td>9</td><td> PDO 26</td></tr> <tr><td>10-31</td><td> Reserved</td></tr> </tbody> </table>					Bit	Assignment (1 = assigned, 0 = not assigned)	0	PDO 1	1	PDO 3	2	PDO 4	3	PDO 5	4	PDO 21	5	PDO 22	6	PDO 23	7	PDO 24	8	PDO 25	9	PDO 26	10-31	Reserved
Bit	Assignment (1 = assigned, 0 = not assigned)																											
0	PDO 1																											
1	PDO 3																											
2	PDO 4																											
3	PDO 5																											
4	PDO 21																											
5	PDO 22																											
6	PDO 23																											
7	PDO 24																											
8	PDO 25																											
9	PDO 26																											
10-31	Reserved																											

**2153h: TPDO Value-Reached Direction**

TPDO Value-Reached Direction				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – 2 <sup>16</sup>	N/A	Read / Write	Yes
<b>Description:</b>				
If the value of this object is 0, the assigned TPDOs (defined by 2152h) are sent if the observed object (identified in 2150h) reaches the predefined value (set by 2151h) in the downward direction. Otherwise the assigned TPDOs are sent if the value of the observed object reaches the predefined value in the upward direction.				

**2.4 Drive Configuration****2.4.1 Motion Control Profile****20D0h: Control Loop Configuration Parameters**

Control Loop Configuration				
Data Type	Data Range	Units	Accessibility	Stored to NVM
N/A	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Control loop configuration. Drive setup and configuration software will determine the values in this parameter. For systems that do not load parameter values from non-volatile memory but rather download parameters to the drive upon each system initialization, this parameter should be read from the drive upon completion of setup and configuration and saved with all other relevant drive parameters.				

**2032h: Feedback Sensor Parameters**

Encoder Wiring Polarity				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – [2 <sup>16</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the encoder wiring polarity.				

Maximum Phase Detection Current				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	0 – [2 <sup>31</sup> – 1]	DC2	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the maximum phase detection current that is allowed during a phase detect. See “Appendix” on page 283 for units conversion.				

<b>2032.03h</b> Maximum Phase Detection Time Limit				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – [2 <sup>(32) – 1</sup> ]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b> Contains a value corresponding to the maximum phase detection time limit.				

<b>2032.04h</b> Maximum Phase Detection Brake Time				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 – [2 <sup>(32) – 1</sup> ]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b> Contains a value corresponding to the maximum phase detection brake time.				

<b>2032.05h</b> Maximum Phase Detection Motion				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – [2 <sup>(16) – 1</sup> ]	DG1	Read / Write	Yes
<b>Description:</b> Contains a value corresponding to the maximum phase detection motion that is allowed during a phase detect. See “Appendix” on page 283 for unit conversion details.				

<b>2032.06h</b> Resolver Resolution				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – [2 <sup>(16) – 1</sup> ]	N/A	Read / Write	Yes
<b>Description:</b> Contains a value corresponding to the resolver resolution.				

<b>2032.07h</b> Serial Encoder Type												
Data Type	Data Range	Units	Accessibility	Stored to NVM								
Unsigned16	0 – [2 <sup>(16) – 1</sup> ]	N/A	Read / Write	Yes								
<b>Description:</b> Contains a value corresponding to the serial encoder type:												
<table border="1"> <thead> <tr> <th>Value</th> <th>Serial Encoder Type</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not Assigned</td> </tr> <tr> <td>1</td> <td>Hiperface</td> </tr> <tr> <td>2</td> <td>Endat</td> </tr> </tbody> </table>					Value	Serial Encoder Type	0	Not Assigned	1	Hiperface	2	Endat
Value	Serial Encoder Type											
0	Not Assigned											
1	Hiperface											
2	Endat											

<b>Position Interpolation</b>																										
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>																						
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes																						
<b>Description:</b> Contains a value corresponding to the position interpolation for Sin/Cos encoder interpolation. The number of position counts per Sin/Cos cycle is equal to 4 multiplied by the interpolation value. This only applies to position. The measured velocity is unaffected by the interpolation.																										
<table border="1"> <thead> <tr> <th>Value</th><th>Interpolation</th></tr> </thead> <tbody> <tr><td>0</td><td>1x</td></tr> <tr><td>1</td><td>2x</td></tr> <tr><td>2</td><td>4x</td></tr> <tr><td>3</td><td>8x</td></tr> <tr><td>4</td><td>16x</td></tr> <tr><td>5</td><td>32x</td></tr> <tr><td>6</td><td>64x</td></tr> <tr><td>7</td><td>128x</td></tr> <tr><td>8</td><td>256x</td></tr> <tr><td>9</td><td>512x</td></tr> </tbody> </table>					Value	Interpolation	0	1x	1	2x	2	4x	3	8x	4	16x	5	32x	6	64x	7	128x	8	256x	9	512x
Value	Interpolation																									
0	1x																									
1	2x																									
2	4x																									
3	8x																									
4	16x																									
5	32x																									
6	64x																									
7	128x																									
8	256x																									
9	512x																									

<b>Encoder Steps Per Encoder Sine Period</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b> Contains a value corresponding to the encoder steps per encoder sine period.				

<b>Secondary Encoder Position Interpolation</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b> Contains a value corresponding to the secondary encoder position interpolation.				

<b>Low Speed Smoothing Constant</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[-2 <sup>(31)</sup> ] – [2 <sup>(31)</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b> Contains a value corresponding to the low speed smoothing constant.				

<b>Encoder Emulation Divide By</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	1-20h	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the emulated encoder divide by amount. The drive will output an emulated encoder frequency equal to the drive's interpreted encoder frequency divided by the divide amount. Allowable values are 1,2,4,8,16 and 32.				

<b>Sin/Cos Error Window</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0000h – 4000h	N/A (SF1)	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the Sin/Cos error window for drives that support a 1V peak-to-peak encoder. The valid range in physical units is 0 to 1. The window determines whether or not a feedback sensor error should be activated according to the health of a Sin/Cos encoder (see object 2027h). If x is the error window entered in this object, then an error is activated when the health of the encoder is not within the range $1 \pm x$ . See " <a href="#">Appendix</a> " on page 283 for information on scaling.				

<b>Emulation Output Mode</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0-1	N/A	Read / Write	Yes
<b>Description:</b>				
This applies only to drives that support sin/cos encoder or absolute encoder feedback. Specifies whether the output encoder signal is buffered (0) or emulated (1).				

<b>Position of Emulated Index</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(32)}] - [2^{(31)}-1]$	counts	Read / Write	Yes
<b>Description:</b>				
This applies only to drives that support sin/cos encoder or absolute encoder feedback. Specifies the position of the emulated index in drive counts.				

<b>Emulated Counts per Emulated Index</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	counts	Read / Write	Yes
<b>Description:</b>				
This applies only to drive that support sin/cos encoder or absolute encoder feedback. Specifies the number of emulated counts per emulated index.				

**2046h: Auxiliary Input Parameters**

Auxiliary Input - Input Counts: Config 0				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	1 - [2 <sup>(16)</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the number of input counts in the input/output ratio used for Encoder following and Step and Direction modes in Configuration 0.				

Auxiliary Input - Output Counts: Config 0				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	-[2 <sup>(16)</sup> - 1] - [2 <sup>(16)</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the output in the input/output ratio used for Encoder following and Step and Direction modes in Configuration 0. Encoder following mode can be used only when the position loop is closed. However, Step and Direction can be used to control position, velocity or current. Therefore, the scaling value used is mode dependent.				

Auxiliary Input - Input Counts: Config 1				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	1 - [2 <sup>(16)</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the number of input counts in the input/output ratio used for Encoder following and Step and Direction modes in Configuration 1.				

Auxiliary Input - Output Counts: Config 1				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	-[2 <sup>(16)</sup> - 1] - [2 <sup>(16)</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the output in the input/output ratio used for Encoder following and Step and Direction modes in Configuration 1. Encoder following mode can be used only when the position loop is closed. However, Step and Direction can be used to control position, velocity or current. Therefore, the scaling value used is mode dependent.				

**2034h: Current Loop & Commutation Control Parameters**

Torque Current Loop Proportional Gain				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	0 - [2 <sup>(15)</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains the value of proportional gain for the current loop. This value is calculated from the gain value as follows: $Gain \times 2^9 = Value \text{ to the drive}$				

<b>Torque Current Loop Integral Gain</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 – [2 <sup>(15)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains the value of integral gain for the current loop. This value is calculated from the gain value as follows: $Gain \times 2^9 = Value \text{ to the drive}$				

<b>Torque Current Target Offset</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	[-2 <sup>(15)</sup> ] – [2 <sup>(15)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the torque current target offset				

<b>Peak Current Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 – [2 <sup>(15)</sup> -1]	DC1	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the peak current limit set in the drive. See “Appendix” on page 283 for unit conversion.				

<b>Peak Current Hold Time</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> -1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the peak current time set in the drive.				

<b>Continuous Current Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 – [2 <sup>(15)</sup> -1]	DC1	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the continuous current limit set in the drive. See “Appendix” on page 283 for unit conversion.				

<b>Peak to Continuous Current Transition Time</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> -1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the peak to continuous current transition time set in the drive.				

<b>Flux Current Reference Loop Proportional Gain</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the flux current reference loop proportional gain. The flux current loop is only used for AC induction motors. This value can be calculated from the gain value as follows: (Flux Current Reference Loop Proportional Gain) x 10000h, where ( 0 ≤ Gain ≤ 32767 )				

<b>Flux Current Reference Loop Integral Gain</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the flux current reference loop integral gain. The flux current loop is only used for AC induction motors. This value can be calculated from the gain value as follows: (Flux Current Reference Loop Integral Gain) x 400000h, where ( 0 ≤ Gain ≤ 512 )				

<b>Rated Peak Line Current</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the rated peak line current allowed when using an AC induction motor.				

<b>No Load Peak Magnetization Current</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the no-load peak magnetization current allowed when using an AC induction motor.				

<b>Rated Frequency</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the rated frequency.				

<b>2034.0Dh</b> <b>Rated Rotor No Load Base Speed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	RPM	Read / Write	Yes
<b>Description:</b> Contains a value corresponding to the rated rotor no-load base speed. This parameter is only used with an AC induction motor.				

<b>2034.0Eh</b> <b>FW Threshold Speed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	N/A	Read / Write	Yes
<b>Description:</b> Contains a value corresponding to the field weakening threshold speed. This parameter is used for AC induction motors only.				

<b>2034.0Fh</b> <b>Motor Type</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	-	N/A	Read / Write	Yes
<b>Description:</b> Contains a value corresponding to the type of motor connected to the drive.				

<b>2034.10h</b> <b>Auxiliary Commutation Mode</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	-	N/A	Read / Write	Yes
<b>Description:</b> Contains a value corresponding to the auxiliary commutation mode. Auxiliary commutation only occurs if the drive is connected to a <b>brushed</b> motor. Brushed motors commutate the motor internally and therefore do not require the drive to commutate the motor. The drive supplies current over two phases. This remains fixed for a brushed drive.				

<b>2034.11h</b> <b>Encoder Direction</b>																			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>															
Unsigned16	0 – 3	N/A	Read / Write	Yes															
<b>Description:</b> Contains a value corresponding to the direction of the encoder feedback.																			
<table border="1"> <thead> <tr> <th><b>Data Value</b></th> <th><b>Rotation Direction</b></th> <th><b>Primary Feedback Polarity</b></th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Inverted</td> <td>Inverted</td> </tr> <tr> <td>1</td> <td>Inverted</td> <td>Standard</td> </tr> <tr> <td>2</td> <td>Standard</td> <td>Inverted</td> </tr> <tr> <td>3</td> <td>Standard</td> <td>Standard</td> </tr> </tbody> </table>					<b>Data Value</b>	<b>Rotation Direction</b>	<b>Primary Feedback Polarity</b>	0	Inverted	Inverted	1	Inverted	Standard	2	Standard	Inverted	3	Standard	Standard
<b>Data Value</b>	<b>Rotation Direction</b>	<b>Primary Feedback Polarity</b>																	
0	Inverted	Inverted																	
1	Inverted	Standard																	
2	Standard	Inverted																	
3	Standard	Standard																	

<b>Synchronization Mode</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	-	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the current commutation method.				

<b>Encoder Counts Per Electrical Cycle</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	counts	Read / Write	Yes
<b>Description:</b>				
Contains the number of encoder counts per electrical cycle.				

<b>NTHS Angle 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>16</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the NTHS angle 1.				

<b>NTHS Angle 2</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>16</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the NTHS angle 2.				

<b>NTIS Angle 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>16</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the NTIS angle 1.				

<b>NTIS Angle 2</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>16</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the NTIS angle 2.				

<b>NTA-EZ Position</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the NTA-EZ position.				

<b>Max SPA Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the max SPA error.				

<b>Max SPA Adjustment</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the max SPA adjustment.				

<b>EC Adjust Count</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the EC adjust count.				

<b>ECC Adjust Amount</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	[-2 <sup>(15)</sup> ] – [2 <sup>(15)</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the ECC adjust amount.				

<b>Valid HS Mask</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the valid HS mask.				

<b>Hall Parameter 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to Hall Parameter 1.				

<b>Hall Parameter 2</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to Hall Parameter 2.				

<b>Hall Parameter 3</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to Hall Parameter 3.				

<b>Hall Parameter 4</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to Hall Parameter 4.				

<b>Hall Parameter 5</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to Hall Parameter 5.				

<b>Hall Parameter 6</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to Hall Parameter 6.				

<b>Hall Parameter 7</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to Hall Parameter 7.				

<b>Hall Parameter 8</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to Hall Parameter 8.				

<b>Phase Detect Control</b>														
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>										
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes										
<b>Description:</b>														
Contains a value corresponding to the Phase Detect Control options:														
<table border="1"> <thead> <tr> <th><b>Data Value</b></th> <th><b>Description</b></th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Normal Phase Detect Operation</td> </tr> <tr> <td>1</td> <td>Ignore User Positive Limit Event</td> </tr> <tr> <td>2</td> <td>Ignore User Negative Limit Event</td> </tr> <tr> <td>3</td> <td>Ignore both User Positive and Negative Limit Events</td> </tr> </tbody> </table>					<b>Data Value</b>	<b>Description</b>	0	Normal Phase Detect Operation	1	Ignore User Positive Limit Event	2	Ignore User Negative Limit Event	3	Ignore both User Positive and Negative Limit Events
<b>Data Value</b>	<b>Description</b>													
0	Normal Phase Detect Operation													
1	Ignore User Positive Limit Event													
2	Ignore User Negative Limit Event													
3	Ignore both User Positive and Negative Limit Events													

<b>Phase Offset</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	[-2 <sup>(15)</sup> ] – [2 <sup>(15)</sup> – 1]	DG1	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the Phase Advance feature.				

<b>Current Limiting Algorithm</b>												
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>								
Integer16	0-2	N/A	Read / Write	Yes								
<b>Description:</b>												
This enum selects from one of three current limiting algorithms. See “ <a href="#">Appendix B - Current Limiting Algorithm</a> ” on page <a href="#">286</a> for more details.												
<table border="1"> <thead> <tr> <th><b>Data Value</b></th> <th><b>Description</b></th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Time Based (Default)</td> </tr> <tr> <td>1</td> <td>Charge Based with RMS Scaling</td> </tr> <tr> <td>2</td> <td>Charge Based</td> </tr> </tbody> </table>					<b>Data Value</b>	<b>Description</b>	0	Time Based (Default)	1	Charge Based with RMS Scaling	2	Charge Based
<b>Data Value</b>	<b>Description</b>											
0	Time Based (Default)											
1	Charge Based with RMS Scaling											
2	Charge Based											

<b>Torque At Command Window</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> – 1]	DC2	Read / Write	Yes
<b>Description:</b>				
Contains a value for an At Command window around the current error. While in current mode, when the current error is within this window, the At Command event will be active.				

### **2036h: Velocity Loop Control Parameters**

<b>Velocity Feedback Direction</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	-	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the feedback polarity of an auxiliary encoder used for velocity feedback.				

<b>Velocity Feedback Filter Coefficient</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>30</sup> ]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the velocity feedback filter coefficient. To convert between the value entered into DriveWare and the value sent to the drive, use the following functions:				
DriveWare to drive: $2^{30}(-e^a + 1) = P$ where a = [value entered into DriveWare] x (-6.283185307x10 <sup>-4</sup> ) and P = [value sent to drive]				
Drive to DriveWare: $\frac{\ln\left(1 - \frac{P}{2^{30}}\right)}{-6.283185307 \times 10^{-4}} = [\text{value seen in DriveWare (Hz)}]$ where P = [value in drive]				

<b>Velocity Loop Proportional Gain: Gain Set 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> –1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the proportional loop gain of the velocity loop for Gain Set 0. This value can be calculated from the gain value as follows: (Velocity Loop Proportional Gain) x 0666h, where (0 ≤ Velocity Proportional Gain ≤ 1,310,700d)				

<b>Velocity Loop Integral Gain: Gain Set 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the integral loop gain of the velocity loop for Gain Set 0. This value can be calculated from the gain value as follows: (Velocity Loop Integral Gain) x 06666666h, where (1 ≤ Velocity Loop Integral Gain ≤ 20d)				

<b>Velocity Loop Derivative Gain: Gain Set 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the derivative loop gain of the velocity loop for Gain Set 0. This value can be calculated from the gain value as follows: (Velocity Loop Derivative Gain) x 0666h, where (1 ≤ Velocity Loop Derivative Gain ≤ 80d)				

<b>Velocity Loop Acceleration Feed Forward Gain: Gain Set 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the velocity loop acceleration feed forward gain for Gain Set 0. (Velocity Loop Acceleration Feed Forward Gain) x 0666h, where (1 ≤ Velocity Loop Acceleration Feed Forward Gain ≤ 80d)				

<b>Velocity Loop Integrator Decay Rate</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	%	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the velocity loop integrator decay rate. The value is in percentage of the Integrator Gain.				

<b>Velocity Loop Proportional Gain: Gain Set 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the proportional loop gain of the velocity loop for Gain Set 1. This value can be calculated from the gain value as follows: (Velocity Loop Proportional Gain) x 0666h, where (0 ≤ Velocity Proportional Gain ≤ 1,310,700d)				

<b>Velocity Loop Integral Gain: Gain Set 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the integral loop gain of the velocity loop for Gain Set 1. This value can be calculated from the gain value as follows: (Velocity Loop Integral Gain) x 06666666h, where (1 ≤ Velocity Loop Integral Gain ≤ 20d)				

<b>Velocity Loop Derivative Gain: Gain Set 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the derivative loop gain of the velocity loop for Gain Set 1. This value can be calculated from the gain value as follows: (Velocity Loop Derivative Gain) x 0666h, where (1 ≤ Velocity Loop Derivative Gain ≤ 80d)				

<b>Velocity Loop Acceleration Feed Forward Gain: Gain Set 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the velocity loop acceleration feed forward gain for Gain Set 1. (Velocity Loop Acceleration Feed Forward Gain) x 0666h, where (1 ≤ Velocity Loop Acceleration Feed Forward Gain ≤ 80d)				

## 2037h: Velocity Limits

<b>Motor Over Speed Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	DS1	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the motor over speed limit set in the drive. When the velocity of the motor meets or exceeds this value, the drive will indicate a motor over speed condition is present. See “Appendix” on page 283 for unit conversion.				

<b>Zero Speed Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	DS1	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the motor zero speed limit set in the drive. When the velocity of the motor reaches this value or LOWER, the drive will indicate that it has reached a zero speed condition. See “Appendix” on page 283 for unit conversion.				

<b>At Velocity Window</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	0 – [2 <sup>31</sup> -1]	DS4	Read / Write	Yes
<b>Description:</b>				
Contains a value for an At Velocity tolerance window around the target velocity. The At Velocity Window functions like a tolerance value for the velocity error. When the velocity error is within this window either above or below the target velocity, the drive will indicate that it is At Command. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Velocity Loop Following Error Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	0 – [2 <sup>31</sup> -1]	DS1	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the velocity at speed limit set in the drive. If the measured velocity meets or exceeds this value, the drive will perceive this as a velocity following error. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Positive Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	DS1	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the positive velocity limit set in the drive. When the speed set by this value is met or exceeded, the drive will indicate that the positive limit was reached. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Negative Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	DS1	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the negative velocity limit set in the drive. When the speed set by this value is met or exceeded, the drive will indicate that the negative limit was reached. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Velocity Loop Integrator Decay Active Window</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the velocity loop integrator decay active window.				

**2038h: Position Loop Control Parameters**

Position Loop Proportional Gain: Gain Set 0				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the position loop proportional gain for Gain Set 0. This value can be calculated from the gain value using the following formula: (Position Loop Proportional Gain) x 68DB8h, where (0 ≤ Gain ≤ 5000)				

Position Loop Integral Gain: Gain Set 0				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the position loop integral gain for Gain Set 0. This value can be calculated from the gain value using the following formula: (Position Loop Integral Gain) x 68DB8BB1Eh, where (0 ≤ Gain ≤ 0.076293363)				

Position Loop Derivative Gain: Gain Set 0				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the position loop derivative gain for Gain Set 0. This value can be calculated from the gain value using the following formula: (Position Loop Derivative Gain) x 68DBh, where (0 ≤ Gain ≤ 79999.999)				

Position Loop Velocity Feed Forward Gain: Gain Set 0				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the position loop velocity feed forward gain for Gain Set 0. This value can be calculated from the gain value using the following formula: (Position Loop Velocity Feed Forward Gain) x 68DBh, where (0 ≤ Gain ≤ 39999.999)				

Position Loop Acceleration Feed Forward Gain: Gain Set 0				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the position loop acceleration feed forward gain for Gain Set 0. This value can be calculated from the gain value using the following formula: (Position Loop acceleration Feed Forward Gain) x 68DBh, where (0 ≤ Gain ≤ 39999.999)				

<b>Position Feedback Direction</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	-	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the feedback polarity of an auxiliary encoder used for position feedback.				

<b>Position Loop Integrator Decay Rate</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	%	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the position loop integrator decay rate. The value is in percentage of the position loop Integrator Gain.				

<b>Position Loop Proportional Gain: Gain Set 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the position loop proportional gain for Gain Set 1. This value can be calculated from the gain value using the following formula: (Position Loop Proportional Gain) x 68DB8h, where (0 ≤ Gain ≤ 5000)				

<b>Position Loop Integral Gain: Gain Set 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the position loop integral gain for Gain Set 1. This value can be calculated from the gain value using the following formula: (Position Loop Integral Gain) x 68DB8BB1Eh, where (0 ≤ Gain ≤ 0.076293363)				

<b>Position Loop Derivative Gain: Gain Set 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>31</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the position loop derivative gain for Gain Set 1. This value can be calculated from the gain value using the following formula: (Position Loop Derivative Gain) x 68DBh, where (0 ≤ Gain ≤ 79999.999)				

<b>2038.04h Position Loop Velocity Feed Forward Gain: Gain Set 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>(31)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the position loop velocity feed forward gain for Gain Set 1. This value can be calculated from the gain value using the following formula: (Position Loop Velocity Feed Forward Gain) x 68DBh, where (0 ≤ Gain ≤ 39999.999)				

<b>2038.05h Position Loop Acceleration Feed Forward Gain: Gain Set 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>(31)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the position loop acceleration feed forward gain for Gain Set 1. This value can be calculated from the gain value using the following formula: (Position Loop acceleration Feed Forward Gain) x 68DBh, where (0 ≤ Gain ≤ 39999.999)				

## 2039h: Position Limits

<b>2039.01h Measured Position Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[-2 <sup>(31)</sup> ] - [2 <sup>(31)</sup> -1]	counts	Read / Write	Yes
<b>Description:</b>				
Replacement value for the measured position when the Set Position event is triggered. This allows you to redefine the current measured position (e.g. reset to zero).				

<b>2039.02h Home Position Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[-2 <sup>(31)</sup> ] - [2 <sup>(31)</sup> -1]	counts	Read / Write	Yes
<b>Description:</b>				
Position value of the home position. When the measured position reaches this position, within the In-Home Position Window, the At-Home event becomes active.				

<b>2039.03h Max Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[-2 <sup>(31)</sup> ] - [2 <sup>(31)</sup> -1]	counts	Read / Write	Yes
<b>Description:</b>				
Maximum allowed measured position. The Max Measured Position event will become active if the measured position exceeds this value.				

<b>Min Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	counts	Read / Write	Yes
<b>Description:</b>				
Minimum allowed measured position. The Min Measured Position event will become active if the measured position exceeds this value.				

<b>At Home Position Window</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	counts	Read / Write	Yes
<b>Description:</b>				
Defines a window around the Home Position Value, such that when the measured position is within this window, the At-Home event will be active.				

<b>In Position Window</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$0 - [2^{(32)} - 1]$	counts	Read / Write	Yes
<b>Description:</b>				
Defines a window around the target position, such that when the position error is within this window, the At Command event will be active.				

<b>Position Following Error Window</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$0 - [2^{(32)} - 1]$	counts	Read / Write	Yes
<b>Description:</b>				
The maximum allowed position error (difference between target position and measured position), prior to setting the "Position Following Error" event (active in position mode only). For CANopen drives, this parameter is equivalent to the "Position Following Error Limit" of DSP402 (object 6065h).				

<b>Max Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	counts	Read / Write	Yes
<b>Description:</b>				
Maximum allowed target position. The Max Target Position event will become active if the target position exceeds this value.				

<b>Min Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[-2 <sup>(31)</sup> ] - [2 <sup>(31)</sup> - 1]	counts	Read / Write	Yes
<b>Description:</b>				
Minimum allowed target position. The Min Target Position event will become active if the target position exceeds this value.				

<b>Position Limits Control</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	-	N/A	Read / Write	Yes
<b>Description:</b>				
Defines if the position limits are enabled or not. 3 = Enable Limits, 0 = Disable Limits.				

<b>Position Loop Integrator Decay Active Window</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>(31)</sup> -1]	counts	Read / Write	Yes
<b>Description:</b>				
Contains a value that corresponds to the position loop integrator decay active window.				

### **6065h: Position Following Error Window**

<b>Position Following Error Window</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 - [2 <sup>(32)</sup> -1]	counts	Read / Write	Yes
<b>Description:</b>				
The maximum allowed position error (difference between target and measured position), prior to setting the “Position Following Error” event (active in position mode only).				

### **6066h: Position Following Error Time Out**

<b>Position Following Error Time Out</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	2 - [2 <sup>(15)</sup> -1]	ms	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Position Following Error before its Event Action (2065h) is executed. The functionality of this object is identical to that of the manufacturer-specific object 2064.16h.				

**60F4h: Position Following Error Actual Value**

Position Following Error Actual Value				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$[-2^{32}] - [2^{(32)} - 1]$	counts	Read Only	Yes
<b>Description:</b>				
Provides the actual value of the position following error, defined as the difference between target and measured position.				

**6098h: Homing Method**

Homing Method				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer8	1 – 35	N/A	Read / Write	Yes
<b>Description:</b>				
There are almost 35 homing methods supported by AMC CANopen servo drives. See “ <a href="#">Homing</a> ” on page 40 for details on each homing method.				

**6099h: Homing Speeds**

Speed During Search For Switch				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	$0 - (2^{32}-1)$	DS4	Read / Write	Yes
<b>Description:</b>				
Sets the speed during the first stage of Homing algorithms. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

Speed During Search For Zero				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	$0 - (2^{32}-1)$	DS4	Read / Write	Yes
<b>Description:</b>				
Sets the speed during the search for zero. This is usually after the search for switch has completed and is set much slower for accuracy. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

**609Ah: Homing Acceleration**

Homing Acceleration				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	$0 - (2^{32}-1)$	DA1	Read / Write	Yes
<b>Description:</b>				
Sets the accelerations and decelerations used by the drive’s homing routine. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion details.				

## 607Ch: Home Offset

Home Offset				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$-2^{31} - (2^{31}-1)$	counts	Read / Write	Yes
<b>Description:</b>				
When the homing routine is complete, the zero position found by the drive is given an offset equal to the value stored in this object. All moves are interpreted relative to this new zero position. When homing completes, the equation for the drive's current position is "Current position = 0 – Home Offset value".				

## 203Ah: Homing Configuration Parameters

Homing Speed During Search For Switch				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 - $[2^{32} - 1]$	DS4	Read / Write	Yes
<b>Description:</b>				
The magnitude of the velocity to be used during the search for the switch (before searching for the home/zero position). See " <a href="#">Appendix</a> " on <a href="#">page 283</a> for unit conversion.				

Homing Speed During Search For Zero				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 - $[2^{32} - 1]$	DS4	Read / Write	Yes
<b>Description:</b>				
The magnitude of the velocity to be used during the search for the home/zero position. See " <a href="#">Appendix</a> " on <a href="#">page 283</a> for unit conversion.				

Homing Method				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - $[2^{16} - 1]$	N/A	Read / Write	Yes
<b>Description:</b>				
The type of homing routine used. See " <a href="#">Homing</a> " on <a href="#">page 40</a> section for routine descriptions.				

Homing Acceleration				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	0 - $[2^{32} - 1]$	DA1	Read / Write	Yes
<b>Description:</b>				
The acceleration and deceleration used during the search for the switch and during the search for zero. See " <a href="#">Appendix</a> " on <a href="#">page 283</a> for unit conversion details.				

**2048h: PVT Parameters**

Buffer Threshold Warning Level				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
A buffer threshold warning will occur when this number of PVT points is left in the buffer.				

PVT Input Method				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines if incremental or absolute position is to be used with PVT commands. Incremental position sets the PVT target position point equal to the previous PVT position point plus the specified value. Absolute position sets the PVT target position point equal to the specified value.				
Value	Input Method			
0	Absolute position with sequence counter			
1	Incremental position with sequence counter			

**6086h: Motion Profile Type**

Motion Profile Type				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	0 - 2	N/A	Read / Write	No
<b>Description:</b>				
Specifies the type of profile to be used for profiled position mode (see object 6060 for setting modes). The default profile type is linear (trapezoidal), but accel/decel may be selected. This value is not stored to NVM. Specific values for either profile can be configured using object 203C.				
Value	Input Method			
0 (default)	Linear Ramp (trapezoidal profile)			
2	Accel/Decel (jerk-free ramp)			

**6088h: Torque Profile Type**

Torque Profile Type				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	0	N/A	Read Only	No
<b>Description:</b>				
Specifies the type of profile to be used for profiled torque mode (see object 6060 for setting modes). The value is fixed equal to 0 which specifies a linear (trapezoidal) profile.				

**203Ch: Command Limiter Parameters** The Command Limiter limits the slope of the target command in any mode. It is broken into four components, where each component is assigned to one sub-index. To remove any effects of the command limiter, maximize all limiter parameters. Some limiter parameters have units that change with the operating mode of the drive. For these parameters, refer to [Table 2.1](#) to make the correct unit selection.

**TABLE 2.1** Command Limiter Units

Drive Operation Mode	Units
Current (Torque)	DJ1
Velocity	DA2
Position (Around Velocity Or Current)	DS2

<b>203C.01h</b> <b>Linear Ramp Positive Target Positive Change: Config 0</b>				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned48	0 - [2 <sup>(48)</sup> -1]	See Table 2.1	Read / Write	Yes
<b>Description:</b>				
Defines the maximum positive change in positive command used with the command limiter in Configuration 0. Units are mode dependant. See "Appendix" on page 283 for unit conversions.				

<b>203C.02h</b> <b>Linear Ramp Positive Target Negative Change: Config 0</b>				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned48	0 - [2 <sup>(48)</sup> -1]	See Table 2.1	Read / Write	Yes
<b>Description:</b>				
Defines the maximum negative change in positive command used with the command limiter in Configuration 0. Units are mode dependant. See "Appendix" on page 283 for unit conversions.				

<b>203C.03h</b> <b>Linear Ramp Negative Target Negative Change: Config 0</b>				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned48	0 - [2 <sup>(48)</sup> -1]	See Table 2.1	Read / Write	Yes
<b>Description:</b>				
Defines the maximum negative change in negative command used with the command limiter in Configuration 0. Units are mode dependant. See "Appendix" on page 283 for unit conversions.				

<b>203C.04h</b> <b>Linear Ramp Negative Target Positive Change: Config 0</b>				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned48	0 - [2 <sup>(48)</sup> -1]	See Table 2.1	Read / Write	Yes
<b>Description:</b>				
Defines the maximum positive change in negative command used with the command limiter in Configuration 0. Units are mode dependant. See "Appendix" on page 283 for unit conversions.				

<b>203C.05h</b> <b>Linear Ramp Positive Target Positive Change: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned48	0 - [2 <sup>48</sup> -1]	See Table 2.1	Read / Write	Yes
<b>Description:</b>				
Defines the maximum positive change in positive command used with the command limiter in Configuration 1. Units are mode dependant. See "Appendix" on page 283 for unit conversions.				

<b>203C.06h</b> <b>Linear Ramp Positive Target Negative Change: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned48	0 - [2 <sup>48</sup> -1]	See Table 2.1	Read / Write	Yes
<b>Description:</b>				
Defines the maximum negative change in positive command used with the command limiter in Configuration 1. Units are mode dependant. See "Appendix" on page 283 for unit conversions.				

<b>203C.07h</b> <b>Linear Ramp Negative Target Negative Change: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned48	0 - [2 <sup>48</sup> -1]	See Table 2.1	Read / Write	Yes
<b>Description:</b>				
Defines the maximum negative change in negative command used with the command limiter in Configuration 1. Units are mode dependant. See "Appendix" on page 283 for unit conversions.				

<b>203C.08h</b> <b>Linear Ramp Negative Target Positive Change: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned48	0 - [2 <sup>48</sup> -1]	See Table 2.1	Read / Write	Yes
<b>Description:</b>				
Defines the maximum positive change in negative command used with the command limiter in Configuration 1. Units are mode dependant. See "Appendix" on page 283 for unit conversions.				

<b>203C.09h</b> <b>Controlled Accel/Decel Maximum Speed: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer64	0 - [2 <sup>64</sup> -1]	DS3	Read / Write	Yes
<b>Description:</b>				
Sets the maximum speed for a profile in Configuration 0. See "Appendix" on page 283 for unit conversions.				

<b>203C.0Ah</b> Controlled Accel/Decel Maximum Acceleration: Config 0				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	0 - [2 <sup>(32)</sup> -1]	DA3	Read / Write	Yes
<b>Description:</b>				
Defines the maximum acceleration used with the command limiter in Configuration 0. See " <a href="#">Appendix</a> " on page 283 for unit conversions.				

<b>203C.0Bh</b> Controlled Accel/Decel Maximum Deceleration: Config 0				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	0 - [2 <sup>(32)</sup> -1]	DA3	Read / Write	Yes
<b>Description:</b>				
Defines the maximum deceleration used with the command limiter in Configuration 0. See " <a href="#">Appendix</a> " on page 283 for unit conversions.				

<b>203C.0Ch</b> Controlled Accel/Decel Maximum Speed: Config 1				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer64	0 - [2 <sup>(64)</sup> -1]	DS3	Read / Write	Yes
<b>Description:</b>				
Sets the maximum speed for a profile in Configuration 1. See " <a href="#">Appendix</a> " on page 283 for unit conversions.				

<b>203C.0Dh</b> Controlled Accel/Decel Maximum Acceleration: Config 1				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	0 - [2 <sup>(32)</sup> -1]	DA3	Read / Write	Yes
<b>Description:</b>				
Defines the maximum acceleration used with the command limiter in Configuration 1. See " <a href="#">Appendix</a> " on page 283 for unit conversions.				

<b>203C.0Eh</b> Controlled Accel/Decel Maximum Deceleration: Config 1				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	0 - [2 <sup>(32)</sup> -1]	DA3	Read / Write	Yes
<b>Description:</b>				
Defines the maximum deceleration used with the command limiter in Configuration 1. See " <a href="#">Appendix</a> " on page 283 for unit conversions.				

**60C2h: Interpolation Time Period** This object is used only for synchronous cyclic modes of operation (see "[6060h: Modes Of Operation](#)" on page 241). The interpolation time period defines the rate in which target commands are sent by the host to the drive. When a periodic target command is sent to the drive at a rate slower than the loop update rate, there is potential for the loop gains to spike with each new target command. Defining the interpolation time period allows the target to follow a linear ramp between target commands. The interpolation time period is made up of two values as follows:

Interpolation Time Period = [interpolation time period value] x  $10^{(\text{interpolation time index})}$  seconds

The drive will support an interpolation time period between 0 and 1 second. If the value is not a multiple of the loop update rate, it will be truncated to the next lowest multiple.

Interpolation Time Period Value				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned 8	0 - 255	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the mantissa of the interpolation time period.				

Interpolation Time Index				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned 8	-6 to 0	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the exponent of the interpolation time period.				

## 2.4.2 Hardware Profile

### 200Bh: Stored User Parameters

User Defined Drive Name				
Data Type	Data Range	Units	Accessibility	Stored to NVM
String256	ASCII Values	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a user specified drive name for the drive. The characters in the string are stored as ASCII values. For the drive name "AMC", the digits stored are: 41h, 4Dh, 43h				

### 2008h: Drive Initialization Parameters

Start-Up Sequence Control																		
Data Type	Data Range	Units	Accessibility	Stored to NVM														
Unsigned16	0 – $[2^{(16)} - 1]$	N/A	Read / Write	Yes														
<b>Description:</b>																		
Defines how the drive will behave when power is first applied.																		
<table border="1"> <thead> <tr> <th>Bit</th> <th>Drive Initialization Parameters</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disable Bridge</td> </tr> <tr> <td>1</td> <td>Load Config 1</td> </tr> <tr> <td>2</td> <td>Phase Detect</td> </tr> <tr> <td>3</td> <td>Set Position</td> </tr> <tr> <td>4</td> <td>Enable Motion Engine After Startup Sequence</td> </tr> <tr> <td>5...15</td> <td>Reserved</td> </tr> </tbody> </table>					Bit	Drive Initialization Parameters	0	Disable Bridge	1	Load Config 1	2	Phase Detect	3	Set Position	4	Enable Motion Engine After Startup Sequence	5...15	Reserved
Bit	Drive Initialization Parameters																	
0	Disable Bridge																	
1	Load Config 1																	
2	Phase Detect																	
3	Set Position																	
4	Enable Motion Engine After Startup Sequence																	
5...15	Reserved																	

Start-Up Phase Detect Configuration										
Data Type	Data Range	Units	Accessibility	Stored to NVM						
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read / Write	Yes						
<b>Description:</b> Defines how the Phase Detect feature will behave when power is first applied.										
<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Phase Detect Immediately upon power-up</td></tr> <tr> <td>1</td><td>Phase Detect after the first bridge enable upon power-up</td></tr> </tbody> </table>					Value	Description	0	Phase Detect Immediately upon power-up	1	Phase Detect after the first bridge enable upon power-up
Value	Description									
0	Phase Detect Immediately upon power-up									
1	Phase Detect after the first bridge enable upon power-up									

## 20C8h: Motion Engine Configuration

Start-Up Motion Type				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – 1FFFh	N/A	Read / Write	Yes
<b>Description:</b> Defines the startup behavior when running a motion engine index upon power-up. The bit values are broken up as defined below.				
<p><b>Bits 0:2</b>      0: Indexer Mode      1-7: Reserved</p> <p><b>Bits 3:4</b>      0: Motion initiated via digital inputs      1: Motion initiated via Network commands</p> <p><b>Bits 5:8</b>      Defines the index number to load on power-up</p> <p><b>Bits 9:15</b>      0: Motion will not immediately start.      1: Motion will automatically start if the Motion Engine is configured to be enabled on power-up.      2-7: Reserved</p>				

## 2033h: User Voltage Protection Parameters

Over-Voltage Limit				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	[–2 <sup>(15)</sup> ] – [2 <sup>(15)</sup> – 1]	DV1	Read Only	Yes
<b>Description:</b> Contains the over voltage limit specified for the drive. It must be set lower than the drive over-voltage hardware shutdown point and greater than the Nominal DC Bus Voltage. See “Appendix” on page 283 for unit conversion.				

<b>Under-Voltage Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{15}] - [2^{15}-1]$	DV1	Read Only	Yes
<b>Description:</b>				
Contains the under voltage limit specified for the drive. It must be set above the drive under-voltage hardware shutdown point and less than the Nominal DC Bus Voltage. See " <a href="#">Appendix</a> " on page <a href="#">283</a> for unit conversion.				

<b>Shunt Regulator Enable Threshold</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$0 - [2^{15}-1]$	DV1	Read Only	Yes
<b>Description:</b>				
Contains a value corresponding to the shunt regulator enable threshold voltage. When the bus reaches this voltage, built in shut regulator will turn on to allow excess energy to be dissipated across an external shunt resistor. Not all drives have built in shunt regulators. See " <a href="#">Appendix</a> " on page <a href="#">283</a> for unit conversion.				

<b>Shunt Regulator Configuration</b>										
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>						
Unsigned16	See Table	N/A	Read / Write	Yes						
<b>Description:</b>										
Contains a value corresponding to the current state of the shunt regulator.										
<table border="1"> <thead> <tr> <th><b>Value (Hex)</b></th> <th><b>Description</b></th> </tr> </thead> <tbody> <tr> <td>00</td> <td>Enable Shunt Regulator</td> </tr> <tr> <td>02</td> <td>Disable Shunt Regulator</td> </tr> </tbody> </table>					<b>Value (Hex)</b>	<b>Description</b>	00	Enable Shunt Regulator	02	Disable Shunt Regulator
<b>Value (Hex)</b>	<b>Description</b>									
00	Enable Shunt Regulator									
02	Disable Shunt Regulator									

<b>External Shunt Resistance</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	$0 - [2^{16}-1]$	ohms ( $\Omega$ )	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the resistance of the external shunt resistor.				

<b>External Shunt Power</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	$0 - [2^{16}-1]$	watts (W)	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the amount of power the external shunt resistor is allowed to dissipate.				

<b>External Shunt Inductance</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	microhenrys (μH)	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the inductance of the external shunt resistor.				

### **2054h: Drive Temperature Parameters**

<b>External Analog Temperature Disable Level</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[-2 <sup>(31)</sup> ] - [2 <sup>(31)</sup> – 1]	DT1	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the temperature disable level for an analog over temperature event. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>External Analog Temperature Enable Level</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[-2 <sup>(31)</sup> ] - [2 <sup>(31)</sup> – 1]	DT1	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the temperature re-enable level after the analog over temperature event has been activated. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Thermistor Disable Resistance</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> – 1]	Ohms	Read / Write	Yes
<b>Description:</b>				
If supported by the hardware, this value represents the value of the thermistor resistance (ohms) in which the Motor Over Temperature Event is to trip. For a Positive Thermal Coefficient (PTC), the disable resistance will be greater than or equal to the enable value. For a Negative Thermal Coefficient (NTC), the disable resistance will be less than the enable value.				

<b>Thermistor Enable Resistance</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> – 1]	Ohms	Read / Write	Yes
<b>Description:</b>				
If supported by the hardware, this value represents the value of the thermistor resistance (ohms) in which the Motor Over Temperature Event is to release. For a Positive Thermal Coefficient (PTC), the disable resistance will be greater than or equal to the enable value. For a Negative Thermal Coefficient (NTC), the disable resistance will be less than the enable value.				

<b>Thermal Monitor Configuration</b>														
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>										
N/A	N/A	-	Read / Write	Yes										
<b>Description:</b> If supported by the hardware, configures the operation of the thermistor/thermal cutoff switch.														
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2"><b>Valid Values</b></th> </tr> </thead> <tbody> <tr> <td>0</td><td>Disabled</td></tr> <tr> <td>1</td><td>Thermistor Active</td></tr> <tr> <td>2</td><td>Thermal Cutoff Switch Active Closed</td></tr> <tr> <td>3</td><td>Thermal Cutoff Switch Active High</td></tr> </tbody> </table>					<b>Valid Values</b>		0	Disabled	1	Thermistor Active	2	Thermal Cutoff Switch Active Closed	3	Thermal Cutoff Switch Active High
<b>Valid Values</b>														
0	Disabled													
1	Thermistor Active													
2	Thermal Cutoff Switch Active Closed													
3	Thermal Cutoff Switch Active High													

**2043h: Capture Configuration Parameters** The following tables are used by the sub-indices of this object.

**TABLE 2.2** Capture Edge Configuration

<b>Value</b>	<b>Description</b>
0	None / Off
1	Rising Edge
2	Falling Edge
3	Both Rising and Falling Edges

**TABLE 2.3** Capture Trigger Type

<b>Value</b>	<b>Description</b>
0	Single Trigger: Captures one value at a time. Need to reset Capture before capturing another.
1	Continuous Trigger: Captures a new value each time Capture input is triggered without having to reset.

**TABLE 2.4** Capture Source High/Low Values

Signal Source	Low Value	High Value
Velocity Feedback	16	17
Velocity Measured	18	19
Velocity Target	20	21
Velocity Demand	22	23
Velocity Error	24	25
Position Measured	26	27
Position Target	28	29
Position Demand	30	31
Position Error	32	33
Auxiliary Position Input	34	35
Phase Angle	15	87
Stator Angle	86	87

Capture 'A' Edge Configuration				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	0 - 3	N/A	Read / Write	Yes
<b>Description:</b>				
Selects the edge(s) that will trigger Capture A to capture the pre-selected signal source. See <a href="#">Table 2.2</a> for a list of allowable values.				

Capture 'A' Trigger				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	0 - 1	N/A	Read / Write	Yes
<b>Description:</b>				
Selects whether a value should be captured only once, upon the first applicable edge that is encountered, or every time an edge is encountered. See <a href="#">Table 2.3</a> for a list of allowable values.				

Capture 'A' Source – Low Value				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	See <a href="#">Table 2.4</a>	N/A	Read / Write	Yes
<b>Description:</b>				
This sub-index is used together with the next to select the signal source to capture. See <a href="#">Table 2.4</a> for a list of allowable values.				

<b>Capture 'A' Source – High Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	See <a href="#">Table 2.4</a>	N/A	Read / Write	Yes
<b>Description:</b>				
This sub-index is used together with the previous to select the signal source to capture. See <a href="#">Table 2.4</a> for a list of allowable values.				

<b>Capture 'B' Edge Configuration</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 - 3	N/A	Read / Write	Yes
<b>Description:</b>				
Selects the edge(s) that will trigger Capture B to capture the pre-selected signal source. See <a href="#">Table 2.2</a> for a list of allowable values.				

<b>Capture 'B' Trigger</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 - 1	N/A	Read / Write	Yes
<b>Description:</b>				
Selects whether a value should be captured only once, upon the first applicable edge that is encountered, or every time an edge is encountered. See <a href="#">Table 2.3</a> for a list of allowable values.				

<b>Capture 'B' Source – Low Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	See <a href="#">Table 2.4</a>	N/A	Read / Write	Yes
<b>Description:</b>				
This sub-index is used together with the next to select the signal source to capture. See <a href="#">Table 2.4</a> for a list of allowable values.				

<b>Capture 'B' Source – High Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	See <a href="#">Table 2.4</a>	N/A	Read / Write	Yes
<b>Description:</b>				
This sub-index is used together with the previous to select the signal source to capture. See <a href="#">Table 2.4</a> for a list of allowable values.				

<b>Capture 'C' Edge Configuration</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 - 3	N/A	Read / Write	Yes
<b>Description:</b>				
Selects the edge(s) that will trigger Capture C to capture the pre-selected signal source. See <a href="#">Table 2.2</a> for a list of allowable values.				

<b>Capture 'C' Trigger</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 - 1	N/A	Read / Write	Yes
<b>Description:</b>				
Selects whether a value should be captured only once, upon the first applicable edge that is encountered, or every time an edge is encountered. See <a href="#">Table 2.3</a> for a list of allowable values.				

<b>Capture 'C' Source – Low Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	See <a href="#">Table 2.4</a>	N/A	Read / Write	Yes
<b>Description:</b>				
This sub-index is used together with the next to select the signal source to capture. See <a href="#">Table 2.4</a> for a list of allowable values.				

<b>Capture 'C' Source – High Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	See <a href="#">Table 2.4</a>	N/A	Read / Write	Yes
<b>Description:</b>				
This sub-index is used together with the previous to select the signal source to capture. See <a href="#">Table 2.4</a> for a list of allowable values.				

## 2058h: Digital Input Parameters

TABLE 2.5 Object 2058 Mapping

<b>Bit</b>	<b>Digital Input Mask*</b>
0	Digital Input 1
1	Digital Input 2
2	Digital Input 3
3	Digital Input 4
4	Digital Input 5
5	Digital Input 6
6	Digital Input 7
7	Digital Input 8
8...15	Reserved

\* Number of actual inputs depends on drive model

<b>Digital Input Mask: Active Level</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Determines which digital inputs are active high and which are active low. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: User Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to User Disable. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Positive Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the positive limit. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Negative Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to negative limit. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Motor Over Temperature</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to activate Motor Over Temperature. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Phase Detection</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to activate Phase Detection. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>2058.07h</b>	<b>Digital Input Mask: Auxiliary Disable</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to activate the Auxiliary Disable. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>2058.08h</b>	<b>Digital Input Mask: Set Position</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to activate the Set Position event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>2058.09h</b>	<b>Digital Input Mask: Start Homing</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to activate the Start Homing event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>2058.0Ah</b>	<b>Digital Input Mask: Home Switch</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Home Switch. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>2058.0Bh</b>	<b>Digital Input Mask: User Stop</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Stop event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>2058.0Ch</b>	<b>Digital Input Mask: Set / Reset Capture A</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Set / Reset Capture A event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Set / Reset Capture B</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Set / Reset Capture B event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Set / Reset Capture C</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Set / Reset Capture C event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Reset Event History</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Reset Event History event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Configuration Select 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Configuration Select 0 event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Reserved</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read / Write	Yes

<b>Digital Input Mask: Gain Select 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Gain Select 0 event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Zero Position Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Zero Position Error event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Reserved</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read / Write	Yes
<b>Reserved</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read / Write	Yes

<b>Digital Input Mask: Motion Engine Mode</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Motion Engine Mode event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Motion Engine Enable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Motion Enable Enable event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Motion Execute</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Motion Execute event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Motion Select 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Motion Select 0 event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Motion Select 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Motion Select 1 event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Motion Select 2</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Motion Select 2 event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Motion Select 3</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Motion Select 3 event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Motion Engine Abort</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Motion Engine Abort event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Motion Engine Reset</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Motion Engine Reset event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Jog Plus</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Jog Plus event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Jog Minus</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Jog Minus event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Jog 0 Select</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Jog 0 Select event. See <a href="#">Table 2.5</a> above for mapping structure.				

<b>Digital Input Mask: Jog 1 Select</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital inputs, if any, are assigned to the Jog 1 Select event. See <a href="#">Table 2.5</a> above for mapping structure.				

## 205Ah: Digital Output Parameters

TABLE 2.6 Object 205A Mapping

<b>Bit</b>	<b>Digital Output Mask</b>
0	Digital Output 1
1	Digital Output 2
2	Digital Output 3
3	Digital Output 4
4...15	Reserved

<b>Digital Output Mask: Active Level</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs are active high and which are active low. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Drive Reset</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Drive Reset event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Drive Internal Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Drive Internal Error event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Short Circuit Fault</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Short Circuit Fault event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Over-Current Fault</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Over-Current event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Hardware Under Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Hardware Under Voltage event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Hardware Over Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Hardware Over Voltage event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Drive Over Temperature</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Drive Over Temperature event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Parameter Restore Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Parameter Restore Error event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Parameter Store Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Parameter Store Error event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Invalid Hall State</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Invalid Hall State event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Phase Synchronization Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Phase Synchronization Error event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Motor Over Temperature</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Motor Over Temperature event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Phase Detection Fault</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Phase Detection Fault event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Feedback Sensor Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Feedback Sensor Error event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Log Entry Missed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Log Entry Missed event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Software Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Software Disable event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the User Disable event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Positive Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Positive Limit event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Negative Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Negative Limit event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Current Limiting (Foldback)</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Current Limiting event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Continuous Current Limit Reached</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Continuous Current Limit Reached event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Current Loop Saturated</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Current Loop Saturated event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Under Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the User Under Voltage event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Over Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the User Over Voltage event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Non-Sinusoidal Commutation</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Non-Sinusoidal Commutation. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Phase Detection</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Phase Detection event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Auxiliary Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the User Auxiliary Disable event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Shunt Regulator</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Shunt Regulator event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Phase Detection Complete</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Phase Detection Complete event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Command Limiter Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Command Limiter Active event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Motor Over Speed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Motor Over Speed event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: At Command</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the At Command event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Zero Velocity</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Zero Velocity event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Velocity Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Velocity Following Error event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Positive Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Positive Velocity Limit event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Negative Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Negative Velocity Limit event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Max Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Max Measured Position event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Min Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Min Measured Position event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: At Home Position</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the At Home Position event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Position Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Position Following Error event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Max Target position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Max Target Position Limit event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Min Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Min Target Position Limit event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Set Measured Position</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Set Measured Position event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Homing Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Homing Active event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Apply Brake</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Apply Brake event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: PVT Buffer Full</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the PVT Buffer Full event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: PVT Buffer Empty</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the PVT Buffer Empty event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: PVT Buffer Threshold</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the PVT Buffer Threshold event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: PVT Buffer Failure</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the PVT Buffer Failure event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: PVT Buffer Empty Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the PVT Buffer Empty Stop event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: PVT Sequence Number</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the PVT Sequence Number event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Communication Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Communication Error event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Homing Complete</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Homing Complete event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Commanded Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Commanded Stop event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the User Stop event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Bridge Enabled</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Bridge Enabled status. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Dynamic Brake Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Dynamic Brake Active event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Stop Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Stop Active event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Positive Stop Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Positive Stop Active event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Negative Stop Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Negative Stop Active event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Positive Inhibit Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Positive Inhibit Active event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Negative Inhibit Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to the Negative Inhibit Active event. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 1. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 2</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 2. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 3</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 3. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 4</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 4. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 5</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 5. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 6</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 6. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 7</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 7. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 8</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 8. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 9</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 9. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 10</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 10. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 11</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 11. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 12</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 12. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 13</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 13. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 14</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 14. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 15</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 15. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: User Bit 16</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to User Bit 16. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Capture A</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Capture A. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Capture B</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Capture B. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Capture C</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Capture C. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Commanded Positive Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Commanded Positive Limit. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Commanded Negative Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Commanded Negative Limit. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Gain Set 1 Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Gain Set 1 Active. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Zero Position Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Zero Position Error. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Motion Engine Fault</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Motion Engine Fault. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Motion Engine Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Motion Engine Active. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Active Motion Busy</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Active Motion Busy. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Active Motion Done</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Active Motion Done. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Active Motion Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Active Motion Error. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Active Motion Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Active Motion Active. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Active Motion Aborted</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Active Motion Aborted. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Active Motion Execute</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Active Motion Execute. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Active Motion MotionDone</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Active Motion MotionDone. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Active Motion SequenceDone</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Active Motion SequenceDone. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Absolute Position Valid</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Absolute Position Valid See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: Jog Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to Jog Active. See <a href="#">Table 2.6</a> above for mapping structure.				

<b>Digital Output Mask: PWM and Direction Broken Wire</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines which digital outputs, if any, are assigned to PWM and Direction Broken Wire. See <a href="#">Table 2.6</a> above for mapping structure.				

## 2044h: Analog Input Parameters

<b>Analog Input 1 Offset: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	[-2 <sup>15</sup> ] - [2 <sup>15</sup> - 1]	DAI	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the Analog Input 1 Offset in Configuration 0. To convert the desired Offset Voltage to the appropriate do the following: Multiply Voltage (in decimal) by 819.2 and ignore any resulting fractional part. Now convert this decimal value to hexadecimal.				

<b>Analog Input 1 Scale Factor: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the scale factor for analog input 1 in Configuration 0. The values contained are mode dependent and require a different algorithm to calculate for each mode.				
<ul style="list-style-type: none"> <li>•Assigned to Current Loop Example: Desired scale factor = <math>(X \text{ Amps} / 1 \text{ Volt})</math>  <math>(X \text{ Amps} * 10 * 2^{18}) / \text{Drive Peak Current} = \text{Value in decimal; convert to hex.}</math></li> <li>•Assigned to Velocity Loop Example: Desired Scale factor = <math>(X \text{ cnts/sec} / 1 \text{ Volt})</math>            Convert X cnts/sec → Y cnts/100us by dividing by 10000.            Now multiply: <math>Y \text{ cnts} * 20 * 2^{18} = \text{Value in Decimal; convert to hex.}</math></li> <li>•Assigned to Position Loop Example: Desired Scale Factor = <math>(X \text{ cnts} / 1 \text{ Volt})</math>            Now Multiply: <math>X \text{ cnts} * 80 = \text{Value in Decimal; convert to hex.}</math></li> <li>•Assigned to Current Limit Example: Desired Scale Factor = <math>(X\% \text{ of drive peak} / 1 \text{ Volt})</math>            Cannot achieve a value higher than 20% / 1 Volt.            Now Multiply <math>X * 2^{18} / 5 = \text{Value in Decimal; convert to hex.}</math></li> <li>•Assigned to External Temperature: Desired Scale Factor = <math>(X \text{ degrees C} / 1 \text{ Volt})</math>            Now multiply <math>X * 20 * 2^{18} = \text{Value in Decimal; convert to hex}</math></li> </ul>				

<b>Analog Input 2 Offset: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)} - 1]$	DAI	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the Analog Input 2 Offset in Configuration 0. To convert the desired Offset Voltage to the appropriate value do the following: Multiply Voltage (in decimal) by 819.2 and ignore any resulting fractional part. Now convert this decimal value to hexadecimal.				

<b>Analog Input 2 Scale Factor: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the scale factor for analog input 2 in Configuration 0. This value is mode dependent and requires a different algorithm to calculate for each mode.				
<ul style="list-style-type: none"> <li>•Assigned to Current Loop Example: Desired scale factor = <math>(X \text{ Amps} / 1 \text{ Volt})</math>  <math>(X \text{ Amps} * 10 * 2^{18}) / \text{Drive Peak Current} = \text{Value in decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to Velocity Loop Example: Desired Scale factor = <math>(X \text{ cnts/sec} / 1 \text{ Volt})</math>            Convert X cnts/sec → Y cnts/100us by dividing by 10000.            Now multiply: <math>Y \text{ cnts} * 20 * 2^{18} = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to Position Loop Example: Desired Scale Factor = <math>(X \text{ cnts} / 1 \text{ Volt})</math>            Now Multiply: <math>X \text{ cnts} * 80 = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to Current Limit Example: Desired Scale Factor = <math>(X\% \text{ of drive peak} / 1 \text{ Volt})</math>            Cannot achieve a value higher than 20% / 1 Volt.            Now Multiply <math>X * 2^{18} / 5 = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to External Temperature: Desired Scale Factor = <math>(X \text{ degrees C} / 1 \text{ Volt})</math>            Now multiply <math>X * 20 * 2^{18} = \text{Value in Decimal; convert to hex}</math></li> </ul>				

<b>Analog Input 3 Offset: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)} - 1]$	DAI	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the Analog Input 3 Offset in Configuration 0. To convert the desired Offset Voltage to the appropriate value do the following: Multiply Voltage (in decimal) by 819.2 and ignore any resulting fractional part. Now convert this decimal value to hexadecimal.				

<b>Analog Input 3 Scale Factor: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the scale factor for analog input 3 in Configuration 0. The value is mode dependent and requires a different algorithm to calculate for each mode.				
<ul style="list-style-type: none"> <li>•Assigned to Current Loop Example: Desired scale factor = <math>(X \text{ Amps} / 1 \text{ Volt})</math>  <math>(X \text{ Amps} * 10 * 2^{18}) / \text{Drive Peak Current} = \text{Value in decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to Velocity Loop Example: Desired Scale factor = <math>(X \text{ cnts/sec} / 1 \text{ Volt})</math>            Convert X cnts/sec → Y cnts/100us by dividing by 10000.            Now multiply: <math>Y \text{ cnts} * 20 * 2^{18} = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to Position Loop Example: Desired Scale Factor = <math>(X \text{ cnts} / 1 \text{ Volt})</math>            Now Multiply: <math>X \text{ cnts} * 80 = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to Current Limit Example: Desired Scale Factor = <math>(X\% \text{ of drive peak} / 1 \text{ Volt})</math>            Cannot achieve a value higher than 20% / 1 Volt.            Now Multiply <math>X * 2^{18} / 5 = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to External Temperature: Desired Scale Factor = <math>(X \text{ degrees C} / 1 \text{ Volt})</math>            Now multiply <math>X * 20 * 2^{18} = \text{Value in Decimal; convert to hex}</math></li> </ul>				

<b>Analog Input 4 Offset: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)} - 1]$	DAI	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the Analog Input 4 Offset in Configuration 0. To convert the desired Offset Voltage to the appropriate value do the following: Multiply Voltage (in decimal) by 819.2 and ignore any resulting fractional part. Now convert this decimal value to hexadecimal.				

<b>Analog Input 4 Scale Factor: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the scale factor for analog input 4 in Configuration 0. The value is mode dependent and requires a different algorithm to calculate for each mode.				
<ul style="list-style-type: none"> <li>•Assigned to Current Loop Example: Desired scale factor = <math>(X \text{ Amps} / 1 \text{ Volt})</math>  <math>(X \text{ Amps} * 10 * 2^{18}) / \text{Drive Peak Current} = \text{Value in decimal; convert to hex.}</math></li> <li>•Assigned to Velocity Loop Example: Desired Scale factor = <math>(X \text{ cnts/sec} / 1 \text{ Volt})</math>            Convert X cnts/sec → Y cnts/100us by dividing by 10000.            Now multiply: <math>Y \text{ cnts} * 20 * 2^{18} = \text{Value in Decimal; convert to hex.}</math></li> <li>•Assigned to Position Loop Example: Desired Scale Factor = <math>(X \text{ cnts} / 1 \text{ Volt})</math>            Now Multiply: <math>X \text{ cnts} * 80 = \text{Value in Decimal; convert to hex.}</math></li> <li>•Assigned to Current Limit Example: Desired Scale Factor = <math>(X\% \text{ of drive peak} / 1 \text{ Volt})</math>            Cannot achieve a value higher than 20% / 1 Volt.            Now Multiply <math>X * 2^{18} / 5 = \text{Value in Decimal; convert to hex.}</math></li> <li>•Assigned to External Temperature: Desired Scale Factor = <math>(X \text{ degrees C} / 1 \text{ Volt})</math>            Now multiply <math>X * 20 * 2^{18} = \text{Value in Decimal; convert to hex}</math></li> </ul>				

<b>Analog Input 1 Offset: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)} - 1]$	DAI	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the Analog Input 1 Offset in Configuration 1. To convert the desired Offset Voltage to the appropriate do the following: Multiply Voltage (in decimal) by 819.2 and ignore any resulting fractional part. Now convert this decimal value to hexadecimal.				

<b>Analog Input 1 Scale Factor: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the scale factor for analog input 1 in Configuration 1. The values contained are mode dependent and require a different algorithm to calculate for each mode.				
<ul style="list-style-type: none"> <li>•Assigned to Current Loop Example: Desired scale factor = <math>(X \text{ Amps} / 1 \text{ Volt})</math>  <math>(X \text{ Amps} * 10 * 2^{18}) / \text{Drive Peak Current} = \text{Value in decimal; convert to hex.}</math></li> <li>•Assigned to Velocity Loop Example: Desired Scale factor = <math>(X \text{ cnts/sec} / 1 \text{ Volt})</math>            Convert X cnts/sec → Y cnts/100us by dividing by 10000.            Now multiply: <math>Y \text{ cnts} * 20 * 2^{18} = \text{Value in Decimal; convert to hex.}</math></li> <li>•Assigned to Position Loop Example: Desired Scale Factor = <math>(X \text{ cnts} / 1 \text{ Volt})</math>            Now Multiply: <math>X \text{ cnts} * 80 = \text{Value in Decimal; convert to hex.}</math></li> <li>•Assigned to Current Limit Example: Desired Scale Factor = <math>(X\% \text{ of drive peak} / 1 \text{ Volt})</math>            Cannot achieve a value higher than 20% / 1 Volt.            Now Multiply <math>X * 2^{18} / 5 = \text{Value in Decimal; convert to hex.}</math></li> <li>•Assigned to External Temperature: Desired Scale Factor = <math>(X \text{ degrees C} / 1 \text{ Volt})</math>            Now multiply <math>X * 20 * 2^{18} = \text{Value in Decimal; convert to hex}</math></li> </ul>				

<b>Analog Input 2 Offset: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)} - 1]$	DAI	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the Analog Input 2 Offset in Configuration 1. To convert the desired Offset Voltage to the appropriate value do the following: Multiply Voltage (in decimal) by 819.2 and ignore any resulting fractional part. Now convert this decimal value to hexadecimal.				

<b>Analog Input 2 Scale Factor: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the scale factor for analog input 2 in Configuration 1. This value is mode dependent and requires a different algorithm to calculate for each mode.				
<ul style="list-style-type: none"> <li>•Assigned to Current Loop Example: Desired scale factor = <math>(X \text{ Amps} / 1 \text{ Volt})</math>  <math>(X \text{ Amps} * 10 * 2^{18}) / \text{Drive Peak Current} = \text{Value in decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to Velocity Loop Example: Desired Scale factor = <math>(X \text{ cnts/sec} / 1 \text{ Volt})</math>            Convert X cnts/sec → Y cnts/100us by dividing by 10000.            Now multiply: <math>Y \text{ cnts} * 20 * 2^{18} = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to Position Loop Example: Desired Scale Factor = <math>(X \text{ cnts} / 1 \text{ Volt})</math>            Now Multiply: <math>X \text{ cnts} * 80 = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to Current Limit Example: Desired Scale Factor = <math>(X\% \text{ of drive peak} / 1 \text{ Volt})</math>            Cannot achieve a value higher than 20% / 1 Volt.            Now Multiply <math>X * 2^{18} / 5 = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>•Assigned to External Temperature: Desired Scale Factor = <math>(X \text{ degrees C} / 1 \text{ Volt})</math>            Now multiply <math>X * 20 * 2^{18} = \text{Value in Decimal; convert to hex}</math></li> </ul>				

<b>Analog Input 3 Offset: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)} - 1]$	DAI	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the Analog Input 3 Offset in Configuration 1. To convert the desired Offset Voltage to the appropriate value do the following: Multiply Voltage (in decimal) by 819.2 and ignore any resulting fractional part. Now convert this decimal value to hexadecimal.				

<b>Analog Input 3 Scale Factor: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the scale factor for analog input 3 in Configuration 1. The value is mode dependent and requires a different algorithm to calculate for each mode.				
<ul style="list-style-type: none"> <li>•Assigned to Current Loop Example: Desired scale factor = <math>(X \text{ Amps} / 1 \text{ Volt})</math>  <math>(X \text{ Amps} * 10 * 2^{18}) / \text{Drive Peak Current} = \text{Value in decimal; convert to hex}</math></li> <li>•Assigned to Velocity Loop Example: Desired Scale factor = <math>(X \text{ cnts/sec} / 1 \text{ Volt})</math>            Convert X cnts/sec → Y cnts/100us by dividing by 10000            Now multiply: <math>Y \text{ cnts} * 20 * 2^{18} = \text{Value in Decimal; convert to hex.}</math></li> <li>•Assigned to Position Loop Example: Desired Scale Factor = <math>(X \text{ cnts} / 1 \text{ Volt})</math>            Now Multiply: <math>X \text{ cnts} * 80 = \text{Value in Decimal; convert to hex}</math></li> <li>•Assigned to Current Limit Example: Desired Scale Factor = <math>(X\% \text{ of drive peak} / 1 \text{ Volt})</math>            Cannot achieve a value higher than 20% / 1 Volt            Now Multiply <math>X * 2^{18} / 5 = \text{Value in Decimal; convert to hex}</math></li> <li>•Assigned to External Temperature: Desired Scale Factor = <math>(X \text{ degrees C} / 1 \text{ Volt})</math>            Now multiply <math>X * 20 * 2^{18} = \text{Value in Decimal; convert to hex}</math></li> </ul>				

<b>Analog Input 4 Offset: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)} - 1]$	DAI	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the Analog Input 4 Offset in Configuration 1. To convert the desired Offset Voltage to the appropriate value do the following: Multiply Voltage (in decimal) by 819.2 and ignore any resulting fractional part. Now convert this decimal value to hexadecimal.				

<b>Analog Input 4 Scale Factor: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{31}] - [2^{31} - 1]$	N/A	Read / Write	Yes
<b>Description:</b>				
Contains a value corresponding to the scale factor for analog input 4 in Configuration 1. The value is mode dependent and requires a different algorithm to calculate for each mode.				
<ul style="list-style-type: none"> <li>Assigned to Current Loop Example: Desired scale factor = <math>(X \text{ Amps} / 1 \text{ Volt})</math>  <math>(X \text{ Amps} * 10 * 2^{18}) / \text{Drive Peak Current} = \text{Value in decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>Assigned to Velocity Loop Example: Desired Scale factor = <math>(X \text{ cnts/sec} / 1 \text{ Volt})</math>  Convert X cnts/sec → Y cnts/100us by dividing by 10000.  Now multiply: <math>Y \text{ cnts} * 20 * 2^{18} = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>Assigned to Position Loop Example: Desired Scale Factor = <math>(X \text{ cnts} / 1 \text{ Volt})</math>  Now Multiply: <math>X \text{ cnts} * 80 = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>Assigned to Current Limit Example: Desired Scale Factor = <math>(X\% \text{ of drive peak} / 1 \text{ Volt})</math>  Cannot achieve a value higher than 20% / 1 Volt.  Now Multiply <math>X * 2^{18} / 5 = \text{Value in Decimal; convert to hex.}</math></li> </ul>				
<ul style="list-style-type: none"> <li>Assigned to External Temperature: Desired Scale Factor = <math>(X \text{ degrees C} / 1 \text{ Volt})</math>  Now multiply <math>X * 20 * 2^{18} = \text{Value in Decimal; convert to hex}</math></li> </ul>				

**203Dh: Deadband Parameters** Some deadband parameters have units that vary with the operating mode of the drive. For these parameters, refer to [Table 2.7](#) for the correct unit selection.

**TABLE 2.7** Deadband Units

<b>Drive Operation Mode</b>	<b>Units</b>
Current (Torque)	DC2
Velocity	DS1
Position (Around Velocity Or Current)	counts

<b>Deadband Type: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 - 1	N/A	Read / Write	Yes
<b>Description:</b>				
Deadband Type for Configuration 0.				
<b>Value</b>		<b>Description</b>		
0		Non-linear (starts smoothly after reaching end of deadband)		
1		Linear (jumps to command after reaching end of deadband)		

<b>Deadband Width: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>(31)-1</sup> ]	See Table 2.7	Read / Write	Yes
<b>Description:</b>				
The width from the midpoint to one end of the deadband in Configuration 0. Therefore, the total width is 2X this value.				

<b>Deadband Set Point: Config 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[-2 <sup>(31)</sup> ] – [2 <sup>(31)-1</sup> ]	See Table 2.7	Read / Write	Yes
<b>Description:</b>				
Midpoint of the Deadband in Configuration 0.				

<b>Deadband Type: Config 1</b>										
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>						
Integer16	0 - 1	N/A	Read / Write	Yes						
<b>Description:</b>										
Deadband Type for Configuration 1.										
<table border="1"> <thead> <tr> <th><b>Value</b></th> <th><b>Description</b></th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Non-linear (starts smoothly after reaching end of deadband)</td> </tr> <tr> <td>1</td> <td>Linear (jumps to command after reaching end of deadband)</td> </tr> </tbody> </table>					<b>Value</b>	<b>Description</b>	0	Non-linear (starts smoothly after reaching end of deadband)	1	Linear (jumps to command after reaching end of deadband)
<b>Value</b>	<b>Description</b>									
0	Non-linear (starts smoothly after reaching end of deadband)									
1	Linear (jumps to command after reaching end of deadband)									

<b>Deadband Width: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	0 – [2 <sup>(31)-1</sup> ]	See Table 2.7	Read / Write	Yes
<b>Description:</b>				
The width from the midpoint to one end of the deadband in Configuration 1. Therefore, the total width is 2X this value.				

<b>Deadband Set Point: Config 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[-2 <sup>(31)</sup> ] – [2 <sup>(31)-1</sup> ]	See Table 2.7	Read / Write	Yes
<b>Description:</b>				
Midpoint of the Deadband in Configuration 1.				

**203Eh: Jog Parameters**

<b>Max Acceleration</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	1 – [2 <sup>31</sup> -1]	DA4	Read / Write	Yes
<b>Description:</b>				
Sets the acceleration for Jog 0 and Jog 1.				

<b>Max Deceleration</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	1 – [2 <sup>31</sup> -1]	DA4	Read / Write	Yes
<b>Description:</b>				
Sets the deceleration for Jog 0 and Jog 1.				

<b>Jog Speed 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	1 – [2 <sup>31</sup> -1]	DS1	Read / Write	Yes
<b>Description:</b>				
Sets the target speed for Jog 0.				

<b>Jog Speed 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	1 – [2 <sup>31</sup> -1]	DS1	Read / Write	Yes
<b>Description:</b>				
Sets the target speed for Jog 1.				

<b>Jog Speed 2</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	1 – [2 <sup>31</sup> -1]	DS1	Read / Write	Yes
<b>Description:</b>				
Sets the target speed for Jog 2.				

<b>Jog Speed 3</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	1 – [2 <sup>31</sup> -1]	DS1	Read / Write	Yes
<b>Description:</b>				
Sets the target speed for Jog 3.				

**205Ch: Analog Output Parameters**

Analog Output 1 Signal Select A				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Together with Signal Select B determines which internal drive parameter is assigned to analog output 1.				

Analog Output 1 Signal Select B				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Together with Signal Select A determines which internal drive parameter is assigned to analog output 1.				

Analog Output 1 Offset				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	[-2 <sup>(15)</sup> ] - [2 <sup>(15)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Analog output 1 offset.				

Analog Output 1 Gain				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	[-2 <sup>(31)</sup> ] - [2 <sup>(31)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Analog output 1 gain.				

Analog Output 1 Operator				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Analog output 1 operator.				

Analog Output 2 Signal Select A				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Together with Signal Select B determines which internal drive parameter is assigned to analog output 2.				

<b>Analog Output 2 Signal Select B</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Together with Signal Select B determines which internal drive parameter is assigned to analog output 2.				

<b>Analog Output 2 Offset</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	[-2 <sup>15</sup> ] - [2 <sup>15</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Analog output 2 offset.				

<b>Analog Output 2 Gain</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[-2 <sup>31</sup> ] - [2 <sup>31</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Analog output 2 gain.				

<b>Analog Output 2 Operator</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Analog output 2 operator.				

## 2062h: Braking/Stop General Properties

<b>Braking: Delay After Applying Brake</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
Specifies the delay, in milliseconds, after applying the external brake before disabling the power bridge or dynamic braking.				

<b>2062.02h</b>	<b>Braking: Delay Before Disengaging Brake</b>						
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>			
Unsigned16	0 - [2 <sup>16</sup> - 1]	milliseconds (ms)	Read / Write	Yes			
<b>Description:</b>							
Specifies the delay, in milliseconds, before releasing the external brake after enabling the power bridge or discontinuing dynamic braking.							

<b>2062.03h</b>	<b>Stop Deceleration Limit - Position Mode</b>						
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>			
Integer32	1 - [2 <sup>31</sup> - 1]	DA1	Read / Write	Yes			
<b>Description:</b>							
Specifies the maximum position mode deceleration during a controlled Stop event. See " <a href="#">Appendix</a> " on page 283 for unit conversion details.							

<b>2062.04h</b>	<b>Stop Deceleration Limit - Velocity Mode</b>						
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>			
Integer32	1 - [2 <sup>31</sup> - 1]	DA1	Read / Write	Yes			
<b>Description:</b>							
Specifies the maximum velocity mode acceleration during a controlled Stop event. See " <a href="#">Appendix</a> " on page 283 for unit conversion details.							

<b>2062.05h</b>	<b>Stop Jerk Limit - Current Mode</b>						
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>			
Integer32	1 - [2 <sup>31</sup> - 1]	DJ1	Read / Write	Yes			
<b>Description:</b>							
Sets the rate at which the target current ramps down during a Stop event. Only valid for current mode. See " <a href="#">Appendix</a> " on page 283 for unit conversion details.							

## 2064h: Event Response Time Parameters

<b>2064.01h</b>	<b>Event Response Time: Motor Over Temperature</b>						
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>			
Unsigned16	0 - [2 <sup>15</sup> - 1]	milliseconds (ms)	Read / Write	Yes			
<b>Description:</b>							
The time delay after the occurrence of Motor Over Temperature before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.							

<b>Event Response Time: Feedback Sensor Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of a Feedback Sensor Error before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Log Entry Missed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of a Log Entry Missed before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: User Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of a User Disable before the power bridge is disabled. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Positive Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of a Positive Limit input before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Negative Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of a Negative Limit input before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Current Limiting</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	Milliseconds	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Current Limiting before its Event Action (2065h) is executed.				

<b>Event Response Time: Continuous Current</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of reaching the Continuous Current setting before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Current Loop Saturated</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Current Loop Saturated before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: User Under Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of User Under Voltage before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: User Over Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of a user-specified Over Voltage level before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Motor Over Speed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Motor Over Speed before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: User Auxiliary Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of a User Auxiliary Disable input before dynamic braking is applied. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Shunt Regulator</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Shunt Regulator activity before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Command Limiter Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Command Limiter Active before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: At Command</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of At Command before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Zero Velocity</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Zero Velocity before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Velocity Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Velocity Following Error before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Positive Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Positive Velocity Limit before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Negative Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Negative Velocity Limit before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: At Home Position</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of At Home Position before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Position Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Position Following Error before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Max Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Max Target Position Limit before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Min Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Min Target Position Limit before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Max Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Maximum Measured Position Limit before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Min Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Minimum Measured Position Limit before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: PVT Buffer Full</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of PVT Buffer Full before its Event Action (2065h) is executed.				

<b>Event Response Time: PVT Buffer Empty</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of PVT Buffer Empty before its Event Action (2065h) is executed.				
The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: PVT Buffer Threshold</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of PVT Buffer Threshold before its Event Action (2065h) is executed.				
The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: PVT Buffer Failure</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of PVT Buffer Failure before its Event Action (2065h) is executed.				
The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: PVT Buffer Empty Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(15)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of PVT Buffer Empty Stop before its Event Action (2065h) is executed.				
The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: PVT Sequence Number</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>15</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of PVT Sequence Number before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: Communication Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>15</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Communication Error before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: User Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>15</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of a User Stop command before stopping the motor. The event action is disabled when bit 15 is set to 1.				

<b>Event Response Time: PWM and Direction Broken Wire</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>15</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of PWM and Direction Broken Wire before its Event Action (2065h) is executed. The event action is disabled when bit 15 is set to 1.				

## 2065h: Event Action Parameters

<b>Event Action: Parameter Restore Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Parameter Restore Error. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Parameter Store Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Parameter Store Error. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Invalid Hall State</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after an Invalid Hall State. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Phase Synch Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Phase Synch Error. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Motor Over Temperature</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Motor Over Temperature. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Feedback Sensor Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Feedback Sensor Error. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Log Entry Missed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Log Entry Missed. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Current Limiting</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Current Limiting. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Continuous Current</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Continuous Current. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Current Loop Saturated</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after Current Loop Saturated. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: User Under Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a User Under Voltage. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: User Over Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a User Over Voltage. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Shunt Regulator</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after Shunt Regulator active. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Command Limiter Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after Command Limiter Active. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Motor Over Speed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Motor Over Speed. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: At Command</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after an At Command state. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Zero Velocity</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Zero Velocity state. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Velocity Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Velocity Following Error. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Positive Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Positive Velocity Limit. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Negative Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Negative Velocity Limit. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Max Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Max Measured Position Limit. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Min Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Min Measured Position Limit. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: At Home Position</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after an At Home Position state. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Position Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Position Following Error. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Max Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Max Target Position Limit. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Min Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Min Target Position Limit. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: PVT Buffer Full</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a PVT Buffer Full status. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: PVT Buffer Empty</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a PVT Buffer Empty status. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: PVT Buffer Threshold</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after reaching PVT Buffer Threshold. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: PVT Buffer Failure</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a PVT Buffer Failure. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: PVT Buffer Empty Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a PVT Buffer Empty Stop. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: PVT Sequence Number</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a PVT Sequence Number. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Communication Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Communication Error. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: User Positive Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a User Positive Limit. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: User Negative Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a User Negative Limit. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Drive Reset</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Drive Reset. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Drive Internal Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Drive Internal Error. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Short Circuit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Short Circuit. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Current Overshoot</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Current Overshoot. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Hardware Under Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Hardware Under Voltage. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Hardware Over Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Hardware Over Voltage. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Drive Over Temperature</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Drive Over Temperature. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Software Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Software Disable. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: User Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a User Disable. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: User Auxiliary Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a User Auxiliary Disable. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>Event Action: Phase Detection Fault</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read / Write	Yes
<b>Description:</b>				
The action of the drive immediately after a Phase Detection Fault. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.				

<b>2065.2Fh</b>		<b>Event Action: Commanded Positive Limit</b>																			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>			<b>Accessibility</b>			<b>Stored to NVM</b>													
Unsigned16	0 – 15	N/A			Read / Write			Yes													
<b>Description:</b>																					
The action of the drive immediately after a Commanded Positive Limit. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.																					

<b>2065.30h</b>		<b>Event Action: Commanded Negative Limit</b>																			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>			<b>Accessibility</b>			<b>Stored to NVM</b>													
Unsigned16	0 – 15	N/A			Read / Write			Yes													
<b>Description:</b>																					
The action of the drive immediately after a Commanded Negative Limit. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.																					

<b>2065.31h</b>		<b>Event Action: PWM and Direction Broken Wire</b>																			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>			<b>Accessibility</b>			<b>Stored to NVM</b>													
Unsigned16	0 – [2 <sup>(15)</sup> – 1]	N/A			Read / Write			Yes													
<b>Description:</b>																					
The action of the drive immediately after a PWM and Direction Broken Wire. Refer to <a href="#">Table 2.8</a> below for the valid event actions and their respective values.																					

**TABLE 2.8** Event Action Options

<b>Sub Index</b>	<b>Event</b>	<b>Valid Event Action Values (refer to Table 2.9 for value definitions)</b>											
01h	Parameter Restore Error	-	1	-	-	4	-	-	-	8	9	10	11
02h	Parameter Store Error	-	1	-	-	4	-	-	-	8	9	10	11
03h	Invalid Hall State	-	1	-	-	4	-	-	-	8	9	10	11
04h	Phase Synch Error	0	1	-	-	4	-	-	-	8	9	10	11
05h	Motor Over Temperature	0	1	2	3	4	5	6	7	8	9	10	11
06h	Feedback Sensor Error	0	1	2	3	4	5	6	7	8	9	10	11
07h	Log Entry Missed	0	1	2	3	4	5	6	7	8	9	10	11
08h	Current Limiting	0	1	2	3	4	5	6	7	8	9	10	11
09h	Continuous Current	0	1	2	3	4	5	6	7	8	9	10	11
0Ah	Current Loop Saturated	0	1	2	3	4	5	6	7	8	9	10	11
0Bh	User Under Voltage	0	1	2	3	4	5	6	7	8	9	10	11
0Ch	User Over Voltage	0	1	2	3	4	5	6	7	8	9	10	11
0Dh	Shunt Regulator	0	1	-	-	4	-	-	-	8	9	10	11
0Eh	Command Limiter Active	0	-	-	-	-	-	-	-	-	-	-	-
0Fh	Motor Over Speed	0	1	2	3	4	5	6	7	8	9	10	11

10h	At Command	0	1	2	3	4	5	6	7	8	9	10	11
11h	Zero Velocity	0	-	-	-	-	-	-	-	-	-	-	-
12h	Velocity Following Error	0	1	2	3	4	5	6	7	8	9	10	11
13h	Positive Velocity Limit	0	1	2	3	4	5	6	7	8	9	10	11
14h	Negative Velocity Limit	0	1	2	3	4	5	6	7	8	9	10	11
15h	Max Measured Position Limit	0	1	2	3	4	5	6	7	8	9	10	11
16h	Min Measured Position Limit	0	1	2	3	4	5	6	7	8	9	10	11
17h	At Home Position	0	-	-	-	-	-	-	-	-	-	-	-
18h	Position Following Error	0	1	2	3	4	5	6	7	8	9	10	11
19h	Max Target Position Limit	0	1	2	3	4	5	6	7	8	9	10	11
1Ah	Min Target Position Limit	0	1	2	3	4	5	6	7	8	9	10	11
1Bh	PVT Buffer Full	0	1	2	3	4	5	6	7	8	9	10	11
1Ch	PVT Buffer Empty	0	1	2	3	4	5	6	7	8	9	10	11
1Dh	PVT Buffer Threshold	0	1	2	3	4	5	6	7	8	9	10	11
1Eh	PVT Buffer Failure	0	1	2	3	4	5	6	7	8	9	10	11
1Fh	PVT Buffer Empty Stop	0	1	2	3	4	5	6	7	8	9	10	11
20h	PVT Sequence Number	0	1	2	3	4	-	-	-	8	9	10	11
21h	Communication Error	0	1	2	3	4	5	6	7	8	9	10	11
22h	User Positive Limit	-	-	2	-	-	5	-	-	-	-	-	-
23h	User Negative Limit	-	-	-	3	-	-	6	-	-	-	-	-
24h	Drive Reset	-	1	-	-	-	-	-	-	-	-	-	10
25h	Drive Internal Error	-	1	-	-	-	-	-	-	-	-	-	10
26h	Short Circuit	-	1	-	-	-	-	-	-	-	-	-	10
27h	Current Overshoot	-	1	-	-	-	-	-	-	-	-	-	10
28h	Hardware Under Voltage	-	1	-	-	-	-	-	-	-	-	-	10
29h	Hardware Over Voltage	-	1	-	-	-	-	-	-	-	-	-	10
2Ah	Drive Over Temperature	-	1	-	-	-	-	-	-	-	-	-	10
2Bh	Software Disable	-	1	-	-	-	-	-	-	-	8	-	10
2Ch	User Disable	-	1	-	-	-	-	-	-	-	8	-	10
2Dh	User Auxiliary Disable	-	1	-	-	4	-	-	-	8	9	10	11
2Eh	Phase Detection Fault	-	1	-	-	-	-	-	-	8	-	10	-
2Fh	Commanded Positive Limit	-	-	2	-	-	5	-	-	-	-	-	-
30h	Commanded Negative Limit	-	-	-	3	-	-	6	-	-	-	-	-

**TABLE 2.9** Event Action Values Definition

<b>Event Action Values</b>	<b>Hex Values</b>	<b>Event Actions</b>
0	00h	No Action
1	01h	Disable Power Bridge
2	02h	Disable Positive Direction
3	03h	Disable Negative Direction
4	04h	Dynamic Brake
5	05h	Positive Stop
6	06h	Negative Stop
7	07h	Stop
8	08h	Apply Brake <b>then</b> Disable Bridge
9	09h	Apply Brake <b>then</b> Dynamic Brake
10	0Ah	Apply Brake <b>and</b> Disable Bridge
11	0Bh	Apply Brake <b>and</b> Dynamic Brake

**2066h: Event Recovery Time Parameters**

<b>2066.01h</b> <b>Event Recovery Time: Motor Over Temperature</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>16</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Motor Over Temperature is no longer true before its Event Action (2065h) is removed.				

<b>2066.02h</b> <b>Event Recovery Time: Feedback Sensor Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>16</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Feedback Sensor Error is no longer true before its Event Action (2065h) is removed.				

<b>2066.03h</b> <b>Event Recovery Time: Log Entry Missed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>16</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Log Entry Missed is no longer true before its Event Action (2065h) is removed.				

<b>2066.04h</b>	<b>Event Recovery Time: User Disable</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after User Disable is no longer true before its Event Action (2065h) is removed.				

<b>2066.05h</b>	<b>Event Recovery Time: Positive Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Positive Limit is no longer true before its Event Action (2065h) is removed.				

<b>2066.06h</b>	<b>Event Recovery Time: Negative Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Negative Limit is no longer true before its Event Action (2065h) is removed.				

<b>2066.07h</b>	<b>Event Recovery Time: Current Limiting</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Current Limiting is no longer true before its Event Action (2065h) is removed.				

<b>2066.08h</b>	<b>Event Recovery Time: Continuous Current Limiting</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Continuous Current Limiting is no longer true before its Event Action (2065h) is removed.				

<b>2066.09h</b>	<b>Event Recovery Time: Current Loop Saturated</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Current Loop Saturated status is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: User Under Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after User Under Voltage is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: User Over Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after User Over Voltage is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: User Dynamic Brake</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after User Dynamic Brake is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: Shunt Regulator</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Shunt Regulator active is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: Command Limiter Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Command Limiter Active is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: Motor Over Speed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Motor Over Speed is no longer true before its Event Action (2065h) is removed.				

<b>2066.10h</b>	<b>Event Recovery Time: At Command</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after At Command is no longer true before its Event Action (2065h) is removed.				

<b>2066.11h</b>	<b>Event Recovery Time: Zero Velocity</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Zero Velocity is no longer true before its Event Action (2065h) is removed.				

<b>2066.12h</b>	<b>Event Recovery Time: Velocity Following Error</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Velocity Following Error is no longer true before its Event Action (2065h) is removed.				

<b>2066.13h</b>	<b>Event Recovery Time: Positive Velocity Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Positive Velocity Limit is no longer true before its Event Action (2065h) is removed.				

<b>2066.14h</b>	<b>Event Recovery Time: Negative Velocity Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Negative Velocity Limit is no longer true before its Event Action (2065h) is removed.				

<b>2066.15h</b>	<b>Event Recovery Time: Max Measured Position Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Max Measured Position Limit status is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: Min Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Min Measured Position Limit status is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: At Home Position</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after no longer At Home Position before its Event Action (2065h) is removed.				

<b>Event Recovery Time: Position Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Position Following Error is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: Max Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Max Target Position Limit is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: Min Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Min Target Position Limit is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: PVT Buffer Full</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after PVT Buffer Full is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: PVT Buffer Empty</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after PVT Buffer Empty is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: PVT Buffer Threshold</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after PVT Buffer Threshold is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: PVT Buffer Failure</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after PVT Buffer Failure is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: PVT Buffer Empty Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after PVT Buffer Empty Stop is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: PVT Sequence Number</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after PVT Sequence Number error is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: Communication Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after Communication Error is no longer true before its Event Action (2065h) is removed.				

<b>Event Recovery Time: User Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after User Stop is no longer true before it is considered no longer active.				

<b>Event Recovery Time: PWM and Direction Broken Wire</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time delay after PWM and Direction Broken Wire is no longer true before it is considered no longer active.				

## 2067h: Event Time-Out Window Parameters

<b>Event Time-Out Window: Motor Over Temperature</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Motor Over Temperature as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Feedback Sensor Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Feedback Sensor Error as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: User Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a User Disable as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: User Positive Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Positive Limit as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: User Negative Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Negative Limit as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Current Limiting</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of Current Limiting as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Continuous Current</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of Continuous Current as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Current Loop Saturated</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Current Loop Saturated as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: User Under Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a User Under Voltage as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: User Over Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a User Over Voltage as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: User Auxiliary Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a User Auxiliary Disable as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Shunt Regulator</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Shunt Regulator as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Command Limiter Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Command Limiter Active as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Motor Over Speed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Motor Over Speed as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: At Command</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of At Command as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Zero Velocity</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of Zero Velocity as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Velocity Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Velocity Following Error as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Positive Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Positive Velocity Limit as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Negative Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Negative Velocity Limit as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Max Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of Max Measured Position Limit as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Min Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of Min Measured Position Limit as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: At Home Position</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of At Home Position as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Position Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Position Following Error as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Max Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of Max Target Position Limit as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Min Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of Min Target Position Limit as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: PVT Buffer Full</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a PVT Buffer Full as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: PVT Buffer Empty</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a PVT Buffer Empty as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: PVT Buffer Threshold</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a PVT Buffer Threshold as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: PVT Buffer Failure</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a PVT Buffer Failure as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: PVT Buffer Empty Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a PVT Buffer Empty Stop as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: PVT Sequence Number</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a PVT Sequence Number as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: Communication Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a Communication Error as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: User Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of a User Stop as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

<b>Event Time-Out Window: PWM and Direction Broken Wire</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> –1]	milliseconds (ms)	Read / Write	Yes
<b>Description:</b>				
The time, after the Recovery Time (2066h) and subsequent removal of the event action, during which the drive will NOT consider an occurrence of PWM and Direction as a new occurrence. The Event Action (2065h) will still be applied in case an event does occur within this window. However, that occurrence will not be counted as a new occurrence with regard to the Maximum Recoveries (2068h) attribute.				

## 2068h: Event Maximum Recoveries Parameters

Event Maximum Recoveries: Short Circuit				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Short Circuit performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Short Circuit event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

Event Maximum Recoveries: Hardware Under Voltage				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Hardware Under Voltage performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Hardware Under Voltage event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

Event Maximum Recoveries: Hardware Over Voltage				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Hardware Over Voltage performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Hardware Over Voltage event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

Event Maximum Recoveries: Drive Over Temperature				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Drive Over Temperature performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Drive Over Temperature event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Invalid Hall State</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of an Invalid Hall State performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Invalid Hall State event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Phase Synchronization Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Phase Synchronization Error performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Phase Synchronization Error event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Motor Over Temperature</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Motor Over Temperature performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Motor Over Temperature event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Phase Detection Failure</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Phase Detection Failure performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Phase Detection Failure event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Feedback Sensor Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Feedback Sensor Error performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Feedback Sensor Error event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Log Entry Missed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Log Entry Missed performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Log Entry Missed event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: User Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a User Disable performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the User Disable event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: User Positive Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Positive Limit performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Positive Limit event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: User Negative Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Negative Limit performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Negative Limit event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Current Limiting</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Current Limiting performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Current Limiting event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Continuous Current Limiting</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Continuous Current Limiting performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Continuous Current Limiting event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Current Loop Saturated</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Current Loop Saturated performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Current Loop Saturated event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: User Under Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a User Under Voltage performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the User Under Voltage event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: User Over Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a User Over Voltage performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the User Over Voltage event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: User Auxiliary Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a User Auxiliary Disable performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the User Auxiliary Disable event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Shunt Regulator</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Shunt Regulator performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Shunt Regulator event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Command Limiter Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Command Limiter Active performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Command Limiter Active event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Motor Over Speed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of a Motor Over Speed performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Motor Over Speed event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: At Command</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of At Command performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the At Command event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Zero Velocity</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Zero Velocity performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Zero Velocity event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Velocity Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Velocity Following Error performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Velocity Following Error event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Positive Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Positive Velocity Limit performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Positive Velocity Limit event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Negative Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Negative Velocity Limit performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Negative Velocity Limit event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Max Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Max Measured Position performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Max Measured Position event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Min Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Min Measured Position performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Min Measured Position event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: At Home Position</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of At Home Position performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the At Home Position event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Position Following Errors</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Position Following Errors performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Position Following Errors event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Max Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Max Target Position performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Max Target Position event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Min Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Min Target Position performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Min Target Position event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: PVT Buffer Full</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of PVT Buffer Full performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the PVT Buffer Full event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: PVT Buffer Empty</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of PVT Buffer Empty performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the PVT Buffer Empty event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: PVT Buffer Threshold</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of PVT Buffer Threshold performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the PVT Buffer Threshold event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: PVT Buffer Failure</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of PVT Buffer Failure performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the PVT Buffer Failure event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: PVT Buffer Empty Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of PVT Buffer Empty Stop performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the PVT Buffer Empty Stop event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: PVT Sequence Number</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of PVT Buffer Sequence Number performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the PVT Buffer Sequence Number event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: Communication Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of Communication Error performs the action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the Communication Error event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: User Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of User Stop performs the event action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the User Stop event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

<b>Event Maximum Recoveries: PWM and Direction Broken Wire</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 65535	N/A	Read / Write	Yes
<b>Description:</b>				
Each occurrence of PWM and Direction Broken Wire performs the event action assigned to this event. Each time the event is removed for longer than the addition of the values in the Time-Out Window (2067h) and Recovery Time (2066h), a recovery counter is incremented. This object sets the maximum recovery count allowed before the PWM and Direction Broken Wire event latches and must be actively reset in order to enable the bridge. Re-setting the recovery counter requires a connection to the AMC drive configuration software appropriate for this drive. For more information on event handling, see the Help file associated with the AMC drive configuration software.				

**205Bh: Programmable Status Parameters** Determines which events will be mapped to the StatusWord (6041h) bits, indicated below. When multiple events are mapped to a single bit, they will be logically OR-ed.

**TABLE 2.10** Programmable Status Mapping

<b>Programmable Status Mask</b>	<b>Description</b>
Bit 0...12	Reserved
Bit 13	Bit 11 (Internal Limit Active) in 6041h (StatusWord)
Bit 14	Bit 7 (Warning) in 6041h (StatusWord)
Bit 15	Bit 8 (manufacturer specific) in 6041h (StatusWord)

<b>Programmable Status Mask: Drive Reset</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Drive Reset event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.02h</b> <b>Programmable Status Mask: Drive Internal Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Drive Internal Error event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.03h</b> <b>Programmable Status Mask: Short Circuit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Short Circuit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.04h</b> <b>Programmable Status Mask: Over Current</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Over Current event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.05h</b> <b>Programmable Status Mask: Hardware Under Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Hardware Under Voltage event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.06h</b> <b>Programmable Status Mask: Hardware Over Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Hardware Over Voltage event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.07h</b> <b>Programmable Status Mask: Drive Over Temperature</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Drive Over Temperature event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.08h</b> <b>Programmable Status Mask: Parameter Restore Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Parameter Restore Error event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.09h</b> <b>Programmable Status Mask: Parameter Store Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Parameter Store Error event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.0Ah</b> <b>Programmable Status Mask: Invalid Hall State</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Invalid Hall State event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.0Bh</b> <b>Programmable Status Mask: Phase Synchronization Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Phase Synchronization Error event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.0Ch</b> <b>Programmable Status Mask: Motor Over Temperature</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Motor Over Temperature event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.0Dh</b> <b>Programmable Status Mask: Phase Detection Fault</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Phase Detection Fault event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.0Eh</b> <b>Programmable Status Mask: Feedback Sensor Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Feedback Sensor Error event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.0Fh</b> <b>Programmable Status Mask: Log Entry Missed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Log Entry Missed event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.10h</b> <b>Programmable Status Mask: Software Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Software Disable Event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.11h</b> <b>Programmable Status Mask: User Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Disable Event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.12h</b> <b>Programmable Status Mask: Positive Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Positive Limit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.13h</b> <b>Programmable Status Mask: Negative Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Negative Limit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.14h</b> <b>Programmable Status Mask: Current Limiting (Foldback)</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Current Limiting event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.15h</b> <b>Programmable Status Mask: Continuous Current Limit Reached</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Continuous Current Limit Reached event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.16h</b> <b>Programmable Status Mask: Current Loop Saturated</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to Current Loop Saturated event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.17h</b> <b>Programmable Status Mask: User Under Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the User Under Voltage event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.18h</b> <b>Programmable Status Mask: User Over Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the User Over Voltage event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.19h</b> <b>Programmable Status Mask: Non-sinusoidal Commutation</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Non-sinusoidal Commutation event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Phase Detection</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Phase Detection event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Auxiliary Disable</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Auxiliary Disable event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Shunt Regulator</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Shunt Regulator event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Phase Detection Complete</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Phase Detection Complete event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Command Limiter Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Command Limiter Active event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Motor Over Speed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Motor Over Speed event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: At Command</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the At Command event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Zero Velocity</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Zero Velocity event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Velocity Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Velocity Following Error event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Positive Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Positive Velocity Limit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Negative Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Negative Velocity Limit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Max Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Max Measured Position event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.26h</b> <b>Programmable Status Mask: Min Measured Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Min Measured Position Limit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.27h</b> <b>Programmable Status Mask: At Home Position</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the At Home Position event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.28h</b> <b>Programmable Status Mask: Position Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Position Following Error event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.29h</b> <b>Programmable Status Mask: Max Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Max Target Position Limit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.2Ah</b> <b>Programmable Status Mask: Min Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Min Target Position Limit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.2Bh</b> <b>Programmable Status Mask: Set Measured Position</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Set Measured Position event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Homing Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Homing Active event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Apply Brake</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Apply Brake event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: PVT Buffer Full</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the PVT Buffer Full event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: PVT Buffer Empty</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the PVT Buffer Empty event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: PVT Buffer Threshold</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the PVT Buffer Threshold event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: PVT Buffer Failure</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the PVT buffer failure event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.32h</b> <b>Programmable Status Mask: PVT Buffer Empty Stop Mask</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the PVT Buffer Empty Stop event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.33h</b> <b>Programmable Status Mask: PVT Sequence Number</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the PVT Sequence Number event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.34h</b> <b>Programmable Status Mask: Communication Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Communication Error Mask event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.35h</b> <b>Programmable Status Mask: Homing Complete</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Homing Complete event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.36h</b> <b>Programmable Status Mask: Commanded Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Commanded Stop event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.37h</b> <b>Programmable Status Mask: User Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the User Stop event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Bridge Enabled</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Bridge Enabled event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Dynamic Brake Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Dynamic Brake Active event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Stop Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Stop Active event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Positive Stop Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Positive Stop Active event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Negative Stop Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Negative Stop Active event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Positive Inhibit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Positive Inhibit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Negative Inhibit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Negative Inhibit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 1 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 2</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 2 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 3</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 3 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 4</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 4 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 5</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 5 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 6</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 6 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 7</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 7 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 8</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 8 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 9</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 9 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 10</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 10 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 11</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 11 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 12</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 12 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 13</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 13 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 14</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 14 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 15</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 15 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: User Bit 16</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the User Bit 16 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Capture 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Capture 1 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Capture 2</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Capture 2 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Capture 3</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Capture 3 event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Commanded Positive Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Commanded Positive Limit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Commanded Negative Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Commanded Negative Limit event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Gain Set 1 Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Gain Set 1 Active event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>Programmable Status Mask: Zero Position Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Zero Position Error event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.56h</b> Programmable Status Mask: Motion Engine Fault				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Motion Engine Fault event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.57h</b> Programmable Status Mask: Motion Engine Active				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Motion Engine Active event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.58h</b> Programmable Status Mask: Active Motion Execute				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Active Motion Execute event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.59h</b> Programmable Status Mask: Active Motion Busy				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Active Motion Busy event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.5Ah</b> Programmable Status Mask: Active Motion Active				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Active Motion Active event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.5Bh</b> Programmable Status Mask: Active Motion MotionDone				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - [2 <sup>16</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b>				
Specifies which StatusWord bit, if any, is assigned to the Active Motion MotionDone event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.5Ch</b> <b>Programmable Status Mask: Active Motion SequenceDone</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Active Motion SequenceDone event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.5Dh</b> <b>Programmable Status Mask: Active Motion Done</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Active Motion Done event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.5Eh</b> <b>Programmable Status Mask: Active Motion Aborted</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Active Motion Aborted event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.5Fh</b> <b>Programmable Status Mask: Active Motion Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the Active Motion Error event. See <a href="#">Table 2.10</a> above for mapping structure.				

<b>205B.60h</b> <b>Programmable Status Mask: PWM and Direction Broken Wire</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	N/A	Read / Write	Yes
<b>Description:</b> Specifies which StatusWord bit, if any, is assigned to the PWM and Direction Broken Wire event. See <a href="#">Table 2.10</a> above for mapping structure.				

## 208Ch: Product Information

Hardware Information																														
Data Type	Data Range	Units	Accessibility	Stored to NVM																										
String(352)	ASCII	N/A	Read Only	Yes																										
<b>Description:</b>																														
Provides all the drive information in a single 352-byte string. The meaning of each byte in the string is divided into sections according to the following table. Bytes 2 through 33 provide the "Control Board Name" for example.																														
<table border="1"> <thead> <tr> <th>Byte Definitions</th><th>Description</th></tr> </thead> <tbody> <tr><td>0..1</td><td>Reserved</td></tr> <tr><td>2..33</td><td>Control Board Name</td></tr> <tr><td>34..65</td><td>Control Board Version</td></tr> <tr><td>66..97</td><td>Control Board Serial Number</td></tr> <tr><td>98..129</td><td>Control Board Build Date</td></tr> <tr><td>130..161</td><td>Control Board Build Time</td></tr> <tr><td>162..191</td><td>Reserved</td></tr> <tr><td>192..223</td><td>Product Part Number (including revision letter)</td></tr> <tr><td>224..255</td><td>Product Version</td></tr> <tr><td>256..287</td><td>Product Serial Number</td></tr> <tr><td>288..319</td><td>Product Build Date</td></tr> <tr><td>320..351</td><td>Product Build Time</td></tr> </tbody> </table>					Byte Definitions	Description	0..1	Reserved	2..33	Control Board Name	34..65	Control Board Version	66..97	Control Board Serial Number	98..129	Control Board Build Date	130..161	Control Board Build Time	162..191	Reserved	192..223	Product Part Number (including revision letter)	224..255	Product Version	256..287	Product Serial Number	288..319	Product Build Date	320..351	Product Build Time
Byte Definitions	Description																													
0..1	Reserved																													
2..33	Control Board Name																													
34..65	Control Board Version																													
66..97	Control Board Serial Number																													
98..129	Control Board Build Date																													
130..161	Control Board Build Time																													
162..191	Reserved																													
192..223	Product Part Number (including revision letter)																													
224..255	Product Version																													
256..287	Product Serial Number																													
288..319	Product Build Date																													
320..351	Product Build Time																													

## 208Dh: Firmware Information

Firmware Version				
Data Type	Data Range	Units	Accessibility	Stored to NVM
String(32)	ASCII	N/A	Read Only	Yes
<b>Description:</b>				
Returns a 32-byte string containing the firmware version that is currently running on the drive.				

Bootloader Version				
Data Type	Data Range	Units	Accessibility	Stored to NVM
String(32)	ASCII	N/A	Read Only	Yes
<b>Description:</b>				
Returns a 32-byte string containing the bootloader version that is currently running on the drive.				

FPGA-Image Version				
Data Type	Data Range	Units	Accessibility	Stored to NVM
String(32)	ASCII	N/A	Read Only	Yes
<b>Description:</b>				
Returns a 32-byte string containing the FPGA-image version that is currently running on the drive.				

**20D8h: Power Board Information**

<b>20D8.01h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes

<b>20D8.02h</b>	<b>Name</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
String(32)	N/A	N/A	Read Only	Yes

<b>20D8.03h</b>	<b>Version</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
String(32)	N/A	N/A	Read Only	Yes

<b>20D8.04h</b>	<b>Serial Number</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
String(32)	N/A	N/A	Read Only	Yes

<b>20D8.05h</b>	<b>Build Date</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
String(32)	N/A	N/A	Read Only	Yes

<b>20D8.06h</b>	<b>Build Time</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
String(32)	N/A	N/A	Read Only	Yes

<b>20D8.07h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes

<b>20D8.08h</b>	<b>DC Bus Under Voltage</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> - 1]	PBV	Read Only	Yes

<b>20D8.09h</b>				
<b>DC Bus Over Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	PBV	Read Only	Yes

<b>20D8.0Ah</b>				
<b>Reserved</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned32	N/A	N/A	Read Only	Yes

<b>20D8.0Bh</b>				
<b>Reserved</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	N/A	N/A	Read Only	Yes

<b>20D8.0Ch</b>				
<b>Maximum Peak Current</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	PBC	Read Only	Yes

<b>20D8.0Dh</b>				
<b>Maximum Continuous Current</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	PBC	Read Only	Yes

<b>20D8.0Eh</b>				
<b>Maximum Peak Current Time</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	PBT	Read Only	Yes

<b>20D8.0Fh</b>				
<b>Maximum Peak To Continuous Current Time</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	PBT	Read Only	Yes

<b>20D8.10h</b>				
<b>Reserved</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes

<b>20D8.11h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.12h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.13h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.14h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.15h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.16h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.17h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.18h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.19h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.1Ah</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.1Bh</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes

<b>20D8.1Ch</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.1Dh</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.1Eh</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.1Fh</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.20h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	N/A	N/A	Read Only	Yes
<b>20D8.21h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.22h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.23h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes

<b>20D8.24h</b>	<b>Switching Frequency</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	PBF	Read Only	Yes

<b>20D8.25h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes

<b>20D8.26h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.27h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.28h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.29h</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.2Ah</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes
<b>20D8.2Bh</b>	<b>Reserved</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	Yes

## 2.5 Drive Operation Objects

The following objects are typically used during operation. They are either used to perform specific tasks or to obtain information from the drive. These objects have been divided into the following three categories: Control Objects, Command Objects, and Monitor Objects.

### 2.5.1 Control Objects

#### 6040h: ControlWord

ControlWord				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - 65535	N/A	Read / Write	No
<b>Description:</b>				
The ControlWord object sets the control state machine in the drive. “State Machine Overview” on page 35 explains each drive state and how to use the ControlWord to move the drive to that state. Below is a table providing the basic ControlWord commands.				
Value (Hex)	Command	Description		
80	Reset Fault	On any transition to "1" of bit 7 causes a Reset Fault		
04	Disable Voltage	Drive in "Switch On Disabled" state		
06	Shutdown	Drive in "Ready to Switch On" state		
07	Switch On	Drive in "Switched On" state		
0F	Enable Operation	Drive in "Operation Enabled" state		
02	Stop	Drive in "Stop Active" state		
1F	Start Homing	Starts Homing (when in homing mode)		
0F	End Homing	Ends Homing		

See “ControlWord (6040h)” on page 38 for more information on this subject.

## 2001h: Control Parameters

Drive Control Word 0				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – 1FFFh	N/A	Read/Write*	No

**Description:**

This bit field enables/disables certain drive functions according to the table below.

Bit	Name	Description
0	Software Disable	Causes the bridge to be disabled.
1	Zero Position Error	Sets the target position equal to the measured position.
2	Phase Detect	Activates the phase detection routine.
3	Set Position	Causes the position counter to be loaded with the preset position value.
4	Motion Engine Enable	Causes the auxiliary input command counter to be loaded with the preset command value.
5	Home Execute	Causes the homing routine to be active.
6	Commanded Stop	Causes the drive to stop.
7	Capture 1 Arm	A change from 0 to 1 arms/rearms Capture unit 1. A change from 1 to 0 Disarms it.
8	Capture 2 Arm	A change from 0 to 1 arms/rearms Capture unit 2. A change from 1 to 0 Disarms it.
9	Capture 3 Arm	A change from 0 to 1 arms/rearms Capture unit 3. A change from 1 to 0 Disarms it.
10	Commanded Positive Limit	Activates positive limiting.
11	Commanded Negative Limit	Activates negative limiting.
12	Reset Events	Resets all but the following events: Current Overshoot, Parameter Restore Error, Parameter Store Error, Phase Detection Failure, Software Disable
13-15	Reserved	Read as zero / write as zero.

<b>Drive Control Word 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 1FFFh	N/A	Read/Write*	No
<b>Description:</b>				
This bit field enables/disables certain drive functions according to the table below.				
<b>Bit</b>	<b>Name</b>	<b>Description</b>		
0	Gain Parameters Set	A change from 0 to 1 selects Gain Set 1. A change from 1 to 0 selects Gain Set 0.		
1	Command Limiter Parameters Set	A change from 0 to 1 selects Command Limiter Set 1. A change from 1 to 0 selects Command Limiter Set 0.		
2	Command Source Modifier Set	A change from 0 to 1 selects Source Modifier Set 1. A change from 1 to 0 selects Source Modifier Set 0.		
3	Jog Plus	Writing a 1 asserts Jog Plus. Writing a 0 deasserts Jog Plus.		
4	Jog Minus	Writing a 1 asserts Jog Minus. Writing a 0 deasserts Jog Minus.		
5	Jog Select	Writing a 1 selects the Jog 1 Speed. Writing a zero selects the Jog 0 Speed.		
6-15	Reserved	Read as zero / write as zero.		

<b>User Bit Control</b>																																						
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>																																		
Unsigned16	0 – FFFFh	N/A	Read / Write	No																																		
<b>Description:</b>																																						
Toggles the User Bits on or off by assigning a 1 or 0 to the appropriate bit. See the table below for bit assignment. Note that User Bits can be mapped to digital outputs through the configuration software or by directly configuring command 2024h.																																						
<table border="1"> <thead> <tr> <th><b>Bit</b></th><th><b>Assignment (1 = asserted, 0 = not asserted)</b></th></tr> </thead> <tbody> <tr><td>0</td><td>User Bit #1</td></tr> <tr><td>1</td><td>User Bit #2</td></tr> <tr><td>2</td><td>User Bit#3</td></tr> <tr><td>3</td><td>User Bit #4</td></tr> <tr><td>4</td><td>User Bit #5</td></tr> <tr><td>5</td><td>User Bit #6</td></tr> <tr><td>6</td><td>User Bit #7</td></tr> <tr><td>7</td><td>User Bit #8</td></tr> <tr><td>8</td><td>User Bit #9</td></tr> <tr><td>9</td><td>User Bit #10</td></tr> <tr><td>10</td><td>User Bit #11</td></tr> <tr><td>11</td><td>User Bit #12</td></tr> <tr><td>12</td><td>User Bit #13</td></tr> <tr><td>13</td><td>User Bit #14</td></tr> <tr><td>14</td><td>User Bit #15</td></tr> <tr><td>15</td><td>User Bit #16</td></tr> </tbody> </table>					<b>Bit</b>	<b>Assignment (1 = asserted, 0 = not asserted)</b>	0	User Bit #1	1	User Bit #2	2	User Bit#3	3	User Bit #4	4	User Bit #5	5	User Bit #6	6	User Bit #7	7	User Bit #8	8	User Bit #9	9	User Bit #10	10	User Bit #11	11	User Bit #12	12	User Bit #13	13	User Bit #14	14	User Bit #15	15	User Bit #16
<b>Bit</b>	<b>Assignment (1 = asserted, 0 = not asserted)</b>																																					
0	User Bit #1																																					
1	User Bit #2																																					
2	User Bit#3																																					
3	User Bit #4																																					
4	User Bit #5																																					
5	User Bit #6																																					
6	User Bit #7																																					
7	User Bit #8																																					
8	User Bit #9																																					
9	User Bit #10																																					
10	User Bit #11																																					
11	User Bit #12																																					
12	User Bit #13																																					
13	User Bit #14																																					
14	User Bit #15																																					
15	User Bit #16																																					

## 6060h: Modes Of Operation

Modes Of Operation																												
Data Type	Data Range	Units	Accessibility	Stored to NVM																								
Integer8	-128 - 127	N/A	Read / Write	No																								
<b>Description:</b>																												
This object indicates the requested mode of operation. This may differ from the actual mode of operation if the mode change is not yet possible (for example, if the mode change is requested while the drive is in the operation enabled state). The actual mode of operation can be found using the read-only object 6061. <a href="#">"Modes of Operation" on page 48</a> explains the valid control loop configurations for an AMC CANopen servo drive.																												
<table border="1"> <thead> <tr> <th>Value</th><th>Operation Mode</th></tr> </thead> <tbody> <tr><td>1</td><td>Profile Position Mode</td></tr> <tr><td>3</td><td>Profile Velocity Mode</td></tr> <tr><td>4</td><td>Profile Torque Mode (current mode)</td></tr> <tr><td>6</td><td>Homing Mode</td></tr> <tr><td>7</td><td>Interpolated Position Mode (PVT)</td></tr> <tr><td>8</td><td>Cyclic Synchronous Position Mode</td></tr> <tr><td>9</td><td>Cyclic Synchronous Velocity Mode</td></tr> <tr><td>A</td><td>Cyclic Synchronous Torque Mode (current mode)</td></tr> <tr><td>9E</td><td>Config 0</td></tr> <tr><td>DE</td><td>Config 1</td></tr> <tr><td>FF</td><td>None (Use active configuration settings)</td></tr> </tbody> </table>					Value	Operation Mode	1	Profile Position Mode	3	Profile Velocity Mode	4	Profile Torque Mode (current mode)	6	Homing Mode	7	Interpolated Position Mode (PVT)	8	Cyclic Synchronous Position Mode	9	Cyclic Synchronous Velocity Mode	A	Cyclic Synchronous Torque Mode (current mode)	9E	Config 0	DE	Config 1	FF	None (Use active configuration settings)
Value	Operation Mode																											
1	Profile Position Mode																											
3	Profile Velocity Mode																											
4	Profile Torque Mode (current mode)																											
6	Homing Mode																											
7	Interpolated Position Mode (PVT)																											
8	Cyclic Synchronous Position Mode																											
9	Cyclic Synchronous Velocity Mode																											
A	Cyclic Synchronous Torque Mode (current mode)																											
9E	Config 0																											
DE	Config 1																											
FF	None (Use active configuration settings)																											

## 2.5.2 Command Objects

### 6071h: Target Current

Target Current				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	$-2^{15} - (2^{15}-1)$	DC2	Read / Write	No
<b>Description:</b>				
Sets the Target Current while in Current Mode (set by object 6060h). See <a href="#">"Appendix" on page 283</a> for units conversion.				

### 60FFh: Target Velocity

Target Velocity				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$-2^{31} - (2^{31}-1)$	DS1	Read / Write	No
<b>Description:</b>				
Use this object to set the Target Velocity when the drive is in Velocity mode. See <a href="#">"Appendix" on page 283</a> for unit conversion.				

### 607Ah: Target Position

Target Position				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$-2^{31} - (2^{31}-1)$	counts	Read / Write	No
<b>Description:</b>				
Sets the Target Position value while in position mode (set by object 6060h). This is the target position before limiting and profiling is applied. Position error is derived from demanded position, which is this signal after limiting and profiling is applied.				

### 60B1h: Velocity Offset

Velocity Offset				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	$-2^{31} - (2^{31}-1)$	DS1	Read / Write	No
<b>Description:</b>				
Contains a value corresponding to offset for the target velocity value. Used with cyclic synchronous position and cyclic synchronous velocity modes. In cyclic synchronous position mode, this object contains the input value for velocity feed forward. In cyclic synchronous velocity mode it contains the commanded velocity offset.				

### 60B2h: Current Offset

Current Offset				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	$-2^{14} - (2^{14}-1)$	DC2	Read / Write	No
<b>Description:</b>				
Contains a value corresponding to offset for the target current value. Used with cyclic synchronous modes of operation. In cyclic synchronous position mode and cyclic synchronous velocity mode, this object contains the input value for current feed forward. In cyclic synchronous torque mode it contains the commanded current offset.				

**2045h: Interface Inputs** Interface inputs can be used in place of analog inputs for any function that can be assigned to an analog input. Examples of this include command source, feedback source, and motor temperature source. The units for interface inputs are dependent upon the function the interface input is assigned to as given in [Table 2.11](#). For details on unit conversion see [“Appendix” on page 283](#).

**TABLE 2.11** Interface Input Units

Interface Input Function	Units
Position Command Source	counts
Velocity Command Source	DS1
Torque/Current Command Source	DC2
Position Feedback Source	counts
Velocity Feedback Source	DS1
Motor Temperature Source	DT1

Interface Input 1				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	See Table 2.11	Read / Write	No
<b>Description:</b>				
Defines the value used with interface input 1.				

Interface Input 2				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	See Table 2.11	Read / Write	No
<b>Description:</b>				
Defines the value used with interface input 2.				

Interface Input 3				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	See Table 2.11	Read / Write	No
<b>Description:</b>				
Defines the value used with interface input 3.				

Interface Input 4				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$[-2^{(31)}] - [2^{(31)} - 1]$	See Table 2.11	Read / Write	No
<b>Description:</b>				
Defines the value used with interface input 4.				

## 2.5.3 Motion Engine Command Objects

### 20C9h: Motion Engine Control

Start-Up Motion Type				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – [2 <sup>16</sup> – 1]	N/A	Read / Write	Yes
<b>Description:</b>				
Defines the startup behavior when running a motion engine index upon power-up. The bit values are broken up as defined below.				
<b>Bits 0:15 - Enumerated values</b>				
0: Select Motion (This enum is only used when motion is initiated via a digital input.)				
1: Initiate Selected Motion (Run the index specified in the Motion Engine Control Data)				
2: Abort Active Motion (No fault, Motion Engine will return to ready for motion start)				
3: Reset Motion Engine Fault and return to the ready for motion state				
4: Initiate Dynamic Index				
5: Set Motion Select Source				
6-15: Reserved				
<b>Bits 16:31 - This is the data that is associated with each of the action enums above. The allowable values for each enum are as follows</b>				
0: Select Index - When the communication channel is the motion select source, the valid range is [0,15], otherwise it is an error				
1: Initiate Selected Motion - When the communication channel is the motion select source, this value will be the motion that is initiated. Otherwise it will be ignored.				
2: Abort Active Motion - Values are ignored				
3: Reset Motion Engine - Values are ignored				
4: Initiate Dynamic Index - Values are ignored				
5: Set Motion Select Source - 0:Hardware, 1:Communication Channel - all other values are invalid				
6: Load Program Page - When the communication channel is the motion select source				
7-15: Reserved				

### 20CAh: Dynamic Index Data

Move Index				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 - FFFFh	-	Read / Write	No
<b>Description:</b>				
When defining a dynamic index, this value should be set to 0x0020.				

<b>Move Type</b>										
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>						
Unsigned16	0 - FFFFh	-	Read / Write	No						
<b>Description:</b> Defines the type of move.										
<table border="1"> <thead> <tr> <th><b>Value</b></th><th><b>Move Type</b></th></tr> </thead> <tbody> <tr> <td>0x0008</td><td>Absolute</td></tr> <tr> <td>0x0018</td><td>Relative</td></tr> </tbody> </table>					<b>Value</b>	<b>Move Type</b>	0x0008	Absolute	0x0018	Relative
<b>Value</b>	<b>Move Type</b>									
0x0008	Absolute									
0x0018	Relative									

<b>Repeat Count</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	-	Read / Write	No
<b>Description:</b> Specifies the number of times to repeat the move. Only valid for relative moves.				

<b>Dwell Time</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	milliseconds (ms)	Read / Write	No
<b>Description:</b> Specifies the time after the move is complete before the Index Done status becomes active.				

<b>Position Target - Word 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	counts	Read / Write	No
<b>Description:</b> The least significant word in the 2-word (32-bit) position command. Depending on the assigned move type, will apply to an absolute or relative position target.				

<b>Position Target - Word 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	counts	Read / Write	No
<b>Description:</b> The most significant word in the 2-word (32-bit) position command. Depending on the assigned move type, will apply to an absolute or relative position target.				

<b>Max Velocity - Word 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	DS3	Read / Write	No
<b>Description:</b>				
The least significant word in the 4-word (64-bit) maximum velocity value. See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>Max Velocity - Word 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	DS3	Read / Write	No
<b>Description:</b>				
The second word in the 4-word (64-bit) maximum velocity value. See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>Max Velocity - Word 2</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	DS3	Read / Write	No
<b>Description:</b>				
The third word in the 4-word (64-bit) maximum velocity value. See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>Max Velocity - Word 3</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	DS3	Read / Write	No
<b>Description:</b>				
The most significant word in the 4-word (64-bit) maximum velocity value. See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>Max Acceleration - Word 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	DS3	Read / Write	No
<b>Description:</b>				
The least significant word in the 2-word (32-bit) maximum acceleration value. See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>Max Acceleration - Word 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	DA5	Read / Write	No
<b>Description:</b>				
The most significant word in the 2-word (32-bit) maximum acceleration value. See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>20CA.0Dh</b>				
<b>Max Deceleration - Word 0</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	DA5	Read / Write	No
<b>Description:</b>				
The least significant word in the 2-word (32-bit) maximum deceleration value. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>20CA.0Eh</b>				
<b>Max Deceleration - Word 1</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - FFFFh	DA5	Read / Write	No
<b>Description:</b>				
The most significant word in the 2-word (32-bit) maximum deceleration value. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>20CA.0Fh - 20CA.1Ch</b>				
<b>Reserved</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	-	-	-	No

## 2.5.4 Monitor Objects

### 6041h: StatusWord

<b>6041h</b>				
<b>StatusWord</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - 655535	N/A	Read Only	No

**Description:**

The StatusWord is used to determine which state the drive is in. “[Drive States](#)” on page 36 explains each drive’s state and the StatusWord bit definitions. Below is a table of the hex values for each state.

<b>Value</b>	<b>State</b>	<b>Description</b>
xxxx xxxx x0xx 0000	Not Ready to Switch On	Drive is initializing, drive is disabled
xxxx xxxx x1xx 0000	Switch On Disabled	Drive completed initialization, drive is disabled
xxxx xxxx x01x 0001	Ready to Switch On	Bus power may be applied, drive is disabled
xxxx xxxx x01x 0011	Switched On	Bus power is applied, drive is disabled
xxxx xxxx x01x 0111	Operation Enabled	Drive is enabled
xxxx xxxx x0xx 1000	Fault	Drive is in the fault state
xxxx xxxx x00x 0111	Stop Active	Stop received from host and now in this state

**20EC<sub>h</sub>: NMT State**

NMT State				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – [2(16)-1]	N/A	Read Only	No
<b>Description:</b>				
Contains the NMT State. For more information, see “NMT Error Control” on page 7.				

**2002<sub>h</sub>: Drive Status**

Drive Bridge Status				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	N/A	N/A	Read Only	No
<b>Description:</b>				
The function of each bit is given in <a href="#">Table 2.12</a> below.				

Drive Protection Status				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	N/A	N/A	Read Only	No
<b>Description:</b>				
The function of each bit is given in <a href="#">Table 2.12</a> below.				

System Protection Status				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	N/A	N/A	Read Only	No
<b>Description:</b>				
The function of each bit is given in <a href="#">Table 2.12</a> below.				

Drive/System Status 1				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	N/A	N/A	Read Only	No
<b>Description:</b>				
The function of each bit is given in <a href="#">Table 2.12</a> below.				

<b>Drive/System Status 2</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	No
<b>Description:</b>				
The function of each bit is given in <a href="#">Table 2.12</a> below.				

<b>Drive/System Status 3</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	No
<b>Description:</b>				
The function of each bit is given in <a href="#">Table 2.12</a> below.				

<b>Active Algorithm Status</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only	No
<b>Description:</b>				
The function of each bit is given in <a href="#">Table 2.12</a> below.				

**TABLE 2.12** Drive Status bit-field definitions

<b>Bit</b>	<b>Drive Bridge Status</b>	<b>Drive Protection Status</b>	<b>System Protection Status</b>	<b>Drive System Status 1</b>	<b>Drive System Status 2</b>	<b>Drive System Status 3</b>	<b>Active Algorithm Status</b>
0	Bridge Enabled	Drive Reset	Parameter Restore Error	Log Entry Missed	Zero Velocity	PVT Buffer Full	Absolute Position Valid
1	Dynamic Brake Enabled	Drive Internal Error	Parameter Store Error	Software Disable	At Command	PVT Buffer Empty	Positive Stop Active
2	Stop Enabled	Short Circuit	Invalid Hall State	User Disable	Velocity Following Error	PVT Buffer Threshold	Negative Stop Active
3	Positive Stop Enabled	Current Overshoot	Phase Sync. Error	User Positive Inhibit	Positive Target Velocity Limit	PVT Buffer Failure	Reserved
4	Negative Stop Enabled	Under Voltage	Motor Over Temperature	User Negative Inhibit	Negative Target Velocity Limit	PVT Buffer Empty Stop	Reserved
5	Positive Torque Inhibit Active	Over Voltage	Phase Detection Fault	Current Limiting	Command Limiter Active	PVT Buffer Sequence Error	Reserved
6	Negative Torque Inhibit Active	Drive Over Temperature	Feedback Sensor Error	Continuous Current	In Home Position	Commanded Stop	Reserved
7	External Brake Active	Reserved	Motor Over Speed	Current Loop Saturated	Position Following Error	User Stop	Reserved
8	Reserved	Reserved	Max Measured Position	User Under Voltage	Max Target Position Limit	Capture 1 Triggered	Reserved
9	Reserved	Reserved	Min Measured Position	User Over Voltage	Min Target Position Limit	Capture 2 Triggered	Reserved
10	Reserved	Reserved	Comm. Error (Node Guarding)	Non-sinusoidal Commutation	Set Position	Capture 3 Triggered	Reserved
11	Reserved	Reserved	PWM Input Broken Wire	Phase Detection	Reserved	Commanded Positive Limit	Reserved
12	Reserved	Reserved	Reserved	Reserved	Homing Active	Commanded Negative Limit	Reserved
13	Reserved	Reserved	Reserved	User Auxiliary Disable	Reserved	Reserved	Reserved
14	Reserved	Reserved	Reserved	Shunt Regulator	Homing Complete	Reserved	Reserved
15	Reserved	Reserved	Reserved	Phase Detection Complete	Zero Position Error	Reserved	Reserved

## 2003h: Drive Status History

Drive Bridge Status History				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	N/A	N/A	Read Only*	No
<b>Description:</b>				
If an event becomes active and then becomes inactive, Drive Status History will mark the event with a history bit. If a bit is 1, that event has occurred sometime in the past; 0 indicates the event has never occurred since power-up. The function of each bit is given in <a href="#">Table 2.12</a> of object 2002h.				
*Features a Read / Write function, in that any history bit can be cleared by writing a 1 to that bit.				

Drive Protection Status History				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	N/A	N/A	Read Only*	No
<b>Description:</b>				
If an event becomes active and then becomes inactive, Drive Status History will mark the event with a history bit. If a bit is 1, that event has occurred sometime in the past; 0 indicates the event has never occurred since power-up. The function of each bit is given in <a href="#">Table 2.12</a> of object 2002h.				
*Features a Read / Write function, in that any history bit can be cleared by writing a 1 to that bit.				

System Protection Status History				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	N/A	N/A	Read Only*	No
<b>Description:</b>				
If an event becomes active and then becomes inactive, Drive Status History will mark the event with a history bit. If a bit is 1, that event has occurred sometime in the past; 0 indicates the event has never occurred since power-up. The function of each bit is given in <a href="#">Table 2.12</a> of object 2002h.				
*Features a Read / Write function, in that any history bit can be cleared by writing a 1 to that bit.				

Drive/System Status 1 History				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	N/A	N/A	Read Only*	No
<b>Description:</b>				
If an event becomes active and then becomes inactive, Drive Status History will mark the event with a history bit. If a bit is 1, that event has occurred sometime in the past; 0 indicates the event has never occurred since power-up. The function of each bit is given in <a href="#">Table 2.12</a> of object 2002h.				
*Features a Read / Write function, in that any history bit can be cleared by writing a 1 to that bit.				

<b>Drive/System Status 2 History</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only*	No
<b>Description:</b>				
If an event becomes active and then becomes inactive, Drive Status History will mark the event with a history bit. If a bit is 1, that event has occurred sometime in the past; 0 indicates the event has never occurred since power-up. The function of each bit is given in <a href="#">Table 2.12</a> of object 2002h.				
*Features a Read / Write function, in that any history bit can be cleared by writing a 1 to that bit.				

<b>Drive/System Status 3 History</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	N/A	N/A	Read Only*	No
<b>Description:</b>				
If an event becomes active and then becomes inactive, Drive Status History will mark the event with a history bit. If a bit is 1, that event has occurred sometime in the past; 0 indicates the event has never occurred since power-up. The function of each bit is given in <a href="#">Table 2.12</a> of object 2002h.				
*Features a Read / Write function, in that any history bit can be cleared by writing a 1 to that bit.				

## 2029h: Motion Engine Status

<b>Active Sequence</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
N/A	-2 - 15	N/A	Read Only	No
<b>Description:</b>				
Displays the active sequence number when using motion engine sequencing.				
<b>Bits 0:7</b>				
0-15 for index 0 to 15				
FE: Dynamic Index				
FF: No Invalid Index				
<b>Bits 8:15</b>				
Reserved				

<b>Reserved</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
N/A	-	-	Read Only	No

<b>Reserved</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
N/A	-	-	Read Only	No

<b>Motion Engine Status</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
N/A	0 - 9	N/A	Read Only	No

**Description:**

Defines the present state of the motion engine.

<b>Value</b>	<b>Motion Engine State</b>
0	Inactive
1	Waiting for Motion Start (Motion Engine is enabled and ready for an index)
2	Executing Motion (Index is currently running)
3	Program Load in Progress (Motion Engine is not ready for commanded index)
4	Program Load Failure - CRC Error (Problem loading Index. Must reset Motion Engine to continue)
5	Invalid Data Parameter (Problem loading Index. Must reset Motion Engine to continue)
6	Invalid Op-Code (Problem loading Index. Must reset Motion Engine to continue)
7	Halt Asserted (Motion has been interrupted)
8	Invalid Reference Frame (Problem with index parameters)
9	Invalid Bridge State (Bridge must be enabled to begin indexed motion)
10	Invalid Op-code for Dynamic Motion (Problem with index parameters)
11	User Defined Fault
12	Single Step Complete
13	Break Point Active

## 6061h: Modes Of Operation Display

Modes Of Operation Display																								
Data Type	Data Range	Units	Accessibility	Stored to NVM																				
Integer8	-128 - 127	N/A	Read Only	No																				
<b>Description:</b>																								
A “Mode Of Operation” refers to how the drive’s internal control loops are configured. <a href="#">“Modes of Operation” on page 48</a> explains the valid control loop configurations for an AMC CANopen servo drive.																								
<table border="1"> <thead> <tr> <th>Value</th><th>Operation Mode</th></tr> </thead> <tbody> <tr><td>1</td><td>Profile Position Mode</td></tr> <tr><td>3</td><td>Profile Velocity Mode</td></tr> <tr><td>4</td><td>Profile Torque Mode (current mode)</td></tr> <tr><td>6</td><td>Homing Mode</td></tr> <tr><td>7</td><td>Interpolated Position Mode (PVT)</td></tr> <tr><td>8</td><td>Cyclic Synchronous Position Mode</td></tr> <tr><td>9</td><td>Cyclic Synchronous Velocity Mode</td></tr> <tr><td>A</td><td>Cyclic Synchronous Torque Mode</td></tr> <tr><td>FF</td><td>Custom Configured Modes</td></tr> </tbody> </table>					Value	Operation Mode	1	Profile Position Mode	3	Profile Velocity Mode	4	Profile Torque Mode (current mode)	6	Homing Mode	7	Interpolated Position Mode (PVT)	8	Cyclic Synchronous Position Mode	9	Cyclic Synchronous Velocity Mode	A	Cyclic Synchronous Torque Mode	FF	Custom Configured Modes
Value	Operation Mode																							
1	Profile Position Mode																							
3	Profile Velocity Mode																							
4	Profile Torque Mode (current mode)																							
6	Homing Mode																							
7	Interpolated Position Mode (PVT)																							
8	Cyclic Synchronous Position Mode																							
9	Cyclic Synchronous Velocity Mode																							
A	Cyclic Synchronous Torque Mode																							
FF	Custom Configured Modes																							

## 200Eh: Feedback Sensor Values

Primary Encoder Counts				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	counts	Read Only	No
<b>Description:</b>				
Contains the current number of encoder counts from the primary encoder. It is an absolute value in that it does not depend on the current load measured position or home values.				

Latched Encoder/Resolver Position				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned32	$0 - [2^{(32)}-1]$	counts	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the latched encoder/resolver position.				

Commutation Synchronization Counts				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	counts	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the commutation synchronization counts.				

<b>Hall Sensor Values</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the Hall sensor values.				

## 2027h: Feedback Hardware Diagnostics

<b>Sin/Cos Encoder Sine</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	[–2 <sup>(15)</sup> ] – [2 <sup>(15)</sup> – 1]	Volts (SF1)	Read Only	No
<b>Description:</b>				
Represents the differential voltage of the +/- sine input of a 1V peak-to-peak encoder. Only applicable to drives that support Sin/Cos encoders. See “Appendix” on page 283 for information on scaling.				

<b>Sin/Cos Encoder Cosine</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	[–2 <sup>(15)</sup> ] – [2 <sup>(15)</sup> – 1]	Volts (SF1)	Read Only	No
<b>Description:</b>				
Represents the differential voltage of the +/- cosine input of a 1V peak-to-peak encoder. Only applicable to drives that support Sin/Cos encoders. See “Appendix” on page 283 for information on scaling.				

<b>Sin/Cos Encoder Health</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	[–2 <sup>(15)</sup> ] – [2 <sup>(15)</sup> – 1]	Volts (SF1)	Read Only	No
<b>Description:</b>				
Represents the health of the Sin/Cos encoder inputs according the formula below, where a value closer to 1 is healthy and a value closer to 0 is unhealthy. See “Appendix” on page 283 for information on scaling.				
Encoder Health = $\text{Sin}^2 + \text{Cos}^2$				

<b>Absolute Encoder Fault Word</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 – [2 <sup>16</sup> – 1]	N/A	Read Only	No

**Description:**

Contains a value that corresponds to an absolute encoder fault code. Fault codes are listed below by encoder type. The drive checks for faults and attempts to clear them during a phase detection routine. If a fault cannot be cleared, the appropriate fault code will be given by this sub-index and the drive will activate a feedback sensor error.

**Hiperface (Stegmann):**

<b>Status Value</b>	<b>Status Name</b>
00h	No Error
01h	Analog signals outside of specification
02h	Internal angle offset erroneous
03h	Data field partition destroyed
04h	Analog limit is not available
05h	Internal I <sup>2</sup> C is not serviceable
06h	Internal checksum error
07h	Encoder reset occurred
08h	Counter overflow
09h	Parity error
0Ah	Checksum of transmitted data is wrong
0Bh	Unknown command code
0Ch	Number of data transmitted is wrong
0Dh	Command argument transmitted is impermissible
0Eh	Data may not be written to the data field selected
0Fh	Wrong access code
10h	Size of specified data field cannot be changed
11h	Specified word address outside data field
12h	Access to non-existent data field
1Ch	Monitoring the magnitude of the analog signals
1Dh	Critical encoder current
1Eh	Critical encoder temperature
1Fh	Speed too high, position information not possible
20h	Position of single turn impermissible
21h	Position error, multi-turn
22h	Position error, multi-turn
23h	Position error, multi-turn
28h	Error absolute value formation linear measuring system

**EnDat (Heidenhein):**

<b>Bit</b>	<b>Fault Name</b>
0	Light Source
1	Signal Amplitude
2	Position Value
3	Over Voltage
4	Under Voltage
5	Over Current
6	Battery
7-15	RFU

<b>Reserved</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 – [2 <sup>(16)</sup> –1]	N/A	Read Only	No
<b>Reserved</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 – [2 <sup>(16)</sup> –1]	N/A	Read Only	No

### **201Ch: Gearing Values**

<b>Gear Input</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[-2 <sup>(31)</sup> ] – [2 <sup>(31)</sup> -1]	Counts	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the number of encoder counts sent to the gearing module.				

<b>Present Gear Input Counts</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> -1]	N/A	Read Only	No
<b>Description:</b>				
Value corresponding to the denominator of the gear ratio.				

<b>Present Gear Output Counts</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> -1]	N/A	Read Only	No
<b>Description:</b>				
Value corresponding to the numerator of the gear ratio.				

### **201Eh: Auxiliary Encoder Value**

<b>Auxiliary Encoder Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	-2 <sup>31</sup> – (2 <sup>31</sup> -1)	Counts	Read Only	No
<b>Description:</b>				
Contains the raw number of counts seen on the auxiliary encoder input. This value resets to zero when the drive is power-cycled.				

<b>Auxiliary Position Index Capture Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$-2^{31} - (2^{31}-1)$	counts	Read Only	No
<b>Description:</b>				
Contains the position of the last auxiliary encoder index captured by the drive. Requires auxiliary encoder with index.				

### **6077h: Actual Current**

<b>Actual Current</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$-2^{15} - (2^{15}-1)$	DC1	Read Only	No
<b>Description:</b>				
Contains the instantaneous current applied to the motor. See " <a href="#">Appendix</a> " on page 283 for units conversion.				

### **2010h: Current Values**

<b>Current Target - Torque</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DC2	Read Only	No
<b>Description:</b>				
Contains the value of the target current (torque-producing). See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>Current Demand - Torque</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DC1	Read Only	No
<b>Description:</b>				
Contains the value of the demand current (torque-producing). See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>Current Measured - Torque</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DC1	Read Only	No
<b>Description:</b>				
Contains the value of the measured current (torque-producing). See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>2010.04h</b>				
<b>Current Error - Torque</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DC1	Read Only	No
<b>Description:</b>				
Contains the error between the target current and the measured current (torque-producing). This is equivalent to: demand current minus measured current. When the demand current is reached, the current error is zero. See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>2010.05h</b>				
<b>Current Target - Flux</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DC2	Read Only	No
<b>Description:</b>				
Contains the value of the target current (flux-producing). See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>2010.06h</b>				
<b>Current Demand - Flux</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DC1	Read Only	No
<b>Description:</b>				
Contains the value of the demand current (flux-producing). See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>2010.07h</b>				
<b>Current Measured - Flux</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DC1	Read Only	No
<b>Description:</b>				
Contains the value of the measured current (flux-producing). See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>2010.08h</b>				
<b>Current Error - Flux</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DC1	Read Only	No
<b>Description:</b>				
Contains the value of the Current error (flux-producing). See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>2010.09h</b>				
<b>Current Target - Flux Reference</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DC2	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the Current target flux reference. See " <a href="#">Appendix</a> " on page 283 for unit conversion.				

<b>2010.0Ah</b>				
<b>Current Demand - Flux Reference</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	N/A	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the current demand flux reference.				

<b>2010.0Bh</b>				
<b>Current Measured - Flux Reference</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	N/A	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the current measured flux reference.				

<b>2010.0Ch</b>				
<b>Current Error - Flux Reference</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	N/A	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the current error flux reference.				

<b>2010.0Dh</b>				
<b>Current Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	N/A	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the current limit.				

<b>2010.0Eh</b>				
<b>Current Measured - Phase A</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DC1	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the current measured in phase A. See “Appendix” on page 283 for unit conversion.				

<b>2010.0Fh</b>				
<b>Current Measured - Phase B</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DC1	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the current measured in phase B. See “Appendix” on page 283 for unit conversion.				

<b>Phase Angle - Rotor</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 359	DG1	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the Phase Angle – Rotor. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Phase Angle - Stator</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 359	DG1	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the Phase Angle – Stator. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Torque Summation Input</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DC2	Read Only	No
<b>Description:</b>				
Contains the raw current command before filtering or an offset has been applied. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Torque Summation Offset</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DC2	Read Only	No
<b>Description:</b>				
Contains the offset of the commanded current in the current loop. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

## 606Bh: Velocity Demand

<b>Velocity Demand</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$-2^{31} - (2^{31}-1)$	DS1	Read Only	No
<b>Description:</b>				
Velocity Demand is defined as the target velocity, after limits and profiling, which is applied to the signal. This is the signal used by the velocity loop to produce a velocity error signal. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

**606Ch: Actual Velocity**

Actual Velocity				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$-2^{31} - (2^{31}-1)$	DS1	Read Only	No
<b>Description:</b>				
Actual Velocity is defined as the measured velocity, after conditioning, used to close the drive's velocity loop. See " <a href="#">Appendix</a> " on page <a href="#">283</a> for unit conversion.				

**606Dh: Velocity Window**

Velocity Window				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	$0 - [2^{16} - 1]$	DS1	Read / Write	No
<b>Description:</b>				
The maximum allowed difference between the target velocity and the velocity actual value. Bit 10 of the statusword shall be set to 1 ( <i>target reached</i> ) when the difference between the target velocity and velocity actual value is within the velocity window longer than the velocity window time. See " <a href="#">Appendix</a> " on page <a href="#">283</a> for unit conversion.				

**606Eh: Velocity Window Time**

Velocity Window Time				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	$0 - [2^{15} - 1]$	ms	Read / Write	Yes
<b>Description:</b>				
The time delay after the occurrence of Velocity Following Error before its Event Action (2065h) is executed. The functionality of this object is identical to that of manufacturer-specific object 2064.12h.				

**6069h: Velocity Sensor Actual Value**

Velocity Sensor Actual Value				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer32	$-2^{31} - (2^{31}-1)$	DS1	Read Only	No
<b>Description:</b>				
The value read from this object is the velocity measured directly from the primary feedback device before filtering or conditioning is applied. To read the actual velocity value used by the velocity control loop, see " <a href="#">606Ch: Actual Velocity</a> ". See " <a href="#">Appendix</a> " on page <a href="#">283</a> for unit conversion.				

**2011h: Velocity Values**

<b>Velocity Measured Pre-Filter</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DS1	Read Only	No
<b>Description:</b>				
Contains the measured velocity before the feedback cutoff filter. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Velocity Measured Post-Filter</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DS1	Read Only	No
<b>Description:</b>				
Contains the measured velocity after the feedback cutoff filter. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Velocity Target</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DS1	Read Only	No
<b>Description:</b>				
Contains the current velocity target when the drive is in velocity mode. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Velocity Demand</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DS1	Read Only	No
<b>Description:</b>				
Contains the current velocity demand when the drive is in velocity mode. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Velocity Loop Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DS1	Read Only	No
<b>Description:</b>				
Contains the error between the target velocity and the measured velocity. This is equivalent to target velocity minus measured velocity. When the current commanded velocity is reached, the velocity loop error will be zero. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Velocity Summation Input</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DS1	Read Only	No
<b>Description:</b>				
Contains the raw velocity command before filtering or an offset has been applied. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

<b>Velocity Summation Offset</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)-1}]$	DS1	Read Only	No
<b>Description:</b>				
Contains the offset of the commanded velocity in the velocity loop. See “ <a href="#">Appendix</a> ” on page 283 for unit conversion.				

### **6064h: Actual Position**

<b>Actual Position</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$-2^{31} - (2^{31}-1)$	counts	Read Only	No
<b>Description:</b>				
Position Actual Value contains the measured position of the primary feedback device. This is the actual value used to create position error in position mode.				

### **2012h: Position Values**

<b>Position Measured</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)-1}]$	counts	Read Only	No
<b>Description:</b>				
Contains the current measured position in counts.				

<b>Position Target</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)-1}]$	counts	Read Only	No
<b>Description:</b>				
Contains the current commanded position when the drive is used in the position mode.				

<b>Position Demand</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)-1}]$	counts	Read Only	No
<b>Description:</b>				
Contains the current position demand in counts.				

<b>Position Loop Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	counts	Read Only	No
<b>Description:</b>				
Contains the error between the target position (in counts) and the measured position (in counts). This is equivalent to target position (counts) minus measured position (counts). When the current commanded position is reached, the position loop error will be zero.				

<b>Position Summation Input</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	counts	Read Only	No
<b>Description:</b>				
Contains the raw position command before filtering or an offset has been applied.				

<b>Position Summation Offset</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	counts	Read Only	No
<b>Description:</b>				
Contains the offset of the commanded position in the position loop.				

<b>Position Index Capture Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	counts	Read Only	No
<b>Description:</b>				
Contains the position of the last encoder index captured by the drive. Requires encoder with index.				

**200Ch: PVT Quick Status**

PVT Quick Status				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	0 – [2 <sup>(16)</sup> – 1]	N/A	Read Only	No

**Description:**  
Consolidates status information with regards to PVT. Bit definitions are given below.

Bit	PVT Drive Status
0-4	Number of PVT points in the drive
5-7	Reserved
8	Zero Speed
9	At Command
10	Homing Active
11	Homing Complete
12	Bridge Enabled
13	Brake Enabled
14	Stop
15	PVT Executing

**201Dh: PVT Status Values**

PVT Status				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	See Table	N/A	Read Only	No

**Description:**  
A bit field corresponding to the current status of PVT. The bit field definitions are given below.

Bit	PVT Status	Description
0	Buffer Full	The PVT Buffer is Full
1	Buffer Empty	The PVT Buffer is Empty
2	Buffer Threshold	The PVT Buffer has reached its threshold
3	Buffer Failure	Problem Reading Point from PVT Buffer
4	Buffer Empty Stop	The PVT Buffer is Empty, Last PVT Point has been reached
5	PVT point wrong sequence	A PVT Point Sequence Error has occurred
6	PVT Buffer Executing	The PVT Buffer is presently in use
7...15	Reserved	Reserved for future use

<b>PVT Points Remaining</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the number of PVT points remaining in the PVT buffer. This value gets decremented by 1 after each PVT point is executed. When it reaches zero, the PVT buffer is empty.				

<b>PVT Sequence Number</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – 15	N/A	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the current PVT point in the PVT buffer that is being executed.				

### **60C1h: Interpolation Data Record**

<b>1<sup>st</sup> Parameter of Interpolated Function</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
PVT Data Type	N/A	N/A	N/A	Yes
<b>Description:</b>				
Holds the active PVT end point. This object is not accessible. Note that DSP402 relates this object to the Interpolation Sub Mode Select object (60C0h) and reserves that object for specifying the interpolation mode the drive should use. However, AMC drives use a single interpolation method (PVT) and, as a result, there is no need for object 60C0h.				

### **2014h: Command Limiter Input**

<b>Input Command</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)-1}]$	N/A	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the input of the command limiter.				

### **200Fh: Power Bridge Values**

<b>DC Bus Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	0 – $[2^{(15)}-1]$	DV1	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the DC Bus Voltage. See “Appendix” on page 283 for unit conversions.				

<b>Phase A Output Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DPV	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the Phase A Output Voltage. See <a href="#">"Appendix"</a> on page 283 for unit conversion details.				

<b>Phase B Output Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DPV	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the Phase B Output Voltage. See <a href="#">"Appendix"</a> on page 283 for unit conversion details.				

<b>Phase C Output Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DPV	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the Phase C Output Voltage. See <a href="#">"Appendix"</a> on page 283 for unit conversion details.				

<b>Trap Mode Output Voltage</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DPV	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the trap mode output voltage. See <a href="#">"Appendix"</a> on page 283 for unit conversion details.				

## 2021h: Drive Temperature Values

<b>External Thermal Sense Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	N/A	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the external thermal sense value.				

<b>Thermistor Resistance</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 – [2 <sup>(16)</sup> -1]	Ohms	Read Only	No
<b>Description:</b>				
If supported by the hardware, this value represents the measured thermistor resistance value in ohms.				

**2019h: Capture Values** The capture values have units that vary with the operating mode of the drive. For these parameters, refer to [Table 2.13](#) for the correct unit selection.

**TABLE 2.13** Capture Units

<b>Drive Operation Mode</b>	<b>Units</b>
Current (Torque)	DC2
Velocity	DS1
Position (Around Velocity Or Current)	counts

<b>Capture 'A' Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[ $-2^{(31)}$ ] - [ $2^{(31)}-1$ ]	See <a href="#">Table 2.13</a>	Read Only	No
<b>Description:</b>				
Capture A captured value				

<b>Capture 'B' Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[ $-2^{(31)}$ ] - [ $2^{(31)}-1$ ]	See <a href="#">Table 2.13</a>	Read Only	No
<b>Description:</b>				
Capture B captured value				

<b>Capture 'C' Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	[ $-2^{(31)}$ ] - [ $2^{(31)}-1$ ]	See <a href="#">Table 2.13</a>	Read Only	No
<b>Description:</b>				
Capture C captured value				

**2023h: Digital Input Values**

Digital Inputs (Post Active Level)																																						
Data Type	Data Range	Units	Accessibility	Stored to NVM																																		
Unsigned16	See Table	N/A	Read Only	No																																		
<b>Description:</b>																																						
Bit field corresponding to the state of the digital inputs. Bit field definitions are given below.																																						
<table border="1"> <thead> <tr> <th>Bit</th><th>Digital Inputs*</th></tr> </thead> <tbody> <tr><td>0</td><td>Digital Input 1</td></tr> <tr><td>1</td><td>Digital Input 2</td></tr> <tr><td>2</td><td>Digital Input 3</td></tr> <tr><td>3</td><td>Digital Input 4</td></tr> <tr><td>4</td><td>Digital Input 5</td></tr> <tr><td>5</td><td>Digital Input 6</td></tr> <tr><td>6</td><td>Digital Input 7</td></tr> <tr><td>7</td><td>Digital Input 8</td></tr> <tr><td>8</td><td>Digital Input 9</td></tr> <tr><td>9</td><td>Digital Input 10</td></tr> <tr><td>10</td><td>Digital Input 11</td></tr> <tr><td>11</td><td>Digital Input 12</td></tr> <tr><td>12</td><td>Digital Input 13</td></tr> <tr><td>13</td><td>Digital Input 14</td></tr> <tr><td>14</td><td>Digital Input 15</td></tr> <tr><td>15</td><td>Digital Input 16</td></tr> </tbody> </table>					Bit	Digital Inputs*	0	Digital Input 1	1	Digital Input 2	2	Digital Input 3	3	Digital Input 4	4	Digital Input 5	5	Digital Input 6	6	Digital Input 7	7	Digital Input 8	8	Digital Input 9	9	Digital Input 10	10	Digital Input 11	11	Digital Input 12	12	Digital Input 13	13	Digital Input 14	14	Digital Input 15	15	Digital Input 16
Bit	Digital Inputs*																																					
0	Digital Input 1																																					
1	Digital Input 2																																					
2	Digital Input 3																																					
3	Digital Input 4																																					
4	Digital Input 5																																					
5	Digital Input 6																																					
6	Digital Input 7																																					
7	Digital Input 8																																					
8	Digital Input 9																																					
9	Digital Input 10																																					
10	Digital Input 11																																					
11	Digital Input 12																																					
12	Digital Input 13																																					
13	Digital Input 14																																					
14	Digital Input 15																																					
15	Digital Input 16																																					

\*Number of actual inputs depends on drive model

**2024h: Digital Output Values**

2024.01h	Digital Outputs (Pre Active Level)																																					
Data Type	Data Range	Units	Accessibility	Stored to NVM																																		
Unsigned16	See Table	N/A	Read Only	No																																		
<b>Description:</b>																																						
Bit field corresponding to the state of the digital inputs. Bit field definitions are given below.																																						
<table border="1"> <thead> <tr> <th>Bit</th><th>Digital Outputs*</th></tr> </thead> <tbody> <tr><td>0</td><td>Digital Output 1</td></tr> <tr><td>1</td><td>Digital Output 2</td></tr> <tr><td>2</td><td>Digital Output 3</td></tr> <tr><td>3</td><td>Digital Output 4</td></tr> <tr><td>4</td><td>Digital Output 5</td></tr> <tr><td>5</td><td>Digital Output 6</td></tr> <tr><td>6</td><td>Digital Output 7</td></tr> <tr><td>7</td><td>Digital Output 8</td></tr> <tr><td>8</td><td>Digital Output 9</td></tr> <tr><td>9</td><td>Digital Output 10</td></tr> <tr><td>10</td><td>Digital Output 11</td></tr> <tr><td>11</td><td>Digital Output 12</td></tr> <tr><td>12</td><td>Digital Output 13</td></tr> <tr><td>13</td><td>Digital Output 14</td></tr> <tr><td>14</td><td>Digital Output 15</td></tr> <tr><td>15</td><td>Digital Output 16</td></tr> </tbody> </table>					Bit	Digital Outputs*	0	Digital Output 1	1	Digital Output 2	2	Digital Output 3	3	Digital Output 4	4	Digital Output 5	5	Digital Output 6	6	Digital Output 7	7	Digital Output 8	8	Digital Output 9	9	Digital Output 10	10	Digital Output 11	11	Digital Output 12	12	Digital Output 13	13	Digital Output 14	14	Digital Output 15	15	Digital Output 16
Bit	Digital Outputs*																																					
0	Digital Output 1																																					
1	Digital Output 2																																					
2	Digital Output 3																																					
3	Digital Output 4																																					
4	Digital Output 5																																					
5	Digital Output 6																																					
6	Digital Output 7																																					
7	Digital Output 8																																					
8	Digital Output 9																																					
9	Digital Output 10																																					
10	Digital Output 11																																					
11	Digital Output 12																																					
12	Digital Output 13																																					
13	Digital Output 14																																					
14	Digital Output 15																																					
15	Digital Output 16																																					

\*Number of actual outputs depends on drive model

**201Ah: Analog Input Values**

201A.01h	Analog Input 1 Value			
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	$[-2^{15}] - [2^{15}-1]$	DAI	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the voltage present on analog input 1. See <a href="#">“Appendix” on page 283</a> for unit conversion details.				

201A.02h	Analog Input 2 Value			
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	$[-2^{15}] - [2^{15}-1]$	DAI	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the voltage present on analog input 2. See <a href="#">“Appendix” on page 283</a> for unit conversion details.				

<b>Analog Input 3 Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DAI	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the voltage present on analog input 3. See “Appendix” on page 283 for unit conversion details.				

<b>Analog Input 4 Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(15)}] - [2^{(15)}-1]$	DAI	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the voltage present on analog input 4. See “Appendix” on page 283 for unit conversion details.				

### **2015h: Deadband Input Value**

<b>Deadband Input Value</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer32	$[-2^{(31)}] - [2^{(31)}-1]$	DC2, DS1, counts	Read Only	No
<b>Description:</b>				
Value of the command input to the Deadband function. Mode dependant units.				

### **201Bh: PWM and Direction Input Values**

<b>Applied PWM Duty Cycle</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$[-2^{(13)}] - [2^{(13)}]$	Fractional duty cycle * $2^{(13)}$	Read Only	No
<b>Description:</b>				
Contains the value of the input duty cycle expressed as a signed fraction when the drive is configured for PWM command input. This value represents the measured duty cycle after polarity and inversions applied.				

<b>Input PWM Duty Cycle</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Integer16	$0 - [2^{(13)}]$	duty cycle * $2^{(31)}$	Read Only	No
<b>Description:</b>				
Contains the value of the input duty cycle expressed as an unsigned fraction when the drive is configured for PWM command input. This value represents the measured duty cycle before polarity and inversions applied.				

**2025h: Analog Output Values**

Analog Output 1 Value				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	$[-2^{15}] - [2^{15}-1]$	DAO	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the value of analog output 1. The analog outputs have a range of 0 to 10 Volts. See "Appendix" on page 283 for unit conversion details.				

Analog Output 2 Value				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Integer16	$[-2^{15}] - [2^{15}-1]$	DAO	Read Only	No
<b>Description:</b>				
Contains a value corresponding to the value of analog output 2. The analog outputs have a range of 0 to 10 Volts. See "Appendix" on page 283 for unit conversion details.				

**2028h: Fault Log Counter**

Log Counter: Total Run Time				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned48	$0 - 2^{48}$	msec	Read Only	No
<b>Description:</b>				
This object holds the total run time of the drive.				

Log Counter: Drive Reset				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	$0 - [2^{16}-1]$	count	Read Only	No
<b>Description:</b>				
Number of times Drive Reset occurred in the life of the drive.				

Log Counter: Drive Internal Error				
Data Type	Data Range	Units	Accessibility	Stored to NVM
Unsigned16	$0 - [2^{16}-1]$	count	Read Only	No
<b>Description:</b>				
Number of times Drive Internal Error occurred in the life of the drive.				

<b>2028.04h</b>	<b>Log Counter: Short Circuit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Short Circuit occurred in the life of the drive.				

<b>2028.05h</b>	<b>Log Counter: Current Overshoot</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Current Overshoot occurred in the life of the drive.				

<b>2028.06h</b>	<b>Log Counter: Hardware Under Voltage</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Hardware Under Voltage occurred in the life of the drive.				

<b>2028.07h</b>	<b>Log Counter: Hardware Over Voltage</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Hardware Over Voltage occurred in the life of the drive.				

<b>2028.08h</b>	<b>Log Counter: Drive Over Temperature</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Drive Over Temperature occurred in the life of the drive.				

<b>2028.09h</b>	<b>Log Counter: Parameter Restore Error</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Parameter Restore Error occurred in the life of the drive.				

<b>2028.0Ah</b>	<b>Log Counter: Parameter Store Error</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Parameter Store Error occurred in the life of the drive.				

<b>2028.0Bh</b>	<b>Log Counter: Invalid Hall State</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Invalid Hall State occurred in the life of the drive.				

<b>2028.0Ch</b>	<b>Log Counter: Phase Synchronization Error</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Phase Sync. Error occurred in the life of the drive.				

<b>2028.0Dh</b>	<b>Log Counter: Motor Over Temperature</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Motor Over Temperature occurred in the life of the drive.				

<b>2028.0Eh</b>	<b>Log Counter: Phase Detection Fault</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Phase Detection Fault occurred in the life of the drive.				

<b>2028.0Fh</b>	<b>Log Counter: Feedback Sensor Error</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Feedback Sensor Error occurred in the life of the drive.				

<b>2028.10h</b>	<b>Log Counter: Log Entry Missed</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Log Entry Missed occurred in the life of the drive.				

<b>2028.11h</b>	<b>Log Counter: Software Disable</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Software Disable occurred in the life of the drive.				

<b>2028.12h</b>	<b>Log Counter: User Disable</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times User Disable occurred in the life of the drive.				

<b>2028.13h</b>	<b>Log Counter: User Positive Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times User Positive Limit occurred in the life of the drive.				

<b>2028.14h</b>	<b>Log Counter: User Negative Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times User Negative Limit occurred in the life of the drive.				

<b>2028.15h</b>	<b>Log Counter: Current Limiting</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Current Limiting occurred in the life of the drive.				

<b>2028.16h</b>	<b>Log Counter: Continuous Current</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Continuous Current occurred in the life of the drive.				

<b>2028.17h</b>	<b>Log Counter: Current Loop Saturated</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Current Loop Saturated occurred in the life of the drive.				

<b>2028.18h</b>	<b>Log Counter: User Under Voltage</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times User Under Voltage occurred in the life of the drive.				

<b>2028.19h</b>	<b>Log Counter: User Over Voltage</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times User Over Voltage occurred in the life of the drive.				

<b>2028.1Ah</b>	<b>Log Counter: User Auxiliary Disable</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times User Auxiliary Disable occurred in the life of the drive.				

<b>2028.1Bh</b>	<b>Log Counter: Shunt Regulator Active</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Shunt Regulator Active occurred in the life of the drive.				

<b>Log Counter: Command Limiter Active</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Command Limiter Active occurred in the life of the drive.				

<b>Log Counter: Motor Overspeed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Motor Overspeed occurred in the life of the drive.				

<b>Log Counter: At Command</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times At Command occurred in the life of the drive.				

<b>Log Counter: Zero Speed</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Zero Speed occurred in the life of the drive.				

<b>Log Counter: Velocity Following Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Velocity Following Error occurred in the life of the drive.				

<b>Log Counter: Positive Target Velocity Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Positive Target Velocity Limit occurred in the life of the drive.				

<b>2028.22h</b>	<b>Log Counter: Negative Target Velocity Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Negative Target Velocity Limit occurred in the life of the drive.				

<b>2028.23h</b>	<b>Log Counter: Upper Measured Position Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Upper Measured Position Limit occurred in the life of the drive.				

<b>2028.24h</b>	<b>Log Counter: Lower Measured Position Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Lower Measured Position Limit occurred in the life of the drive.				

<b>2028.25h</b>	<b>Log Counter: At Home Position</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times At Home Position occurred in the life of the drive.				

<b>2028.26h</b>	<b>Log Counter: Position Following Error</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Position Following Error occurred in the life of the drive.				

<b>2028.27h</b>	<b>Log Counter: Upper Target Position Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Upper Target Position Limit occurred in the life of the drive.				

<b>Log Counter: Lower Target Position Limit</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Lower Target Position Limit occurred in the life of the drive.				

<b>Log Counter: PVT Buffer Full</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times PVT Buffer Full occurred in the life of the drive.				

<b>Log Counter: PVT Buffer Empty</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times PVT Buffer Empty occurred in the life of the drive.				

<b>Log Counter: PVT Buffer Threshold Exceeded</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times PVT Buffer Threshold Exceeded occurred in the life of the drive.				

<b>Log Counter: PVT Buffer Failure</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times PVT Buffer Failure occurred in the life of the drive.				

<b>Log Counter: PVT Buffer Empty Stop</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times PVT Buffer Empty Stop occurred in the life of the drive.				

<b>2028.2Eh</b>	<b>Log Counter: PVT Sequence Error</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times PVT Sequence Error occurred in the life of the drive.				

<b>2028.2Fh</b>	<b>Log Counter: Communication Channel Error</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Communication Channel Error occurred in the life of the drive.				

<b>2028.30h</b>	<b>Log Counter: Commanded Stop</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Commanded Stop occurred in the life of the drive.				

<b>2028.31h</b>	<b>Log Counter: User Stop</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times User Stop occurred in the life of the drive.				

<b>2028.32h</b>	<b>Log Counter: Commanded Positive Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Commanded Positive Limit occurred in the life of the drive.				

<b>2028.33h</b>	<b>Log Counter: Commanded Negative Limit</b>			
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>16</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times Commanded Negative Limit occurred in the life of the drive.				

<b>Log Counter: PWM and Direction Broken Wire Error</b>				
<b>Data Type</b>	<b>Data Range</b>	<b>Units</b>	<b>Accessibility</b>	<b>Stored to NVM</b>
Unsigned16	0 - [2 <sup>(16)</sup> -1]	count	Read Only	No
<b>Description:</b>				
Number of times PWM and Direction Broken Wire Error occurred in the life of the drive.				



# Appendix

## A.1 Appendix A - Units

Table A.1 below shows scaling factors and formulas for converting physical units to drive units.

**TABLE A.1 Drive Units and Scaling Factors**

Abbreviation	Drive Unit Type	Physical Units	Data Type	Scaling Factor
DA1	Acceleration	counts/s <sup>2</sup>	Integer32/Unsigned32	$2^{34}/K_S^2$
DA2	Acceleration	counts/s <sup>2</sup>	Unsigned48	$2^{34}/K_I K_S^2$
DA3	Acceleration	counts/s <sup>2</sup>	Integer32	$2^{28}/K_{MS} K_S$
DA4	Acceleration	counts/s <sup>2</sup>	Integer32	$(2^{18})/(K_S^2)$
DA5	Acceleration	counts/s <sup>2</sup>	Unsigned48	$2^{28}/K_{DS} K_S$
DC1	Current	A	Integer16	$2^{13}/K_P$
DC2	Current	A	Integer32	$2^{15}/K_P$
DJ1	Jerk	A/s	Unsigned48	$2^{32}/(K_P K_S)$
DG1	Angle	degrees	Integer16/Unsigned16	$2^{16}/360$
DS1	Speed/Velocity	counts/s	Integer32	$2^{17}/K_I K_S$
DS2	Speed/Velocity	counts/s	Unsigned48	$2^{17}/K_S$
DS3	Speed/Velocity	counts/s	Integer64	$2^{33}/K_S$
DS4	Speed/Velocity	counts/s	Unsigned32	$2^{17}/K_S$
DV1	Voltage	V	Integer16	$2^{14}/(1.05 K_{OV})$
DPV	Phase Voltage	V	Integer16	$2^{14}/K_B$
DAI	Analog Input Voltage	V	Integer16	$2^{14}/20$
DAO	Analog Output Voltage	V	Integer16	$2^{14}/10$
DT1	Temperature	°C	Integer32	$2^{16}$
PBC	Power Board Current	A	Unsigned16	10
PBV	Power Board Voltage	V	Unsigned16	10
PBT	Power Board Time	s	Unsigned16	100
PBF	Power Board Frequency	kHz	Unsigned32	$2^{16}$
SF1	Scale Factor 1	-	-	$2^{14}$

1. Multiply physical units by the scaling factor to obtain drive units. Divide drive units by the scaling factor to obtain physical units.

The drive units used for a parameter depend upon the parameter type and size. Drive units must be rounded to the nearest integer and then converted to a hexadecimal base of the appropriate data type before they are written to the drive. When converting to a signed integer

data type, use two's complement for representation of negative numbers (see “[Conversion Example 3](#)” on page 285). Some scaling factors involve drive dependent constants. These constants are given in [Table A.2](#), along with details on determining their values.

**TABLE A.2 Drive dependent conversion constants**

Constant	Value
K <sub>B</sub>	DC Bus Voltage in volts. This value can be read from 200F.01h.
K <sub>DPS</sub>	Maximum dynamic index speed (in counts/s). This value can be read from 20CA.07h, 20CA.08h, 20CA.09h, and 20CA.0Ah.
K <sub>I</sub>	Feedback interpolation value. Only applies to drives that support 1 V <sub>pp</sub> Sin/Cos feedback. For all other drives, K <sub>I</sub> = 1. When applicable, this value can be read from 2032.08h.
K <sub>MS</sub>	Maximum profiler speed (in counts/s) for an Accel/Decel command profile. This value can be read from 203C.09h for Configuration 0 and 203C.0Ch for Configuration 1.
K <sub>OV</sub>	The hardware defined, DC bus, over-voltage limit of the drive in volts. This value can be read from 20D8.09h.
K <sub>P</sub>	The maximum rated peak current of the drive in amps. For example, 20 for the DPRALTE-020B080. This value can be read from 20D8.0Ch.
K <sub>S</sub>	Switching frequency of the drive in Hz. Most drives have a switching frequency of 20 kHz (K <sub>S</sub> = 20,000), however, drives that operate beyond 400 V usually have a switching frequency of 10 kHz (K <sub>S</sub> = 10,000). This value can be read from 20D8.24h (in kHz).

### A.1.1 Conversion Example 1

- **Drive:** DPRALTE-020B080
- **Feedback:** 1000 Line Incremental Encoder

To specify a Motor Over Speed Limit (2037.01h) of 10,000 RPM, first convert to the appropriate physical unit as shown below, keeping in mind that counts have a quadrature resolution (4X) over lines.

$$10,000 \frac{\text{rev}}{\text{min}} \times \frac{1000 \text{ lines}}{1 \text{ rev}} \times \frac{4 \text{ counts}}{1 \text{ line}} \times \frac{1 \text{ min}}{60 \text{ sec}} = 666,666.7 \frac{\text{counts}}{\text{sec}}$$

Motor Over Speed is of data type Integer32 and uses DS1 drive units. Taking the appropriate 32-bit scaling factor from [Table A.1](#) yields

$$666,666.7 \times \frac{2^{17}}{K_I K_S} = 666,666.7 \times \frac{2^{17}}{1 \times 20,000} = 4369066.9$$

where K<sub>I</sub> = 1 because we are not dealing with 1 V<sub>pp</sub> Sin/Cos feedback. Rounding this to the nearest integer and converting to a hexadecimal base then results in

$$4369067_{10} = 42AAAB_{16}$$

Now, to apply the setting, a value of 42AAABh would be written to sub-index 2037.01h.

### A.1.2 Conversion Example 2

- **Drive:** DPCANIA-030A400



- **Feedback:** 1Vp-p Sine/Cosine Encoder

To specify a Motor Over Speed Limit (2037.01h) of 10,000 RPM, first convert to the appropriate physical unit as shown below, keeping in mind that counts have a quadrature resolution (4X) over each cycle.

$$10,000 \frac{\text{rev}}{\text{min}} \times \frac{K_I \cdot \# \text{cycles}}{1 \text{rev}} \times \frac{4 \text{counts}}{1 \text{cycle}} \times \frac{1 \text{min}}{60 \text{sec}} = 666.7 \cdot K_I \cdot \# \frac{\text{counts}}{\text{sec}}$$

Motor Over Speed is of data type Integer32 and uses DS1 drive units. Taking the appropriate 32-bit scaling factor from [Table A.1](#) yields:

$$666.7 \cdot K_I \cdot \# \times \frac{2^{17}}{K_I K_S} = 666.7 \cdot \# \times \frac{2^{17}}{20,000} = 4369.0669 \cdot \#$$

where the  $K_I$  term cancels out. Rounding this to the nearest integer and converting to a hexadecimal base then results in:

$$4369067_{10} = 42AAAB_{16}$$

Now, to apply the setting, a value of 42AAABh would be written to sub-index 2037.01h.

### A.1.3 Conversion Example 3

To set a temperature parameter to 23°F first convert to the appropriate physical unit as shown below.

$$\frac{5}{9}(23 - 32) = -5^{\circ}\text{C.}$$

Referring to [Table A.1](#), the appropriate scaling factor yields:

$$-5 \times 2^{16} = -327680$$

Because the resulting integer value is negative, two's complement notation will be used to represent its hexadecimal equivalent. To obtain the two's complement, the positive version of the desired number should be subtracted from  $2^N$ , where N is the number of bits in the data type. Temperature parameters use the data type Integer32 so the calculation is as follows:

$$2^N - 327680 = 2^{32} - 327680 = 4294639616$$


$$4294639616_{10} = FFFB0000_{16}$$

The final step would be to write a value of FFFB0000h to the appropriate parameter.

## A.2 Appendix B - Current Limiting Algorithm

In order to understand the current limiting algorithm used by *ADVANCED* Motion Controls DP Series drives, it is necessary to first understand the different current limiting regions. The graph in [Figure A.1](#) breaks the available current into three different regions.

**FIGURE A.1** Current Limiting Regions



- **Continuous Region:** The commanded current is less than or equal to the continuous current limit. The available current is equal to the commanded current.
- **Peak Region:** The commanded current is between the continuous and peak current limits. The available current is equal to the commanded current for a limited time (Peak Time).
- **Foldback Region:** Commanded current is between the continuous and peak current limits of the drive. The available current is less than the commanded current. The available current decreases over time until it equals the continuous current limit. The rate of this decrease is equal to:


$$\text{Slope} = \frac{I_p - I_c}{t_f}$$

$I_p$	Peak current limit
$I_c$	Continuous current limit
$t_f$	Foldback time

### A.2.1 Time-Based Peak Current Limiting

The full peak value of current is available to begin with. When a current command is equal to the peak current limit, the current begins to foldback to the continuous limit after  $T_p$ , following the same slope as given in Figure A.1. Once the available current has reached the continuous current limit after  $t_f$ , the available current will be limited to the continuous current limit until the commanded current is dropped below the continuous level.


**FIGURE A.2** Time-Based Peak Current Limiting



## A.2.2 Time-Based Non-Peak Current Limiting

When the commanded current is between the peak and continuous current limits, the available current will begin to foldback at the intersection with the slope from “[Time-Based Peak Current Limiting](#)”. The larger the commanded current, the sooner the available current will begin to foldback.

**FIGURE A.3** Time-Based Non-Peak Current Limiting



### A.2.3 Time-Based Current Recovery


Initially, the full peak value of current is available. A commanded current above the continuous level causes the available current to foldback to the continuous level as shown in the first graph of [Figure A.4](#). When the commanded current drops below the continuous current limit value ( $A_1$  in the first graph), the available current will then begin to recover along the slope of the foldback line towards the peak current level, as shown in the second graph of [Figure A.4](#). The relationship between the commanded current and the recovered current is given as:

$$A_2 = \frac{1}{2}A_1$$

Using this relationship, you can calculate the amount of time recovered,  $\Delta t$ , by using the following equation:

$$\Delta t = \frac{A_1}{2(I_p - I_c)}$$

**FIGURE A.4** Time-Based Current Recovery - Foldback and Commanded Current




Note that current must be commanded below the specified continuous value to start recovering from a foldback condition.

## A.2.4 Charge-Based Peak Current Limiting

The charge is full to begin with. When a current greater than the continuous current limit is commanded, the charge begins to decay. The loss of charge is determined by the area under the curve as shown in [Figure A.5](#). The larger the command, the faster the charge will decay. When the charge decreases to zero, the available current will be limited to the continuous current limit until the charge is restored.


**FIGURE A.5** Charge-Based Peak Current Limiting



### A.2.5 Charge-Based Non-Peak Current Limiting

When the commanded current is between the peak and continuous current limits, the commanded current will be available for a longer period when compared to limiting at peak command. Note that the slope of the line during foldback is the same for both cases.


**FIGURE A.6** Charge-Based Non-Peak Current Limiting



## A.2.6 Charge-Based Current Recovery

After losing some value of charge, the charge may be recovered when the commanded value is dropped less than the continuous current limit. The amount of charge recovered depends on the magnitude of the commanded current and the amount of time in which it is commanded. The amount of charge recovered can be calculated by measuring the area within the curve as shown during the charge recovery phase in Figure A.7.

**FIGURE A.7** Charge Recovery




## A.2.7 RMS Current Scaling

RMS Current Scaling uses the charge-based algorithm described above. The only difference is the value of the continuous current the drive is capable of outputting. The continuous RMS limit can be used when the motor is moving so that the electrical cycle frequency is greater than the upper frequency assigned to that drive. The upper frequency is typically around 5Hz or 150 RPM for a 4-pole motor. The continuous RMS value is the continuous DC value multiplied by the square root of two.

$$I_{crms} \equiv \sqrt{2} \cdot I_{cdc}$$

When the electrical cycle frequency drops below the upper frequency, the continuous current drops below the RMS value. When the motor is moving at slow speeds, the continuous current is equal to the DC value of the current.

**FIGURE A.8 RMS Current Limiting**





<b>Numerics</b>						
1000h:	Device Type .....	73	1416h:	Communication Parameter. 82	1803h:	Communication Parameter. 85
100Bh:	Stored Node-ID .....	73	1417h:	23rd Receive PDO Communication Parameter. 83	1804h:	4th Transmit PDO Communication Parameter. 86
100Ch:	Guard Time .....	73	1419h:	24th Receive PDO Communication Parameter. 83	1814h:	5th Transmit PDO Communication Parameter. 87
100Dh:	Life Time Factor .....	74	1600h:	26th Receive PDO Mapping Parameter .....	1815h:	21st Transmit PDO Communication Parameter. 88
1010h:	Store Drive Parameters ...	70	1601h:	1st Receive PDO Mapping Parameter .....	1816h:	22nd Transmit PDO Communication Parameter. 88
1011h:	Restore Drive Parameters	71	1602h:	2nd Receive PDO Mapping Parameter .....	1817h:	23rd Transmit PDO Communication Parameter. 89
1016h:	Consumer Heartbeat Time .	74	1603h:	3rd Receive PDO Mapping Parameter .....	1818h:	24th Transmit PDO Communication Parameter. 90
1017h:	Producer Heartbeat Time	74	1604h:	4th Receive PDO Mapping Parameter .....	1819h:	25th Transmit PDO Communication Parameter. 90
1018h:	Identity Object .....	74	1614h:	5th Receive PDO Mapping Parameter .....	1Ao0h:	26th Transmit PDO Communication Parameter. 91
1400h:	1st Receive PDO Communication Parameter	77	1615h:	21st Receive PDO Mapping Parameter .....	1Ao2h:	1st Transmit PDO Mapping Parameter .....
1401h:	2nd Receive PDO Communication Parameter	78	1616h:	22nd Receive PDO Mapping Parameter .....	1Ao3h:	3rd Transmit PDO Mapping Parameter .....
1402h:	3rd Receive PDO Communication Parameter	79	1617h:	23rd Receive PDO Mapping Parameter .....	1Ao4h:	4th Transmit PDO Mapping Parameter .....
1403h:	4th Receive PDO Communication Parameter	80	1800h:	24th Receive PDO Mapping Parameter .....		5th Transmit PDO Mapping Parameter .....
1404h:	5th Receive PDO Communication Parameter	80	1802h:	1st Transmit PDO Communication Parameter. 84		87
1414h:	21st Receive PDO Communication Parameter	81		3rd Transmit PDO		
1415h:	22nd Receive PDO					

1A14h:	21st Transmit PDO Mapping Parameter .....	88	201Ch:	Gearing Values.....	257	2046h:	Auxiliary Input Parameters
1A15h:	22nd Transmit PDO Mapping Parameter .....	89	201Dh:	PVT Status Values .....	266	2048h:	105
1A16h:	23rd Transmit PDO Mapping Parameter .....	90	201Eh:	Auxiliary Encoder Value	257	2054h:	257
1A17h:	24th Transmit PDO Mapping Parameter .....	90	2021h:	Drive Temperature Values ..	268	2058h:	131
1A18h:	25th Transmit PDO Mapping Parameter .....	91	2023h:	Digital Input Values .....	270	205Ah:	124
1A19h:	26th Transmit PDO Mapping Parameter .....	92	2024h:	Digital Output Values ..	271	205Bh:	141
2001h:	Control Parameters.....	238	2025h:	Analog Output Values....	273	205Ch:	214
2002h:	Drive Status.....	248	2027h:	Feedback Hardware Diagnostics .....	255	205Dh:	169
2003h:	Drive Status History .....	251	2028h:	Fault Log Counter .....	273	2062h:	170
2005h:	Serial Interface Configuration.....	77	2029h:	Motion Engine Status ...	252	2064h:	Event Response Time
2008h:	Drive Initialization Parameters .....	128	2032h:	Feedback Sensor Parameters .....	101	2065h:	Parameters .....
2009h:	Load EEPROM Values....	72	2033h:	User Voltage Protection Parameters .....	129	2066h:	171
200Ah:	AMC Store Drive Parameters .....	72	2034h:	Current Loop & Commutation Control Parameters .....	105	2067h:	Event Action Parameters
200Bh:	Stored User Parameters	128	2036h:	Velocity Loop Control Parameters .....	113	2068h:	178
200Ch:	PVT Quick Status .....	266	2037h:	Velocity Limits.....	115	2069h:	Event Recovery Time
200Eh:	Feedback Sensor Values	254	2038h:	Position Loop Control Parameters .....	117	2070h:	Parameters .....
200Fh:	Power Bridge Values.....	267	2039h:	Position Limits.....	119	2071h:	190
2010h:	Current Values.....	258	203Ah:	Homing Configuration Parameters .....	123	2072h:	Event Time-Out Window
2011h:	Velocity Values .....	263	203Ch:	Command Limiter Parameters .....	124	2073h:	Parameters .....
2012h:	Position Values .....	264	203Dh:	Deadband Parameters ...	166	2074h:	196
2014h:	Command Limiter Input	267	203Eh:	Jog Parameters .....	168	2075h:	Event Maximum Recoveries
2015h:	Deadband Input Value ..	272	2043h:	Capture Configuration Parameters .....	132	2076h:	Parameters .....
2019h:	Capture Values.....	269	2044h:	Analog Input Parameters....	158	2077h:	204
201Ah:	Analog Input Values .....	271	2045h:	Interface Inputs .....	242	2078h:	Product Information ..
201Bh:	PWM and Direction Input Values.....	272				2079h:	231
						2080h:	Firmware Information...
						20C8h:	231
						20C9h:	Motion Engine Configuration .....
						20CAh:	129
						20D0h:	Motion Engine Control..
						20D8h:	244
						20D9h:	Dynamic Index Data ..
						20DCh:	244
						20D8h:	Control Loop Configuration
						20D9h:	Parameters .....
						20E6h:	101
						20EBh:	Power Board Information ...
						20E7h:	232
						20E8h:	CANopen Parameters .....
						20E9h:	75
						20EAh:	Time Stamp Settings.....
						20EBh:	75
						20ECCh:	NMT State .....
						2100h:	248
							2101h:
							Stored Bus Speed.....
							73

2111h:	SDO Size Indication ..... 76	2152h:	TPDO Value-Reached Assigned TPDOs ..... 100	60F4h:	Position Following Error Actual Value ..... 122
2120h:	TPDO Timer1 Cycle Time 95	2153h:	TPDO Value-Reached Direction ..... 101	60FFh:	Target Velocity ..... 241
2121h:	TPDO Timer1 Assigned TPDOs ..... 95	6040h:	ControlWord ..... 237	<b>A</b>	Abort Codes See Service Data Object
2122h:	TPDO Timer1 Next Processing Time ..... 96	6041h:	StatusWord ..... 247		Agency Compliances ..... i
2123h:	TPDO Timer2 Cycle Time 96	6060h:	Modes Of Operation ..... 241		Arbitration Field ..... 3
2124h:	TPDO Timer2 Assigned TPDOs ..... 96	6061h:	Modes Of Operation Display 254		Asynchronous Transmission See Process Data Object
2125h:	TPDO Timer2 Next Processing Time ..... 96	6064h:	Actual Position ..... 264		Trigger Mechanisms ..... ii
2130h:	TPDO Value-Changed Object ID ..... 97	6065h:	Position Following Error Window ..... 121	<b>B</b>	Attention Symbols ..... ii
2131h:	TPDO Value-Changed Delta Value ..... 97	6066h:	Position Following Error Time Out ..... 121		BOOT-UP Message See Messages
2132h:	TPDO Value-Changed Assigned TPDOs ..... 97	6069h:	Velocity Sensor Actual Value 262		Boot-Up State See States
2133h:	TPDO Value-Changed Object Last Value ..... 98	606Bh:	Velocity Demand ..... 261		Bus Traffic ..... 5
2140h:	TPDO Bits-Changed_1 Object ID ..... 98	606Ch:	Actual Velocity ..... 262	<b>C</b>	COB-ID ..... 4
2141h:	TPDO Bits-Changed_1 Object Bit Mask ..... 98	606Dh:	Velocity Window ..... 262		Communication Hardware
2142h:	TPDO Bits-Changed_1 Assigned TPDOs ..... 98	606Eh:	Velocity Window Time .. 262		CAN hardware Setup ..... 66
2143h:	TPDO Bits-Changed_1 Object Last Value ..... 99	6071h:	Velocity Window Time .. 262		RS-232 hardware Setup ..... 66
2144h:	TPDO Bits-Changed_2 Object ID ..... 99	6077h:	Target Current ..... 241		Communication Parameter Object
2145h:	TPDO Bits-Changed_2 Object Bit Mask ..... 99	607Ah:	Actual Current ..... 258		See Process Data Object
2146h:	TPDO Bits-Changed_2 Assigned TPDOs ..... 99	607Ch:	Target Position ..... 242		Configuration
2147h:	TPDO Bits-Changed_2 Object Last Value ..... 100	6086h:	Home Offset ..... 123		Communication State Machine ..... 6
2150h:	TPDO Value-Reached Object ID ..... 100	6088h:	Motion Profile Type ..... 124		Company Website ..... i
2151h:	TPDO Value-Reached.... 100	6098h:	Torque Profile Type ..... 124		Control State Machine ..... 6, 35
		6099h:	Homing Method ..... 122		ControlWord (6040h) ..... 35, 38
		609Ah:	Homing Speeds ..... 122		Current Limiting ..... 112, 286–293
		60B1h:	Homing Acceleration .... 122		Charge-Based ..... 290–292
		60B2h:	Velocity Offset ..... 242		RMS Current Scaling ..... 293
		60C1h:	Current Offset ..... 242		Time-Based ..... 287–289
		60C2h:	Interpolation Data Record.. 267	<b>D</b>	
			Interpolation Time Period .... 127		DS301 ..... 1
					DSP402 ..... 1
				<b>E</b>	EMERGENCY Error Codes ..... 13
					EMERGENCY Message See Messages
					Error Codes See EMERGENCY Error Codes
				<b>H</b>	
					Hardware
					API ..... 67
					CAN Card ..... 66
					CAN Mating Connector ..... 67
					CAN Port Wiring ..... 67
					Heartbeat ..... 7, 9
					Homing ..... 40, 51
					Example ..... 47
					Method 1 ..... 42
					Method 2 ..... 42
					Method 35 ..... 46
					Methods 17 – 30 ..... 46
					Methods 3 & 4 ..... 43
					Methods 33 – 34 ..... 46

---

Methods 5 & 6 .....	43	Modes of Operation .....	48
Methods 7 – 14 .....	44	Custom Defined Modes .....	54
<b>I</b>		Profile Current Mode .....	51
ID		Profile Position Mode .....	49
COB .....	4	Profile Velocity Mode .....	50
Node .....	4	PVT Mode See Interpolated Position Mode	
Interpolated Position Mode .....	51, 54	<b>N</b>	
Buffer .....	59	Network Management .....	6
Enabling .....	56	NMT Error Control See Messages	
Examples .....	60	NMT Message See Messages	
Message Protocol .....	57	NMT State Machine See Communication State Machine	
Status .....	59	Node Guarding .....	7, 9
<b>L</b>		Node-ID .....	4
Life Guarding .....	7, 9	<b>O</b>	
<b>M</b>		Objects .....	2
Mapping Parameter Object See Process Data Object		Operational State See States	
Configuration		<b>P</b>	
Messages		Pre-Operational State See States	
Boot-Up .....	4, 11	Process Data Object	
EMERGENCY .....	4, 13	Configuration .....	25, 27, 28, 31
Fields .....	3	Messages .....	25, 31
Format (Little Endian) .....	4	Receive PDO .....	25
NMT .....	4, 5	RTR Bit .....	29
NMT Error Control .....	4, 7	SDO Comparison .....	15
PDO .....	4	Transmission Type .....	28
PDO See Process Data Object		Transmit PDO .....	25
SDO .....	4	Trigger Mechanisms .....	29, 32, 33
SDO See Service Data Object		PVT See Interpolated Position Mode	
SYNC .....	4, 12		
TIME STAMP .....	4, 14		
Types .....	5		
		<b>R</b>	
		Revision History .....	iii
		RPDO See Process Data Object	
		RTR Bit .....	4, 29
		<b>S</b>	
		SDO See Service Data Object	
		Service Data Object	
		Abort Transfer Messages .....	21
		Expedited .....	16
		Messages .....	15, 23
		PDO Comparison .....	15
		Segmented .....	16
		States	
		Communication (NMT) .....	6
		Control (Operational) .....	36
		StatusWord (6041h) .....	36, 39
		Stopped State See States	
		SYNC Message See Messages	
		<b>T</b>	
		TIME STAMP Message See Messages	
		TPDO See Process Data Object	
		Trademarks .....	i
		<b>U</b>	
		Units .....	283
		<b>W</b>	
		Warning Symbols .....	ii

**DriveWare® CANopen Communication**  
Reference Manual  
MNCMCNRF-13



3805 Calle Tecate • Camarillo, CA 93012-5068  
Tel: (805) 389-1935   Fax: (805) 384-2315   [www.a-m-c.com](http://www.a-m-c.com)