

Proposed Pull Requests

Fork [stevenrwood/ioSender](#) → upstream [terjeio/ioSender](#) · base branch **master** · 26 branches (PR 8 stacks on PR 3; PRs 9-10 on the integrated keymap/Xbox base; PRs 11-15 off master; PRs 16-17 stack on PR 15; PRs 18-24 off master; PR 25 stacks on PR 14; PRs 26-27 off master) · all branches LF-normalized (`.gitattributes * text=auto eol=lf`) · **none submitted upstream yet** (staging document)

1	Bug Fixes for released ioSender	pr/fix-rp-math-build	Files: 5 0 0 Lines: +28 -10
2	Surface Motor Fault / Warning signals	pr/motor-signals	Files: 2 0 0 Lines: +5 -32
3	Console persistence + Key Mappings editor	pr/keymapping_editor	Files: 12 0 +4 Lines: +1224 -15
4	Connection-loss handling + auto-reconnect	pr/connection-loss-reconnect	Files: 10 0 0 Lines: +522 -63
5	Stepper calibration (scratch) tab	pr/stepper-calibration-scratch	Files: 13 0 +3 Lines: +773 -2
6	Load Folder + Fusion batch-post add-in	pr/load-folder	Files: 28 0 +8 Lines: +1634 -8
7	High-DPI / large-text layout	pr/highdpi-layout	Files: 27 0 0 Lines: +126 -109
8	Xbox controller + Key Mappings editor polish	pr/xbox-mapping	Files: 14 0 +4 Lines: +2255 -687
9	Configurable main page + flyouts + jogging panels (XL)	pr/main-page-layout	Files: 31 0 +20 Lines: +2835 -119
10	Macro manager + run-only flyout	pr/macro-editor	Files: 16 0 +2 Lines: +598 -26
11	Macro Processor Enhancements	pr/macro-processor	Files: 8 0 +1 Lines: +723 -21
12	Onboarding tooltips	pr/onboarding-tooltips	Files: 14 0 0 Lines: +283 -28
13	Build documentation (Mega-XL notes + tool-change guide)	pr/build-docs	Files: 1 0 +8 Lines: +2662 0
14	SD + LittleFS file browser & file manager	pr/sdcard-filesystems	Files: 12 0 +3 Lines: +945 -135
15	USB / Ethernet / simulator connection support + Connect menu	pr/connect-simulator	Files: 26 0 +3 Lines: +1151 -68
16	Validate controller (check-mode g-code conformance test)	pr/validate	Files: 19 0 +1 Lines: +1208 -38
17	Restore main window position across launches	pr/window-restore	Files: 2 0 0 Lines: +60 -7
18	grbl:Settings — live edits, change highlight, revert & snapshots	pr/grbl-settings	Files: 12 0 +2 Lines: +659 -43

19	Console — inline terminal-style comm and prompt	pr/mdi-console	Files: 13 0 0 Lines: +220 -21
20	3D view — Ctrl+click to jog + per-axis orientation	pr/click-to-jog	Files: 5 0 0 Lines: +206 -60
21	grbl:Settings — Machine Setup Wizard	pr/machine-setup-wizard	Files: 12 0 +3 Lines: +1740 -1
22	Keyboard jog — keep active when Job-view focus drifts	pr/keyboard-jog-focus	Files: 2 0 0 Lines: +23 -1
23	Go To — optional safe-Z (lift, traverse, descend)	pr/safe-z-goto	Files: 10 0 0 Lines: +54 -8
24	comms — fix telnet/websocket UI deadlock	pr/telnet-deadlock-fix	Files: 2 0 0 Lines: +29 -10
25	ATC tool-change macro provisioning (install ATC + Start Job)	pr/atc-macros	Files: 7 0 +5 Lines: +804 -10
26	Offsets — editable G28/G30 (Set rapids & stores)	pr/editable-predefined-offsets	Files: 1 0 0 Lines: +21 -2
27	Dialogs — center owner-less modal dialogs	pr/dialog-centering	Files: 4 0 0 Lines: +4 -2
Totals (27 PRs)			Files: 196 0 +64 Lines: +18929 -1526

Cross-repo: which of these PRs the stevenwood/Simulator fork relies on.

Separate repos — no build dependency. The coupling is runtime / protocol: the simulator only exercises a feature when the ioSender PR below drives it over the socket. (Simulator PR numbers refer to that fork's proposed-prs tracker.)

ioSender PR	Used by Simulator PR	Coupling
PR 6 load-folder	sim-view (3D carve)	PushHeaderToSimulator() sends the program's leading (STOCK ...) / (TOOL ...) comments so the carve knows stock size + cutter geometry.
PR 11 macro-processor	littlefs	0<name> CALL forwarding resolves macros stored on the simulator's /littlefs.
PR 14 sdcard-filesystems	littlefs, ymodem-socket	File browser + YModem uploader that puts files onto the simulator filesystem.
PR 15 connect-simulator	sim-view, persistence-reboot, sim-core base	Connects to the standalone sim; <i>always-send-comments</i> forces (TOOL)/(STOCK) through for the carve; (vestigial) download of the sim-latest CI build; "My Machine" EEPROM uses the sim's settings persistence.
PR 25 atc-macros	ymodem-socket, littlefs, sim-probe	"Install ATC macros" uploads via YModem to /littlefs; the Start-Job / probe_tfl cycle drives the modelled probe surfaces.

For the full virtual-CNC experience, run **ioSender@integration** against **Simulator@integration** — a bundle (the firmware-submodule fixes ride along inside the sim). Full matrix (Simulator → ioSender, with strength) is in the Simulator fork's **proposed-prs.html**.

PR 1 Bug Fixes for released ioSender

Branch `pr/fix-rp-math-build`

Compare <https://github.com/terjeio/ioSender/compare/master...stevenrwood:ioSender:pr/fix-rp-math-build>

File	+	-
<code>.gitattributes</code>	3	2
<code>CNC Controls/CNC Controls/JobControl.xaml.cs</code>	7	0
<code>CNC Controls/CNC Controls/Widget.cs</code>	3	1
<code>CNC Core/CNC Core/CNC Core.csproj</code>	6	0
<code>CNC Core/CNC Core/Grbl.cs</code>	9	7

A bucket of fixes for bugs that exist in released ioSender, independent of the feature PRs. Each is small and self-contained:

- **RP.Math build fix.** CNC Core compiles `GCodeEmulator.cs`, which uses the `RP.Math.Vector3` type, but the project file declared no reference to `RP.Math`, so a clean build fails to resolve the type. Adds the `RP.Math` and `RP.Math.Vector3` references using the *same* `HintPath` convention already used by `CNC Controls.csproj` (`..\..\Vector-master\RP.Math.Vector3\bin\Release\`). Purely additive.
- **LF line-ending guard.** Adds `.gitattributes (* text=auto eol=lf)` so line endings are normalized.
- **CSV null-reference fix.** Avoids a `NullReferenceException` when an alarm/error/settings-group CSV resource is missing.
- **Boolean settings convention.** The settings editor checkbox initialised with `value == "1"`, but a boolean is true when `value != "0"` everywhere else (the list, controller-value parsing). Booleans reported as a truthy value other than the literal `"1"` showed enabled in the list yet left the checkbox unchecked. Canonicalises boolean values to `"1"/"0"` in `GrblSettingDetails.Value` and reads the checkbox with the `!= "0"` convention.
- **Null-comms streaming guard.** `JobControl.ResponseReceived` is raised by a specific comms instance but writes to the static `Comms.com`; during a reconnect/teardown (startup handshake or relaunch) that static can be null while an in-flight response from the old link still arrives, NREing in the `SendMDI/Reset` cases. Bails out early when `Comms.com` is null.

PR 2 Surface Motor Fault and Motor Warning signals in Signals display

Branch `pr/motor-signals`

Compare <https://github.com/terjeio/ioSender/compare/master...stevenrwood:ioSender:pr/motor-signals>

File	+	-
CNC Controls/CNC Controls/SignalsControl.xaml	2	30

Removes the capability-gating Styles that prevented the Motor Fault (**F**) and Motor Warning (**W**) indicators from ever showing.

grblHAL does not advertise these as `NEWOPT` capability tokens, so the visibility gates were effectively dead code — the LEDs were permanently hidden. Motor Fault / Warning are now always displayed alongside the other signal LEDs (H / S / P), turning red when the corresponding signal triggers. This surfaces the Motor Fault signal as intended, without requiring the firmware to advertise a capability flag.

PR 3 Persist console state and add an in-app Key Mappings editor

Branch pr/keymapping_editor

Compare https://github.com/terjeio/ioSender/compare/master...stevenrwood:ioSender:pr/keymapping_editor

File	+	-
CNC Controls/CNC Controls/AppConfig.cs	14	0
CNC Controls/CNC Controls/AppConfigView.xaml	1	1
CNC Controls/CNC Controls/AppConfigView.xaml.cs	16	3
CNC Controls/CNC Controls/CNC Controls.csproj	7	0
CNC Controls/CNC Controls/ConsoleControl.xaml	3	3
CNC Controls/CNC Controls/ConsoleControl.xaml.cs	14	0
CNC Controls/CNC Controls/ConsoleWindow.xaml.cs	47	0
CNC Controls/CNC Controls/KeyMapEditor.xaml	115	0
CNC Controls/CNC Controls/KeyMapEditor.xaml.cs	606	0
CNC Core/CNC Core/CNC Core.csproj	7	0
CNC Core/CNC Core/KeyPressHandler.cs	111	0
CNC Core/CNC Core/ShortcutKey.cs	136	0
ioSender XL/ioSender XL/App.config	6	0
ioSender XL/ioSender XL/MainWindow.xaml.cs	69	3
ioSender/ioSender/MainWindow.xaml.cs	69	3

Persists the console's state across sessions and replaces the old App Settings "Save key mappings" button (which only dumped the current bindings to `KeyMap<mode>.xml` for hand-editing) with a proper in-app **Edit Key Mappings** dialog. Applies to both **ioSender** and **ioSender XL**.

Console persistence: the three console checkboxes (*Verbose*, *Filter out realtime responses*, *Show all realtime responses*), whether the floating console window is open, and that window's size/position (clamped to the visible desktop so it can never restore off-screen) are all remembered. A new `ConsoleShortcut` setting (default Esc) toggles the console; it is now a first-class action inside the mappings editor rather than a separate, ad-hoc tab. A shared `ShortcutKey` helper (parse / storage / display) is used by both main windows, and an `AppConfig.ConsoleShortcutChanged` event re-registers the key live without a restart.

Key Mappings editor (`KeyMapEditor`, modal so jog/realtime dispatch can't fire mid-capture):

- One grouped, collapsible outline of every bindable action (grouped by function, like the Load Folder outline; groups remember their expansion per session). Click a row, press a combo to assign; right-click for *Reset to default* / *Clear*.
- Bindings changed from the factory default are highlighted; group headers flag a modified group and offer *Expand all* / *Collapse all* / *Reset group*.
- Per-axis jog keys are folded into the same list; rows and group headers carry tooltips.
- A *No-numpad keys* preset remaps the NumPad jog/step/feed actions to `Ctrl+1-8` and `[ ] - =` for keyboards without a numeric keypad (Windows exposes no reliable API to detect numpad

presence, so this is a user-triggered preset).

The `KeyPressHandler` gains an editor API (`GetActionBindings/GetJogBindings/Apply...`) over its existing function catalog, identifying bindings by reflection method name with a friendly-label map. Persistence still uses the existing `SaveMappings/LoadMappings`.

PR 4 Fix unhandled exceptions on connection loss (e.g. SD card swap)

Branch `pr/connection-loss-reconnect`

Compare <https://github.com/terjeio/ioSender/compare/master...stevenrwood:ioSender:pr/connection-loss-reconnect>

File	+	-
CNC Controls/CNC Controls/AppConfig.cs	5	0
CNC Controls/CNC Controls/SDCardView.xaml.cs	13	0
CNC Core/CNC Core/Comms.cs	74	0
CNC Core/CNC Core/EltimaStream.cs	6	0
CNC Core/CNC Core/Grbl.cs	13	4
CNC Core/CNC Core/GrblViewModel.cs	45	0
CNC Core/CNC Core/SerialStream.cs	179	42
CNC Core/CNC Core/TelnetStream.cs	105	7
CNC Core/CNC Core/WebsocketStream.cs	79	8

When the controller's serial/USB device disappears — for example a board that resets and re-enumerates when its SD card is removed or reinserted — the status-poll timer kept writing to the dead port. The write threw (an `IOException`, then an `InvalidOperationException`: "BaseStream only available when the port is open") on a `System.Timers.Timer` thread, and the unhandled exception terminated the whole process. Opening the SD card tab afterwards threw similarly from `PurgeQueue`.

Changes:

- Guard all stream writes (`IsOpen` + `try/catch`). A device-gone fault now closes the port and starts an auto-reconnect instead of crashing.
- Add a shared, transport-agnostic `Reconnector` (used by serial, network and websocket) exposing `ConnectionLost` / `Reconnected` events. `GrblViewModel` handles them (stop/resume polling, show status); it is wired up at connect time in `AppConfig`.
- **Serial:** refactor open into a reusable `OpenPort()` that probes `GetPortNames()` and re-opens; publish the port only once it is actually open, to avoid a non-null-but-closed race; make `PurgeQueue` tolerant of a closed port; harden the receive handler against a port torn down mid-read.
- **Telnet / websocket:** guarded writes, loss detection (read returning 0 / `OnClose`) and reconnect via the same helper.
- Wrap the poll-timer callback in `try/catch` as a last line of defence.
- Guard the SD card view against acting on a closed connection.

PR 5 Add Stepper calibration (scratch) tab to grbl:Settings

Branch pr/stepper-calibration-scratch

Compare <https://github.com/terjeio/ioSender/compare/master...stevenrwood:ioSender:pr/stepper-calibration-scratch>

File	+	-
CNC Controls/CNC Controls/CNC Controls.csproj	7	0
CNC Controls/CNC Controls/GrblConfigView.xaml	3	0
CNC Controls/CNC Controls/IGrblConfigTab.cs	1	0
CNC Controls/CNC Controls/StepperCalibrationScratchWizard.xaml	92	0
CNC Controls/CNC Controls/StepperCalibrationScratchWizard.xaml.cs	486	0
.gitattributes	3	2
CNC Controls/CNC Controls/LibStrings.xaml	1	0
CNC Core/CNC Core/CNC Core.csproj	6	0
ioSender XL/ioSender XL/App.config	6	0
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	168	0

Adds a new tab to grbl:Settings for V-bit *scratch-line* steps/mm calibration over a long span — a more accurate alternative to the short jog-based calibration for the X and Y axes.

It generates an .nc program that scratches paired lines (perpendicular to the calibrated axis) for several candidate steps/mm values. Because GRBL cannot change \$100/\$101 mid-program, each candidate is simulated using the *commanded-distance trick*: the commanded distance $C = \text{span} \times \text{candidate} / \text{current}$, so the machine physically travels the distance that the candidate steps/mm value *would* produce.

The program is loaded into the job view (with an optional save to disk). After cutting, the user measures the actual spacings; the tab then computes and saves the corrected \$100/\$101 from those measurements (an implied value per pair, averaged). The prolog mirrors the Load Folder convention. X/Y only — Z continues to use the existing jog wizard.

Includes a small follow-up commit with high-DPI layout tweaks for the new tab.

PR 6 Add "Load Folder": load a folder of per-toolpath .nc files as one outlined program

Branch pr/load-folder
 Compare <https://github.com/terjeio/ioSender/compare/master...stevenwood:ioSender:pr/load-folder>

File	+	-
.gitattributes	3	2
CNC Controls/CNC Controls/CNC Controls.csproj	2	0
CNC Controls/CNC Controls/FolderPicker.cs	159	0
CNC Controls/CNC Controls/FusionFolderLoader.cs	353	0
CNC Controls/CNC Controls/GCode.cs	156	0
CNC Controls/CNC Controls/GCodeListControl.xaml	45	0
CNC Controls/CNC Controls/GCodeListControl.xaml.cs	129	0
CNC Controls/CNC Controls/JobControl.xaml.cs	4	0
CNC Core/CNC Core/GCodeJob.cs	41	5
CNC Core/CNC Core/GrblViewModel.cs	7	1
Fusion Addin/README.md	116	0
Fusion Addin/install-macos.sh	39	0
Fusion Addin/install-windows.ps1	40	0
Fusion Addin/ioSenderBatchPost/ioSenderBatchPost.manifest	11	0
Fusion Addin/ioSenderBatchPost/ioSenderBatchPost.py	476	0
ioSender XL/ioSender XL/MainWindow.xaml	1	0
ioSender XL/ioSender XL/MainWindow.xaml.cs	5	0
ioSender/ioSender/MainWindow.xaml	1	0
ioSender/ioSender/MainWindow.xaml.cs	5	0
CNC Controls/CNC Controls/LibStrings.xaml	1	0
CNC Core/CNC Core/CNC Core.csproj	6	0
ioSender XL/ioSender XL/App.config	6	0
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	21	0
Locale/*/csv/ioSender.resources.*.csv (7 locales)	7	0

File > Load Folder reads a folder of per-operation files named <seq>_<name>_T<tool>.nc (as produced by the companion Fusion 360 add-in) and assembles them in memory into a single program:

- strips each file's header and program-end footer;
- inserts a G53 G0 Z0 safe-Z retract + M6 T<n> tool change before each toolpath, but only when the file does not already contain an M6 (so any post works);
- optionally restores rapid moves that Fusion Personal Use downgraded to G1;
- shows the result as a collapsible per-toolpath outline (groups default collapsed, and stay expanded while scrolling);

- adds *Start from this toolpath* and *Run just this toolpath* (the latter bounded to that section), each preceded by the G90 G94 / G17 / G21 prolog.

The new `FusionFolderLoader` is a faithful C# port of the add-in's combine / strip / rapid-restore rules; `FolderPicker` uses the modern `IFileOpenDialog` (`FOS_PICKFOLDERS`) for folder selection.

`GCodeBlock` gains a `Section` tag for outline grouping and an optional `AddLineNumbers` gate;

`GrblViewModel` gains `IsFolderView` and a one-shot `RunToBlock` end-bound consumed by

`CycleStart`.

Companion Fusion 360 add-in (`ioSenderBatchPost`): a standalone add-in (no external framework) that posts every operation in every setup to its own `<seq>_<name>_T<tool>.nc` file in a chosen folder — the input for Load Folder. Combining, tool-change insertion and rapid restoration are intentionally left to `ioSender`, so the add-in only posts. A post-processor dropdown (default `grbl.cps`) selects which post Fusion runs per operation. Ships with `install-windows.ps1` / `install-macos.sh` and a README. Fusion auto-discovers it once copied, but it must be enabled once via *Scripts and Add-Ins*.

Tool table for the simulator: the add-in also writes a `0_ToolTable.nc` carrying `(STOCK X= Y= Z=)` and `(TOOL T= D= TYPE= [A=])` comment lines — the stock box size and each tool's diameter and shape (FLAT/BALL/VBIT, with the V-bit included angle) — read from the setup's stock parameters and tool definitions. Load Folder detects this file (name matches `tool table`), loads it first with comments preserved, and pushes the leading `(STOCK ...)/(TOOL ...)` lines to a connected `grblHAL` simulator, which uses them for its 3D material-removal carve (real controllers ignore the comments). A dialog checkbox toggles it; the output matches the `SRWCommands PostProcess` add-in byte-for-byte. See `TOOL_TABLE_FORMAT.md` in the simulator repo.

Note: the `Fusion Addin/` folder is an optional companion tool; the maintainer may prefer to host it separately. It can be dropped from the PR if so.

PR 7 Improve high-DPI / large-text-size layout across the UI

Branch `pr/highdpi-layout`
Compare <https://github.com/terjeio/ioSender/compare/master...stevenwood:ioSender:pr/highdpi-layout>

File	+	-
CNC Controls Camera/ ... /ConfigControl.xaml	3	3
CNC Controls Lathe/ ... /ConfigControl.xaml	6	6
CNC Controls Probing/ ... /ProbingView.xaml	6	6
CNC Controls Probing/ ... /ProbingView.xaml.cs	3	1
CNC Controls/ ... /BasicConfigControl.xaml	4	4
CNC Controls/ ... /CoordValueSetControl.xaml	6	6
CNC Controls/ ... /FeedControl.xaml	5	5
CNC Controls/ ... /GotoBaseControl.xaml	5	5
CNC Controls/ ... /GotoControl.xaml	1	1
CNC Controls/ ... /JogBaseControl.xaml	2	2
CNC Controls/ ... /LEDControl.xaml	4	5
CNC Controls/ ... /NumericField.xaml	6	3
CNC Controls/ ... /NumericField.xaml.cs	3	1
CNC Controls/ ... /OutlineBaseControl.xaml	8	4
CNC Controls/ ... /OutlineControl.xaml	1	1
CNC Controls/ ... /OutlineFlyout.xaml	1	1
CNC Controls/ ... /OverrideControl.xaml	3	3
CNC Controls/ ... /SpindleControl.xaml	8	8
CNC Controls/ ... /StatusControl.xaml	3	3
CNC Controls/ ... /StepperCalibrationWizard.xaml	2	2
CNC Controls/ ... /StripGCodeConfigControl.xaml	15	9
CNC Controls/ ... /ToolView.xaml	2	2
CNC Controls/ ... /TrinamicView.xaml	1	1
CNC Controls/ ... /WorkParametersControl.xaml	18	18
ioSender XL/ioSender XL/JobView.xaml	6	6
ioSender/ioSender/JobView.xaml	1	1

Makes the UI usable at 125–150% Windows text scaling by replacing fixed control heights/widths with auto-sizing plus `MinWidth/MinHeight`, so labels and fields grow with the font instead of clipping or overlapping. Changes are layout-only — no behavioural changes.

- **Shared controls:** the `NumericField` label column now auto-sizes (`MinWidth = ColonAt`) with a `SharedSizeGroup` so labels align in any container that sets `Grid.IsSharedSizeScope`. `CoordValueSetControl`, `StatusControl`, `LEDControl` (dropped a hard `MaxHeight`) and `OverrideControl` no longer pin `Height/Width`; the **Spindle** group switches its fixed `Width=250` to `MinWidth` so the RPM field is no longer clipped at larger text sizes.

- **grbl:Settings config controls** (Basic / StripGCode / Lathe / Camera) and both Stepper calibration tabs auto-size their rows and the Axis dropdown; the Probing view auto-sizes its left panel with shared-size label alignment.
- **Main window** (JobView XL + ioSender): right-panel grid / columns / panels auto-size instead of fixed 515 / 250 px, and each panel control (WorkParameters, Spindle, Coolant, Outline, Feed, Goto) auto-sizes.

PR 8 Native Xbox controller support (+ Key Mappings editor polish)

Branch pr/xbox-mapping

Depends on PR 3 (pr/keymapping_editor) — this branch is stacked on it; the figures below are the delta on top of PR 3.

Compare https://github.com/stevenwood/ioSender/compare/pr/keymapping_editor...pr/xbox-mapping

File	+	-
CNC Core/CNC Core/XInput.cs	160	0
CNC Core/CNC Core/ControllerService.cs	186	0
CNC Core/CNC Core/ControllerMapper.cs	408	0
CNC Core/CNC Core/CNC Core.csproj	9	0
CNC Core/CNC Core/GrblViewModel.cs	16	0
CNC Core/CNC Core/KeyPressHandler.cs	23	0
CNC Controls/CNC Controls/JogBaseControl.xaml.cs	5	0
CNC Controls/CNC Controls/KeyMapEditor.xaml	222	79
CNC Controls/CNC Controls/KeyMapEditor.xaml.cs	958	606
.gitattributes	3	2
ioSender XL/ioSender XL/App.config	6	0
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	259	0

Adds first-class game-controller support with **zero new dependencies** — the project uses no NuGet, so the controller is read via native **XInput** P/Invoke (xinput1_4.dll, falling back to xinput9_1_0.dll). A ~60 Hz DispatcherTimer poll layer runs in parallel to the keyboard handler.

- **Interop / service:** XInput.cs wraps the gamepad state and vibration structs; ControllerService.cs scans all four slots, edge-detects button down/up, and exposes Connected/Disconnected events, deadzone/normalize helpers and rumble.
- **Button map:** ControllerMapper.cs dispatches a default, fully re-mappable button map to machine actions (A = Cycle Start, B = Feed Hold, X = Spindle Stop, Y = Home, Back = Reset, Start = Unlock, D-pad = step-jog X/Y). Actions route through the same GrblViewModel.ExecuteCommand path as the on-screen buttons and are gated to a live connection in Idle/Jog/Tool states (with a status message when ignored). A short rumble confirms connection.
- **Analog jog:** the left stick proportionally jogs X/Y and the triggers jog Z, via throttled overlapping \$J= moves (jog-cancel on release) so motion stays smooth; speed scales with stick deflection. Enable, left-stick deadzone, max-feed multiple of the Jog panel feed, and per-axis invert are user-configurable. The button map and analog settings persist to ControllerMap.xml.
- **Controller tab** in the Key Mappings editor: live press indicator, per-button action dropdowns (each button's default marked with a leading *), *Restore Defaults* (enabled only when modified), machine-direction-aware tooltips, and the analog-jog settings — machine dispatch is paused while the dialog is open. New JogDistanceProvider/JogFeedProvider hooks let controller jog match the on-screen Jog panel's current step and feed.

The same branch also carries the keyboard-tab polish (changed-binding highlight with per-row/group reset, *Clear* moved into the row menu, column sizing, and the grouped outline now keeps a section expanded while scrolling instead of collapsing it). The branch is fully LF-normalized, so the counts above are the real diff — no line-ending noise.

PR 9 Configurable main page + flyouts + jog panels (ioSender XL)

Branch pr/main-page-layout

Depends on The integrated Key Mappings + Xbox base in master (PRs 3 & 8); the figures below are the delta on top of that base.

Compare <https://github.com/stevenwood/ioSender/compare/master...pr/main-page-layout>

File	+	-
CNC Controls/CNC Controls/AppConfig.cs	141	20
CNC Controls/CNC Controls/AppConfigView.xaml	3	1
CNC Controls/CNC Controls/AppConfigView.xaml.cs	168	0
CNC Controls/CNC Controls/BasicConfigControl.xaml	2	0
CNC Controls/CNC Controls/CNC Controls.csproj	65	0
CNC Controls/CNC Controls/Converters.cs	17	0
CNC Controls/CNC Controls/JogBaseControl.xaml	2	2
CNC Controls/CNC Controls/JogBaseControl.xaml.cs	157	2
CNC Controls/CNC Controls/JogConfigControl.xaml	7	7
CNC Controls/CNC Controls/JogSlider.xaml	66	0
CNC Controls/CNC Controls/JogSlider.xaml.cs	51	0
CNC Controls/CNC Controls/JogUiConfigControl.xaml	18	9
CNC Controls/CNC Controls/KbdJogGridControl.xaml	46	0
CNC Controls/CNC Controls/KbdJogGridControl.xaml.cs	64	0
CNC Controls/CNC Controls/KeyboardJoggingControl.xaml	25	0
CNC Controls/CNC Controls/KeyboardJoggingControl.xaml.cs	34	0
CNC Controls/CNC Controls/LimitsControl.xaml	6	24
CNC Controls/CNC Controls/LimitsControl.xaml.cs	77	0
CNC Controls/CNC Controls/MachinePositionControl.xaml	69	0
CNC Controls/CNC Controls/MachinePositionControl.xaml.cs	21	0
CNC Controls/CNC Controls/MainPageEditor.xaml	108	0
CNC Controls/CNC Controls/MainPageEditor.xaml.cs	288	0
CNC Controls/CNC Controls/MainPanelRegistry.cs	111	0
CNC Controls/CNC Controls/NumericField.xaml	12	2
CNC Controls/CNC Controls/NumericField.xaml.cs	38	0
CNC Controls/CNC Controls/OffsetFlyout.xaml	41	0
CNC Controls/CNC Controls/OffsetFlyout.xaml.cs	133	0
CNC Controls/CNC Controls/PanelFlyout.xaml	43	0
CNC Controls/CNC Controls/PanelFlyout.xaml.cs	80	0
CNC Controls/CNC Controls/Properties/Settings.Designer.cs	36	0
CNC Controls/CNC Controls/Properties/Settings.settings	9	0
CNC Controls/CNC Controls/SidebarItem.cs	23	4
CNC Controls/CNC Controls/TabRegistry.cs	42	0

CNC Controls/CNC Controls/ToggleControl.xaml	20	2
CNC Controls/CNC Controls/UIJogGridControl.xaml	65	0
CNC Controls/CNC Controls/UIJogGridControl.xaml.cs	80	0
CNC Controls/CNC Controls/UIJoggingControl.xaml	44	0
CNC Controls/CNC Controls/UIJoggingControl.xaml.cs	29	0
CNC Core/CNC Core/KeyPressHandler.cs	22	4
CNC Core/CNC Core/SerialStream.cs	1	1
ioSender XL/ioSender XL/JobView.xaml	23	14
ioSender XL/ioSender XL/JobView.xaml.cs	100	19
ioSender XL/ioSender XL/MainWindow.xaml	3	3
ioSender XL/ioSender XL/MainWindow.xaml.cs	123	5
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	322	0

ioSender XL only. Makes the crowded right-hand panel area configurable instead of fixed. A new **Edit Main Page** dialog (beside *Edit Key Bindings*) is a shuttle editor with three buckets — *Available*, *Main page* (up to six slots), and *Flyouts* — so each named panel can be placed on the main page or as a pinnable right-edge flyout, or left off entirely to reclaim space. Nothing is auto-assigned.

- **Flyouts** share a flush, tab-height border and distribute their content vertically; each has a pin (stays open when another flyout opens, and persists across launches) and a close button.
- **Per-offset flyouts** (G28 / G30 / G54..G59.3 / G92) are tiny *Go* buttons (tooltip shows the live coordinates; G28/G30 also get a *Set* = G28.1/G30.1) so several can be pinned beside the jog panel.
- **Jog panels** — UI jogging (distance + speed) and keyboard default-speed — become assignable panels rendered as compact sliders with a read-only value; Settings.App stays the editor. The jog-arrow radios are hidden only when the UI jog panel is assigned.
- **Settings.App** gains opt-in autosave (with a discard prompt) and a *Reset to default* context-menu entry on numeric fields; the old *Edit Key Mappings* button is renamed **Edit Key Bindings**.

Layout choices persist (panels / flyouts / pins serialized as CSV to sidestep the XmlSerializer list-append quirk). Also includes robustness fixes: a resilient `SerialStream.OutCount` that no longer throws on a dropped port, and a deferred main-panel build so startup can't race the config load.

Extended: a fourth bucket places panels *left* of the 3D view (DRO, Program limits, Machine Position now in the registry) in a scroll region that never overlaps the fixed Signals/Status block. Per-offset *Set* now also handles G54–G59.3 (captures the current machine position as that coordinate system's origin via G10 L2 P<n>). The UI jog panel renders as a 2×4 distance/speed grid with green-click selection, a *Continuous* toggle and a *Remember distance & speed across restarts* option; *Link distance and speed to UI jogging* makes keyboard jogging follow the UI distance *and* speed (hiding the Keyboard Jogging panel). Coolant toggles render as a self-contained red/green pill (no theme dependency). A new **Tabs** tab in the editor reorders / hides the main TabControl tabs (Settings.App protected), applied on startup via `TabRegistry / Config.Tabs`. The *Restart* button moved to Settings.App (next to *Edit Main Page*), enabled only after a layout/tab change.

Panel refinements: the Machine Position panel shows MPos as a live *work* + `WorkPositionOffset` sum (tracking the DRO notifications); the limits panel stays visible and shows the machine soft-limit envelope from \$13x/\$23 when no program is loaded (program bounding box when one is), retitling itself *Machine limits / Program limits* accordingly; the 2×4 jog grid keeps its green selection highlight

using the retained discrete index (survives keyboard/continuous-mode flips); and the **Tabs** editor now also lists tabs that host an `IGrblConfigTab` (no `ViewType`) by falling back to the `TabItem` name.

PR 10 Macro manager + run-only flyout

Branch pr/macro-editor

Depends on The integrated base in master (the button sits next to PR 3's "Edit Key Bindings" on Settings:App); the figures below are the delta on top.

Compare <https://github.com/stevenwood/ioSender/compare/master...pr/macro-editor>

File	+	-
CNC Controls/CNC Controls/MacroManagerDialog.xaml.cs	316	0
CNC Controls/CNC Controls/MacroManagerDialog.xaml	81	0
CNC Controls/CNC Controls/MacroExecuteControl.xaml.cs	19	8
CNC Controls/CNC Controls/AppConfig.cs	19	0
CNC Controls/CNC Controls/AppConfigView.xaml.cs	10	0
CNC Controls/CNC Controls/MacroExecuteControl.xaml	8	16
CNC Controls/CNC Controls/CNC Controls.csproj	7	0
CNC Core/CNC Core/GCode.cs	5	0
CNC Controls/CNC Controls/JobControl.xaml.cs	3	2
CNC Controls/CNC Controls/MacroToolbarControl.xaml.cs	3	0
CNC Controls/CNC Controls/AppConfigView.xaml	1	0
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	126	0

Adds an **Edit Macros** button to the Settings:App page opening a macro manager — a DataGrid with one row per macro, in the spirit of Fusion's *Scripts and Add-Ins* dialog — and reworks the on-screen macro flyout for running.

- **Name** and a **Prompt** (confirm-before-run) flag are edited in-line; an assignable **Key** column (F1–F12) sets the function key (keys are unique; *Create* auto-assigns the first free one); a **File** column shows the referenced file for @<path> macros (full path on hover), blank for inline.
- **Edit** edits the macro's definition (inline G-code, or the @<path> reference line) and reads it back; **View** opens what it points to — the referenced file for an @<path> macro (created if missing, to author a new one), otherwise the code. **Create/Delete** add and remove rows.
- The **macro flyout** is now run-only: a macro-name dropdown plus a **Run** button (the Edit button is gone — editing lives in the manager). It pre-selects the most recently run macro, persisted in `Config.LastMacroId` and updated from every run path (flyout, toolbar, F-keys), falling back to the first.

The macro's function key is decoupled from its Id via a new `Macro.FKey` field (legacy configs migrated on load: Id n keeps Fn). The @<path> *run-time* resolution — loading and running the referenced file, with directive processing — is provided by **PR 11**; this PR adds the manager/flyout support for authoring, viewing, and repointing references.

PR 11 Macro Processor Enhancements

Branch `pr/macro-processor`

Depends on Off master, independent of PR 10. The two are complementary: PR 10's manager *authors* macros, this *executes* them.

Compare <https://github.com/stevenwood/ioSender/compare/master...pr/macro-processor>

File	+	-
CNC Controls/CNC Controls/MacroProcessor.cs	582	0
CNC Controls/CNC Controls/MacroToolBarControl.xaml.cs	1	1
CNC Controls/CNC Controls/MacroExecuteControl.xaml.cs	1	1
CNC Controls/CNC Controls/JobControl.xaml.cs	1	2
CNC Controls/CNC Controls/CNC Controls.csproj	1	0
CNC Core/CNC Core/GCodeParser.cs	31	12
CNC Core/CNC Core/NGCExpr.cs	22	0
CNC Core/CNC Core/Grbl.cs	11	0
CNC Core/CNC Core/GrblViewModel.cs	9	2

A sender-side **macro pre-processor** (`MacroProcessor.Run`) that interprets parenthesised directives before the remaining lines are streamed to the controller. All macro entry points — the top toolbar, the on-screen macro flyout, and the F-key handler — now route through it (previously the toolbar called `ExecuteMacro` directly and silently ignored every directive).

Directives, each a no-op the controller would treat as a comment, interpreted by the sender instead:

- **(PREREQ, cond, ...)** — require machine state *before* anything streams; if unmet the macro aborts with a message and nothing is sent. Conditions: `homed`, `idle`, `tlo`, `noalarm`, `connected`; stored positions / work offsets `g28`, `g30`, `g92`, `g54`–`g59.3` ("set" if any axis offset is non-zero, read fresh from `$#`); and any other token is required to be a controller `$I` build option (NEWOPT, e.g. `EXPR`), matched exactly and case-sensitively. `homed` reads `grblHAL's live sys.homed.mask` from `$#` rather than the change-based status `H: cache`, which can stay stale after a position-loss alarm.
- **(MBOX, [buttons,] message)** — modal hold; OK/OKCANCEL/YESNO, Cancel/No aborts the rest.
- **(WAITIDLE)** — hold streaming until the controller finishes what was sent and returns to Idle — needed after a controller-side job such as `$F=<file>`, which acks immediately and drops sender input while it runs.
- **(PROMPT param, default [, label])** — collect input values in a single up-front dialog and bind them two ways: assign the globals on the controller (so `$F=` files can read them) and substitute the references in the streamed body.
- **@<path>** — a macro whose body is a single `@<path>` line is a reference to an external file: that file's current contents are loaded and run in its place, re-read on every run — so a macro can be developed by editing the file directly. The loaded contents go through the same directive pipeline. (PR 10 adds the manager/flyout support for authoring and repointing these references.)

Supporting core changes so macros stream cleanly to an NGC-capable controller, all in the spirit of "don't reject what the controller can evaluate": `ExecuteMacro` now inherits the controller's expression

support (as file streaming already did) and forwards verbatim any line its own parser cannot handle; `GCodeParser` recognises **named O-word subroutine calls** (0<name> CALL [...]) and forwards them to the controller, which resolves the named sub from its filesystem; and the `$# [HOME:...:mask]` homed-axes mask is parsed for the authoritative homed check.

PR 12 Onboarding tooltips

Branch	pr/onboarding-tooltips
Depends on	Off master, independent. Aimed at users new to CNC.
Compare	https://github.com/stevenwood/ioSender/compare/master...pr/onboarding-tooltips

File	+	-
CNC Controls/CNC Controls/Converters.cs	50	0
CNC Controls/CNC Controls/StatusControl.xaml	3	0
CNC Controls/CNC Controls/StripGCodeConfigControl.xaml	10	5
CNC Controls/CNC Controls/JogUiConfigControl.xaml	10	9
CNC Controls/CNC Controls/JogConfigControl.xaml	7	7
CNC Controls/CNC Controls/BasicConfigControl.xaml	3	3
CNC Controls/CNC Controls/FileActionControl.xaml	4	4
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	196	0

Tooltips aimed at users new to CNC, where ioSender's UI is otherwise terse.

- **State field** — a context-aware tooltip explains the current controller state in plain language (Idle, Run, Hold, Check, Tool, Door, ...). For an **alarm** it appends the controller's specific message — e.g. ALARM 4: Probe fail ..., pulled from the GrblAlarms enumeration loaded at connect — plus how to recover, so a bare ALARM:4 is self-explanatory instead of a code to look up. (A new GrblStateToTooltipConverter drives a ToolTip binding on the State box.)
- **Settings:App** — a “what it does and why it’s useful” tooltip on each application setting (the grbl settings page already self-documents in its right-hand pane, so it’s left alone). Keyboard jogging (fast/slow/step feed & distance, link-step-to-UI), UI jogging (the four distance and four speed presets, noting distance and speed are selected *independently*), and GCode command stripping (M6/M7/M8/G61-G64, for machines lacking the matching hardware). Also fixes the “Keep MDI focus” tooltip (it had been copy-pasted from the buffering option) and the circular “Send comments” one.

PR 13 Build documentation: Mega-XL upgrade notes + repeatable tool-change guide

Branch pr/build-docs
Depends on Off master, independent. Documentation only — no code or build changes.
Compare <https://github.com/stevenwood/ioSender/compare/master...pr/build-docs>

File	+	-
docs/Mega-XL-Upgrades.html	840	0
docs/Mega-XL-Upgrades.pdf	bin	0
docs/Repeatable-Tool-Change.html	419	0
docs/Repeatable-Tool-Change.pdf	bin	0

Two self-contained HTML documents (each rendered to a companion PDF), added under a new docs/ folder. Purely additive; touches no source.

- **Repeatable-Tool-Change** — a turnkey, novice-friendly tool-change guide built around a **G59.3 fixed toolsetter** and a T<n>/M6 flow, with a top-down machine travel diagram (color-coded paths). Aimed at the goal of repeatable, hands-off tool changes for users new to CNC.
- **Mega-XL-Upgrades** — build notes for an upgraded Kickstarter v1.0 Mega V XL: frame/spindle/motion/probing/power sections, a back-of-enclosure two-panel harness model (hand-built SVG diagrams), a cable & wiring schedule, and an **interactive bill-of-materials worksheet** — an in-page editor (double-click to edit Qty / Unit / Description / Source, live extended & category subtotals & grand total, URL shortening, Save-to-download) plus a linked table of contents.

The Mega-XL notes are specific to one machine and may be of limited upstream interest — they can be hosted separately or dropped from the PR. The repeatable tool-change guide is more generally applicable. The associated controller macros (`tc.macro`, `probe_tfl.macro`) and the ATC provisioning UI are intentionally *not* in this PR — they remain with the macro work, pending firmware support.

PR 14 SD + LittleFS file browser & file manager on the SD Card tab

Branch	pr/sdcard-filesystems
Depends on	Off master, independent.
Compare	https://github.com/stevenwood/ioSender/compare/master...pr/sdcard-filesystems

File	+	-
CNC Controls/CNC Controls/SDCardView.xaml.cs	505	111
CNC Controls/CNC Controls/GrblFilesystems.cs	142	0
tests/GrblFilesystemsTests.cs	83	0
CNC Core/CNC Core/TelnetStream.cs	54	14
tests/README.md	22	0
CNC Controls/CNC Controls/SDCardView.xaml	19	6
CNC Core/CNC Core/YModem.cs	14	4
CNC Controls/CNC Controls/CNC Controls.csproj	1	0
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	105	0

The SD Card tab listed only one filesystem (the SD card, or whatever was the current filesystem). On grblHAL builds that have both an SD card and a LittleFS store, the other filesystem — and any macros on it — were invisible.

This enumerates every mounted filesystem via \$FI ([FS:<name>@<path> size, free]) and lists them together in one grid with a new **Location** column, plus a per-filesystem **free-space banner** above the list. The right-click menu is reworked from *Run / Download and run / Delete* into a small **file manager**, and file operations target the file's own filesystem — a bare name on the root volume (unchanged single-SD behaviour) or an absolute path on a sub-mount such as `/littlefs`.

- **File manager menu:** *View / Edit / Create* (new content, or from a local file) open the file in Notepad — Edit and Create write the result back to the controller when Notepad closes; *Load* and *Load and run* bring the program into ioSender; *Copy to / Move to* transfer a file to another mounted filesystem (submenus built live from the mounts); *Delete*. Actions are enabled only for a real selected file.
- **Empty filesystems are visible:** a mount with no files gets a placeholder row so it can still be selected as an upload / copy target; the listing's re-entrant `Load()` is guarded (it pumps the dispatcher while waiting on the controller, so an overlapping refresh could corrupt the shared table).
- **Correct attribution under nested mounts:** a root \$F recurses into sub-mounts, so an SD-root listing also returned the `/littlefs/*` files; each result is now attributed to its deepest containing mount, so files are not duplicated under (and mis-pathed on) the parent filesystem.
- **Upload to any filesystem:** `UploadLocalFile` targets a chosen filesystem via \$CWD (the FTP path is built from the explicit destination, not the possibly-stale `FsCwd`), and upload is allowed on a LittleFS-only controller (no SD card present, so no SD mount status to require).
- **Upload reliability:** `TelnetStream` now writes *synchronously* — overlapped `WriteAsync` calls silently dropped a YModem block's payload/CRC — and `PurgeQueue` clears the async-read buffer instead of racing a second synchronous read on the same stream (which lost per-block ACKs,

producing 0-byte files and multi-minute uploads); plus a bounded connect timeout so a reconnect retries quickly. YModem per-block ACK timeouts are raised (10 s open / 5 s block) to ride out flash-filesystem GC stalls, and blocks are sent in **128-byte (SOH)** packets rather than 1024-byte (STX): grblHAL's YModem receive ring is 1024 bytes (usable 1023), so a full 1029-byte STX packet can't fit — over telnet it arrives in a TCP burst faster than the firmware drains it and overflows, stalling the transfer (a one-block file uploaded, larger ones hung). 128-byte blocks fit with margin on any transport.

- **Backward compatible:** builds that don't implement \$FI (or report nothing mounted, `error:65`) return no `[FS:...]` lines, and the view falls back to the original single-filesystem mount + \$F listing untouched. An SD card with files in its root works exactly as before, now also showing free space.
- **New GrblFilesystems.cs** holds pure, dependency-free helpers (mount-line parser, human-readable size, path qualification, free-space summary) and the `FsMount` model; the live \$FI/\$F querying lives in `GrblSDCard`.
- **Unit tested:** `tests/GrblFilesystemsTests.cs` exercises the pure helpers (29 assertions, run via the Framework `csc` — see `tests/README.md`; the app has no test project).

Builds clean (CNC Controls and the full ioSender solution). Also the groundwork (and the reliable LittleFS upload path) that the ATC macro-provisioning work reuses to target the \$FI-discovered LittleFS path instead of a hardcoded one.

PR 15 USB / Ethernet / simulator connection support + Connect menu

Branch	pr/connect-simulator
Depends on	Off master, independent.
Compare	https://github.com/stevenwood/ioSender/compare/master...pr/connect-simulator

File	+	-
CNC Controls/CNC Controls/SimulatorManager.cs	474	0
ioSender XL/ioSender XL/MainWindow.xaml.cs	208	14
CNC Controls/CNC Controls/AppConfig.cs	165	28
CNC Controls/CNC Controls/BasicConfigControl.xaml	1	0
CNC Controls/CNC Controls/PortDialog.xaml.cs	56	2
CNC Controls/CNC Controls/PortDialog.xaml	43	8
ioSender XL/ioSender XL/MainWindow.xaml	39	2
CNC Controls/CNC Controls/GrblConfigControl.xaml.cs	22	0
simulator/README.md	18	0
CNC Core/CNC Core/TelnetStream.cs	14	3
CNC Controls/CNC Controls/JobControl.xaml.cs	14	2
CNC Controls/CNC Controls/UIUtils.cs	12	4
ioSender XL/ioSender XL/ioSender XL.csproj	12	0
CNC Core/CNC Core/HelperClasses.cs	8	2
ioSender XL/ioSender XL/JobView.xaml.cs	18	2
CNC Core/CNC Core/GrblViewModel.cs	7	0
readme.md	2	0
CNC Controls/CNC Controls/CNC Controls.csproj	2	0
CNC Controls/CNC Controls/Widget.cs	1	1
.gitignore	5	0
CNC Controls/CNC Controls/GrblConfigControl.xaml	1	0
simulator/sim-build.json	1	0
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	28	0

Adds first-class connection setup to the sender: pick USB (serial), Ethernet (host:port, now accepting hostnames as well as IPv4), or a local grblHAL **simulator** from a tab in the connection dialog, and (re)connect at any time from a menu. (*Updated 2026-06-20: the simulator is now run standalone and connected to over a port; the launch/download/My-Machine dialog was stripped out, and connection-loss + comment-forwarding fixes were folded in.*)

- **Simulator tab — connect-only:** the simulator now runs *standalone* — the user launches grblHAL_sim.exe directly (it opens its own 3D view + config window and listens on a TCP port), and ioSender simply connects to 127.0.0.1:<port>. The tab is reduced to a single *Port* field (“Launch grblHAL_sim.exe first, then connect”); ioSender no longer launches, downloads or manages the simulator process.

- **Connect / Reconnect:** a File > Connect... item opens the dialog; while connected it becomes *Reconnect...* (disconnects, then re-opens the dialog so a different target can be chosen). The app now stays open when started without a connection instead of exiting, so the menu is reachable.
- **Remembered network host:** the dialog's network tab defaults to the most recent IP that connected successfully (persisted as `Config.NetworkHost`) rather than always the mDNS name `grblHAL.local`. It starts empty; on a serial connection it is seeded from the controller's \$I-reported IP if still unset — so after one USB session a later reconnect already offers the controller's real address. Empty falls back to `grblHAL.local`; the bundled simulator (127.0.0.1) is excluded.
- **Prefer network connection (opt-in):** a Settings:App checkbox (`Config.PreferNetwork`, default off). After a serial/USB connection whose \$I reports an IP, ioSender probes `<ip>:23` and, if it answers, automatically switches the live link to the network — status line: *"Connection migrated to network (ip:23)"* — falling back to the serial port if the network connect fails. The probe runs off the UI thread; the switch is deferred and guarded against re-entry, and only fires from a serial link with a known IP.
- **Target status & cues:** the status bar shows the current connection target (`GrblViewModel.ConnectionTarget`), **green** when connected and **red** when not. The connect dialog opens on the tab matching the active target (Serial / Network / Simulator, disambiguated via the `StartSimulator` flag) and **green**-bolds that header; the XL window background tints **pale yellow** while connected to the **simulator** (restored to grey on a real target or when disconnected), so a virtual machine is unmistakable.
- **"Not connected" on a dropped socket:** when the link drops (e.g. the simulator window is closed) the reconnect loop keeps the target name set, so the target box would otherwise still read connected. An `IsConnectionLost` trigger now turns the XL target box red and shows *Not connected* until the connection is re-established.
- **Stop the job on disconnect:** if the controller connection drops *during a running job*, the **client-side** stream is torn down (job state reset to idle) so the UI no longer hangs waiting on ok responses that will never arrive — previously this was handled cleanly only while idle. This is a Stop, not a feed-hold, and because the link is already gone it cannot command the controller; what the machine does physically on comms loss is up to the firmware.
- **Always send comments to the simulator:** g-code comments are forwarded to the simulator regardless of the app's *Send comments* setting — the simulator reads them for tool/stock metadata (`(TOOL ...)`, `(STOCK ...)`) that drives its 3D view and material-removal carve.
- **Startup ordering:** `AppConfig.SetupAndOpen` is split into `LoadConfig` (run synchronously at construction, so config is available before any control's `Loaded` handler reads it) and `OpenConnection` (deferred to `ApplicationIdle` so the main window paints before the — possibly blocking — connection dialog). Transport is chosen by target string (`COMx` vs `host:port`) rather than a leading-digit IPv4 check.
- **Copy current settings to the simulator:** a *Copy to simulator* button on the `grbl:Settings` tab (next to Save) mirrors the live controller settings into the bundled simulator's "My Machine" EEPROM via `SimulatorManager.BuildMyMachineEeprom`, so a later simulator connection boots with this machine's configuration.

Builds clean (CNC Controls and the full ioSender XL + classic solutions) off **master**. The "My Machine" EEPROM builder is now wired to the *Copy to simulator* button (above); the `SimulatorManager` launch / web-builder-download machinery is no longer wired to the (now connect-only) dialog — a candidate for removal in a follow-up. No simulator binary is committed; see `simulator/README.md`.

PR 16 Validate controller (check-mode g-code conformance test)

Branch	pr/validate
Depends on	Stacked on pr/connect-simulator (PR 15).
Compare	https://github.com/stevenwood/ioSender/compare/pr/connect-simulator...pr/validate

File	+	-
CNC Controls/CNC Controls/ValidateProcessor.cs	1091	0
CNC GCodeViewer/CNC GCodeViewer/Renderer.xaml.cs	81	16
ioSender XL/ioSender XL/MainWindow.xaml.cs	3	21
CNC Controls/CNC Controls/CNC Controls.csproj	1	0
CNC Controls/CNC Controls/LibStrings.xaml	3	0
ioSender XL/ioSender XL/MainWindow.xaml	1	1
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	21	0
Locale/*/csv/ioSender.resources.*.csv (7 locales)	7	0

Replaces the placeholder *Validate controller* action (PR 15) with a real, in-app conformance test: it streams a g-code program tailored to the connected controller's reported capabilities and reports which commands it accepts — without moving the machine.

- **Capability-tailored test:** generated from \$I build options, axis count, \$32 mode, tool count, aux-I/O counts and the work coordinate systems present, so a feature the firmware was never built with is not tested (and cannot be reported as a false failure).
- **Check mode, no motion:** streamed in \$C check mode and parsed only — the machine never moves, so homing and a clear envelope are not required. One feature per line, so an `error:N` pinpoints exactly which command the controller rejected.
- **Robust against grbl's check-mode behaviour:** a check-mode error *latches* the parser (every later line then errors), so the run recovers on each error — reset, re-enter check mode (unlocking first if the reset re-alarmed a homed machine), re-apply the modal set-up — then resumes, always re-confirming check mode before sending another line so a test line can never reach the controller as real motion.
- **Non-destructive:** check mode *commits* G10/G92 writes, so the run snapshots and restores the work offsets / tool table and avoids the un-restorable writes (G28.1/G30.1, and G92 when an offset is active). Machine settings (\$\$) are never written.
- **Progress & results:** a small non-modal panel shows a live pass/fail tally and the current test as it streams; on completion a *View Summary* button opens the full report (grouped by category, error code/message per failure, the pre-run parameter snapshot, Copy-to-clipboard). The controller is left in `Idle` with check mode off.
- **3D visualization:** the passed bounded-motion features are assembled into a runnable program (absolute G90 moves at a fast feed) and loaded into the buffer, so the user can press Cycle Start and watch the toolpath run in the 3D view via the normal job path. The viewer also gains an *always-active machine scene* (work envelope, axes and a live tool cone shown when homed even

with no program loaded), plus fixes to the tool/executed-trail animation subscription and a bounded executed-trail advance (an out-of-range block was an unbounded spin).

Right-click the **Target** status item → *Validate controller*. Builds clean on `pr/connect-simulator`; the only failures on a stock grblHAL are commands it genuinely does not implement (e.g. `G90 . 1`, `G61 . 1`, `G64`, `M52`; `M56` needs parking-override enabled).

PR 17 Restore main window position across launches

Branch `pr/window-restore`

Depends on Stacked on `pr/connect-simulator` (PR 15) — the restore runs in its `CompleteStartup`.

Compare <https://github.com/stevenwood/ioSender/compare/pr/connect-simulator...pr/window-restore>

File	+	-
<code>ioSender XL/ioSender XL/MainWindow.xaml.cs</code>	58	7
<code>CNC Controls/CNC Controls/AppConfig.cs</code>	2	0

The "Restore last window size on startup" option restored only the window *size*; the position was discarded (clamped to the top-left). This persists the position too.

- **Position persisted:** new `WindowLeft/WindowTop` settings, saved on close (using `RestoreBounds` when maximized so the un-maximized rectangle is stored) and restored on startup — but only when the saved rectangle lands on a currently-connected monitor (checked against the whole virtual desktop), so a window saved on a since-removed screen can't open off-screen.
- **Takes effect immediately:** the live "save" flag was only set at startup, so toggling the option mid-session did nothing until a restart. It now updates live and captures + persists the current placement the instant the option is enabled.

Builds clean on `pr/connect-simulator`. Stacked there because the size/position restore lives in that branch's `CompleteStartup`; the underlying `KeepWindowSize` option is from `master`.

PR 18 grbl:Settings — live edits, change highlight, revert & snapshots

Branch	pr/grbl-settings
Depends on	Off master, independent.
Compare	https://github.com/stevenwood/ioSender/compare/master...pr/grbl-settings

File	+	-
CNC Core/CNC Core/Grbl.cs	356	15
CNC Controls/CNC Controls/GrblConfigControl.xaml	49	6
CNC Controls/CNC Controls/GrblConfigControl.xaml.cs	39	8
CNC Controls/CNC Controls/Widget.cs	25	14
CNC Controls/CNC Controls/RestorePointDialog.xaml	41	0
CNC Controls/CNC Controls/RestorePointDialog.xaml.cs	65	0
CNC Controls/CNC Controls/CNC Controls.csproj	7	0
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	77	0

Orca/PrusaSlicer-style indication of which controller \$ settings you have changed, on the grbl:Settings **Basic** tab, plus live editing feedback, granular revert and automatic per-Save restore points. Applies to both the grblHAL settings tree and the classic-grbl grid.

- **Live edits in the left-hand list:** edits stage in a pending-changes map (`GrblSettings.PendingEdits`) that the list reads via a new `EditValue`, so the value and its highlight update *immediately* without mutating the controller value. Checkboxes/radios commit on change; text/numeric editors commit on lost focus. Pending edits are flushed to `Value` and cleared on Save; discarded on Reload/Restore.
- **Two highlight states:** **orange/bold** = unsaved edit (`IsEdited`); **blue** = saved to the controller this session but still different from the session-start value (`IsSavedModified`). Groups roll up the same way.
- **Revert from a right-click menu:** *Revert to value at startup* on a setting, and *Revert all in group to value at startup* on a group node (staged as a pending edit, written on next Save).
- **Snapshot on Save + Restore picker:** every Save writes a timestamped restore point (full settings dump in the Backup format, led by a `; changes (N): old→new` comment block), per controller identity, keeping the last 20. The **Restore** button opens a picker listing restore points newest-first with a changed-count column and a per-row tooltip showing exactly what each Save changed; *Browse...* falls back to any backup file.
- **Baselines, cleanly separated:** `GrblSettingDetails` tracks the current value, the frozen *startup* value (highlight) and the *loaded* controller value (drives `IsDirty`). Making `IsDirty` mean "differs from the controller" rather than "changed" fixes a spurious "settings changed, save now?" prompt when reverting an edit back to the controller value.
- **Bitfield flag tooltip:** `BITFIELD/XBITFIELD` settings still display numerically, but hovering the value shows the set flags decoded to their labels (one per line, N/A entries skipped) via `GrblSettingDetails.BitfieldLabels`.

Builds clean off `master` (CNC Controls and the full ioSender solution); verified against the bundled grblHAL simulator. Per-setting "revert to factory default" is intentionally deferred — grblHAL exposes no per-setting default (only the global

\$RST=\$ reset-all)), so factory revert would need a future firmware-side snapshot of as-flashed values.

PR 19 Console — inline terminal-style command prompt

Branch	pr/mdi-console
Depends on	Off master, independent.
Compare	https://github.com/stevenwood/ioSender/compare/master...pr/mdi-console

File	+	-
CNC Controls/CNC Controls/ConsoleControl.xaml.cs	117	0
CNC Controls/CNC Controls/ConsoleControl.xaml	28	4
CNC Core/CNC Core/GrblViewModel.cs	20	0
CNC Core/CNC Core/KeyPressHandler.cs	7	0
CNC Controls/CNC Controls/MDIControl.xaml.cs	5	16
CNC Controls/CNC Controls/MDIControl.xaml	1	1
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	42	0

Makes the **Console** tab read like a traditional terminal by adding a command input line at the bottom, while keeping the global single-line MDI strip for the other tabs (3D View, Program). A natural answer to "why is MDI a separate strip instead of a console prompt?" — now it can be both.

- **Reuses the MDI plumbing:** Enter routes the line through the existing MDICommand, which already echoes the command into the console's ResponseLog — so the typed command and its response read inline like a shell. No JobView changes.
- **Shared command history:** a single GrblViewModel.MDIHistory (newest first) is fed by both the MDI strip and the console prompt and surfaced in both — the strip's dropdown binds to it and the prompt recalls it with Up/Down (Esc clears). A command entered in either place is recallable in the other. (The view-model CommandLog is not populated for these entries, so it is not used.)
- **Same guards, auto-focus:** the prompt is locked out while a job runs (same as the MDI strip) and grabs focus when the console becomes visible (tab switch or the pop-out console window) so it's ready to type into.
- **Pop-out for free:** the prompt is self-contained in ConsoleControl, so the detachable console window (which hosts the same control) gets it too.
- **Output context menu:** right-click the response log for *Clear all*, *Clear up to here* (drops the clicked line and everything above it), and *Save...* (writes the in-memory log to a text file).
- **No jog conflict:** the keyboard-jog handler jogs whenever a key is *mapped* to jog (Up/Down are by default) *before* its per-key text-box guard, so the prompt's arrows would otherwise move the machine. ProcessKeyPress now forces no-jog when the focused element is a TextBox tagged "MDI", and the prompt is tagged accordingly — uniformly exempting both the MDI strip's edit box and the console prompt.

Builds clean off master (CNC Controls and the full ioSender solution); verified against the bundled grblHAL simulator: commands echo + execute, auto-focus, history recall (Up/Down step through prior commands), and an A/B test confirming Up jogs the DRO when a non-input element is focused but does not when the console prompt is focused. Keys are handled in PreviewKeyDown so the arrows reach the prompt rather than being consumed by the TextBox.

PR 20 3D view — Ctrl+click to jog + per-axis orientation

Branch	pr/click-to-jog
Depends on	Off master, independent.
Compare	master...pr/click-to-jog

File	+	-
CNC GCodeViewer/CNC GCodeViewer/Renderer.xaml.cs	164	52
CNC Core/CNC Core/Grbl.cs	26	1
CNC GCodeViewer/CNC GCodeViewer/RenderControl.xaml	11	7
CNC Core/CNC Core/GCodeEmulator.cs	3	0
CNC Controls/CNC Controls/AppConfig.cs	2	0

Ctrl+left-click in the 3D or top-down (XY) view jogs the machine to the clicked XY position — a quick coarse-positioning aid that complements the jog buttons (park over a corner to set work zero, check alignment, touch-screen rigs).

- **Safe by construction:** the move always retracts **Z to the top of travel first**, then rapids to the new XY, so the traverse can never plough through stock or fixtures. Only X/Y move; plain left-drag still rotates the camera.
- **How it maps:** the click ray is intersected with the work Z=0 plane (HelixToolkit UnProject) to recover an XY target, converted to machine coordinates ($MPos = WPos + WCO$), clamped to the soft-limit travel exactly as the jog limiter does, and emitted as two queued `$J=G53` jogs at the controller's max rate (`$110`–`$112`) so it moves at rapid speed.
- **Guarded:** requires homed + idle + max travel set + soft limits (`$20`) on, with a status-bar reason when a prerequisite is missing. Gated by a `GCodeViewerConfig.ClickToJog` setting (default on).
- **Orientation fix (prerequisite):** the rendered machine frame — work envelope, floor grid and crosshair — now honors the `$23` homing-direction mask + force-set-origin *per axis*, so the view matches any home corner (e.g. top-back-left, X+/Y-/Z-) instead of assuming +X/+Y. Standard +X/+Y/-Z machines render identically to before. `GrblInfo.ForceSetOrigin` now reads the live `$22` bit 3 rather than the `$I OPT 'Z'` flag (absent on some builds, e.g. the simulator), so the orientation is correct even when the option string omits it. The camera bounding box in the always-on machine scene is derived from the same per-axis envelope, fixing a mirrored home corner in the 3D view.
- **Toolbar tidy-up:** the 3D-view toolbar tooltips now show on disabled buttons and are reworded for consistency, the *save view* button is no longer needlessly gated, and the *show job envelope* button enables only with a file loaded. A null-tokens guard in `GCodeEmulator` avoids a crash when the machine scene renders with no program loaded.

Builds clean off `master` (CNC GCodeViewer chain). Verified on the author's machine: Ctrl+click retracts Z then rapids to the clicked XY at the configured max rate, and the envelope/grid orient to the real home corner.

PR 21 grbl:Settings — Machine Setup Wizard

Branch	pr/machine-setup-wizard
Depends on	Off master, independent.
Compare	master...pr/machine-setup-wizard

File	+	–
CNC Controls/CNC Controls/MachineSetupWizard.xaml.cs	795	0
CNC Controls/CNC Controls/MachineSetupWizard.xaml	278	0
CNC Controls/CNC Controls/MachineCatalog.cs	194	0
CNC Controls/CNC Controls/GrblConfigView.xaml.cs	30	0
CNC Controls/CNC Controls/CNC Controls.csproj	8	0
CNC Controls/CNC Controls/GrblConfigView.xaml	4	0
CNC Controls/CNC Controls/AppConfig.cs	2	0
CNC Controls/CNC Controls/IGrblConfigTab.cs	2	1
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	427	0

A guided, first-run **Machine Setup Wizard** tab in grbl:Settings that configures the machine-description settings a fresh controller needs — so a new machine can be described without hunting through the \$ list. Auto-selected when the machine looks unconfigured (no remembered machine, or \$130–\$132 all zero).

- **Single page, nothing written until applied:** the whole machine description is laid out on one page — machine selector, a clickable home-position picture, a per-axis table, and the remaining homing & limits questions — so it reads at a glance instead of an eight-step click-through. *Apply* writes the changes via `GrblSettings.Save()`.
- **Apply only when there's something to write:** Apply is disabled while the wizard's values already match the controller; the pending-change set recomputes on every edit (machine pick, field, reload). Numeric settings are compared by value, so a formatting-only difference (1 vs 1.000) is not flagged as a change. Hovering Apply lists the exact pending writes (\$id name: old → new).
- **Out of the way:** sits as the *last* grbl:Settings tab (rarely needed after initial commissioning), so Basic settings is the default tab.
- **Machine catalog:** a built-in catalog (`MachineCatalog.cs`) of common hobby machines as manufacturer → product → model drop-downs (or a custom X×Y), each carrying a sensible home corner and force-set-origin default; the first entry is a generic XYZ machine with limit switches. Picking a model pre-fills the page, which the user then confirms or tweaks.
- **Axis table:** an editable per-axis grid — travel limit (\$130–\$132), max rate (\$110–\$112), steps/mm (\$100–\$102), invert direction (\$3) and normally-closed limit (\$5) — edited in place.
- **Home corner:** a clickable isometric box — click the corner where the machine homes — sets the X/Y homing directions (\$23) and auto-enables force-set-origin (\$22 bit 3) on grblHAL; Z is fixed to the top of the gantry. This is the same convention that orients the 3D view (PR 20). The axis table also carries a per-axis **Home min (\$23)** checkbox kept in sync with the picture, so the homing direction is visible/editable per axis (Z's box is locked to “top”).

- **Homing & limits:** hard limits (\$21) default on, with the remaining global questions as a short list and the explanatory help moved into per-input tooltips. A right-justified *Firmware Info* button shows the live \$I build output in a non-modal dialog.
- **Remembered & forgettable:** the chosen machine is saved (`AppConfig.LastMachine`) and restored next launch — keeping the live controller values over the catalog preset on restore — and a *Forget machine* button clears it so the wizard reappears next time.
- **Correct write order & honest errors:** grblHAL rejects soft limits (\$20=1) unless homing is enabled (`error:10`). Apply now enables homing by the user's intent (writing \$22 even on a fresh controller where it is currently off, instead of gating on the live state) and writes soft limits in a second pass — after \$22 — since `GrblSettings.Save()` writes in ascending id order. Soft limits are only requested when homing will be on. On failure it lists the exact rejected \$ settings and the controller's reason rather than a generic “failed to write settings”.

Builds clean off `master` (CNC Controls and the full ioSender solution). UI verified by the author against a live controller and the bundled simulator; interactive \$3 direction-verify and homing-cycle-order editing were intentionally left out of this first cut. The first-run gate that forces the wizard to the foreground until a machine is applied — and its skip-when-connected-to-the-simulator behaviour — depend on connection-side plumbing and ride along in the integration branch rather than this stand-alone PR. The “copy this machine into the simulator’s My Machine profile” action now lives on the `grbl:Settings` tab ([PR 15](#)).

PR 22 Keyboard jog — keep active when Job-view focus drifts

Branch pr/keyboard-jog-focus
Depends on Off master, independent.
Compare [master...pr/keyboard-jog-focus](#)

File	+	-
ioSender XL/ioSender XL/MainWindow.xaml.cs	19	0
ioSender XL/ioSender XL/JobView.xaml.cs	4	1

Keyboard jogging only fired through `JobView.OnPreviewKeyDown`, which needs keyboard focus inside the Job view's tree. Interacting with a flyout, side panel or menu moves focus out, so the arrow keys stopped jogging until the view was re-focused (e.g. by switching tabs). This keeps jog alive on the Job page wherever focus has drifted.

- **Window-level forwarding:** the existing `MainWindow` tunneling `PreviewKeyDown` (always fires) forwards jog keys to `JobView.ProcessKeyPreview` when the Job view is the current view but is not keyboard-focused. The focused case is unchanged — `JobView` still handles it, including its MDI/DRO/spindle/work-params jog gates.
- **Skips text input:** forwarding is suppressed when focus is in any `TextBoxBase`, so typing in the MDI strip or console prompt never jogs.
- **Clean stop:** a mirrored `PreviewKeyUp` forwards the key-up too, so a continuous jog started while the view was unfocused still receives its release and stops (no text-input guard here — an in-progress jog must always cancel).

Builds clean off `master` (the full `ioSender` solution). Two-file change reusing the console-shortcut `PreviewKeyDown` hook already on `master`; `ProcessKeyPreview` is promoted to `public` so the window can forward into it.

PR 23 Go To — optional safe-Z (lift, traverse, descend)

Branch [pr/safe-z-goto](#)
Depends on Off master, independent.
Compare [master...pr/safe-z-goto](#)

File	+	-
CNC Controls/CNC Controls/GotoBaseControl.xaml.cs	34	8
CNC Controls/CNC Controls/AppConfig.cs	5	0
CNC Controls/CNC Controls/BasicConfigControl.xaml	1	0
Locale/*/csv/CNC.Controls.WPF.resources.*.csv (7 locales)	14	0

A **Go To** a work-coordinate origin (G54–G59.3), G28 or G30 was a single coordinated rapid — a straight diagonal in machine space that can drag Z through clamps, fixtures or tall stock on the way. This adds an optional safe-Z decomposition so the traverse always happens clear of anything standing up in Z.

- **Three-phase move:** with *Safe Z on Go To* enabled, each Go To becomes G53 G0 Z0 (retract to machine top), then G53 G0 X...Y... (traverse at the safe height), then G53 G0 Z... (descend to the target). Machine Z0 is the homed top — already top-minus-pull-off with force-set-origin — so it never re-trips the Z limit, and it needs no configured clearance height (it clears anything that physically fits under the gantry).
- **All Go To targets:** applies uniformly to the selected work origin and to G28/G30, read from the same \$#-populated coordinate table the work-origin button already used (so G28/G30 get true X/Y-then-Z, not a firmware diagonal). Rotary axes travel with X/Y; only Z is separated.
- **Guarded, with a clean fallback:** gated on the *Safe Z on Go To* option (Settings:App → Main, default on), the machine being **homed** (machine coordinates valid) and **soft limits** (\$20) on so the three rapids are envelope-checked. If any is missing it falls back to the original single coordinated move — no behaviour change for unhomed/soft-limits-off setups.

Builds clean off **master** (both apps). The setting lives in the Base app config so it shows in the always-present Main settings panel regardless of jog mode; grbl's junction deviation (~0.01 mm) means the corners are effectively full stops, so no dwell is needed between phases.

PR 24 comms — fix telnet/websocket UI deadlock

Branch `pr/telnet-deadlock-fix`
Depends on Off master, independent.
Compare [master...pr/telnet-deadlock-fix](#)

File	+	-
CNC Core/CNC Core/TelnetStream.cs	17	6
CNC Core/CNC Core/WebsocketStream.cs	12	4

Over a telnet or websocket connection the UI could freeze whenever a modal message box (e.g. a macro M0/MBOX hold) was open while polling continued — a lock-ordering **deadlock** between the read callback and the UI thread.

- **The deadlock:** `ReadComplete` ran a synchronous `Dispatcher.Invoke(DataReceived)` *while holding* `lock(input)`. The UI thread's `PurgeQueue` also takes `lock(input)`, so once the dispatcher was busy (a modal pumping its own message loop) the read callback waited on the UI thread while the UI thread waited on the lock — a classic cyclic wait that hung the app.
- **The fix:** extract the complete replies from the buffer *under* the lock, then release it *before* dispatching them to `DataReceived`. The serial and Eltima streams already dispatched after releasing the lock (via `BeginInvoke`); this brings telnet/websocket in line.

Builds clean off upstream `master` (2.0.47); a pure comms-layer fix, no UI or feature change. Surfaced while testing the ATC Start Job sequence (PR 25), whose install-probe MBOX hold kept an active telnet poll — exactly the deadlock window.

PR 25 ATC tool-change macro provisioning (Install ATC + Start Job)

Branch [pr/atc-macros](#)

Depends on Stacked on [pr/sdcard-filesystems](#) (PR 14, for the SD Card tab's filesystem upload). Runtime: the Start Job macro's directives + `0<cal>` CALL forwarding need [pr/macro-processor](#) (PR 11).

Compare [pr/sdcard-filesystems...pr/atc-macros](#)

File	+	-
CNC Controls/CNC Controls/AtcMacros.cs	369	0
CNC Controls/CNC Controls/SDCardView.xaml.cs	80	3
CNC Controls/CNC Controls/SDCardView.xaml	4	1
CNC Controls/CNC Controls/CNC Controls.csproj	11	0
CNC Core/CNC Core/Grbl.cs	14	1
CNC Core/CNC Core/YModem.cs	14	5
ioSender XL/ioSender XL/JobView.xaml.cs	6	0
ioSender/ioSender/JobView.xaml.cs	6	0
macros/tc.macro	105	0
macros/probe_tfl.macro	140	0
macros/start_job.macro	52	0
macros/cal.macro	3	0

Turnkey **repeatable tool change** for ATC controllers: ioSender ships the controller-side tool-change macro set and installs it to the controller's persistent **LittleFS**, then seeds an ioSender-side "Start Job" macro that drives the home → set-WCS → reference-toolsetter → run sequence. The novice only sets G28/G30/G59.3 and supplies a 3D probe + toolsetter.

- **Embedded macros + provisioning:** AtcMacros.cs carries cal/probe_tfl/tc.macro as embedded resources and uploads them to /littlefs over **YModem** (absolute /littlefs/<name> path so they land on the right filesystem even with an SD card mounted at root; a atc.sum SHA-256 sidecar detects drift / re-installs).
- **Explicit "Install ATC macros" button** on the SD Card tab is the *only* provisioning trigger — user-initiated, re-verifying the filesystem each click. Auto-on-connect/auto-on-show were removed after proving fragile against controller-I/O timing (could wedge the link or hang on close).
- **\$I capability parsing** (Grbl.cs): ATC=1 → HasATC, ATC=0 → AtcMacrosRequired (an ATC is configured but its tc.macro is missing — prompt to install + reboot), YM → HasYModem. A 2-arg YModem.Upload(path, remoteName) overload targets an absolute remote path.
- **Start Job macro** (both apps): seeded on connect to an ATC controller (@start_job.macro, run line-by-line through the macro pre-processor). The controller-side macros it CALLs stay on LittleFS, resolved by `0<cal>` CALL / M6. The Start Job go-to G30/G28 moves are written as an explicit safe-Z sequence (lift to machine top, traverse X/Y, descend) rather than a bare diagonal rapid; the Z probes descend to -140 (below the spoilboard, within \$132).
- **Embed-on-Build:** CNC Controls.csproj disables VS's fast up-to-date check so edits to the external ..\..\macros*.macro embedded resources are actually re-embedded on a normal Build

(the fast check ignores external files and would otherwise ship a stale copy).

Builds clean in Release for both apps; the full Start Job sequence was verified end-to-end on hardware (2026-06-18). Kept self-contained on PR 14 by seeding the Start Job macro without an auto function-key (that nicety needs PR 10's **Macro.FKey**); assign one in the Macro manager if wanted. The **O<cal> CALL** error:81 fix lives in PR 11 (label/keyword gap-close) plus a firmware-side macro-search-path fix.

Branch	pr/editable-predefined-offsets
Depends on	Off master, independent.
Compare	master...pr/editable-predefined-offsets

File	+	-
CNC Controls/CNC Controls/OffsetView.xaml.cs	21	2

The predefined offsets G28 and G30 were read-only in the Offsets view — you could only store the *current* machine position. This makes them **editable**: type a target and *Set* now honours it.

- **Set rapids, then stores:** because G28.1/G30.1 can only capture the live position, *Set* first rapids the machine to the edited target with G53 G0, then stores it with G28.1/G30.1. A confirmation prompt spells out the move first (it physically moves the machine); a pending unit change is honoured around the move.
- **Everything else unchanged:** non-predefined work offsets keep their existing behaviour.

Builds clean off **master** (CNC Controls and the full ioSender solution). One-file change to **OffsetView**.

PR 27 Dialogs — center owner-less modal dialogs

Branch pr/dialog-centering
Depends on Off master, independent.
Compare [master...pr/dialog-centering](#)

File	+	-
CNC Controls/CNC Controls/MPGPending.xaml	1	0
CNC Controls/CNC Controls/AppConfig.cs	1	1
CNC Controls Probing/CNC Controls Probing/ProbeVerify.xaml	1	0
CNC Controls Probing/CNC Controls Probing/ProbingViewModel.cs	1	1

Two modal dialogs — **MPGPending** (the “MPG mode active” prompt shown during the connect handshake) and **ProbeVerify** (probe-connection check) — set neither `Owner` nor `WindowStartupLocation`, so they opened as independent OS-placed top-level windows with their own taskbar button instead of centering over `ioSender`.

- **Owner + CenterOwner:** each now sets `Owner` to the main window at the call site and `WindowStartupLocation=CenterOwner + ShowInTaskbar=False` in XAML, so they center over the client area and stay attached to the app — matching every other dialog in the sender.

Builds clean off `master`. The other modal dialogs already set an owner; the owned-but-not-centered ones (g-code transform / importer dialogs) were left as-is for now.