Lenovo

Lenovo XClarity Controller REST API Guide



Note: Before using this information, read the general information in "Notices" on page cclxxvii.
Fifth Edition (Oct 2020)
© Copyright Lenovo 2017, 2020. LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration (GSA) contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Contents

Chapter 1. Introduction 1	Resource NetworkDeviceFunction 47
Authentication Methods	GET - Collection of Network device
Lenovo Extended Registries	function 48
Tools for Redfish	GET – Network device PCIe functions 48
Chapter 2. Service Root 5	Chapter 7. Power, thermal and
Resource ServiceRoot	redundancy 51
GET – Service root properties 5	Resource Power
	GET – Power management properties 51
Chapter 3. Session Management 9	PATCH - Update power management
Resource SessionService 9	properties
GET – Session management properties 9	Resource Power (Flex System Enterprise Chassis or Lenovo D2 Enclosure)
Resource Session	GET – Power management properties 67
GET – Session properties 10	Resource Thermal
POST- Create a session	
DELETE- Delete a session	GET – Thermal management properties 68
Observant Assessment Management 40	Chapter 8. BMC Management 73
Chapter 4. Account Management 13	Resource Manager
Resource AccountService	GET – BMC management properties 73
GET – Account management properties 13	PATCH – Update BMC time zone and other
Resource ManagerAccount	oem properties
GET – Account properties	POST – BMC reset 81
PATCH – Update userid/password/role/	
PasswordChangeRequired	Chapter 9. Network management 83
Resource Role	Resource EthernetInterface (BMC NIC) 83
GET – Role properties	GET - Collection of BMC ethernet interface
PATCH – Update custom role privileges 24	properties
Chapter 5. Chassis Management 27	GET – BMC Ethernet properties 84
Resource Chassis	PATCH – Update BMC Ethernet configurations
GET – Collection for chassis	PATCH – Update BMC Ethernet over USB
GET – Chassis properties	configurations
PATCH – Update chassis asset tag and	Resource EthernetInterface (Server NIC) 98
location LED and other location properties 33	GET – Collection of server Ethernet
Resource Chassis (Flex System Enterprise Chassis	interfaces
or Lenovo D2 Enclosure	GET – Server Ethernet interface properties 99
GET - Collection for Flex System Enterprise	GET – Server Ethernet over USB
Chassis or Lenovo D2 Enclosure 37	properties
GET – Flex System Enterprise Chassis or	Resource HostInterface
Lenovo D2 Enclosure properties	GET - Collection of host interface 102
Chapter 6. Network Adapter	GET – Host interface properties 103
Devices 41	PATCH – Enable/disable host interface 104
Resource NetworkAdapters	Resource ManagerNetworkProtocol 105
GET – Collection of Network adapters	GET – BMC network services 105
GET – Network adapter properties 42	PATCH - Update BMC network service
Resource NetworkPort	configurations
GET – Network port properties 46	

Chapter 10. Serial Interface	Resource PCIeFunction	162
Management	GET – Functions of server PCIe functions	162
Resource SerialInterface	Resource PCIeSIot	164
GET – Collection of BMC serial interface 113	GET – Server PCIe slots	164
GET – BMC serial interface properties 114	Resource Processor	166
PATCH - Update BMC serial interface	GET – Collection of CPUs	166
configurations	GET – CPU properties	167
Chantar 11 Virtual Madia	Resource ProcessorMetric	170
Chapter 11. Virtual Media	GET – Processor metric properties	170
Management	Resource Memory Metrics	
Resource VirtualMedia	GET – memory metrics properties	
GET – Collection of virtual media		
GET – Virtual media properties	Chapter 15. Storage	
PATCH – Insert/Eject a virtual media 119	Management	
Chapter 12. Server Management121	Resource Storage	175
Resource ComputerSystem	GET – Collection of storage controllers	175
GET – Collection for server	GET – Storage controller properties	176
GET – Server properties	Resource Drive	180
PATCH – Update next-one-time boot	GET – Drives managed by storage	
configurations and other properties 130	controller	
POST – Server reset operations	Resource Volume	184
1 001 001101100010 porazione. 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	GET – Volumes managed by storage	404
Chapter 13. Log Service and Event	controller	184
Log	Chapter 16. BIOS Setting and Boot	
Resource LogService	Management	187
GET - Collection of BMC log services 133	Resource Bios	
GET – Service for BMC active logs 134	GET – Resource for BIOS	
GET – Service for BMC event logs 135	POST – Change BIOS password settings	
GET – Service for BMC audit event logs 137	POST – Reset BIOS operation	
GET – Service for BMC Maintenance event	GET – The pending BIOS settings	
logs	PATCH – Update pending BIOS settings	
GET - Service for BMC Service Advisor event		
logs	Resource AttributeRegistry	
POST – Clear event logs 140	GET – BIOS attribute registries	
Resource LogEntry	Resource SecureBoot	
GET – BMC active log entries 141	GET – Secure boot properties	
GET – BMC Platform event log entries 143	PATCH – Update secure boot properties	
GET – BMC Audit event log entries 144	POST – Reset secure boot keys	201
GET – BMC Maintenance event log entries 146	Chapter 17. Firmware Inventory and	
GET – BMC Service Advisor event log	Update Service	いっち
entries	Resource UpdateService	
Chapter 14. Server Inventory151	GET – Properties for firmware update	200
-	service	205
Resource Memory	PATCH- Update update service status	
GET – Collection of server memories 151	POST – Simple update for firmware	
GET – Server memory properties	POST – HTTP Push update for firmware	
Resource NetworkInterface	POST – Multipart HTTP Push update for	_ 12
GET – Collection of network interfaces 158	firmware	219
GET – Server network interfaces	Resource FirmwareInventory	
Resource PCleDevice	GET – Collection for firmware inventories on	
GET – Server PCIe devices 160	the server	224

GET – Firmware inventory properties 225	Resource MetricReport
Chapter 18. Task Management229	GET – MetricReport properties
Resource TaskService	Resource MetricDefinition
GET – Task service properties 229	GET – Collection of MetricDefinition
Resource Task	
GET – Task properties	GET – MetricDefinition inventory properties
Chapter 19. Event Service	Chapter 21. Job Management261
Resource EventService	Resource JobService
GET – Event service properties 233	GET - Job management properties 261
POST – Submit a test event	Resource Job
Resource Event Subscription	GET – Job properties
GET - Collection of event subscriptions 237	PATCH – Update Schedule properties 264
GET – Event subscriptions	
POST – Create a subscription 239	Chapter 22. Certificate
DELETE- Delete a subscription 241	Management
SSE subscription 242	Resource CertificateService
Event	GET – Certificate service properties 267
Event properties	POST – Generate CSR 268
	POST – Replace Certificate 270
Chapter 20. Telemetry	Resource CertificateLocations
Management	GET – Certificate locations properties 271
Resource TelemetryService	Resource Certificate
GET – Telemetry service properties 247	GET – Certificate properties 272
GET – Action info of	POST – Rekey
SubmitTestMetricReport 248	POST – Renew
POST – Submit a test Metric Report 249	Notices
Resource MetricReportDefinition 250	Trademarks cclxxviii
GET - Collection of MetricReportDefinition 250	
GET – MetricReportDefinition properties 252	Index

Chapter 1. Introduction

The Lenovo XClarity Controller (XCC) provides support for the industry standard Redfish Scalable Platforms Management API. The Redfish API can be used to access XCC data and services from applications running outside of the XCC. This allows for easy integration of Lenovo XCC capabilities into Lenovo or 3rd party software. Redfish uses RESTful interface semantics and JSON resource payload to perform system management via the HTTPS protocol. It is suitable for a wide range of servers, from stand-alone servers to rack mount and bladed environments, and scales equally well for large scale cloud environments.

The XClarity Controller currently supports Redfish Specification v1.8.0 and Redfish Schema Bundle 2019.2. This document explains how to use the Redfish functions of the XClarity Controller on ThinkSystem servers.

For more information on the Redfish industry standard, please refer to the following resources:

- DMTF Redfish Forum: http://dmtf.org/redfish
 - Schemas, Specs, Mockups, White Papers, FAQ, Educational Material & more.
- DMTF Redfish Developer Portal: http://redfish.dmtf.org
 - Educational material, Hosted Schema files, documentation & other links.
- DMTF Redfish Tools: http://github.com/dmtf
 - Open source tools and libraries to help developers get started with Redfish .
- Redfish User Forum: http://www.redfishforum.com
 - DMTF forum for questions, suggestions and discussion of all Redfish topics.

Authentication Methods

Redfish requires the use of a compliant TLS connection to transport the data. XCC Redfish interface supports both "Basic Authentication" and "Session Login Authentication". Per Redfish specification, the only resource that can accessed without requiring authentication is the service root "/redfish/v1/".

HTTP Basic Authentication (as defined by RFC7235) uses HTTP "Authorization" header field to authenticate requests from a user agent or client (like a web browser) to XCC Redfish service. The value of this header consists of credentials containing the authentication information of the user agent for the realm of the resource being requested. Below is an an example of doing this operation in curl:

```
curl https://10.10.0.128/redfish/v1/Systems/1 -X GET -k -H "Content-type: application/json" -H "Authorization: Basic VVNFUklEOlBBU1NXMFJE"
```

The credentials in this example are base64 encoding string of "USERID:PASSW0RD".

A client or user agent can also create a Redfish login session via the Session management interface described in "Session Management" section of this guide. The client creating login session should save "session-auth-token" returned from the HTTP response header field "X-Auth-Token". The "session-auth-token" is used to authenticate subsequent requests by setting the HTTP request header "X-Auth-Token" with the "session-auth-token". Below is an an example of doing this operation in curl:

```
curl https://10.10.0.128/redfish/v1/Systems/1 -X GET -k -H "Content-type: application/json" -H "X-Auth-Token: session-auth-token"
```

The maximum open session count is set to 16 and session could have timeout.

Lenovo Extended Registries

Registry resources assist in interpreting Redfish resources beyond what is defined in the Redfish Schema. Examples of registries include Message Registries, Event Registries and BIOS Attribute Registries.

Registries are themselves resources which provide static, read-only JSON encoded information. Standard registries published by DMTF are available for download from https://redfish.dmtf.org/registries . The XCC Redfish service provides a a collection of Registries at "/redfish/v1/Registries", which contain DMTF standard registries as well as Lenovo extended registries.

Message Registry

- In addition to the standard base message registry "Base.1.4.0.json", XCC provides the OEM registry "ExtendedError.1.1.0.json" to extend messages used by XCC Redfish service. The URIs for the registries are "/redfish/v1/schemas/registries/ ExtendedError.1.1.0.json", and "/redfish/v1/Registries/ LenovoExtendedWarning.1.0.0".

The registry for resource event ("/redfish/v1/Registries/ResourceEvent.1.0.2") defines messages to use for related changes on Redfish resources. The registry for task event ("/redfish/v1/Registries/ TaskEvent.1.0.1") defines the messages to use to present changes related to a Redfish task.

In firmware update processes, there are messages to present the update progress or errors encountered. Refer to the Lenovo Firmware Update Message Register (/redfish/v1/schemas/registries/ LenovoFirmwareUpdateRegistry.1.0.0.json) to get messages defined and know resolutions.

Event Registry

- XCC Redfish events reference messages that are defined in various message registries. There are two types of events in XCC:
 - "platform events" that are detected by hardware and software. This is a superset of the events corresponding to IPMI SEL. These events use the Redfish registry "/redfish/v1/schemas/registries/ EventRegistry.1.0.0.json".
 - "audit events" that record actions performed by users. Audit events uses the same registry EventRegistry.1.0.0.json as above.

• Bios Attribute Registry

 BIOS attributes use attribute registry file "/redfish/v1/schemas/registries/BiosAttributeRegistry,1.0.0. ison". The registry file contains inventory and configuration attribute information provided by Lenovo UEFI.

Privilege Registry

- The Redfish resources have access control according to privileges of an account requesting Redfish service. The privilege registry defines the required privileges to access a resource. In the registry there are mappings between required privileges and operation types permitted.

Tools for Redfish

Since Redfish is a REST API, standard REST clients can be used to interact with the service. This includes popular tools such as curl, as well as native access from scripting languages like Python and PowerShell. Postman is another example of an easy to use HTTP REST client tool. The tool is available from https:// www.getpostman.com/.

Lenovo provides some Python and PowerShell sample scripts to use Redfish. These are available as open source code on Lenovo's Github page http://github.com/lenovo/

• Lenovo Python Redfish Scripts: https://github.com/lenovo/python-redfish-lenovo

• Lenovo PowerShell Redfish Scripts: https://github.com/lenovo/powershell-redfish-lenovo

These scripts utilize Redfish API to manage Lenovo ThinkSystem servers. The list of scripts is growing over time. Currently, the scripts support hardware/firmware inventory, basic management of configuration and control, firmware updates, and alerts/eventing. The scripts can be used both remotely (out-of-band to the XCC Network) and locally (in-band on the ThinkSystem server, connecting to the XCC local host Network interface).

Other open source tools that support Redfish include Ansible, which added support for Redfish starting with version 2.7, in the form of three modules for Remote Hardware Management. These modules are tested on Lenovo ThinkSystem servers:

- redfish_facts: https://docs.ansible.com/ansible/latest/modules/redfish_facts_module.html
- redfish_command: https://docs.ansible.com/ansible/latest/modules/redfish_command_module.html
- redfish config: https://docs.ansible.com/ansible/latest/modules/redfish config module.html

In addition, DMTF provides some open source tools for Redfish development and support. And the Redfish toolsets of DMTF grow and gain version updates over time. These are available at the DMTF Github page: https://github.com/DMTF

DMTF Redfish Tool	Description of Tool
Redfish Mockup Creator	A python3.4 program that creates a Redfish Mockup folder structure from a real live Redfish service
Redfish Service Validator	The Redfish Service Validator is a Python3 tool for checking conformance of any "device" with a Redfish service interface against Redfish CSDL schema
Redfish Tool	A Python34 program that implements a command line tool for accessing the Redfish API
Redfish Interface Emulator	The Redfish Interface Emulator can emulate a Redfish- based interface statically (GET) or dynamically (POST, PATCH, DELETE)
Redfish Mockup Server	A simple Python 3.4 program that can be copied into a folder at the top of any Redfish mockup and can serve Redfish requests on the specified IP/port.
Python Redfish Library	Python library for interacting with devices which support a Redfish Service

Chapter 2. Service Root

Resource ServiceRoot

The resource represents the root of the Redfish service. All other resources accessible through the Redfish interface on the XCC are linked directly or indirectly from the Service Root.

Number of Resources	1
Resource Path	/redfish/v1/
Schema file	ServiceRoot_v1.xml

GET - Service root properties

Use the GET method to retrieve properties in Service Root (/redfish/v1/) for Redfish service.

Request URL

https://<BMC_IPADDR>/redfish/v1/

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
ld	String	"RootService".
Name	String	"Root Service".
Description	String	"This resource is used to represent a service root for a Redfish implementation."
Vendor	String	"Lenovo"
SessionService	Link	A reference link to session service resource.
Managers	Link	A reference link to a collection of managers.
RedfishVersion	String	Version of the implemented Redfish service.
UUID	String	Unique identifier for the service instance.
Chassis	Link	A reference link to chassis resource.
Tasks	Link	A reference link to a collection of tasks.
EventService	Link	A reference link to event service resource.
JsonSchemeas	Link	A reference link to Json Schema resource.
AccountService	Link	A reference link to account service resource.
CertificateService	Link	A reference link to certificate service resource.
Systems	Link	A reference link to a collection of systems.
Registries	Link	A reference link to a collection of registries.

Field		Туре	Description
UpdateService		Link	A reference link to update service resource.
TelemetryService	ce	Link	A reference link to telemetry service resource.
Links		Object	Expanded.
Sessions		Link	A reference link to a collection of sessions.
ProtocolFeature	esSupported	Object	Expanded.
ExcerptQuery	У	Boolean	False.
			Indicates whether the 'excerpt' query parameter is supported.
FilterQuery		Boolean	True.
			Indicates whether the \$filter query parameter is supported.
OnlyMember	Query	Boolean	True.
			Indicates whether the 'only' query parameter is supported.
SelectQuery		Boolean	True.
			Indicates whether the \$select query parameter is supported.
ExpandQuery	/	Object	Expanded.
ExpandAll		Boolean	True.
			Indicates whether the \$expand support of asterisk (expand all entries) is supported.
Levels		Boolean	True.
			Indicates whether the expand support of the \$levels qualifier is supported by the service.
Links		Boolean	True.
			Indicates whether the \$expand support of tilde (expand only entries in the Links section) is supported.
MaxLevels		Integer	2.
			Indicates the maximum number value of the \$levels qualifier in \$expand operations.
NoLinks		Boolean	True.
			Indicates whether the \$expand support of period (only expand entries not in the Links section) is supported.

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"Tasks": {
    "@odata.id": "/redfish/v1/TaskService"
"Chassis": {
    "@odata.id": "/redfish/v1/Chassis"
"@odata.id": "/redfish/v1/",
"ProtocolFeaturesSupported": {
    "ExcerptQuery": true,
    "FilterQuery": true,
    "OnlyMemberQuery": true,
    "ExpandQuery": {
        "Levels": true,
        "NoLinks": true,
        "Links": true,
        "ExpandAll": true,
        "MaxLevels": 2
    "SelectQuery": true
"Links": {
    "Sessions": {
        "@odata.id": "/redfish/v1/SessionService/Sessions"
},
"RedfishVersion": "1.8.0",
"EventService": {
    "@odata.id": "/redfish/v1/EventService"
"JsonSchemas": {
    "@odata.id": "/redfish/v1/JsonSchemas"
"Systems": {
    "@odata.id": "/redfish/v1/Systems"
"@odata.id": "/redfish/v1/TelemetryService"
"Registries": {
    "@odata.id": "/redfish/v1/Registries"
"CertificateService": {
    "@odata.id": "/redfish/v1/CertificateService"
"UUID": "55833BF4-5BBB-11E7-997F-0A94EF402C57",
"Vendor": "Lenovo",
"Name": "Root Service",
"JobService": {
    "@odata.id": "/redfish/v1/JobService"
},
"Managers": {
    "@odata.id": "/redfish/v1/Managers"
"@odata.type": "#ServiceRoot.v1_5_2.ServiceRoot",
"SessionService": {
    "@odata.id": "/redfish/v1/SessionService"
},
```

```
"Id": "RootService",
   "@odata.etag": "\"3eb4a2dd56aeaf723ada88cbf6b1b7f4\"",
   "Description": "This resource is used to represent a service root for a Redfish implementation."
}
```

Chapter 3. Session Management

Resource SessionService

The resource represents a collection of sessions for the Redfish service. All session resources accessible through the interface link from the SessionService resource.

Number of Resources	1
Resource Path	/redfish/v1/SessionService
Schema file	SessionService_v1.xml

GET – Session management properties

Use the GET method to retrieve properties in SessionService resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/SessionService

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	Fixed string "SessionService".
Sessions	Object	This property shall contain the link to a collection of Sessions.
ServiceEnabled	Boolean	The value of this property shall be a boolean indicating whether this service is enabled.
SessionTimeout	Number	This is the number of seconds of inactivity that a session may have before the session service closes the session due to inactivity. The value should between 30 and 86400.
Description	String	This string is used to represent the Session Service Properties for a Redfish implementation.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

When the request is successful, a message body similar to the following is returned:

```
[
    "Id": "SessionService",
    "Name": "SessionService",
    "@odata.context": "/redfish/v1/$metadata#SessionService.SessionService",
    "@odata.etag": "\"e863af1e936fd7556be8ebb637f07117\"",
```

```
"@odata.type": "#SessionService.v1_1_4.SessionService",
    "SessionTimeout": 300,
    "@odata.id": "/redfish/v1/SessionService",
    "Sessions": {
        "@odata.id": "/redfish/v1/SessionService/Sessions"
    "ServiceEnabled": true,
    "Description": "This resource is used to represent a session service for a Redfish implementation."
}
```

Resource Session

The resource represents a session implementation for the Redfish service.

Number of Resources	Number of sessions established
Resource Path	/redfish/v1/SessionService/Sessions/{1N}
Schema file	Session_v1.xml

GET – Session properties

Use the GET method to retrieve properties in Session resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/SessionService/Sessions/{1...N}

Request body

None

Response body

Field	Туре	Description
UserName	String	The username who creates this session.
Password	String	This property is used in a POST to specify a password when creating a new session. This property is null on a GET.
SessionType	String	Session Type string and it is depended on the session type (ex. Redfish, WebGUI etc.)
Name	String	A session id value
Id	String	A session id value

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"@odata.id": "/redfish/v1/SessionService/Sessions/1945",
"Password": null,
"@odata.type": "\#Session.v1\_2\_1.Session",
```

```
"Id": "1945",
     "SessionType": "Redfish",
     "@odata.etag": "\"Od4c28aa83147126c9e1dbd5f5633bc8\"",
"Name": "1945",
     "UserName": "USERID"
}
```

POST- Create a session

Create a session resource for further access authentications.

Request URL

POST https://<BMC_IPADDR>/redfish/v1/SessionService/Sessions

Request body

Field	Туре	Description
UserName	String	The username who creates this session.
Password	String	This property is used in a POST to specify a password when creating a new session. This property is null on a GET.

Response body

Field	Туре	Description
UserName	String	The username who creates this session.
Password	String	This property is used in a POST to specify a password when creating a new session. This property is null on a POST response.
Session- Type	String	"Redfish"
Name	String	A session name
ld	String	A session id value

Response header

Field	Description
Location	Link to the session resource created.
X-Auth-Token An authentication code is generated when a new session is created.	

Status code

HTTP Status Code	Error Message ID
201	Created
401	NoValidSession
500	InternalError

Example

The following example is PATCH body.

```
{
   "UserName" : "USERID",
   "Password" : "PASSWORD"
}
The following example JSON response is returned:
{
    "@odata.id": "/redfish/v1/SessionService/Sessions/1945",
    "Password": null,
    "@odata.type": "#Session.v1_2_1.Session",
    "Id": "1945",
    "SessionType": "Redfish",
    "@odata.etag": "\"0d4c28aa83147126c9e1dbd5f5633bc8\"",
"Name": "1945",
    "UserName": "USERID"
}
```

DELETE- Delete a session

Use the DELETE method to delete session resource for Redfish service. Remove the session established for client access.

Request URL

DELETE https://<BMC_IPADDR>/redfish/v1/SessionService/Sessions/{1...N}

Request body

None

Response

None

Status code

HTTP Status Code	Error Message ID
204	No content
500	InternalError

Response example

None

Chapter 4. Account Management

Resource AccountService

The resource represents a collection of accounts and roles for the Redfish service. All existing sessions and roles resources accessible through the interface link from the AccountService resource.

Number of Resources	1
Resource Path	/redfish/v1/AccountService
Schema file	AccountService_v1.xml

GET – Account management properties

Use the GET method to retrieve properties in AccountService resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/AccountService

Request body

None

Response body

Field	Туре	Description
AccountLockoutThreshold	Number	The number of failed login attempts before a user account is locked for a specified duration. The value should be between 0 and 10.
AccountLockoutDuration	Number	The time in seconds an account is locked after the account lockout threshold is met. If the value is 0, the property will showshows null, otherwise it is 60~172800
AccountLockoutCounterResetEnabled	Boolean	The value indicates whether the threshold counter will be reset before account is locked for a specified duration. This property is hidden if AccountLockoutDuration is null, otherwise it shows identically to AccountLockoutDuration does.
Id	String	"AccountService".
Name	String	Fixed string "AccountService".
MaxPasswordLength	Number	The maximum password length that the implementation will allow a password to be set to. The value is 20 and cannot be modified.
MinPasswordLength	Number	The minimum password length that the implementation will allow a password to be set to. The value is 8 and cannot be modified.
Accounts	Object	This property shall contain the link to a collection of type ManagerAccount
Roles	Object	This property shall contain the link to a collection of type Role.
ServiceEnabled	Boolean	The value of this property shall be a boolean indicating whether this service is enabled. The value is "True" and cannot modified.
Description	String	This resource is used to represent a management account service for a Redfish implementation.

Field	Туре	Description
LocalAccountAuth	String	This property shall govern how the service uses the Accounts collection within this AccountService as part of authentication. Details about each of the modes are found in the description of the enum values.
LocalAccountAuth@Redfish. AllowableValues	Array	Items: string Item count: 4 The annotation is hidden on a Flex System compute node.
LDAP	Object	The first LDAP external account provider this AccountService supports.
AccountProviderType	String	This property contains the type of external account provider this resource references.
Authentication	Object	This property contains the authentication information for the external account provider.
AuthenticationType	String	This property contains the type of authentication used to connect to the external account provider.
Certificates	Link	The value of this property is a URI reference to a collection of certificates.
LDAPService	Object	This property contains additional mapping information needed to parse a generic LDAP service.
SearchSettings	Object	This property contains the settings needed to search an external LDAP service.
BaseDistinguishedNames	String	The base distinguished names to use when searching the LDAP service.
GroupNameAttribute	String	The attribute name that contains the name of the Group on the group LDAP entry.
GroupsAttribute	String	The attribute name that contains the Groups for a user on the user LDAP entry.
UsernameAttribute	String	The attribute name that contains the Username on the user LDAP entry.
ServiceAddresses	String	This property contains the addresses of the user account providers this resource references. The format of this field depends on the Type.
RemoteRoleMapping	Array	This property shall contain a collection of the mapping rules to convert the external account providers account information to the local Redfish Role.
RemoteRoleMapping[N]	Object	Expand
LocalRole	String	The value of this property shall contain the value of the Roleld property within a Role resource on this Redfish service in which to map the remote user or group.
RemoteGroup	String	The value of this property shall contain the name of the remote group (or in the case of a Redfish Service, remote role) that will be mapped to the local role referenced by this entity.
ServiceAddresses	Array	LDAP server address, array type
ServiceEnabled	Boolean	LDAP enablement

HTTP Status Code	Error Message ID
500	InternalError

Example

{

```
"Accounts": {
    "@odata.id": "/redfish/v1/AccountService/Accounts"
"AccountLockoutThreshold": 5,
"@odata.id": "/redfish/v1/AccountService",
"AccountLockoutDuration": 3600,
"ServiceEnabled": true,
"MinPasswordLength": 10,
"AccountLockoutCounterResetAfter": 3600,
"Description": "This resource is used to represent a management account service for a Redfish implementation.",
"LocalAccountAuth": "Enabled",
"LDAP": {
    "RemoteRoleMapping": [
        {
             "LocalRole": null,
             "RemoteGroup": null
        },
             "LocalRole": null,
             "RemoteGroup": null
             "LocalRole": null,
             "RemoteGroup": null
```

```
"LocalRole": null,
             "RemoteGroup": null
        },
             "LocalRole": null,
             "RemoteGroup": null
        }
    "Authentication": {
         "AuthenticationType": "UsernameAndPassword"
    "Certificates": {
         "@odata.id": "/redfish/v1/AccountService/LDAP/Certificates"
    },
    "ServiceAddresses": [
         "192.168.0.227:50637",
         "0.0.0.0:389",
         "0.0.0.0:389".
         "0.0.0.0:389"
    "LDAPService": {
         "SearchSettings": {
             "BaseDistinguishedNames": [
                  "ou=Users,dc=ibmbase,dc=com"
             ],
             "UsernameAttribute": "cn",
             "GroupsAttribute": "",
             "GroupNameAttribute": "memberOf"
    },
    "ServiceEnabled": true
"Name": "AccountService",
"Roles": {
    "@odata.id": "/redfish/v1/AccountService/Roles"
"0em": {
    "Lenovo": {
         "PasswordChangeOnNextLogin": true,
         "CurrentLoggedUsers": [],
         "GroupProfiles@Redfish.Deprecated": "The property is deprecated. Please use RemoteRoleMapping instead.",
```

```
"PasswordLength": 10,
        "PasswordExpirationPeriodDays": 90,
        "PasswordChangeOnFirstAccess": true,
        "@odata.type": "\#LenovoAccountService.v1\_0\_0.LenovoAccountServiceProperties",
        "MinimumPasswordChangeIntervalHours": 24,
        "MinimumPasswordReuseCycle": 5,
        "WebInactivitySessionTimeout": 20,
        "GroupProfiles": {
             "@odata.id": "/redfish/v1/AccountService/Oem/Lenovo/GroupProfiles"
        "PasswordExpirationWarningPeriod": 5
    }
"@odata.type": "#AccountService.v1 6 O.AccountService",
"LocalAccountAuth@Redfish.AllowableValues": [
    "Enabled",
    "Disabled",
    "LocalFirst",
    "Fallback"
"MaxPasswordLength": 32,
"@odata.etag": "\"fc78176d1e9673250dac95c513f397b6\"",
"AccountLockoutCounterResetEnabled": true,
"Id": "AccountService"
```

Resource ManagerAccount

The resource represents an account implementation for the Redfish service.

Number of Resources	Number of accounts created (1-12)	
Resource Path	/redfish/v1/AccountService/Accounts/{112}	
Schema file	ManagerAccount_v1.xml	

GET – Account properties

Use the GET method to retrieve properties in Account resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/AccountService/Accounts/{1...12}

Request body

None

}

Response body

Field	Туре	Description
Name	String	The format is UserX (X=1~12).
Password	String	The password of the account. Display null on a GET
Roleld	String	The value of this property shall be the ID of the Role resource that configured for this account

Field	Туре	Description
PasswordChangeRequired	Boolean	The value of this property shall be true if the password for this account must be changed before further access is allowed. Access to the service may be denied by the implementation if the password has not been changed. A ManagerAccount created with an initial PasswordChangeRequired value of true may be used to force a password change before first access using the account. When the 'Password' property for this account is updated, the service shall set the value to false.
UserName	String	The value of this property shall be the user name for this account.
Locked	Boolean	This property indicates that the account has been auto-locked by the account service because the lockout threshold has been exceeded. When set to true, the account is locked. A user admin can write the property false to manually unlock, or the account service will unlock it once the lockout duration period has passed.
Description	String	This resource is used to represent an account for the manager for a Redfish implementation.
Links	Object	Expand
Role	Link	Link to the Role instance which this account is mapped to.
AccountTypes	Array	Items: string Item count: 1
AccountTypes[N]	String	"Redfish"

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "Description": "This resource is used to represent an account for the manager for a Redfish implementation.",
    "Name": "User1",
    "Id": "1",
    "@odata.etag": "\"8d328fe085afa2ac5fe997c3ea7fa2ef\"",
    "Links": {
         "Role": {
              "@odata.id": "/redfish/v1/AccountService/Roles/Administrator"
    "AccountTypes": [
         "Redfish"
    ],
"PasswordChangeRequired": false,
'''' "/radfish/v1/Accoun
    "@odata.id": "/redfish/v1/AccountService/Accounts/1",
    "Password": null,
    "@odata.type": "#ManagerAccount.v1_4_0.ManagerAccount",
    "RoleId": "Administrator",
    "0em": {
         "Lenovo": {
              "SSHPublicKey": [
```

```
"",
"",
"",
"",
"",
"",
"AccessType": "Get",
"PrivacyProtocolPassword": null,
"Destination": "",
"AuthenticationProtocol": "None",
"PrivacyProtocol": "None"
},
"@odata.type": "#LenovoManagerAccount.v1_0_0.LenovoManagerAccount"
}

},
"Enabled": true,
"Locked": false,
"UserName": "USERID"
}
```

PATCH - Update userid/password/role/ PasswordChangeRequired

Use the PATCH method to update properties in Account resource for Redfish service.

Request URL

PATCH https://<BMC_IPADDR>/redfish/v1/AccountService/Accounts/{1...12}

Request body

Properties to be updated are shown as bellow, all of these properties can be changed individually.

Field	Туре	Description
UserName	String	The value of this property shall be the user name for this account.
Password	String	The password of the account. Display null on a PATCH response.
Roleld	String	The value of this property shall be the ID of the Role resource that configured for this account
PasswordChangeRe- quired	Boolean	The value of this property shall be true if the password for this account must be changed before further access is allowed. Access to the service may be denied by the implementation if the password has not been changed. A ManagerAccount created with an initial PasswordChangeRequired value of true may be used to force a password change before first access using the account. When the 'Password' property for this account is updated, the service shall set the value to false.

Response body

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example is **PATCH body**.

```
The following example JSON response is returned:
{
    "UserName": "USERID",
    "RoleId": "Administrator",
    "PasswordChangeRequired": false
}
The following example JSON response is returned:
{
    "AccountTypes": [
        "Redfish"
    "@odata.type": "#ManagerAccount.v1_4_0.ManagerAccount",
    "@odata.id": "/redfish/v1/AccountService/Accounts/1",
    "Password": null,
    "Links": {
        "Role": {
             "@odata.id": "/redfish/v1/AccountService/Roles/Administrator"
    "Name": "User1",
    "Enabled": true,
    "Id": "1",
    "0em": {
        "Lenovo": {
             "SSHPublicKey": [
             "SNMPv3Settings": {
                 "AccessType": "Get",
                 "PrivacyProtocolPassword": null,
                 "Destination": ""
                 "AuthenticationProtocol": "None",
                 "PrivacyProtocol": "None"
             "@odata.type": "#LenovoManagerAccount.v1 0 O.LenovoManagerAccount"
        }
    "RoleId": "Administrator",
    "UserName": "USERID",
    "PasswordChangeRequired": false,
    "@odata.etag": "\"fab97f1216ebd001a50b81fb6d23270b\"",
    "Locked": false,
    "Description": "This resource is used to represent an account for the manager for a Redfish implementation."
}
```

Resource Role

The resource represents a role implementation for the Redfish service.

Number of Resources	Number of roles presented (3-32)
Resource Path	/redfish/v1/AccountService/Roles/{Administrator, Operator,ReadOnly and CustomRole{N}}
Schema file	Role_v1.xml

GET - Role properties

Use the GET method to retrieve properties in Role resource for Redfish service.

Request URL

 $\texttt{GET https://} < BMC_IPADDR > \texttt{redfish/v1/AccountService/Roles/} \{ \texttt{Administrator,Operator,ReadOnly} \ \ \texttt{and} \ \ \texttt{CustomRole} \{ \texttt{N} \} \}$

Request body

None

Response body

Field	Туре	Description	
Name	String	Any of "Administrator, Operator, ReadOnly, and CustomRole{N}"	
ld	String	Any of "Administrator, Operator, ReadOnly, and CustomRole{N}"	
Roleld	String	Pre-defined roles: "Administrator", "Operator", and "ReadOnly"	
OemPrivileges	Array	The value of this property shall be the OEM privileges that this role includes. For pre-defined roles, this property shall be readOnly. For custom roles some implementations may not allow writing this property. The values can be	
		"Supervisor",	
		"ReadOnly",	
		"UserAccountManagement",	
		"RemoteConsoleAccess",	
		"RemoteConsoleAndVirtualMediaAcccess",	
		"RemoteServerPowerRestartAccess",	
		"AbilityClearEventLogs",	
		"AdapterConfiguration_Basic",	
		"AdapterConfiguration_NetworkingAndSecurity",	
		"AdapterConfiguration_Advanced"	
OemPrivileges[N]	String	The OEM privilege string. This value can depend on user selection. Refer to OemPrivileges@Redfish.AllowableValues.	
OemPrivileges@Redfish. AllowableValues	Array	The OEM privileges allowable for UPDATE opeation. This property is displayed in custom roles and hidden for Administrator, Operator and ReadOnly.	

Field	Туре	Description
OemPrivileges@Redfish.	String	The values should be :
AllowableValues[N]		"UserAccountManagement",
		"RemoteConsoleAccess",
		"RemoteConsoleAndVirtualMediaAccess",
		"RemoteServerPowerRestartAccess",
		"AbilityClearEventLogs",
		"Configuration_Basic",
		"Configuration_NetworkingAndSecurity",
		"Configuration_Advanced",
		"Configuration_UEFISecurity"
IsPredefined	Boolean	This role is pre-defined or not. Note: the pre-defined roles are Administrator, Operator, ReadOnly.
AssignedPrivileges	Array	DMTF Standard property.
Description	String	This resource is used to represent a user role for the user account for a Redfish implementation.

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON responses are returned:

Resource /AccountService/Roles/Administrator:

```
{
    "IsPredefined": true,
    "@odata.id": "/redfish/v1/AccountService/Roles/Administrator",
    "AssignedPrivileges": [
        "Login",
        "ConfigureManager",
        "ConfigureUsers",
        "ConfigureSelf",
        "ConfigureComponents"
    ],
"Name": "Administrator",
    "@odata.type": "#Role.v1_2_4.Role",
    "OemPrivileges": [
        "Supervisor"
    "Id": "Administrator",
    "@odata.etag": "\"aade26bf7b815e38f2c05df254f8a080\"",
    "RoleId": "Administrator",
    "Description": "This resource is used to represent a user role for the user account for a Redfish implementation."
}
```

```
Resource / Account Service / Roles / Operator:
{
    "IsPredefined": true,
    "Id": "Operator",
    "AssignedPrivileges": [
         "Login",
         "Configure Self",
         "ConfigureComponents"
    "Name": "Operator",
    "@odata.type": "#Role.v1 2 4.Role",
    "OemPrivileges": [
         "RemoteServerPowerRestartAccess",
         "AbilityClearEventLogs",
         "Configuration_Basic",
         "Configuration_NetworkingAndSecurity"
    "@odata.id": "/redfish/v1/AccountService/Roles/Operator",
    "@odata.etag": "\"e2f69b3d79821fd69587ccad12295c70\"",
    "RoleId": "Operator",
    "Description": "This resource is used to represent a user role for the user account for a Redfish implementation."
}
Resource / Account Service / Roles / Read Only:
    "IsPredefined": true.
    "Id": "ReadOnly",
    "AssignedPrivileges": [
         "Login",
         "ConfigureSelf"
    "Name": "ReadOnly",
    "@odata.type": "#Role.v1 2 4.Role",
    "OemPrivileges": [
        "ReadOnly"
    "@odata.id": "/redfish/v1/AccountService/Roles/ReadOnly",
    "@odata.etag": "\"aa8e529f6994a33c3a1f4c923f51c4cb\"",
    "RoleId": "ReadOnly",
    "Description": "This resource is used to represent a user role for the user account for a Redfish implementation."
}
Resource /AccountService/Roles/CustomRole12:
{
    "IsPredefined": false,
    "Id": "CustomRole12"
    "AssignedPrivileges": [
         "Login"
    "Name": "CustomRole12",
    "@odata.type": "#Role.v1 2 4.Role",
    "RoleId": "CustomRole12",
    "OemPrivileges": [
         "UserAccountManagement"
    "@odata.id": "/redfish/v1/AccountService/Roles/CustomRole12",
    "@odata.etag": "\"1cb07bd5147b5751700f2728e290e080\"",
```

```
"OemPrivileges@Redfish.AllowableValues": [
    "UserAccountManagement",
    "RemoteConsoleAccess",
    "RemoteConsoleAndVirtualMediaAccess",
    "Remote Server Power Restart Access",\\
    "AbilityClearEventLogs",
    "Configuration_Basic",
    "Configuration_NetworkingAndSecurity",
    "Configuration_Advanced",
    "Configuration_UEFISecurity"
"Description": "This resource is used to represent a user role for the user account for a Redfish implementation."
```

PATCH - Update custom role privileges

Use the PATCH method to update properties in Role resource for Redfish service.

Request URL

}

PATCH https://<BMC_IPADDR>/redfish/v1/AccountService/Roles/CustomRole{N}

Request body

Properties to be updated are shown as below, all of these properties can be changed individually.

Field	Туре	Description
OemPrivileges	Array	The value of this property shall be the OEM privileges that this role includes. For pre-defined roles, this property shall be readOnly. For custom roles some implementations may not allow writing this property. The values can be
		"UserAccountManagement",
		"RemoteConsoleAccess",
		"RemoteConsoleAndVirtualMediaAccess",
		"RemoteServerPowerRestartAccess",
		"AbilityClearEventLogs",
		"Configuration_Basic",
		"Configuration_NetworkingAndSecurity",
		"Configuration_Advanced",
		"Configuration_UEFISecurity"

Response

The response returns same content as GET operation with updated properties.

HTTP Status Code	Error Message ID
500	InternalError

Example

}

```
The following example is PATCH body.
{
   "OemPrivileges" : [
      " RemoteConsoleAccess "
}
The following example JSON response is returned:
{
    "IsPredefined": false,
    "Id": "CustomRole12",
    "AssignedPrivileges": [
         "Login"
    "Name": "CustomRole12",
    "RoleId": "CustomRole12",
    "@odata.type": "#Role.v1_2_4.Role",
    "OemPrivileges": [
         "RemoteConsoleAccess"
    "@odata.id": "/redfish/v1/AccountService/Roles/CustomRole12",
    "@odata.etag": "\"7465e9c5393c1fbc1da204d67d854889\"",
    "OemPrivileges@Redfish.AllowableValues": [
         "UserAccountManagement",
         "RemoteConsoleAccess",
         "RemoteConsoleAndVirtualMediaAccess",
         "RemoteServerPowerRestartAccess",
         "AbilityClearEventLogs",
         "Configuration_Basic",
         "Configuration NetworkingAndSecurity",
         "Configuration_Advanced",
         "Configuration_UEFISecurity"
    "Description": "This resource is used to represent a user role for the user account for a Redfish implementation."
```

Chapter 5. Chassis Management

Resource Chassis

This resource is used to represent a chassis for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/ Chassis/1
Schema file	Chassis_v1.xml

GET - Collection for chassis

Use the GET method to retrieve properties in Chassis collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	"ChassisCollection".
Members	Array	Items: A reference link to an element of Chassis.
Description	String	"A collection of Chassis resource instances."

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

When the request is successful, a message body similar to the following is returned:

GET - Chassis properties

Use the GET method to retrieve properties in Chassis resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/1

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
ld	String	Uniquely identifies the resource within the collection of Chassis. Always set to "1".
Description	String	Provides a description of this chassis resource.
LogServices	Link	A reference link to the log services resource contained in this chassis.
Power	Link	A reference link to the power resource contained in this chassis.
AssetTag	String	The user assigned asset tag for this chassis.
ChassisType String		This property indicates the type of physical form factor of this resource. Valid values include:
		RackMount. The server is a rack-mounted server.
		Blade. The server is a blade-based server.
		StandAlone. The server is a tower-based server.
EnvironmentalClass	String	The ASHRAE Environmental Class for this chassis.
HeightMn	Number	The height of the chassis.
IndicatorLED	String	The state of the indicator LED, used to identify the chassis. Valid values include:
		Off. The Indicator LED is off.
		Lit. The Indicator LED is lit.
		Blinking. The Indicator LED is blinking.
Links	Object	Expanded.
ComputerSystems	Array	An array of references to the computer systems contained in this chassis.
ComputerSystems[1]	Link	A reference link to a resource of computer system.
ContainedBy	Link	The value of this property is a URI reference to a chassis resource of the Flex System Enterprise Chassis or Lenovo D2 Enclosure.
CooledBy	Array	An array of IDs of resources that cool this chassis.
CooledBy[N]	Link	A reference link to a resource of cooling device.
Drives	Array	An array of resources to disk drives of in this chassis.
Drives[N]	Link	A reference link to a resource of disk drive.

Field	Туре	Description
ManagedBy	Array	An array of references to the managers responsible for managing this chassis.
ManagedBy[0]	Link	A reference link to a resource of manager responsible for managing this chassis.
ManagersInChassis	Array	An array of references to the managers contained in this chassis.
ManagerInChassis[0]	Link	A reference link to a resource of manager.
PCIeDevices	Array	An array of references to the PCle devices located in this chassis.
PCIeDevices[N]	Llnk	A reference link to a resource of PCIe device located in this chassis.
PoweredBy	Array	An array of IDs of resources that power this chassis.
PoweredBy[N]	Link	A reference link to a resource of power device.
Processors	Array	An array of references to the processors located in this chassis.
Processors[N]	Link	A reference link to a resource of processors located in this chassis.
Storage	Array	An array of references to the storage subsystems connected to or inside this chassis.
Storage[N]	Link	A reference link to a resource of storage device inside this chassis.
Manufacturer	String	The manufacturer of this chassis. Always set to "Lenovo" or "LNVO".
Model	String	The model number for the chassis.
Name	String	The name of the Chassis resource. Always set to "Chassis".
NetworkAdapters	Link	A reference link to a collection of network adapter resources contained in this chassis.
PartNumber	String	The part number of this chassis.
Power	Link	A reference link to a resource of power device contained in this chassis.
PowerState	String	The current power state of this chassis. Valid values include: On Off
SKU	String	The SKU for this chassis.
SerialNumber	String	The serial number of this chassis.
Thermal	Link	A reference link to the thermal resource contained in this chassis.
Status	Object	Contains the following elements.
Health	String	The current health of this chassis as indicated by the entries in the event log. Valid values include:
		OK: Normal. No warning or critical events in the event log of this chassis.
		Critical: A critical condition exists that requires immediate attention. At least one critical event in the event log of this chassis.
		Warning: A condition exists that requires attention. At least one warning in the event log (but no critical events) of this chassis.
State	String	"Enabled".
UUID	String	The UUID for this chassis.

Fi	eld	Туре	Description
Lo	ocation	Object	The location of chassis.
	Contacts	Array	An array of contact information.
	Contacts[0]	Object	Expanded
	ContactName	String	Name of this contact.
	PartLocation	Object	The part location within the placement.
	LocationOrdinalValue	Integer	The number that represents the location of the part. If LocationType is `slot` and this unit is in slot 2, the LocationOrdinalValue is 2.
	LocationType	String	The type of location of the part, such as slot, bay, socket and slot.
	ServiceLabel	String	The label of the part location, such as a silk-screened name or a printed label.
	Placement	Object	A place within the addressed location.
	Rack	String	The name of a rack location within a row.
	RackOffset	Integer	The vertical location of the item, in terms of RackOffsetUnits.
	RackOffsetUnits	String	The type of rack units in use.
	PostalAddress	Object	The postal address of the addressed Resource.
	Building	String	The name of the building.
	Location	String	The room designation or other additional information.
	Name	String	The name.
	Room	String	The name or number of the room.

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "SerialNumber": "NARVIR073",
    "@odata.id": "/redfish/v1/Chassis/1",
"IndicatorLED": "Lit",
    "PowerState": "On",
    "NetworkAdapters": {
         "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters"
    "EnvironmentalClass": "A4",
    "0em": {
         "Lenovo": {
             "@odata.type": "#LenovoChassis.v1 0 O.LenovoChassisProperties",
             "FruPartNumber": "01GT946",
             "Sensors": {
                  "@odata.id": "/redfish/v1/Chassis/1/Oem/Lenovo/Sensors"
             "ProductName": "ThinkSystem SR860",
             "LEDs": {
```

```
"@odata.id": "/redfish/v1/Chassis/1/Oem/Lenovo/LEDs"
             },
             "Slots": {
                 "@odata.id": "/redfish/v1/Chassis/1/Oem/Lenovo/Slots"
        }
    },
    "ChassisType": "RackMount",
    "Location": {
        "PostalAddress": {
             "Location": ""
             "Room": "10F",
             "Building": "ZJ",
             "Name": "Narvi-SR860V2-1"
        "Placement": {
             "RackOffset": 48,
             "Rack": "15C",
             "RackOffsetUnits": "EIA_310"
        "PartLocation": {},
        "Contacts": [
                 "ContactName": ""
             }
        ]
    "Model": "7Z59CT01WW",
    "PCIeSlots": {
         "@odata.id": "/redfish/v1/Chassis/1/PCIeSlots"
    "Description": "This resource is used to represent a chassis or other physical enclosure for a
Redfish implementation.",
    "Thermal": {
        "@odata.id": "/redfish/v1/Chassis/1/Thermal"
   },
"Links": {
"^rive
        "Drives": [],
         "CooledBy": [
             {
                 "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/0"
             },
             {
                 "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/1"
             },
             {
                 "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/2"
             },
             {
                 "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/3"
             },
             {
                 "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/4"
             },
             {
                 "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/5"
             },
             {
                 "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/6"
             },
             {
```

```
"@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/7"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/8"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/9"
        }
    ],
    "ComputerSystems": [
             "@odata.id": "/redfish/v1/Systems/1"
        }
    ],
    "PCIeDevices": [
        {
             "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/ob 1"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/slot 13"
        }
    ],
    "PoweredBy": [
        {
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/0"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/1"
        },
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/2"
        },
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/3"
   ],
"Storage": [],
    "ManagersInChassis": [
             "@odata.id": "/redfish/v1/Managers/1"
    ],
    "Processors": [
        {
             "@odata.id": "/redfish/v1/Systems/1/Processors/1"
        },
        {
             "@odata.id": "/redfish/v1/Systems/1/Processors/2"
    ],
    "ManagedBy": [
        {
             "@odata.id": "/redfish/v1/Managers/1"
"AssetTag": "asset tag",
"PCIeDevices": {
    "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices"
"Status": {
```

```
"State": "Enabled",
        "Health": "Critical"
    "Id": "1".
    "Name": "Chassis",
    "HeightMm": 177.8,
    "Power": {
        "@odata.id": "/redfish/v1/Chassis/1/Power"
    "SKU": "7Z59CT01WW",
    "@odata.type": "#Chassis.v1_10_0.Chassis",
    "PartNumber": "SB27A22721",
    "Manufacturer": "Lenovo",
    "@odata.etag": "\"fe34706c251e3daaea48d0a60565431b\"",
    "LogServices": {
        "@odata.id": "/redfish/v1/Systems/1/LogServices"
    "UUID": "55833BF4-5BBB-11E7-997F-0A94EF402C57"
}
```

PATCH – Update chassis asset tag and location LED and other location properties

Use the PATCH method to update properties in Chassis resource for Redfish service.

Request URL

PATCH https://<BMC_IPADDR>/redfish/v1/Chassis/1

Request body

Properties to be updated are shown as bellow, all of these properties can be changed individually.

Field	Туре	Error Message ID	
AssetTag	String	The user assigned asset tag for this chassis.	
		Maximum string length of AssetTag is 32.	
IndicatorLED	String	The state of the indicator LED, used to identify the chassis.	
		Available value is either "Lit" or "Blinking" or "Off".	
Location	Object	The location of chassis.	
Contacts	Array	An array of contact information.	
Contacts[0]	Object	Expanded	
ContactName	String	Name of this contact.	
Placement	Object	A place within the addressed location.	
Rack	String	The name of a rack location within a row.	
RackOffset	Integer	The vertical location of the item, in terms of RackOffsetUnits.	
PostalAddress	Object	The postal address of the addressed Resource.	
Building	String	The name of the building.	
Location	String	The room designation or other additional information.	

Field		Туре	Error Message ID
	Name	String	The name.
	Room	String	The name or number of the room.

Response

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example is PATCH body.

```
{
   "AssetTag" : "chassis in use"
```

After the PATCH operation runs successfully, querying the chassis resource returns below example JSON response:

```
{
    "SerialNumber": "NARVIR073",
    "@odata.id": "/redfish/v1/Chassis/1",
    "IndicatorLED": "Lit",
    "PowerState": "On",
    "NetworkAdapters": {
         "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters"
    "EnvironmentalClass": "A4",
    "0em": {
        "Lenovo": {
             "@odata.type": "#LenovoChassis.v1 0 O.LenovoChassisProperties",
             "FruPartNumber": "01GT946",
             "Sensors": {
                 "@odata.id": "/redfish/v1/Chassis/1/Oem/Lenovo/Sensors"
             "ProductName": "ThinkSystem SR860",
             "LEDs": {
                 "@odata.id": "/redfish/v1/Chassis/1/Oem/Lenovo/LEDs"
             "Slots": {
                 "@odata.id": "/redfish/v1/Chassis/1/Oem/Lenovo/Slots"
    "ChassisType": "RackMount",
    "Location": {
        "PostalAddress": {
             "Location": ""
             "Room": "10F",
             "Building": "ZJ",
             "Name": "Narvi-SR860V2-1"
        "Placement": {
```

```
"RackOffset": 48,
        "Rack": "15C",
        "RackOffsetUnits": "EIA_310"
    "PartLocation": {},
    "Contacts": [
             "ContactName": ""
},
"Model": "7Z59CT01WW",
"PCIeSlots": {
    "@odata.id": "/redfish/v1/Chassis/1/PCIeSlots"
"Description": "This resource is used to represent a chassis or other physical enclosure for a Redfish implementation.",
"Thermal": {
    "@odata.id": "/redfish/v1/Chassis/1/Thermal"
"Links": {
    "Drives": [],
    "CooledBy": [
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/0"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/1"
        },
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/2"
        },
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/3"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/4"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/5"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/6"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/7"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/8"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/9"
        }
    "ComputerSystems": [
             "@odata.id": "/redfish/v1/Systems/1"
    "PCIeDevices": [
             "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/ob 1"
```

```
},
        {
             "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/slot_13"
        }
    "PoweredBy": [
        {
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/0"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/1"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/2"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/3"
        }
    "Storage": [],
    "ManagersInChassis": [
        {
             "@odata.id": "/redfish/v1/Managers/1"
        }
    ],
    "Processors": [
        {
             "@odata.id": "/redfish/v1/Systems/1/Processors/1"
        },
             "@odata.id": "/redfish/v1/Systems/1/Processors/2"
        }
    ],
    "ManagedBy": [
        {
             "@odata.id": "/redfish/v1/Managers/1"
    ]
"AssetTag": "chassis in use",
"PCIeDevices": {
    "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices"
"Status": {
    "State": "Enabled",
    "Health": "Critical"
"Id": "1",
"Name": "Chassis",
"HeightMm": 177.8,
"Power": {
    "@odata.id": "/redfish/v1/Chassis/1/Power"
"SKU": "7Z59CT01WW",
"@odata.type": "#Chassis.v1_10_0.Chassis",
"PartNumber": "SB27A22721",
"Manufacturer": "Lenovo",
"@odata.etag": "\"fe6783781ffb0b49d7667e84ce6a624a\"",
"LogServices": {
    "@odata.id": "/redfish/v1/Systems/1/LogServices"
```

},

```
"UUID": "55833BF4-5BBB-11E7-997F-0A94EF402C57"
```

Resource Chassis (Flex System Enterprise Chassis or Lenovo D2 Enclosure

This resource is used to represent a Flex System Enterprise Chassis or Lenovo D2 Enclosure for a Redfish implementation.

This resource is only for Platform type Iteblade and Highdense

Number of Resources	1
Resource Path	/redfish/v1/ Chassis/2
Schema file	Chassis_v1.xml

GET – Collection for Flex System Enterprise Chassis or Lenovo D2 Enclosure

Use the GET method to retrieve properties in Chassis collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	"ChassisCollection".
Members	Array	Items: A reference link to an element of Chassis.
Description	String	"A collection of Chassis resource instances."

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
        "@odata.id": "/redfish/v1/Chassis/2"
"@odata.type": "#ChassisCollection.ChassisCollection",
"@odata.etag": "\"af5a94479815eb5f87fe91ea08fde0ac\"",
"Members@odata.count": 2,
"Description": "A collection of Chassis resource instances."
```

GET - Flex System Enterprise Chassis or Lenovo D2 Enclosure properties

Use the GET method to retrieve properties in Flex System Enterprise Chassis or Lenovo D2 Enclosure resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/2

Request body

None

Response body

		1	
Fi	eld	Туре	Description
SerialNumber		String	The serial number of this chassis.
Cł	nassisType	String	This property indicates the type of physical form factor of this resource.
De	escription	String	Provides a description of this chassis resource.
Liı	nks	Object	Expanded
	Contains	Array	An array of references to the chassis contained in this chassis.
	Contains [N]	Link	The value of this property is a URI reference to the resource of chassis.
М	odel	String	The model number for the chassis.
ld		String	Uniquely identifies the resource within the collection of Chassis. Always set to "2".
St	atus	Object	Contains the following elements
	State	String	"Enabled"
Na	ame	String	The name of the Chassis resource. Always set to "Chassis Enclosure".
Power		Link	A reference link to the power resource contained in this chassis.
Manufacturer S		String	The manufacturer of this chassis. Always set to "Lenovo" or "LNVO".
Lo	Location Ob		The location of chassis.
	PartLocation	Object	The part location within the placement.
	LocationOrdinalValue	Integer	The number that represents the location of the part. If LocationType is `slot` and this unit is in slot 2, the LocationOrdinalValue is 2.

I	Fiel	ld	Туре	Description
		LocationType	String	The type of location of the part, such as slot, bay, socket and slot.
	Р	Placement	Object	A place within the addressed location.
		AdditionalInfo	String	Area designation or other additional info.

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "SerialNumber": "485034927",
    "Id": "2",
    "@odata.id": "/redfish/v1/Chassis/2",
    "Status": {
         "State": "Enabled"
    },
    "Links": {
         "Contains": [
             {
                  "@odata.id": "/redfish/v1/Chassis/1"
             }
        ]
    },
"Name": "Chassis Enclosure",
    "Power": {
         "@odata.id": "/redfish/v1/Chassis/2/Power"
    },
    "Manufacturer": "Lenovo",
    "@odata.type": "#Chassis.v1_9_1.Chassis",
    "ChassisType": "Enclosure",
    "Location": {
         "PartLocation": {
             "LocationType": "Bay",
             " LocationOrdinalValue ": 1
         "Placement": {
             "AdditionalInfo": "CMM"
    },
    "@odata.etag": "\"92e4b90992e982ce122a657d1cc2e307\"",
    "Model": "Iteblade",
    "Description": "This resource is used to represent a physical enclosure for a Redfish implementation."
}
```

Chapter 6. Network Adapter Devices

Resource NetworkAdapters

This resource is used to represent network adapters for a Redfish implementation.

Number of Resources	Number of adapters
Resource Path	/redfish/v1/ Chassis/1/NetworkAdapters/{Location} (Location= ob-X or slot-Y)
Schema file	NetworkAdapterCollection_v1.xm
	NetworkAdapter_v1.xml

GET – Collection of Network adapters

Use the GET method to retrieve properties in NetworkAdapter collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/1/NetworkAdapters

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	"NetworkAdaptersCollection".
Members	Array	Items: A reference link to an element of NetworkAdapters.
Description	String	"A collection of NetworkAdapter resource instances."

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

© Copyright Lenovo 2017, 2020

```
"@odata.etag": "\"7c4a52116d626ea10f04de562c990269\"",
    "Members@odata.count": 1,
    "Description": "A collection of NetworkAdapter resource instances."
}
```

GET – Network adapter properties

Use the GET method to retrieve properties in NetworkAdapter resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/1/NetworkAdapters/{Location}

{Location}: Location of the corresponding NetworkAdapter device. {Location}=ob-X or slot-Y. ob stands for onboard device and slot stands for add-on card. X is the sequence number for onboard device starting from 1. Y is the slot number of add-on card.

Request body

None

Response body

Field	Туре	Description
Id	String	Only Ethernet, Fibre Channel, InfiniBand devices support to have the NetworkAdapter resource now:
		For add-on devices, the value is "slot-{slot number}"
		For on-board devices, the value is "ob-{index}"
Controllers	Array	The set of network controllers ASICs that make up this NetworkAdapter
Controllers[]	Obejct	Expanded
FirmwarePackage- Version	String	The version of the user-facing firmware package
Location	Object	The location of network adapter.
PartLocation	Object	The part location within the placement.
ServiceLabel	String	The label of the part location, such as a silk-screened name or a printed label. PCle X (X is the slot number)
LocationType	String	The type of location of network adapter. Fixed value : Slot
LocationOrdinal- Value	Integer	The number that represents the location of the part. If LocationType is `slot` and this unit is in slot 2, the LocationOrdinalValue is 2.
Info	String	The location of the Resource: Slot {N} (N is the slot number) or "OnBoard".
Infoformat	String	The format of the Info property. "Slot X" or "OnBoard".
Info@Redfish. Deprecated	String	The property is deprecated. Please use PartLocation instead.
InfoFormat@Red- fish.Deprecated	String	The property is deprecated. Please use PartLocation instead.
Links	Object	Links for this controller
PCleDevices	Array	Items: link
PCleDevices[]	Link	Link to related PCleDevice

Field		Туре	Description	
NetworkPorts Array		Array	Items: link	
Ш	NetworkPorts[]	Link	Link to related NetworkPorts	
Ш	NetworkDevice- Functions	Array	Items: link	
	NetworkDevice- Functions[]	Link	Link to related NetworkDeviceFunctions	
	ControllerCapabili- ties	Object	The capabilities of a controller	
	NetworkPortCount	Number	The count of physical ports of this adapter	
	NetworkDevice- FunctionCount	Number	The count of logical ports of this adapter	
De	escription	String	A NetworkAdapter represents the physical network adapter capable of connecting to a computer network	
М	anufacturer	String	The manufacturer or OEM of this network adapter	
М	Model Str		The model string for this network adapter	
SI	KU	String	The manufacturer SKU for this network adapter	
Name Stri		String	The card name for this network adapter	
Pa	artNumber	String	The part number for this network adapter.	
Se	SerialNumber Str		The serial number for this network adapter	
Status (Object	expand	
State St		String	Enabled	
Health String		String	This represents the health state of this resource	
Ne	etworkPorts	Link	Link to related NetworkPortsCollection	
NetworkDeviceFunc- Link tions		Link	Link to related NetworkDeviceFunctionsCollection	

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"SerialNumber": "L2NV97J018G",
"NetworkDeviceFunctions": {
    "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkDeviceFunctions"
},
"Id": "slot-13",
"@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13",
"NetworkPorts": {
    "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkPorts"
},
"Status": {
```

```
"State": "Enabled",
    "Health": "OK"
},
"Name": "Broadcom NetXtreme PCIe 1Gb 2-Port RJ45 Ethernet Adapter",
"Controllers": [
    {
        "ControllerCapabilities": {
             "NetworkDeviceFunctionCount": 2,
             "NetworkPortCount": 2
        "FirmwarePackageVersion": "212.0.5.4",
        "Location": {
             "PartLocation": {
                 "LocationType": "Slot",
                 "ServiceLabel": "PCIe 13",
                 "LocationOrdinalValue": 13
             },
             "InfoFormat": "Slot X",
             "Info": "Slot 13",
             "Info@Redfish.Deprecated": "The property is deprecated. Please use PartLocation instead.",
             "InfoFormat@Redfish.Deprecated": "The property is deprecated. Please use PartLocation instead."
        },
        "Links": {
             "NetworkPorts": [
                 {
                     "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkPorts/1"
                 },
                 {
                     "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkPorts/2"
                 }
             "NetworkDeviceFunctions": [
                 {
                     "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkDeviceFunctions/1.1"
                 },
                 {
                     "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkDeviceFunctions/2.1"
                 }
            ],
             "PCIeDevices": [
                 {
                     "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/slot 13"
                 }
            1
        "PCIeInterface": {
             "LanesInUse": 2,
             "MaxPCIeType": "Gen2",
             "MaxLanes": 4,
             "PCIeType": "Gen2"
        }
    }
"PartNumber": "SN30L21970",
"SKU": "00YK550",
"@odata.type": "#NetworkAdapter.v1_3_0.NetworkAdapter",
"0em": {
    "Lenovo": {
        "@odata.type": "#LenovoDeviceInfo.v1 0 O.LenovoDeviceInfo",
        }
```

```
},
"Manufacturer": "Broadcom Limited",
"@odata.etag": "\"9b40314193f036ad3898f8482b8a3a9a\"",
"Model": "5720",
"Description": "A NetworkAdapter represents the physical network adapter capable of connecting to a computer network."
}
```

Resource NetworkPort

This resource is used to represent network ports for a Redfish implementation.

Number of Resources	Number of network ports
Resource Path	/redfish/v1/Chassis/1/NetworkAdapters/{Location}/ NetworkPorts/{1-N} (Location= ob-X or slot-Y)
Schema file	NetworkPortCollection_v1.xml NetworkPort v1.xml

GET – Collection of network ports

Use the GET method to retrieve properties in NetworkPort collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/1/NetworkAdapters/{Location}/NetworkPorts

Request body

None

Response body

Field	Туре	Description
Name	String	"NetworkPortsCollection".
Members	Array	Items: A reference link to an element of NetworkPorts.
Description	String	"A Collection of NetworkPort resource instances."

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"@odata.type": "#NetworkPortCollection.NetworkPortCollection",
"@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkPorts",
"Members@odata.count": 2,
"@odata.etag": "\"8e527250b8722a01098e15a8e56f0aa4\"",
"Name": "NetworkPortCollection",
"Description": "A collection of NetworkPort resource instances."
```

GET – Network port properties

Use the GET method to retrieve properties in network port resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/1/NetworkAdapters/{Location}/NetworkPorts/{1-N}

{Location}: Location of the corresponding NetworkAdapter device. {Location}=ob-X or slot-Y. ob stands for onboard device and slot stands for add-on card. X is the sequence number for onboard device starting from 1. Y is the slot number of add-on card.

{1-N}: Index of network physical port.

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Id	String	Index.
ActiveLinkTechnology	String	Network Port Active Link Technology
AssociatedNetworkAddresses	Array	The array of configured network addresses (MAC or WWN) that are associated with this Network Port
Description	String	A Network Port represents a discrete physical port capable of connecting to a network.
LinkStatus	String	The status of the link between this port and its link partner
Name	String	"Phyical Port X" (X = the ld value)
NetDevFuncMaxBWAlloc	Array	The array of minimum bandwidth allocation percentages for the Network Device Functions associated with this port
NetDevFuncMaxBWAlloc[]	Object	Expanded
MaxBWAllocPercent	Number	The maximum bandwidth allocation percentage allocated to the corresponding network device function instance
NetworkDeviceFunction	Link	Link to a NetworkDeviceFunction
PhysicalPortNumber	String	The physical port number label for this port
PortMaximumMTU Num		The largest maximum transmission unit (MTU) that can be configured for this network port
Status Object		Expand
State	String	Enabled

F	ield	Туре	Description
	HeadIth	String	ОК
	HealthRollup	String	This represents the health state of this resource and its dependent resources

HTTP Status Code	Error Message ID
500	InternalError

Response example

The following example JSON response is returned:

```
"AssociatedNetworkAddresses": [
        "B02628C5541C"
    "NetDevFuncMaxBWAlloc": [
             "NetworkDeviceFunction": {
                 "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkDeviceFunctions/1.1"
             "MaxBWAllocPercent": null
    ],
    "Id": "1",
    "Status": {
         "State": "Enabled",
         "Health": "OK",
        "HealthRollup": "OK"
    },
    "Name": "Phyical Port 1",
    "CurrentLinkSpeedMbps": null,
    "ActiveLinkTechnology": "Ethernet",
    "@odata.type": "#NetworkPort.v1_2_3.NetworkPort",
    "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkPorts/1",
    "PortMaximumMTU": 72000,
    "@odata.etag": "\"18feOfdd69f686adb26dd74b7334181d\"",
    "PhysicalPortNumber": "1",
    "Description": "A Network Port represents a discrete physical port capable of connecting to a network."
}
```

Resource NetworkDeviceFunction

This resource is used to represent network device function for a Redfish implementation.

Number of Resources	Number of network device functions
Resource Path	/redfish/v1/Chassis/1/NetworkAdapters/{Location}/ NetworkDeviceFunctions/{1-M}.{1-N} (Location= ob-X or slot-Y)
Schema file	NetworkDeviceFunctionCollection_v1.xml
	NetworkDeviceFunction_v1.xml

GET – Collection of Network device function

Use the GET method to retrieve properties in NetworkDeviceFunction collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/1/NetworkAdapters/{Locaton}/NetworkDeviceFunctions

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	"NetworkDeviceFunctionCollection".
Members	Array	Items: A reference link to an element of NetworkDeviceFunction.
Description	String	"A collection of NetworkDeviceFunction resource instances".

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "Members": [
             "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkDeviceFunctions/1.1"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkDeviceFunctions/2.1"
    "@odata.type": "#NetworkDeviceFunctionCollection.NetworkDeviceFunctionCollection",
    "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkDeviceFunctions",
    "Members@odata.count": 2,
    "@odata.etag": "\"f98d64ab9ab89400faa5b2f4e0784f47\"",
    "Name": "NetworkDeviceFunctionCollection",
    "Description": "A collection of NetworkDeviceFunction resource instances."
}
```

GET – Network device PCIe functions

Use the GET method to retrieve properties in NetworkDeviceFunction resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/1/NetworkAdapters/{Locaton}/NetworkDeviceFunctions/{1-M}.{1-N}

{Location}: Location of the corresponding NetworkAdapter device. {Location}=ob-X or slot-Y. ob stands for onboard device and slot stands for add-on card. X is the sequence number for onboard device starting from 1. Y is the slot number of add-on card.

{1-M}: Index of physical network port.

{1-N}: Index of logical network port.

Request body

None

Response body

Field	Туре	Description
ld	String	Physical port index +"." + the logical port index, for the associated NetworkPort resource.
AssignablePhysicalPorts	Array	Items: link.
AssignablePhysicalPorts[N]	Link	Link to possible NetworkPorts.
PhysicalPortAssignment	Link	Link to related NetworkPort.
Description	String	A Network Device Function represents a logical interface exposed by the network adapter.
DeviceEnabled	Boolean	True.
Ethernet	Object	Expand (If this is Ethernet, the below items will be displayed).
PermanentMACAddress	String	This is the permanent MAC address assigned to this network device function (physical function).
MACAddress	String	This is the currently configured MAC address of the (logical port) network device function.
MTUSize	Number	The Maximum Transmission Unit (MTU) configured for this network device function.
FibreChannel Object		Expand (If this is FibreChannel, the below items will be displayed).
PermanentWWPN	String	This is the permanent WWPN address assigned to this network device function (physical function).
WWPN	String	This is the currently configured WWPN address of the network device function (physical function).
Links	Object	Expand.
PCleFunction	Link	Link to a PCIeFunction.
Name	String	"Logical Port"+" "+"logical port index"
NetDevFuncType	Enum String	The configured capability of this network device function.
Status	Object	Expand.
State	String	Enabled.
Health	String	OK.
HealthRollup	String	This represents the health state of this resource and its dependent resources.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "Ethernet": {
        "MACAddress": "b0:26:28:c5:54:1c",
        "PermanentMACAddress": "b0:26:28:c5:54:1c",
        "MTUSize": 72000
    "Status": {
        "State": "Enabled",
        "Health": "OK",
        "HealthRollup": "OK"
    },
    "DeviceEnabled": true,
    "PhysicalPortAssignment": {
        "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkPorts/1"
    "Links": {
        "PhysicalPortAssignment": {
             "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkPorts/1"
        "PCIeFunction": {
             "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/slot 13/PCIeFunctions/slot 13.00"
    },
    "Name": "Logical Port 1",
    "NetDevFuncType": "Ethernet",
    "AssignablePhysicalPorts": [
        {
             "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkPorts/1"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkPorts/2"
        }
    "@odata.id": "/redfish/v1/Chassis/1/NetworkAdapters/slot-13/NetworkDeviceFunctions/1.1",
    "@odata.type": "#NetworkDeviceFunction.v1_3_3.NetworkDeviceFunction",
    "Id": "1.1",
    "PhysicalPortAssignment@Redfish.Deprecated": "The property is deprecated. Please use
Links/PhysicalPortAssignment instead.",
    "@odata.etag": "\"436229ed07f09d724dcb0ec5bad22368\"",
    "AssignablePhysicalPorts@odata.count": 2,
    "Description": "A Network Device Function represents a logical interface exposed by the network
adapter."
}
```

Chapter 7. Power, thermal and redundancy

Resource Power

This resource is used to represent power management for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/Chassis/1/Power
Schema file	Power_v1.xml

GET – Power management properties

Use the GET method to retrieve properties in Power resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/1/Power

Request body

None

Response body

Field		Туре	Description
ld		String	"Power".
Ν	lame	String	The name of power resource. Always set to "Power".
D	Description	String	"Power Consumption and Power Limiting"
Р	PowerControl	Array	This is the definition for power control function (power reading/limiting).
	PowerControl[1]	Object	This is the base type for addressable members of PowerControl array.
Î	Memberld	String	Index of this PowerControl array.
Î	Name	String	Power Control Function name. Always set to "Server Power Control".
	PhysicalContext	String	The area, device, or set of devices to which this power control applies.
Î	PowerConsumedWatts	Number	The actual power being consumed by the chassis.
	PowerRequestedWatts	Number	The potential power that the chassis resources are requesting which may be higher than the current level being consumed since requested power includes budget that the chassis resource wants for future use.
	PowerAvailableWatts	Number	The amount of power not already budgeted and therefore available for additional allocation. (powerCapacity - powerAllocated). This indicates how much reserve power capacity is left.
	PowerCapacityWatts	Number	The total amount of power available to the chassis for allocation. This may the power supply capacity, or power budget assigned to the chassis from an up-stream chassis.

© Copyright Lenovo 2017, 2020 51

Fie	ield	Туре	Description
	PowerAllocatedWatts	Number	The total amount of power that has been allocated (or budegeted)to chassis resources.
	Status	Object	Power limit status and configuration information for this chassis. Note: If the tier level of this system is less than 3, this value will be hiden.
	State	String,	This indicates the known state of the resource, such as if it is enabled. Always set to "Enable".
	HealthRollup	String	This indicates the health state of this power control. Valid values:
			"OK": "Normal",
			"Warning": "A condition exists that requires attention",
			"Critical": "A critical condition exists that requires immediate attention".
	Health	String	"OK"
	PowerLimit	Object	Power limit status and configuration information for this chassis. Note: If the tier level of this system is less than 3 or if the platform is a blade platform, this object will be hidden.
	LimitInWatts	Number	The Power limit in watts. Set to null to disable power capping.
	LimitException	String	The action that is taken if the power cannot be maintained below the LimitInWatts. Always set to "NoAction". Valid values:
			"NoAction": "Take no action when the limit is exceeded".
	PowerMetrics	Object	Power readings for this chassis.
	IntervallnMin	Number	The time interval (or window) in which the PowerMetrics are measured over. Always set to 60.
	MinConsumedWatts	Number	The lowest power consumption level over the measurement window (the last IntervalInMin minutes).
	MaxConsumedWatts	Number	The highest power consumption level that has occured over the measurement window (the last IntervalInMin minutes).
	AverageConsumedWatts	Number	The average power level over the measurement window (the last IntervalInMin minutes).
	Status	Object	Describes the status and health of a resource and its children.
	State	String	This indicates the known state of the resource, such as if it is enabled. Always set to "Enable".
	HealthRollup	String	This indicates the health state of this power control. Valid values:
			"OK": "Normal",
			"Warning": "A condition exists that requires attention",
			"Critical": "A critical condition exists that requires immediate attention".
	Health	String	"OK"
	RelatedItem	Array	An array of links to resource of chassis
Π	RelatedItem[1]	Link	A reference link to a resource of chassis
	PowerControl[3]	Object	This is the base type for addressable members of PowerControl array.

Field		Туре	Description
	Memberld	String	Index of this PowerControl array.
	Name	String	Power Control Function name. Always set to "Memory Sub-system Power".
	PhysicalContext	String	The area, device, or set of devices to which this power control applies. Always set to "MemorySubsystem".
	PowerConsumedWatts	Number	The actual power being consumed by the MemorySubsystem.
	PowerMetrics	Object	Power readings for this MemorySubsystem.
	IntervallnMin	Integer	The time interval (or window) in which the PowerMetrics are measured over. Always set to 1.
	MinConsumedWatts	Number	The lowest power consumption level over the measurement window (the last IntervalInMin minutes).
	MaxConsumedWatts	Number	The highest power consumption level that has occured over the measurement window (the last IntervalInMin minutes).
	AverageConsumedWatts	Number	The average power level over the measurement window (the last IntervalInMin minutes).
1	Status	Object	Describes the status and health of a resource and its children.
	State	String	This indicates the known state of the resource, such as if it is enabled. Always set to "Enable".
	HealthRollup	String	This indicates the health state of this power control. Valid values: "OK": "Normal", "Warning": "A condition exists that requires attention", "Critical": "A critical condition exists that requires immediate attention".
	Health	String	"OK"
	RelatedItem	Array	An array of links to resource of chassis
	RelatedItem[1]	Link	A reference link to a resource of chassis
P	PowerSupplies Arı		Details of the power supplies associated with this system or device. Items count is the number of installed power supplies in this system. If the system does not install any PSU, like Flex systems and high dense systems, this array will be hidden.
	PowerSupplies[N]	Object	Details of the power supply associated with this system or device.
	Memberld	String	This is the identifier for the member within the collection. The string starts with "PSU" and follows with PSU ID, like "PSU1".
	Name	String,	The name of the Power Supply. Always equals to Memberld.
	PowerSupplyType	String	The Power Supply type (AC or DC). Valid values: "Unknown": "The power supply type cannot be determined". "AC": "Alternating Current (AC) power supply". "DC": "Direct Current (DC) power supply". "ACorDC": "Power Supply supports both DC or AC".

Fie	Field		Туре	Description
	Lir	neInputVoltageType	String	The line voltage type supported as an input to this Power Supply. Valid values:
				"Unknown": "The power supply line input voltage type cannot be determined"
				"ACLowLine": "100-127V AC input. Deprecated: Use AC120V".
				"ACMidLine": "200-240V AC input. Deprecated: Use AC240V".
				"DC240V": "DC 240V nominal input"
	Po	owerCapacityWatts	Number	The maximum capacity of this Power Supply.
	La	stPowerOutputWatts	Number	The average power output of this Power Supply.
	Po	owerInputWatts	Number	The measured input power of this power supply.
	Po	owerOutputWatts	Number	The measured output power of this power supply.
	Ef	ficiencyPercent	Number	The measured efficiency of this power supply as a percentage.
	Но	otPluggable	Boolean	An indication of whether this device can be inserted or removed while the equipment is in operation.
	Lo	cation	Object	The location of the power supply.
		PartLocation	Object	The part location within the placement.
		ServiceLabel	String	The label of the part location, such as a silk-screened name or a printed label. Always set to "PSU" + psu_id.
		LocationType	String	The type of location of the part, such as slot, bay, socket and slot. Always set to "Slot".
		LocationOrdinalValue	Integer	The number that represents the location of the part. If LocationType is `slot` and this unit is in slot 2, the LocationOrdinalValue is 2.
	М	odel	String	The model number for this Power Supply.
	Fir	rmwareVersion	String	The firmware version for this Power Supply. The firmware string consists of primary firmware version and secondary firmware version, which are defined in PowerSupply OEM section.
	Se	erialNumber	String	The serial number for this Power Supply.
	Pa	artNumber	String	The part number for this Power Supply.
	Ма	anufacturer	String	The manufacturer of this power supply
	In	outRanges	String	The input ranges that the power supply can use. Item count is always set to 1.
		InputRanges[1]	Object	Details for input ranges that the power supply can use.
		InputType	String	Valid values: "AC", "DC"
		MaximumVoltage	Number	The maximum line input voltage at which this power supply input range is effective.
		MinimumVoltage	Number	The minimum line input voltage at which this power supply input range is effective.
\prod		OutputWattage	Number	The same as the PowerCapacityWatts
	St	atus	Object	Describes the status and health of a resource and its children.

Field		Туре	Description	
		State	String	This indicates the known state of this power supply. Valid values:
				"Enabled": "This function or resource has been enabled",
				"Disabled": "This function or resource has been disabled".
		Health	String	This indicates the health state of this power supply. Valid values:
				"OK": "Normal",
				"Warning": "A condition exists that requires attention",
				"Critical": "A critical condition exists that requires immediate attention".
		RelatedItem	Array	An array of links to resource of chassis
		RelatedItem[1]	Link	A reference link to a resource of chassis
Re	ed	undancy	Array	Redundancy information for the power subsystem of this system or device. Item count is always set to 1. If the system does not install any PSU, like Flex systems and high dense systems, this array will be hidden.
	Re	edundancy[1]	Object	Details indicating power supplies redundancy.
		Memberld	String	Index of this Redundancy array.
		Name	String	"PSU Redundancy"
		Mode	String	"N+m"
		MaxNumSupported	Integer	Maximum number of members allowable for this particular redundancy group.
		MinNumNeeded	Integer	Minumum number of members needed for this group to be redundant.
				The value is 2
		RedundancyEnabled	Boolean	Indicate whether redundancy is enabled.
		Status	Object	Describes the status and health of the resource and its children.
		State	String	This indicates the known state of this redundancy. Valid values:
				"Enabled": "This function or resource has been enabled",
				"Disabled": "This function or resource has been disabled".
		Health	String	This indicates the health state of this redundancy. Valid values:
				"OK": "Normal",
				"Warning": "A condition exists that requires attention",
				"Critical": "A critical condition exists that requires immediate attention".
		RedundancySet	Array	This is the definition for redundancy set.
				Item count is the number of the Power's PowerSupplies.
		RedundancySet[N]	Link	The link to Power's PowerSupplies.
Re	Redundancy Array		Array	Redundancy information for the power subsystem of this system or device. Item count is always set to 1. If the system does not install any PSU, like Flex systems and high dense systems, this array will be hidden.

Field		Туре	Description
F	Redundancy[1]	Object	Details indicating power supplies redundancy.
	Memberld	String	Index of this Redundancy array.
	Name	String	"PSU Redundancy".
	Mode	String	"N+m".
	MaxNumSupported	Integer	Maximum number of members allowable for this particular redundancy group.
	MinNumNeeded	Integer	Minumum number of members needed for this group to be redundant. The value is 2
	RedundancyEnabled	Boolean	Indicate whether redundancy is enabled.
	Status	Object	Describes the status and health of the resource and its children.
	State	String	This indicates the known state of this redundancy. Valid values: Enabled": "This function or resource has been enabled". "Disabled": "This function or resource has been disabled".
	Health	String	This indicates the health state of this redundancy Valid values: "OK": "Normal". "Warning": "A condition exists that requires attention". "Critical": "A critical condition exists that requires immediate attention".
	RedundancySet	Array	This is the definition for redundancy set. Item count is the number of the Power's PowerSupplies.
	RedundancySet[N]	Link	The link to Power's PowerSupplies.
Vo	Itages	Array	This is the definition for voltage sensors. Item count is the number of voltage sensors in this system.
١	/oltages[N]	Object	The definition for a voltage sensor.
	Memberld	String	Index of this Voltage array
	Name	String	Voltage sensor name.
	SensorNumber	Number	A numerical identifier to represent the voltage sensor.
	Status	Object	Describes the status and health of a resource and its children.
	State	String,	This indicates the known state of this voltage sensor. Valid values: "Enabled": "This function or resource has been enabled". "Disabled": "This function or resource has been disabled".
	ReadingVolts	Number	The current value of the voltage sensor. If the State of this voltage sensor is "disabled", "ReadingVolts" will be hiden.
	UpperThresholdNonCritical	Number	Above normal range.
	UpperThresholdCritical	Number	Above normal range but not yet fatal.
	UpperThresholdFatal	Number	Above normal range and is fatal.
	LowerThresholdNonCritical	Number	Below normal range.
	LowerThresholdCritical	Number	Below normal range but not yet fatal.

Field		Туре	Description
	LowerThresholdFatal	Number	Below normal range and is fatal.
	MinReadingRange	Number	Minimum value for CurrentReading.
	MaxReadingRange	Number	Maximum value for CurrentReading.
	PhysicalContext	String	Describes the area or device to which this voltage measurement applies. Always set to "VoltageRegulator". "VoltageRegulator": "A voltage regulator device".
	RelatedItem	Array	Describes the areas or devices to which this temperature measurement applies. Item count is 2.
	RelatedItem[N]	Link	The element of the array provides a link to device applied. One element links to chassis resource. One element links to system resource.

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"PowerControl@odata.count": 3,
"PowerSupplies": [
    {
        "SerialNumber": "D1DG94C006R",
        "InputRanges": [
            {
                 "InputType": "AC",
                 "OutputWattage": 1800,
                 "MaximumVoltage": 240,
                 "MinimumVoltage": 200
        "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/0",
        "PowerOutputWatts": 69,
        "RelatedItem@odata.count": 1,
        "MemberId": "O",
        "PartNumber": "SP57A14705",
        "Location": {
             "PartLocation": {
                 "LocationType": "Slot",
                 "ServiceLabel": "PSU1",
                 "LocationOrdinalValue": 1
        "LineInputVoltageType": "ACMidLine",
        "RelatedItem": [
                 "@odata.id": "/redfish/v1/Chassis/1"
        "EfficiencyPercent": 80,
        "Status": {
```

```
"State": "Enabled",
         "Health": "OK"
    "LineInputVoltage": 220,
    "Name": "PSU1",
    "LastPowerOutputWatts": 10,
    "FirmwareVersion": "6.11",
    "0em": {
         "Lenovo": {
             "HistoryPowerSupplyMetric": {
                  "@odata.id": "/redfish/v1/Chassis/1/Power/PowerSupplies/0/Oem/Lenovo/HistoryPowerSupplyMetric"
             "Location": {
                  "Info": "Slot 1",
                  "InfoFormat": "Slot X"
             "Location@Redfish.Deprecated": "The property is deprecated. Please use Location instead.",
             "FruPartNumber": "03T8714",
             "@odata.type": "#LenovoPower.v1 0 0.PowerSupply"
        }
    },
    "HotPluggable": false,
    "PowerInputWatts": 86,
    "Manufacturer": "DETA",
    "PowerSupplyType": "AC",
    "Model": "LENOVO-SP57A14705",
    "PowerCapacityWatts": 1800
},
    "SerialNumber": null,
    "InputRanges": [
        {
             "InputType": null,
             "OutputWattage": null,
             "MaximumVoltage": null,
             "Minimum Voltage": null
        }
    ],
    "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/1",
    "PowerOutputWatts": null,
    "RelatedItem@odata.count": 1,
    "MemberId": "1",
    "PartNumber": null,
    "LineInputVoltageType": null,
    "Location": {
         "PartLocation": {
             "LocationType": "Slot",
             "ServiceLabel": "PSU2",
             "LocationOrdinalValue": 2
        }
    },
    "RelatedItem": [
        {
             "@odata.id": "/redfish/v1/Chassis/1"
         }
    ],
    "EfficiencyPercent": null,
    "Status": {
         "State": "Absent",
         "Health": null
    },
```

```
"LineInputVoltage": null,
    "Name": "PSU2",
    "FirmwareVersion": null,
    "LastPowerOutputWatts": null,
    "0em": {
         "Lenovo": {
             "HistoryPowerSupplyMetric": {
                 "@odata.id": "/redfish/v1/Chassis/1/Power/PowerSupplies/1/Oem/Lenovo/HistoryPowerSupplyMetric"
             "Location": {
                 "Info": "Slot 2",
                 "InfoFormat": "Slot X"
             "Location@Redfish.Deprecated": "The property is deprecated. Please use Location instead.",
             "FruPartNumber": null,
             "@odata.type": "#LenovoPower.v1_0_0.PowerSupply"
        }
    "HotPluggable": null,
    "PowerCapacityWatts": null,
    "Manufacturer": null,
    "PowerSupplyType": null,
    "Model": null,
    "PowerInputWatts": null
},
    "SerialNumber": null,
    "InputRanges": [
        {
             "InputType": null,
             "OutputWattage": null,
             "MaximumVoltage": null,
             "MinimumVoltage": null
        }
    ],
    "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/2",
    "PowerOutputWatts": null,
    "RelatedItem@odata.count": 1.
    "MemberId": "2",
    "PartNumber": null,
    "LineInputVoltageType": null,
    "PowerInputWatts": null,
    "RelatedItem": [
        {
             "@odata.id": "/redfish/v1/Chassis/1"
        }
    ],
    "EfficiencyPercent": null,
    "Status": {
         "State": "Absent",
        "Health": null
    },
    "LineInputVoltage": null,
    "Name": "PSU3",
    "FirmwareVersion": null,
    "LastPowerOutputWatts": null,
    "0em": {
         "Lenovo": {
             "HistoryPowerSupplyMetric": {
                  "@odata.id": "/redfish/v1/Chassis/1/Power/PowerSupplies/2/Oem/Lenovo/HistoryPowerSupplyMetric"
             },
```

```
"Location": {
                  "Info": "Slot 3",
                  "InfoFormat": "Slot X"
             "Location@Redfish.Deprecated": "The property is deprecated. Please use Location instead.",
             "FruPartNumber": null,
             "@odata.type": "#LenovoPower.v1_0_0.PowerSupply"
         }
    },
    "HotPluggable": null,
    "Location": {
         "PartLocation": {
             "LocationType": "Slot",
             "ServiceLabel": "PSU3",
             "LocationOrdinalValue": 3
        }
    },
    "Manufacturer": null,
    "PowerSupplyType": null,
    "Model": null,
    "PowerCapacityWatts": null
},
    "SerialNumber": null,
    "InputRanges": [
        {
             "InputType": null,
             "OutputWattage": null,
             "MaximumVoltage": null,
             "MinimumVoltage": null
        }
    ],
    "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/3",
    "PowerOutputWatts": null,
    "RelatedItem@odata.count": 1,
    "MemberId": "3",
    "PartNumber": null,
    "LineInputVoltageType": null,
    "FirmwareVersion": null,
    "RelatedItem": [
        {
             "@odata.id": "/redfish/v1/Chassis/1"
         }
    ],
    "EfficiencyPercent": null,
    "Status": {
         "State": "Absent",
         "Health": null
    "LineInputVoltage": null,
    "Name": "PSU4",
    "LastPowerOutputWatts": null,
    "PowerInputWatts": null,
    "0em": {
         "Lenovo": {
             "HistoryPowerSupplyMetric": {
                  "@odata.id": "/redfish/v1/Chassis/1/Power/PowerSupplies/3/Oem/Lenovo/HistoryPowerSupplyMetric"
             "Location": {
                  "Info": "Slot 4",
                  "InfoFormat": "Slot X"
```

```
},
                 "Location@Redfish.Deprecated": "The property is deprecated. Please use Location instead.",
                 "FruPartNumber": null,
                 "@odata.type": "#LenovoPower.v1_0_0.PowerSupply"
             }
        },
        "HotPluggable": null,
        "Location": {
             "PartLocation": {
                 "LocationType": "Slot",
                 "ServiceLabel": "PSU4",
                 "LocationOrdinalValue": 4
             }
        },
        "Manufacturer": null,
        "PowerSupplyType": null,
        "Model": null,
        "PowerCapacityWatts": null
    }
"Id": "Power",
"Redundancy@odata.count": 1,
"0em": {
    "Lenovo": {
        "@odata.type": "#LenovoPower.v1 0 O.Capabilities",
        "LocalPowerControlEnabled": true,
        "PowerOnPermissionEnabled": true,
        "PowerRestorePolicy": "Restore",
        "WakeOnLANEnabled": true
    }
},
"Name": "Power",
"@odata.id": "/redfish/v1/Chassis/1/Power",
"PowerSupplies@odata.count": 4,
"PowerControl": [
    {
        "PowerLimit": {
             "LimitException": "NoAction",
             "LimitInWatts": null
        },
        "RelatedItem": [
             {
                 "@odata.id": "/redfish/v1/Chassis/1"
        ],
        "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerControl/0",
        "Status": {
             "HealthRollup": "OK",
             "Health": "OK",
             "State": "Enabled"
        },
        "PowerAllocatedWatts": 1800,
        "Name": "Server Power Control",
        "PowerAvailableWatts": 0,
        "PhysicalContext": "Chassis",
        "PowerMetrics": {
             "IntervalInMin": 1,
             "MinConsumedWatts": 8,
             "MaxConsumedWatts": 11,
             "AverageConsumedWatts": 10
        },
```

```
"RelatedItem@odata.count": 1,
             "MemberId": "O",
             "0em": {
                 "Lenovo": {
                      "PowerUtilization": {
                          "MaxLimitInWatts": 1800,
                          "EnablePowerCapping": false,
                          "LimitMode": "AC",
                          "EnablePowerCapping@Redfish.Deprecated": "The property is deprecated. Please use
LimitInWatts instead.",
                          "CapacityMinAC": 190,
                          "MinLimitInWatts": 0.
                          "GuaranteedInWatts": 190,
                          "CapacityMinDC": 172,
                          "CapacityMaxDC": 396,
                          "CapacityMaxAC": 426
                      "HistoryPowerMetric": {
                          "@odata.id": "/redfish/v1/Chassis/1/Power/PowerControl/O/Oem/Lenovo/HistoryPowerMetric"
                      "@odata.type": "#LenovoPower.v1_0_0.PowerControl"
                 }
             "PowerRequestedWatts": 426,
             "PowerConsumedWatts": 18,
             "PowerCapacityWatts": 1800
        },
             "RelatedItem": [
                 {
                      "@odata.id": "/redfish/v1/Systems/1/Processors"
                 }
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerControl/1",
             "Status": {
                 "HealthRollup": "OK",
                 "Health": "OK",
                 "State": "Enabled"
             "Name": "CPU Sub-system Power",
             "PhysicalContext": "CPUSubsystem",
             "PowerMetrics": {
                 "IntervalInMin": 1,
                 "MinConsumedWatts": 0,
                 "MaxConsumedWatts": 0,
                 "AverageConsumedWatts": 0
             "RelatedItem@odata.count": 1,
             "MemberId": "1",
             "PowerConsumedWatts": 0
        },
             "RelatedItem": [
                 {
                      "@odata.id": "/redfish/v1/Systems/1/Memory"
                 }
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerControl/2",
             "Status": {
                 "HealthRollup": "OK",
                 "Health": "OK",
```

```
"State": "Enabled"
        "Name": "Memory Sub-system Power",
        "PhysicalContext": "MemorySubsystem",
        "PowerMetrics": {
             "IntervalInMin": 1,
             "MinConsumedWatts": 0,
             "MaxConsumedWatts": 0,
             "AverageConsumedWatts": 0
        "RelatedItem@odata.count": 1,
        "MemberId": "2",
        "PowerConsumedWatts": 0
    }
"Voltages": [
    {
        "MaxReadingRange": 3.32,
        "RelatedItem": [
                 "@odata.id": "/redfish/v1/Systems/1"
            },
            {
                 "@odata.id": "/redfish/v1/Chassis/1"
            }
        "@odata.id": "/redfish/v1/Chassis/1/Power#/Voltages/0",
        "Status": {
             "State": "Enabled"
        "SensorNumber": 3,
        "Name": "CMOS Battery",
        "PhysicalContext": "VoltageRegulator",
        "RelatedItem@odata.count": 2,
        "MemberId": "0",
        "MinReadingRange": null,
        "LowerThresholdNonCritical": 2.39,
        "ReadingVolts": 3.07.
        "LowerThresholdCritical": 2.25
    },
        "MaxReadingRange": 3.98,
        "RelatedItem": [
            {
                 "@odata.id": "/redfish/v1/Systems/1"
            },
            {
                 "@odata.id": "/redfish/v1/Chassis/1"
        ],
        "@odata.id": "/redfish/v1/Chassis/1/Power#/Voltages/1",
        "Status": {
             "State": "Enabled"
        },
        "SensorNumber": 160,
        "Name": "SysBrd 3.3V",
        "PhysicalContext": "VoltageRegulator",
        "RelatedItem@odata.count": 2,
        "LowerThresholdCritical": 2.96,
        "MinReadingRange": null,
        "UpperThresholdCritical": 3.63,
```

```
"Reading Volts": 3.39,
        "MemberId": "1"
    },
        "MaxReadingRange": 5.87,
        "RelatedItem": [
             {
                 "@odata.id": "/redfish/v1/Systems/1"
             },
             {
                 "@odata.id": "/redfish/v1/Chassis/1"
             }
        ],
         "@odata.id": "/redfish/v1/Chassis/1/Power#/Voltages/2",
        "Status": {
             "State": "Enabled"
        "SensorNumber": 161,
        "Name": "SysBrd 5V",
        "PhysicalContext": "VoltageRegulator",
        "RelatedItem@odata.count": 2,
        "LowerThresholdCritical": 4.51,
        "MinReadingRange": null,
        "UpperThresholdCritical": 5.5,
        "Reading Volts": 4.99,
        "MemberId": "2"
    },
        "MaxReadingRange": 14.03,
        "RelatedItem": [
             {
                 "@odata.id": "/redfish/v1/Systems/1"
             },
             {
                 "@odata.id": "/redfish/v1/Chassis/1"
             }
        ],
        "@odata.id": "/redfish/v1/Chassis/1/Power#/Voltages/3",
         "Status": {
             "State": "Enabled"
        "SensorNumber": 162,
        "Name": "SysBrd 12V",
        "PhysicalContext": "VoltageRegulator",
        "RelatedItem@odata.count": 2,
        "MemberId": "3",
        "MinReadingRange": null,
        "UpperThresholdCritical": 13.2,
        "ReadingVolts": 11.83,
        "LowerThresholdCritical": 10.62
    }
"@odata.type": "#Power.v1_6_0.Power",
"Voltages@odata.count": 4,
"@odata.etag": "\"ad15f5455b53c4f5d6a0d36fdb38a2ba\"",
"Redundancy": [
    {
        "@odata.id": "/redfish/v1/Chassis/1/Power#/Redundancy/0",
        "Status": {
             "State": "Enabled",
             "Health": "OK"
```

```
"Name": "PSU Redundancy",
        "RedundancySet": [
            {
                 "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/0"
            },
            {
                 "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/1"
            },
            {
                 "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/2"
            },
            {
                 "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/3"
        "Lenovo": {
                 "NonRedundantAvailablePower": 1800,
                 "PowerRedundancySettings": {
                     "EstimatedUsage": "21.17%",
                     "MaxPowerLimitWatts": 1800,
                     "PowerRedundancyPolicy": "RedundantWithThrottling",
                     "PowerFailureLimit": 0
                 "@odata.type": "\#LenovoRedundancy.v1\_0\_0.LenovoRedundancyProperties"
            }
        "RedundancyEnabled": true,
        "MemberId": "0",
        "MinNumNeeded": 2,
        "MaxNumSupported": 2,
        "Mode": "N+m",
        "RedundancySet@odata.count": 4
"Description": "Power Consumption and Power Limiting"
```

PATCH – Update power management properties

Use the PATCH method to update properties in Power resource for Redfish service.

Request URL

}

PATCH https://<BMC_IPADDR>/redfish/v1/Chassis/1/Power

Request body

Properties to be updated are shown as below, all of these properties can be changed individually.

Fie	ld	Туре	Description
PowerControl		Object	Expanded.
F	PowerLimit	Object	Expanded.
	LimitInWatts	Number	The Power limit in watts. Null means power capping disabled

Response

The response returns same content as GET operation with updated properties.

HTTP Status Code	Error Message ID
400	PropertyValueTypeError, Conflict
500	InternalError

Example

The following example is PATCH body.

```
{
     "PowerControl": [
              "PowerLimit": {
                  "LimitInWatts": 800
         }
    ]
}
```

After the PATCH operation runs successfully, querying the Power resource returns below example JSON response:

```
{
    "PowerControl@odata.count": 3,
    "PowerControl": [
             "PowerLimit": {
                  "LimitException": "No Action",
                  "LimitInWatts": 800
             "RelatedItem": [
                 {
                      "@odata.id": "/redfish/v1/Chassis/1"
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerControl/0",
        },
    "Name": "Power",
    "@odata.id": "/redfish/v1/Chassis/1/Power",
    "@odata.type": "#Power.v1_6_0.Power",
    "@odata.etag": "\"ee6a4e2b17f6176e60f74867634ce2bb\"",
}
```

Resource Power (Flex System Enterprise Chassis or Lenovo D2 **Enclosure**)

This resource is used to represent power management (Flex System Enterprise Chassis or Lenovo D2 Enclosure) for a Redfish implementation.

Resource Path	/redfish/v1/Chassis/2/Power
Schema file	Power_v1.xml

GET – Power management properties

Use the GET method to retrieve properties in Power resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/2/Power

Request body

None

Response body

Fie	elo	d	Туре	Description
ld		String	"Power".	
Name		String	The name of power resource. Always set to "Power".	
Description		cription	String	"Power Consumption and Power Limiting"
PowerControl		rerControl	Array	This is the definition for power control function (power reading/limiting).
	Р	owerControl[1]	Object	This is the base type for addressable members of PowerControl array.
		Memberld	String	Index of this PowerControl array.
		Name	String	Power Control Function name. Always set to "Server Power Control".
		PowerConsumedWatts	Number	The actual power being consumed by the chassis.
		PowerCapacityWatts	Number	The total amount of power available to the chassis for allocation. This may the power supply capacity, or power budget assigned to the chassis from an up-stream chassis.
		RelatedItem	Array	An array of links to resource of chassis
		RelatedItem[1]	Link	A reference link to a resource of chassis

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"@odata.type": "#Power.v1_5_3.Power",
    "Id": "Power",
    "@odata.id": "/redfish/v1/Chassis/2/Power",
    "@odata.etag": "\"e6e56474dde0e18185c641e587ca1790\"",
"Name": "Power",
    "Description": "Power Consumption and Power Limiting"
}
```

Resource Thermal

This resource is used to represent thermal management for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/Chassis/1/Thermal
Schema file	Thermal_v1.xml

GET – Thermal management properties

Use the GET method to retrieve properties in Thermal resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/1/Thermal

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Id	String	Uniquely identifies the resource within the thermal resource. Always set to "1".
Name	String	The name of thermal resource. Always sets to "Thermal".
Description	String	Provides a description of the thermal resource.
Status	Object	Describes the status and health of a resource and its children.
State	String	This indicates the known state of the resource, such as if it is enabled.
HealthRollup	String	This represents the overall health state from the view of this resource.
Temperatures	Array	This is the definition for temperature sensors.
Temperatures[1]	Object	This is the definition for a specified temperature sensor.
Memberld	String	This is the identifier for the member within the collection.
Name	String	The name of this temperature sensor.
LowerThresholdCritical	Number	Below normal range but not yet fatal.
LowerThresholdFatal	Number	Below normal range and is fatal.

F	Field	Туре	Description
	LowerThresholdNonCritical	Number	Below normal range.
	UpperThresholdCritical	Number	Above normal range but not yet fatal.
	UpperThresholdFatal	Number	Above normal range and is fatal.
	UpperThresholdNonCritical	Number	Above normal range.
	MinReadingRangeTemp	Number	Minimum value for ReadingCelsius.
	MaxReadingRangeTemp	Number	Maximum value for ReadingCelsius.
	PhysicalContext	String	Describes the area or device to which this temperature measurement applies.
	ReadingCelsius	Number	Temperature.
	RelatedItem	Array	Describes the areas or devices to which this temperature measurement applies. Item count is 2 or 3.
	RelatedItem[N]	Link	The element of the array provides a link to device applied. One element links to chassis resource. One element links to system resource.
			If the PhysicalContext is "CPU" there is an element links related processor resource.
	SensorNumber	Number	A numerical identifier to represent the temperature sensor.
	Status	Object	Describes the status and health of a resource and its children.
	State	String	This indicates the known state of the resource, such as if it is enabled.
F	ans	Array	This is the definition for fans.
	Fan[N]	Object	This is the definition for a specified fan.
	Memberld	String	This is the identifier for the member within the collection.
	Name	String	Name of the fan.
	MaxReadingRange	Number	Maximum value for Reading.
	MinReadingRange	Number	Minimum value for Reading.
	PhysicalContext	String	Describes the area or device associated with this fan.
	Reading	Number	Current fan speed.
	ReadingUnits	String	Units in which the reading and thresholds are measured. Always set to "RPM".
	RelatedItem	Array	The ID(s) of the resources serviced with this fan.
	RelatedItem[N]	Link	The element of the array provides a link to device applied. One element links to chassis resource. One element links to system resource.
	Status	Object	Describes the status and health of a resource and its children.
	State	String	This indicates the known state of the resource, such as if it is enabled.
	Health	String	This represents the health state of this resource in the absence of its dependent resources.
	UpperThresholdCritical	Number	Above normal range but not yet fatal.
_			

I	Field		Туре	Description
		UpperThresholdFatal	Number	Above normal range and is fatal.
		UpperThresholdNonCritical	Number	Above normal range.
		LowerThresholdCritical	Number	Below normal range but not yet fatal.
		LowerThresholdFatal	Number	Below normal range and is fatal.
		LowerThresholdNonCritical	Number	Below normal range.

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "Fans": [
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/0",
             "ReadingUnits": "RPM",
             "PhysicalContext": "SystemBoard",
             "LowerThresholdFatal": null,
             "Location": {
                  "PartLocation": {
                      "LocationType": "Slot",
                      "ServiceLabel": "Fan 1 Tach",
                      "LocationOrdinalValue": 1
                 }
             "UpperThresholdCritical": null,
             "MaxReadingRange": 18360,
             "RelatedItem": [
                 {
                      "@odata.id": "/redfish/v1/Systems/1"
                 },
                 {
                      "@odata.id": "/redfish/v1/Chassis/1"
                  }
             "LowerThresholdCritical": 3,
             "Status": {
                  "State": "Enabled",
                 "Health": "OK"
             },
             "FanName": "Fan 1 Tach",
             "Name": "Fan 1 Tach",
             "Reading": 0,
             "UpperThresholdNonCritical": null,
             "0em": {
                  "Lenovo": {
                          "InfoFormat@Redfish.Deprecated": "The property is deprecated. Please use
PartLocation instead.",
                          "InfoFormat": "Slot X",
                          "Info": "Slot 1",
```

```
"Info@Redfish.Deprecated": "The property is deprecated. Please use PartLocation
instead."
                      }
                 }
             "HotPluggable": true,
             "MinReadingRange": 0,
             "MemberId": "0",
             "LowerThresholdNonCritical": null,
             "SensorNumber": 65,
             "UpperThresholdFatal": null
        }
    "@odata.id": "/redfish/v1/Chassis/1/Thermal",
    "Status": {
         "State": "Enabled",
         "HealthRollup": "OK"
    "Name": "Thermal",
    "Id": "1",
    "0em": {
         "Lenovo": {
             "@odata.type": "#LenovoThermal.v1_0_0.Thermal",
             "HistoryTempMetric": {
                  "@odata.id": "/redfish/v1/Chassis/1/Thermal/Oem/Lenovo/HistoryTempMetric"
             }
        }
    "@odata.type": "#Thermal.v1_5_3.Thermal",
    "Temperatures": [
             "PhysicalContext": "Intake",
             "LowerThresholdCritical": null,
             "RelatedItem": [
                 {
                      "@odata.id": "/redfish/v1/Systems/1"
                 },
                 {
                      "@odata.id": "/redfish/v1/Chassis/1"
                 }
             "UpperThresholdFatal": 50,
             "Status": {
                  "State": "Enabled"
             "SensorNumber": 49,
             "Name": "Ambient Temp",
             "MaxReadingRangeTemp": 100,
             "UpperThresholdNonCritical": 43,
             "UpperThresholdCritical": 47,
             "LowerThresholdNonCritical": null,
             "MemberId": "0",
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Temperatures/0",
             "MinReadingRangeTemp": 0,
             "LowerThresholdFatal": null,
             "ReadingCelsius": 43
        }
```

```
"Description": "It represents the properties for Temperature and Cooling."
}
```

Chapter 8. BMC Management

Resource Manager

This resource is used to represent manager for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/Managers/1
Schema file	Manager_v1.xml

GET – BMC management properties

Use the GET method to retrieve properties in manager resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1

Request body

None

Response body

Turk Browning				Paradiation.
Field			Туре	Description
ld	ld		String	Always set to 1.
N	Name		String	"Manager".
Α	Actions		Object	Expanded.
	#N	lanager.Reset	Object	Expanded.
		ResetType@Redfish. AllowableValues	Array	Items: string
				Item count: 2
		ResetType@Redfish. AllowableValues[0]	String	"GracefulRestart". It indicates bmc will be restart in a graceful way.
		ResetType@Redfish. AllowableValues[1]	String	"ForceRestart". It indicates bmc will be restart right away.
Α	AutoDSTEnabled Boole.		Boolean	true, false
С	CommandShell		Object	Expanded.
	Se	rviceEnabled	Boolean	True, if SSH is enabled.
				False, if SSH is disabled.
	MaxConcurrentSessions Integer		Integer	2
	ConnectTypesSupported Array		Array	SSH. Currently only SSH is supported.
DateTime String		String	The current DateTime (with offset) for the manager, used to set or read time.	
DateTimeLocalOffset String		String	The time offset from UTC that the DateTime property is set to in format: +06:00 .	

© Copyright Lenovo 2017, 2020 **73**

Field	Туре	Description
Description	String	"This resource is used to represent a management subsystem for a Redfish implementation."
GraphicalConsole	Object	Expanded.
ServiceEnabled	Boolean	True, if FOD key is installed.
MaxConcurrentSessions	Integer	6.
ConnectTypesSupported	Array	Items: string.
		Item count: 1.
ConnectTypesSupported[0]	String	"KVMIP".
ManagerType	String	This property represents the type of manager that this resource represents. This property represents the type of manager that this resource represents. The value is "BMC(A controller which provides management functions for a single computer system)".
Model	String	The model information of this Manager as defined by the manufacturer. The value is "Lenovo XClarity Controller".
EthernetInterfaces	Link	A link to a URI reference to collection of Ethernet interface. This is a reference to a collection of NICs that this manager uses for network communication.
HostInterfaces	Link	A link to a URI reference to collection of host interface. This is a reference to a collection of NICs that host uses for network communication.
LogServices	Link	A link to a URI reference to collection of log service which is a collection of Logs used by the manager.
NetworkProtocol	Link	A link to a URI reference to collection of network protocol which is a reference to network services and their settings that the manager controls.
SerialInterfaces	Link	A link to a URI reference to collection of serial interface that this manager uses for serial and console communication.
VirtualMedia	Link	A link to a URI reference to collection of virtual media which are for the use of this manager.
FirmwareVersion	String	Firmware version of this Manager.
Links	Object	References to resources that are related to, but not contained by (subordinate to) this resource.
ManagerForChassis	Array	An array of references to the chassis that this manager has control over."
ManagerForChassis[0]	Link	The value of this property is a URI reference to a resource of chassis.
ManagerForChassis@odata.	Int	1
ManagerForServers	Array	An array of references to the systems that this manager has control over.
ManagerForServers[0]	Link	The value of this property is a URI reference to a resource of computer system.
ManagerForServers@odata.	Int	1

Field	Туре	Description
ActiveSoftwareImage	Link	The value of this property is a URI reference to a resource of firmware inventory.
SoftwareImages	Array	Items: link
		Item count: 2
SoftwareImages[N]	Link	The value of this property is a URI reference to a resource of firmware inventory.
SoftwareImages.@odata.count	Int	2
PowerState	Object	The value of this property indicates power state. It is always "On".
SerialConsole	Object	Expanded.
ConnectTypesSupported	Array	Items: string.
		Item count: 2.
ConnectTypesSupported[0]	String	"IPMI".
ConnectTypesSupported[1]	String	"SSH".
MaxConcurrentSessions	Integer	2.
ServiceEnabled	Boolean	True, if SSH is enabled.
		False, if SSH is disabled.
ServiceEntryPointUUID	String	The value of this property indicates UUID of service entry point.
Status	Object	Expanded.
State	String	The value of this property indicates state of manager. It is always "Enabled".
UUID	String	The value of this property indicates UUID of manager.

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "DateTimeLocalOffset": "+13:00",
    "@odata.id": "/redfish/v1/Managers/1",
    "NetworkProtocol": {
         "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol"
    },
"PowerState": "On",
    "Links": {
         "ActiveSoftwareImage": {
             "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/BMC-Primary"
        },
"SoftwareImages": [
                 "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/BMC-Primary"
             },
```

```
{
            "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup"
        }
    "ManagerForServers@odata.count": 1,
    "ManagerForChassis": [
        {
            "@odata.id": "/redfish/v1/Chassis/1"
    "ManagerForServers": [
        {
            "@odata.id": "/redfish/v1/Systems/1"
    "ManagerForChassis@odata.count": 1,
    "SoftwareImages@odata.count": 2
"SerialConsole": {
    "MaxConcurrentSessions": 2,
    "ServiceEnabled": true,
    "ConnectTypesSupported": [
        "IPMI",
        "SSH"
"FirmwareVersion": "TGBT99T 3.23 2020-03-23",
"Actions": {
    "#Manager.Reset": {
        "@Redfish.ActionInfo": "/redfish/v1/Managers/1/ResetActionInfo",
        "target": "/redfish/v1/Managers/1/Actions/Manager.Reset",
        "title": "Reset",
        "ResetType@Redfish.AllowableValues": [
            "GracefulRestart",
            "ForceRestart"
        1
    }
},
"SerialInterfaces": {
    "@odata.id": "/redfish/v1/Managers/1/SerialInterfaces"
"DateTime": "2020-03-24T19:52:02+13:00",
"VirtualMedia": {
    "@odata.id": "/redfish/v1/Managers/1/VirtualMedia"
"Description": "This resource is used to represent a management subsystem for a Redfish implementation.",
"AutoDSTEnabled": true,
"LogServices": {
    "@odata.id": "/redfish/v1/Systems/1/LogServices"
"CommandShell": {
    "MaxConcurrentSessions": 2,
    "ServiceEnabled": true,
    "ConnectTypesSupported": [
        "SSH"
"Status": {
    "State": "Enabled"
},
```

```
"Id": "1".
"Name": "Manager",
"ManagerType": "BMC",
"ServiceEntryPointUUID": "00000000-0000-0000-0000-00000000000",
"0em": {
    "Lenovo": {
        "Recipients": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/Recipients"
        "FoD": {
            "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/FoD"
        },
        "Security": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/Security"
        "SecureKeyLifecycleService": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/SecureKeyLifecycleService"
        "Watchdogs": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/Watchdogs"
        "ServiceAdvisor": "/redfish/v1/Managers/1/Oem/Lenovo/ServiceAdvisor",
        "ServiceData": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/ServiceData"
        },
        "OPSettings": {
             "ClientID": null,
             "AuthorizationServerUri": null,
             "SSOState": false,
             "PubKey": null,
             "UserInfoUri": ""
        "DateTimeService": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/DateTimeService"
        "RemoteMap": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/RemoteMap"
        },
        "@odata.type": "#LenovoManager.v1 0 O.LenovoManagerProperties",
        "RemoteControl": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/RemoteControl"
        "ServerProfile": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/ServerProfile"
        "KCSEnabled": true,
        "RecipientsSettings": {
             "RetryCount": 5,
             "RetryInterval": 0.5,
             "RntryRetryInterval": 0.5
        },
        "Configuration": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/Configuration"
    }
},
"@odata.type": "#Manager.v1_6_0.Manager",
"GraphicalConsole": {
    "MaxConcurrentSessions": 6,
    "ServiceEnabled": true,
    "ConnectTypesSupported": [
```

```
"KVMIP"
        ]
    "HostInterfaces": {
        "@odata.id": "/redfish/v1/Managers/1/HostInterfaces"
    "@odata.etag": "\"15a803ef2ef6b2ff69dbba\"",
    "Model": "Lenovo XClarity Controller",
    "EthernetInterfaces": {
        "@odata.id": "/redfish/v1/Managers/1/EthernetInterfaces"
}
```

PATCH – Update BMC time zone and other oem properties

Use the PATCH method to update properties in Manager resource for Redfish service.

Request URL

PATCH https://<BMC_IPADDR>/redfish/v1/Managers/1

Request parameters

Properties to be updated are shown as below, all of these properties can be changed individually.

Field	Туре	Description
DateTime- LocalOffset	String	The time offset from UTC that the DateTime property is set to. Allowable values list as follows:
		"+00:00", "+01:00", "+02:00", "+03:00", "+03:30", "+04:00", "+04:30", "+05:00", "+05:30", "+05:45", "+06:00", "+06:30", "+07:00", "+08:00", "+09:00", "+09:30", "+10:00", "+11:00", "+12:00", "+13:00", "-12:00", "-11:00", "-10:00", "-09:00", "-08:00", "-07:00", "-06:00", "-05:00", "-04:30", "-04:00", "-03:30", "-03:00", "-02:00", "-01:00"
		This property can't be patched when DST is enabled or host time is local time.

Response body

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example is PATCH body.

```
"DateTimeLocalOffset" : "+08:00"
}
```

The resource updated is returned.

```
{
    "DateTimeLocalOffset": "+08 :00",
    "@odata.id": "/redfish/v1/Managers/1",
    "NetworkProtocol": {
        "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol"
    "PowerState": "On",
    "Links": {
        "ActiveSoftwareImage": {
             "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/BMC-Primary"
        "SoftwareImages": [
            {
                 "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/BMC-Primary"
            },
            {
                 "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup"
            }
        "ManagerForServers@odata.count": 1,
        "ManagerForChassis": [
            {
                 "@odata.id": "/redfish/v1/Chassis/1"
            }
        "ManagerForServers": [
            {
                 "@odata.id": "/redfish/v1/Systems/1"
        "ManagerForChassis@odata.count": 1,
        "SoftwareImages@odata.count": 2
    "MaxConcurrentSessions": 2,
        "ServiceEnabled": true,
        "ConnectTypesSupported": [
             "IPMI",
             "SSH"
        1
    "Firmware Version": "TGBT99T 3.23 2020-03-23",
    "Actions": {
        "#Manager.Reset": {
             "@Redfish.ActionInfo": "/redfish/v1/Managers/1/ResetActionInfo",
             "target": "/redfish/v1/Managers/1/Actions/Manager.Reset",
            "title": "Reset",
             "ResetType@Redfish.AllowableValues": [
                 "GracefulRestart",
                 "ForceRestart"
            ]
        }
    },
    "SerialInterfaces": {
        "@odata.id": "/redfish/v1/Managers/1/SerialInterfaces"
    "DateTime": "2020-03-24T20:10:14+13:00",
    "VirtualMedia": {
        "@odata.id": "/redfish/v1/Managers/1/VirtualMedia"
    "Description": "This resource is used to represent a management subsystem for a Redfish implementation.",
```

```
"AutoDSTEnabled": true,
"LogServices": {
    "@odata.id": "/redfish/v1/Systems/1/LogServices"
\hbox{\tt "CommandShell": } \{
    "MaxConcurrentSessions": 2,
    "ServiceEnabled": true,
    "ConnectTypesSupported": [
        "SSH"
},
"UUID": "00000000-0000-0000-0000-00000000000".
"Status": {
    "State": "Enabled"
"Id": "1".
"Name": "Manager",
"ManagerType": "BMC",
"ServiceEntryPointUUID": "00000000-0000-0000-0000-0000000000",
"0em": {
    "Lenovo": {
         "Recipients": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/Recipients"
         "FoD": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/FoD"
         "Security": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/Security"
         "SecureKeyLifecycleService": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/SecureKeyLifecycleService"
         "Watchdogs": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/Watchdogs"
         "ServiceAdvisor": "/redfish/v1/Managers/1/Oem/Lenovo/ServiceAdvisor",
         "ServiceData": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/ServiceData"
        },
         "OPSettings": {
             "ClientID": null,
             "AuthorizationServerUri": null,
             "SSOState": false,
             "PubKey": null,
             "UserInfoUri": ""
         "DateTimeService": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/DateTimeService"
         },
         "RemoteMap": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/RemoteMap"
         "@odata.type": "\#LenovoManager.v1\_0\_0.LenovoManagerProperties",
         "RemoteControl": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/RemoteControl"
         "ServerProfile": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/ServerProfile"
         "KCSEnabled": true,
```

```
"RecipientsSettings": {
             "RetryCount": 5,
             "RetryInterval": 0.5,
             "RntryRetryInterval": 0.5
         "Configuration": {
             "@odata.id": "/redfish/v1/Managers/1/Oem/Lenovo/Configuration"
    }
},
"@odata.type": "#Manager.v1_6_0.Manager",
"GraphicalConsole": {
    "MaxConcurrentSessions": 6,
    "ServiceEnabled": true,
    "ConnectTypesSupported": [
         "KVMIP"
},
"HostInterfaces": {
    "@odata.id": "/redfish/v1/Managers/1/HostInterfaces"
"@odata.etag": "\"15a7f4e5d9cd32ff69dbab\"",
"Model": "Lenovo XClarity Controller",
"EthernetInterfaces": {
    "@odata.id": "/redfish/v1/Managers/1/EthernetInterfaces"
}
```

POST - BMC reset

Use the POST method to reset the BMC.

Request URL

}

POST https://<BMC_IPADDR>/redfish/v1/Managers/1/Actions/Manager.Reset

Request body

Field	Туре	Description	
Reset- Type	String	It indicates the reset type for bmc. Valid values: "GracefulRestart", "ForceRestart"	

Response body

None

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

The following example is POST body.

```
{
    "ResetType": "GracefulRestart"
}
```

The following example JSON response is returned:

None

Chapter 9. Network management

Resource EthernetInterface (BMC NIC)

This resource is used to represent the BMC ethernet Interfaces for a Redfish implementation.

Number of Resources	2
Resource Path	/redfish/v1/Managers/1/EthernetInterfaces/{NIC, ToHost}
Schema file	EthernetInterfaceCollection_v1.xml
	EthernetInterface_v1.xml

GET – Collection of BMC ethernet interface properties

Use the GET method to retrieve properties in Ethernet interface collection resource for a BMC.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/EthernetInterfaces

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Members	Array	Items: A reference link of the elements of EthernetInterface.
Name	String	EthernetInterfaceCollection.
Descrpition	String	A collection of EthernetInterface resource instances.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

The following example JSON response is returned:

© Copyright Lenovo 2017, 2020

```
"@odata.type": "#EthernetInterfaceCollection.EthernetInterfaceCollection",
    "@odata.etag": "\"3a44d9cd5c02b15baae44caebe1d29fb\"",
    "Members@odata.count": 2,
    "Description": "A collection of EthernetInterface resource instances."
}
```

GET – BMC Ethernet properties

Use the GET method to retrieve properties in Ethernet interface resource for a BMC.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/EthernetInterfaces/{NIC,ToHost}

Request body

None

Response body

Field	Туре	Description
FQDN	String	The complete, fully qualified domain name for this XCC interface
IPv6DefaultGateway	String	The current IPv6 default gateway address that is in use on this XCC interface
ld	String	{1N}
IPv6StaticAddresses	Array	An array of objects used to represent the IPv6 static connection characteristics for this XCC interface
IPv6StaticAddresses	Object	Array element
PrefixLength	Nunber	The Prefix Length of this IPv6 address
Address	String	A valid IPv6 address
AutoNeg	Boolean	Indicates if the speed and duplex are automatically negotiated and configured on this XCC interface:
		True. Auto negotiation of speed and duplex is enabled.
		False. Auto negotiation of speed and duplex is disabled.
IPv6AddressPolicyTable	Array	An array of objects used to represent the Address Selection Policy Table as defined in RFC 6724
IPv6AddressPolicyEntry	Object	Array element
Prefix	String	The prefix of IPv6 address.
Precedence	Number	Fix value "10".
Label	Number	The label of IPv6 address.
SpeedMbps	String	The current speed in Mbps of this XCC interface (units: Mbit/s). This property is null on a GET.
Status Object		Expanded.
State	String	"Enabled" if this Ethernet interface is enabled.
Health	String	null
HostName String		The host name for this XCC interface, without any domain information.

Fie	eld	Туре	Description
ΙΡν	r6Addresses	Array	An array of objects used to represent the IPv6 connection characteristics for this XCC interface
ı	Pv6Address	Object	Array element
	Address	String	The IPv6 Address
	PrefixLength	Number	The IPv6 Address Prefix Length
	AddressOrigin	String	The type of the IPv6 address origin for this XCC interface:
			Static. A static address as configured by the user.
			DHCPv6. Address is provided by a DHCPv6 service.
			LinkLocal. Address is valid only for this network segment (link).
			SLAAC. Address is provided by a Stateless Address AutoConfiguration (SLAAC) service.
	AddressState	String	The current state of this address as defined in RFC 4862:
			Preferred. This address is currently within both it's valid and preferred lifetimes as defined in RFC 4862.
			Deprecated. This address is currently within it's valid lifetime, but is now outside of it's preferred lifetime as defined in RFC 4862.
			Tentative. This address is currently undergoing Duplicate Address Detection testing as defined in RFC 4862 section 5.4.
			Failed. This address has failed Duplicate Address Detection testing as defined in RFC 4862 section 5.4 and is not currently in use."
Ful	FullDuplex Boolean		The duplex status of the Ethernet connection on this XCC interface:
			True. In Full Duplex mode.
			False. Not in Full Duplex mode.
ΙΡν	4StaticAddresses	Array	An array of objects used to represent the IPv4 connection characteristics for this XCC interface.
I	Pv4StaticAddress	Object	Array element
	Address	String	The IPv4 Address
	SubnetMask	String	The IPv4 Subnet mask.
	AddressOrigin	String	Static.
	Gateway	String	The IPv4 gateway for this address
ΙΡν	r4Address	Array	An array of objects used to represent the IPv4 connection characteristics for this XCC interface
I	Pv4Address	Object	Array element
	Address	String	the IPv4 Address
	SubnetMask	String	the IPv4 Subnet mask.
	AddressOrigin	String	This indicates how the address was determined:
			Static. A static address as configured by the user.
			DHCP. Address is provided by a DHCPv4 service.
			BOOTP. Address is provided by a BOOTP service.
			IPv4LinkLocal . Address is valid only for this network segment (link).

Field		Туре	Description
	Gateway	String	the IPv4 gateway for this address
NameServers		Array	DNS name servers that are currently in use on this XCC interface (IPv4 1st,2nd, 3rd ip address, IPv6 1st,2nd, 3rd ip address)
lı	nterfaceEnabled	Boolean	A boolean indicating whether this interface is enabled
L	inkStatus	String	The value of this property represents the current status of link.
			Valid values:
			LinkUp, NoLink, LinkDown.
			The description of LinkUp is "The link is available for communication on this interface."
			The description of NoLink is "There is no link or connection detected on this interface."
			The description of LinkDown is "There is no link on this interface, but the interface is connected.
L	inks	Object	Expanded.
	Chassis	Link	The value of this property shall be a reference to a resource of type Chassis that represent the physical container associated with this Ethernet Interface.
	HostInterface	Link	The value of this property shall be a reference to a resource of type HostInterface which represents the interface used by a host to communicate with a Manager. Only in ToHost has this property.
MACAddress		String	The currently configured MAC address of the (logical port) interface.
F	PermanentMACAddress	String	The permanent MAC address assigned to this interface (port).
١	Name	String	The name of the resource(eth1/eth0/usb0)
Ν	MTUSize	Number	The currently configured Maximum Transmission Unit (MTU) in bytes on this XCC interface
١	/LAN	Link	The value of this property shall be the VLAN for this interface. If this interface supports more than one VLAN, the VLAN property shall not be present and the VLANS collection link shall be present instead.
	VLANEnable	Boolean	The property of VLAN is Enable or not.
	VLANId	Number	The ld of VLAN.
Ν	MaxIPv6StaticAddresses	Number	The maximum number of IPv6 static address.
DHCPv4		Object	Expanded.
	UseDNSServers	Boolean	Use DNS servers or not.
	UseDomainName	Boolean	Use Domain Name or not.
	DHCPEnabled	Boolean	The DHCP is Enabled or not.
Ĺ	UseNTPServers	Boolean	Not used, always null.
	UseGateway	Boolean	Not used, always null.
	UseStaticRoutes	Boolean	Not used, always null.
_			

Field	Туре	Description
FallbackAddress	String	DHCPv4 fallback address method for this interface.
		Valid values:None, Static
DHCPv6	Object	Expanded
UseDNSServers	Boolean	Use DNS servers or not.
UseDomainName	Boolean	Use Domain Name or not.
OperatingMode	String	The operating mode is Stateful or Disabled.
UseNTPServers	Boolean	Not used, always null.
UseRapidCommit	Boolean	Not used, always null.
IPv6StaticDefaultGateways	Array	An array of objects used to represent the IPv6 static default gateway for this XCC interface.
Address	String	Static IPv6 default gateway address
PrefixLength	Integer	Fixed value "0"
StaticNameServers	Array	Items: string
		Items count: 6
StatelessAddressAutoConfig Object		Expanded
IPv4AutoConfigEnabled	Boolean	Not used, always null. Only in NIC has this property.
IPv6AutoConfigEnabled	Boolean	Enable IPv6 Auto Config or not.
Description String		Fixed string "Manager Ethernet Interface"

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"DHCPv6": {
      "UseNTPServers": null,
      "OperatingMode": "Disabled",
"UseDNSServers": false,
      "UseDomainName": false,
"UseRapidCommit": null
},
"Links": {
      "Chassis": {
            "@odata.id": "/redfish/v1/Chassis/1"
},
"VLAN": {
"VLAN
      "VLANEnable": false,
      "VLANId": 1
},
"Oem": {
      "Lenovo": {
```

```
"@odata.type": "#LenovoEthernetInterface.v1_0_0.LenovoEthernetInterfaceProperties",
         "DomainName": "",
         "IPv4Enabled": true,
         "IPv4AddressAssignedby": "Static",
         "InterfaceNicMode": "Dedicated",
         "NetworkSettingSync": true,
         "IPv6AddressAssignedby": [],
         "InterfaceFailoverMode": "Shared",
         "IPv6Enabled": false
    }
},
"IPv6Addresses": [],
"Status": {
    "Health": null,
    "State": "Enabled"
"IPv6DefaultGateway": "::",
"IPv6StaticDefaultGateways": [
         "Address": "::",
        "PrefixLength": 0
"StaticNameServers": [
    "0.0.0.0",
    "0.0.0.0",
    "0.0.0.0",
    "::",
    "::",
    "::"
"MTUSize": 1500,
"FullDuplex": null,
"IPv4StaticAddresses": [
         "AddressOrigin": "Static",
         "Gateway": "192.168.0.1",
         "Address": "192.168.0.41"
         "SubnetMask": "255.255.255.0"
    }
"IPv6AddressPolicyTable": [
         "Label": 0,
         "Precedence": 50,
         "Prefix": "::1/128"
    },
        "Label": 3,
        "Precedence": 11,
        "Prefix": "::/96"
    },
        "Label": 4,
        "Precedence": 35,
        "Prefix": "::ffff:0.0.0.0/96"
    },
        "Label": 6,
         "Precedence": 10,
         "Prefix": "2001::/32"
```

```
},
        "Label": 7,
        "Precedence": 10,
        "Prefix": "2001:10::/28"
    },
        "Label": 12,
        "Precedence": 1,
        "Prefix": "3ffe::/16"
    },
        "Label": 2,
         "Precedence": 30,
        "Prefix": "2002::/16"
    },
        "Label": 11,
        "Precedence": 1,
        "Prefix": "fec0::/10"
    },
        "Label": 5,
        "Precedence": 5,
        "Prefix": "fc00::/7"
    },
        "Label": 1,
        "Precedence": 40,
        "Prefix": "::/0"
"PermanentMACAddress": "7c:d3:0a:5e:22:65",
\verb"StatelessAddressAutoConfig": \{
    "IPv4AutoConfigEnabled": null,
    "IPv6AutoConfigEnabled": false
},
"NameServers": [
    "::"
"Name": "Manager Ethernet Interface",
"AutoNeg": true,
"@odata.etag": "\"24596c8504c398d843823abc542140fa\"",
"MACAddress": "7c:d3:0a:5e:22:65",
"FQDN": "XCC-7X00-1234567890",
"Description": "Manager Ethernet Interface",
"@odata.type": "#EthernetInterface.v1_5_0.EthernetInterface",
"InterfaceEnabled": true,
"Id": "NIC",
"LinkStatus": "LinkUp",
"DHCPv4": {
    "UseNTPServers": null,
    "UseDNSServers": true,
    "UseGateway": null,
    "FallbackAddress": "None",
    "DHCPEnabled": false,
```

```
"UseDomainName": true,
    "UseStaticRoutes": null
"IPv6StaticAddresses": [
    {
         "Address": "::",
         "PrefixLength": 64
],
"HostName": "XCC-7X00-1234567890<sub>,</sub>
"@odata.id": "/redfish/v1/Managers/1/EthernetInterfaces/NIC",
"IPv4Addresses": [
    {
         "AddressOrigin": "Static",
         "Gateway": "192.168.0.1",
         "Address": "192.168.0.41",
         "SubnetMask": "255.255.255.0"
"MaxIPv6StaticAddresses": 1,
"SpeedMbps": null
```

PATCH – Update BMC Ethernet configurations

Use the PATCH method to update properties in Ethernet interface resource for a BMC.

Request URL

}

PATCH https://<BMC_IPADDR>/redfish/v1/Managers/1/EthernetInterfaces/NIC

Request body

Properties to be updated are shown below:

Field	Туре	Description
InterfaceEnabled	Boolean	A boolean indicating whether this interface is enabled.
MACAddress	String	The currently configured MAC address of the (logical port) interface.
SpeedMbps	String	The current speed in Mbps of this XCC interface(units: Mbit/s)
		The property value should be between 10 and 100.
AutoNeg	Boolean	Indicate if the speed and duplex are automatically negotiated and configured on this XCC interface:
		True. Auto negotiation of speed and duplex is enabled.
		False. Auto negotiation of speed and duplex is disabled.
FullDuplex	Boolean	The duplex status of the Ethernet connection on this XCC interface:
		True. In Full Duplex mode.
		False. Not in Full Duplex mode.
MTUSize	Number	The currently configured Maximum Transmission Unit (MTU) in bytes on this XCC interface
HostName	String	The host name for this XCC interface, without any domain information.

Field	Туре	Description
IPv4StaticAddresses	Array	An array of objects used to represent the IPv4 connection characteristics for this XCC interface
IPv6StaticAddresses	Array	An array of objects used to represent the IPv6 static connection characteristics for this XCC interface
IPv6StaticDefaultGateways	Array	An array of objects used to represent the IPv6 static default gateways for this XCC interface
Address	String	The gateway address
VLAN	Link	The value of this property shall be the VLAN for this interface. If this interface supports more than one VLAN, the VLAN property shall not be present and the VLANS collection link shall be present instead.
VLANEnable	Boolean	The property of VLAN is Enable or not.
VLANId	Number	The ld of VLAN.
DHCPv4	Object	Expanded
DHCPEnabled	Boolean	The DHCP is Enabled or not.
UseDNSServers	Boolean	Use DNS servers or not.
UseDomainName	Boolean	Use Domain Name or not.
FallbackAddress	String	DHCPv4 fallback address method for this interface. Valid values: None, Static.
DHCPv6	Object	Expanded
OperatingMode	String	The property of operating mode.
		The value should be "Stateful" or "Disabled".
UseDNSServers	Boolean	Use DNS servers or not.
UseDomainName	Boolean	Use Domain Name or not.
StaticNameServers	Array	Items: string
		Items count: 6
StatelessAddressAutoConfig	Object	Expanded
IPv6AutoConfigEnabled	Boolean	Enable IPv6 Auto Config or not.

Response body

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID	
400	PropertyValueNotInList, PropertyValueFormatError, PropertyValueTypeError, PropertyNotWritable	
500	InternalError	

Example

The following example is PATCH body.

```
"MTUSize": 1490,
```

```
"SpeedMbps": 100,
    "FullDuplex": true
}
The resource after updated is returned.
{
    "DHCPv6": {
         "UseNTPServers": null,
         "OperatingMode": "Disabled",
         "UseDNSServers": false,
         "UseDomainName": false,
         "UseRapidCommit": null
    "Links": {
         "Chassis": {
             "@odata.id": "/redfish/v1/Chassis/1"
    },
    "VLAN": {
         "VLANEnable": false,
         "VLANId": 1
    },
    "Oem": {
         "Lenovo": {
             "@odata.type": "#LenovoEthernetInterface.v1_0_0.LenovoEthernetInterfaceProperties",
             "DomainName": "",
             "IPv4Enabled": true,
             "IPv4AddressAssignedby": "Static",
             "InterfaceNicMode": "Dedicated",
             "NetworkSettingSync": true,
             "IPv6AddressAssignedby": [],
             "InterfaceFailoverMode": "Shared",
             "IPv6Enabled": false
        }
    },
    "IPv6Addresses": [],
    "Status": {
         "Health": null,
         "State": "Enabled"
    "IPv6DefaultGateway": "::",
    "IPv6StaticDefaultGateways": [
             "Address": "::",
             "PrefixLength": 0
    "StaticNameServers": [
        "0.0.0.0",
         "0.0.0.0",
         "0.0.0.0",
         "::",
         "::",
         "::"
    "MTUSize": 1490,
    "FullDuplex": true,
    "IPv4StaticAddresses": [
         {
             "AddressOrigin": "Static",
```

```
"Gateway": "192.168.0.1",
        "Address": "192.168.0.41",
        "SubnetMask": "255.255.255.0"
    }
"IPv6AddressPolicyTable": [
    {
        "Label": 0,
        "Precedence": 50,
        "Prefix": "::1/128"
    },
        "Label": 3,
        "Precedence": 11,
        "Prefix": "::/96"
    },
        "Label": 4,
        "Precedence": 35,
        "Prefix": "::ffff:0.0.0.0/96"
    },
        "Label": 6,
        "Precedence": 10,
        "Prefix": "2001::/32"
    },
        "Label": 7,
        "Precedence": 10,
        "Prefix": "2001:10::/28"
    },
        "Label": 12,
        "Precedence": 1,
        "Prefix": "3ffe::/16"
    },
        "Label": 2,
         "Precedence": 30,
        "Prefix": "2002::/16"
    },
        "Label": 11,
        "Precedence": 1,
        "Prefix": "fec0::/10"
    },
        "Label": 5,
        "Precedence": 5,
        "Prefix": "fc00::/7"
    },
        "Label": 1,
        "Precedence": 40,
        "Prefix": "::/0"
    }
"PermanentMACAddress": "7c:d3:0a:5e:22:65",
"StatelessAddressAutoConfig": {
    "IPv4AutoConfigEnabled": null,
    "IPv6AutoConfigEnabled": false
```

```
"NameServers": [
    "",
""
   "",
"Name": "Manager Ethernet Interface",
"AutoNeg": true,
"@odata.etag": "\"24596c8504c398d843823abc542140fa\"",
"MACAddress": "7c:d3:0a:5e:22:65",
"FQDN": "XCC-7X00-1234567890",
"Description": "Manager Ethernet Interface",
"@odata.type": "#EthernetInterface.v1 5 O.EthernetInterface",
"InterfaceEnabled": true,
"Id": "NIC",
"LinkStatus": "LinkUp",
"DHCPv4": {
    "UseNTPServers": null,
    "UseDNSServers": true,
    "UseGateway": null,
    "FallbackAddress": "None",
    "DHCPEnabled": false,
    "UseDomainName": true,
    "UseStaticRoutes": null
"IPv6StaticAddresses": [
    {
        "Address": "::",
        "PrefixLength": 64
"HostName": "XCC-7X00-1234567890",
"@odata.id": "/redfish/v1/Managers/1/EthernetInterfaces/NIC",
"IPv4Addresses": [
        "AddressOrigin": "Static",
        "Gateway": "192.168.0.1",
        "Address": "192.168.0.41"
        "SubnetMask": "255.255.255.0"
"MaxIPv6StaticAddresses": 1,
"SpeedMbps": 100
```

PATCH – Update BMC Ethernet over USB configurations

Use the PATCH method to update properties in Ethernet interface resource for a BMC.

Request URL

PATCH https://<BMC_IPADDR>/redfish/v1/Managers/1/EthernetInterfaces/ToHost

Request body

Properties to be updated are shown as bellow, all of these properties can be changed individually.

}

Field	Туре	Error Message ID	
InterfaceEnabled	Boolean	A boolean indicating whether this interface is enabled.	
IPv4StaticAddress- es	Array	An array of objects used to represent the IPv4 connection characteristics for this XCC interface. Only the static IPv4 address can be updated.	

Response body

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

{

The following example is PATCH body.

The resource after updated is returned.

```
"FQDN": "",
"Id": "ToHost",
"InterfaceEnabled": true,
"Links": {
     "Chassis": {
         "@odata.id": "/redfish/v1/Chassis/1"
     "HostInterface": {
         "@odata.id": "/redfish/v1/Managers/1/HostInterfaces/1"
},
"AutoNeg": false,
"AdressPolice
"IPv6AddressPolicyTable": [
     {
         "Precedence": 50,
         "Prefix": "::1/128",
         "Label": 0
     },
         "Precedence": 11,
         "Prefix": "::/96",
         "Label": 3
     },
         "Precedence": 35,
         "Prefix": "::ffff:0.0.0.0/96",
         "Label": 4
```

```
},
     {
         "Precedence": 10,
         "Prefix": "2001::/32",
         "Label": 6
     },
         "Precedence": 10,
         "Prefix": "2001:10::/28",
"Label": 7
     },
         "Precedence": 1,
         "Prefix": "3ffe::/16",
         "Label": 12
     },
         "Precedence": 30,
         "Prefix": "2002::/16",
         "Label": 2
     },
         "Precedence": 1,
         "Prefix": "fec0::/10",
         "Label": 11
     },
         "Precedence": 5,
         "Prefix": "fc00::/7",
         "Label": 5
         "Precedence": 40,
         "Prefix": "::/0",
         "Label": 1
     }
],
"SpeedMbps": 100,
"HostName": "",
"IPv6Addresses": [
          "AddressState": "Preferred",
          "Address": "fe80::7ed3:aff:feed:bb1a",
          "PrefixLength": 64,
         "AddressOrigin": "LinkLocal"
     }
"FullDuplex": true,
"StaticNameServers": [
     "0.0.0.0",
     "0.0.0.0",
     "0.0.0.0",
    "::",
"::",
"DHCPv4": {
     "UseDNSServers": false,
     "FallbackAddress": "None",
     "UseGateway": null,
     "UseNTPServers": null,
```

```
"UseDomainName": false.
    "DHCPEnabled": false,
    "UseStaticRoutes": null
"IPv4Addresses": [
    {
        "Gateway": "0.0.0.0",
        "Address": "169.254.95.118",
        "SubnetMask": "255.255.0.0",
        "AddressOrigin": "Static"
    }
"Description": "Management Network Interface",
"StatelessAddressAutoConfig": {
    "IPv4AutoConfigEnabled": null,
    "IPv6AutoConfigEnabled": false
},
"IPv6StaticDefaultGateways": [
    {
        "PrefixLength": 0,
        "Address": "::"
"MTUSize": 1500,
"DHCPv6": {
    "OperatingMode": "Disabled",
    "UseNTPServers": null,
    "UseDomainName": false,
    "UseRapidCommit": null,
    "UseDNSServers": false
"Status": {
    "State": "Enabled",
    "Health": null
"MACAddress": "7c:d3:0a:ed:bb:1a",
"Name": "Manager Ethernet Over USB Interface",
"IPv4StaticAddresses": [
    {
         "Gateway": "0.0.0.0",
        "Address": "169.254.95.119",
        "SubnetMask": "255.255.0.0",
        "AddressOrigin": "Static"
    }
"@odata.id": "/redfish/v1/Managers/1/EthernetInterfaces/ToHost",
"0em": {
    "Lenovo": {
        "OSIPv4Address": "169.254.95.120",
        "AddressMode": "IPv6LLA",
        "@odata.type": "#LenovoEthernetInterface.v1 0 O.LenovoEthernetInterfaceProperties",
        "PortForwarding": {
             "@odata.id": "/redfish/v1/Managers/1/EthernetInterfaces/ToHost/Oem/Lenovo/PortForwarding"
    }
},
"@odata.type": "#EthernetInterface.v1_5_1.EthernetInterface",
"MaxIPv6StaticAddresses": 0,
"LinkStatus": "LinkUp",
"@odata.etag": "\"f57f676204ef32c8c907e\"",
"PermanentMACAddress": "7c:d3:0a:ed:bb:1a",
```

```
"NameServers": []
}
```

Resource EthernetInterface (Server NIC)

This resource is used to represent the Server Ethernet Interfaces for a Redfish implementation.

Number of Resources	Number of server Ethernet interfaces
Resource Path	/redfish/v1/Systems/1/EthernetInterfaces/NIC{1-N}, ToManager
Schema file	EthernetInterfaceCollection_v1.xml
	EthernetInterface_v1.xml

GET – Collection of server Ethernet interfaces

Use the GET method to retrieve properties in Ethernet interface collection resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/EthernetInterfaces

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Members	Array	Items: A reference link of the elements of EthernetInterface
Name	String	EthernetInterfaceCollection
Description	String	A collection of EthernetInterface resource instances.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

When the request is successful, a message body similar to the following is returned:

```
"@odata.id": "/redfish/v1/Systems/1/EthernetInterfaces",
"Name": "EthernetInterfaceCollection",
"@odata.context": "/redfish/v1/$metadata#EthernetInterfaceCollection.EthernetInterfaceCollection",
"Members": [
    {
        "@odata.id": "/redfish/v1/Systems/1/EthernetInterfaces/ToManager"
    },
        "@odata.id": "/redfish/v1/Systems/1/EthernetInterfaces/NIC1"
    },
```

GET – Server Ethernet interface properties

Use the GET method to retrieve properties in Ethernet interface resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/EthernetInterfaces/NIC{1...N}

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
ld	String	NIC{1N}
SpeedMbps	String, Null	The current speed in Mbps of this XCC interface(units: Mbit/s)
InterfaceEnabled	Boolean, Null	A boolean indicating whether this interface is enabled
MACAddress	String	The currently configured MAC address of the (logical port) interface.
PermanentMACAddress	String	The permanent MAC address assigned to this interface (port).
Name	String	"External Ethernet Interface"
LinkStatus	String	The link status of this interface (port)
Status	Object	Expand
State	String	"Enabled" for support inventory display.
Health	String	"OK" for support inventory display.
Links	Object	Expand
Chassis	Link	The value is a reference to the resource "Chassis" that represent the physical container.
Description	String	External Network Interface
FQDN	String	Fully qualified domain name
HostName	String	Host name
NameServers	Array	DNS servers in use
IPv4Addresses	Array	IPv4 addresses currently assigned to this interface

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "FODN": "".
    "Id": "NIC1",
    "NameServers": [],
    "SpeedMbps": null,
    "HostName": ""
    "IPv4Addresses": [],
    "Description": "Enternal Network Interface",
    "Status": {
         "State": "Enabled",
        "Health": "OK"
    "MACAddress": "7e:d3:0a:ed:bb:1b",
    "Name": "Enternal Ethernet Interface",
    "InterfaceEnabled": true,
    "@odata.type": "#EthernetInterface.v1_5_1.EthernetInterface",
    "Links": {
         "Chassis": {
             "@odata.id": "/redfish/v1/Chassis/1"
    "LinkStatus": "LinkDown",
    "@odata.etag": "\"4524b3cedd2525a9e6c\"",
    "PermanentMACAddress": "7e:d3:0a:ed:bb:1b",
    "@odata.id": "/redfish/v1/Systems/1/EthernetInterfaces/NIC1"
}
```

GET – Server Ethernet over USB properties

Use the GET method to retrieve properties in Ethernet interface resource between the server and manager.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/EthernetInterfaces/ToManager

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
ld	String	ToManager
SpeedMbps	String	The current speed in Mbps of this XCC interface(units: Mbit/s)
InterfaceEnabled	Boolean	A boolean indicating whether this interface is enabled

Field	Туре	Description
MACAddress	String	The currently configured MAC address of the (logical port) interface.
PermanentMACAddress	String	The permanent MAC address assigned to this interface (port).
Name	String	"Host Ethernet Interface"
LinkStatus	String	The link status of this interface (port).
Status	Object	Expand
State	String	"Enabled"
Health	String	Null
Links	Object	Expand
Chassis	Link	The value is a reference to the resource "Chassis" that represent the physical container.
HostInterface	Link	A reference to the recource "HostInterface" which represents the interface used by the host to communicate with the manager.
Description	String	Host Network Interface
FQDN	String	"" (empty string)
HostName	String	"" (empty string)
NameServers	String	Empty array
	Array	
IPv4Addresses	Array	Empty array

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"FQDN": "",
"Id": "ToManager",
"NameServers": [],
"SpeedMbps": 100,
"HostName": "",
"IPv4Addresses": [],
"Description": "Host Network Interface",
"Status": {
    "State": "Enabled",
    "Health": null
},
"MACAddress": "7e:d3:0a:ed:bb:1b",
"Name": "Host Ethernet Interface",
"InterfaceEnabled": true,
"@odata.type": "#EthernetInterface.v1_5_1.EthernetInterface",
"Links": {
    "Chassis": {
        "@odata.id": "/redfish/v1/Chassis/1"
```

```
"HostInterface": {
             "@odata.id": "/redfish/v1/Managers/1/HostInterfaces/1"
    "LinkStatus": "LinkUp",
    "@odata.etag": "\"4524b3cedd2525a9e6c\"",
    "PermanentMACAddress": "7e:d3:0a:ed:bb:1b",
    "@odata.id": "/redfish/v1/Systems/1/EthernetInterfaces/ToManager"
}
```

Resource HostInterface

Use the GET method to retrieve properties in Host interface resource for a server.

Number of Resources	1
Resource Path	/redfish/v1/Managers/1/HostInterfaces
Schema file	HostInterfaceCollection_v1.xml
	HostInterface_v1.xml

GET - Collection of host interface

Use the GET method to retrieve properties in HostInterface collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/HostInterfaces

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	"HostInterfaceCollection"
Members	Array	Items: A reference link to an element of Host interface
Description	String	"A collection of HostInterface resource instances."

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "@odata.id": "/redfish/v1/Managers/1/HostInterfaces",
    "Members@odata.count": 1,
    "@odata.context": "/redfish/v1/$metadata#HostInterfaceCollection.HostInterfaceCollection",
```

```
"Members": [
    {
        "@odata.id": "/redfish/v1/Managers/1/HostInterfaces/1"
"@odata.type": "#HostInterfaceCollection.HostInterfaceCollection",
"@odata.etag": "\"806b8bd9d1a64fa1ac993403401f40e0\"",
"Name": "HostInterfaceCollection",
"Description": "A collection of HostInterface resource instances."
```

GET – Host interface properties

Use the GET method to retrieve properties in HostInterface resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/HostInterfaces/1

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Id	String	Uniquely identifies the resource within the collection of Chassis. Always set to "1".
Description	String	Provides a description of Host Interface resources.
ExternallyAccessible	Boolean	Always set to false
HostEthernetInterfaces	Link	A reference link to the collection of ethernet interfaces that the system uses for network communication with the host interface.
HostInterfaceType	String	"NetworkHostInterface"
InterfaceEnabled	Boolean	Indicates whether this interface is enabled.
Links	Object	Expanded
ComputerSystems	Array	An array of references to the computer systems connected to this host interface.
ComputerSystems[0]	Link	A reference link to a resource of computer system
ManagerEthernetInterface	Link	A reference link to a single ethernet interface that the manager uses for network communication with the host interface.
Name	String	The name of the host interface resource. Always set to "Host Interface".
NetworkProtocol	Link	A reference link to the network services and their settings that the manager controls.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

When the request is successful, a message body similar to the following is returned:

```
{
    "HostInterfaceType": "NetworkHostInterface",
    "NetworkProtocol": {
        "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol"
    "Id": "1",
    "InterfaceEnabled": true,
    "Links": {
        "ComputerSystems": [
                 "@odata.id": "/redfish/v1/Systems/1"
        ]
    "Name": "Host Interface",
    "@odata.context": "/redfish/v1/$metadata#HostInterface.HostInterface",
    "@odata.etag": "\"173c848afdf17b76c0b2defce1f48be7\"",
    "@odata.type": "#HostInterface.v1_2_0.HostInterface",
    "ManagerEthernetInterface": {
        "@odata.id": "/redfish/v1/Managers/1/EthernetInterfaces/ToHost"
    },
    "@odata.id": "/redfish/v1/Managers/1/HostInterfaces/1",
    "ExternallyAccessible": false,
    "HostEthernetInterfaces": {
        "@odata.id": "/redfish/v1/Managers/1/HostInterfaces/1/HostEthernetInterfaces"
    "Description": "This resource shall be used to represent Host Interface resources as part of the
Redfish specification."
```

PATCH - Enable/disable host interface

Use the PATCH method to update properties in Host Interface resource for Redfish service.

Request URL

PATCH https://<BMC_IPADDR>/redfish/v1/Managers/1/HostInterfaces/1

Request body

Properties to be updated are shown as bellow, all of these properties can be changed individually.

Field	Туре	Error Message ID	
InterfaceEn- abled	Boolean	Indicate whether this interface is enabled.	

Response body

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

The following example is PATCH body.

```
{
    "InterfaceEnabled" : false
}
```

After the PATCH operation runs successfully, querying the host interface resource returns below example JSON response:

```
"HostInterfaceType": "NetworkHostInterface",
    "NetworkProtocol": {
        "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol"
    "Id": "1".
    "InterfaceEnabled": false,
    "Links": {
         "ComputerSystems": [
                 "@odata.id": "/redfish/v1/Systems/1"
        ]
    "Name": "Host Interface",
    "@odata.context": "/redfish/v1/$metadata#HostInterface.HostInterface",
    "@odata.etag": "\"3d8fd8e9aa9e2d0aa76f0ac687eecbbd\"",
    "@odata.type": "#HostInterface.v1 2 O.HostInterface",
    "ManagerEthernetInterface": {
         "@odata.id": "/redfish/v1/Managers/1/EthernetInterfaces/ToHost"
    },
    "@odata.id": "/redfish/v1/Managers/1/HostInterfaces/1",
    "ExternallyAccessible": false,
    "HostEthernetInterfaces": {
        "@odata.id": "/redfish/v1/Managers/1/HostInterfaces/1/HostEthernetInterfaces"
    "Description": "This resource shall be used to represent Host Interface resources as part of the
Redfish specification."
}
```

Resource ManagerNetworkProtocol

Use the GET method to retrieve properties in ManagerNetworkProtocol resource for a server.

Number of Resources	1
Resource Path	/redfish/v1/Managers/1/NetworkProtocol
Schema file	ManagerNetworkProtocol_v1.xml

GET – BMC network services

Use the GET method to retrieve properties definition for the network protocol in a BMC.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/NetworkProtocol

Request body

None

Response body

Field	Туре	Description
ld	String	"NetworkProtocol".
Name	String	Fixed string "ManagerNetworkProtocol".
Description	String	"The resource is used to represent the network service settings for the manager for a Redfish implementation."
HostName	String	The DNS Host Name of this manager, without any domain information
		The value is the hostname of this XCC.
FQDN	String	This is the fully qualified domain name for the manager obtained by DNS including the host name and top-level domain name.
		The FQDN of this XCC.
DHCP	Object	Settings for this Manager's DHCP support
ProtocolEnabled	Boolean	Indicate if the protocol is enabled or disabled.
DHCPv6	Object	Settings for this Manager's DHCPv6 support
ProtocolEnabled	Boolean	Indicate if the protocol is enabled or disabled.
SNMP	Object	Settings for this Manager's SNMP support
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled.
		Fixed value "true".
Port	Number	Indicates the protocol port.
NTP	Object	Settings for this Manager's NTP support.
NTPServers	Array	Items: string
		List of NTP servers IP.
ProtocolEnabled	Boolean	Indicate if the protocol is enabled or disabled.
HTTP	Object	Settings for this Manager's HTTP protocol support
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled.
		Fixed value "true".
Port	Number	Indicates the protocol port.
HTTPS	Object	Settings for this Manager's HTTPS protocol support.
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled.
Port	Number	Indicates the protocol port.
Certificates	Link	The value of this property shall be a reference to a collection of certificates.
VirtualMedia	Object	Settings for this Manager's Virtual Media support

Field	Туре	Description
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled.
		Fixed value "true".
Port	Number	Indicates the protocol port.
KVMIP	Object	Settings for this Manager's KVM-IP protocol support.
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled.
		Fixed value "true".
Port	Number	Indicates the protocol port.
SSH	Object	Settings for this Manager's SSH (Secure Shell) protocol support
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled.
Port	Number	Indicates the protocol port.
IPMI	Object	Settings for this Manager's IPMI-over-LAN protocol support.
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled.
Port	Number	Indicates the protocol port. Fixed port "623"
SSDP	Object	Settings for this Manager's SSDP support.
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled. Fixed value "true".
Port	Number	Indicates the protocol port. Fixed port "1900"
NotifyMulticastIntervalSeconds	Number	Indicates how often the Multicast is done from this service for SSDP. Fixed value "60"
NotifyTTL	Number	Indicates the time to live hop count for SSDPs Notify messages. Fixed value "2"
NotifyIPv6Scope	String	Indicates the scope for the IPv6 Notify messages for SSDP. Fixed value "Organization"
Status	Object	Expanded
State	String	"Enabled"
Health		"OK"

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"FQDN": "XCC.example.com",
"SNMP": {
  "ProtocolEnabled": false,
  "Port": 161
"HostName": "XCC-7Z72-1234567890",
```

```
"VirtualMedia": {
         "ProtocolEnabled": true,
        "Port": 3900
    "Description": "The resource is used to represent the network service settings for the manager for
a Redfish implementation.",
    "KVMIP": {
        "ProtocolEnabled": true,
        "Port": 3900
    "DHCPv6": {
        "ProtocolEnabled": true
    "HTTP": {
        "ProtocolEnabled": true,
        "Port": 80
    },
    "Status": {
        "State": "Enabled",
        "Health": "OK"
    "SSH": {
        "ProtocolEnabled": true,
        "Port": 22
    "Name": "Manager Network Protocol",
    "DHCP": {
        "ProtocolEnabled": true
    "HTTPS": {
        "ProtocolEnabled": true,
        "Port": 443,
         "Certificates": {
             "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates"
   },
"Oem": {
    "!en!
        "Lenovo": {
             "CimOverHTTPS": {
                 "ProtocolEnabled": true,
                 "Port": 5989
             },
             "SLP": {
                 "ProtocolEnabled": true,
                 "MulticastAddress": "239.255.255.253",
                 "AddressType": "Multicast",
                 "Port": 427
             },
             "SNMP": {
                 "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/Oem/Lenovo/SNMP"
             },
             "DNS": {
                 "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/Oem/Lenovo/DNS"
             "@odata.type": "#LenovoManagerNetworkProtocol.v1_0_0.LenovoManagerNetworkProtocolProperties",
             "SMTPClient": {
                 "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/Oem/Lenovo/SMTPClient"
             "LDAPClient": {
                 "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/Oem/Lenovo/LDAPClient"
             },
```

```
"OpenPorts": [
                  "22",
                  "68",
                  "80",
                  "115"
                  "122",
                  "427",
                  "443",
                  "546",
                  "623".
                  "1900",
                  "3389",
                  "3900",
                  "5900",
                  "5989"
             ]
         }
     "@odata.type": "#ManagerNetworkProtocol.v1 5 O.ManagerNetworkProtocol",
    "SSDP": {
         "ProtocolEnabled": true,
         "NotifyMulticastIntervalSeconds": 60,
         "NotifyTTL": 2,
         "NotifyIPv6Scope": "Organization",
         "Port": 1900
    },
     "IPMI": {
         "ProtocolEnabled": true,
         "Port": 623
     "@odata.etag": "\"c2c25d55979b2e15bd76d\"",
    "Id": "NetworkProtocol",
    "NTP": {
         "NTPServers": [
         "ProtocolEnabled": false
    }
}
```

PATCH - Update BMC network service configurations

Use the PATCH method to update properties in the network protocol resource in a BMC.

Request URL

PATCH https://<BMC_IPADDR>/redfish/v1/Managers/1/NetworkProtocol

Request body

Properties to be updated are shown as bellow, all of these properties can be changed individually.

I	Field	Туре	Description
	HTTPS	Object	Settings for this Manager's HTTPS protocol support.
	Port	Number	Indicates the protocol port.

Field	Туре	Description
SSH Object		Settings for this Manager's SSH (Secure Shell) protocol support
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled.
Port	Number	Indicates the protocol port.
VirtualMedia	Object	Settings for this Manager's Virtual Media support
Port	Number	Indicates the protocol port.
IPMI	Object	Settings for this Manager's IPMI-over-LAN protocol support.
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled.
SSDP	Object	Settings for this Manager's SSDP support.
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled. Fixed value "true".
NTP Object		Settings for this Manager's NTP support
NTPServers	Array	Items: string
		List of NTP servers IP
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled.
SNMP	Object	Settings for this Manager's SNMP support
ProtocolEnabled	Boolean	Indicates if the protocol is enabled or disabled.
		Fixed value "true".
Port	Number	Indicate the protocol port.
DHCP	Object	Settings for this Manager's DHCP support
ProtocolEnabled	Boolean	Indicate if the protocol is enabled or disabled.
DHCPv6	Object	Settings for this Manager's DHCPv6 support
ProtocolEnabled	Boolean	Indicate if the protocol is enabled or disabled.

Response

The response returns same content as GET operation with updated properties.

Status code

HTTP STATUS Code	Error Message ID
500	InternalError

Example

The following example is PATCH body.

```
"HTTPS" : {
      "Port" : 445
}
```

The following example JSON response is returned:

{

```
"FQDN": "XCC-7Z72-1234567890.lenovo.com",
    "SNMP": {
        "ProtocolEnabled": false,
        "Port": 161
    },
    "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol",
    "HostName": "XCC-7Z72-1234567890",
    "VirtualMedia": {
        "ProtocolEnabled": true,
        "Port": 3900
    },
    "Description": "The resource is used to represent the network service settings for the manager for
a Redfish implementation.",
    "KVMIP": {
        "ProtocolEnabled": true,
        "Port": 3900
    },
    "DHCPv6": {
        "ProtocolEnabled": true
    "ProtocolEnabled": true,
        "Port": 80
    },
    "Status": {
        "State": "Enabled",
        "Health": "OK"
    },
    "SSH": {
        "ProtocolEnabled": true,
        "Port": 22
    "Name": "Manager Network Protocol",
    "DHCP": {
        "ProtocolEnabled": true
    },
    "HTTPS": {
        "ProtocolEnabled": true,
        "Port": 445,
        "Certificates": {
             "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates"
        }
    },
    "0em": {
        "Lenovo": {
             "CimOverHTTPS": {
                 "ProtocolEnabled": true,
                 "Port": 5989
            },
             "SLP": {
                 "ProtocolEnabled": true,
                 "MulticastAddress": "239.255.255.253",
                 "AddressType": "Multicast",
                 "Port": 427
             "SNMP": {
                 "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/Oem/Lenovo/SNMP"
             "DNS": {
                 "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/Oem/Lenovo/DNS"
             },
```

```
"@odata.type": "#LenovoManagerNetworkProtocol.v1_0_0.LenovoManagerNetworkProtocolProperties",
          "SMTPClient": {
              "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/Oem/Lenovo/SMTPClient"
          "LDAPClient": {
              "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/Oem/Lenovo/LDAPClient"
          "OpenPorts": [
              "22",
"68",
"80",
              "115".
              "427",
              "443",
              "546",
              "623",
              "1900",
              "3389",
              "3900",
              "5900",
              "5989",
              "5989"
         ]
     }
},
"@odata.type": "#ManagerNetworkProtocol.v1_5_0.ManagerNetworkProtocol",
"SSDP": {
     "ProtocolEnabled" \colon \ true,
     "NotifyMulticastIntervalSeconds": 60,
     "NotifyTTL": 2,
     "NotifyIPv6Scope": "Organization",
     "Port": 1900
},
"IPMI": {
     "ProtocolEnabled": true,
     "Port": 623
},
"@odata.etag": "\"c36fafc1ef532f05bd7b9\"",
"Id": "NetworkProtocol",
"NTP": {
     "NTPServers": [
         "",
""
         "",
""
     "ProtocolEnabled": false
}
```

}

Chapter 10. Serial Interface Management

Resource SerialInterface

The resource represents the serial interface implementation for Redfish service.

Number of Resources	1
Resource Path	/redfish/v1/ Managers/1/SerialInterfaces/1
Schema file	SerialInterfaceCollection_v1.xml
	SerialInterface_v1.xml

GET – Collection of BMC serial interface

Use the GET method to retrieve properties in the serial interface collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/SerialInterfaces

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	"SerialInterfaceCollection"
Members	Array	Items: A reference link to an element of Serial Interface

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

When the request is successful, a message body similar to the following is returned:

© Copyright Lenovo 2017, 2020

```
"Description": "A collection of SerialInterface resource instances."
}
```

GET – BMC serial interface properties

Use the GET method to retrieve properties in the resource of serial interface for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/SerialInterfaces/1

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
id	String	"1"
Name	String	"Serial Interface"
BitRate	String	Bit rate of the serial interface. Valid values include: 9600, 19200, 38400, 57600, 115200
SignalType	String	"Rs232"
Parity	String	Parity information for the serial interface, valid values include: None, Odd, Even.
StopBits	String	Serial interface stop bits
DataBits	String	8
Description	String	Serial Interface of Redfish
FlowControl	String	"None"
InterfaceEnabled	Boolean	Indicates whether this interfaces is enabled

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

When the request is successful, a message body similar to the following is returned:

```
"SignalType": "Rs232",
"BitRate": "115200",
"@odata.id": "/redfish/v1/Managers/1/SerialInterfaces/1",
"InterfaceEnabled": true,
"Description": "Serial port redirection of the host.",
"Name": "Serial Interface",
"@odata.context": "/redfish/v1/$metadata#SerialInterface.SerialInterface",
"StopBits": "1",
"0em": {
    "Lenovo": {
```

```
"CLIMode": "UserDefined",
        "@odata.type": "#LenovoSerialInterface.v1_0_0.LenovoSerialInterfaceProperties",
        "EnterCLIKeySequence": "^[(",
        "SerialInterfaceState": "Enabled"
    }
"@odata.type": "#SerialInterface.v1_1_3.SerialInterface",
"DataBits": "8",
"Id": "1",
"@odata.etag": "\"bc5c2883051b4e001123be789f9c8034\"",
"Parity": "None",
"FlowControl": "None"
```

PATCH – Update BMC serial interface configurations

Use the PATCH method to update properties in the resource of serial interface for Redfish service.

Request URL

}

PATCH https://<BMC_IPADDR>/redfish/v1/Managers/1/SerialInterfaces/1

Request body

Properties to be updated are shown as bellow, all of these properties can be changed individually.

Field	Туре	Error Message ID
BitRate	String	Valid values: 9600, 19200, 38400, 57600, 115200
StopBits	String	Serial interface stop bits.
		Valid values: 1, 2
Parity	String	Valid values: None, Odd, Even.
InterfaceEnabled	Boolean	Valid values: True/False

Response body

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example is PATCH body.

```
"BitRate": "57600",
"Parity": "Even"
```

After the PATCH operation runs successfully, querying the chassis resource returns below example JSON response:

```
"@odata.context" : "/redfish/v1/$metadata#SerialInterface.SerialInterface",
```

```
"BitRate" : "57600",
    "Parity" : "Even",
    "Id" : "1",
    "SignalType" : "Rs232",
    "0em" : {
        "Lenovo" : {
            "EnterCLIKeySequence" : "^[(",
"SerialInterfaceState" : "Enabled",
            "CLIMode" : "UserDefined"
       }
    },
    "StopBits": "1",
"DataBits": "8",
"@odata.etag": "\"c27142bd8ebce22599a3beed29808fd3\"",
"@odata.id": "/redfish/v1/Managers/1/SerialInterfaces/1",
    "@odata.type" : "#SerialInterface.v1_1_3.SerialInterface",
    "Description" : "Serial port redirection of the host.",
    "Name" : "Serial Interface",
    "FlowControl" : "None",
    "InterfaceEnabled" : true
}
```

Chapter 11. Virtual Media Management

Resource VirtualMedia

This resource shall be used to represent a virtual media service for a Redfish implementation.

Number of Resources	10
Resource Path	/redfish/v1/Managers/1/VirtualMedia/{Id}
Schema file	VirtualMediaCollection_v1.xml
	VirtualMedia_v1.xml

GET – Collection of virtual media

Use the GET method to retrieve properties in virtual media collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/VirtualMedia

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	"VirtualMediaCollection"
Members	Array	Items: A reference link to an element of virtual media

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

When the request is successful, a message body similar to the following is returned:

© Copyright Lenovo 2017, 2020

```
"@odata.id": "/redfish/v1/Managers/1/VirtualMedia/EXT1"
    },
    {
        "@odata.id": "/redfish/v1/Managers/1/VirtualMedia/EXT2"
    },
    {
        "@odata.id": "/redfish/v1/Managers/1/VirtualMedia/EXT3"
    },
    {
        "@odata.id": "/redfish/v1/Managers/1/VirtualMedia/EXT4"
    },
    {
        "@odata.id": "/redfish/v1/Managers/1/VirtualMedia/Remote1"
    },
    {
        "@odata.id": "/redfish/v1/Managers/1/VirtualMedia/Remote2"
    },
    {
        "@odata.id": "/redfish/v1/Managers/1/VirtualMedia/Remote3"
    },
        "@odata.id": "/redfish/v1/Managers/1/VirtualMedia/Remote4"
"@odata.type": "#VirtualMediaCollection.VirtualMediaCollection",
"@odata.etag": "\"c54172a08a2b5db8321ef2d79e8850b2\"",
"Members@odata.count": 10,
"Description": "A collection of VirtualMedia resource instances"
```

GET – Virtual media properties

Use the GET method to retrieve properties in virtual media resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/VirtualMedia/{Id}

Request body

None

}

Response body

Field	Туре	Description
ld	String	This field shows the storage type with index value.
		The Id value will be any of (Remote1,, Remote4), (RDOC1, RDOC2) or (EXT1,, EXT4).
Description	String	"This resource is used to represent a virtual media service for a Redfish implementation"
Name	String	"VirtualMedia"
ImageName	String	Image name
Image	String	A URI providing the location of the selected image.
MediaTypes	Array	The media types supported as virtual media
MediaTypes[]	String	The type values for virtual disk devices.

Field	Туре	Description
ConnectedVia	String	Current virtual media connection methods.
Inserted	Boolean	Indicates the virtual media is inserted in the virtual device or not.
WriteProtected	Boolean	Indicate the media is write protected
UserName	String	User name
Password	String	null

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "ConnectedVia": "NotConnected",
    "Id": "RDOC1",
    "@odata.etag": "\"3da38b2209e828a948b\"",
     "MediaTupes": [
         "CD",
         "DVD",
         "Floppy",
         "USBStick"
    "Image": null,
    "@odata.id": "/redfish/v1/Managers/1/VirtualMedia/RDOC1",
    "Name": "VirtualMedia",
    "Password": null,
    "@odata.type": "#VirtualMedia.v1_3_2.VirtualMedia",
    "WriteProtected": true,
     "Description": "This resource shall be used to represent a virtual media service for a Redfish implementation.",
    "Inserted": false,
    "ImageName": null,
    "UserName": null
}
```

PATCH - Insert/Eject a virtual media

Use the PATCH method to insert or eject a virtual media.

Notes: In current implementation:

- Not support to insert/eject "Remote(N)" media.
- Not support to insert "RDOC{N}" media.
- Only support to insert "EXT{N}" media via protocol HTTP or no credential required NFS.

Request URL

PATCH https://<BMC_IPADDR>/redfish/v1/Managers/1/VirtualMedia/{id}

Request body

Properties to be updated are shown as bellow, all of these properties can be changed individually.

Field	Туре	Error Message ID		
Image	String	A URI providing the location of the selected image. Set to null to eject the virtual media.		
Inserted	Boolean	Indicate if virtual media is inserted in the virtual device. set to false to eject the virtual media.		
WriteProtected Boolean Ind		Indicate the media is write protected.		
UserName String User name		User name		
Password String null		null		

Response

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
400	InsufficientPrivilege, Conflict, PropertyValueTypeError, PropertyMissing, PropertyNotWritable, SourceDoesNotSupportProtocol
500	InternalError

Example

{

The following example is PATCH body.

```
"Image": "http://192.168.1.2/Core-current.iso",
    "Inserted": true,
    "WriteProtected": true,
    "UserName":"test",
    "Password": "PASSWORD"
}
```

After the PATCH operation runs successfully, querying the chassis resource returns below example

```
"ConnectedVia": "URI",
"Id": "EXT1",
"MediaTypes": [
    "CD",
    "DVD"
"Image": "http://192.168.1.2/Core-current.iso",
"@odata.context": "/redfish/v1/$metadata#VirtualMedia.VirtualMedia",
"@odata.id": "/redfish/v1/Managers/1/VirtualMedia/EXT1",
"ImageName": "Core-current.iso",
"@odata.type": "#VirtualMedia.v1_3_0.VirtualMedia",
"WriteProtected": true,
"@odata.etag": "\"5fb9f3ba323469f34cf349a889ff49cf\"",
"Inserted": true,
"Name": "VirtualMedia",
 "Password": null,
"Description": "This resource shall be used to represent a virtual media service for a Redfish implementation."
"Inserted": false,
  "UserName": "test"
```

}

Chapter 12. Server Management

Resource ComputerSystem

This resource is used to represent computer system for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/Systems/1
Schema file	ComputerSystemCollection_v1.xml
	ComputerSystem_v1.xml

GET – Collection for server

Use the GET method to retrieve properties in Systems collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	"ComputerSystemCollection".
Members	Array	Items: A reference link to an element of Systems.
Description	String	"A collection of ComputerSystem resource instances".

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

When the request is successful, a message body similar to the following is returned:

© Copyright Lenovo 2017, 2020 121

```
"Name": "ComputerSystemCollection",
"Description": "A collection of ComputerSystem resource instances."
```

GET – Server properties

Use the GET method to retrieve properties in System resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1

Request body

None

}

Response body

Field	Туре	Description	
ld	String	"1"	
Name	String	"ComputerSystem"	
Description	String	"This resource is used to represent a computing system for a Redfish implementation."	
SystemType	String	the type of computer system represented by this resource	
AssetTag	String	the asset tag of the system	
Manufacturer	String	the manufacturer tag of the system	
Model	String	model of the system	
SubModel	String	Sub model of the system	
SKU	String	The manufacturer SKU for this system.	
SerialNumber	String	Serial number of the system	
PartNumber	String	null	
UUID	String	the universal unique identifier (UUID) for this system	
HostName	String	the full name of this host: XCC-SubModel-SerialNumber	
IndicatorLED	String	the indicator light state for the indicator light associated with this system	
Boot	Object	Describes boot information for the current resource. Changes to this object do not alter the BIOS persistent boot order configuration	
BootSourceOverri- deEnabled	String	Describes the state of the Boot Source Override feature	
BootSourceOverride- Mode	String	The BIOS Boot Mode (either Legacy or UEFI) to be used when BootSourceOverrideTarget boot source is booted from	
UefiTargetBootSour- String ceOverride		The UEFI Device Path of the device to boot from when BootSourceOverrideSupported is UefiTarget.	
BootSourceOverride- Target	String	The current boot source to be used at next boot instead of the normal boot device, if BootSourceOverrideEnabled is true	
BootSourceOverride-	Array	Items: string	
Target @Redfish. AllowableValues		Item count: 8	

Field	Туре	Description
BootSourceOverride- Target @Redfish. AllowableValues[0]	String	"None"
BootSourceOverride- Target @Redfish. AllowableValues[1]	String	"Pxe"
BootSourceOverride- Target @Redfish. AllowableValues[2]	String	"Cd"
BootSourceOverride- Target @Redfish. AllowableValues[3]	String	"Usb"
BootSourceOverride- Target @Redfish. AllowableValues[4]	String	"Hdd"
BootSourceOverride- Target @Redfish. AllowableValues[5]	String	"BiosSetup"
BootSourceOverride- Target @Redfish. AllowableValues[6]	String	"Diags"
BootSourceOverride- Target @Redfish. AllowableValues[7]	String	"UefiTarget"
BootSourceOverrideEnabled @Redfish. AllowableValues	Array	Items: string Item count: 2
BootSourceOverrideEnabled @Redfish. AllowableValues[0]	String	"Once"
BootSourceOverrideEnabled @Redfish. AllowableValues[1]	String	"Disabled"
BiosVersion	String	The version of the system BIOS
TrustedModules	Object	An array of trusted modules in the system.
InterfaceType	String	The interface type of the Trusted Module.
FirmwareVersion	String	The firmware version of this Trusted Module.
InterfaceTypeSelection	String	The interface type selection supported by this Trusted Module.
Status	Object	The status of this trusted module.
State String ProcessorSummary Object		The state of this trusted module.
		This object describes the central processors of the system in general detail.
Count	Number	The number of processors in the system.
LogicalProcessor- Count Integer		The logical Processor Count.

Field	Туре	Description	
Metrics	Link	The link to the metrics associated with all processors in this system.	
Model	String	The processor model for the primary or majority of processors in this system.	
Status	Object	Reflect the processor summary status	
State	String	"Enabled"	
HealthRollup	String	This represents the overall health state from the view of this resource.	
Health	String	This represents the health state of this resource in the absence of its dependent resources.	
MemorySummary	Object	This object describes the memory of the system in general detail.	
Metrics	Link	The link to the metrics associated with all memories in this system.	
TotalSystemMemor- yGiB	Number	The total installed, operating system-accessible memory (RAM), measured in GiB	
Status	Object	Reflect the memory summary status	
State	String	"Enabled".	
HealthRollup	String	This represents the overall health state from the view of this resource.	
Health	String	This represents the health state of this resource in the absence of its dependent resources.	
Processors	Link	This object describes the processor of the system in general detail.	
Status	Object	Expanded	
State	String	"Enabled"	
HealthRollup	String	This represents the overall health state from the view of this resource.	
Health	String	This represents the health state of this resource in the absence of its dependent resources.	
Links	Object	An object for reference links	
ManagedBy	Array	An array of references to Managers responsible for this system	
Chassis	Array	An array of references to the chassis in which this system is contained	
PoweredBy	Array	An array of references to power responsible for this system	
CooledBy	Array	An array of references to cooling device responsible for this system	
EthernetInterfaces	Link	A reference to the collection of Ethernet interfaces associated with this system	
NetworkInterfaces	Link	A reference to the collection of network interfaces associated with this system	
LogServices	Link	A reference to the collection of Log Services associated with this system	
PowerState	String	current power state of the system	
Bios	Link	A reference to the BIOS settings associated with this system.	
Memory	Link	A reference to the collection of memory device associated with this system.	
Storage	Link	A reference to the collection of storage device with this system.	
SecureBoot	Link	A reference to the SecureBoot settings associated with this system.	
HostWatchdogTimer Object		This object describes the Host Watchdog Timer functionality for this system.	

Field	Туре	Description
FunctionEnabled	Boolean	This indicates if the Host Watchdog Timer functionality has been enabled. Additional host-based software is necessary to activate the timer function.
Status	Object	Expanded
State	String	"Disabled"or"StandbyOffline".
TimeoutAction	String	This property indicates the action to perform when the Watchdog Timer reaches its timeout value.
TimeoutAction@	Array	Item type: string
Redfish. AllowableValues		Item count: 1
		Item: ["PowerCycle"]
WarningAction	String	This property indicates the action to perform when the Watchdog Timer is close (typically 3-10 seconds) to reaching its timeout value.
WarningAction@	Array	Item type: string
Redfish. AllowableValues		Item count: 1
		Item: ["None"]
PCIeDevices	Array	An array of references to pci devices in which this system is contained
PCIeFunctions	Array	An array of references to pci functions in which this system is contained
Actions	Object	The available actions for this resource.
#ComputerSystem. Reset	Object	This action shall perform a reset of the ComputerSystem. For systems which implement APCI Power Button functionality, the PushPowerButton value shall perform or emulate an ACPI Power Button push. The ForceOff value shall remove power from the system or perform an ACPI Power Button Override (commonly known as a 4-second hold of the Power Button). The ForceRestart value shall perform a ForceOff action followed by a On action.
@Redfish.ActionInfo	Link	{SR}/Systems/1/ResetActionInfo
ResetType@Red-	Array	Items: string
fish. AllowableValues		Item count: 7
ResetType@Red- fish. AllowableValues[0]	String	"On"
ResetType@Red- fish. AllowableValues[1]	String	"Nmi"
ResetType@Red- fish. AllowableValues[2]	String	"GracefulShutdown"
ResetType@Red- fish. AllowableValues[3]	String	"GracefulRestart"
ResetType@Red- fish. AllowableValues[4]	String	"ForceOn"

Field	Туре	Description
ResetType@Red- fish. AllowableValues[5]	String	"ForceOff"
ResetType@Red- fish. AllowableValues[6]	String	"ForceRestart"

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "SerialNumber": "NARVIR073",
    "Id": "1",
    "IndicatorLED": "Off",
    "PowerState": "On",
    "ProcessorSummary": {
        "Status": {
             "HealthRollup": "OK",
             "Health": "OK",
            "State": "Enabled"
            "@odata.id": "/redfish/v1/Systems/1/ProcessorSummary/ProcessorMetrics"
        },
        "Model": "Genuine Intel(R) CPU 0000%@",
        "LogicalProcessorCount": 48
    "NetworkInterfaces": {
        "@odata.id": "/redfish/v1/Systems/1/NetworkInterfaces"
    "Storage": {
        "@odata.id": "/redfish/v1/Systems/1/Storage"
    "PartNumber": null,
    "SubModel": "7Z59",
    "Bios": {
        "@odata.id": "/redfish/v1/Systems/1/Bios"
    "UUID": "55833bf4-5bbb-11e7-997f-0a94ef402c57",
    "Name": "ComputerSystem",
    "HostWatchdogTimer": {
        "WarningAction": "None",
         "WarningAction@Redfish.AllowableValues": [
             "None"
         "Status": {
             "State": "Disabled"
        "TimeoutAction": "PowerCycle",
        "TimeoutAction@Redfish.AllowableValues": [
```

```
"PowerCycle"
    ],
    "FunctionEnabled": false
},
"0em": {
    "Lenovo": {
        "ScheduledPowerActions": {
             "@odata.id": "/redfish/v1/Systems/1/Oem/Lenovo/ScheduledPowerActions"
        "FrontPanelUSB": {
             "InactivityTimeoutMins": 5,
             "IDButton": "On",
             "PortSwitchingTo": "Server",
             "FPMode": "Shared"
        },
        "Sensors": {
             "@odata.id": "/redfish/v1/Chassis/1/Oem/Lenovo/Sensors"
        "SystemStatus": "BootingOSOrInUndetectedOS",
        "NumberOfReboots": 22,
        "HistorySysPerf": {
             "@odata.id": "/redfish/v1/Systems/1/Oem/Lenovo/HistorySysPerf"
        "@odata.type": "#LenovoComputerSystem.v1_0_0.LenovoSystemProperties",
        "TotalPowerOnHours": 219,
        "Metrics": {
             "@odata.id": "/redfish/v1/Systems/1/Oem/Lenovo/Metrics"
        "BootSettings": {
             "@odata.id": "/redfish/v1/Systems/1/Oem/Lenovo/BootSettings"
    }
"@odata.type": "#ComputerSystem.v1_9_0.ComputerSystem",
"Manufacturer": "Lenovo",
"@odata.etag": "\"42a3dfa9254124eb4ca7a70e77fb8ce7\"",
"Actions": {
    "#ComputerSystem.Reset": {
        "title": "Reset",
        "target": "/redfish/v1/Systems/1/Actions/ComputerSystem.Reset",
        "@Redfish.ActionInfo": "/redfish/v1/Systems/1/ResetActionInfo",
        "ResetTupe@Redfish.AllowableValues": [
            "On",
             "Nmi",
             "GracefulShutdown",
             "GracefulRestart",
             "ForceOn",
             "ForceOff",
             "ForceRestart"
        ]
    },
    "0em": {
        "#LenovoComputerSystem.BootToBIOSSetup": {
            "title": "BootToBIOSSetup",
            "target": "/redfish/v1/Systems/1/Actions/Oem/LenovoComputerSystem.BootToBIOSSetup"
        "#LenovoComputerSystem.CustomizedReset": {
             "target": "/redfish/v1/Systems/1/Actions/Oem/LenovoComputerSystem.CustomizedReset",
             "title": "CustomizedReset",
             "ResetType@Redfish.AllowableValues": [
                 "On"
```

```
]
        }
    }
"EthernetInterfaces": {
    "@odata.id": "/redfish/v1/Systems/1/EthernetInterfaces"
"Boot": {
    "BootSourceOverrideEnabled@Redfish.AllowableValues": [
         "Once",
         "Disabled"
    "BootSourceOverrideTarget@Redfish.AllowableValues": [
         "None",
         "Pxe",
         "Cd",
         "Usb",
         "Hdd",
        "BiosSetup",
        "Diags",
        "UefiTarget"
    "UefiTargetBootSourceOverride": null,
    "BootSourceOverrideTarget": "None",
    "BootSourceOverrideEnabled": "Disabled",
    "BootSourceOverrideMode": "UEFI"
"@odata.id": "/redfish/v1/Systems/1",
"AssetTag": "",
"PCIeFunctions": [
         "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/slot_13/PCIeFunctions/slot_13.00"
    },
    {
         "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/slot_13/PCIeFunctions/slot_13.01"
    },
    {
         "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/ob 1/PCIeFunctions/ob 1.02"
    }
],
"SystemType": "Physical",
"BiosVersion": "M5E101Q",
"HostName": "Narvi-SR860V2-1",
"MemorySummary": {
    "Status": {
         "HealthRollup": "OK",
        "Health": "OK",
        "State": "Enabled"
    },
    "Metrics": {
        "@odata.id": "/redfish/v1/Systems/1/MemorySummary/MemoryMetrics"
    "TotalSystemMemoryGiB": 16
"Processors" \colon \ \{
    "@odata.id": "/redfish/v1/Systems/1/Processors"
"PCIeFunctions@odata.count": 3,
"SecureBoot": {
    "@odata.id": "/redfish/v1/Systems/1/SecureBoot"
},
```

```
"PCIeDevices": [
    {
        "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/slot_13"
    },
    {
        "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/ob_1"
"TrustedModules": [
    {
        "Status": {
             "State": "Absent"
        "InterfaceType": "TPM2 0",
        "FirmwareVersion": "7.2.1.0",
        "InterfaceTypeSelection": "BiosSetting"
    }
"PCIeDevices@odata.count": 2,
"SKU": "7Z59CT01WW",
"Model": "ThinkSystem SR860",
"Description": "This resource is used to represent a computing system for a Redfish implementation.",
    "CooledBy": [
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/0"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/1"
        },
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/2"
        },
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/3"
        },
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/4"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/5"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/6"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/7"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/8"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Thermal#/Fans/9"
        }
    "Chassis": [
             "@odata.id": "/redfish/v1/Chassis/1"
    "PoweredBy": [
```

```
{
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/0"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/1"
        },
        {
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/2"
        {
             "@odata.id": "/redfish/v1/Chassis/1/Power#/PowerSupplies/3"
    "ManagedBy": [
        {
             "@odata.id": "/redfish/v1/Managers/1"
"LogServices": {
    "@odata.id": "/redfish/v1/Systems/1/LogServices"
"Memory": {
    "@odata.id": "/redfish/v1/Systems/1/Memory"
"Status": {
    "HealthRollup": "OK",
    "Health": "OK",
    "State": "Enabled"
}
```

PATCH – Update next-one-time boot configurations and other properties

Use the PATCH method to update properties in System resource for Redfish service.

Request URL

}

PATCH https://<BMC_IPADDR>/redfish/v1/Systems/1

Request body

Properties to be updated are shown as below.

Field		Туре	Description
Boot		Object	Describes boot information for the current resource. Changes to this object do not alter the BIOS persistent boot order configuration.
	BootSourceOverrideEnabled	String	Describes the state of the Boot Source Override feature.
	BootSourceOverrideMode	String	The BIOS Boot Mode (either Legacy or UEFI) to be used when BootSourceOverrideTarget boot source is booted from.
	UefiTargetBootSourceOverride	String	The UEFI Device Path of the device to boot from when BootSourceOverrideSupported is UefiTarget.
	BootSourceOverrideTarget	String	The current boot source to be used at next boot instead of the normal boot device, if BootSourceOverrideEnabled is true
HostWatchdogTimer		Object	This object describes the Host Watchdog Timer functionality for this system.

F	ield	Туре	Description
	FunctionEnabled	Boolean	This indicates if the Host Watchdog Timer functionality has been enabled. Additional host-based software is necessary to activate the timer function.
Α	ssetTag	String	The asset tag of the system.
lı	ndicatorLED	Object	The indicator light state for the indicator light associated with this system

Response

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example is PATCH body.

```
"Boot" : {
      "BootSourceOverrideMode" : "Legacy",
      "BootSourceOverrideTarget" : "Hdd",
      "BootSourceOverrideEnabled" : "Once",
      "UefiTargetBootSourceOverride" : null
   "HostWatchdogTimer" : {
  "FunctionEnabled": true
   },
   "AssetTag": "asset tag",
   "IndicatorLED": "Lit"
}
```

After the PATCH operation runs successfully, querying the system resource returns below example JSON response:

```
{
    "IndicatorLED": "Lit",
     "HostWatchdogTimer": {
         "WarningAction": "None",
         "WarningAction@Redfish.AllowableValues": [
             "None"
         "Status": {
             "State": "Disabled"
         "FunctionEnabled": true,
         "TimeoutAction@Redfish.AllowableValues": [
             "PowerCycle"
         "TimeoutAction": "PowerCycle"
     "AssetTag": "asset tag",
    "Boot": {
```

```
"BootSourceOverrideEnabled@Redfish.AllowableValues": [
             "Once",
             "Disabled"
         "BootSourceOverrideMode": "Legacy",
         "UefiTargetBootSourceOverride": null,
         "BootSourceOverrideEnabled": "Once",
         "BootSourceOverrideTarget@Redfish.AllowableValues": [
             "Pxe",
             "Cd",
             "Usb",
             "Hdd",
             "BiosSetup",
             "Diags",
             "UefiTarget"
         "BootSourceOverrideTarget": "Hdd"
    },
}
```

POST – Server reset operations

Use the POST method for server reset operations.

Request URL

POST https://<BMC_IPADDR>/redfish/v1/Systems/1/Actions/ComputerSystem.Reset

Request body

Field	Error Message ID
ResetType	System reset type, possible values:
	On/ForceOff/GracefulShutdown/GracefulRestart/ ForceRestart/Nmi/ForceOn

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

The following example is POST body.

```
{
    "ResetType" : "On"
```

The following example JSON response is returned:

None

Chapter 13. Log Service and Event Log

Resource LogService

This resource is used to provided Log Service and Event Log for a Redfish implementation.

Number of Resources	5
Resource Path	/redfish/v1/ Systems/1/LogServices/{AuditLog, PlatformLog, ActiveLog, MaintenanceLog, SaLog}
Schema file	LogServiceCollection_v1.xml
	LogService_v1.xml

GET – Collection of BMC log services

Use the GET method to retrieve properties in log services resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	The name of the log services collection. Always set to "LogServiceCollection".
Members	Array	Contains the members of log services collection.
Description	String	A collection of LogService resource instances.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

When the request is successful, a message body similar to the following is returned:

© Copyright Lenovo 2017, 2020 133

```
"@odata.id": "/redfish/v1/Systems/1/LogServices/ActiveLog"
        },
        {
             "@odata.id": "/redfish/v1/Systems/1/LogServices/MaintenanceLog"
        },
        {
             "@odata.id": "/redfish/v1/Systems/1/LogServices/SaLog"
    "@odata.type": "#LogServiceCollection.LogServiceCollection",
    "@odata.id": "/redfish/v1/Systems/1/LogServices",
    "Name": "LogServiceCollection",
    "@odata.etag": "\"3fe90c8760bf2429e61\"",
    "Members@odata.count": 5,
    "Description": "A collection of LogService resource instances."
}
```

GET – Service for BMC active logs

Use the GET method to retrieve properties in active log service resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices/ActiveLog

Request body

None

Response body

Field	Туре	Description
Id	String	Uniquely identifies the resource within the collection of the log services resource. Always set to "ActiveLog".
Name	String	The name of the resource or array element.
DateTimeLocalOffset	String	The UTC offset that the current DateTime property value contains in the `+HH:MM` format.
MaxNumberOfRecords	Number	The maximum number of log entries this service can have. Always set to 1024.
DateTime	String	The current DateTime (with offset) for the log service, used to set or read time.
ServiceEnabled	Boolean	Indicates whether this service is enabled.
LogEntryType	String	"Multiple"
Entries	Object	References to the log entry collection.
Description	String	This resource is used to represent a log service for a Redfish implementation.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"DateTimeLocalOffset": "+00:00",
    "@odata.id": "/redfish/v1/Systems/1/LogServices/ActiveLog",
    "Name": "LogService",
    "Entries": {
        "@odata.id": "/redfish/v1/Systems/1/LogServices/ActiveLog/Entries"
    "MaxNumberOfRecords": 1024,
    "DateTime": "2020-06-03T06:33:48+00:00",
    "@odata.type": "#LogService.v1_1_3.LogService",
    "LogEntryType": "Multiple",
    "Id": "ActiveLog",
    "@odata.etag": "\"3807510e8e6b24e8f42\"",
    "ServiceEnabled": true,
    "Description": "This resource is used to represent a log service for a Redfish implementation."
}
```

GET – Service for BMC event logs

Use the GET method to retrieve properties in Platform log service resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices/PlatformLog

Request body

None

Response body

Field	Туре	Description
Id	String	Uniquely identifies the resource within the collection of the log services resource. Always set to "PlatformLog".
Name	String	The name of the resource or array element.
DateTimeLocalOffset	String	The UTC offset that the current DateTime property value contains in the `+HH:MM` format.
MaxNumberOfRecords	Number	The maximum number of log entries this service can have. Always set to 1024.
DateTime	String,	The current DateTime (with offset) for the log service, used to set or read time.
OverWritePolicy	String	The overwrite policy for this service that takes place when the log is full. Always set to "WrapsWhenFull" – "When full, new entries to the Log will overwrite previous entries".
ServiceEnabled	Boolean	Indicate whether this service is enabled.
LogEntryType	String	"Multiple"
Entries	Object	References to the log entry collection.
Actions	Object	The available actions for this resource.
#LogService.ClearLog	Object	This action is used to clear all platform log entries.
Description	String	This resource is used to represent a log service for a Redfish implementation.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "DateTimeLocalOffset": "+00:00",
    "Id": "PlatformLog",
    "@odata.id": "/redfish/v1/Systems/1/LogServices/PlatformLog",
    "ServiceEnabled": true,
    "LogEntryType": "Multiple",
    "Name": "LogService",
    "Entries": {
         "@odata.id": "/redfish/v1/Systems/1/LogServices/PlatformLog/Entries"
    "MaxNumberOfRecords": 1024,
    "DateTime": "2020-06-03T06:35:36+00:00",
    "@odata.type": "#LogService.v1 1 3.LogService",
    "OverWritePolicy": "WrapsWhenFull",
    "0em": {
         "Lenovo": {
             "HiddenFirstSeqNum": 1,
             "LastSeqNum": 316,
             "@odata.type": "#LenovoLogService.v1_0_0.LenovoLogServiceProperties",
             "FirstSeqNum": 5,
             "VMMoveCategory": [
                 {
                      "VMMoveCategoryName": "RAS event VM movement support",
                      "VMMoveCategoryBit": 0,
                      "VMMoveCategoryType": "VMEFlag"
                 }
             1,
             "HiddenLastSeqNum": 7,
             "SupportedCategories": 3087007930,
             "DesiredCategories": 2147483684
        }
    "@odata.etag": "\"93a07843ee0d2d2672f4c\"",
    "Actions": {
         "0em": {
             "#LenovoLogService.GetLogEntriesBySequenceNumber": {
                 "title": "GetLogEntriesBySequenceNumber",
                 "target": "/redfish/v1/Systems/1/LogServices/PlatformLog/Actions/Oem/LenovoLogService.
GetLogEntriesBySequenceNumber"
             }
         "#LogService.ClearLog": {
             "title": "ClearLog",
             "target": "/redfish/v1/Systems/1/LogServices/PlatformLog/Actions/LogService.ClearLog"
    "Description": "This resource is used to represent a log service for a Redfish implementation."
}
```

GET – Service for BMC audit event logs

Use the GET method to retrieve properties in Platform log service resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices/AuditLog

Request body

None

Response body

Field	Туре	Description
Id	String	Uniquely identifies the resource within the collection of the log services resource. Always set to "AuditLog".
Name	String	The name of the resource or array element.
DateTimeLocalOffset	String	The UTC offset that the current DateTime property value contains in the `+HH:MM` format.
MaxNumberOfRecords	Number	The maximum number of log entries this service can have. Always set to 1024.
DateTime	String,	The current DateTime (with offset) for the log service, used to set or read time.
OverWritePolicy	String	The overwrite policy for this service that takes place when the log is full. Always set to "WrapsWhenFull" – "When full, new entries to the Log will overwrite previous entries".
ServiceEnabled	Boolean	Indicate whether this service is enabled.
LogEntryType	String	"Multiple"
Entries	Object	References to the log entry collection.
Actions	Object	The available actions for this resource.
#LogService.ClearLog	Object	This action is used to clear all standard log entries.
Description	String	This resource is used to represent a log service for a Redfish implementation

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"DateTimeLocalOffset": "+00:00",
"DateTime": "2020-06-03T07:21:22+00:00",
"@odata.id": "/redfish/v1/Systems/1/LogServices/AuditLog",
"Id": "AuditLog",
"Entries": {
    "@odata.id": "/redfish/v1/Systems/1/LogServices/AuditLog/Entries"
"Name": "LogService",
```

```
"ServiceEnabled": true.
    "MaxNumberOfRecords": 1024,
    "0em": {
         "Lenovo": {
             "HiddenFirstSeqNum": 3,
             "@odata.type": "#LenovoLogService.v1_0_0.LenovoLogServiceProperties",
             "FirstSeqNum": 1,
             "HiddenLastSeqNum": 60,
             "LastSeqNum": 311
        }
    },
    "@odata.type": "#LogService.v1_1_3.LogService",
    "OverWritePolicy": "WrapsWhenFull",
    "LogEntryType": "Multiple",
    "@odata.etag": "\"7b494747f82927f1bd1\"",
    "Actions": {
        "0em": {
             "#LenovoLogService.GetLogEntriesBySequenceNumber": {
                 "title": "GetLogEntriesBySequenceNumber",
                 "target": "/redfish/v1/Systems/1/LogServices/AuditLog/Actions/Oem/
LenovoLogService.GetLogEntriesBySequenceNumber"
         "#LogService.ClearLog": {
             "title": "ClearLog",
             "target": "/redfish/v1/Systems/1/LogServices/AuditLog/Actions/LogService.ClearLog"
    "Description": "This resource is used to represent a log service for a Redfish implementation."
}
```

GET – Service for BMC Maintenance event logs

Use the GET method to retrieve properties in maintenance log service resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices/MaintenanceLog

Request body

None

Response body

Field	Туре	Description
Id	String	Uniquely identifies the resource within the collection of the log services resource. Always set to "MaintenanceLog".
Name	String	The name of the resource or array element.
DateTimeLocalOffset	String	The UTC offset that the current DateTime property value contains in the `+HH:MM` format.
MaxNumberOfRecords	Number	The maximum number of log entries this service can have. Always set to 1024.
DateTime	String,	The current DateTime (with offset) for the log service, used to set or read time.
ServiceEnabled	Boolean	Indicate whether this service is enabled.
LogEntryType	String	"Multiple"

Field	Туре	Description
Entries	Object	References to the log entry collection.
Description	String	This resource is used to represent a log service for a Redfish implementation.

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"DateTimeLocalOffset": "+00:00",
"@odata.id": "/redfish/v1/Systems/1/LogServices/MaintenanceLog",
"Name": "LogService",
"Entries": {
    "@odata.id": "/redfish/v1/Systems/1/LogServices/MaintenanceLog/Entries"
"MaxNumberOfRecords": 750,
"DateTime": "2020-06-03T07:21:52+00:00",
"@odata.type": "#LogService.v1_1_3.LogService",
"LogEntryType": "Multiple",
"Id": "MaintenanceLog",
"@odata.etag": "\"3ac30640398727e442b\"",
"ServiceEnabled": true,
"Description": "This resource is used to represent a log service for a Redfish implementation."
```

GET – Service for BMC Service Advisor event logs

Use the GET method to retrieve properties in service advisor log service resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices/SaLog

Request body

None

Field	Туре	Description
Id	String	Uniquely identifies the resource within the collection of the log services resource. Always set to "MaintenanceLog".
Name	String	The name of the resource or array element.
DateTimeLocalOffset	String	The UTC offset that the current DateTime property value contains in the `+HH:MM` format.
MaxNumberOfRecords	Number	The maximum number of log entries this service can have. Always set to 750.
DateTime	String,	The current DateTime (with offset) for the log service, used to set or read time.

Field	Туре	Description
ServiceEnabled	Boolean	Indicate whether this service is enabled.
LogEntryType	String	"Multiple"
Entries	Object	References to the log entry collection.
Description	String	This resource is used to represent a log service for a Redfish implementation

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

POST – Clear event logs

Use the POST method to clear event logs.

Request URL

POST https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices/StandardLog/Actions/LogService.ClearLog

Request body

None

Response body

None

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

The following example is POST body.

None

The following example JSON response is returned:

None

Resource LogEntry

This resource is used to provide logs of LogEntry for a Redfish implementation

Number of Resources	Number of log entries
Resource Path	/redfish/v1/ Systems/1/LogServices/PlatformLog/ Entries
	/redfish/v1/Systems/1/LogServices/AuditLog/ Entries
	/redfish/v1/Systems/1/LogServices/ActiveLog/ Entries
	/redfish/v1/Systems/1/LogServices/MaintenanceLog/ Entries
	/redfish/v1/Systems/1/LogServices/SaLog/ Entries
Schema file	LogEntryCollection_v1.xml
	LogEntry_v1.xml

GET – BMC active log entries

Use the GET method to retrieve properties in active log entries for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices/ActiveLog/Entries

Request body

None

Field	Туре	Description
Id	String	Uniquely identifies the resource within the collection of the log entiries.
Name	String	The name of the resource or array element. Always set to "LogEntry".
Severity	String	The severity of the log entry.
Created	String	The time the log entry was created.
EventId	String	The unique instance identifier for an event.
EntryType	String	The type of log entry. Always set to "Oem".
OemRecordFormat	String	If the entry type is Oem, this will contain more information about the record format from the Oem. Always set to "Lenovo".
OemLogEntryCode	String	The OEM-specific entry code.
Message	String	The actual Log Entry.

Field	Туре	Description
MessageArgs	Array	Arguments for the message.
Description	String	A collection of Active LogEntry resource instances.

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "Members": [
        {
             "Id": "427",
             "MessageArgs": [
                 "processor 1"
             "@odata.id": "/redfish/v1/Systems/1/LogServices/ActiveLog/Entries/427",
             "Severity": "Critical",
             "EntryType": "Oem",
             "Name": "LogEntry",
             "Created": "2020-06-02T02:20:07.639+00:00",
             "OemLogEntryCode": "PLAT0062",
             "0em": {
                 "Lenovo": {
                     "RelatedEventID": "",
                      "IsLocalEvent": true,
                      "EventID": "0x806F05070301FFFF",
                      "TotalSequenceNumber": "427",
                      "EventID@Redfish.Deprecated": "The property is deprecated. Please use EventId instead.",
                      "EventFlag": 0,
                      "EventType": 0,
                      "CommonEventID": "FQXSPPU0009N",
                      "Source": "Processors",
                      "LenovoMessageID": "PLAT0062",
                      "RawDebugLogURL": "",
                      "ReportingChain": "XCC",
                      "TSLVersion": "16",
                      "@odata.type": "#LenovoLogEntry.v1_0_0.ActiveLogEntry"
                 }
             "EventId": "0x806F05070301FFFF",
             "OemRecordFormat": "Lenovo",
             "Message": "processor 1 has a Configuration Mismatch.",
             "@odata.etag": "\"69da974945f5296f92a\"",
             "@odata.type": "#LogEntry.v1_5_0.LogEntry",
             "Description": "This resource is used to represent a log entry for log services for a
Redfish implementation."
"@odata.type": "#LogEntryCollection.LogEntryCollection",
    "@odata.id": "/redfish/v1/Systems/1/LogServices/ActiveLog/Entries",
    "Members@odata.count": 1,
    "@odata.etag": "\"24e5339e3932332c8fb019\"",
    "Name": "LogEntryActiveLogEntryCollection",
```

```
"Description": "A collection of LogEntryActiveLogEntry resource instances."
}
```

GET – BMC Platform event log entries

Use the GET method to retrieve properties in Platform log entries for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices/PlatformLog/Entries

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Id	String	Uniquely identifies the resource within the collection of the log entiries.
Name	String	The name of the resource or array element. Always set to "LogEntry".
Severity	String	The severity of the log entry.
Created	String	The time the log entry was created.
EventId	String	The unique instance identifier for an event.
EntryType	String	The type of log entry. Always set to "Oem".
EventGroupId	String	The identifier to correlate events come from a same cause. Always set to 0.
OemRecordFormat	String	If the entry type is Oem, this will contain more information about the record format from the Oem. Always set to "Lenovo".
OemLogEntryCode	String	The OEM-specific entry code.
Message	String	The actual Log Entry.
MessageArgs	Array	Arguments for the message.
Description	String	A collection of Platform LogEntry resource instances.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"Members": [
        "Message": "ENET[CIM:ep1] IPv6-LinkLocal:HstName=XCC-7Z60-SN, IP@=fe80::0a94:efff:feaf:4e9f ,Pref=64 .",
        "@odata.etag": "\"ejUxX1N0YW5kYXJkTG9nRW50cnkK5\"",
        "MessageArgs": [
            "CIM:ep1",
```

```
"XCC-7Z60-SN",
                 "fe80::0a94:efff:feaf:4e9f",
                 "64"
             "@odata.id": "/redfish/v1/Systems/1/LogServices/PlatformLog/Entries/5",
             "Description": "This resource is used to represent a log entry for log services for a Redfish implementation.",
             "EntryType": "Oem",
             "Name": "LogEntry",
             "EventGroupId": 0,
             "OemLogEntryCode": "Lenovo0055",
             "0em": {
                 "Lenovo": {
                      "ReportingChain": "",
                      "IsLocalEvent": true,
                      "RawDebugLogURL": "",
                      "EventID@Redfish.Deprecated": "The property is deprecated. Please use EventId instead.",
                      "EventFlag": 0,
                      "AuxiliaryData": ""
                      "Source": "System",
                      "FailingFRU": [
                               "FRUSerialNumber": "",
                               "FRUNumber": ""
                          }
                      "TSLVersion": "0",
                      "RelatedEventID": "",
                      "Serviceable": "Not Serviceable",
                      "EventID": "0x4000003700000000",
                      "EventSequenceNumber": 5,
                      "EventType": 0,
                      "@odata.type": "#LenovoLogEntry.v1_0_0.PlatformLogEntry",
                      "LenovoMessageID": "Lenovo0055",
                      "AffectedIndicatorLEDs": [],
                      "TotalSequenceNumber": 8,
                      "CommonEventID": "FQXSPNM4028I",
                      "Hidden": false
                 }
             "@odata.type": "#LogEntry.v1_5_0.LogEntry",
             "OemRecordFormat": "Lenovo",
             "Id": "5",
             "Severity": "OK",
             "EventId": "0x4000003700000000",
             "Created": "2019-12-20T01:51:47.819+00:00"
        },
"@odata.type": "#LogEntryCollection.LogEntryCollection",
    "@odata.id": "/redfish/v1/Systems/1/LogServices/PlatformLog/Entries",
    "Members@odata.count": 234,
    "@odata.etag": "\"7a0c2ef50776342e2a9600f\"",
    "Name": "LogEntryPlatformLogEntryCollection",
    "Description": "A collection of LogEntryPlatformLogEntry resource instances."
}
```

GET – BMC Audit event log entries

Use the GET method to retrieve properties in Audit log entries for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices/AuditLog/Entries

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
ld	String	Uniquely identifies the resource within the collection of the log entiries.
Name	String	The name of the resource or array element. Always set to "LogEntry".
Severity	String	The severity of the log entry.
Created	String	The time the log entry was created.
EventId	String	The unique instance identifier for an event.
EntryType	String	The type of log entry. Always set to "Oem".
EventGroupId	String	The identifier to correlate events come from a same cause. Always set to 0.
OemRecordFormat	String	If the entry type is Oem, this will contain more information about the record format from the Oem. Always set to "Lenovo".
OemLogEntryCode	String	The OEM-specific entry code.
Message	String	The actual Log Entry.
MessageArgs	Array	Arguments for the message.
Description	String	A collection of Platform LogEntry resource instances.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"Members": [
             "Message": "Undefined TPM POLICY found",
             "@odata.etag": "\"ejUxX1NOYW5kYXJkTG9nRW50cnkK1\"",
             "MessageArgs": [],
             "@odata.id": "/redfish/v1/Systems/1/LogServices/AuditLog/Entries/1",
             "Description": "This resource is used to represent a log entry for log services for a
Redfish implementation.",
"EntryType": "Oem",
             "Name": "LogEntry",
             "EventGroupId": 0,
             "OemLogEntryCode": "UEFI",
             "0em": {
```

```
"Lenovo": {
                      "ReportingChain": "UEFI",
                      "IsLocalEvent": true,
                      "RawDebugLogURL": ""
                      "EventID@Redfish.Deprecated": "The property is deprecated. Please use EventId instead.",
                      "EventFlag": 0,
                      "AuxiliaryData": ""
                      "Source": "System",
                      "FailingFRU": [
                          {
                               "FRUSerialNumber": "",
                               "FRUNumber": ""
                          }
                      "TSLVersion": "O",
                      "RelatedEventID": "",
                      "Serviceable": "Not Serviceable",
                      "EventID": "0x0000000000000000",
                      "EventSequenceNumber": 1,
                      "EventType": 0,
                      "@odata.type": "#LenovoLogEntry.v1 0 0.AuditLogEntry",
                      "LenovoMessageID": "UEFI",
                      "AffectedIndicatorLEDs": [],
                      "TotalSequenceNumber": 1,
                      "CommonEventID": "FQXSFPU4051G",
                      "Hidden": false
                 }
             "@odata.type": "#LogEntry.v1_5_0.LogEntry",
             "OemRecordFormat": "Lenovo",
             "Id": "1",
             "Severity": "OK",
             "EventId": "0x0000000000000000",
             "Created": "2019-12-20T01:51:27.000+00:00"
        },
    "@odata.type": "#LogEntryCollection.LogEntryCollection",
    "@odata.id": "/redfish/v1/Systems/1/LogServices/AuditLog/Entries",
    "Members@odata.count": 188,
    "@odata.etag": "\"601ae59a9185682d37fb812\"",
    "Name": "LogEntryAuditLogEntryCollection",
    "Description": "A collection of LogEntryAuditLogEntry resource instances."
}
```

GET – BMC Maintenance event log entries

Use the GET method to retrieve properties in Maintenance log entries for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices/MaintenanceLog/Entries

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Id	String	Uniquely identifies the resource within the collection of the log entiries.
Name	String	The name of the resource or array element. Always set to "LogEntry".
Created	String	The time the log entry was created.
EntryType	String	The type of log entry. Always set to "Oem".
EventGroupId	String	The identifier to correlate events come from a same cause.
OemRecordFormat	String	If the entry type is Oem, this will contain more information about the record format from the Oem. Always set to "Lenovo".
Message	String	The actual Log Entry.
Description	String	A collection of Platform LogEntry resource instances.

HTTP Status Code	Error Message ID	
500	InternalError	

Example

The following example JSON response is returned:

```
"Members": [
        {
             "@odata.id": "/redfish/v1/Systems/1/LogServices/MaintenanceLog/Entries/3",
             "EntryType": "Oem",
             "Name": "LogEntry",
             "EventGroupId": 1,
             "Id": "1",
             "Severity": null,
             "@odata.type": "#LogEntry.v1 5 O.LogEntry",
             "OemRecordFormat": "Lenovo",
             "Message": "CPU 2(SKU NO: 01048340) is added.",
             "@odata.etag": "\"31ba8a086a922965c8b\"",
             "Created": "2019-12-20T01:52:13Z",
             "Description": "This resource is used to represent a log entry for log services for a
Redfish implementation."
        },
],
    "@odata.type": "#LogEntryCollection.LogEntryCollection",
    "@odata.id": "/redfish/v1/Systems/1/LogServices/MaintenanceLog/Entries",
    "Members@odata.count": 83,
    "@odata.etag": "\"1171e4930e543e359ab966e\"",
    "Name": "LogEntryMaintenanceLogEntryCollection",
    "Description": "A collection of LogEntryMaintenanceLogEntry resource instances."
}
```

GET – BMC Service Advisor event log entries

Use the GET method to retrieve properties in Service Advisor log entries for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/LogServices/SaLog/Entries

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
ld	String	Uniquely identifies the resource within the collection of the log entiries.
Name	String	The name of the resource or array element. Always set to "LogEntry".
Created	String	The time the log entry was created.
EntryType	String	The type of log entry. Always set to "Oem".
OemRecordFormat	String	If the entry type is Oem, this will contain more information about the record format from the Oem. Always set to "Lenovo".
Message	String	The actual Log Entry.
Description	String	A collection of Platform LogEntry resource instances.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "Members": [
             "@odata.id": "/redfish/v1/Systems/1/LogServices/SaLog/Entries/1",
            "Id": "1",
             "EntryType": "Oem",
            "Name": "LogEntry",
             "Severity": "OK",
             "Created": "2020-06-05T06:26:00Z",
             "0em": {
                 "Lenovo": {
                     "EventSeverity": "INFO",
                     "CaseNumber": "N/A",
                     "EventStatus": "Pending"
                 }
             "EventId": "FQXSPSS4004I",
             "OemRecordFormat": "Lenovo",
             "Message": "Test Call Home Generated by user USERID.",
             "@odata.etag": "\"38fc1e1486a128a43c3\"",
             "@odata.type": "#LogEntry.v1_5_0.LogEntry",
             "Description": "This resource is used to represent a log entry for log services for a
Redfish implementation."
        }
```

```
"@odata.type": "#LogEntryCollection.LogEntryCollection",
    "@odata.id": "/redfish/v1/Systems/1/LogServices/SaLog/Entries",
    "Members@odata.count": 1,
    "@odata.etag": "\"64b7bffdea2a25aff8f\"",
    "Name": "LogEntryServiceAdvisorLogEntryCollection",
    "Description": "A collection of LogEntryServiceAdvisorLogEntry resource instances."
}
```

Chapter 14. Server Inventory

Resource Memory

This resource is used to represent memory for a Redfish implementation.

Number of Resources	Number of memories supported
Resource Path	/redfish/v1/Systems/1/Memory/{1-N}
Schema file	MemoryCollection_v1.xml
	Memory_v1.xml

GET – Collection of server memories

Use the GET method to retrieve properties in Memory collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/Memory

Request body

None

Response body

Field	Туре	Description
Name	String	"Memory Collection"
Members	Array	Items: A reference link to an element of memory resource
Description	String	A Collection of memory resource instances.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

© Copyright Lenovo 2017, 2020 151

```
},
{
    "@odata.id": "/redfish/v1/Systems/1/Memory/5"
},
{
    "@odata.id": "/redfish/v1/Systems/1/Memory/6"
},
{
    "@odata.id": "/redfish/v1/Systems/1/Memory/7"
},
{
    "@odata.id": "/redfish/v1/Systems/1/Memory/8"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/9"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/10"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/11"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/12"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/13"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/14"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/15"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/16"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/17"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/18"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/19"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/20"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/21"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/22"
    "@odata.id": "/redfish/v1/Systems/1/Memory/23"
},
    "@odata.id": "/redfish/v1/Systems/1/Memory/24"
```

```
],
"Oem": {
    "Lenovo": {
        "@odata.id": "/redfish/v1/Systems/1/Memory/Oem/Lenovo/HistoryMemMetric"
        }
    },
"@odata.type": "#MemoryCollection.MemoryCollection",
"@odata.type": "#MemoryCollection.MemoryCollection",
"@odata.id": "/redfish/v1/Systems/1/Memory",
"Name": "Memory Collection",
"@odata.etag": "\"a2fb3627522630e8b7fe2\"",
"Members@odata.count": 24,
"Description": "A collection of memory resource instances."
}
```

GET – Server memory properties

Use the GET method to retrieve properties in Memory resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/Memory/{1-N}

Request body

None

Field	Туре	Description
ld	String	1~{n}, n is the index of this memory
Name	String	In format "DIMM n", n is the index of memory resource
Description	String	"This resource is used to represent a memory for a Redfish implementation."
Allowed- SpeedsMHz	Array	The value of this property shall be the speed supported by this Memory.
BaseModu- leType	String	The value of this property shall be the base module type of Memory.
BusWidth- Bits	Number	The value of this property shall be the bus width in bits.
Capacity- MiB	Number	The value of this property shall be the Memory capacity in MiB.
DataWidth- Bits	Number	The value of this property shall be the data width in bits.
DeviceID	String	The value of this property shall be the device ID of the Memory.
DeviceLo- cator	String	Location of the Memory in the platform.
Function- Classes	Array	Function Classes by the Memory. For DRAM, the valid value is ["Volatile"].
Manufactur- er	String	The Memory manufacturer.
MemoryDe- viceType	String	The value of this property shall be the Memory Device Type as defined by SMBIOS.

Field	Туре	Description
MemoryLo- cation	Object	Memory connection information to sockets and memory controllers.
Socket	Number	Socket Number in which Memory is connected.
Memory- Controller	Number	Memory controller Number in which Memory is connected.
Channel	Number	Channel Number in which Memory is connected.
Slot	Number	Slot Number in which Memory is connected.
MemoryMe- dia	Array	The value of this property shall be the media types of this Memory. For DRAM, the valid value is ["DRAM"].
Memory- Type	String	The value of this property shall be the type of Memory represented by this resource. For DRAM, the value is "DRAM".
Operating- MemoryMo- des	Array	Memory modes supported by the Memory. For DRAM, the valid value is ["Volatile"].
Operating- SpeedMhz	Number	Operating speed of Memory in MHz.
PartNumber	String	The product part Number of this device.
RankCount	Number	Number of ranks available in the Memory.
Security- Capabilities	Object	Security capabilities of the memory.
SerialNum- ber	String	The product serial Number of this device.
Status	Object	Contains the following elements
Health	String	The current health of this chassis as indicated by the entries in the event log. Valid values include:
		OK. Normal. No warning or critical events in the event log of this chassis.
		Critical. A critical condition exists that requires immediate attention. At least one critical event in the event log of this chassis.
		Warning. A condition exists that requires attention. At least one warning in the event log (but no critical events) of this chassis.
State	String	Valid values:
		"Absent": memory is not present
		"Enabled": memory is enabled
		"Disabled": memory is disabled
		"UnavailableOffline": memory is present but offline
Subsystem- DeviceID	String	Subsystem Device ID.
Subsystem- VendorID	String	SubSystem Vendor ID.
VendorID	String	The value of this property shall be the vendor ID of the Memory.

Field	Туре	Description	
Persisten- tRegionSi- zeLimitMiB	Number	Total size of persistent regions in mebibytes (MiB).	
Regions	Array	Memory regions information within the Memory.	
Regions[N]	Object	expand	
RegionId	String	Unique region ID representing a specific region within the memory.	
Memory- Classifi- cation	String	The classification of memory that the memory region occupies.	
SizeMiB	Integer	Size of this memory region in mebibytes (MiB).	
VolatileRe- gionSizeLi- mitMiB	Number	Total size of volatile regions in mebibytes (MiB).	
ModuleMa- nufacturer- ID	String	The manufacturer ID of this memory module.	
Vendorl- D@Redfish. Deprecated	String	The property is deprecated. Please use ModuleManufacturerID instead.	
ModulePro- ductID	String	The product ID of this memory module.	
Devicel- D@Redfish. Deprecated	String	The property is deprecated. Please use ModuleProductID instead.	
Memory- Subsystem- Controller- Manufactur- erID	String	The manufacturer ID of the memory subsystem controller of this memory module.	
Subsystem- Vendorl- D@Redfish. Deprecated	String	The property is deprecated. Please use MemorySubsystemControllerManufacturerID instead.	
Memory- Subsystem- Controller- ProductID	String	The product ID of the memory subsystem controller of this memory module.	
Subsystem- Devicel- D@Redfish. Deprecated	String	The property is deprecated. Please use MemorySubsystemControllerProductID instead.	
NonVolatile- SizeMiB	Integer	Total size of the non-volatile portion memory in MiB. Only present for non-volatile DIMM.	
VolatileSize- MiB	Integer	Total size of the volitile portion memory in MiB.	
CacheSize- MiB	Integer	Total size of the cache portion memory in MiB. Only present for non-volatile DIMM.	

Field	Туре	Description
LogicalSize- Integer MiB		Total size of the logical memory in MiB. Only present for non-volatile DIMM.
Location	Object	The location of the memory.
PartLoca- tion	Object	The part location within the placement.
Locatio- nOrdinal- Value	Integer	The Number that represents the location of the part. If LocationType is `slot` and this unit is in slot 2, the LocationOrdinalValue is 2.
Location- Type	String	The type of location of the part, such as slot, bay, socket and slot. It is hard code to "Slot".
Service- Label	String	The label of the part location, such as a silk-screened name or a printed label.
Links	Object	Expanded
Chassis Link		A reference to the Chassis which contains this Memory.

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "AllowedSpeedsMHz": [
        2666
    "VolatileRegionSizeLimitMiB": null,
    "MemoryDeviceType": "DDR4",
    "Id": "1",
    "MemorySubsystemControllerProductID": "0x0000",
    "Links": {
        "Chassis": {
            "@odata.id": "/redfish/v1/Chassis/1"
    },
    "MemoryMedia": [
        "DRAM"
   "DeviceID@Redfish.Deprecated": "The property is deprecated. Please use ModuleProductID instead.",
    "MemoryLocation": {
        "Channel": 1,
        "MemoryController": 0,
        "Slot": 1,
        "Socket": 1
    "MemorySubsystemControllerManufacturerID": "0x0000",
    "MemoryType": "DRAM",
    "DeviceLocator": "DIMM 1",
    "DataWidthBits": 64,
    "0em": {
        "Lenovo": {
```

```
"@odata.type": "#LenovoMemory.v1_0_0.LenovoMemory",
             "FruPartNumber": ""
        }
    },
    "@odata.type": "#Memory.v1_8_0.Memory",
    "RankCount": 1,
    "Manufacturer": "Micron Technology",
    "DeviceID": "DIMM_1",
    "VendorID": "Micron Technology",
    "Regions": [],
    "ModuleProductID": "0x0000",
    "@odata.id": "/redfish/v1/Systems/1/Memory/1",
    "Location": {
         "PartLocation": {
             "LocationType": "Slot",
             "ServiceLabel": "DIMM 1",
             "LocationOrdinalValue": 0
        }
    "SerialNumber": "196B4B73",
    "SecurityCapabilities": {},
    "CapacityMiB": 16384,
    "Description": "This resource is used to represent a memory for a Redfish implementation.",
    "OperatingSpeedMhz": 2666,
    "@odata.etag": "\"b6bf584749a1586a76e5e2f68c0882c9\"",
    "SubsystemDeviceID": "0x0000",
    "OperatingMemoryModes": [
         "Volatile"
    "Status": {
         "State": "Enabled",
         "Health": "OK"
    "BaseModuleType": "UDIMM",
    "VendorID@Redfish.Deprecated": "The property is deprecated. Please use ModuleManufacturerID
instead.",
    "ModuleManufacturerID": "0x2c80",
    "SubsystemVendorID@Redfish.Deprecated": "The property is deprecated. Please use
MemorySubsystemControllerManufacturerID instead.",
    "SubsystemVendorID": "0x0000",
    "SubsystemDeviceID@Redfish.Deprecated": "The property is deprecated. Please use
MemorySubsystemControllerProductID instead.",
    "BusWidthBits": 72,
    "Name": "DIMM 1",
    "PersistentRegionSizeLimitMiB": null,
    "VolatileSizeMiB": 16384,
    "FunctionClasses": [
         "Volatile"
    ]
}
```

Resource NetworkInterface

This resource is used to represent network interfaces for a Redfish implementation.

Number of Resources	Number of network interfaces
Resource Path	/redfish/v1/ Systems/1/NetworkInterfaces/{1-N}
Schema file	NetworkInterfaceCollection_v1.xml
	NetworkInterface_v1.xml

GET – Collection of network interfaces

Use the GET method to retrieve properties in server network interfaces collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/NetworkInterfaces

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	"NetworkInterfaceCollection"
Members	Array	Items: A reference link to an element of network interface resource
Description	String	A Collection of NetworkInterface resource instances.

Status code

HTTP Status Code	Error Message ID	
500	InternalError	

Example

```
{
              "@odata.context" : "/redfish/v1/\$metadata\#NetworkInterfaceCollection.NetworkInterfaceCollection", and the substitution of th
              "Members@odata.count" : 3,
              "@odata.id" : "/redfish/v1/Systems/1/NetworkInterfaces",
              "@odata.etag" : "\"f274d6bbbebc305a01d229c86400b764\"",
              "Members" : [
                          {
                                         "@odata.id" : "/redfish/v1/Systems/1/NetworkInterfaces/1"
                          },
                          {
                                         "@odata.id" : "/redfish/v1/Systems/1/NetworkInterfaces/2"
                          },
                          {
                                         "@odata.id" : "/redfish/v1/Systems/1/NetworkInterfaces/3"
              "@odata.type" : "#NetworkInterfaceCollection.NetworkInterfaceCollection",
              "Name" : "NetworkInterfaceCollection",
              "Description" : "A collection of NetworkInterface resource instances."
}
```

GET – Server network interfaces

Use the GET method to retrieve properties in Network interface for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/NetworkInterfaces/{1-N}

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Id	String	Index
Description	String	A NetworkInterface contains references linking NetworkAdapter, NetworkPort, and NetworkDeviceFunction resources and represents the functionality available to the containing system.
Name	String	Network Interface X (X=1-N)
Status	Object	expand
State	String	Enabled
Health	String	ОК
Links	Object	expand
NetworkAdapter	Link	Link to related NetworkAdapter.
NetworkPorts	Link	Link to related NetworkPortCollection.
NetworkDeviceFunctions	Link	Link to related NetworkDeviceFunctionCollection.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"@odata.context" : "/redfish/v1/$metadata#NetworkInterface.NetworkInterface",
"Id" : "1",
"Status" : {
    "Health" : "OK",
    "State" : "Enabled"
},
"NetworkPorts" : {
    "@odata.id" : "/redfish/v1/Chassis/1/NetworkAdapters/ob-1/NetworkPorts"
},
"Links" : {
    "NetworkAdapter" : {
        "Qodata.id" : "/redfish/v1/Chassis/1/NetworkAdapters/ob-1"
     }
},
```

```
"NetworkDeviceFunctions" : {
      "@odata.id" : "/redfish/v1/Chassis/1/NetworkAdapters/ob-1/NetworkDeviceFunctions"
   "@odata.etag" : "\"dc20bec25dc27d97279c8bada95185d6\"",
   "@odata.id" : "/redfish/v1/Systems/1/NetworkInterfaces/1",
   "@odata.type" : "#NetworkInterface.v1_1_1.NetworkInterface",
   "Description" : "A NetworkInterface contains references linking NetworkAdapter, NetworkPort, and
                     NetworkDeviceFunction resources and represents the functionality available to the
                     containing system.",
   "Name" : "Network Interface 1"
}
```

Resource PCIeDevice

This resource is used to represent PCIe device for a Redfish implementation.

Number of Resources	Number of PCIe devices
Resource Path	/redfish/v1/Chassis/1/PCleDevices/{deviceLocation} (deviceLocation=ob_X or slot_Y)
Schema file	PCIeDevice_v1.xml

GET - Server PCIe devices

Use the GET method to retrieve properties in PCleDevice collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/1/PCIeDevices/{deviceLocation} (deviceLocation=ob_X or slot_Y)

Request body

None

Field	Туре	Description
Id	String	The Id property uniquely identifies this PCIe device.
DeviceType	String	The device type for this PCIe device
FirmwareVersion	String	The version of firmware for this PCIe device
SKU	String	This is the SKU for this PCIe device
Links	Object	Expand
Chassis	Array	Link to chassis resource
PCIeFunctions	Array	Link to the related PCIeFunctions
Manufacturer	String	This is the manufacturer of this PCle device
Model	String	This is the model number for the PCIe device
Name	String	The card name in VPD (Vital Product Data) for this PCIe device, if it is an on-board PCIe device, add "(onboard)" in the end.
		If there is no VPD data, this property will be "Adapter".
PartNumber	String	The part number for this PCIe device

F	Field	Туре	Description
5	SerialNumber	String	The serial number for this PCIe device
F	PCleInterface	Object	These properties shall contain the definition for a PCle Interface for a Redfish implementation.
	LanesInUse	Integer	The number of PCIe lanes in use by this device.
	MaxPCleType	String	The highest version of the PCIe specification supported by this device.
	MaxLanes	Integer	The number of PCIe lanes supported by this device.
5	Status	Object	Expand
	State	String	Enabled
	Health	String	This represents the health state of this resource
Ε	Description	String	This resource represents the properties of a PCleDevice attached to a System.

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "SerialNumber": null,
    "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/slot_3",
         "Links/PCIeFunctions@Redfish.Deprecated": "The property is deprecated. Please use PCIeFunctions instead.",
         "Chassis": [
             {
                 "@odata.id": "/redfish/v1/Chassis/1"
             }
         "PCIeFunctions": [
             {
                 "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/slot_3/PCIeFunctions/slot_3.00"
             }
        ]
    "PCIeFunctions": {
         "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/slot_3/PCIeFunctions"
    "PCIeInterface": {
         "LanesInUse": null,
         "MaxLanes": null,
         "MaxPCIeType": "Gen3"
    "PartNumber": null,
    "Description": "This resource represents the properties of a PCIeDevice attached to a System.",
    "FirmwareVersion": null,
    "Status": {
         "State": "Enabled",
         "Health": "OK"
```

```
"Name": "Adapter",
"Id": "slot_3",
"0em": {
    "Lenovo": {
         "@odata.type": "#LenovoDeviceInfo.v1_0_0.LenovoDeviceInfo",
         "Location": {
             "PartLocation": {
                 "LocationType": "Slot",
                  "ServiceLabel": "PCIe 3",
                  "LocationOrdinalValue": 3
             },
             "InfoFormat": "Slot X",
             "Info": "Slot 3",
             "Info@Redfish.Deprecated": "The property is deprecated. Please use PartLocation instead.",
             "InfoFormat@Redfish.Deprecated": "The property is deprecated. Please use PartLocation instead."
        }
    }
"@odata.type": "#PCIeDevice.v1 4 O.PCIeDevice",
"SKU": null,
"Manufacturer": null,
"@odata.etag": "\"e7a9cb060992cf9c73f21a48370932b8\"",
"Model": null,
"DeviceType": "SingleFunction"
```

Resource PCIeFunction

This resource is used to represent PCle function information for a Redfish implementation.

Number of Resources	Number of PCIe functions
Resource Path	/redfish/v1/Systems/1/PCleFunctions/{Location} (Location=ob_X.YY or slot_W.ZZ)
Schema file	PCIeFunction_v1.xml

GET – Functions of server PCIe functions

Use the GET method to retrieve properties in PCIeFunction collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/PCIeFunctions/{Location}

Request body

None

}

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
ld	String	The Id property uniquely identifies this PCIe function.
ClassCode	String	The Class Code of this PCIe function

Field	Туре	Description
Description	String	This resource represents the properties of a PCleFunction attached to a System.
DeviceClass	String	The class for this PCIe Function
Deviceld	String	The Device ID of this PCIe function
FunctionId	String	The the PCIe Function identifier
FunctionType	String	Physical
Links	Object	expand
Drives	Array	Link to related the Drive resources
EthernetInterfaces	Array	Link to related the EthernetInterface resources
StorageControllers	Array	Link to related the StorageController resources
PCleDevice	Link	Link to related the PCleDevice resource
NetworkDeviceFunctions	Link	Link to related NetworkDeviceFunctions resource
Name	String	The card name in VPD (Vital Product Data) + bus number, device number, function number
		If there is no VPD data, using "Adapter" instead of card name.
Status	Object	Expand
State	String	Enabled
Health	String	ОК
HealthRollup	String	Status values: Critical/Warning/OK
RevisionId	String	The Revision ID of this PCIe function
SubsystemId	String	The Subsystem ID of this PCIe function
SubsystemVendorld	String	The Subsystem Vendor ID of this PCIe function
Vendorld	String	The Vendor ID of this PCIe function

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "VendorId": "0x14e4",
    "Id": "ob_3.01",
"Links": {
         "Drives": [],
         "PCIeDevice": {
              "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/ob_3"
         },
"StorageControllers": [],
         "NetworkDeviceFunctions": [],
         "EthernetInterfaces": []
```

```
},
    "FunctionId": 1,
    "SubsystemId": "0x4042",
    "Description": "This resource represents the properties of a PCIeFunction attached to a System.",
    "FunctionType": "Physical",
    "Status": {
        "State": "Enabled",
         "Health": "OK",
        "HealthRollup": "OK"
    "DeviceClass": "NetworkController",
    "Name": "Adapter 03:00:01",
    "SubsystemVendorId": "Ox17aa",
    "@odata.type": "#PCIeFunction.v1_2_3.PCIeFunction",
    "DeviceId": "Ox165f",
    "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/ob 3/PCIeFunctions/ob 3.01",
    "@odata.etag": "\"8c4b6c7797c87b8affd4bef11ee9df50\"",
    "RevisionId": "OxOO",
    "ClassCode": "0x020000"
}
```

Resource PCIeSlot

This resource is used to represent PCIe slot for a Redfish implementation.

Number of Resources	Number of PCIe slots
Resource Path	/redfish/v1/Chassis/1/PCleSlots
Schema file	PCIeDevice_v1.xml

GET - Server PCIe slots

Use the GET method to retrieve properties in PCIeSlots for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Chassis/1/PCIeSlots

Request body

None

F	Field	Туре	Description
le	d	String	"PCIeSlots"
١	lame	String	"PCIe Slots"
	Description	String	This resource shall be used to represent a set of PCIe slot information for a Redfish implementation.
5	Slots	Object	An array of PCI Slot information.
	Links	Object	The links to other Resources that are related to Slots.
	PCleDevice	Link	Link to related PCleDevice.
	Location	Object	The location of the PCle slot.

Fie	ield	Туре	Description
	PartLocation	Object	The part location within the placement.
	ServiceLabel	String	The label of the part location, such as PCIe X (X is the slot number).
	LocationType	String	The type of location of the part, such as slot.
	LocationOrdinalValue	String	The number that represents the location of the part.
			If LocationType is `slot` and this unit is in slot 2, the LocationOrdinalValue is 2.
	InfoFormat	String	The format of the Info property. Always set to "Slot X".
	Info	String	The location of the Resource: Slot X (X is the slot number)
	Info@Redfish.Deprecated	String	The property is deprecated. Please use PartLocation instead.
	InfoFormat@Redfish. Deprecated	String	The property is deprecated. Please use PartLocation instead.
	Status	Object	The status and health of PCleSlots.
	State	String	The known state of PCleSlots, such as, enabled, disabled.
	Health	String	This represents the health state of this resource.

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "Name": "PCIe Slots",
    "@odata.type": "#PCIeSlots.v1_1_1.PCIeSlots",
    "@odata.id": "/redfish/v1/Chassis/1/PCIeSlots",
    "Id": "PCIeSlots",
    "@odata.etag": "\"cc0d36eadd67a45054edfaaadfbe2893\"",
    "Slots": [
             "Location": {
                 "PartLocation": {
                     "LocationType": "Slot",
                     "ServiceLabel": "PCIe 4",
                     "LocationOrdinalValue": 4
                 "InfoFormat": "Slot X",
                 "Info": "Slot 4",
                 "Info@Redfish.Deprecated": "The property is deprecated. Please use PartLocation instead.",
                 "InfoFormat@Redfish.Deprecated": "The property is deprecated. Please use PartLocation instead."
             },
             "Links": {
                 "PCIeDevice": [
                          "@odata.id": "/redfish/v1/Chassis/1/PCIeDevices/slot_4"
             },
```

```
"Status": {
                 "State": "Enabled",
                 "Health": "OK"
        }
    "Description": "This resource shall be used to represent a set of PCIe slot information for a
Redfish implementation."
```

Resource Processor

This resource is used to represent processor for a Redfish implementation.

Number of Resources	Number of processors supported
Resource Path	/redfish/v1/Systems/1/Processors/{1-N}
Schema file	ProcessorCollection_v1.xml
	Processor_v1.xml

GET - Collection of CPUs

Use the GET method to retrieve properties in Processor collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/Processors

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Name	String	"ProcessorCollection"
Members	Array	Items: A reference link to an element of processor resource
Description	String	A Collection of Processor resource instances.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Response example

When the request is successful, a message body similar to the following is returned:

```
"@odata.id": "/redfish/v1/Systems/1/Processors",
"Name": "ProcessorCollection",
"@odata.context": "/redfish/v1/$metadata#ProcessorCollection.ProcessorCollection",
```

```
"Members": [
    {
        "@odata.id": "/redfish/v1/Systems/1/Processors/1"
    },
    {
        "@odata.id": "/redfish/v1/Systems/1/Processors/2"
],
"Lenovo": {
        "HistoryCPUMetric": {
             "@odata.id": "/redfish/v1/Systems/1/Processors/Oem/Lenovo/HistoryCPUMetric"
    }
},
"@odata.type": "#ProcessorCollection.ProcessorCollection",
"@odata.etag": "\"70be1e1cd02f7e3e91cbdcf744254ffa\"",
"Members@odata.count": 2,
"Description": "A collection of Processor resource instances."
```

GET - CPU properties

Use the GET method to retrieve properties in Processor collection for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/Processors/{1-N}

Request body

None

Field	Туре	Description
Description	String	"This resource is used to represent a processor for a Redfish implementation."
TotalEnabledCores	Integer	The total number of enabled cores that this processor contains.
Id	String	1~{N}, N=1- number of processors
InstructionSet	String	"x86-64"
Manufacturer	String	The processor manufacturer.
MaxSpeedMHz	Number	The maximum clock speed of the processor.
Model	String	The product model of the processor.
Name	String	"Processor {N}", N=1- number of processor
ProcessorArchitecture	String	"x86"
ProcessorId	Object	Expanded
EffectiveFamily	String	The effective Family for this processor.
EffectiveModel	String	The effective Model for this processor.
IdentificationRegisters	String	The contents of the Identification Registers (CPUID) for this processor.

Field		Туре	Description
	Microcodelnfo	String	null
	Step	String	The Step value for this processor.
	Vendorld	String	The Vendor Identification for this processor.
Р	rocessorType	String	"CPU"
S	ocket	String	The socket or location of the processor.
S	tatus	Object	Contains the following elements
	Health	String	The current health of this chassis as indicated by the entries in the event log. Valid values include: OK: Normal. No warning or critical events in the event log of this chassis. Critical: A critical condition exists that requires immediate
			 attention. At least one critical event in the event log of this chassis. Warning: A condition exists that requires attention. At least one warning in the event log (but no critical events) of this chassis.
	State	String	"Enabled": processor is present
			"Absent": processor is not present
Т	otalCores	Number	The total number of cores contained in this processor.
T	otalThreads	Number	The total number of execution threads supported by this processor.
L	ocation	Object	The location of the processor.
	PartLocation	Object	The part location within the placement.
	LocationOrdinalValue	Integer	The number that represents the location of the part.
			If LocationType is `slot` and this unit is in slot 2, the LocationOrdinalValue is 2.
	LocationType	String	The type of location of the part, such as slot, bay, socket and slot. Here hard code to "Socket"
	ServiceLabel	String	The label of the part location, such as a silk-screened name or a printed label.
Т	DPWatts	Integer	The nominal Thermal Design Power (TDP) in watts.
Ν	1etrics	Link	The link to the metrics associated with this processor.
Ρ	rocessorMemory	Array	The memory directly attached or integrated witin this Procesor.
	MemoryType	String	The type of memory used by this processor.
	CapacityMiB	Integer	The memory capacity in MiB.
	IntegratedMemory	Boolean	An indication of whether this memory is integrated within the processor.
	SpeedMHz	Integer	The operating speed of the memory in MHz.
L	inks	Object	Expand
	Chassis Link		/redfish/v1/Chassis/1/

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "Id": "1".
    "Metrics": {
        "@odata.id": "/redfish/v1/Systems/1/Processors/1/ProcessorMetrics"
    "Links": {
        "Chassis": {
             "@odata.id": "/redfish/v1/Chassis/1"
        }
    },
    "TotalThreads": 8,
    "InstructionSet": "x86-64",
    "Location": {
        "PartLocation": {
             "LocationType": "Socket",
             "ServiceLabel": "CPU 1",
             "LocationOrdinalValue": 0
        }
    },
    "ProcessorArchitecture": "x86",
    "Description": "This resource is used to represent a processor for a Redfish implementation.",
    "ProcessorMemory": [
        {
             "SpeedMHz": null,
             "MemoryType": "L1Cache",
             "IntegratedMemory": true,
             "CapacityMiB": 0
        },
             "SpeedMHz": null,
             "MemoryType": "L2Cache",
             "IntegratedMemory": true,
             "CapacityMiB": 1
        },
             "SpeedMHz": null,
             "MemoryType": "L3Cache",
             "IntegratedMemory": true,
             "CapacityMiB": 8
        }
    "@odata.etag": "\"711ad8aa7b0d88030dab0027194d29e7\"",
    "@odata.id": "/redfish/v1/Systems/1/Processors/1",
    "TotalCores": 4,
    "Status": {
         "State": "Enabled",
        "Health": "OK"
    "ProcessorType": "CPU",
    "Name": "Processor 1",
    "ProcessorId": {
```

```
"Step": "0x0a",
     "VendorId": "GenuineIntel",
     "EffectiveModel": "Ox9e",
     "EffectiveFamily": "0x06",
     "IdentificationRegisters": "0x000906eabfebfbff",
    "MicrocodeInfo": null
},
"TotalEnabledCores": 4,
"0em": {
     "Lenovo": {
         "ProcessorFamily": 179,
         "CacheInfo": [
             {
                  "InstalledSizeKByte": 256,
                  "MaxCacheSizeKByte": 256,
                  "CacheLevel": "L1"
             },
                  "InstalledSizeKByte": 1024,
                  "MaxCacheSizeKByte": 1024,
                  "CacheLevel": "L2"
             },
                  "InstalledSizeKByte": 8192,
                  "MaxCacheSizeKByte": 8192,
                  "CacheLevel": "L3"
             }
         "@odata.type": "#LenovoProcessor.v1_0_0.LenovoProcessor",
         "NumberOfEnabledCores": 4,
         "ExternalBusClockSpeedMHz": 100,
         "CurrentClockSpeedMHz": 4300
},
"@odata.type": "#Processor.v1 5 1.Processor",
"TDPWatts": 0,
"Manufacturer": "Intel(R) Corporation",
"MaxSpeedMHz": 4700,
"Model": "Intel(R) Xeon(R) E-2174G CPU @ 3.80GHz",
"Socket": "CPU 1"
```

Resource ProcessorMetric

This resource is used to represent processor for a Redfish implementation.

Number of Resources	1 + N. (N: Number of processors supported)
Resource Path	/redfish/v1/Systems/1/ ProcessorSummary/ ProcessorMetrics /redfish/v1/Systems/1/Processors/{1-N}/ ProcessorMetrics
Schema file	ProcessorMetric_v1.xml

GET – Processor metric properties

Use the GET method to retrieve properties in Processor Metric for Redfish service.

}

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/ProcessorSummary/ProcessorMetrics

Request body

None

Response body

Field	Туре	Description
ld	String	"ProcessorMetrics".
Name	String	"Processor Summary Metrics".
Description	String	"This resource is used to represent processor summary metrics for a Redfish implementation."
BandwidthPercent	String	The CPU bandwidth as a percentage.
ConsumedPowerWatt	String	The power, in watts, that the processor has consumed.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"BandwidthPercent": 0,
    "Description": "This resource is used to represent processor summary metrics for a Redfish implementation.",
    "@odata.type": "#ProcessorMetrics.v1_0_1.ProcessorMetrics",
    "@odata.id": "/redfish/v1/Systems/1/ProcessorSummary/ProcessorMetrics",
    "Id": "ProcessorMetrics",
    "@odata.etag": "\"6de4c04fbae63c91eec00838a25f9c9b\"",
    "Name": "Processor Summary Metrics",
    "ConsumedPowerWatt": 20
}
```

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/Processors/{1-N}/ProcessorMetrics

Request body

None

Field	Туре	Description
Id	String	"ProcessorMetrics".
Name	String	"Processor Metrics".
Description	String	"This resource is used to represent a processor metrics for a Redfish implementation.".
TemperatureCelsius	Number	The temperature of the processor.

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "@odata.type": "#ProcessorMetrics.v1_0_1.ProcessorMetrics",
    "TemperatureCelsius": 28,
    "@odata.id": "/redfish/v1/Systems/1/Processors/1/ProcessorMetrics",
    "Id": "ProcessorMetrics",
    "@odata.etag": "\"a119a8346c59c241cb617f1aec5c6549\"",
    "Name": "Processor Metrics",
    "Description": "This resource is used to represent a processor metrics for a Redfish implementation."
}
```

Resource Memory Metrics

This resource is used to represent memory metrics summary for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/Systems/1/MemorySummary/MemoryMetrics
Schema file	MemoryMetrics_v1.xml

GET – memory metrics properties

Use the GET method to retrieve properties in Memory resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/MemorySummary/MemoryMetrics

Request body

None

Response body

Field	Туре	Description
Id	String	"MemoryMetrics"
Name	String	"Memory Summary Metrics"
Description	String	"This resource is used to represent a summary for a Redfish implementation."
BandwidthPercent	String	Memory average percentage

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"BandwidthPercent": 0,
    "@odata.type": "#MemoryMetrics.v1_2_0.MemoryMetrics",
    "Id": "MemoryMetrics",
    "@odata.id": "/redfish/v1/Systems/1/MemorySummary/MemoryMetrics",
    "@odata.etag": "\"23d1af2855a224e2416\"",
    "Name": "Memory Summary Metrics",
    "Description": "The usage and health statistics for system memory summary."
}
```

Chapter 15. Storage Management

Resource Storage

This Resource is used to represent Storage for a Redfish implementation.

Number of Resources	Number of storage controllers
Resource Path	/redfish/v1/ Systems/1/Storage/{ld}
Schema file	StorageCollection_v1.xml
	Storage_v1.xml

GET - Collection of storage controllers

Use the GET method to retrieve the properties storage collection resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/Storage

Request body

None

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Members	Array	Items: A reference link of the elements of Storage.
Name	String	StorageCollection
Description	String	A collection of storage resource instances.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

© Copyright Lenovo 2017, 2020 175

```
},
        {
             "@odata.id": "/redfish/v1/Systems/1/Storage/M.2 "
        },
        {
             "@odata.id": "/redfish/v1/Systems/1/Storage/Direct_Attached_NVMe"
    ],
"@odata.type": "#StorageCollection.StorageCollection",
    "@odata.id": "/redfish/v1/Systems/1/Storage",
    "Name": "StorageCollection",
    "@odata.etag": "\"3fe649519a8f27e9c28\"",
    "Members@odata.count": 5,
    "Description": "A collection of storage resource instances"
}
```

GET – Storage controller properties

Use the GET method to retrieve the properties of storage resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/Storage/{Id}

Response body

Field	Туре	Description
Description	String	"This resource is used to represent a storage for a Redfish implementation.
ld	String	The identifier of this resource.
Links	Object	Expanded.
Enclosures	Array	A URI reference to a resource of chassis.
Enclosures[N]	Object	Link. /redfish/v1/Chassis/1
Name	String	The name of this resource.
Status	Object	Expanded.
State	String	"Enabled"
HealthRollup	String	This represents the overall health state from the view of this resource.
Health	String	Total health info of selected storage, including the controller, drive and volume
StorageControllers	Array	Controller info of the selected storage.
StorageControllers [N]	Object	Expended
AssetTag	String	Asset tag for this storage controller.
PCleInterface	Object	The PCIe of this storage controller.
LanesInUse	Integer	Using lanes of the PCle interface.
MaxLanes	Integer	The maximum lanes of the PCle interface.
MaxPCleType	String	The maximum type of the PCIe interface.
PCIeType	String	PCIe type.
SupportedRAID- Types	Array	The set of RAID types supported by the storage controller.

Fi	Field Type		Description
	FirmwareVersion String		Controller's firmware info
	Identifiers Array		Items: the durable names of the storage controller
			Item count: 1
	Identifiers[N]	Object	Expanded.
	DurableName- Format	String	"UUID"
	DurableName	String	The UUID of this storage controller.
	Manufacturer	String	The manufacturer of this storage controller.
	Model	String	This is the model number for the storage controller
	Memberld	String	This is the identifier for the member within the collection.
	Name	String	The name of the Storage Controller.
	Cachesummary	Object	The cache memory of the storage controller in general detail.
	TotalCacheSize- MiB	Integer	The total configured cache memory, measured in MiB.
	PersistentCache- SizeMiB	Integer	The portion of the cache memory that is persistent, measured in MiB.
	Status	Object	The status for the cache summary of this storage controller.
	State	String	The state for the cache summary of this storage controller.
	Health	String	The health for the cache summary of this storage controller.
	Location	Object	The location of the storage controller.
	PartLocation	Object	The part location within the placement.
	LocationOrdi- nalValue	Integer	The number that represents the location of this storage controller.
	LocationType	String	"Slot"
	ServiceLabel	String	The service lable of this storage controller.
	InfoFormat	String	"Slot X"
	Info	String	The value is "Slot X".
	InfoForma- t@Redfish. Deprecated	String	The property is deprecated. Please use PartLocation instead.
	Info@Redfish. Deprecated	String	The property is deprecated. Please use PartLocation instead.
\prod	SKU	String	The SKU for this storage controller.
\prod	PartNumber	String	The part number for this storage controller.
\prod	SerialNumber	String	The serial number for this storage controller.
Ħ	SpeedGbps	Number	The maximum speed of the storage controller's device interface.
	SupportedCon- trollerProtocols	Array	The supported set of protocols for communicating to this storage controller.

F	ield	Туре	Description
	upportedDevice- rotocols	Array	The protocols that the storage controller can use to communicate with attached devices.
	Status	Object	The status for this storage controller.
	State	String	The state for this storage controller.
Ш	Health	String	The health for this storage controller.
D	rives	Array	Drives connected to selected controller
	Orives[N]	Object	link
٧	olumes	Array	The volumes created by the controller
,	Volumes[N]	Object	link

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "Drives": [
             "@odata.id": "/redfish/v1/Systems/1/Storage/RAID Slot18/Drives/Disk.O"
        },
        {
             "@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.1"
        },
             "@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.2"
        },
             "@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.3"
        },
{
             "@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.4"
        },
{
             "@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.5"
        },
             "@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.6"
        },
             "@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.7"
        },
{
             "@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.8"
        },
        {
             "@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.9"
        },
        {
```

```
"@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.10"
    },
    {
        "@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.11"
    }
"@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18",
"Volumes": {
    "@odata.id": "/redfish/v1/Systems/1/Storage/RAID Slot18/Volumes"
"StorageControllers": [
    {
         "SerialNumber": "SP627P1828",
         "SupportedDeviceProtocols": [
             "SATA",
             "SAS"
        ],
        "@odata.id": "/redfish/v1/Systems/1/Storage/RAID Slot18#/StorageControllers/0",
        "AssetTag": "",
        "MemberId": "O",
        "Location": {
             "PartLocation": {
                 "LocationType": "Slot",
                 "ServiceLabel": "PCI 18",
                 "LocationOrdinalValue": 18
             "InfoFormat": "Slot X",
             "Info": "Slot 18",
             "Info@Redfish.Deprecated": "The property is deprecated. Please use PartLocation instead.",
             "InfoFormat@Redfish.Deprecated": "The property is deprecated. Please use PartLocation instead."
        "FirmwareVersion": "51.10.0-2837",
        "Status": {
             "Health": "OK"
        "SupportedControllerProtocols": [
             "PCIe"
        ],
         "Name": "ThinkSystem RAID 930-16i 4GB Flash PCIe 12Gb Adapter",
        "SKU": "01KN508",
         "Oem": {
             "Lenovo": {
                 "SupportedRaidLevels": "0/1/5/6/10/50/60",
                 "Battery": {
                      "SerialNumber": "7962",
                      "RemainingCapacity": "362]",
                      "DesignVoltageMV": 9500,
                      "CurrentMA": 0,
                      "ProductName": "CVPM05",
                      "OperationalStatus": "Operational",
                      "DesignCapacity": "306J",
                      "VoltageMV": 9829,
                      "TemperatureCelsius": 28,
                      "BatteryType": "TMMC",
                      "Manufacturer": "LSI",
                      "Chemistry": "EDLC",
                      "FirmwareDescription": "07251-00",
                      "FullChargeCapacity": "0]"
                 },
                 "Mode": "RAID/JBOD",
                 "SupportedRaidLevels@Redfish.Deprecated": "The property is deprecated. Please use
```

```
SupportedRAIDTypes instead."
                 }
             "Identifiers": [
                 {
                      "DurableNameFormat": "UUID",
                      "DurableName": "00000000000000500605B2016249C0"
                  }
             ],
             "PartNumber": "SR17A04506",
             "SpeedGbps": 12,
             "Manufacturer": "Lenovo",
             "SupportedRAIDTypes": [
                  "RAIDO",
                  "RAID1",
                  "RAID5",
                  "RAID6",
                  "RAID10",
                  "RAID50",
                  "RAID60"
             "Model": "SAS3516",
             "CacheSummary": {
                  "Status": {
                      "State": "Enabled",
                      "Health": "Warning"
                  "TotalCacheSizeMiB": 4096,
                  "PersistentCacheSizeMiB": 128
             }
        }
    "Name": "RAID Storage",
    \verb"StorageControllers@odata.count": 1,\\
    "Id": "RAID_Slot18",
    "@odata.type": "#Storage.v1_7_0.Storage",
    "Links": {
         "Enclosures": [
             {
                  "@odata.id": "/redfish/v1/Chassis/1"
        ]
    "Drives@odata.count": 12,
    "@odata.etag": "\"f8bf8ed58a4584cf58c6a1a8eff8af13\"",
    "Status": {
         "State": "Enabled",
        "Health": "OK",
        "HealthRollup": "OK"
    },
    "Description": "This resource is used to represent a storage for a Redfish implementation."
}
```

Resource Drive

This Resource is used to represent drive information for a Redfish implementation.

Number of Resources	Number of drives managed by storage controller
Resource Path	/redfish/v1/Systems/1/Storage/Id/Drives/{DriveId}
Schema file	Drive_v1.xml

GET – Drives managed by storage controller

Use the GET method to retrieve the drive resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/Storage/Id/Drives/{DriveId}

Request body

None

Response body

Field	Туре	Description
AssetTag	String	The asset tag for this drive.
Description	String	"This resource is used to represent a drive for a Redfish implementation."
BlockSizeBytes	Number	Size of the smallest addressible unit of the associated drive.
CapableS- peedGbs	Number	Fastest capable bus speed of the associated drive.
CapacityBytes	Number	Size in bytes of this Drive.
EncryptionAbility	String	One of {"None", "SelfEncryptingDrive"}
EncryptionStatus	String	One of {"Unlocked", "Locked", "Unencrypted"}
Negotiated- SpeedGbs	Number	The speed, in gigabit per second (Gbit/s), at which this drive currently communicates to the storage controller.
HotspareType	String	One of {"None" ,"Global"}
ld	String	drive slot id
FailurePredicted	Boolean	Indicate this drive currently predicting a failure in the near future.
Identifiers	Array	The Durable names for the drive.
Identifiers[N]	Object	Expanded.
DurableName- Format	String	"UUID"
DurableName	String	Drive's uuid info
Links	Object	Expanded.
Chassis	Link	A URI reference to a resource of chassis.
Volumes	Array	An array of references to the volumes contained in this drive.
Volumes[N]	Link	Link
PCleFunctions	Array	An array of links to the PCIe functions that the drive produces.
PCIeFunctions [N]	Link	link

Field	Туре	Description
PhysicalLocation	Object	The location of this drive.
PartLocation	Object	The part location within the placement.
LocationOrdi- nalValue	Integer	The number that represents the location of this drive.
LocationType	String	"Bay".
ServiceLabel	String	The service label of this drive.
Info	String	Slot number of the drive
InfoFormat	String	"Slot Number"
Manufacturer	String	Drive's manufacture
MediaType	String	Drive's media type
Model	String	Model of the drive
Name	String	Name of the drive
PredictedMedia- LifeLeftPercent	Number	0-100. disk info remaining life
SKU	String	The SKU for this drive.
StatusIndicator	String	The state of the status indicator, which communicates status information about this drive.
PartNumber	String	Part number of the drive
Protocol	String	The protocol this drive is using to communicate to storage controller.
Revision	String	Drive's firmware/hardware version.
RotationS- peedRPM	Number	Drive's rotation speed.
SerialNumber	String	Serial number of the drive
Status	Object	Expanded.
State	String	"Enabled"
Health	String	Drive's health info

Note: The resource "Drive" can describe multiple types of drives. For some cases, such as NVMe added on M.2 card, partial info may not be available.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
     "SerialNumber": "WOKO2Y42",
    "Id": "Disk.1",
"@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.1",
```

```
"Revision": "L5A7",
    "AssetTag": "",
    "FailurePredicted": false,
    "BlockSizeBytes": 512,
    "HotspareType": "None",
    "CapableSpeedGbs": 12,
    "Identifiers": [
        {
             "DurableName": "",
             "DurableNameFormat": "UUID"
        }
    "StatusIndicator": null,
    "PartNumber": "SH20L60465",
    "EncryptionStatus": "Unencrypted",
    "MediaType": "HDD",
    "Description": "This resource is used to represent a drive for a Redfish implementation.",
Volumes": [],
         "Chassis": {
             "@odata.id": "/redfish/v1/Chassis/1"
         "PCIeFunctions": []
    "RotationSpeedRPM": 10500,
    "NegotiatedSpeedGbs": 12,
    "@odata.type": "#Drive.v1_6_0.Drive",
    "Status": {
         "State": "Enabled",
         "Health": "OK"
    "Protocol": "SAS",
    "Name": "300GB 10K 12Gbps SAS 2.5 HDD",
    "PredictedMediaLifeLeftPercent": null,
    "EncryptionAbility": "None",
    "0em": {
         "Lenovo": {
             "DriveStatus": "Unconfigured good",
             "@odata.type": "#LenovoDrive.v1_0_0.LenovoDrive"
        }
    },
    "CapacityBytes": 300000000000,
    "PhysicalLocation": {
         "PartLocation": {
             "LocationType": "Bay",
             "ServiceLabel": "Drive 1",
             "LocationOrdinalValue": 1
         "InfoFormat": "Slot Number",
         "Info": "Slot 1",
         "Info@Redfish.Deprecated": "The property is deprecated. Please use PartLocation instead.",
         "InfoFormat@Redfish.Deprecated": "The property is deprecated. Please use PartLocation instead."
    },
    "Manufacturer": "LENOVO",
    "@odata.etag": "\"9ed0621341dee6bbe98b640ddee6ad61\"",
    "Model": "ST300MM0048",
    "SKU": "00FC612"
}
```

Resource Volume

This resource is used to represent volume information for a Redfish implementation.

Number of Resources	Number of volumes managed by storage controller
Resource Path	/redfish/v1/Systems/1/Storage/Id/Volumes/{VolumeId}
Schema file	Volume_v1.xml

GET – Volumes managed by storage controller

Use the GET method to retrieve the volume resource for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/Storage/Id/Volumes/{VolumeId}

Response body

Field	Туре	Description
Description	String	"This resource is used to represent voulme in Redfish implementation"
BlockSizeBytes	Number	Size of the smallest addressible unit of the associated volume.
CapacityBytes	Number	Size in bytes of this volume.
Id	String	Volume Id.
Links	Object	Expanded.
Drives	Array	An array of references to the drives that are used to creat the volume.
Drives[n]	Link	Link
RAIDType	String	The RAID type of this volume.
Name	String	Volume info name.
Status Object		Expanded.
State	String	The state of this volume.
Health	String	The health of this volume.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "Id": "1",
    "Status": {
         "State": "Enabled",
         "Health": "OK"
```

```
},
     "Links": {
          "Drives": [
              {
                    "@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Drives/Disk.2"
               }
         ]
     },
     "Name": "Vmware6.5U2",
     "0em": {
         "Lenovo": {
               "DriveCachePolicy": "",
               "AccessPolicy": "",
"WritePolicy": "",
               "ReadPolicy": "",
               "Bootable": true,
               "IOPolicy": "",
               "RaidLevel": "RAID O"
         }
     "RAIDType": "RAIDO",
     "@odata.type": "#Volume.v1_0_3.Volume",
     "BlockSizeBytes": 512,
     "CapacityBytes": 238370684928,
     "@odata.etag": "\"4d95fa55d052d9655821a0fa68bb4b56\"",
"@odata.id": "/redfish/v1/Systems/1/Storage/RAID_Slot18/Volumes/1",
     "Description": "This resource is used to represent a volume for a Redfish implementation."
}
```

Chapter 16. BIOS Setting and Boot Management

Resource Bios

This resource is used to represent the BIOS setting for a Redfish implementation.

Number of Resources	2
Resource Path	/redfish/v1/Systems/1/Bios
	/redfish/v1/Systems/1/Bios/Pending
Schema file	Bios_v1.xml

GET - Resource for BIOS

Use the GET method to retrieve properties in BIOS resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/Bios

Request body

None

Response body

Fi	iel	d	Туре	Description
ld	ld		String	"Bios".
N	ar	ne	String	"Bios".
D	es	cription	String	"System Bios".
A [·]	ttr	ibuteRegistry	String	"BiosAttributeRegistry.1.0.0".
A ⁻	ttr	ibutes	Object	This is the manufacturer/provider specific list of BIOS attributes.
A	ct	ions	Object	Expanded.
	#1	Bios.ChangePassword	Object	Expanded
		@Redfish.ActionInfo	Link	/redfish/v1/Systems/1/Bios/ChangePasswordActionInfo
		PasswordName@Redfish.	Array	Items: string
		AllowableValues		Item count: 2
		PasswordName@Redfish. AllowableValues[0]	String	"UefiAdminPassword".
		PasswordName@Redfish. AllowableValues[1]	String	"UefiPowerOnPassword".
	#Bios.ResetBios		Object	Expanded.
@	@Redfish.Settings Object		Object	Expanded.
	Messages		Array	Items:object.

© Copyright Lenovo 2017, 2020 187

F	Field		Туре	Description
		Messages[N]	Object	Expanded.
		Messageld	String	"RebootRequired".
		RelatedProperties	Array	Items:string.
		RelatedProperties[N]	String	The setting name of BIOS attributes. The format will be "#/Attributes/" + the name of attribute.
		Severity	String	"Warning".
		Message	String	"Changes completed successfully, but these changes will not take effect until next reboot."
		Resolution	String	"Reboot the computer system for the changes to take effect."
	SettingsObject		Link	/redfish/v1/Systems/1/Bios/Pending
	Time		String	Indicate the time when the Attributes last applied.
	SupportedApplyTimes		Array	Items: string
				Item count: 1
		SupportedApplyTimes[0]	String	"OnReset".
L	ink	S	Object	Expanded
	ActiveSoftwareImage		Link	/redfish/v1/UpdateService/FirmwareInventory/UEFI
	SoftwareImages		Array	Items:string
				Item count: 1
	SoftwareImages[1]		Link	/redfish/v1/UpdateService/FirmwareInventory/UEFI

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
     "@odata.type": "#Bios.v1_0_6.Bios",
    "Actions": {
         "#Bios.ResetBios": {
              "target": "/redfish/v1/Systems/1/Bios/Actions/Bios.ResetBios",
"title": "ResetBios"
         },
"#Bios.ChangePassword": {
\text{Vama@Padfis}}
              "PasswordName@Redfish.AllowableValues": [
                   "UefiAdminPassword",
                   "UefiPowerOnPassword"
              "@Redfish.ActionInfo": "/redfish/v1/Systems/1/Bios/ChangePasswordActionInfo",
              "target": "/redfish/v1/Systems/1/Bios/Actions/Bios.ChangePassword",
              "title": "ChangePassword"
         }
    },
"Id": "Bios",
```

```
"AttributeRegistry": "BiosAttributeRegistry.1.0.0",
    "Attributes": {
    },
    "Name": "Bios",
    "@odata.id": "/redfish/v1/Systems/1/Bios",
    "@odata.etag": "\"610e10e486e3486d2a50c5b9e6750559\"",
    "Description": "System Bios",
    "@Redfish.Settings": {
         "@odata.type": "#Settings.v1_2_1.Settings",
         "SettingsObject": {
             "@odata.id": "/redfish/v1/Systems/1/Bios/Pending"
         "Messages": [],
         "SupportedApplyTimes": [
             "OnReset"
         "Time": "2019-11-28T10:07:08+00:00"
    }
}
```

POST - Change BIOS password settings

Use the POST method to change BIOS password settings

Request URL

POST https://<BMC_IPADDR>/redfish/v1/Systems/1/Bios/Actions/Bios.ChangePassword

Request body

Field	Туре	Error Message ID
PasswordName	String	"UefiAdminPassword" or "UefiPowerOnPassword"
NewPassword	String	Configure parameter NewPassword, empty value will clear current password. If it's not empty, the password length must be at least 8 and at most 20. The password rule shall follow the lenovo uefi password rule, no three continuous and same characters appear in password.

Response body

None

Status code

HTTP Status Code	Error Message ID
200	RebootRequired
400	ActionParamFormatError
403	InsufficientPrivilege
500	InternalError

Response example

```
The following example is POST body.
```

```
{
"PasswordName" : "UefiAdminPassword"
```

POST - Reset BIOS operation

Use the POST method to reset BIOS password settings

Request URL

POST https://<BMC_IPADDR>/redfish/v1/Systems/1/Bios/Actions/Bios.ResetBios

Request body

None

Response body

None

Status code

HTTP Status Code	Error Message ID
200	RebootRequired
403	Forbidden
500	InternalError
503	ServiceUnavailable

Response example

POST body is empty.

The following response is returned:

```
, ]
```

GET – The pending BIOS settings

Use the GET method to retrieve properties in Bios resource (pending) for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/Bios/Pending

Request body

None

Response

Field	Туре	Description
Id	String	"Pending"
Name	String	"Pending"
Description	String	"Bios Pending Setting"
AttributeRegistry	String	"BiosAttributeRegistry.1.0.0"
Attributes	Object	Expanded, the pending data of BIOS attributes

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "Id": "Pending",
    "Name": "Pending",
    "@odata.context": "/redfish/v1/$metadata#Bios.Bios",
    "@odata.type": "#Bios.v1_0_6.Bios",
    "AttributeRegistry": "BiosAttributeRegistry.1.0.0",
    "Attributes": {
        "DevicesandIOPorts_Device_Slot6" : "Enable",
        "Memory_MemorySpeed" : "MaxPerformance",
        "Processors_CPUPstateControl" : "Autonomous",
        "Processors_CStates" : "Disable",
        ...
        ...
        },
        "@odata.etag": "\"55e794278a844299f0ee2f8eb5c57a9e\"",
        "@odata.id": "/redfish/v1/Systems/1/Bios/Pending",
        "Description": "Bios Pending Setting"
}
```

PATCH – Update pending BIOS settings

Use the PATCH method to update properties in BIOS resource for Redfish service.

Request URL

PATCH https://<BMC_IPADDR>/redfish/v1/Systems/1/Bios/Pending

Request body

Properties to be updated are shown as bellow, all of these properties can be changed individually.

Field	Туре	Description
Attributes	Object	Expanded, the pending data of BIOS attributes

Response

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
200	RebootRequired
403	InsufficientPrivilege
500	InternalError
503	ServiceUnavailable

Example

The following example is PATCH body.

```
{
    "Attributes":{
         "DevicesandIOPorts_Device_Slot6": "Disable"
    }
}
```

After the PATCH operation runs successfully, querying the system resource returns below example JSON response:

```
"@odata.context" : "/redfish/v1/$metadata#Bios.Bios",
"Id" : "Pending",
"AttributeRegistry": "BiosAttributeRegistry.1.0.0",
"@odata.id" : "/redfish/v1/Systems/1/Bios/Pending",
"@odata.etag" : "\"150413e15fe8f09a9a53b1f0edf68cfe\"",
"Attributes" : {
   "DevicesandIOPorts Device Slot6" : "Disable",
   "Memory_MemorySpeed" : "MaxPerformance",
   "Processors_CPUPstateControl" : "Autonomous",
```

Resource AttributeRegistry

This resource is used to represent the attribute registry for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/schemas/registries/ BiosAttributeRegistry.1.0.0.json
Schema file	AttributeRegistry_v1.xml

GET – BIOS attribute registries

Use the GET method to retrieve properties in AttributeRegistry for Redfish service.

Request URL

 ${\tt GET\ https://<} BMC_IPADDR > / {\tt redfish/v1/schemas/registries/BiosAttributeRegistry. 1.0.0. json}$

Request body

None

Response body

Field		Туре	Description
ld		String	"BiosAttributeRegistry.1.0.0"
Langua	age	String	"en"
Name		String	"Bios Attribute Registry Version 1"
Owning	gEntity	String	"Lenovo"
Registr	ryEntries	Object	List of all attributes and their metadata for this component
Attribu	utes	Array	The array containing the attributes and their possible values
Attrib	outes[N]	Object	An attribute and its possible values
Attrik Nam	bute- ne	String	The unique name of the attribute
Curr	entValue	String	null
Defa	aultValue	String	The default current value of the attribute
Disp	olayName	String	Display name of this attribute
Disp	layOrder	Number	The numeric value describing the ascending order that the attribute is displayed relative to other attributes
Gray	/Out	Boolean	The gray-out state of this attribute
Help	Text	String	The help text for the attribute
Hidd	den	Boolean	The hidden state of this attribute
Lowe	erBound	Number	The lower limit of the value of an attribute of type 'Integer'.
Max	Length	Number	The maximum character length of the value of an attribute of type 'string'
Men	uPath	String	A path that describes the menu hierarchy of this attribute
MinL	_ength	Number	The minimum character length of the value of an attribute of type 'string'
Read	dOnly	Boolean	The read-only state of this attribute
Rese quire	etRe- ed	Boolean	The value shall be true for all BIOS registry attributes.

Scalarincrement Number The amount to increment or decrement the value of an attribute of type 'Integer' time a user requests a value change	
UpperBound Number The upper limit of the value of an attribute of type 'Integer'	each
Value	
Value[N]	
ValueDis- playName ValueName String The value name of the attribute ValueExpression A regular expression that is used to validate the value of the attribute. This is only applicable to attributes of type 'string' or 'Integer' WarningText String The warning text for changing the attribute WriteOnly Boolean Defines whether this attribute is write-only. Such attributes revert back to their in value after settings are applied Dependencies Array The array containing a list of dependencies of attributes on this component Dependency Object A dependency expression for one or more Attributes in this Attribute Registry MapFrom Array Array of the map-from conditions for mapping dependency MapFrom Object The attribute that is used to evaluate this dependency expression MapFrom-Condition The attribute that is used to evaluate this dependency expression MapFrom-Condition String The condition that is used to evaluate this dependency expression MapFrom-Property The value to use to evaluate this dependency expression.	
PlayName The value name of the attribute	
ValueExpression String A regular expression that is used to validate the value of the attribute. This is only applicable to attributes of type 'string' or 'Integer' WarningText String The warning text for changing the attribute WriteOnly Boolean Defines whether this attribute is write-only. Such attributes revert back to their invalue after settings are applied Dependencies Array The array containing a list of dependencies of attributes on this component Dependencies Object A dependency of attributes on this component Dependency Object The dependency expression for one or more Attributes in this Attribute Registry MapFrom Array Array of the map-from conditions for mapping dependency MapFrom Object A map-from condition for mapping dependency MapFrom String The attribute that is used to evaluate this dependency expression MapFrom-Condition String The condition that is used to evaluate this dependency expression MapFrom-Property String The value to use to evaluate this dependency expression.	је'
Sion applicable to attributes of type 'string' or 'Integer'	
WriteOnly Boolean Defines whether this attribute is write-only. Such attributes revert back to their in value after settings are applied Dependencies Array The array containing a list of dependencies of attributes on this component Dependencies Object A dependency of attributes on this component Dependency Object The dependency expression for one or more Attributes in this Attribute Registry MapFrom Array Array of the map-from conditions for mapping dependency MapFrom Object A map-from condition for mapping dependency MapFrom String The attribute that is used to evaluate this dependency expression MapFrom-Condition String The condition that is used to evaluate this dependency expression MapFrom-Property String "CurrentValue" The value to use to evaluate this dependency expression.	,
Value after settings are applied	
Dependencies [N] A dependency of attributes on this component [N] Dependency Object The dependency expression for one or more Attributes in this Attribute Registry MapFrom Array Array of the map-from conditions for mapping dependency MapFrom Object A map-from condition for mapping dependency MapFrom String The attribute that is used to evaluate this dependency expression MapFrom-Condition String The condition that is used to evaluate this dependency expression MapFrom-Property String The value to use to evaluate this dependency expression.	tial
NapFrom String MapFrom-Condition MapFrom-Condition String MapFrom-Condition MapFrom-Conditio	
MapFrom Array Array of the map-from conditions for mapping dependency MapFrom [N] Object A map-from condition for mapping dependency MapFrom [N] String The attribute that is used to evaluate this dependency expression MapFrom Condition String The condition that is used to evaluate this dependency expression MapFrom Property String "CurrentValue" MapFrom String The value to use to evaluate this dependency expression.	
MapFrom Object A map-from condition for mapping dependency MapFro- mAttribute String The attribute that is used to evaluate this dependency expression MapFrom- Condition String The condition that is used to evaluate this dependency expression MapFrom- Condition String "CurrentValue" MapFrom- Property String The value to use to evaluate this dependency expression.	
[N] MapFromAttribute String The attribute that is used to evaluate this dependency expression MapFromCondition String The condition that is used to evaluate this dependency expression MapFromProperty String "CurrentValue" MapFromString The value to use to evaluate this dependency expression.	
mAttribute MapFrom-Condition MapFrom-Property MapFrom-Property MapFrom-Property MapFrom-String The condition that is used to evaluate this dependency expression "CurrentValue" The value to use to evaluate this dependency expression.	
Condition MapFrom- Property MapFrom- String "CurrentValue" "MapFrom- String The value to use to evaluate this dependency expression.	
Property MapFrom- String The value to use to evaluate this dependency expression.	
MapTerms String The logical term used to combine two or more MapFrom conditions in this dependency expression	
MapToAttri- String The Name of the attribute that is affected by this dependency expression bute	
MapToProp- String The meta-data property of the attribute specified in MapFromAttribute that is use evaluate this dependency expression	d to
MapToValue Boolean TRUE	
Dependency- String The AttributeName of the attribute whose change triggers the evaluation of this dependency expression	
Type String "Map"	
Menus Array The array containing the attributes menus and their hierarchy.	
Menus[N] Object A menu and its hierarchy	

	Field	Туре	Description
П	DisplayName	String	The user-readable display string of this menu in the defined 'Language'
	DisplayOrder	Number	The numeric value describing the ascending order in which this menu is displayed relative to other menus
П	GrayOut	Boolean	FALSE
П	MenuName	String	The unique name string of this menu
П	MenuPath	String	A path that describes this menu hierarchy relative to other menus
П	ReadOnly	Boolean	FALSE
	RegistryVersion	String	"1.0.0"
	SupportedSys- tems	Array	Array of systems supported by this attribute registry
	SupportedSystems[N]	Object	A system supported by this attribute registry
П	ProductName	String	Use the product name of the system
I	SystemId	String	The system ID of the system
	FirmwareVer- sion	String	Firmware version

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
"@odata.type": "#AttributeRegistry.v1_3_0.AttributeRegistry",
"RegistryVersion": "1.0.0",
"Id": "BiosAttributeRegistry.1.0.0",
"SupportedSystems": [
        "ProductName": "Lenovo ThinkSystem SR650",
        "SystemId": "7X0025Z000",
        "FirmwareVersion": "CDI340M"
    }
"Language": "en",
"Name": "Bios Attribute Registry Version 1",
"@odata.id": "/redfish/v1/schemas/registries/BiosAttributeRegistry.1.0.0.json",
"OwningEntity": "Lenovo",
"@odata.context": "/redfish/v1/$metadata#AttributeRegistry.AttributeRegistry",
"RegistryEntries": {
    "Dependencies": [
             "Type": "Map",
             "Dependency": {
                 "MapToValue": true,
                 "MapFrom": [
                          "MapFromAttribute": "LegacyBIOS_LegacyBIOS",
```

```
"MapFromProperty": "CurrentValue",
                      "MapFromValue": "Enable",
                      "MapFromCondition": "EQU"
                 }
             "MapToProperty": "GrayOut",
             "MapToAttribute": "BootModes_SystemBootMode"
         "DependencyFor": "BootModes_SystemBootMode"
    },
         "Type": "Map",
         "Dependency": {
             "MapToValue": true,
             "MapFrom": [
                 {
                      "MapFromAttribute": "SystemRecovery_POSTWatchdogTimer",
                      "MapFromProperty": "CurrentValue",
                      "MapFromValue": "Disable",
                      "MapFromCondition": "EQU"
                 }
             "MapToProperty": "GrayOut",
             "MapToAttribute": "SystemRecovery_POSTWatchdogTimerValue"
         "DependencyFor": "SystemRecovery_POSTWatchdogTimerValue"
    }
"Menus": [
    {
         "GrayOut": false,
         "ReadOnly": false,
         "MenuPath": "./",
         "MenuName": "BiosMainMenu",
         "DisplayOrder": 1,
         "DisplayName": "BIOS Configuration"
    },
    {
         "GrayOut": false,
         "ReadOnly": false,
         "MenuPath": "./UEFILanguage/UEFILanguage_UEFILanguagepage",
         "MenuName": "UEFILanguage_UEFILanguagepage",
         "DisplayOrder": 3,
         "DisplayName": "UEFILanguage"
    }
],
"Attributes": [
    {
         "GrayOut": false,
         "Type": "Enumeration",
         "HelpText": "Enable/Disable POST Watchdog Timer.",
         "DefaultValue": "Disable",
         "WarningText": "POST Watchdog Timer changes require a system reboot to take effect.",
         "DisplayName": "POST Watchdog Timer",
         "CurrentValue": null,
         "ReadOnly": false,
         "AttributeName": "SystemRecovery POSTWatchdogTimer",
         "Value": [
             {
```

```
"ValueDisplayName": "Disable",
                          "ValueName": "Disable"
                     },
                          "ValueDisplayName": "Enable",
                          "ValueName": "Enable"
                 "MenuPath": "./SystemRecovery/SystemRecovery_SystemRecovery",
                 "Hidden": false,
                 "DisplayOrder": 1,
                 "ResetRequired": true,
                 "WriteOnly": false
             },
             {
                 "GrayOut": false,
                 "Type": "Enumeration",
                 "HelpText": "Display the current secure boot mode",
                 "DefaultValue": null,
                 "WarningText": "Secure Boot Mode changes require a system reboot to take effect.",
                 "DisplayName": "Secure Boot Mode",
                 "CurrentValue": null,
                 "ReadOnly": true,
                 "AttributeName": "SecureBootConfiguration_SecureBootMode",
                 "Value": [
                          "ValueDisplayName": "UserMode",
                          "ValueName": "UserMode"
                     },
                          "ValueDisplayName": "SetupMode",
                          "ValueName": "SetupMode"
                     },
                          "ValueDisplayName": "AuditMode",
                          "ValueName": "AuditMode"
                     },
                          "ValueDisplayName": "DeployedMode",
                          "ValueName": "DeployedMode"
                     }
                 "MenuPath": "./SecureBootConfiguration/SecureBootConfiguration_SecureBootConfiguration",
                 "Hidden": false,
                 "DisplayOrder": 118,
                 "ResetRequired": true,
                 "WriteOnly": false
             }
        ]
    }
}
```

Resource SecureBoot

This resource is used to represent secure boot information for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/Systems/1/SecureBoot
Schema file	SecureBoot_v1.xml

GET – Secure boot properties

Use the GET method to retrieve properties in SecureBoot resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Systems/1/SecureBoot

Request body

None

Status code

HTTP Status Code	Error Message ID	
500	InternalError	

Response body

The response is a JSON object that contains the following parameters:

Field	Туре	Description
Id	String	"SecureBoot".
Name	String	"Secure Boot".
Description	String	"UEFI Secure Boot Configuration".
SecureBootEnable	Boolean, Null	Enable or disable UEFI Secure Boot (takes effect on next boot).
SecureBootCurrentBoot	String, Null	Secure Boot state during the current boot cycle.
SecureBootMode String, Null Property value: "UserMode" "SetupMode" "AuditMode" "DeployedMode"		 "UserMode" "SetupMode" "AuditMode"
Actions Object		Expanded.
#SecureBoot.ResetKeys	Object	Refer to the Post section.
@Redfish.ActionInfo	Link	/redfish/v1/Systems/1/SecureBoot/ResetKeysActionInfo.

Response example

When the request is successful, a message body similar to the following is returned:

```
{
    "SecureBootCurrentBoot": "Disabled",
```

```
"@odata.id": "/redfish/v1/Systems/1/SecureBoot",
"Name": "Secure Boot",
"@odata.context": "/redfish/v1/$metadata#SecureBoot.SecureBoot",
"Id": "SecureBoot",
"@odata.type": "#SecureBoot.v1_0_4.SecureBoot",
"SecureBootEnable": true,
"SecureBootMode": "SetupMode",
"@odata.etag": "\"95230d5e00821715e4de6085f28c564e\"",
"Actions": {
    "#SecureBoot.ResetKeys": {
        "target": "/redfish/v1/Systems/1/SecureBoot/Actions/SecureBoot.ResetKeys",
        "title": "ResetKeys",
        "@Redfish.ActionInfo": "/redfish/v1/Systems/1/SecureBoot/ResetKeysActionInfo"
    }
},
"Description": "UEFI Secure Boot Configuration"
}
```

PATCH – Update secure boot properties

Use the PATCH method to update properties in SecureBoot resource for Redfish service.

Request URL

PATCH https://<BMC_IPADDR>/redfish/v1/Systems/1/SecureBoot

Request body

Properties to be updated are shown as below, all of these properties can be changed individually.

Field	Error Message ID		
SecureBootEna- ble	Enable or disable UEFI Secure Boot (takes effect on next boot).		
bie	XCC will assert RPP (Remote Physical Presence) internally when receiving this cmd.		
	If assert RPP successfully, return code 200 + @Message.ExtendedInfo "RebootRequired":		
	"RebootRequired": {		
	"Description": "Indicates that one or more properties were changed, and/or actions completed successfully. However, these changes will not take effect until the next system reboot.",		
	"Message": "Changes completed successfully, but these changes will not take effect until next reboot.",		
	"Severity": "Warning",		
	"NumberOfArgs": 0,		
	"ParamTypes": [],		
	"Resolution": "Reboot the computer system for the changes to take effect."		
	},		
	else return code 200 + @Message.ExtendedInfo "PhysicalPresenceError":		
	"PhysicalPresenceError": {		
	"Description": "The operation failed because Physical Presence or Remote Physical Presence was not asserted.",		
	"Message": " The operation failed because of Remote Physical Presence security requirements.",		
	"Severity": "Warning",		
	"NumberOfArgs": 0,		
	"ParamTypes": [],		
	"Resolution": "Attempt asserting Physical Presence or Remote Physical Presence, and retry the operation."		
	},		

Response body

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
200	RebootRequired
403	InsufficientPrivilege
500	InternalError

Response example

```
The following example is PATCH body.
"SecureBootEnable": true
}
Get the following response:
    "SecureBootCurrentBoot": "Disabled",
    "@odata.id": "/redfish/v1/Systems/1/SecureBoot",
    "Name": "Secure Boot",
    "@odata.context": "/redfish/v1/$metadata#SecureBoot.SecureBoot",
    "Id": "SecureBoot",
    "@odata.type": "#SecureBoot.v1_0_4.SecureBoot",
    "SecureBootEnable": true,
    "SecureBootMode": "SetupMode",
    "@odata.etag": "\"95230d5e00821715e4de6085f28c564e\"",
         "#SecureBoot.ResetKeys": {
             "target": "/redfish/v1/Systems/1/SecureBoot/Actions/SecureBoot.ResetKeys",
             "title": "ResetKeys",
             "@Redfish.ActionInfo": "/redfish/v1/Systems/1/SecureBoot/ResetKeysActionInfo"
        }
    },
    "Description": "UEFI Secure Boot Configuration",
    "@Message.ExtendedInfo": [
             "MessageArgs": [],
             "Resolution": "Reboot the computer system for the changes to take effect.",
             "MessageId": "ExtendedError.1.1.RebootRequired",
             "Severity": "Warning",
             "Message": "Changes completed successfully, but these changes will not take effect until next reboot.",
             "@odata.type": "#Message.v1 0 6.Message"
        }
    ]
}
```

POST - Reset secure boot keys

Use the POST method to reset secure boot keys.

Request URL

POST https://<BMC_IPADDR>/redfish/v1/Systems/1/SecureBoot/Actions/SecureBoot.ResetKeys

Request body

Field	Туре	Error Message ID	
ResetKeysType	String	This action is used to reset the Secure Boot keys(takes effect on next boot):	
		Value:	
		"ResetAllKeysToDefault"	
		"DeleteAllKeys"	
		"DeletePK"	
		XCC will assert RPP (Remote Physical Presence) internally when receiving this cmd.	
		If assert RPP successfully, return code 200 + @Message.ExtendedInfo "RebootRequired":	
		"RebootRequired": {	
		"Description": "Indicates that one or more properties were changed, and/or actions completed successfully. However, these changes will not take effect until the next system reboot.",	
		"Message": "Changes completed successfully, but these changes will not take effect until next reboot.",	
		"Severity": "Warning",	
		"NumberOfArgs": 0,	
		"ParamTypes": [],	
		"Resolution": "Reboot the computer system for the changes to take effect."	
		},	
		else return code 200 + @Message.ExtendedInfo "PhysicalPresenceError":	
		"PhysicalPresenceError": {	
		"Description": "The operation failed because Physical Presence or Remote Physical Presence was not asserted.",	
		"Message": "The operation failed because of Remote Physical Presence security requirements.",	
		"Severity": "Warning",	
		"NumberOfArgs": 0,	
		"ParamTypes": [],	
		"Resolution": "Attempt asserting Physical Presence or Remote Physical Presence, and retry the operation."	
		},	

Status code

HTTP Status Code	Error Message ID
200	RebootRequired, PhysicalPresenceError
403	Forbidden
500	InternalError

Response example

The following example is PATCH body. { "ResetKeysType": "DeletePK" } Get the following response: { "@Message.ExtendedInfo": [{ "MessageArgs": [], "Resolution": "Reboot the computer system for the changes to take effect.", "MessageId": "ExtendedError.1.1.RebootRequired", "Severity": "Warning",
"Message": "Changes completed successfully, but these changes will not take effect until next reboot.", "@odata.type": "#Message.v1_0_6.Message"] }

Chapter 17. Firmware Inventory and Update Service

Resource UpdateService

This resource shall be used to represent update service information for a Redfish implementation. It represents the properties that affect the service itself.

Number of Resources	1
Resource Path	/redfish/v1/UpdateService
Schema file	UpdateService_v1.xml

GET – Properties for firmware update service

Use the GET method to retrieve the update service resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/UpdateService

Response body

Field	Туре	Description
Id	String	"UpdateService"
Name	String	"Update Service"
Description	String	"Lenovo firmware update service".
ServiceEnabled	Boolean	True.
Status	Object	Expanded.
HealthRollup	String	"OK".
Health	String	"OK".
State	String	"Enabled".
Actions	Object	Expanded.
#UpdateService.SimpleUpdate	Object	Expanded.
@Redfish.ActionInfo	Link	"/redfish/v1/UpdateService/SimpleUpdateActionInfo"
target	String	A link to the involved action.
title	String	"SimpleUpdate".
Targets@Redfish. AllowableValues	Link	"/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup"
TransferProtocol @Redfish. AllowableValues	Array	Allowable values for SimpleUpdate action Item: string Item count: 2
TransferProtocol @Redfish. AllowableValues[N]	String	"SFTP". "TFTP".

© Copyright Lenovo 2017, 2020 **205**

Field	Туре	Description
HttpPushUri	Link	The URI used to perform an HTTP or HTTPS push update to the Update Service. Value is "/fwupdate".
HttpPushUriTargets	Array	Items: string
		Item count: 0-1
HttpPushUriTargets[N]	String	An array of URIs that indicate where to apply the update image. It is initially blank, and the value updated by client is not kept after XCC reset.
HttpPushUriTargetsBusy	Boolean	An indication of whether any client has reserved the HttpPushUriTargets property. The value is initially false, and is not kept after XCC reset.
HttpPushUriOptions	Object	Expanded
HttpPushUriApplyTime	Object	Expanded
ApplyTime[N]	String	"Immediate"
FirmwareInventory	Object	URI to the firmware info on the server
MultipartHttpPushUri	String	The URI used to perform an HTTPS push update to the Service with a multipart formatted request body; value is "/mfwupdate".
MaxImageSizeBytes	Integer	250000000

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

```
{
    "MultipartHttpPushUri": "/mfwupdate",
    "Id": "UpdateService",
    "ServiceEnabled": true,
    "HttpPushUri": "/fwupdate",
    "HttpPushUriTargets": [],
    "Description": "Lenovo firmware update service.",
    "FirmwareInventory": {
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory"
    "Status": {
        "HealthRollup": "OK",
        "Health": "OK",
        "State": "Enabled"
    "Name": "Update Service",
    "HttpPushUriTargetsBusy": false,
    "0em": {
        "Lenovo": {
             "FirmwareServices": {
                 "@odata.id": "/redfish/v1/UpdateService/Oem/Lenovo/FirmwareServices"
             "@odata.type": "#LenovoUpdateService.v1_0_0.LenovoUpdateService"
```

```
}
    },
    "@odata.type": "#UpdateService.v1_6_0.UpdateService",
    "Actions": \{
         "#UpdateService.SimpleUpdate": {
             "target": "/redfish/v1/UpdateService/Actions/UpdateService.SimpleUpdate",
             "title": "SimpleUpdate",
             "TransferProtocol@Redfish.AllowableValues": [
                 "TFTP",
                 "SFTP"
             ],
             "Targets@Redfish.AllowableValues": [
                 "/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup"
             "@Redfish.ActionInfo": "/redfish/v1/UpdateService/SimpleUpdateActionInfo"
        }
    },
    "MaxImageSizeBytes": 250000000,
    "@odata.etag": "\"593b8fa08d40fe0001e39baf3ac3094a\"",
    "HttpPushUriOptions": {
         "HttpPushUriApplyTime": {
             "ApplyTime": "Immediate"
    "@odata.id": "/redfish/v1/UpdateService"
}
```

PATCH- Update update service status

Use the PATCH method to update the updateservice resource properties and status.

Request URL

PATCH https://<BMC_IPADDR>/redfish/v1/UpdateService

Request body

Field	Туре	Description
HttpPushUri- Targets	Array	Items: string Item count: 0-1
HttpPushUr- iTargets[N]	String	An array of URIs that indicate where to apply the update image. It is initially blank, and the value updated by client is not kept after XCC reset.
HttpPushUri- TargetsBusy	Boolean	An indication of whether any client has reserved the HttpPushUriTargets property. The value is initially false, and is not kept after XCC reset.

Response

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example is PATCH body

```
"HttpPushUriTargets" : [
"/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup"
  ]
}
After the PATCH operation runs successfully, querying the update service resource returns below example
JSON response:
{
    "MultipartHttpPushUri": "/mfwupdate",
    "Id": "UpdateService",
    "ServiceEnabled": true.
    "HttpPushUri": "/fwupdate",
    "HttpPushUriTargets": [
         "/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup"
    "Description": "Lenovo firmware update service.",
    "FirmwareInventory": {
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory"
    "Status": {
        "HealthRollup": "OK",
        "Health": "OK",
        "State": "Enabled"
    },
    "Name": "Update Service",
    "HttpPushUriTargetsBusy": false,
    "0em": {
        "Lenovo": {
             "FirmwareServices": {
                 "@odata.id": "/redfish/v1/UpdateService/Oem/Lenovo/FirmwareServices"
             "@odata.type": "#LenovoUpdateService.v1_0_0.LenovoUpdateService"
    },
    "@odata.type": "#UpdateService.v1 6 O.UpdateService",
    "HttpPushUriOptions": {
         "HttpPushUriApplyTime": {
             "ApplyTime": "Immediate"
        }
    "MaxImageSizeBytes": 250000000,
    "@odata.etag": "\"7dd4c1a358b13e95cc1c93d70426ad56\"",
    "Actions": {
         "#UpdateService.SimpleUpdate": {
             "target": "/redfish/v1/UpdateService/Actions/UpdateService.SimpleUpdate",
             "title": "SimpleUpdate",
             "TransferProtocol@Redfish.AllowableValues": [
                 "TFTP",
                 "SFTP"
             "Targets@Redfish.AllowableValues": [
                 "/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup"
             "@Redfish.ActionInfo": "/redfish/v1/UpdateService/SimpleUpdateActionInfo"
        }
    "@odata.id": "/redfish/v1/UpdateService"
```

}

POST – Simple update for firmware

This action can perform an update of installed software component(s) as contained within a software image file located at a URI referenced by the ImageURI parameter.

Request URL

POST https://<BMC_IPADDR>/redfish/v1/UpdateService/Actions/UpdateService.SimpleUpdate

Request body

Parameter	Туре	Error Message ID
ImageURI	String	URI for the image file
Targets	String	URIs of the resource that is expected to update That is, when you indend to update firmware for BMC(Backup), the Targets parameter must be [/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup]. This is also the exclusive case to provide a value in Targets to update firmware with Redfish, and only applicable for BMC(Backup) update. In order to update other kind of firmware, the Targets is not needed or accepts null value.
TransferProtocol	String	Network protocol used by the Service to retrieve the firmware image file
Username	String	User name to access an sftp server. It's required when the image is located on an sftp server, and username:password is not available in ImageURI.
Password	String	Password to access an sftp server. It's required when the image is located on an sftp server, and username:password is not available in ImageURI.

Response

Field	Туре	Error Message ID
ld	String	The created task ID.
Name	String	Task name.
Description	String	This resource represents a task for a Redfish implementation.
TaskMonitor	String	The URI of the Task Monitor for this task.
StartTime	String	The date-time stamp that the task was last started.
TaskState	String	The state of the task.
Messages	Array	This is an array of messages associated with the task.
PercentCom- plete	Integer	Task completion in percent.
HidePayload	Boolean	Indicates Payload object is hdden and not returned on GET.

Status code

HTTP Status Code	Error Message ID
202	Accepted
400	BadRequest, ActionParamMissing , ActionParamTypeError , ActionParamFormatError
419	Conflict
500	InternalError

Example

The following example is the request to update BMC(Backup). The POST body is filled as below:

```
"ImageURI": "sftp://192.168.1.126/tmp/xcc/lnvgy_fw_xcc_cdi338d-2.70_anyos_noarch.uxz",
  "Targets": [
    "/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup"
  "Username": "userid",
  "Password": "password"
The following example JSON response is returned.
   "Id" : "c13eea76-4ee3-4696-8e03-0f0b16bb6512",
   "Messages" : [],
   "TaskState" : "New",
   "@odata.etag" : "\"1577366735335\"",
   "@odata.id" : "/redfish/v1/TaskService/Tasks/c13eea76-4ee3-4696-8e03-0f0b16bb6512",
   "PercentComplete" : 0,
   "@odata.type" : "#Task.v1_4_1.Task",
   "StartTime" : "2019-12-26T13:25:35+00:00",
   "Description": "This resource represents a task for a Redfish implementation.",
   "Name" : "Task c13eea76-4ee3-4696-8e03-0f0b16bb6512",
   "HidePayload" : true,
   "TaskMonitor" : "/redfish/v1/TaskService/Oc24a2O2-c4ef-4bf8-9c10-2bb8O6ffd8a2"
}
In the response body, a new created "task" resource is included. Then "Get" the URI to check the updating
process. The following example JSON response is returned.
{
    "StartTime": "2019-12-26T13:25:35+00:00",
    "TaskState": "Running",
    "HidePayload": true,
    "@odata.id": "/redfish/v1/TaskService/Tasks/c13eea76-4ee3-4696-8e03-0f0b16bb6512",
    "PercentComplete": 17.
    "Name": "Task c13eea76-4ee3-4696-8e03-0f0b16bb6512",
    "TaskMonitor": "/redfish/v1/TaskService/Oc24a2O2-c4ef-4bf8-9c10-2bb8O6ffd8a2",
    "Id": "c13eea76-4ee3-4696-8e03-0f0b16bb6512",
    "@odata.type": "#Task.v1 4 1.Task",
    "@odata.etag": "\"1577366759808\"",
    "Messages": [
            "@odata.type": "#Message.v1_0_7.Message",
            "Message": "The task with id c13eea76-4ee3-4696-8e03-0f0b16bb6512 has changed to progress
17 percent complete.",
            "Resolution": "None.",
            "Severity": "OK",
            "MessageId": "TaskEvent.1.0.TaskProgressChanged",
            "MessageArgs": [
                 "c13eea76-4ee3-4696-8e03-0f0b16bb6512",
                 "17"
            ]
        },
            "@odata.type": "#Message.v1_0_7.Message",
            "Message": "Transfer 49 percent complete.",
```

```
"Resolution": "None",
             "Severity": "OK",
             "MessageId": "LenovoFirmwareUpdateRegistry.1.0.UpdateTransferInProgress",
             "MessageArgs": [
                  "49"
             ]
         }
    "Description": "This resource represents a task for a Redfish implementation."
}
The following example is the request to update UEFI. The POST body is filled as below:
  "ImageURI": "sftp://192.168.1.126/tmp/uefi/lnvgy_fw_uefi_ive148m-2.41_anyos_32-64.uxz",
  "Username":"userid",
  "Password":"password"
}
The following example JSON response for POST SimpleUpdate action is returned.
   "Id" : "5913dce0-dbc7-4ba3-a643-0f4cd4bec5e8",
   "Messages" : [],
   "TaskState" : "New",
   "@odata.etag" : "\"1577365985589\"",
"@odata.id" : "/redfish/v1/TaskService/Tasks/5913dce0-dbc7-4ba3-a643-0f4cd4bec5e8",
   "PercentComplete" : 0,
   "@odata.type" : "#Task.v1_4_1.Task",
   "StartTime" : "2019-12-26T13:13:05+00:00",
   "Description": "This resource represents a task for a Redfish implementation.",
   "Name" : "Task 5913dceO-dbc7-4ba3-a643-0f4cd4bec5e8",
   "HidePayload" : true,
   "TaskMonitor" : "/redfish/v1/TaskService/20c990b8-6a6b-44dd-818c-9e6348bdfc4d"
}
In the response body, a new created "task" resource is included. Then "Get" the URI to check the updating
process. The following example JSON response is returned.
    "StartTime": "2019-12-26T13:13:05+00:00",
    "TaskState": "Running",
    "HidePayload": true,
    "@odata.id": "/redfish/v1/TaskService/Tasks/5913dce0-dbc7-4ba3-a643-0f4cd4bec5e8",
    "PercentComplete": 59,
    "Messages": [
         {
             "MessageArgs": [
                  "5913dce0-dbc7-4ba3-a643-0f4cd4bec5e8",
                 "59"
             "Message": "The task with id 5913dceO-dbc7-4ba3-a643-0f4cd4bec5e8 has changed to progress 59 percent
complete.",
             "MessageId": "TaskEvent.1.0.TaskProgressChanged",
             "Severity": "OK",
             "Resolution": "None.",
             "@odata.type": "#Message.v1 0 7.Message"
         },
             "MessageArgs": [
```

```
"1".
                 "/redfish/v1/UpdateService/FirmwareInventory/UEFI",
                 "UEFI-IVE1-6",
                 "48M-2.41",
                 "Unknown"
             "Message": "Assignment 1: Resource /redfish/v1/UpdateService/FirmwareInventory/UEFI SoftwareID UEFI-IVE1-6
Version 48M-2.41 to Version Unknown.",
             "@odata.type": "#Message.v1 0 7.Message",
             "Severity": "OK",
             "MessageId": "LenovoFirmwareUpdateRegistry.1.0.UpdateAssignment",
             "Resolution": "None"
        },
             "@odata.type": "#Message.v1_0_7.Message",
             "Message": "Assignment 1: Apply 38 percent complete.",
             "Resolution": "None",
             "Severity": "OK",
             "MessageId": "LenovoFirmwareUpdateRegistry.1.0.PayloadApplyInProgress",
             "MessageArgs": [
                 "1",
                 "38"
            ]
        }
    ],
    "@odata.type": "#Task.v1_4_1.Task",
    "Name": "Task 5913dce0-dbc7-4ba3-a643-0f4cd4bec5e8",
    "Id": "5913dce0-dbc7-4ba3-a643-0f4cd4bec5e8",
    "@odata.etag": "\"1577366006339\"",
    "TaskMonitor": "/redfish/v1/TaskService/20c990b8-6a6b-44dd-818c-9e6348bdfc4d",
    "Description": "This resource represents a task for a Redfish implementation."
}
```

POST – HTTP Push update for firmware

This operation can perform an update of installed software component(s) by pushing a software image file to the URI referenced by UpdateService. HttpPushUri property. In XCC redfish service, the UpdateService. HttpPushUri property value is "/fwupdate".

Request URL

POST https://<BMC_IPADDR>/fwupdate

Request body

The HTTP POST operation shall provide authentication with the sufficient privilege to access the UpdateService resource.

Response

Field	Туре	Error Message ID	
ld	String	The created task ID.	
Name	String	Task name.	
Description	String	This resource represents a task for a Redfish implementation.	
TaskMonitor	String	The URI of the Task Monitor for this task.	
StartTime	String	The date-time stamp that the task was last started.	
TaskState	String	The state of the task.	

Field	Туре	Error Message ID	
Messages	Array	This is an array of messages associated with the task.	
PercentCom- plete	Integer	Task completion in percent.	
HidePayload	Boolean	Indicates Payload object is hdden and not returned on GET.	

Note: The client may optionally include "Content-Length" header in the POST request to indicate the POST body size. XCC checks this header and verity the size is supported for firmware updates. If the file size is beyond what the service can support, it returns code 413 with error messages indicating file size too large.

Http Push update may be rejected with code 503 when Multipart HTTP push update is in progress, and vice versa.

Status code

HTTP Status Code	Error Message ID
202	Accepted
400	BadRequest, ActionParamMissing , ActionParamTypeError , ActionParamFormatError
413	RequestEntityTooLarge
500	InternalError
503	ServiceUnavailable

Example

The following example with curl commands is the HTTP push update procedure for UEFI/ BMC(Backup).

• Step 1. Update HttpPushUriTargetsBusy to true.

Client should first check HttpPushUriTargetsBusy property. When the value is false, change HttpPushUriTargetsBusy property to True, in order to claim the service is occupied for firmware update. Other clients should not update firmware on this server to avoid interference.

The PATCH body is:

```
{
   "HttpPushUriTargetsBusy" : true
```

 Step 2. If client intends to update BMC(Backup), there is an extra step here to provide HttpPushUriTargets.

Skip this step if it is not to update BMC(Backup) firmware.

The PATCH body is:

```
"HttpPushUriTargets" : [
   "/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup"
```

• Step 3. Push the firmware image to the URL in HttpPushUri property.

Sample curl command is below for HTTP push update request for UEFI.

```
curl -s -k -u USERID:PASSWORD --data-binary @/tmp/uefi/lnvgy_fw_uefi_ive148m-2.41_anyos_32-64.uxz
https://192.168.1.126:443/fwupdate
```

note: you can add '-v' to the curl command to observe file transfer progress.

Sample curl command is below for HTTP push update request for BMC(Backup).

```
curl -s -k -u USERID:PASSWORD --data-binary @/tmp/xcc/lnvgy fw xcc cdi338d-2.70 anyos noarch.uxz
https://192.168.1.126:443/fwupdate
```

The following sample JSON response is returned.

```
"Id" : "a274a218-58bc-4100-9ec3-6843dfaa486c",
   "Messages" : [],
   "TaskState" : "New",
   "@odata.etag" : "\"1577227530316\"",
   "@odata.id" : "/redfish/v1/TaskService/Tasks/a274a218-58bc-4100-9ec3-6843dfaa486c",
   "PercentComplete" : 0,
   "@odata.type" : "#Task.v1_4_1.Task",
   "StartTime" : "2019-12-24T22:45:30+00:00",
   "Description": "This resource represents a task for a Redfish implementation.",
   "Name" : "Task a274a218-58bc-4100-9ec3-6843dfaa486c",
   "HidePayload" : true,
   "TaskMonitor" : "/redfish/v1/TaskService/d3883fd4-ed0b-45dc-8c21-f7ad45f81c5d"
}
```

In the response body, a new created task resource is included. And a task monitor resource is referenced in TaskMonitor property.

Step 4. Client needs to periodically check the URI of task for updating progress.

In the following are sample JSON responses for continuously checking a task resource. (The task Id is ef05579b-380c-4f23-a20d-d890073fb588)

The 1st check, task overall progress 31%. It is verifying the uploaded image.

```
"Id" : "ef05579b-380c-4f23-a20d-d890073fb588",
   "Messages" : [
         "MessageArgs" : [
            "ef05579b-380c-4f23-a20d-d890073fb588",
             "31"
         "Resolution" : "None.",
         "Message" : "The task with id ef05579b-380c-4f23-a20d-d890073fb588 has changed to progress 31 percent
complete."
         "@odata.type" : "#Message.v1_0_7.Message",
         "MessageId" : "TaskEvent.1.0.TaskProgressChanged",
         "Severity" : "OK"
      },
         "MessageArgs" : [
             "0"
          "Resolution" : "None",
         "Message" : "Verify O percent complete.",
         "@odata.type" : "#Message.v1 0 7.Message",
```

```
"Severity" : "OK",
          "MessageId" : "LenovoFirmwareUpdateRegistry.1.0.UpdateVerifyInProgress"
      }
   "TaskState" : "Running",
   "@odata.etag" : "\"1577225350164\"",
   "@odata.id": "/redfish/v1/TaskService/Tasks/ef05579b-380c-4f23-a20d-d890073fb588",
   "PercentComplete" : 31,
   "@odata.type" : "#Task.v1_4_1.Task",
   "StartTime" : "2019-12-24T22:09:02+00:00",
   "Description" : "This resource represents a task for a Redfish implementation.",
   "Name" : "Task ef05579b-380c-4f23-a20d-d890073fb588".
   "HidePayload" : true,
   "TaskMonitor" : "/redfish/v1/TaskService/bf3cd02d-a77e-4ad4-8df8-f00802fc40e0"
}
The 2<sup>nd</sup> check, task overall progress 58%. It is applying the image.
   "Id": "ef05579b-380c-4f23-a20d-d890073fb588",
   "Messages" : [
      {
          "MessageArgs" : [
             "ef05579b-380c-4f23-a20d-d890073fb588",
             "58"
          "Resolution" : "None.",
          "Message" : "The task with id ef05579b-380c-4f23-a20d-d890073fb588 has changed to progress 58 percent
complete.",
         "@odata.type" : "#Message.v1_0_7.Message",
         "MessageId": "TaskEvent.1.0.TaskProgressChanged",
          "Severity" : "OK"
      },
      {
          "MessageArgs" : [
             "1",
             "/redfish/v1/UpdateService/FirmwareInventory/UEFI",
             "UEFI-IVE1-6",
             "48M-2.41",
             "Unknown"
          "Resolution" : "None",
          "Message" : "Assignment 1: Resource /redfish/v1/UpdateService/FirmwareInventory/UEFI SoftwareID UEFI-IVE1-6
Version 48M-2.41 to Version Unknown.",
          "@odata.type" : "#Message.v1_0_7.Message",
          "MessageId" : "LenovoFirmwareUpdateRegistry.1.0.UpdateAssignment",
          "Severitu" : "OK"
      },
          "MessageArgs" : [
             "1",
             "36"
          "Resolution" : "None",
          "Message" : "Assignment 1: Apply 36 percent complete.",
          "@odata.type" : "#Message.v1_0_7.Message",
          "MessageId" : "LenovoFirmwareUpdateRegistry.1.0.PayloadApplyInProgress",
          "Severity" : "OK"
      }
   "TaskState" : "Running",
```

```
"@odata.etag" : "\"1577225369708\"",
   "@odata.id": "/redfish/v1/TaskService/Tasks/ef05579b-380c-4f23-a20d-d890073fb588",
   "PercentComplete" : 58,
   "@odata.type" : "#Task.v1_4_1.Task",
   "StartTime" : "2019-12-24T22:09:02+00:00",
   "Description": "This resource represents a task for a Redfish implementation.",
   "Name" : "Task ef05579b-380c-4f23-a20d-d890073fb588",
   "HidePayload" : true,
   "TaskMonitor" : "/redfish/v1/TaskService/bf3cd02d-a77e-4ad4-8df8-f00802fc40e0"
}
The next check, task overall progress 74%. It is further applying the image.
{
   "Id" : "ef05579b-380c-4f23-a20d-d890073fb588",
   "Messages" : [
      {
          "MessageArgs" : [
             "ef05579b-380c-4f23-a20d-d890073fb588",
             "74"
          "Resolution" : "None.",
          "Message" : "The task with id ef05579b-380c-4f23-a20d-d890073fb588 has changed to progress 74 percent
complete.",
          "@odata.type" : "#Message.v1_0_7.Message",
          "MessageId" : "TaskEvent.1.0.TaskProgressChanged",
          "Severity" : "OK"
      },
      {
          "MessageArgs" : [
             "/redfish/v1/UpdateService/FirmwareInventory/UEFI",
             "UEFI-IVE1-6".
             "48M-2.41",
            "Unknown"
         ],
         "Resolution" : "None",
         "Message" : "Assignment 1: Resource /redfish/v1/UpdateService/FirmwareInventory/UEFI SoftwareID UEFI-IVE1-6
Version 48M-2.41 to Version Unknown.",
         "@odata.type" : "#Message.v1_0_7.Message",
          "MessageId" : "LenovoFirmwareUpdateRegistry.1.0.UpdateAssignment",
          "Severity" : "OK"
      },
          "MessageArgs" : [
            "1",
             "61"
          "Resolution" : "None",
          "Message" : "Assignment 1: Apply 61 percent complete.",
          "@odata.type" : "#Message.v1 0 7.Message",
          "MessageId" : "LenovoFirmwareUpdateRegistry.1.0.PayloadApplyInProgress",
         "Severity" : "OK"
      }
   "TaskState" : "Running",
   "@odata.etag" : "\"1577225376926\"",
   "@odata.id": "/redfish/v1/TaskService/Tasks/ef05579b-380c-4f23-a20d-d890073fb588",
   "PercentComplete" : 74,
   "@odata.type" : "#Task.v1 4 1.Task",
   "StartTime" : "2019-12-24T22:09:02+00:00",
```

```
"Description": "This resource represents a task for a Redfish implementation.",
   "Name": "Task ef05579b-380c-4f23-a20d-d890073fb588",
   "HidePayload" : true,
   "TaskMonitor" : "/redfish/v1/TaskService/bf3cd02d-a77e-4ad4-8df8-f00802fc40e0"
}
The next check, task overall progress 100%. Image applying completed. And task state is completed.
   "Id" : "ef05579b-380c-4f23-a20d-d890073fb588".
   "Messages" : [
      {
          "MessageArgs" : [
             "ef05579b-380c-4f23-a20d-d890073fb588"
          "Resolution" : "None.",
          "Message" : "The task with id ef05579b-380c-4f23-a20d-d890073fb588 has completed.",
          "@odata.type" : "#Message.v1_0_7.Message",
          "MessageId" : "TaskEvent.1.0.TaskCompletedOK",
          "Severity" : "OK"
      },
          "MessageArgs" : [
            null
          "Resolution" : "None",
          "Message" : "Successfully Completed Request",
          "@odata.type" : "#Message.v1_0_7.Message",
          "MessageId" : "Base.1.5.Success",
          "Severity" : "OK"
      },
          "MessageArgs" : [
             "1",
             "/redfish/v1/UpdateService/FirmwareInventory/UEFI",
             "UEFI-IVE1-6",
             "48M-2.41",
             "48M-2.41"
          "Resolution" : "None",
          "Message" : "Assignment 1: Resource /redfish/v1/UpdateService/FirmwareInventory/UEFI SoftwareID UEFI-IVE1-6
Version 48M-2.41 to Version 48M-2.41.",
          "@odata.type" : "#Message.v1_0_7.Message",
          "MessageId" : "LenovoFirmwareUpdateRegistry.1.0.UpdateAssignment",
          "Severity" : "OK"
      },
      {
          "MessageArgs" : [
          "Resolution" : "None",
          "Message" : "Assignment 1: Apply complete",
          "@odata.type" : "#Message.v1_0_7.Message",
          "MessageId" : "LenovoFirmwareUpdateRegistry.1.0.PayloadApplyCompleted",
          "Severity" : "OK"
   1,
   "TaskState" : "Completed",
   "@odata.etag" : "\"1577225382166\"",
   "@odata.id" : "/redfish/v1/TaskService/Tasks/ef05579b-380c-4f23-a20d-d890073fb588",
   "TaskStatus" : "OK",
```

```
"PercentComplete" : 100,
   "@odata.type" : "#Task.v1_4_1.Task",
   "StartTime" : "2019-12-24T22:09:02+00:00",
   "EndTime" : "2019-12-24T22:09:42+00:00",
   "Description" : "This resource represents a task for a Redfish implementation.",
   "Name" : "Task ef05579b-380c-4f23-a20d-d890073fb588",
   "TaskMonitor" : "/redfish/v1/TaskService/bf3cd02d-a77e-4ad4-8df8-f00802fc40e0",
   "HidePayload" : true
}
```

 Step 5. Client needs to check the task until its state changed to complete or exception. And handle exceptions according to task messages returned.

A sample task response with exception is below.

```
"Id" : "afaef595-c15e-4085-b985-7c6c10f10812",
   "Messages" : [
      {
         "MessageArgs" : [
            "afaef595-c15e-4085-b985-7c6c10f10812"
         "Resolution" : "None.",
         "Message" : "The task with id afaef595-c15e-4085-b985-7c6c10f10812 has completed with warnings.",
         "@odata.type" : "#Message.v1 0 7.Message",
         "MessageId" : "TaskEvent.1.0.TaskCompletedWarning",
         "Severity" : "Warning"
      },
         "MessageArgs" : [
            "(0007): Error verifying image transferred to IMM applies to this system."
         "Resolution" : "Resubmit the request. If the problem persists, consider resetting the service.",
         "Message" : "Verify failed, return code=7 - return message: (0007): Error verifying image transferred to IMM
"MessageId" : "LenovoFirmwareUpdateRegistry.1.0.UpdateVerifyFailed",
         "Severity" : "Warning"
      }
   "TaskState" : "Exception",
   "@odata.etag" : "\"1577224625433\"",
   "@odata.id" : "/redfish/v1/TaskService/Tasks/afaef595-c15e-4085-b985-7c6c10f10812",
   "TaskStatus" : "Warning".
   "PercentComplete" : 31,
   "@odata.type" : "#Task.v1 4 1.Task",
   "StartTime" : "2019-12-24T21:56:55+00:00",
   "EndTime" : "2019-12-24T21:57:05+00:00",
   "Description": "This resource represents a task for a Redfish implementation.",
   "Name" : "Task afaef595-c15e-4085-b985-7c6c10f10812",
   "TaskMonitor" : "/redfish/v1/TaskService/5254c31b-1491-40cd-bd94-cb7d9639b5d4",
   "HidePayload" : true
}
```

XCC keeps a completed/exceptional task resource for status check. Client may access the task monitor resource (the TaskMonitor reference returned in step 3), and XCC removes the corresponding tasks.

Step 6. If the target is BMC(Backup), there is an extra step here to clear HttpPushUriTargets.

Skip this step if it is not BMC(Backup) firmware updated.

The PATCH body is:

```
"HttpPushUriTargets" : [ ]
```

Step 7. Update HttpPushUriTargetsBusy to false.

When the firmware update procedure is completed, change HttpPushUriTargetsBusy property to false, in order to release the service to other clients for firmware update.

The PATCH body is:

```
"HttpPushUriTargetsBusy" : false
```

POST – Multipart HTTP Push update for firmware

This operation can perform an update of installed software component(s) by pushing a software image file to the URI referenced by UpdateService.MultipartHttpPushUri property. In XCC redfish service, the UpdateService.MultipartHttpPushUri property value is "/mfwupdate".

Request URL

POST https://<BMC_IPADDR>/mfwupdate

Request body

The HTTP POST operation shall provide authentication with the sufficient privilege to access the UpdateService resource.

Response

Field	Туре	Error Message ID	
Id	String	The created task ID.	
Name	String	Task name.	
Description	String	This resource represents a task for a Redfish implementation.	
TaskMonitor	String	The URI of the Task Monitor for this task.	
StartTime	String	The date-time stamp that the task was last started.	
TaskState	String	The state of the task.	
Messages	Array	This is an array of messages associated with the task.	
PercentCom- plete	Integer	Task completion in percent.	
HidePayload	Boolean	Indicates Payload object is hdden and not returned on GET.	

Note: The client may optionally include HTTP multipart form data in the POST body to specify the imagefile name as RFC2388 specified. XCC checks this header and verity the size is supported for firmware updates, and returns code 413 when file size is too large. If the client uploads multiple files in a POST request, it returns code 400 with an error message indicating the format is not supported.

Multipart HTTP push update may be rejected with code 503 when Http Push update is in progress, and vice versa.

HTTP Status Code	Error Message ID
202	Accepted
400	BadRequest, ActionParamMissing , ActionParamTypeError , ActionParamFormatError
413	RequestEntityTooLarge
500	InternalError
503	ServiceUnavailable

Example

The following example with curl commands is the multipart HTTP push update procedure for UEFI/ BMC (Backup).

Step 1. Update HttpPushUriTargetsBusy to true.

Client should first check HttpPushUriTargetsBusy property. When the value is false, change HttpPushUriTargetsBusy property to True, in order to claim the service is occupied for firmware update. Other clients should not update firmware on this server to avoid interference.

The PATCH body is:

```
{
   "HttpPushUriTargetsBusy" : true
}
```

 Step 2. If client intends to update BMC(Backup), there is an extra step here to provide HttpPushUriTargets.

Skip this step if it is not to update BMC(Backup) firmware.

The PATCH body is:

```
"HttpPushUriTargets" : [
   "/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup"
```

Step 3. Push the firmware image to the URL in MultipartHttpPushUri property.

Sample curl command is below for multipart HTTP push update request for BMC(Backup).

```
curl -s -k -u USERID:PASSWORD -F 'UpdateParameters={ "Targets":[ "/redfish/v1/UpdateService/FirmwareInventory/
BMC-Backup" ], "@Redfish.OperationApplyTime": "OnStartUpdateRequest"}; type=application/json' -F
'UpdateFile=@/tmp/xcc/xcc-fw.upd;type=application/octet-stream' https://192.168.1.216:443/mfwupdate
```

The following sample JSON response is returned.

```
"Members": [
        "@odata.id": "/redfish/v1/TaskService/Tasks/1491a59d-2abb-4e6e-9e11-84fea2c89ceb"
"@odata.type": "#TaskCollection.TaskCollection",
"@odata.id": "/redfish/v1/TaskService/Tasks".
"Members@odata.count": 1.
```

```
"@odata.etag": "\"1585198032333\\"",
"Name": "Task Collection",
"Description": "This resource represents a Resource Collection of Task instances for a Redfish implementation."
}
```

In the response body, a new created task resource is included. And a task monitor resource is referenced in TaskMonitor property.

• Step 4. Client needs to periodically check the URI of task for updating progress.

In the following are sample JSON responses for continuously checking a task resource. (The task Id is 1491a59d-2abb-4e6e-9e11-84fea2c89ceb)

The 1st check, task overall progress 31%. It is verifying the uploaded image.

"TaskState": "Completed",

"Name": "Task 1491a59d-2abb-4e6e-9e11-84fea2c89ceb",

"EndTime": "2020-03-26T04:48:36+00:00",

```
{
    "StartTime": "2020-03-26T04:47:12+00:00",
    "TaskState": "Running",
    "HidePayload": true,
    "Name": "Task 1491a59d-2abb-4e6e-9e11-84fea2c89ceb",
    "PercentComplete": 31,
    "@odata.id": "/redfish/v1/TaskService/Tasks/1491a59d-2abb-4e6e-9e11-84fea2c89ceb",
    "@odata.type": "#Task.v1_4_2.Task",
    "Id": "1491a59d-2abb-4e6e-9e11-84fea2c89ceb",
    "TaskMonitor": "/redfish/v1/TaskService/7add4883-18c6-431c-9f1b-f2f8cc43804c",
    "@odata.etag": "\"1585198032627\"",
    "Messages": [
        {
             "@odata.type": "#Message.v1 0 8.Message",
             "MessageArgs": [
                 "1491a59d-2abb-4e6e-9e11-84fea2c89ceb",
             "Message": "The task with id 1491a59d-2abb-4e6e-9e11-84fea2c89ceb has changed to progress 30 percent
complete.",
             "Severity": "OK",
             "Resolution": "None.",
             "MessageId": "TaskEvent.1.0.TaskProgressChanged"
        },
             "@odata.type": "#Message.v1 0 8.Message",
             "Message": "Verify 1 percent complete.",
             "Resolution": "None",
             "Severity": "OK",
             "MessageId": "LenovoFirmwareUpdateRegistry.1.0.UpdateVerifyInProgress",
             "MessageArgs": [
                 "0"
        }
    "Description": "This resource represents a task for a Redfish implementation."
}
The next check, task overall progress 100%. Image applying completed. And task state is completed.
{
    "StartTime": "2020-03-26T04:47:12+00:00",
```

```
"HidePayload": true,
    "@odata.id": "/redfish/v1/TaskService/Tasks/1491a59d-2abb-4e6e-9e11-84fea2c89ceb",
    "PercentComplete": 100,
    "TaskStatus": "OK",
    "@odata.type": "#Task.v1_4_2.Task",
    "Id": "1491a59d-2abb-4e6e-9e11-84fea2c89ceb",
    "TaskMonitor": "/redfish/v1/TaskService/7add4883-18c6-431c-9f1b-f2f8cc43804c",
    "Messages": [
        {
             "MessageArgs": [
                 "1491a59d-2abb-4e6e-9e11-84fea2c89ceb"
             "Message": "The task with id 1491a59d-2abb-4e6e-9e11-84fea2c89ceb has completed.",
             "Resolution": "None.",
             "Severity": "OK",
             "MessageId": "TaskEvent.1.0.TaskCompletedOK",
             "@odata.type": "#Message.v1 0 8.Message"
        },
            "@odata.type": "#Message.v1 0 8.Message",
            "MessageArgs": [],
            "Message": "Successfully Completed Request",
             "Severity": "OK",
             "Resolution": "None",
             "MessageId": "Base.1.6.Success"
        },
            "@odata.type": "#Message.v1_0_8.Message",
            "Message": "Assignment 1: Resource /redfish/v1/UpdateService/FirmwareInventory/BMC-Backup SoftwareID
BMC-TEI3-10 Version 95D-3.40 to Version 95D-3.40.",
             "Resolution": "None",
             "Severity": "OK",
             "MessageId": "LenovoFirmwareUpdateRegistry.1.0.UpdateAssignment",
             "MessageArgs": [
                 "1",
                 "/redfish/v1/UpdateService/FirmwareInventory/BMC-Backup",
                 "BMC-TEI3-10",
                 "95D-3.40",
                 "95D-3.40"
            1
        },
             "@odata.type": "#Message.v1 0 8.Message".
            "Message": "Assignment 1: Apply complete",
             "Resolution": "None",
            "Severity": "OK",
             "MessageId": "LenovoFirmwareUpdateRegistry.1.0.PayloadApplyCompleted",
             "MessageArgs": [
                 "1"
        }
    "@odata.etag": "\"1585198116883\"",
    "Description": "This resource represents a task for a Redfish implementation."
}
```

· Step 5. Client needs to check the task until its state changed to complete or exception. And handle exceptions according to task messages returned.

A sample task response with exception is below.

```
{
    "StartTime": "2020-03-26T06:02:32+00:00",
    "TaskState": "Exception",
    "Name": "Task 55b1abaf-a678-4869-aef5-1a57ef76ad3b",
    "EndTime": "2020-03-26T06:02:33+00:00",
    "HidePayload": true,
    "@odata.id": "/redfish/v1/TaskService/Tasks/55b1abaf-a678-4869-aef5-1a57ef76ad3b",
    "PercentComplete": 30,
    "TaskStatus": "Warning",
    "TaskMonitor": "/redfish/v1/TaskService/edece36d-5bcd-4ee1-9a5e-3e498412d502",
    "Id": "55b1abaf-a678-4869-aef5-1a57ef76ad3b",
    "@odata.type": "#Task.v1 4 2.Task",
    "@odata.etag": "\"1585202553905\""
    "Messages": [
        {
             "@odata.type": "#Message.v1 0 8.Message",
             "Message": "The task with id 55b1abaf-a678-4869-aef5-1a57ef76ad3b has completed with warnings.",
             "MessageArgs": [
                 "55b1abaf-a678-4869-aef5-1a57ef76ad3b"
             "Severity": "Warning",
            "Resolution": "None.",
            "MessageId": "TaskEvent.1.0.TaskCompletedWarning"
        },
             "MessageArgs": [
                 "57",
                 "Invalid URI"
             "Message": "Verify failed, return code=57 - return message: Invalid URI",
             "Resolution": "Resubmit the request. If the problem persists, consider resetting the service.",
             "Severity": "Warning",
             "MessageId": "LenovoFirmwareUpdateRegistry.1.0.UpdateVerifyFailed",
             "@odata.type": "#Message.v1 0 8.Message"
    "Description": "This resource represents a task for a Redfish implementation."
}
```

Step 6. If the target is BMC(Backup), there is an extra step here to clear HttpPushUriTargets.

Skip this step if it is not BMC(Backup) firmware updated.

```
The PATCH body is:
```

```
{
    "HttpPushUriTargets" : [ ]
}
```

• Step 7. Update HttpPushUriTargetsBusy to false.

When the firmware update procedure is completed, change HttpPushUriTargetsBusy property to false, in order to release the service to other clients for firmware update.

```
The PATCH body is:
```

```
{
    "HttpPushUriTargetsBusy" : false
```

Resource FirmwareInventory

This resource shall be used to represent a single software component managed by this Redfish Service.

Number of Resources	Number of firmware entries managed
Resource Path	/redfish/v1/UpdateService/FirmwareInventory/{Id}
Schema file	SoftwareInventoryCollection_v1.xml
	SoftwareInventory_v1.xml

GET – Collection for firmware inventories on the server

Use the GET method to retrieve a firmware info list placed on the server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/UpdateService/FirmwareInventory

Response body

Field	Туре	Description
Members	Array	Items: A reference link of the elements of Firmware
Name	String	SoftwareInventoryCollection
Description	String	"Firmware Inventory Collection."

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/Slot_7.Bundle"
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/Ob_1.Bundle"
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/Ob 1.1"
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/Ob_1.2"
    },
    {
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/Ob 3.1"
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/Ob 4.1"
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/Ob_5.1"
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/Slot_7.1"
    },
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/PSU1"
"Members@odata.count": 15,
"@odata.type": "\#SoftwareInventoryCollection.SoftwareInventoryCollection",\\
"@odata.id": "/redfish/v1/UpdateService/FirmwareInventory",
"Members@odata.navigationLink": "/redfish/v1/UpdateService/FirmwareInventory/Members",
"@odata.etag": "\"2f84bcae162420f035fd84e6bb2d13a0\"",
"Name": "SoftwareInventoryCollection",
"Description": "Firmware Inventory Collection.",
"@odata.context": "/redfish/v1/$metadata#SoftwareInventoryCollection.SoftwareInventoryCollection"
```

GET – Firmware inventory properties

Use the GET method to retrieve each firmware info.

Request URL

}

GET https://<BMC_IPADDR>/redfish/v1/UpdateService/FirmwareInventory/{Id}

Response body

Field	Туре	Description
ld	String	The ld property uniquely identifies this firmware.
Description	String	Description for the firmware.
LowestSupportedVersion	String	A string representing the lowest supported version of this software.
Name	String	The name of this firmware.
RelatedItem	Array	URI of the resources associated with this software inventory item.
RelatedItem[N]	Object	Link to the manager resource.
Softwareld	String	A specific ID for identifying this firmware.

Field	Туре	Description
Manufacturer	String	A string representing the manufacturer/producer of this firmware.
ReleaseDate	String	Release date of this firmware.
Status	Object	Expanded.
HealthRollup	String	"OK".
Health	String	"OK"
State	String	The firmware indevtory status such as "Enabled", "Disabled", "StandbySpare".
Updateable	Boolean	Indicates whether the firmware is can be updated by redfish.
Version	String	The firmware version number. In order to be identified by management software, the Version property value can be different to the Version string displayed in Web or Legacy CLI.

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response describes the BMC (Primary) firmware information.

```
{
    "SoftwareId": "BMC-CDI3-10",
    "Updateable": true,
    "Name": "Firmware:BMC",
    "@odata.etag": "\"Od057295e35b9b29dda4595a90d7ac3f\"",
    "Version": "40M-3.00",
    "RelatedItem@odata.count": 1,
    "LowestSupportedVersion": null,
    "@odata.type": "#SoftwareInventory.v1_2_2.SoftwareInventory",
    "Id": "BMC-Primary",
    "RelatedItem": [
             "@odata.id": "/redfish/v1/Managers/1"
    ],
    "Status": {
        "Health": "OK",
        "HealthRollup": "OK",
        "State": "Enabled"
    "ReleaseDate": "2019-09-25T00:00:00Z",
    "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/BMC-Primary",
    "Manufacturer": "Lenovo",
    "Description": "The information of BMC (Primary) firmware."
}
```

The following example JSON response describes firmware information of a RAID adapter.

```
"SoftwareId": "DEVICE-1D490500-13",
```

```
"Updateable": true,
    "Name": "Firmware:DEVICE-ThinkSystem RAID 530-8i PCIe 12Gb Adapter",
    "@odata.etag": "\"dffae54e34119fe6bb7ce896633c58ae\"",
    "Version": "50.5.0-1510",
    "RelatedItem@odata.count": 1,
    "LowestSupportedVersion": null,
    "@odata.type": "#SoftwareInventory.v1_2_2.SoftwareInventory",
    "Id": "Slot_7.Bundle",
    "RelatedItem": [
        {
             "@odata.id": "/redfish/v1/Systems/1/PCIeDevices/slot 7"
        }
    "Status": {
        "Health": "OK",
         "HealthRollup": "OK",
         "State": "Enabled"
    "ReleaseDate": "2018-06-25T00:00:00Z",
    "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/Slot_7.Bundle",
    "Manufacturer": "AVAGO Technologies",
    "Description": "The information of ThinkSystem RAID 530-8i PCIe 12Gb Adapter firmware."
}
```

Chapter 18. Task Management

Resource TaskService

The resource represents a collection of tasks for the Redfish service. All existing tasks are accessible through the links from the TaskService resource.

Number of Resources	1
Resource Path	/redfish/v1/TaskService
Schema file	TaskService_v1.xml

GET – Task service properties

Use the GET method to retrieve properties in TaskService resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/TaskService

Request body

None

Response body

Field	Туре	Description
ld	String	"TaskService".
Name	String	"Task Service".
DateTime	String	The current DateTime (with offset) setting that the task service is using.
CompletedTaskOverWritePolicy	String	"Oldest".
ServiceEnabled	Boolean	This indicates whether this service is enabled.
		Value: True
Status	Object	Expanded.
State	String	"Enabled".
Health	String	"OK".
HealthRollup	String	"OK".
Tasks	Link	This property shall contain the link to a collection of type Task.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

© Copyright Lenovo 2017, 2020 229

```
{
    "Tasks": {
         "@odata.id": "/redfish/v1/TaskService/Tasks"
    "Id": "TaskService",
    "Status": {
         "HealthRollup": "OK",
         "Health": "OK",
"State": "Enabled"
    "Name": "Task Service",
    "ServiceEnabled": true,
    "DateTime": "2019-11-11T14:51:52+00:00",
    "@odata.type": "#TaskService.v1_1_3.TaskService",
    "CompletedTaskOverWritePolicy": "Oldest",
    "@odata.etag": "\"381031aeeabf8aa7d88a786db25df665\"",
    "@odata.id": "/redfish/v1/TaskService",
    "Description": "This resource represents a task service for a Redfish implementation."
}
```

Resource Task

The resource represents Task resource implementation for the Redfish service.

Number of Resources	Number of tasks available in Redfish service
Resource Path	/redfish/v1/TaskService/Tasks/{ld}
Schema file	Task_v1.xml

GET – Task properties

Use the GET method to retrieve properties in Task resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/TaskService/Tasks/{Id}

Request body

None

Response body

Field	Туре	Description
Id	String	The Id property uniquely identifies this task resource.
Name	String	Task {Id}.
Description	String	"This resource represents a task for a Redfish implementation."
StartTime	String	The date-time stamp that the task was last started.
EndTime	String	The date-time stamp that the task was last completed.
HidePayload	Boolean	This property shall indicate whether the contents of the payload should be hidden from view after the task has been created.
PercentComplete	Integer	This property shall indicate the completion progress of the task, reported in percent of completion.

Field	Туре	Description
TaskMonitor	Link	The URI of the Task Monitor for this task. It is a URI for deleting the task when the TaskState is Completed, Exception or Killed.
TaskState	String	The state of the task.
TaskStatus	String	The completion status of the task. The mapping between TaskState and TaskStatus: "Completed" (TaskState) -> "OK" (TaskStatus) "Killed" (TaskState) -> "Warning" (TaskStatus) "Exception" (TaskState) -> "Warning" (TaskStatus) Others (TaskState) -> Do not expose TaskStatus (TaskStatus)
Messages	Object	Expand.
Messages[N]	String	A message associated with the task

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"StartTime": "2019-11-12T15:05:12+00:00",
"@odata.id": "/redfish/v1/TaskService/Tasks/e809efa4-0e8f-48fc-86d9-6d4c5b0d2da0",
"Messages": [
    {
        "@odata.type": "#Message.v1_0_7.Message",
        "MessageArgs": [
            "e809efa4-0e8f-48fc-86d9-6d4c5b0d2da0"
        "Message": "The task with id e809efa4-0e8f-48fc-86d9-6d4c5b0d2da0 has completed.",
        "Severity": "OK",
        "Resolution": "None.",
        "MessageId": "TaskEvent.1.0.TaskCompletedOK"
    },
        "@odata.type": "#Message.v1_0_7.Message",
        "Message": "Successfully Completed Request",
        "MessageArgs": [
            null
        "Severity": "OK",
        "Resolution": "None",
        "MessageId": "Base.1.5.Success"
    },
        "@odata.type": "#Message.v1_0_7.Message",
        "MessageArgs": [
            "1",
            "/redfish/v1/Update Service/Firmware Inventory/BMC-Primary",\\
             "BMC-TEI3-10",
            "57B-1.20",
```

```
"57B-1.20"
            ],
             "Message": "Assignment 1: Resource /redfish/v1/UpdateService/FirmwareInventory/BMC-Primary
SoftwareID BMC-TEI3-10 Version 57B-1.20 to Version 57B-1.20.",
            "Severity": "OK",
            "Resolution": "None",
             "MessageId": "LenovoFirmwareUpdateRegistry.1.0.UpdateAssignment"
        },
            "@odata.type": "#Message.v1_0_7.Message",
             "Message": "Assignment 1: Apply complete",
             "MessageArgs": [
                 "1"
             "Severity": "OK",
             "Resolution": "None",
             "MessageId": "LenovoFirmwareUpdateRegistry.1.0.PayloadApplyCompleted"
    "Id": "e809efa4-0e8f-48fc-86d9-6d4c5b0d2da0",
    "HidePayload": true,
    "Name": "Task e809efa4-0e8f-48fc-86d9-6d4c5b0d2da0",
    "PercentComplete": 100,
    "TaskStatus": "OK",
    "TaskMonitor": "/redfish/v1/TaskService/fdcf8893-817e-4a6a-b990-264123ba4004",
    "TaskState": "Completed",
    "EndTime": "2019-11-12T15:06:33+00:00",
    "@odata.etag": "\"1573571193473\"",
    "@odata.type": "#Task.v1_4_1.Task",
    "Description": "This resource represents a task for a Redfish implementation."
}
```

Chapter 19. Event Service

Resource EventService

This Resource is used to represent event service for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/EventService
Schema file	EventService_v1.xml

GET – Event service properties

Use the GET method to retrieve properties in Event service resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/EventService

Request body

None

Response body

Field	Туре	Description
ld	String	"EventService"
Name	String	"Event Service"
ServiceEnabled	Boolean	TRUE
SSEFilterPropertiesSupported	Object	Expanded
EventType	Boolean	FALSE
ResourceType	Boolean	FALSE
EventFormatType	Boolean	TRUE
RegistryPrefix	Boolean	FALSE
OriginResource	Boolean	FALSE
MetricReportDefinition	Boolean	FALSE
Messageld	Boolean	FALSE
DeliveryRetryAttempts	Integer	3
DeliveryRetryIntervalSeconds	Integer	60 (Unit: seconds)
ResourceTypes	Array	A list of @odata.type values (Schema names) that can be specified in a ResourceType on a subscription.
ResourceTypes[N]	String	Array element of ResourceTypes
		Note: Alert event cannot be filtered by ResourceType
Actions	Object	Expanded

© Copyright Lenovo 2017, 2020 233

Field	Туре	Description
#EventService.SubmitTestEvent	Object	Refer to Actions
Status	Object	Expanded
State	String	"Enabled"
Health	String	"OK"
EventFormatTypes	Array	Item: string
		Item count: 2
EventFormatTypes[N]	String	Valid values: "Event", "MetricReport"
SubordinateResourcesSupported	Boolean	Indicate if the service supports the SubordinateResource property on Event Subscriptions
RegistryPrefixes	Array	Item: string
		Item count: maps to members under the resource /redfish/v1/ Registries
RegistryPrefixes[N]	String	Maps to members under the resource /redfish/v1/Registries
Subscriptions	Link	Reference to event subscriptions of EventDestinationCollection type
ServerSentEventUri	Link	"/redfish/v1/EventService/ServerSentEvent"

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "@odata.type": "#EventService.v1_3_0.EventService",
    "Actions": {
         "#EventService.SubmitTestEvent": {
             "target": "/redfish/v1/EventService/Actions/EventService.SubmitTestEvent",
             "title": "SubmitTestEvent"
        }
    },
    "Name": "Event Service",
    "ServiceEnabled": true,
    "@odata.etag": "\"a38f25daa8bb4c275b165abf5d8216c1\"",
    "ResourceTypes": [
         "AccountService",
        "VolumeCollection"
    ],
"SubordinateResourcesSupported": true,
    "Subscriptions": {
        "@odata.id": "/redfish/v1/EventService/Subscriptions"
    "RegistryPrefixes": [
        "Base",
        "EventRegistry",
```

```
"ExtendedError",
    "LenovoFirmwareUpdateRegistry",
    "ResourceEvent",
    "TaskEvent"
"DeliveryRetryIntervalSeconds": 60,
"DeliveryRetryAttempts": 3,
"Id": "EventService",
"Status": {
    "Health": "OK",
    "State": "Enabled"
"EventFormatTypes": [
    "Event",
    "MetricReport"
],
"SSEFilterPropertiesSupported": {
    "ResourceType": true,
    "RegistryPrefix": true,
    "SubordinateResources": true,
    "MetricReportDefinition": true,
    "MessageId": true,
    "OriginResource": true,
    "EventFormatType": true
"@odata.id": "/redfish/v1/EventService",
"Description": "This resource represents an event service for a Redfish implementation.",
"ServerSentEventUri": "/redfish/v1/EventService/ServerSentEvent"
```

POST - Submit a test event

Use the POST method to send a test event to subscribers.

Request URL

}

POST https://<BMC_IPADDR>/redfish/v1/EventService/Actions/EventService.SubmitTestEvent

Request body

Field	Туре	Error Message ID
EventType	String	The type of event to be added
EventId	String	The ID of event to be added
EventTimes- tamp	String	The time stamp of event to be added
Severity	String	The severity of event to be added
Message	String	The event message text of event to be added
Messageld	String	The message ID of event to be added
MessageArgs	Array	The array of message arguments of event to be added
OriginOfCondition	String	The URL in the OriginOfCondition property of the event to add. It is not a reference object.

Response

None

HTTP Status Code	Error Message ID
204	NoContent
500	InternalError

Example

The following example is POST body

```
{
    "OriginOfCondition": "/redfish/v1/Systems/1/LogServices/StandardLog",
    "Message":"Login ID: USERID from web at IP address 1.1.1.1 has logged off. ----Test Test",
    "MessageArgs":["USERID","web","1.1.1.1"],
    "Severity": "OK",
    "MessageId": "EventRegistry.1.0.FQXSPSE4032I",
    "EventTimestamp":"2018-12-31T00:00:00+00:00",
    "EventId": "000003a"
}
```

The following example JSON response is returned:

None

The following event data is received by a listener stays at the destination subscribed to Redfish service.

```
"Id" : "1",
   "Events" : [
          "EventTimestamp" : "2018-12-31T00:00:00+00:00",
          "MessageArgs" : [
             "USERID",
             "web",
             "1.1.1.1"
          "MemberId" : "0001"
          "OriginOfCondition" : {
             "@odata.id" : "/redfish/v1/Systems/1/LogServices/StandardLog"
          "MessageId" : "EventRegistry.1.0.FQXSPSE4032I",
          "EventGroupId" : 0,
          "EventId" : "0000003a",
          "Message" : "Login ID: USERID from web at IP address 192.168.0.2 has logged off. ----Test Test",
          "Severity" : "OK"
      }
   "@odata.type" : "#Event.v1_4_0.Event",
   "Events@odata.count" : 1,
   "Context" : "Test Context"
   "Name" : "SubmitTestEvent",
   "Description" : "This resource represents an event for a Redfish implementation."
}
```

Resource Event Subscription

This resource is used to provide event subscriptions for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/EventService/Subscriptions
	/redfish/v1/EventService/Subscriptions/{Subscription ID}
Schema file	EventDestination_v1.xml
	EventDestinationCollection_v1.xml

GET – Collection of event subscriptions

Use the GET method to retrieve the properties of event subscription collection resource for a server.

Request URL

 ${\tt GET\ https://<} BMC_IPADDR{\tt >/redfish/v1/EventService/Subscriptions}$

Request body

None

Response body

Field	Туре	Description
Members	Array	Items: A reference link of the elements of event subscriptions.
Name	String	"Subscriptions".

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"Members": [
             "@odata.id": "/redfish/v1/EventService/Subscriptions/EE116883"
    "@odata.type": "#EventDestinationCollection.EventDestinationCollection",
    "@odata.id": "/redfish/v1/EventService/Subscriptions",
    "Members@odata.count": 1,
    "@odata.etag": "\"1554223063641\"",
    "Name": "Subscriptions",
    "@odata.context": "/redfish/v1/$metadata#EventDestinationCollection.EventDestinationCollection"
}
```

GET – Event subscriptions

Use the GET method to retrieve properties in event subscription entries for a server.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/EventService/Subscriptions/{Subscription ID}

Request body

None

Response body

Field	Туре	Description
ld	String	Uniquely identifies the resource within the collection of the subscriptions.
Name	String	"Destination"
Description	String	"This resource represents the target of an event subscription, including the types of events subscribed and context to provide to the target in the Event payload."
Destination	String	This property shall contain a URI to the destination where the events will be sent.
Context	String	A client-supplied string that is stored with the event destination subscription.
Protocol	String	"Redfish"
HttpHeaders	Array	This is for setting HTTP headers, such as authorization information. This object will be null on a GET.
HttpHeaders[N]	Object	This is for setting HTTP headers, such as authorization information. This object will be null on a GET.
Messagelds	Array	A list of Messagelds that the service will only send. If this property is absent or the array is empty, then Events with any Messageld will be sent to the subscriber.
Messagelds[N]	String	Message Id that the service will send
SubordinateResources	Boolean	By setting this to true and specifying OriginResources, this indicates the subscription will be for events from the OriginsResources specified and also all subordinate resources
ResourceTypes	Array	A list of @odata.type values (Schema names) that can be specified in a ResourceType on a subscription.
ResourceTypes[N]	String	Array element of ResourceTypes
		Note: Alert event cannot be filtered by ResourceType
EventFormatType	String	Valid values: "Event", "MetricReport"
		(MetricReport type event is not supported yet)
RegistryPrefixes	Array	Item: string
		Item count: maps to members under the resource /redfish/v1/ Registries
RegistryPrefixes[N]	String	Maps to members under the resource /redfish/v1/Registries
OriginResources	Array	A list of resources for which the service will only send related events. If this property is absent or the array is empty, then Events originating from any resource will be sent to the subscriber.
OriginResources[N]	Link	Reference to the resource for which the service will only send related events.
SubscriptionType	String	Valid values: "RedfishEvent", "SSE"

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "HttpHeaders": [],
    "Id": "3A048D0E",
    "SubordinateResources": null,
    "Context": "Test_Context",
    "MessageIds": [],
    "EventFormatType": "Event",
    "ResourceTypes": [],
    "OriginResources@odata.count": 0,
    "Protocol": "Redfish",
    "Name": "Destination",
    "@odata.id": "/redfish/v1/EventService/Subscriptions/3A048D0E",
    "RegistryPrefixes": [
         "EventRegistry"
    ],
    "@odata.type": "\#EventDestination.v1\_5\_0. EventDestination",
    "SubscriptionType": "RedfishEvent",
    "Destination": "https://192.168.0.2:443",
    "@odata.etag": "\"1575571584025\"",
    "OriginResources": [],
    "Description": "This resource represents the target of an event subscription, including the types
of events subscribed and context to provide to the target in the Event payload."
```

POST - Create a subscription

Create a subscription for Redfish service to send event to subscriber.

Request URL

POST https://<BMC_IPADDR>/redfish/v1/EventService/Subscriptions

Request body

Field	Туре	Description
Destination	String	This property shall contain a URI to the destination where the events will be sent.
Context	String	A client-supplied string that is stored with the event destination subscription.
Protocol	String	"Redfish"
HttpHeaders	Array	This is for setting HTTP headers, such as authorization information. This object will be null on a GET.
HttpHeaders[N]	Object	This is for setting HTTP headers, such as authorization information. This object will be null on a GET.
Messagelds	Array	A list of Messagelds that the service will only send. If this property is absent or the array is empty, then Events with any Messageld will be sent to the subscriber.

Field	Туре	Description
Messagelds[N]	String	Message Id that the service will send
SubordinateResources	Boolean	By setting this to true and specifying OriginResources, this indicates the subscription will be for events from the OriginsResources specified and also all subordinate resources
ResourceTypes	Array	A list of @odata.type values (Schema names) that can be specified in a ResourceType on a subscription.
ResourceTypes[N]	String	Array element of ResourceTypes
		Note: Alert event cannot be filtered by ResourceType
EventFormatType	String	Valid values: "Event", "MetricReport"
		(MetricReport type event is not supported yet)
RegistryPrefixes	Array	Item: string
		Item count: maps to members under the resource /redfish/v1/Registries
RegistryPrefixes[N]	String	Maps to members under the resource /redfish/v1/Registries
OriginResources	Array	A list of resources for which the service will only send related events. If this property is absent or the array is empty, then Events originating from any resource will be sent to the subscriber.
OriginResources[N]	Link	Reference to the resource for which the service will only send related events.

Response body

It responds the created subscription resource, refer the response body of Event subscription with GET method.

Status code

HTTP Status Code	Error Message ID
201	Created
400	BadRequest, PropertyValueNotInList
500	InternalError

Example

```
The following example is POST body.
    "Protocol": "Redfish",
    "Context": "Test_Context",
    "Destination": "https://192.168.0.2:443",
    "RegistryPrefixes": [
        "EventRegistry"
    ]
}
The following example JSON response is returned:
{
    "HttpHeaders": [],
```

```
"Id": "F73991EF",
    "SubordinateResources": null,
    "Context": "Test_Context",
    "MessageIds": [],
    "MetricReportDefinitions@odata.count": 0,
    "EventFormatType": "Event",
    "ResourceTypes": [],
    "Description": "This resource represents the target of an event subscription, including the types
of events subscribed and context to provide to the target in the Event payload.",
    "DeliveryRetryPolicy": "SuspendRetries",
    "OriginResources@odata.count": 0,
    "Status": {
        "State": "Enabled"
    "Protocol": "Redfish",
    "MetricReportDefinitions": [],
    "Actions": {
        "#EventDestination.ResumeSubscription": {
             "title": "ResumeSubscription",
             "target": "/redfish/v1/EventService/Subscriptions/F73991EF/Actions/EventDestination.ResumeSubscription"
    "SubscriptionType": "RedfishEvent",
    "RegistryPrefixes": [
        "EventRegistry"
    "@odata.type": "#EventDestination.v1_6_0.EventDestination",
    "@odata.id": "/redfish/v1/EventService/Subscriptions/F73991EF",
    "Destination": "https://192.168.0.2:443",
    "@odata.etag": "\"1587349612305\"",
    "OriginResources": [],
    "Name": "Destination"
}
```

DELETE- Delete a subscription

Use the DELETE method to delete subscription resource for Redfish service. Remove a subscription created for event to send to client listener.

Request URL

DELETE https://<BMC_IPADDR>/redfish/v1/EventService/Subscriptions/{Subscription ID}

Request body

None

Response

None

Status code

HTTP Status Code	Error Message ID
204	NoContent
500	InternalError

Example

The following example is DELETE body

None

The following example JSON response is returned:

None

SSE subscription

Create a subscription of Server-Sent Events for Redfish service to send event to client and keep the connection open.

Request URL

```
POST https://<BMC_IPADDR>/{ServerSentEventUri}
```

ServerSentEventUri: as specified in ServerSentEventUri property of EventService.

Request body

None

Response body

None

Status code

None

Example

Subscribe SSE events - curl

The following example of curl command is to create SSE connection and receive events through the connection.

```
$ curl "https://192.168.0.1/redfish/v1/EventService/ServerSentEvent" -X GET -k -u USERID:PASSWORD
```

Subscribe SSE events - browser

Use a web browser (e.g. Chrome) to access URI of https://192.168.0.1/redfish/v1/EventService/ ServerSentEvent, and you will see browser displays the received events.

Event JSON data response

The following example JSON response is returned.

```
: stream keep-alive
id:2
data:{
data:
         "Events@odata.count": 1,
         "Id": "2",
data:
         "Events": [
data:
data:
data:
                  "MessageArgs": [
                      "USERID",
data:
                       "the standard password",
data:
```

```
"web".
data:
                       "192.168.0.2"
data:
data:
                  "Message": "Remote Login Successful. Login ID: USERID using the standard password from
data:
web at IP address 192.168.0.2.",
                  "EventGroupId": 0,
data:
                  "0em": {
data:
                       "SystemSerialNumber": "DSYM09X",
data:
                       "Lenovo": {
data:
data:
                           "ReportingChain": "",
data:
                           "IsLocalEvent": true,
data:
                           "RawDebugLogURL": ""
data:
                           "AffectedIndicatorLEDs": [
data:
                           "EventFlag": 0,
data:
                           "AuxiliaryData": "",
data:
                           "Source": "System",
data:
                           "FailingFRU": [
data:
data:
data:
                                    "FRUSerialNumber": "",
                                    "FRUNumber": ""
data:
data:
                                }
data:
                           "TSLVersion": "0",
data:
                           "RelatedEventID": "",
data:
data:
                           "Hidden": false,
                           "EventID": "0x400000e00000000",
data:
                           "EventSequenceNumber": 1616,
data:
                           "EventType": 0,
data:
                           "@odata.type": "#LenovoLogEntry.v1_0_0.StandardLogEntry",
data:
                           "LenovoMessageID": "Lenovo0014",
data:
                           "TotalSequenceNumber": 1965,
data:
                           "CommonEventID": "FQXSPSE4001I",
data:
data:
                           "Serviceable": "Not Serviceable"
data:
data:
                       "SystemMachineTypeModel": "7X05CT01WW",
                       "SystemUUID": "F0F63E94-8E25-11E8-9A5A-7ED30A5E2267"
data:
                  },
data:
                  "EventId": "16ED786F53C",
data:
                  "MemberId": "0001",
data:
                  "MessageId": "EventRegistry.1.0.FQXSPSE4001I",
data:
                  "Severity": "OK",
data:
data:
                  "OriginOfCondition": {
data:
                       "@odata.id": "/redfish/v1/Systems/1/LogServices/StandardLog"
data:
                  "EventTimestamp": "2019-12-05T19:26:16+00:00"
data:
              }
data:
data:
         ],
data:
         "@odata.type": "#Event.v1_4_0.Event",
data:
         "Name": "Redfish Event",
data:
         "Description": "This resource represents an event for a Redfish implementation."
data:}
: stream keep-alive
: stream keep-alive
```

Query SSE event subscription

GET https://192.168.0.1/redfish/v1/EventService/Subscriptions, and find the new subscription of SSE is in the collection.

In the example it is "/redfish/v1/EventService/Subscriptions/C8ECC924".

```
{
    "Members": [
        {
             "@odata.id": "/redfish/v1/EventService/Subscriptions/C8ECC924"
    "@odata.type": "#EventDestinationCollection.EventDestinationCollection",
    "@odata.id": "/redfish/v1/EventService/Subscriptions",
    "Members@odata.count": 1,
    "@odata.etag": "\"1554741700566\"",
    "Name": "Subscriptions",
    "@odata.context": "/redfish/v1/$metadata#EventDestinationCollection.EventDestinationCollection"
}
```

GET https://192.168.0.1/redfish/v1/EventService/Subscriptions/C8ECC924, and find the subscription properties.

```
{
    "HttpHeaders": [],
    "Id": "C8ECC924",
    "SubordinateResources": null,
    "Context": null,
    "MessageIds": [],
    "SubscriptionType": "SSE",
    "ResourceTypes": [],
    "OriginResources@odata.count": 0,
    "Protocol": "Redfish",
    "Name": "Destination",
    "RegistryPrefixes": [],
    "@odata.type": "#EventDestination.v1 5 O.EventDestination",
    "@odata.id": "/redfish/v1/EventService/Subscriptions/C8ECC924",
    "Description": "This resource represents the target of an event subscription, including the types
of events subscribed and context to provide to the target in the Event payload.",
    "@odata.etag": "\"1575573946737\"",
    "OriginResources": [],
    "EventFormatType": "Event"
}
```

Note: the "SubscriptionType" property value is "SSE", that means an SSE subscription.

Event

This Resource is used to represent event information for a Redfish implementation.

Number of Resources	N/A
Resource Path	N/A
Schema file	Event_v1.xml

Event properties

Properties in Event service resource for Redfish service.

Request URL

N/A

Request body

None

Response body

Field	Туре	Description
Id	String	Unique event Id
Name	String	"Redfish Event"
Context	String	A context can be supplied at subscription time. This property is the context value supplied by the subscriber.
Events	Array	Item: event record
		Item count: 1
Events[N]	Object	Expanded
EventType	String	This indicates the type of event sent, according to the definitions in the EventService.
EventId	String	This is a unique instance identifier of an event. Client provides the EventId when it is sent with SubmitTestEvent action.
EventTimestamp	String	This is time the event occurred.
Severity	String	Valid values:
		• "OK"
		"Warning"
		• "Critical"
Message	String	Message text
MessageId	String	This is the key for this message which can be used to look up the message in a message registry.
MessageArgs	Array	Array of message arguments
MessageArgs[N]	String	Message argument
OriginOfCondition	String	The Resource that originated the condition that caused the event to be generated. It's for resource of Platform/Audit log under /redfish/v1/ Systems/1/LogServices.

Status code

N/A

Example

The following is an example for event JSON data response:

```
"Id" : "2",
"Events" : [
      "EventTimestamp" : "2019-12-05T19:26:16+00:00",
      "MessageArgs" : [
```

```
"USERID",
             "the standard password",
             "web",
            "192.168.0.2"
         ],
          "Oem" : {
             "SystemUUID" : "F0F63E94-8E25-11E8-9A5A-7ED30A5E2267",
             "Lenovo" : {
                "IsLocalEvent" : true,
                "AffectedIndicatorLEDs" : [],
                "LenovoMessageID" : "Lenovo0014",
                "EventType" : 0,
                "RelatedEventID" : ""
                "RawDebugLogURL" : "",
                "AuxiliaryData" : "",
                "Source" : "System",
                "FailingFRU" : [
                   {
                       "FRUNumber" : "",
                       "FRUSerialNumber" : ""
                ],
                "EventSequenceNumber" : 1616,
                "EventFlag" : 0,
                "TSLVersion" : "O",
                "CommonEventID" : "FQXSPSE4001I",
                "TotalSequenceNumber" : 1965,
                "EventID" : "0x4000000e00000000",
                "Serviceable" : "Not Serviceable",
                "ReportingChain" : "",
                " @ odata.type" : "\#LenovoLogEntry.v1\_0\_0.StandardLogEntry", \\
                "Hidden" : false
             "SystemMachineTypeModel" : "7X05CT01WW",
             "SystemSerialNumber" : " DSYM09X"
         },
          "MemberId" : "0001"
          "OriginOfCondition" : {
             "@odata.id" : "/redfish/v1/Systems/1/LogServices/StandardLog"
          "MessageId" : "EventRegistry.1.0.FQXSPSE4001I",
          "EventGroupId" : 0,
          "EventId" : "16ED786F53C",
         "Message": "Remote Login Successful. Login ID: USERID using the standard password from web at
IP address 192.168.0.2.",
         "Severity" : "OK"
   ],
   "@odata.type" : "#Event.v1_4_0.Event",
   "Events@odata.count" : 1,
   "Context" : "Test Context",
   "Name" : "Redfish Event",
   "Description": "This resource represents an event for a Redfish implementation."
}
```

Chapter 20. Telemetry Management

Resource TelemetryService

This Resource is used to represent telemetry service for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/TelemetryService
Schema file	TelemetryService_v1.xml

GET – Telemetry service properties

Use the GET method to retrieve properties in Telemetry service resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/TelemetryService

Request body

None

Response body

Field	Туре	Description
Id	String	"TelemetryService".
Name	String	"Telemetry Service".
Description	String	"This resource shall be used to represent a Metrics Service for a Redfish implementation."
SupportedCollectionFunctions	Array	["Average", "Minimum", "Maximum"]
Status	Object	The status of the telemetry service.
State	String	The state of the telemetry service.
Health	String	The health of the telemetry service.
MetricDefinitions	Link	The link to the collection of metric definitions.
MetricReportDefinitions	Link	The link to the collection of metric report definitions.
MetricReports	Link	The link to the collection of metric reports.
Actions	Object	Expanded
#TelemetryService. SubmitTestMetricReport	Object	This action generates a metric report.
target	Link	Link to invoke action.
title	String	"SubmitTestMetricReport"
@Redfish.ActionInfo	Link	Link to the info of this action.

© Copyright Lenovo 2017, 2020 **247**

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "MetricReports": {
         "@odata.id": "/redfish/v1/TelemetryService/MetricReports"
    "@odata.id": "/redfish/v1/TelemetryService",
    "Status": {
         "State": "Enabled",
        "Health": "OK"
    "Name": "Telemetry Service",
    "SupportedCollectionFunctions": [
         "Average",
        "Minimum",
        "Maximum"
    ],
    "Id": "TelemetryService",
    "@odata.type": "#TelemetryService.v1_1_1.TelemetryService",
    "MetricDefinitions": {
         "@odata.id": "/redfish/v1/TelemetryService/MetricDefinitions"
    "MetricReportDefinitions": {
        "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions"
    "@odata.etag": "\"7913d34db76cc9af9c13306d210b0da7\"",
    "Actions": \{
         "#TelemetryService.SubmitTestMetricReport": {
             "target": "/redfish/v1/TelemetryService/Actions/TelemetryService.SubmitTestMetricReport",
             "@Redfish.ActionInfo": "/redfish/v1/TelemetryService/SubmitTestMetricReportActionInfo",
             "title": "SubmitTestMetricReport"
        }
    "Description": "This resource shall be used to represent a Metrics Service for a Redfish implementation."
}
```

GET – Action info of SubmitTestMetricReport

Use the GET method to retrieve properties in action info resource of SubmitTestMetricReport.

Request URL

GET https://<BMC_IPADDR>redfish/v1/TelemetryService/SubmitTestMetricReportActionInfo

Request body

None

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"@odata.type": "#ActionInfo.v1_1_0.ActionInfo",
    "Id": "SubmitTestMetricReport",
    "@odata.id": "/redfish/v1/TelemetryService/SubmitTestMetricReportActionInfo",
    "Parameters": [
             "Required": true,
             "Name": "MetricReportName",
             "DataType": "String"
        },
             "ObjectDataType": "#TelemetryService.v1_1_0.MetricValue",
             "Required": false,
             "Name": "GeneratedMetricReportValues",
             "DataType": "ObjectArray"
        }
    ],
    "Name": "SubmitTestMetricReport",
    "Description": "This action is used to generate a metric report."
}
```

POST – Submit a test Metric Report

Use the POST method to send a test metric report. User can open a SSE stream with filter "EventFormatType eq 'MetricReport'" for getting the test metric report.

Example:

https://sseuri?\$filter=EventFormatType eq 'MetricReport'

Request URL

GET https://<BMC_IPADDR>/redfish/v1/TelemetryService/Actions/TelemetryService.SubmitTestMetricReport

Request body

Field	Туре	Description	
MetricReportName	String	The name of the metric report in generated metric report.	
GeneratedMetri- cReportValues	Array	Items: object Item count: 0 – N	
GeneratedMetri- cReportValues[N]	Object	The content of the MetricReportValues in the generated metric report.	
MetricDefinition	Link	The link to the metric.	
Metricld	String	The metric definitions identifier for this metric.	
MetricProperty	String	The URI for the property from which this metric is derived.	
MetricValue	String	The metric value, as a string.	
Timestamp	String	The time when the metric value is obtained.	

Response

None

HTTP Status Code	Error Message ID
204	NoContent
500	InternalError

Example

The following example is POST body:

Resource MetricReportDefinition

This Resource is used to represent MetricReportDefinition for a Redfish implementation.

Number of Resources	6 or 8. (Depends on machine type)
Resource Path	/redfish/v1/TelemetryService/MetricReportDefinitions/{Id}
Schema file	MetricReportDefinitionCollection_v1.xml
	MetricReportDefinition_v1.xml

GET – Collection of MetricReportDefinition

Use the GET method to retrieve the properties MetricReportDefinition collection resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/TelemetryService/MetricReportDefinitions

Request body

None

Response body

Field	Туре	Description
Members	Array	Items: A reference link of the elements of MetricReportDefinition
Name	String	MetricReportDefinitions
Description	String	"A Collection of MetricReportDefinition resource instances."

Note: the collection of "MetricReportDefinition" may contain members below:

CPUTemp

CPUTempEvent

InletAirTemp

InletAirTempEvent

PowerMetrics

PowerMetricsEvent

PowerSupplyStats

PowerSupplyStatsEvent

CPUUtilizationStats

CPUUtilizationStatsEvent

MemoryUtilizationStats

MemoryUtilizationStatsEvent

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"@odata.etag": "\"60f9b36c0ad1d5903bfbf8286f763d51\"",
"Members@odata.count": 12,
"@odata.type": "#MetricReportDefinitionCollection.MetricReportDefinitionCollection",
"Description": "A Collection of MetricReportDefinition resource instances.",
"Name": "MetricReportDefinitions",
"@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions",
"Members": [
    {
        "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/CPUTemp"
    },
    {
        "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/CPUTempEvent"
        "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/InletAirTemp"
        "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/InletAirTempEvent"
    },
        "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/PowerMetrics"
    },
        "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/PowerMetricsEvent"
```

```
},
        {
             "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/PowerSupplyStats"
        },
        {
             "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/PowerSupplyStatsEvent"
        },
{
             "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/CPUUtilizationStats"
        },
{
             "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/CPUUtilizationStatsEvent"
        },
        {
             "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/MemoryUtilizationStats"
        },
             "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/MemoryUtilizationStatsEvent"
}
```

GET – MetricReportDefinition properties

Use the GET method to retrieve each MetricReportDefinition info.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/TelemetryService/MetricReportDefinitions/{Id}

Response body

Field	Туре	Description
ld	String	The identifier of this resource.
Description	String	"A set of metrics that are collected into a metric report."
Name	String	The name of this resource.
ReportTimespan	String	Specifies the timespan duration of the metric report.
MetricReportDefinitionType	String	Specifies when the metric report is generated.
ReportActions	Array	The set of actions to perform when a metric report is generated.
ReportUpdates	String	"AppendWrapsWhenFull" if this property exists.
AppendLimit	Integer	25920 if this property exists.
Metrics	Array	The list of metrics to include in the metric report.
Metrics[1]	Object	Specifies a metric to include in the metric report.
MetricProperties	String	The set of URIs for the properties on which this metric is collected.
CollectionTimeScope	String	The scope of time scope over which the function is applied.
CollectionDuration	String	The duration over which the function is computed.
Wildcards	Array	The set of wildcards and their substitution values for the entries in the MetricProperties property.
Status	Object	The status for this resource.

Field	Туре	Description
State	String	The state for this resource.
MetricReport	String	The location where the resultant metric report is placed.
Schedule	Object	The schedule for generating the metric report.
RecurrenceInterval	String	The amount of time until the next occurrence occurs.

HTTP Status Code	Error Message ID
500	InternalError

Example

The following examples JSON response describe the PowerMetrics and PowerMetricsEvent.

```
"Wildcards": [
        {
             "Name": "PWild",
             "Values": [
                 "0",
                 "1",
                 "2"
             ]
        }
    "ReportUpdates": "AppendWrapsWhenFull",
    "Metrics": [
        {
             "MetricProperties": [
                 "/redfish/v1/Chassis/1/Power#/PowerControl/{PWild}/PowerMetrics/MaxConsumedWatts",
                 "/redfish/v1/Chassis/1/Power#/PowerControl/{PWild}/PowerMetrics/AverageConsumedWatts",
                 "/redfish/v1/Chassis/1/Power#/PowerControl/{PWild}/PowerMetrics/MinConsumedWatts"
             ],
             "CollectionTimeScope": "Interval",
             "CollectionDuration": "PT30S"
        }
    ],
    "Description": "A set of metrics that are collected into a metric report.",
    "Name": "PowerMetrics",
    "ReportTimespan": "PT24H",
    "Id": "PowerMetrics",
    "@odata.etag": "\"648d59955bddcc7f09232753f8ea5f4b\"",
    "AppendLimit": 25920,
    "ReportActions": [
         "LogToMetricReportsCollection"
    "MetricReport": {
         "@odata.id": "/redfish/v1/TelemetryService/MetricReports/PowerMetrics"
    "@odata.type": "#MetricReportDefinition.v1_3_0.MetricReportDefinition",
    "Status": {
         "State": "Enabled"
    "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/PowerMetrics",
    "MetricReportDefinitionType": "OnRequest"
}
```

```
{
    "Wildcards": [
             "Name": "PWild",
             "Values": [
                  "0",
                  "1",
                  "2"
             ]
        }
    "ReportTimespan": "PT10M",
    "Metrics": [
        {
             "MetricProperties": [
                  "/redfish/v1/Chassis/1/Power#/PowerControl/{PWild}/PowerMetrics/MaxConsumedWatts",
                  "/redfish/v1/Chassis/1/Power#/PowerControl/{PWild}/PowerMetrics/AverageConsumedWatts",
                  "/redfish/v1/Chassis/1/Power#/PowerControl/{PWild}/PowerMetrics/MinConsumedWatts"
             "CollectionTimeScope": "Interval",
             "CollectionDuration": "PT30S"
    "Description": "A set of metrics that are collected into a metric report.",
    "Name": "PowerMetricsEvent",
    "Schedule": {
         "RecurrenceInterval": "PT10M"
    "Id": "PowerMetricsEvent",
    "@odata.etag": "\"ffb0baa73f2c9f39bb6fa63236a919d7\"",
    "ReportActions": [
        "RedfishEvent"
    "@odata.type": "#MetricReportDefinition.v1 3 O.MetricReportDefinition",
         "State": "Enabled"
    "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/PowerMetricsEvent",
    "MetricReportDefinitionTupe": "Periodic"
}
```

Resource MetricReport

This Resource is used to represent MetricReport for a Redfish implementation.

Number of Resources	3 or 4. (Depends on machine type)
Resource Path	/redfish/v1/TelemetryService/MetricReports/{Id}
Schema file	MetricReportCollection_v1.xml
	MetricReport_v1.xml

GET - Collection of MetricReport

Use the GET method to retrieve the properties MetricReport collection resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/TelemetryService/MetricReports

Request body

None

Response body

Field	Туре	Description
Members	Array	Items: A reference link of the elements of MetricReport
Name	String	MetricReports
Description	String	"A Collection of MetricReport resource instances."

Note: the collection of "MetricReport" may contain members below:

CPUTemp

InletAirTemp

PowerMetrics

PowerSupplyStats

CPUUtilizationStats

MemorytilizationStats

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"@odata.etag": "\"9163997f4a80e72089a9d2e8e6f0af45\"",
"Members@odata.count": 6,
"@odata.type": "#MetricReportCollection.MetricReportCollection",
"Description": "A Collection of MetricReport resource instances.",
"Name": "MetricReports",
"@odata.id": "/redfish/v1/TelemetryService/MetricReports",
"Members": [
        "@odata.id": "/redfish/v1/TelemetryService/MetricReports/CPUTemp"
    },
    {
        "@odata.id": "/redfish/v1/TelemetryService/MetricReports/InletAirTemp"
    },
    {
        "@odata.id": "/redfish/v1/TelemetryService/MetricReports/PowerMetrics"
    },
        "@odata.id": "/redfish/v1/TelemetryService/MetricReports/PowerSupplyStats"
```

```
},
        {
             "@odata.id": "/redfish/v1/TelemetryService/MetricReports/CPUUtilizationStats"
        },
        {
             "@odata.id": "/redfish/v1/TelemetryService/MetricReports/MemoryUtilizationStats"
}
```

GET – MetricReport properties

Use the GET method to retrieve each MetricReport info.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/TelemetryService/MetricReports/{Id}

Response body

Field	Туре	Description
ld	String	The identifier of this resource.
Description	String	"The metric definitions used to create a metric report."
Name	String	The name of this resource.
ReportSequence	String	The current sequence identifier for this metric report.
Timestamp	String	The time associated with the metric report in its entirety.
MetricReportDefinition	Link	The definitions in the metric report.
MetricValues	Array	An array of metric values for the metered items of this Metric.
MetricValues[N]	Object	A metric Value.
MetricDefinition	Link	The link to the metric.
Metricld	String	The metric definitions identifier for this metric.
MetricProperty	String	The URI for the property from which this metric is derived.
MetricValue	String	The metric value, as a string.
Timestamp	String	The time when the metric is obtained.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "ReportSequence": "1",
    "Name": "PowerMetrics",
    "MetricValues": [
        {
             "MetricValue": "242",
             "Timestamp": "2020-03-21T09:34:30+00:00",
```

```
"MetricProperty": "/redfish/v1/Chassis/1/Power#/PowerControl/0/PowerMetrics/MaxConsumedWatts"
        },
             "MetricValue": "223",
             "Timestamp": "2020-03-21T09:34:30+00:00",
             "MetricProperty": "/redfish/v1/Chassis/1/Power#/PowerControl/O/PowerMetrics/MinConsumedWatts"
        },
             "MetricValue": "230",
             "Timestamp": "2020-03-21T09:34:30+00:00",
             "MetricProperty": "/redfish/v1/Chassis/1/Power#/PowerControl/O/PowerMetrics/AverageConsumedWatts"
        },
    "MetricReportDefinition": {
        "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions/PowerMetrics"
    "Id": "PowerMetrics",
    "Timestamp": "2020-03-21T09:34:57+00:00",
    "@odata.etag": "\"e941767245f49ddcf2707ee0ba3f9252\"",
    "@odata.type": "#MetricReport.v1 2 O.MetricReport",
    "Description": "The metric definitions used to create a metric report.",
    "MetricValues@odata.count": 25920,
    "@odata.id": "/redfish/v1/TelemetryService/MetricReports/PowerMetrics"
}
```

Resource Metric Definition

This Resource is used to represent MetricDefinition for a Redfish implementation.

Number of Resources	0 or 2. (Depends on machine type)
Resource Path	/redfish/v1/TelemetryService/MetricDefinitions/{Id}
Schema file	MetricDefinitionCollection_v1.xml
	MetricDefinition_v1.xml

GET – Collection of Metric Definition

Use the GET method to retrieve the properties MetricDefinition collection resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/TelemetryService/MetricDefinitions

Request body

None

Response body

Field	Туре	Description
Members	Array	Items: A reference link of the elements of MetricDefinition
Name	String	MetricDefinitions
Description	String	"A Collection of MetricDefinition resource instances."

Note: the collection of "MetricDefinition" may contain members below:

AveragePowerSupplyInput,

AveragePowerSupplyOutput,

AverageCPUUtilization

AverageMemoryUtilization

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "Name": "MetricDefinitions",
    "@odata.etag": "\"52b424e502c413c3426d0b430b95c9a1\"",
    "Members@odata.count": 4,
    "@odata.type": "#MetricDefinitionCollection.MetricDefinitionCollection",
    "Description": "A Collection of MetricDefinition resource instances.",
    "@odata.id": "/redfish/v1/TelemetryService/MetricDefinitions",
    "Members": [
        {
             "@odata.id": "/redfish/v1/TelemetryService/MetricDefinitions/AveragePowerSupplyInput"
        },
        {
             "@odata.id": "/redfish/v1/TelemetryService/MetricDefinitions/AveragePowerSupplyOutput"
        },
        {
             "@odata.id": "/redfish/v1/TelemetryService/MetricDefinitions/AverageCPUUtilization"
        },
        {
             "@odata.id": "/redfish/v1/TelemetryService/MetricDefinitions/AverageMemoryUtilization"
}
```

GET – MetricDefinition inventory properties

Use the GET method to retrieve each MetricDefinition info.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/TelemetryService/MetricDefinitions/{Id}

Response body

Field	Туре	Description
ld	String	The identifier of this resource.
Description	String	The metadata information about a metric.
Name	String	The name of this resource.
MetricType	String	The type of metric.
Implementation	String	The implementation of the metric.

Field	Туре	Description
PhysicalContext	String	The physical context of the metric.
MetricDataType	String	The data type of the metric.
Units	String	The units of measure for this metric.
CalculationAlgorithm	String	The calculation that is performed on a source metric to obtain the metric being defined.
CalculationTimeInterval	String	The time interval over which the metric calculation is performed.
IsLinear	Boolean	An indication of whether the metric values are linear versus non-linear.
Calculable	String	An indication of whether the metric can be used in a calculation.
Wildcards	Array	The wildcards and their substitution values for the entries in the MetricProperties array property.
MetricProperties	Array	The list of URIs with wildcards and property identifiers that this metric definition defines.

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"Wildcards": [
             "Name": "PWild",
             "Values": [
                 "O",
                 "1",
                 "2",
                 "3"
         }
    "CalculationTimeInterval": "PT1S",
    "Description": "The metadata information about a metric.",
    "MetricType": "Numeric",
    "PhysicalContext": "PowerSupply",
    "CalculationAlgorithm": "Average",
    "Name": "AveragePowerSupplyInput",
    "IsLinear": true,
    "MetricDataType": "Integer",
    "Id": "AveragePowerSupplyInput",
    "MetricProperties": [
         "/redfish/v1/Chassis/1/Power#/PowerSupplies/{PWild}/PowerInputWatts"
    "@odata.etag": "\"31db0d95174de283fa99ca3a69891e2c\"",
    "Calculable": "NonSummable",
    "Implementation": "Calculated",
    "@odata.type": "#MetricDefinition.v1_0_3.MetricDefinition",
    "@odata.id": "/redfish/v1/TelemetryService/MetricDefinitions/AveragePowerSupplyInput",
    "Units": "W"
}
```

Chapter 21. Job Management

Resource JobService

The resource represents a collection of jobs for the Redfish service. All job resources accessible through the interface link from the JobService resource.

Number of Resources	1
Resource Path	/redfish/v1/JobService
Schema file	JobService_v1.xml

GET - Job management properties

Use the GET method to retrieve properties in JobService resource for Redfish service

Request URL

GET https://<BMC_IPADDR>/redfish/v1/JobService

Request body

None

Response body

Field	Туре	Description
Descrip- tion	String	The resource is used to represent the Job Service that allows scheduling of operations.
DateTime	String	The current DateTime setting of the Service with offset from UTC.
		Format: YYYY-MM-DDThh:mm:ss[+-]HH:MM
ld	String	Fixed string "JobService"
Jobs	Link	References to the Job collection.
Name	String	Fixed string "Job Service"
Service- Capabili- ties	Object	This type shall contain properties which describe the capabilities or supported features of this implementation of JobService.
Max- Jobs	Integer	Maximum number of Jobs supported. Value is 3.
Max- Steps	Integer Null	Maximum number of Job Steps supported. Value is null.
Sched- uling	Boolean	The value of this property shall indicate the support of scheduling of Jobs using the Schedule object within the Job resource.
Service- Enabled	Boolean	The value of this property shall be a boolean indicating whether this service is enabled.
Status	Object	This property shall specify a valid odata or Redfish property.
Health	String	This represents the health state of this resource in the absence of its dependent resources.

© Copyright Lenovo 2017, 2020 261

Field Type		Туре	Description
	Health- Rollup	String	This represents the overall health state from the view of this resource.
	State	String	This indicates the known state of the resource, such as if it is enabled.

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"Id": "JobService",
    "Status": {
         "HealthRollup": "OK",
         "Health": "OK",
         "State": "Enabled"
    "Name": "Job Service",
    "ServiceEnabled": true,
    "ServiceCapabilities": {
        "MaxJobs": 3,
         "Scheduling": true,
        "MaxSteps": null
    "DateTime": "2020-04-02T05:34:24+00:00",
    "@odata.type": "#JobService.v1 0 2.JobService",
    "@odata.id": "/redfish/v1/JobService",
    "@odata.etag": "\"3d92d9405f98da92492a90a1b8bb9a08\"",
    "Jobs": {
        "@odata.id": "/redfish/v1/JobService/Jobs"
    "Description": "The resource is used to represent the Job Service that allows scheduling of operations."
}
```

Resource Job

The resource represents a job implementation for the Redfish service.

Number of Resources	Number of jobs estabilished	
Resource Path	/redfish/v1/JobService/Jobs/{PowerOff, PowerOn, Restart}	
Schema file	Session_v1.xml, Schedule_v1.xml	

GET – Job properties

Use the GET method to retrieve properties in Job resource for Redfish service

Request URL

GET https://<BMC_IPADDR>/v1/JobService/Jobs/{PowerOff, PowerOn, Restart}

Request body

None

Response body

Field	Туре	Description
Description	String	The resource is used to represent the settings of scheduled {Power Off Power On Restart} actions for a Redfish implementation.
HidePayload	Boolean	An indication of whether the contents of the payload should be hidden from view after the job has been created. If `true`, responses do not return the payload. If `false`, responses return the payload. If this property is not present when the job is created, the default is `false`.
ld	String	PowerOff, PowerOn, Restart
JobState	String	This property shall indicate the state of the job.
JobStatus	String	This property shall indicate the health status of the job.
MaxExecutionTime	String	The maximum amount of time the job is allowed to execute.
	Null	
Messages	Array	Items: object Item count: 0~1
Messages[N]	Object	An array of messages associated with the job.
Name	String	PowerOff, PowerOn, Restart
PercentComplete	Integer	The completion percentage of this job.
	Null	
Schedule	Object	The schedule settings for this job.
EnabledDaysOfWeek	Array	Expand.
EnabledDaysOfWeek [N]	String	Days of the week when scheduled occurrences are enabled, for enabled days of the month and months of the year. If not present, all days of the week are enabled.
EnabledDaysOf- Week@Redfish. AllowableValues	Array	Items: string Item count: 8
EnabledDaysOf- Week@Redfish. AllowableValues[N]	String	"Monday", "Tuesday", "Wednesday", "Thursday", "Friday", "Saturday", "Sunday", "Every"
InitialStartTime	Date- Time	The date and time when the initial occurrence is scheduled to occur.
RecurrenceInterval	String	The amount of time until the next occurrence occurs.
Name	String	The name of the schedule. Value: "Lenovo:{Power Off Power On Restart}"
StepOrder Array		The serialized execution order of the job Steps.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "MaxExecutionTime": null,
    "JobStatus": "OK",
    "Id": "Restart",
    "@odata.id": "/redfish/v1/JobService/Jobs/Restart",
    "HidePayload": true,
    "Messages": [],
    "PercentComplete": null,
    "StepOrder": [],
    "@odata.type": "#Job.v1_0_3.Job",
    "JobState": "Suspended",
    "Name": "Restart",
    "@odata.etag": "\"41754a37fca8f52fe536e42dbcf4c544\"",
    "Schedule": {
         "RecurrenceInterval": null,
        "InitialStartTime": null,
         "EnabledDaysOfWeek@Redfish.AllowableValues": [
             "Monday",
             "Tuesday",
             "Wednesday",
             "Thursday",
             "Friday",
             "Saturday",
             "Sunday",
             "Every"
        "Name": "Lenovo:Restart",
        "EnabledDaysOfWeek": []
    "Description": "The resource is used to represent the settings of scheduled Restart actions for a
Redfish implementation."
```

PATCH – Update Schedule properties

Use the PATCH method to update properties in Job resource for Redfish service

Request URL

GET https://<BMC_IPADDR>/redfish/v1/JobService/Jobs/{PowerOff, PowerOn, Restart}

Request body

Properties to be updated are shown as bellow, all of these properties can be changed individually.

Field	Туре	Description
Schedule	Object	The schedule settings for this job.
Enable- dDaysOf- Week	Array	Expand.
Enable- dDaysOf- Week[N]	String	Days of the week when scheduled occurrences are enabled, for enabled days of the month and months of the year. If not present, all days of the week are enabled.
InitialStart- Time	Date-time	The date and time when the initial occurrence is scheduled to occur.

Response body

The response returns same content as GET operation with updated properties.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

{

}

```
The following example is PATCH body
```

```
{
     "Schedule": {
          "InitialStartTime": null,
          "EnabledDaysOfWeek": [
              "Monday",
"Tuesday",
              "Wednesday",
              "Thursday",
              "Friday"
         ]
     }
}
```

The following example JSON response is returned:

```
"MaxExecutionTime": null,
    "JobStatus": "OK",
    "Id": "Restart",
    "@odata.id": "/redfish/v1/JobService/Jobs/Restart",
    "HidePayload": true,
    "Messages": [],
    "PercentComplete": null,
    "StepOrder": [],
    "@odata.type": "#Job.v1_0_3.Job",
    "JobState": "Suspended",
    "Name": "Restart",
    "@odata.etag": "\"41754a37fca8f52fe536e42dbcf4c544\"",
    "Schedule": {
         "RecurrenceInterval": null,
         "InitialStartTime": null,
         "EnabledDaysOfWeek@Redfish.AllowableValues": [
             "Monday",
             "Tuesday",
             "Wednesday",
             "Thursday",
             "Friday",
             "Saturday",
             "Sunday",
             "Every"
        ],
"Name": "Lenovo:Restart",
         "EnabledDaysOfWeek": []
    "Description": "The resource is used to represent the settings of scheduled Restart actions for a
Redfish implementation."
```

Chapter 22. Certificate Management

Resource CertificateService

This resource is used to represent the certificate service for a Redfish implementation.

Number of Resources	1
Resource Path	/redfish/v1/Systems/1/ CertificateService
Schema file	CertificateService_v1.xml

GET – Certificate service properties

Use the GET method to retrieve properties in CertificateService resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/CertificateService

Request body

None

Response body

Field		Туре	Description
I	d	String	"CertificateService"
1	Name	String	"Certificate Service"
[Description	String	"This resource is used to represent a certificate service for a Redfish implementation."
	CertificateLocations	Link	The information about the location of certificates.
7	Actions	Object	Expanded.
	#CertificateService. GenerateCSR	Object	This action makes a certificate signing request.
	KeyUsage@Redfish. AllowableValues	Array	["DigitalSignature", "NonRepudiation", "KeyEncipherment"]
	KeyCurveld@Red- fish.AllowableValues	Array	["TPM_ECC_NIST_P384"]
	KeyPairAlgorithm@- Redfish. AllowableValues	Array	["TPM_ALG_ECDH"]
	#CertificateService. ReplaceCertificate	Array	This action replaces a certificate.
	CertificateType@R-edfish. AllowableValues	Array	["PEM"]

© Copyright Lenovo 2017, 2020 267

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
{
    "Actions": {
         "#CertificateService.GenerateCSR": {
              "KeyUsage@Redfish.AllowableValues": [
                  "DigitalSignature",
                  "NonRepudiation",
                  "KeyEncipherment"
             "target": "/redfish/v1/CertificateService/Actions/CertificateService.GenerateCSR",
             "title": "Generate a CSR file.",
             "KeyCurveId@Redfish.AllowableValues": [
                  "TPM ECC NIST P384"
              "KeyPairAlgorithm@Redfish.AllowableValues": [
                  "TPM ALG ECDH"
         },
         "#CertificateService.ReplaceCertificate": {
             "target": "/redfish/v1/CertificateService/Actions/CertificateService.ReplaceCertificate",
             "title": "Replace an existing certificate.",
             "CertificateType@Redfish.AllowableValues": [
                  "PEM"
         }
    },
    "@odata.id": "/redfish/v1/CertificateService",
    "@odata.type": "#CertificateService.v1_0_2.CertificateService",
    "Id": "CertificateService",
    "CertificateLocations": {
         "@odata.id": "/redfish/v1/CertificateService/CertificateLocations"
    "@odata.etag": "\"74957388648d2a308f8\"",
    "Name": "Certificate Service",
    "Description": "This resource is used to represent a certificate service for a Redfish implementation."
}
```

POST – Generate CSR

Use the POST method to generate a certificate signing request.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/CertificateService/Actions/CertificateService.GenerateCSR

Request body

Field	Туре	Description	
Certificate- Collection Certificate Object Collection Collection Required. The link to the certificate collection where the certificate is installed a certificate authority (CA) signs the certificate.		Required. The link to the certificate collection where the certificate is installed after the certificate authority (CA) signs the certificate.	
@odata.id	Link	Required. Allowable value: "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates"	

Field	Туре	Description	
Country	String	Required. The two-letter country code of the organization making the request.	
City	String	Required. The city or locality of the organization making the request.	
Common- String Required. The fully qualified domain name of the component to secure Name		Required. The fully qualified domain name of the component to secure.	
State	String	Required. The state, province, or region of the organization making the request.	
Organization	String	Required. The name of the organization making the request.	
Alternative- Names	Array	Optional. The additional host names of the component to secure.	
KeyUsage	Array	Optional. The usage of the key contained in the certificate.	
KeyUsage [N]	String	Any of "DigitalSignature", "NonRepudiation" or "KeyEncipherment".	
Challenge- Password	String	Optional. The challenge password to apply to the certificate for revocation requests.	
ContactPer- son	String	Optional. The name of the user making the request.	
Email	String	Optional. The email address of the contact within the organization making the request.	
GivenName	String	Optional. The given name of the user making the request.	
Initials	String	Optional. The initials of the user making the request.	
KeyCurveld	String	Optional. The curve ID to use with the key, if needed based on the KeyPairAlgorithm parameter value.	
KeyPairAl- gorithm	String	Optional. The type of key-pair for use with signing algorithms.	
Organizatio- nalUnit	String	Optional. The name of the unit or division of the organization making the request.	
Surname	String	Optional. The surname of the user making the request.	
Unstructur- edName	String	Optional. The unstructured name of the subject.	

Response body

Field	Туре	Description	
CSRString	String	The string for the certificate signing request.	
Certificate- Collection	Link	The link to the certificate collection where the certificate is installed.	

Status code

HTTP Status Code	Error Message ID
400	BadRequest, ActionParamMissing , ActionParamTypeError , ActionParamFormatError
500	InternalError

Example

The POST body is filled as below:

```
{
    "CertificateCollection": {
        "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates"
    "Country": "CN",
    "City": "SH",
    "CommonName": "XCC-7Z60-SN",
    "State": "SH"
    "Organization": "Lenovo"
}
The following example JSON response is returned.
{
    "CertificateCollection": {
        "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates"
    "CSRString": "----BEGIN CERTIFICATE REQUEST-----\nMIICFDCCAZsCAQAwTjELMAkGA1UEBhMCQO4xCzAJBgNVBAgMAL
NIMQswCQYDVQQHDAJTSDEPMAOGA1UECgwGTGVub3ZvMRQwEgYDVQQDDAtYQOMtN1o2MC1TTjB2MBAGByqGSM49AgEGBSuBBAAiA2IABOR
bulFysxyzVYaYLy4qcUllJS3fWWLPdRimFsIlrrtdoRsrDEV2B7ChQRdpvNpDr3YFVySIlIPIRUNn1wRob9vSiTb2huXBB2sP5mUh1i5v
oUVwohSAd5mLSOqLKAj7OaCBzTCByqYJKoZIhvcNAQkOMYG8MIG5MAkGA1UdEwQCMAAwCwYDVROPBAQDAqXqMIGeBqNVHREEqZYwqZOCC
1hDQyO3WjYwLVNOhxD+gAAAAAAAAAAQU7//+q5mzgilmZTgwLS1hOTQtZWZmZi1mZWFiLTK5YjMuaXB2Ni1saXRlcmFsLm5ldIcECmjFSI
cQ/oAAAAAAAAKlO///quZtIIpZmU4MCOtYTkOLWVmZmYtZmVhYiO5OWIOLmlwdjYtbGlOZXJhbC5uZXSHBKn+X3YwCgYIKoZIzjOEAwI
DZwAwZAIwdCdbejk+ai7nKL6gz7IE2jHTXux0GzqioC10lQ0qQAt0p4fhcM/4Gt4+w1HfxnrEAjBzIoYSls0iLYxb0jGIJVcBg9liB0qT
bYHXPSK5WaawdKnTo6OC+jPUJr2Z5PPDB5Q=\n----END CERTIFICATE REQUEST----"
}
```

POST - Replace Certificate

Use the POST method to replace a certificate.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/CertificateService/Actions/CertificateService.ReplaceCertificate

Request body

Field	Туре	Description
CertificateUri	Object	Required. The link to the certificate that is being replaced.
CertificateType	String	Required. The format of the certificate. Only allow "PEM".
CertificateString	String	Required. The string for the certificate. Line breaks should be replaced to "\n" in this parameter.

Response body

Status code

HTTP Status Code	Error Message ID
400	BadRequest, ActionParamMissing , ActionParamTypeError , ActionParamFormatError
500	InternalError

Example

The POST body is filled as below:

{

```
"CertificateUri": {
        "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates/1"
    "CertificateType": "PEM",
    "CertificateString": "-----BEGIN CERTIFICATE-----\n.MIIEhTCCA2... HoKwFzKGxRyrsQ \n-----END CERTIFICATE-----"
}
```

The following example JSON response is returned.

None.

Resource CertificateLocations

This resource is used to represent all certificates installed on a given service.

Number of Resources	1
Resource Path	/redfish/v1/Systems/1/CertificateService/ CertificateLocations
Schema file	CertificateLocations_v1.xml

GET – Certificate locations properties

Use the GET method to retrieve properties in CertificateLocations resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/CertificateService/CertificateLocations

Request body

None

Response body

Field	Туре	Description
ld	String	"CertificateLocations"
Name	String	" Certificate Locations"
Description	String	"This resource is used to represent the collection of certificate locations for a Redfish implementation."
CertificateLocations	Link	The information about the location of certificates.
Links	Object	Expanded.
Certificates	Array	An array of links to the certificates installed on this service.

Status code

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

{

```
"Id": "CertificateLocations",
    "@odata.type": "#CertificateLocations.v1_0_2.CertificateLocations",
    "@odata.id": "/redfish/v1/CertificateService/CertificateLocations",
    "@odata.etag": "\"362ae2eb99a12a2722d\"",
    "Links": {
         "Certificates": [
             {
                 "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates/1"
    },
    "Name": "Certificate Locations",
    "Description": "This resource is used to represent the collection of certificate locations for a
Redfish implementation."
```

Resource Certificate

This resource is used to represent all certificate that proves the identify of a component, account, or service.

Number of Resources	N. Depends on how many certificates installed in the system.
Resource Path	/redfish/v1/Managers/1/NetworkProtocol/HTTPS/ Certificates /redfish/v1/AccountService/LDAP/Certificates
	/rediish/vi/AccountService/LDAP/Certificates
Schema file	Certificate_v1.xml

GET - Certificate properties

Use the GET method to retrieve properties in Certificate resource for Redfish service.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates/{id} GET https://<BMC_IPADDR>/redfish/v1/AccountService/LDAP/Certificates/{id}

Request body

None

Response body

F	ield	Туре	Description
lc	I	String	The idex of this certificate resource.
N	ame	String	The name of this certificate resource.
D	escription	String	"This resource is used to represent the certificate for a Redfish implementation."
Α	ctions	Object	Available for /redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates/{id}
	#Certificate.Rekey	Object	This action generates a new key-pair for a certificate and produces a certificate signing request.
	KeyCurveld@Red- fish.AllowableValues	Array	["TPM_ECC_NIST_P384"].

Field	Туре	Description
KeyPairAlgorithm@- Redfish. AllowableValues	Array	["TPM_ALG_ECDH"].
#Certificate.Renew	Object	This action generates a certificate signing request by using the existing information and key-pair of the certificate.
CertificateString	String	The string for the certificate.
CertificateType	String	The format of the certificate. Only supports "PEM".
Issuer	Object	The issuer of the certificate.
City	String	The city or locality of the organization of the entity.
CommonName	String	The fully qualified domain name of the entity.
Country	String	The country of the organization of the entity.
Email	String	The email address of the contact within the organization of the entity.
Organization	String	The name of the organization of the entity.
OrganizationalUnit	String	The name of the unit or division of the organization of the entity.
State	String	The state, province, or region of the organization of the entity.
ValidNotBefore	String	The date when the certificate becomes valid.
ValidNotAfter	String	The date when the certificate is no longer valid.

HTTP Status Code	Error Message ID
500	InternalError

Example

The following example JSON response is returned:

```
"ValidNotAfter": "2029-12-17T01:51:18+00:00",
"@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates/1",
"KeyUsage": [
    "DigitalSignature",
    "NonRepudiation",
    "KeyEncipherment"
"Id": "1",
"Name": "Certificate_HTTPS",
"CertificateType": "PEM",
"@odata.etag": "\"eed23a10000d2d28c9cbd\"",
"Subject": {
    "Organization": "Lenovo",
    "Country": "US",
    "City": "RTP",
    "CommonName": "XCC-7Z60-SN",
    "State": "NC"
"@odata.type": "#Certificate.v1_1_1.Certificate",
"ValidNotBefore": "2019-12-20T01:51:18+00:00",
"Issuer": {
```

```
"Organization": "Lenovo",
        "Country": "US",
        "City": "RTP",
        "CommonName": "XCC-7Z60-SN",
        "State": "NC"
    "CertificateString": "-----BEGIN CERTIFICATE-----\nMIIClTCCAhqgAwIBAgIUfjeBVwa2nDdgtHJxWPn1pn/ZabcwC
gYIKoZIzjOEAwIwTzELMAkGA1UEBhMCVVMxCzAJBgNVBAgMAk5DMQwwCgYDVQQHDANSVFAxDzANBgNVBAoMBkxlbm92bzEUMBIGA1UEAw
wLWENDLTdanjAtU04wHhcNMTkxMjIwMDE1MTE4WhcNMjkxMjE3MDE1MTE4WjBPMQswCQYDVQQGEwJVUzELMAkGA1UECAwCTkMxDDAKBqN
VBAcMA1JUUDEPMA0GA1UECqwGTGVub3ZvMRQwEqYDVQQDDAtYQ0MtN1o2MC1TTjB2MBAGBuqGSM49AqEGBSuBBAAiA2IABAoScPNA/aeC
9MR9j+8wdKVW9F/+LoaNrXH4OvIB4bN7sWMBdcm8/1oF2yknMR87OTf9rtbdb5Wlbf9h+86N96vAYv0hJ1nUD9LtosCtppp/7ULDnNfSp
NRfXoZ1uSnP4aOBtjCBszAJBqNVHRMEAjAAMAsGA1UdDwQEAwIF4DCBmAYDVRORBIGQMIGNqqtYQOMtN1o2MC1TTocQ/oAAAAAAAAAKlO
///q9on4IpZmU4MC0tYTk0LWVmZmYtZmVhZi00ZTlmLmlwdjYtbGl0ZXJhbC5uZXSHEP6AAAAAAAACpTv//6vTqCCKWZl0DAtLWE5NC1
lZmZmLWZlYWYtNGVhMC5pcHY2LWxpdGVyYWwubmV0hwSp/l92MAoGCCqGSM49BAMCA2kAMGYCMQCJI5XXdOr2LvwkEgcpKp/kOlkOYnq2
Bag/E8dVFUF4JwnOHrVUY5pZTgFEUg9rX6ECMQCO6e3av/Tw2EWplx5Q+5pJmiLaoP5V8a+WGXHhqAcqY/OMyrB4oAlaocOQRQGZXdM=
\n----END CERTIFICATE----",
    "Actions": {
        "#Certificate.Rekey": {
            "title": "Generate a new key pair for an existing certificate and produce a CSR.",
            "KeyCurveId@Redfish.AllowableValues": [
                "TPM_ECC_NIST_P384"
            "KeyPairAlgorithm@Redfish.AllowableValues": [
                "TPM ALG ECDH"
            "target": "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates/1/Actions/Certificate.Rekey"
        "#Certificate.Renew": {
            "title": "Generate a CSR using the existing information and key pair of the certificate.",
            "target": "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates/1/Actions/Certificate.Renew"
    "Description": "This resource is used to represent the certificate for a Redfish implementation."
}
```

POST - Rekey

Use the POST method to generate a new key-pair for a certificate and produces a certificate signing request.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates/{id}/Actions/Certificate.Rekey

Request body

Field	Туре	Description
KeyCurveld	String	Required. The curve ID to use with the key, if needed based on the KeyPairAlgorithm parameter value. Allowable value is "TPM_ECC_NIST_P384".
KeyPairAlgor- ithm	String	Required. The type of key-pair for use with signing algorithms. Allowable value is "TPM_ALG_ECDH".
KeyBitLength	Integer	Optional. The length of the key, in bits, if needed based on the KeyPairAlgorithm parameter value.
ChallengePass- word	String	Optional. The challenge password to apply to the certificate for revocation requests.

Response body

Field	Туре	Description
CSRString	String	The string for the certificate signing request.
Certificate	Link	The link to the certificate being rekeyed.

Status code

HTTP Status Code	Error Message ID
400	BadRequest, ActionParamMissing , ActionParamTypeError , ActionParamFormatError
500	InternalError

Example

```
The POST body is filled as below:
```

```
{
    "KeyCurveId": "TPM_ECC_NIST_P384",
    "KeyPairAlgorithm": "TPM_ALG_ECDH"
}
```

The following example JSON response is returned.

```
{
    "Certificate": {
        "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates/1"
}.
```

"CSRString": "----BEGIN CERTIFICATE REQUEST----\nMIICpDCCAioCAQAwTzELMAkGA1UEBhMCVVMxCzAJBgNVBAgMA k5DMQwwCgYDVQQHDANSVFAxDzANBgNVBAoMBkxlbm92bzEUMBIGA1UEAwwLWENDLTdaNjAtUO4wdjAQBgcqhkjOPQIBBgUrgQQAIgNiAA TMCJhOyPzqC7sxdTs9JiJvWNvKsOy9cocFjJnOeoijoKbMn2nSy5yQJwgoeKIoh2eBPnzGl58CI2pYd+APZSTyImltu34Hk+hGY4+ZGHJ EI8fZ5XOO+/tj7k8JEafbgumgggFaMIIBVgYJKoZIhvcNAQkOMYIBRZCCAUMwCQYDVROTBAIwADALBgNVHQ8EBAMCBeAwggEnBgNVHREE ggEeMIIBGoILWENDLTdaNjAtUO6CC1hDQyO3WjYwLVNOhxD+gAAAAAAAQU7//+rO6fgilmZTgwLS1hOTQtZWZmZi1mZWFmLTRLOWYua XB2Ni1saXRlcmFsLm5ldIcQ/oAAAAAAAAAAKlO///q9OoIIpZmU4MCOtYTkOLWVmZmYtZmVhZiOOZWEwLmlwdjYtbGlOZXJhbC5uZXSHBK n+X3aHEP6AAAAAAAAACpTv//6rmbOCKWZlODAtLWE5NC1lZmZmLWZlYWItOTliMy5pcHY2LWxpdGVyYWwubmVOhwQKaMVIhxD+gAAAAAA AAAqU7//+q5m0gilmZTgwLS1hOTQtZWZmZi1mZWFiLTk5YjQuaXB2Ni1saXRlcmFsLm5ldDAKBggqhkjOPQQDAgNoADBlAjBJrD3MgJlD 2pHV4QkaOQa8jbzl214J1rLB8IdKViaDVHgihiusCLPvUM2YCr6bSIcCMQDamvg6r6rPljcaGre8OUuojdANUWcihMVWTdIAtfzdaXHc/d/jjhr9BN2RF59OQLU=\n-----END CERTIFICATE REQUEST-----"

POST – Renew

Use the POST method to generate a certificate signing request by using the existing information and key-pair of the certificate.

Request URL

GET https://<BMC_IPADDR>/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates/{id}/Actions/Certificate.Renew

Request body

None

Response body

Field	Туре	Description
CSRStrin- g	String	The string for the certificate signing request.
Certificate	Link	The link to the certificate being rekeyed.

Status code

HTTP Status Code	Error Message ID	
400	BadRequest	
500	InternalError	

Example

The following example is POST body

None

The following example JSON response is returned:

```
{
    "Certificate": {
        "@odata.id": "/redfish/v1/Managers/1/NetworkProtocol/HTTPS/Certificates/1"
```

"CSRString": "----BEGIN CERTIFICATE REQUEST----\nMIICpDCCAioCAQAwTzELMAkGA1UEBhMCVVMxCzAJBgNVBAgMA k5DMQwwCgYDVQQHDANSVFAxDzANBgNVBAoMBkxlbm92bzEUMBIGA1UEAwwLWENDLTdaNjAtU04wdjAQBgcqhkjOPQIBBgUrgQQAIgNiAA QKEnDzQP2ngvTEfY/vMHSlVvRf/i6Gja1x+DryAeGze7FjAXXJvP9aBdspJzEfOzk3/a7W3W+VpW3/YfvOjferwGL9ISdZ1A/S7aLAraa af+1Cw5zX0qTUX16Gdbkpz+GqqqFaMIIBVqYJKoZIhvcNAQkOMYIBRzCCAUMwCQYDVROTBAIwADALBqNVHQ8EBAMCBeAwqqEnBqNVHREE ggEeMIIBGoILWENDLTdaNjAtUO6CC1hDQyO3WjYwLVNOhxD+gAAAAAAAAAQU7//+rO6fgilmZTgwLS1hOTQtZWZmZi1mZWFmLTRlOWYua XB2Ni1saXRlcmFsLm5ldIcQ/oAAAAAAAAAKlO///q90oIIpZmU4MCOtYTkOLWVmZmYtZmVhZi00ZWEwLmlwdjYtbGl0ZXJhbC5uZXSHBK n+X3aHEP6AAAAAAAAACpTv//6rmb0CKWZlODAtLWE5NC1lZmZmLWZlYWItOTliMy5pcHY2LWxpdGVyYWwubmV0hwQKaMVIhxD+qAAAAAA AAAqU7//+q5m0qilmZTqwLS1hOTQtZWZmZi1mZWFiLTk5YjQuaXB2Ni1saXRlcmFsLm5ldDAKBqqqhkjOPQQDAqNoADBlAjA7v/rOLljB OM4GAajGtrS2yMR/Np8T5evlA5JmXYVIGmcklN7uETz+aokCOG3poSwCMQCybhvJOZmuFQjarW8brInM231OcjWN5bgZyKFAfmcHkZNvk Cau8DB3vI5z309KDeQ=\n----END CERTIFICATE REQUEST----" }

Notices

Lenovo may not offer the products, services, or features discussed in this document in all countries. Consult your local Lenovo representative for information on the products and services currently available in your area.

Any reference to a Lenovo product, program, or service is not intended to state or imply that only that Lenovo product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any Lenovo intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any other product, program, or service.

Lenovo may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document is not an offer and does not provide a license under any patents or patent applications. You can send inquiries in writing to the following:

Lenovo (United States), Inc. 1009 Think Place Morrisville, NC 27560 U.S.A.

Attention: Lenovo VP of Intellectual Property

LENOVO PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. Lenovo may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

The products described in this document are not intended for use in implantation or other life support applications where malfunction may result in injury or death to persons. The information contained in this document does not affect or change Lenovo product specifications or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Lenovo or third parties. All information contained in this document was obtained in specific environments and is presented as an illustration. The result obtained in other operating environments may vary.

Lenovo may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Any references in this publication to non-Lenovo Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this Lenovo product, and use of those Web sites is at your own risk.

Any performance data contained herein was determined in a controlled environment. Therefore, the result obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Trademarks

LENOVO, SYSTEM, NEXTSCALE, SYSTEM X, THINKSERVER, THINKSYSTEM, and XCLARITY are trademarks of Lenovo.

Intel is a trademark of Intel Corporation in the United States, other countries, or both.

Linux is a registered trademark of Linus Torvalds.

Microsoft, Windows, Windows Server, Windows PowerShell, Hyper-V, Internet Explorer, and Active Directory are registered trademarks of the Microsoft group of companies.

Mozilla and Firefox are registered trademarks of Sun Microsystems, Inc. in the United States, other countries, or both.

Nutanix is a trademark and brand of Nutanix, Inc. in the United States, other countries, or both.

Red Hat is a registered trademark of Red Hat, Inc. in the United States and other countries.

SUSE is atrademark of SUSE IP Development Limited or its subsidiaries or affiliates.

VMware vSphere is a registered trademark of VMware in the United States, other countries, or both.

All other trademarks are the property of their respective owners.

Index

A	Collection of event subscriptions
Account management properties GET 13	GET 237 Collection of host interface GET 102
Account properties GET 17	Collection of MetricDefinition
Action info of SubmitTestMetricReport GET 248	GET 257 Collection of MetricReport
authentication methods 1	GET 254 Collection of MetricReportDefinition GET 250
D.	Collection of Network adapters GET 41
В	Collection of Network device function
BIOS attribute registries GET 193, 198	GET 48 Collection of network interfaces
BMC active log entries	GET 158
GET 141 BMC Audit event log entries	Collection of network ports GET 45
GET 144	Collection of server Ethernet interfaces
BMC Ethernet properties GET 84	GET 98 Collection of server memories
BMC Maintenance event log entries	GET 151
GET 146 BMC management properties	Collection of storage controllers GET 175
GET 73	Collection of virtual media GET 117
BMC network services GET 105	CPU properties
BMC Platform event log entries GET 143	GET 167 Create a session
BMC reset	POST 11
POST 81 BMC serial interface properties	Create a subscription POST 239
GET 114	
BMC Service Advisor event log entries GET 147	D
	_
С	DELETE Delete a session 12
	Delete a subscription 241
Certificate locations properties GET 271	Delete a session DELETE 12
Certificate properties	Delete a subscription
GET 272 Certificate service properties	DELETE 241 Drives managed by storage controller
GET 267	GET 181
Change BIOS password settings POST 189	
Chassis properties GET 28	E
Clear event logs	Enable/disable host interface
POST 140 Collection for chassis	PATCH 104
GET 27	Event properties 244 Event service properties
Collection for firmware inventories on the server GET 224	GET 233
Collection for Flex System Enterprise Chassis or Lenovo D2	Event subscriptions GET 237
Enclosure GET 37	
Collection for server	F
GET 121 Collection of BMC log services	-
GET 133 Collection of BMC network interface properties	Firmware inventory properties GET 225
GET 83	Flex System Enterprise Chassis or Lenovo D2 Enclosure
Collection of BMC serial interface GET 113	properties GET 38
Collection of CPUs	Functions of server PCle functions
GET 166	GET 162 Functions of server PCIe Slots

© Copyright Lenovo 2017, 2020 **279**

Ν

Network adapter properties
GET 42
Network device PCIe functions
GET 48
Network port properties
GET 46
notices cclxxvii

PÖST 219

MetricReport properties 256
MetricReportDefinition properties
Network adapter properties 42
Network device PCIe functions

Network port properties 46

Processor metric properties

Resource for BIOS 187

Role properties 21

Power management properties 51, 67

Server Ethernet interface properties

Server Ethernet over USB properties

Server memory properties 153

Properties for firmware update service 205

P	Server network interfaces
DATOLI	GET 159
PATCH Enable/disable host interface 104	Server PCIe devices
Insert/Eject a virtual media 119	GET 160
Properties for firmware update service 207	Server properties GET 122
Update BMC Ethernet configurations 90	Server reset operations
Update BMC Ethernet over USB configurations 94	POST 132
Update BMC network service configurations 109	Service for BMC active logs
Update BMC serial interface configurations 115 Update BMC time zone and other oem properties 78	GET 134
Update chassis asset tag and location LED and other oem	Service for BMC Audit event logs
properties 33	GET 137 Service for BMC event logs
Update custom role privileges 24	GET 135
Update next-one-time boot configurations and other	Service for BMC Maintenance event logs
properties 130	GET 138
Update pending BIOS settings 191 Update power management properties 65	Service for BMC Service Advisor event logs
Update Schedule properties 264	GET 139
Update secure boot properties 199	Service root properties GET 5
Update userid/password/role 19	Session management properties
POST	GET 9
BMC reset 81	Session properties
Change BIOS password settings 189 Clear event logs 140	GET 10
Create a session 11	Simple update for firmware
Create a subscription 239	POST 209 SSE subscription 242
Generate CSR 268	Storage controller properties
HTTP Push update for firmware 212	GET 176
Multipart HTTP Push update for firmware 219	Submit a test event
Rekey 274 Renew 275	POST 235
Replace Certificate 270	Submit a test Metric Report
Reset BIOS operation 190	POST 249
Reset secure boot keys 201	
Server reset operations 132	-
Simple update for firmware 209	Т
Submit a test event 235 Submit a test Metric Report 249	Task properties
Power management properties	GET 230
GET 51, 67	Task service properties
Processor metric properties	GET 229
GET 170	Telemetry service properties GET 247
Properties for firmware update service GET 205	The pending BIOS settings
PATCH 207	GET 191
	Thermal management properties
	GET 68
R	Tools for Redfish 2
••	trademarks cclxxviii
Rekey	
POST 274	U
Renew POST 275	U
Replace Certificate	Update BMC Ethernet configurations
POST 270	PATCH 90
Reset BIOS operation	Update BMC Ethernet over USB configurations
POST 190	PATCH 94 Update BMC network service configurations
Reset secure boot keys	PATCH 109
POST 201 Resource for BIOS	Update BMC serial interface configurations
GET 187	PATCH 115
Role properties	Update BMC time zone and other oem properties
GÉT 21	PATCH 78
	Update chassis asset tag and location LED and other oem properties
	PATCH 33
S	Update custom role privileges
Sanyar Etharnat interface properties	PATCH 24
Server Ethernet interface properties GET 99	Update next-one-time boot configurations and other properties
Server Ethernet over USB properties	PATCH 130 Update pending BIOS settings
GET 100	PATCH 191
Server memory properties	Update power management properties
GET 153	PATCH 65

© Copyright Lenovo 2017, 2020 **281**

Update Schedule properties PATCH 264 Update secure boot properties PATCH 199 Update userid/password/role PATCH 19



Virtual media properties GET 118 Volumes managed by storage controller GET 184

Lenovo

Part Number: SP47A30097

Printed in China

(1P) P/N: SP47A30097

