

AVR Multi Motor Control

Facoltà di Ingegneria dell'Informazione, Informatica e Statistica Corso di Laurea in Ingegneria Informatica e Automatica

Candidate
Paolo Lucchesi
ID number 1765134

Thesis Advisors

Prof. Giorgio Grisetti

Drs. Barbara Bazzana

Academic Year 2021/2022

Thesis not yet defended

Reviewer:

Prof. Silvia Bonomi

AVR Multi Motor Control

Bachelor's thesis. Sapienza – University of Rome

 $\ensuremath{{\mathbb C}}$ 2021 Paolo Lucchesi. All rights reserved

This thesis has been typeset by LATEX and the Sapthesis class.

Website: https://github.com/jcondor98/ammc

Author's email: lucchesi.1765134@studenti.uniroma1.it

Dedicated to my family, my granddad Pietro, my mom Anna Rosa, my dad Marco, my grandmom Pierina and my sister Valentina, which I thank everyday for everything I am.

To my dearest friends in Pitigliano, with whom I share some of the most beautiful $memories\ I$ have.

To Nicola, with whom I have shared part of this path; he helped me in a dark period of my life and he is one of my dearest friends.

Abstract

Nowadays, men physical work is gradually being taken or eased by technology. Many solutions in this area of interest rely on the use of electrical motors to accomplish tasks. Furthermore, electrical motors are widely used in many retail products, such as toys, domotic devices and so on.

In this work I propose, as the result of my bachelor degree apprenticeship, the AVR Multi Motor Control ecosystem as a solution for the management of multiple dc motors. It is composed of a client application for user interaction, a master controller and multiple slave controllers, each handling a single motor. The master controller manages slave controllers, reading and manipulating the dc motors' speed with granularity.

In chapter 1 I give a broad overview on the work done, focusing on the structure of the entire project and the approach I had relating to software architecture, coding and documentation writing.

In chapter 2 I discuss the client-side application, focusing on user interaction and software architectural characteristics.

In chapter 3 I discuss the master controller, focusing on hardware setup and firmware internals.

In chapter 4 I discuss the slave controller, focusing on hardware and the softwaredefined Proportional-Integral-Derivative controller embedded in the firmware.

In chapter 6 I discuss the protocols responsible for the communication between the client application and the master controller, and how I used the underlying serial communication channel.

In chapter 5 I explain how I used the I2C bus to connect the master controller to multiple slave controllers.

Contents

1	Intr	roduction	1
2	Clie	ent-side user interaction	3
	2.1	User Interface	3
	2.2	Primitives offered	3
		2.2.1 Non-interactive mode	4
	2.3	Serial module	4
	2.4	Specification	4
		2.4.1 Software modules	4
		2.4.2 Modules dependency graph	4
	2.5	Man page	4
3	Mas	ster controller	7
	3.1	Hardware setup	7
	3.2	I2C setup	7
	3.3	Power management	7
	3.4	Specification	8
		3.4.1 Software modules	8
		3.4.2 Modules dependency graph	8
		3.4.3 Circuit schematics	10
		3.4.4 Wiring	10
4	Slav	ve controllers	11
	4.1	Hardware setup	11
	4.2	I2C setup	11
	4.3	Proportional-Integral-Derivative controller	12
		4.3.1 Measuring speed	12
		4.3.2 Approximations	12
	4.4	Power management	13
	4.5	Specification	13
		4.5.1 Software modules	13
		4.5.2 Modules dependency graph	13
		4.5.3 Circuit schematics	13
		4.5.4 Wiring	13

viii	Contents

5	Clie	${ m ent} ext{-}{ m Ma}$	ster communication	17
	5.1	Serial	layer	. 17
	5.2	Packe	t headers	. 17
		5.2.1	Identifiers	. 17
		5.2.2	Packet types	. 18
		5.2.3	Motor selector	. 18
	5.3	Ackno	weledgements and errors	. 18
6	Ma	${ m ster} ext{-Sl}$	ave communication	21
		6.0.1	Hardware setup	. 21
		6.0.2	Communication frames	. 21
7	Cor	nclusio	ns	23
Bi	bliog	graphy		25

List of Figures

2.1	Client application modules dependency graph	
3.1	Master controller modules dependency graph	Ć
3.2	Master controller schematics	10
4.1	Slave controller modules dependency graph	14
4.2	Slave controller schematics	14

List of Tables

2.1	Client application software modules	6
	Master application software modules	
	Slave application software modules	
5.2	Packet header fields	19
6.1	Master-to-slave commands):2

Introduction

Client-side user interaction

A client program has been realized to manipulate the dc motors directly from the PC. It can get and set the speed of individual motors, and to apply all the previously set speeds for all of them at once.

A brief list of the client's features is given below:

- Granular handling for getting and setting motors' speed
- Modular and extensible software architecture
- Terminal User Interface, implemented as a command shell
- Support for non-interactive use (i.e. scripting)
- Communication with master controller using the serial protocol
- Compatible with POSIX-compliant environments

The client is also documented with a man page, which can be found in section 2.5.

2.1 User Interface

The end user interacts with the whole ammc ecosystem using a text-based client. It consists in a shell module, which I had written myself, offering some *internal commands* (hardcoded in the shell module itself) and is extended by *external commands* (found in a separated source code entity, and that can even be compiled in a detached transaction unit).

A particular focus was made on the software architecture: indeed, every external command can be realized standalone, and it is easy to add new commands just by altering the *client/source/shell commands.c* source file.

2.2 Primitives offered

The commands that can be used to interface with the ammc ecosystem are the following:

- **connect** < device-path > Connect to a master controller, given the path to the block device representing it.
- **get-speed <motor-id>** Get the speed of a dc motor given its id. The motor id must be specified as a decimal number.
- **set-speed** <**motor-id**>=<**speed**> Set the speed of a dc motor given its id. The motor id must be specified as a decimal number and the speed must be specified in rpm.

apply Apply the previously set speed for all the dc motors.

2.2.1 Non-interactive mode

The client shell is capable of running in non-interactive (i.e. scripting) mode with the -s option. If so, it will parse the input from a specified text file, or from stdin if not provided. A shell launched in non-interactive mode will not print shell prompts, and exit when end-of-file is encountered or on command failure.

2.3 Serial module

The client's serial module has been realized using the POSIX termios interface. Unlike the master controller's counterpart, all its code is reentrant, therefore multiple instances of multiple serial devices can theoretically exist at the same time.

From the client's perspective, the master controller is seen as a file descriptor, and the end user just have to specify the path of the block device file representing the serial communication channel (e.g. $/dev/ttyACM\theta$) using the connect command.

2.4 Specification

2.4.1 Software modules

An exhaustive list of software modules for the client application is given in table 2.1. File paths are relative to the *client*/ directory.

2.4.2 Modules dependency graph

The dependency graph for the client application software modules is shown in figure 2.1. The *debug* module is excluded. Notice how the dependency flow goes in one direction (from top to bottom); this is the result of the software architecture policy used.

2.5 Man page

2.5 Man page 5




Figure 2.1. Client application modules dependency graph

Module	Description	Files
communication	Contains all the top-level communication routines	include/communication.h, source/communication.c
crc	Contains the CRC generation and checking routines	include/crc.h, source/crc.c
debug	Contains convenient debug facilities	include/debug.h
main	Contains the main client application routine	source/main.c
packet	Contains packet generation and manipulation routines	include/packet.h, source/packet.c
ringbuffer	Circular buffer implementa- tion for the serial module	include/ringbuffer.h, source/ringbuffer.c
serial	Contains all the routines for the underlying serial commu- nication layer	include/serial.h, source/serial.c
shell	Main program shell with built- in commands	include/shell.h, source/shell.c
shell_commands	Contains the custom external commands to interact with the master controller	source/shell_commands.c

Table 2.1. Client application software modules

Master controller

The master controller handles all the slave controllers, dispaching arbitrary commands to them using the I2C protocol. It also communicates directly with the client application via serial port.

3.1 Hardware setup

The master controller itself is an AVR *ATMega2560* microcontroller unit[1]. This particular MCU has features convenient for this project, such as:

- I2C dedicated hardware subsystem
- Serial-over-USB bridge
- Relatively powerful specifications for future feature adding
- Plenty of timers and outgoing power pins

A 100pF capacitor is used to block the reset capabilities of the serial-over-usb controller and enhance the serial channel reliability. Two $4.7k\Omega$ resistors are used as open-drain resistors for the I2C bus.

3.2 I2C setup

The I2C protocol is used to communicate with slave controllers. Transmission and reception are interrupt-based, and no busy-wait is used.

The I2C module has broadcasting capabilities, according to the informations found in the I2C standard I2C standard [4]; the broadcasting (i.e. $general\ call$) address used is 0x00. As stated by the standard, the master controller has no knowledge on the number or identity of the slaves receiving a broadcast frame.

3.3 Power management

An own-written wrapper for the avr-gcc standard library's sleep functionalities is used for power management. By default, the master controller is in *idle* mode, and

it is awakened by any raised interrupt, e.g. by incoming serial or I2C data; then, its main loop routine is executed and, if no other operations must be performed, it returns in idle mode.

The master controller is also put in idle when waiting for data inside serial or I2C routines; this is possible thanks to the interrupt-driven nature of the aforementioned modules.

3.4 Specification

3.4.1 Software modules

An exhaustive list of software modules for the master controller firmware is given in table 3.1. File paths are relative to the *master*/ directory.

Module	Description	Files
communication	Contains all the top-level communication routines	include/communication.h, source/communication.c
crc	Contains the CRC generation and checking routines	include/crc.h, source/crc.c
demotor	Contains the top-level routines for interfacing slave controllers	include/dcmotor.h, source/dcmotor.c
main	Contains the main and power management routines	source/main.c
packet	Contains packet generation and manipulation routines	include/packet.h, source/packet.c
ringbuffer	Circular buffer implementation for the serial module	include/ringbuffer.h, source/ringbuffer.c
serial	Contains all the routines for the underlying serial communi- cation layer	include/serial.h, source/serial.c
sleep_util	Handy wrapper for the avr-libc power management facilities	include/sleep_util.h
twi	Contains the I2C/TWI layer which underlies the communication between master and slaves	include/twi.h, source/twi.c

Table 3.1. Master application software modules

3.4.2 Modules dependency graph

The dependency graph for the master controller's software modules is shown in figure 3.1. The *debug* module is excluded. Notice how the dependency flow goes in one direction (from top to bottom); this is the result of the software architecture policy used.




Figure 3.1. Master controller modules dependency graph

10 3. Master controller

3.4.3 Circuit schematics

The complete circuit schematics for the master controller and all its components is shown in figure 3.2.




Figure 3.2. Master controller schematics

3.4.4 Wiring

The wiring correspondence for the master controller MCU is shown in table 3.2.

Board pin	MCU pin	Description
D20 D21 RESET	44/PD1/INT1/SDA 43/PD0/INT0/SCL RESET	

Table 3.2. Master controller wiring

Slave controllers

Each slave controller directly handles a single dc motor, receiving commands from the master controller via I2C. It must offer an interface to get and manipulate its motor's speed.

The slave controller produces a PWM wave having a duty cycle consistent with the speed (given in RPM) specified by the end user in order to control its motor.

Furthermore, it comes with a software Proportional-Integral-Derivative controller to correct the bias between target and actual motor speeds.

4.1 Hardware setup

The slave controller itself is an AVR ATMega328P microcontroller unit[2], which offers the following features of interest:

- CH340 Serial-over-USB controller for convenient firmware flashing
- Reduced size
- Relatively high clock and resources
- Dedicated I2C hardware subsystem
- PWM-capable 8-bit and 16-bit timers

Apart from the motor itself (along with its power supply and eventually its dedicated control board) no additional hardware is used.

4.2 I2C setup

A slave controller communicates with the master controller using the I2C protocol. As for the master controller, both transmission and reception are interrupt-based.

The slave controller is always passive on the bus, waiting to be addressed by the master.

12 4. Slave controllers

4.3 Proportional-Integral-Derivative controller

An own-written, software-defined Proportional-Integral-Derivative controller is used to correct the actual motor speed. As for any PID device, the equation controlling the error is:

$$u(t) = K_p e(t) + K_i \int_{t_0}^t e(\tau) \, d\tau + K_d \frac{d}{dt} \, e(t)$$
 (4.1)

being:

- u(t) the PID control variable
- K_p the proportional gain
- K_i the integral gain
- K_d the derivative gain
- e(t) the measured speed error

4.3.1 Measuring speed

For actual PID capabilities, the slave controller must sample the actual speed of the dc motor at fixed intervals. Therefore, the motor must have an embedded, two-phase digital encoder.

In fact, one phase is wired to an interrupt-enabled input pin, so the slave controller is notified immediately when an encoder signal (raising edge) is generated. Every sampling intervals, the PID routine takes the motor's actual position (measured by the cumulative number of encoder triggers) and computes its real speed.

4.3.2 Approximations

Of course, a software digital PID controller can not compute exact integrals and derivatives, so it is necessary to use approximation.

The integral operation is approximated using *Riemann sums*. Given a time delta Δt (the actual speed sampling interval in this particular case), the approximating law is defined as:

$$\int_{t_0}^t e(\tau) d\tau \approx \sum_{k=1}^n e(t_k^*) \cdot \Delta t \tag{4.2}$$

The derivative operation is approximated using its definition[3]:

$$\frac{d}{dt}e(t) = \lim_{\Delta t \to 0} \frac{e(t + \Delta t) - e(t)}{\Delta t} \implies \frac{d}{dt}e(t) \approx \frac{e(t + \Delta t) - e(t)}{\Delta t}$$
(4.3)

being Δt a time delta (again, the actual speed sampling interval).

4.4 Power management

The same avr-libc wrapper written for the master controller power management is used. By default, the slave controller is in *idle* mode, and it is awakened by any raised interrupt. The main loop routine is executed and the idle mode is entered again. Like for the master controller, the slave is put in idle when waiting for the I2C routines to return.

The AVR idle mode allows the timers to work, so the slave controller can generate PWM waves to control the motors, even while sleeping.

4.5 Specification

4.5.1 Software modules

An exhaustive list of software modules for the slave controllers firmware is given in table 4.1. File paths are relative to the slave/ directory.

Module	Description	Files
dcmotor	Contains stuff to directly manipulate dc motors, including the PID controller, PWM waves generation and speed manipulation routines	include/dcmotor.h, source/dcmotor.c
main	Contains the main and power management routines	source/main.c
sleep_util	Handy wrapper for the avr-libc power management facilities	include/sleep_util.h
twi	Contains the I2C/TWI layer which underlies the communication between master and slaves	include/twi.h, source/twi.c

Table 4.1. Slave application software modules

4.5.2 Modules dependency graph

The dependency graph for the slave controllers' software modules is shown in figure 4.1. The *debug* module is excluded.

4.5.3 Circuit schematics

The complete circuit schematics for the slave controller and all its components is shown in figure 4.2. This circuit can be repeated multiple times (up to 126) in a single ammc ecosystem.

4.5.4 Wiring

The wiring correspondence for the slave controller MCU is shown in table 4.2.

14 4. Slave controllers




Figure 4.1. Slave controller modules dependency graph




Figure 4.2. Slave controller schematics

Board pin	MCU pin	Description
A4	27/PC4/ADC4/SDA	I2C data bus
A5	28/PC5/ADC5/SCL	I2C clock bus
D6	10/PD6/AIN0/OC0A	PWM output to the dc motor
D7	11/PD7/AIN1/ICP1	Encoder phase A, interrupt-enabled
D8	12/PB0/CLK0	Encoder phase B

Table 4.2. Slave controller wiring

Client-Master communication

The client application and the master controller communicate over a protocol built on top of the serial-over-usb layer. Such protocol is completely binary and packet-based. Each packet has a variable length (with a total maximum size of 36 bytes) and its integrity is checked with a trailing CRC-8 checksum.

The protocol comes with a simple handshaking mechanism, in order to synchronize the packet IDs between endpoints and as a shallow proof of correct functionality of the communication layers.

5.1 Serial layer

Data exchange between client and master relies on the serial protocol. For the client application, the *termios* library is used, while for the master controller the (hardware) serial subsystem offered by the AVR microcontroller[1] is used.

The serial communication is set up as follows:

- Baud rate of 115200 baud, double speed transmission
- 8 bit frame width
- No start bits, 1 stop bit (i.e. 8N1)
- No embedded parity bit

For the master controller, both transmission and reception are interrupt-driven, so the communication main routine is only called when data is actually available.

5.2 Packet headers

Each packet's metadata is contained in a fixed size header, composed as describe in table 5.1.

5.2.1 Identifiers

The *id* field stores the packet identifier, which is incremental and can be repeated in a single communication session. When the handshake is performed, or when any

endpoint raises an error (issuing a NAK packet), the id is reset to zero for both sides. Each ACK and NAK packet is generated with the same id of the referred packet (see TODO for further informations).

5.2.2 Packet types

The *type* field stores the packet type. An exhaustive list of packet types is given in table 5.2

5.2.3 Motor selector

The *selector* field is used to store the identifier for the dc motor to manipulate. This field is used in *GET SPEED* and *SET SPEED* packets.

For NAK packets, instead, the *selector* field is used to store error codes (found in table 5.3).

For all the other packet types, the *selector* field is ignored.

5.3 Acknowledgements and errors

A communication endpoint must wait for an acknowledgement message from the counterpart once it sent a packet in order to send a new one. ACK and NAK packets do not bring any data.

When a packet arrives, it is checked for integrity and sanity. If it is sane, then an ACK packet is sent; if not, then a NAK packet is sent. ACK and NAK packets are simply discarded if corrupted in some way.

A NAK packet uses the *selector* field to send to the other endpoint the error code describing what happened on its side. Error codes are listed in table 5.3.

Field	Size (bits)	Description
id	8	Packet ID
$_{\mathrm{type}}$	8	Packet type
selector	8	Selector for DC motors. Also used to store error codes in
		NAK packets
size	8	Total packet size, including header and checksum

Table 5.1. Packet header fields

Type	Code	Description
NULL	0x00	Reserved, never use
HND	0x01	Handshake
ACK	0x02	Acknowledgement
NAK	0x03	Communication error
ECHO	0x04	Echo between Client and Master (debug only)
TWI_ECHO	0x05	Echo a single char to the first Slave via TWI (debug
		only)
GET_SPEED	0x06	Get the current speed for a DC motor
SET_SPEED	0x07	Set (and apply) the speed for a DC motor
APPLY	0x08	Tell all the slaves to apply the previously set speeds
DAT	0x09	Primarily used for responses from the AVR device
LIMIT	0x0A	Used for sanity checks - Must have highest value

Table 5.2. Exhaustive list of packet types

Error	Code	Description	
SUCCESS	0x00	No errors encountered	
ID_MISMATCH	0x01	Id of received packet is not consistent	
CORRUPTED_CHECKSUM	0x02	Checksum mismatch, received packet is	
		corrupted	
$WRONG_TYPE$	0x03	Received packet has invalid type	
TOO_BIG	0x04	Received packet has invalid size (too big)	

 Table 5.3. Exhaustive list of packet types

Master-Slave communication

The master and slave controllers communicate to each other using the I2C bus. Naturally, the master controller is responsible for starting communication sessions, addressing one or all the slaves.

The bitrate is set to 100kbit/s, i.e. the maximum speed available for the original I2C standard[4] (excluding fast modes, which were implemented later).

6.0.1 Hardware setup

The I2C bus itself is a pair of bus rails, named *SDA* and *SCL*, representing data and bus clock respectively.

Two $4.7k\Omega$ resistors connects SDA and SCL to a 5V voltage generator and act as open-drain resistors.

6.0.2 Communication frames

The first byte of the I2C communication frame (excluding, of course, the slave address) is an 8-bit unsigned integer representing the command sent by the master to the slave. The trailing data represents an argument, with its size and shape depending on the type of command issued. Command codes, with their specific arguments, are shown in table 6.1.

Command	Code	Argument size (bytes)	Description
case DC_MOTOR_CMD_GET	0x00	-	Get the dc motor speed in rpm
case DC_MOTOR_CMD_SET	0x01	1	Set the dc motor tar- get speed
case DC_MOTOR_CMD_APPLY	0x02	-	Apply the pre- viously set target speed
case TWI_CMD_ECHO	0x03	1	Send back the received character to the master (debug)

Table 6.1. Master-to-slave commands

Conclusions

Bibliography

- $[1] \ \ Atmel. \ \ Atmel \ \ ATmega 640/V-1280/V-1281/V-2560/V-2561/V \ \ data sheet, \ 2014.$
- [2] Atmel. Atmel ATmega328P datasheet, 2015.
- [3] Doron Levy. Introduction to numerical analysis. http://math.umd.edu/~dlevy/classes/amsc460/na-notes.pdf, 2017.
- [4] Philips Semiconductors. The I2C-bus Specification, 2000.