

Heating Circuit — Layered Shell Version

Small heating circuits find use in many applications. For example, in manufacturing processes they heat up reactive fluids. Figure 1 illustrates a typical heating device shown in this model. The device consists of an electrically resistive layer deposited on a glass plate. The layer causes Joule heating when a voltage is applied to the circuit. The layer's properties determine the amount of heat produced.




Figure 1: Geometry of a heating device.

In this particular model, there are three important design considerations:

- · Noninvasive heating
- Minimal deflection of the heating device
- Avoidance of overheating the process fluid

The heater must also work without failure. The first and second requirements are achieved by inserting a glass plate between the heating circuit and the fluid; it acts as a conducting separator. Glass is an ideal material for both these purposes because it is nonreactive and has a low coefficient of thermal expansion.

Overheating must be avoided due to the risk of self-ignition of the reactive fluid stream. Ignition is also the main reason for separating the electrical circuit from direct contact with the fluid. Heating devices are tailored for each application, making virtual prototyping very important for manufacturers.

For heating circuits in general, the detachment of the resistive layer often determines the failure rate. This is caused by excessive thermally induced interfacial stresses. Once the layer has detached, it gets locally overheated, which further accelerates the detachment. Finally, in the worst case, the circuit might overheat and burn. From this perspective, it is also important to study the interfacial tension due to the different thermal expansion

coefficients of the resistive layer and the substrate as well as the differences in temperature. The geometric shape of the layer is a key parameter to design circuits for proper functioning. You can investigate all of the abovementioned aspects by modeling the circuit.

This multiphysics example simulates the electrical heat generation, the heat transfer, and the mechanical stresses and deformations of a heating circuit device. The model uses the Heat Transfer in Shells interface of the Heat Transfer Module in combination with the Electric Currents, Layered Shell interface from the AC/DC Module or the MEMS Module, and the Layered Shell interface from the Composite Materials Module.

Note: In addition to the Composite Materials Module and the Structural Mechanics Module, this model requires the Heat Transfer Module and either the AC/DC Module or the MEMS Module. It is a layered shell version of the model *Heating Circuit* available in the AC/DC Module, Heat Transfer Module, and Structural Mechanics Module Application Libraries.

Model Definition

Figure 2 shows a drawing of the modeled heating circuit.




Figure 2: Drawing of the heating circuit deposited on a glass plate.

The device consists of a serpentine-shaped Nichrome resistive layer, $10~\mu m$ thick and 5 mm wide, deposited on a glass plate. At each end, it has a silver contact pad measuring 10~mm by $10~\mu m$. When the circuit is in use, the deposited side of the glass plate is in contact with surrounding air, and the back side is in contact with the heated fluid. Assume that the edges and sides of the glass plate are thermally insulated.

Table 1 lists the resistor's dimensions.

TABLE I: DIMENSIONS.

ОВЈЕСТ	LENGTH	WIDTH	THICKNESS
Glass plate	130 mm	80 mm	2 mm
Pads and circuit	-	-	10 μm

LAYERED SHELL APPROACH

Since this model uses a layered shell interface, in which the through thickness integration is inherent to the layered shell formulation itself, a surface geometry as shown in the Figure 3 is sufficient.




Figure 3: Layered shell version of the model geometry.

The layered shell geometry has many zones with layers of different materials and thicknesses. The spatial position of the different zones can be seen in Figure 4 and material and thicknesses for each zone can be seen in Figure 5.

The different zones of the layered shell are by default disconnected. Therefore, continuity conditions connecting layers from neighboring zones are required in all physics interfaces.




Figure 4: Zones with different layers in the layered shell geometry. The green zone has only glass layer, the red zone has glass and Nichrome layers, and yellow zone has glass and Silver layers.




Figure 5: Cross-sectional view of zones having layers of different material and thickness.

BOUNDARY CONDITIONS

During operation the resistive layer produces heat. Model the electrically generated heat using the Electric Currents, Layered Shell interface from the AC/DC Module or the MEMS Module. An electric potential of 12 V is applied to the pads. In the model, you achieve this effect by setting the potential at one edge of the first pad to 12 V, and that of one edge of the other pad to 0 V.

To model the heat transfer in the thin conducting layer, use the Heat Transfer in Shells interface. The heat rate per unit area (measured in W/m²) produced inside the thin layer is given by

$$q_{\text{prod}} = dQ_{\text{DC}} \tag{1}$$

where $Q_{DC} = \mathbf{J} \cdot \mathbf{E} = \sigma |\nabla_t V|^2 (W/m^3)$ is the power density. The generated heat appears as an inward heat flux at the surface of the glass plate.

At steady state, the resistive layer dissipates the heat it generates in two ways: on its upside to the surrounding air (at 293 K), and on its downside to the glass plate. The glass plate is similarly cooled in two ways: on its circuit side by air, and on its back side by a process fluid (353 K). You model the heat fluxes to the surroundings using heat transfer coefficients, h. For the heat transfer to air, $h = 5 \text{ W/(m}^2 \cdot \text{K)}$, representing natural convection. On the glass plate's back side, $h = 20 \text{ W/(m}^2 \cdot \text{K)}$, representing convective heat transfer to the fluid. The sides of the glass plate are insulated.

The model simulates thermal expansion using static structural mechanics analyses. It uses the Layered Shell interface for the glass plate as well as for the circuit layer. The stresses are set to zero at 293 K. You determine the boundary conditions for the Layered Shell interface by adding a rigid motion suppression node and restricting all rigid body modes.

MATERIAL PROPERTIES

Table 2 summarizes the material properties used in the model.

TABLE 2: MATERIAL PROPERTIES.

MATERIAL	E [GPa]	ν	α [I/K]	k [W/(m·K)]	ρ [kg/m ³]	C_p [J/(kg·K)]
Silver	83	0.37	1.89e-5	420	10500	230
Nichrome	213	0.33	le-5	15	9000	20
Glass	73.1	0.17	5.5e-7	1.38	2203	703

Figure 6 shows the heat that the resistive layer generates.




Figure 6: Stationary heat generation in the resistive layer when 12 V is applied.

The highest heating power occurs at the inner corners of the curves due to the higher current density at these spots. The total generated heat, as calculated by integration, is approximately 13.8 W.

Figure 7 shows the temperature of the resistive layer and the glass plate at steady state.




Figure 7: Temperature distribution in the heating device at steady state.

The highest temperature is approximately 428 K, and it appears in the central section of the circuit layer. Interestingly, the temperature differences between the fluid side and the circuit side of the glass plate are quite small because the plate is very thin. Using boundary integration, the integral heat flux on the fluid side evaluates to approximately 8.5 W. This means that the device transfers the majority of the heat it generates 8.5 W out of 13.8 W to the fluid, which is good from a design perspective, although the thermal resistance of the glass plate results in some losses.

The temperature rise also induces thermal stresses due the materials' different coefficients of thermal expansion. As a result, mechanical stresses and deformations arise in the layer and in the glass plate. Figure 8 and Figure 9 shows the effective stress distribution in the device and the resulting deformations. During operation, the glass plate bends toward the air side.




Figure 8: The thermally induced von Mises stress plotted with the deformation in glass plate.

The highest effective stress, approximately 26 MPa, occurs at the inner corners of the curves of the Nichrome circuit. The yield stress for high quality glass is roughly 250 MPa, and for Nichrome it is 360 MPa. This means that the individual objects remain structurally intact for the simulated heating power loads.

Stresses in the interface between the resistive layer and the glass plate must also be considered. Assume that the yield stress of the surface adhesion in the interface is in the region of 50 MPa a value significantly lower than the yield stresses of the other materials in the device. If the effective stress increases above this value, the resistive layer locally detaches from the glass. Once it has detached, heat transfer is locally impeded, which can lead to overheating of the resistive layer and eventually cause the device to fail.




Figure 9: The thermally induced von Mises stress plotted with the deformation in resistive layer.

Figure 10 displays the effective forces acting on the adhesive layer during heater operation. As the figure shows, the device experiences a maximum interfacial stress that is approximately five times smaller than the yield stress. This means that the device is safe in terms of the adhesive stress.

Finally, the warping of the device, that is, its deviation from a plane surface as shown in Figure 11 are studied. The maximum deviation from being a planar surface, is approximately 50 µm. For high-precision applications, such as semiconductor processing, this might be a significant value that limits the device's operating temperature.






Figure 10: The effective forces in the interface between the resistive layer and the glass plate.




Figure 11: Deviation from a plane surface on the fluid side of the glass plate.

Application Library path: Composite Materials Module/Multiphysics/ heating circuit layered

Modeling Instructions

From the File menu, choose New.

In the New window, click Model Wizard.

MODEL WIZARD

- I In the Model Wizard window, click **3D**.
- 2 In the Select Physics tree, select Structural Mechanics>Thermal-Structure Interaction> Thermal Stress, Layered Shell.
- 3 Click Add.
- 4 In the Select Physics tree, select AC/DC>Electric Fields and Currents> Electric Currents in Layered Shells (ecis).
- 5 Click Add.
- 6 Click 🔁 Study.
- 7 In the Select Study tree, select General Studies>Stationary.
- 8 Click M Done.

The Thermal Stress, Layered Shell interface includes the Heat Transfer in Shells and the Layered Shell interfaces. In the silica glass, these two interfaces solve for temperature and displacements, respectively. In the conducting layer representing the circuit, the temperature, electrical potential, and displacement are solved by Heat Transfer In Shells, Electric Currents in Layered Shell, and the Layered Shell interfaces.

GLOBAL DEFINITIONS

Parameters 1

Load the parameters from a file.

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.
- 3 Click Load from File.

4 Browse to the model's Application Libraries folder and double-click the file heating_circuit_layered_parameters.txt.

If you do not want to build the geometry manually, you can load the geometry sequence from the stored model. In the **Model Builder** window, under **Component I (compl)** right-click **Geometry I** and choose **Insert Sequence**. Browse to the model's Application Libraries folder and double-click the file heating_circuit_layered.mph. You can then continue to the **Definitions** section below.

To build the geometry from scratch, continue here.

GEOMETRY I

- I In the Model Builder window, under Component I (compl) click Geometry I.
- 2 In the Settings window for Geometry, locate the Units section.
- 3 From the Length unit list, choose mm.

Work Plane I (wpl)

- I In the Geometry toolbar, click Work Plane.
- 2 In the Settings window for Work Plane, click A Go to Plane Geometry.

Work Plane I (wp I)>Plane Geometry

- I In the Model Builder window, click Plane Geometry.
- 2 Click the **Zoom Extents** button in the **Graphics** toolbar.

Work Plane I (wpl)>Square I (sql)

- I In the Work Plane toolbar, click Square.
- 2 In the Settings window for Square, locate the Size section.
- 3 In the Side length text field, type 10.
- 4 Locate the **Position** section. In the **xw** text field, type 7.
- 5 In the yw text field, type 10.
- 6 Click Pauld Selected.
- 7 Right-click Square I (sql) and choose Duplicate.

Work Plane I (wp I)>Square 2 (sq2)

- I In the Model Builder window, click Square 2 (sq2).
- 2 In the Settings window for Square, locate the Position section.
- 3 In the xw text field, type 30.
- 4 In the yw text field, type 8.

5 Click Pauld Selected.

Work Plane I (wpl)>Polygon I (poll)

- I In the Work Plane toolbar, click / Polygon.
- 2 In the Settings window for Polygon, locate the Coordinates section.
- 3 From the Data source list, choose File.
- 4 Click Browse.
- **5** Browse to the model's Application Libraries folder and double-click the file heating_circuit_layered_polygon.txt.
- 6 Click | Build Selected.

Work Plane I (wpl)>Fillet I (fill)

- I In the Work Plane toolbar, click Fillet.
- 2 On the object **poll**, select Points 2–8, 23–29, 34, 36, 37, 41, and 42 only. It might be easier to select the points by using the **Selection List** window. To open this window, navigate to the **Home** toolbar, click **Windows**, and choose **Selection List**. (If you are running the cross-platform desktop, you find **Windows** in the main menu.)
- 3 In the Settings window for Fillet, locate the Radius section.
- 4 In the Radius text field, type 10.
- 5 Click **Pail Build Selected**.

Work Plane I (wb I)>Fillet 2 (fil2)

- I In the Work Plane toolbar, click Fillet.
- 2 On the object fill, select Points 6–12, 26–31, 37, 40, 43, 46, 49, and 50 only.
- 3 In the Settings window for Fillet, locate the Radius section.
- 4 In the Radius text field, type 5.
- 5 Click | Build Selected.


Work Plane I (wbl)>Rectangle I (rl)

- I In the Work Plane toolbar, click Rectangle.
- 2 In the Settings window for Rectangle, locate the Size and Shape section.
- 3 In the Width text field, type 80.
- 4 In the Height text field, type 130.
- 5 In the Work Plane toolbar, click | Build All.

Form Union (fin)

- I In the **Home** toolbar, click **Build All**.

 The geometry should look like the figure below.
- 2 In the Model Builder window, under Component I (compl)>Geometry I click Form Union (fin).



Before creating layered material stacks, add the materials for individual layers.

ADD MATERIAL

- I In the Home toolbar, click **Add Material** to open the **Add Material** window.
- 2 Go to the Add Material window.
- 3 In the tree, select Built-in>Silica glass.
- 4 Right-click and choose Add to Global Materials.
- 5 In the Home toolbar, click 44 Add Material to close the Add Material window.

GLOBAL DEFINITIONS

Silica Glass

In the Settings window for Material, type Silica Glass in the Label text field.

Silver Layer

- I In the Model Builder window, right-click Materials and choose Blank Material.
- 2 Right-click Material 2 (mat2) and choose Rename.
- 3 In the Rename Material dialog box, type Silver Layer in the New label text field.
- 4 Click OK.

Nichrome Laver

- I In the Model Builder window, right-click Materials and choose Blank Material.
- 2 Right-click Material 3 (mat3) and choose Rename.
- 3 In the Rename Material dialog box, type Nichrome Layer in the New label text field.
- 4 Click OK.

The stacking of the Silver and Nichrome layers is not the same across the glass plate. In order to model the stacking, add a Layered Material Stack node with Layered Material subnodes having different selections.

MATERIALS

Layered Material Stack I (stlmat I)

In the Model Builder window, under Component I (compl) right-click Materials and choose Layers>Layered Material Stack.

Layered Material Link 1 (stlmat1.stllmat1)

In the Model Builder window, right-click Layered Material Link I (stlmat1.stllmat1) and choose Delete.

Layered Material Stack 1 (stlmat1)

- I In the Model Builder window, under Component I (compl)>Materials click Layered Material Stack I (stlmat I).
- 2 In the Settings window for Layered Material Stack, locate the Orientation and Position section.
- 3 From the Position list, choose Bottom side on boundary.

Glass

- I Right-click Layered Material Stack I (stlmat I) and choose Layered Material.
- 2 In the Settings window for Layered Material, type Glass in the Label text field.

3 Locate the Layer Definition section. In the table, enter the following settings:

Layer	Material	Rotation (deg)	Thickness (m)	Mesh elements
Layer 1	Silica Glass (mat I)	0.0	d_glass	3

Silver

- I Right-click Layered Material Stack I (stlmat1) and choose Layered Material.
- 2 In the Settings window for Layered Material, type Silver in the Label text field.
- 3 Locate the Boundary Selection section. Click Clear Selection.
- 4 Click Paste Selection.
- 5 In the Paste Selection dialog box, type 2 4 in the Selection text field.
- 6 Click OK.
- 7 In the Settings window for Layered Material, locate the Layer Definition section.
- **8** In the table, enter the following settings:

Layer	Material	Rotation (deg)	Thickness (m)	Mesh elements
Layer 1	Silver Layer (mat2)	0.0	d_layer	1

Nichrome

- I Right-click Layered Material Stack I (stlmat1) and choose Layered Material.
- 2 In the Settings window for Layered Material, type Nichrome in the Label text field.
- 3 Locate the Boundary Selection section. Click Clear Selection.
- 4 Click Paste Selection.
- 5 In the Paste Selection dialog box, type 3 in the Selection text field.
- 6 Click OK.
- 7 In the Settings window for Layered Material, locate the Layer Definition section.
- **8** In the table, enter the following settings:

Layer	Material	Rotation (deg)	Thickness (m)	Mesh elements
Layer 1	Nichrome Layer (mat3)	0.0	d_layer	1

To visualize the stacking, create a Layer Cross Section Preview plot through an action button in the Layered Material Settings section.

Layered Material Stack 1 (stlmat1)

- I In the Model Builder window, click Layered Material Stack I (stlmat I).
- 2 In the Settings window for Layered Material Stack, click Layer Cross-Section Preview in the upper-right corner of the Layered Material Settings section. From the menu, choose Create Layer Cross-Section Plot.

RESULTS

Layer Cross-Section Preview

- I In the Model Builder window, expand the Results node, then click Layer Cross-Section Preview
- 2 In the Layer Cross-Section Preview toolbar, click Plot.

Before adding the material properties, it is a good idea to first set up the physics, so that COMSOL Multiphysics can detect which material properties are needed.

LAYERED SHELL (LSHELL)

Linear Elastic Material I

- I In the Model Builder window, under Component I (compl)>Layered Shell (Ishell) click Linear Elastic Material I.
- 2 In the Settings window for Linear Elastic Material, locate the Linear Elastic Material section.
- 3 From the Material symmetry list, choose Isotropic.

Rigid Motion Suppression I

In the Physics toolbar, click **Boundaries** and choose Rigid Motion Suppression.

Continuity I

- I In the Physics toolbar, click **Edges** and choose **Continuity**.
- 2 In the Settings window for Continuity, locate the Layer Selection section.
- 3 From the Source list, choose Layered Material Stack I (stlmat1.zonel).
- 4 From the Destination list, choose Layered Material Stack I (stlmat1.zone2).

Continuity 2

- I In the Physics toolbar, click **Edges** and choose **Continuity**.
- 2 In the Settings window for Continuity, locate the Layer Selection section.
- 3 From the Source list, choose Layered Material Stack I (stlmat1.zonel).
- 4 From the Destination list, choose Layered Material Stack I (stlmat1.zone3).

Continuity 3

- I In the Physics toolbar, click F Edges and choose Continuity.
- 2 In the Settings window for Continuity, locate the Layer Selection section.
- 3 From the Source list, choose Layered Material Stack I (stlmat1.zone2).
- 4 From the Destination list, choose Layered Material Stack I (stlmat1.zone3).
- **5** In the **Selection** table, enter the following settings:

	Layered material	Offset (m)
√	Nichrome	0

The absolute displacement of the glass plate is not important in itself, since it is just a function of how the rigid body constraints are applied. Instead, you want to see how much the boundary deviates from being planar.

Warpage I

- I In the Physics toolbar, click **Boundaries** and choose **Warpage**.
- 2 In the Settings window for Warpage, locate the Boundary Selection section.
- 3 From the Selection list, choose All boundaries.
- 4 Locate the Interface Selection section. From the Apply to list, choose Bottom interface.

HEAT TRANSFER IN SHELLS (HTLSH)

Solid 1

- I In the Model Builder window, under Component I (compl)>Heat Transfer in Shells (htlsh) click Solid I.
- 2 In the Settings window for Solid, locate the Layer Model section.
- 3 Clear the Layerwise constant properties check box.

Heat Flux, Interface 1

- I In the Physics toolbar, click **Boundaries** and choose **Heat Flux**, **Interface**.
- 2 In the Settings window for Heat Flux, Interface, locate the Boundary Selection section.
- 3 From the Selection list, choose All boundaries.
- 4 Locate the Interface Selection section. From the Apply to list, choose Top interface.
- 5 Locate the Heat Flux section. From the Flux type list, choose Convective heat flux.
- **6** In the *h* text field, type h air.
- **7** In the T_{ext} text field, type T_air.

Heat Flux, Interface 2

- In the Physics toolbar, click Boundaries and choose Heat Flux, Interface.
- 2 In the Settings window for Heat Flux, Interface, locate the Boundary Selection section.
- 3 From the Selection list, choose All boundaries.
- 4 Locate the Interface Selection section. From the Apply to list, choose Bottom interface.
- 5 Locate the Heat Flux section. From the Flux type list, choose Convective heat flux.
- **6** In the *h* text field, type h_fluid.
- **7** In the T_{ext} text field, type T_fluid.

Continuity I

- I In the Physics toolbar, click **Edges** and choose **Continuity**.
- 2 In the Settings window for Continuity, locate the Layer Selection section.
- 3 From the Source list, choose Layered Material Stack I (stlmat1.zonel).
- 4 From the Destination list, choose Layered Material Stack 1 (stlmat1.zone2).

Continuity 2

- I In the Physics toolbar, click Edges and choose Continuity.
- 2 In the Settings window for Continuity, locate the Layer Selection section.
- 3 From the Source list, choose Layered Material Stack I (stlmat1.zonel).
- 4 From the Destination list, choose Layered Material Stack 1 (stlmat1.zone3).

Continuity 3

- I In the Physics toolbar, click Edges and choose Continuity.
- 2 In the Settings window for Continuity, locate the Layer Selection section.
- 3 From the Source list, choose Layered Material Stack I (stlmat1.zone2).
- 4 From the Destination list, choose Layered Material Stack I (stlmat1.zone3).
- **5** In the **Selection** table, enter the following settings:

	Layered material	Offset (m)
V	Nichrome	0

ELECTRIC CURRENTS IN LAYERED SHELLS (ECIS)

- I In the Model Builder window, under Component I (compl) click Electric Currents in Layered Shells (ecis).
- 2 In the Settings window for Electric Currents in Layered Shells, locate the **Boundary Selection** section.

- 3 In the list, select I (stlmat1).
- 4 Click Remove from Selection.
- **5** Select Boundaries 2–4 only.
- 6 Locate the Shell Properties section. Clear the Use all layers check box.
- 7 In the Selection table, clear the check box for Layer I Glass.

Ground I

- I In the Physics toolbar, click Edges and choose Ground.
- 2 Select Edge 38 only.
- 3 In the Settings window for Ground, locate the Shell Properties section.
- 4 From the Layered material list, choose Layered Material Stack I (stlmat1.zone2).

Electric Potential I

- I In the Physics toolbar, click Edges and choose Electric Potential.
- **2** Select Edge 5 only.
- 3 In the Settings window for Electric Potential, locate the Shell Properties section.
- 4 From the Layered material list, choose Layered Material Stack I (stlmat1.zone2).
- **5** Locate the **Electric Potential** section. In the V_0 text field, type V in.

Continuity I

- I In the Physics toolbar, click Edges and choose Continuity.
- 2 In the Settings window for Continuity, locate the Layer Selection section.
- 3 From the Source list, choose Layered Material Stack I (stlmat1.zone2).
- 4 From the Destination list, choose Layered Material Stack I (stlmat1.zone3).
- **5** In the **Selection** table, enter the following settings:

Layered material	Offset (m)
 Nichrome	0

MULTIPHYSICS

Electromagnetic Heating, Layered Shell I (ehls I)

In the Physics toolbar, click Multiphysics Couplings and choose Boundary> Electromagnetic Heating, Layered Shell.

GLOBAL DEFINITIONS

Silver Layer (mat2)

- I In the Model Builder window, under Global Definitions>Materials click Silver Layer (mat2).
- 2 In the Settings window for Material, locate the Material Contents section.
- **3** In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Young's modulus	E	83e9	Pa	Young's modulus and Poisson's ratio
Poisson's ratio	nu	0.37	I	Young's modulus and Poisson's ratio
Density	rho	10500	kg/m³	Basic
Thermal conductivity	k_iso ; kii = k_iso, kij = 0	420	W/(m·K)	Basic
Heat capacity at constant pressure	Ср	230	J/(kg·K)	Basic
Electrical conductivity	sigma_iso; sigmaii = sigma_iso, sigmaij = 0	sigma_si lver	S/m	Basic
Relative permittivity	epsilonr_iso; epsilonrii = epsilonr_iso, epsilonrij = 0	1	I	Basic
Coefficient of thermal expansion	alpha_iso; alphaii = alpha_iso, alphaij = 0	18.9e-6	I/K	Basic

Nichrome Layer (mat3)

- I In the Model Builder window, click Nichrome Layer (mat3).
- 2 In the Settings window for Material, locate the Material Contents section.

3 In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Young's modulus	E	213e9	Pa	Young's modulus and Poisson's ratio
Poisson's ratio	nu	0.33	I	Young's modulus and Poisson's ratio
Density	rho	9000	kg/m³	Basic
Thermal conductivity	k_iso ; kii = k_iso, kij = 0	15	W/(m·K)	Basic
Heat capacity at constant pressure	Ср	20	J/(kg·K)	Basic
Electrical conductivity	sigma_iso; sigmaii = sigma_iso, sigmaij = 0	sigma_nic hrome	S/m	Basic
Relative permittivity	epsilonr_iso; epsilonrii = epsilonr_iso, epsilonrij = 0	1	I	Basic
Coefficient of thermal expansion	alpha_iso; alphaii = alpha_iso, alphaij = 0	10e-6	I/K	Basic

MESH I

Free Triangular I

- I In the Mesh toolbar, click \triangle More Generators and choose Free Triangular.
- 2 In the Settings window for Free Triangular, locate the Boundary Selection section.
- 3 From the Selection list, choose All boundaries.

Size 1

- I Right-click Free Triangular I and choose Size.
- 2 In the Settings window for Size, locate the Geometric Entity Selection section.

- 3 In the list, select 1.
- 4 Click Remove from Selection.
- **5** Select Boundaries 2–4 only.
- **6** Locate the **Element Size** section. Click the **Custom** button.
- 7 Locate the Element Size Parameters section.
- 8 Select the Maximum element size check box. In the associated text field, type 2.
- 9 Click III Build All.

STUDY I

In the **Home** toolbar, click **Compute**.

RESULTS

Stress, Assembly (Ishell)

In the Settings window for 3D Plot Group, type Stress, Assembly (1shell) in the Label text field.

Surface I

- I In the Model Builder window, expand the Stress, Assembly (Ishell) node, then click Surface 1.
- 2 In the Settings window for Surface, locate the Expression section.
- 3 From the Unit list, choose MPa.
- **4** Click the **Scene Light** button in the **Graphics** toolbar.
- 5 Click the **Zoom Extents** button in the **Graphics** toolbar.

ADD PREDEFINED PLOT

- I In the Home toolbar, click Add Predefined Plot to open the Add Predefined Plot window.
- 2 Go to the Add Predefined Plot window.
- 3 In the tree, select Study I/Solution I (soll)>Layered Shell>Stress, Slice (Ishell).
- 4 Click Add Plot in the window toolbar.

RESULTS

Stress, Glass (Ishell)

I Drag and drop below Stress, Assembly (Ishell).

- 2 In the Settings window for 3D Plot Group, type Stress, Glass (1shell) in the Label text field
- 3 Click to expand the Title section. From the Title type list, choose Manual.
- 4 In the Title text area, type Layered Material Slice: von Mises stress (MPa), Glass.

Layered Material Slice I

- I In the Model Builder window, expand the Stress, Glass (Ishell) node, then click Layered Material Slice I.
- 2 In the Settings window for Layered Material Slice, locate the Expression section.
- **3** From the **Unit** list, choose **MPa**.
- 4 Locate the Through-Thickness Location section. From the Location definition list, choose Physical.
- 5 In the Local z-coordinate text field, type 0 d_glass.

Stress, Glass (Ishell)

In the Model Builder window, right-click Stress, Glass (Ishell) and choose Duplicate.

Stress, Conducting Layer (Ishell)

- I In the Model Builder window, expand the Results>Stress, Glass (Ishell) I node, then click Stress, Glass (Ishell) I.
- 2 Drag and drop below Stress, Glass (Ishell).
- 3 In the Settings window for 3D Plot Group, type Stress, Conducting Layer (1shell) in the Label text field.
- 4 Locate the **Title** section. In the **Title** text area, type Layered Material Slice: von Mises stress (MPa), Conducting Layer.

Layered Material Slice 1

- I In the Model Builder window, click Layered Material Slice I.
- 2 In the Settings window for Layered Material Slice, locate the Through-Thickness Location section.
- 3 In the Local z-coordinate text field, type d_glass+d_layer.

Temperature, Shell (htlsh)

I In the Model Builder window, under Results click Temperature, Shell (htlsh).

2 In the Temperature, Shell (htlsh) toolbar, click Plot.

Surface 1

- I In the Model Builder window, expand the Results>Electric Potential (ecis) node, then click Surface 1.
- 2 In the Settings window for Surface, locate the Expression section.
- 3 In the Expression text field, type ecis. Vc.
- 4 In the Electric Potential (ecis) toolbar, click **Plot**.

ADD PREDEFINED PLOT

- I Go to the Add Predefined Plot window.
- 2 In the tree, select Study I/Solution I (soll)>Layered Shell>Geometry and Layup (Ishell)> Shell Geometry (Ishell).
- 3 Click Add Plot in the window toolbar.
- 4 In the Home toolbar, click Add Predefined Plot to close the Add Predefined Plot window.

RESULTS

Shell Geometry (Ishell)

- I Drag and drop below Stress, Conducting Layer (Ishell).
- 2 Right-click Shell Geometry (Ishell) and choose Duplicate.

Stack Zones

- I In the Model Builder window, click Shell Geometry (Ishell) I.
- 2 Drag and drop below Layer Cross-Section Preview.
- 3 In the Settings window for 3D Plot Group, type Stack Zones in the Label text field.

Surface I

- I In the Model Builder window, expand the Stack Zones node, then click Surface I.
- 2 In the Settings window for Surface, click Replace Expression in the upper-right corner of the Expression section. From the menu, choose Component I (compl)> Layered materials>Layered Material Stack I (stlmat1)>stlmat1.zone - Zone index - 1.
- 3 Locate the Coloring and Style section. From the Coloring list, choose Color table.
- 4 Click Change Color Table.
- 5 In the Color Table dialog box, select Traffic>Traffic in the tree.
- 6 Click OK.

7 In the Stack Zones toolbar, click **Plot**.

Surface Losses

- I In the Home toolbar, click Add Plot Group and choose 3D Plot Group.
- 2 In the Settings window for 3D Plot Group, type Surface Losses in the Label text field.

Surface I

- I In the Surface Losses toolbar, click Surface.
- 2 In the Settings window for Surface, click Replace Expression in the upper-right corner of the Expression section. From the menu, choose Component I (compl)> Electric Currents in Layered Shells>Heating and losses>ecis.Qsh Surface loss density, electromagnetic W/m².
- 3 In the Surface Losses toolbar, click Plot.

Take the following steps to generate a plot of the norm of the surface traction vector in the surface plane.

Interface Stress

- I In the Home toolbar, click **Add Plot Group** and choose **3D Plot Group**.
- 2 In the Settings window for 3D Plot Group, type Interface Stress in the Label text field.
- **3** Locate the **Title** section. From the **Title type** list, choose **Manual**.
- 4 In the Title text area, type Layered Material Slice: Interface Stress (MPa).

Layered Material Slice I

- In the Interface Stress toolbar, click More Plots and choose Layered Material Slice.
- 2 In the Settings window for Layered Material Slice, locate the Expression section.
- 3 In the Expression text field, type sqrt(lshell.sxz^2+lshell.syz^2).
- 4 From the Unit list, choose MPa.
- **5** Locate the **Through-Thickness Location** section. From the **Location definition** list, choose **Physical**.
- 6 In the Local z-coordinate text field, type d_glass.

Selection 1

- I Right-click Layered Material Slice I and choose Selection.
- **2** Select Boundaries 2–4 only.
- 3 In the Interface Stress toolbar, click Plot.

Next, plot the glass plate's deviation from being plane.

ADD PREDEFINED PLOT

- I In the Home toolbar, click Add Predefined Plot to open the Add Predefined Plot window.
- 2 Go to the Add Predefined Plot window.
- 3 In the tree, select Study I/Solution I (soll)>Layered Shell>Warpage (wrpl).
- 4 Click **Add Plot** in the window toolbar.
- 5 In the Home toolbar, click Add Predefined Plot to close the Add Predefined Plot window.

RESULTS

Warping Displacement

- I In the Model Builder window, expand the Warpage (wrpl) node, then click Warping Displacement.
- 2 In the Settings window for Surface, locate the Expression section.
- 3 In the **Unit** field, type um.

Average Displacement

- I In the Model Builder window, click Average Displacement.
- 2 In the Settings window for Surface, locate the Expression section.
- 3 In the **Unit** field, type um.
- 4 In the Warpage (wrp1) toolbar, click Plot.

To calculate the values for the total generated heat and the integrated heat flux on the fluid side, perform a boundary integration. Before creating integration nodes, add a Layered Material dataset with evaluation set on interfaces.

Layered Material

- I In the Model Builder window, expand the Results>Datasets node.
- 2 Right-click Results>Datasets>Layered Material and choose Duplicate.

Layered Material I

- I In the Model Builder window, click Layered Material I.
- 2 In the Settings window for Layered Material, locate the Layers section.
- 3 From the Evaluate in list, choose Interfaces.

Surface Integration 1

- I In the Results toolbar, click 8.85 More Derived Values and choose Integration>
 Surface Integration.
- 2 In the Settings window for Surface Integration, locate the Data section.
- 3 From the Dataset list, choose Layered Material 1.
- 4 Locate the Selection section. From the Selection list, choose All boundaries.
- 5 Click Replace Expression in the upper-right corner of the Expressions section. From the menu, choose Component I (compl)>Heat Transfer in Shells>Boundary fluxes> htlsh.hfi2.q0 Boundary convective heat flux W/m².
- 6 Click **= Evaluate**.

TABLE I

I Go to the Table I window.

The result should be close to 8.5 W.

RESULTS

Surface Integration 2

- I In the Results toolbar, click 8.85 More Derived Values and choose Integration>
 Surface Integration.
- 2 In the Settings window for Surface Integration, locate the Data section.
- 3 From the Dataset list, choose Layered Material I.
- 4 Select Boundaries 2-4 only.
- 5 Locate the Through-Thickness Location section. From the Location input list, choose Manual.
- 6 From the Location definition list, choose Physical.
- 7 Click Replace Expression in the upper-right corner of the Expressions section. From the menu, choose Component I (compl)>Electric Currents in Layered Shells> Heating and losses>ecis.Qsh Surface loss density, electromagnetic W/m².
- 8 Click **= Evaluate**.

TABLE 2

I Go to the Table 2 window.

The result should be close to 13.8 W.