

Outgassing Pipes

This benchmark model computes the pressure in a system of outgassing pipes with a high aspect ratio. The results are compared with a 1D simulation and a Monte-Carlo simulation of the same system from the literature.

Model Definition

The system consists of a long circular tube with a single change in cross section. A constant outgassing flux of 3×10^{-12} Torr-1/cm² is emitted from the walls of the pipes. Two pumps are attached to the system, one directly on the pipe and the other via an additional length of pipe. Both pumps operate at a pump speed of 30 l/s. The model geometry, along with the location of the two pumps, is shown in Figure 1.




Figure 1: Model geometry. The location of the two pumps is indicated. All other surfaces outgas at a constant rate of 3×10^{-12} Torr-l/cm².

Results and Discussion

Figures 2, 3 and 4 show the molecular flux, number density and pressure respectively on the surfaces of the pipes.




Figure 2: Molecular flux on the surface of the pipes.




Figure 3: Number density on the pipe surfaces.




Figure 4: Pressure in the pipes.




Figure 5: Pressure distribution along the top surface of the pipes. The results are compared with those from Ref. 1 and Ref. 2.

The pressure distribution in the pipes is in good agreement with the distributions given in Ref. 1 and Ref. 2.

Application Library path: Molecular Flow Module/Benchmarks/ outgassing pipes

References

- 1. J. Howell, B. Wherle, and H. Jostlein, "Calculation of pressure distribution in vacuum systems using a commercial finite element program," Proc. 991 IEEE Particle Accelerator Conference (APS Beam Physics), vol. 4, pp.2295-2297, 1991.
- 2. R. Kersevan, "Analytical and numerical tools for vacuum systems," CERN Accelerator School, Silken Park Hotel San Jorge, Platija d'Aro, Spain, 16-24 May 2006 (available at http://cas.web.cern.ch/cas/Spain-2006/PDFs/Kersevan.pdf).

Modeling Instructions

From the File menu, choose New.

In the New window, click Model Wizard.

MODEL WIZARD

- I In the Model Wizard window, click **3D**.
- 2 In the Select Physics tree, select Fluid Flow>Rarefied Flow>Free Molecular Flow (fmf).
- 3 Click Add.
- 4 Click \Longrightarrow Study.
- 5 In the Select Study tree, select General Studies>Stationary.
- 6 Click **Done**.

Define model parameters.

GLOBAL DEFINITIONS

Parameters 1

I In the Model Builder window, under Global Definitions click Parameters I.

- 2 In the Settings window for Parameters, locate the Parameters section.
- **3** In the table, enter the following settings:

Name	Expression	Value	Description
T0	293.15[K]	293.15 K	Temperature
Mn0	0.028[kg/mol]	0.028 kg/mol	Molar mass
ps	30[1/s]	0.03 m ³ /s	Pump speed

Define the geometry.

GEOMETRY I

- I In the Model Builder window, under Component I (compl) click Geometry I.
- 2 In the Settings window for Geometry, locate the Units section.
- 3 From the Length unit list, choose cm.

Cylinder I (cyl1)

- I In the Geometry toolbar, click Cylinder.
- 2 In the Settings window for Cylinder, locate the Size and Shape section.
- 3 In the Radius text field, type 2.
- 4 In the Height text field, type 400.
- 5 Locate the Axis section. From the Axis type list, choose x-axis.

Cylinder 2 (cyl2)

- I In the Geometry toolbar, click (Cylinder.
- 2 In the Settings window for Cylinder, locate the Size and Shape section.
- 3 In the Radius text field, type 5.
- 4 In the Height text field, type 100.
- **5** Locate the **Position** section. In the **x** text field, type 400.
- 6 Locate the Axis section. From the Axis type list, choose x-axis.

Cylinder 3 (cyl3)

- I In the Geometry toolbar, click Cylinder.
- 2 In the Settings window for Cylinder, locate the Size and Shape section.
- 3 In the Radius text field, type 2.
- 4 In the Height text field, type 2.
- **5** Locate the **Position** section. In the **x** text field, type 100.

6 In the z text field, type -2. Cylinder 4 (cyl4) I In the Geometry toolbar, click Cylinder. 2 In the Settings window for Cylinder, locate the Size and Shape section. 3 In the Radius text field, type 2. 4 In the Height text field, type 100. **5** Locate the **Position** section. In the **x** text field, type 300. 6 In the z text field, type -100. Cylinder 5 (cyl5) I In the Geometry toolbar, click (Cylinder. 2 In the Settings window for Cylinder, locate the Size and Shape section. 3 In the Radius text field, type 2. 4 In the Height text field, type 4. 5 Locate the **Position** section. In the x text field, type 98. 6 Locate the Axis section. From the Axis type list, choose x-axis. 7 Click **Build Selected**. Cylinder 6 (cyl6) I Right-click Cylinder 5 (cyl5) and choose Duplicate. 2 In the Settings window for Cylinder, locate the Position section. 3 In the x text field, type 298. 4 Click | Build Selected. Cylinder 7 (cyl7) I In the Geometry toolbar, click (Cylinder. 2 In the Settings window for Cylinder, locate the Size and Shape section. 3 In the Radius text field, type 2. 4 In the Height text field, type 2. **5** Locate the **Position** section. In the **x** text field, type 300. 6 In the z text field, type -2. 7 Click | Build Selected. Union I (uni I) I In the Geometry toolbar, click Booleans and Partitions and choose Union.

- 2 In the Settings window for Union, locate the Union section.
- 3 Clear the Keep interior boundaries check box.
- 4 Click in the **Graphics** window and then press Ctrl+A to select all objects.
- 5 Click | Build Selected.
- 6 Click the **Zoom Extents** button in the **Graphics** toolbar.

Add interpolation functions for benchmark comparisons.

DEFINITIONS

Interpolation I (int I)

- I In the Home toolbar, click f(X) Functions and choose Local>Interpolation.
- 2 In the Settings window for Interpolation, locate the Definition section.
- 3 Click Load from File.
- **4** Browse to the model's Application Libraries folder and double-click the file outgassing_pipes_howell.txt.

Interpolation 2 (int2)

- I In the Home toolbar, click f(x) Functions and choose Local>Interpolation.
- 2 In the Settings window for Interpolation, locate the Definition section.
- 3 Click Load from File.
- **4** Browse to the model's Application Libraries folder and double-click the file outgassing_pipes_kersevan.txt.

Set up the physics and boundary conditions.

FREE MOLECULAR FLOW (FMF)

Molecular Flow 1

- I In the Model Builder window, under Component I (compl)>Free Molecular Flow (fmf) click Molecular Flow I.
- 2 In the Settings window for Molecular Flow, locate the Molecular Weight of Species section.
- **3** In the $M_{\text{n.G}}$ text field, type Mn0.

Surface Temperature 1

- I In the Model Builder window, click Surface Temperature 1.
- 2 In the Settings window for Surface Temperature, locate the Surface Temperature section.
- **3** In the *T* text field, type T0.

Wall I

- I In the Model Builder window, click Wall I.
- 2 In the Settings window for Wall, locate the Wall Type section.
- 3 From the Wall type list, choose Outgassing wall.
- 4 Locate the Flux section. From the Outgoing flux list, choose Thermal desorption rate.

Vacuum Pump 1

- I In the Physics toolbar, click Boundaries and choose Vacuum Pump.
- 2 Select Boundaries 10 and 12 only.
- 3 In the Settings window for Vacuum Pump, locate the Vacuum Pump section.
- 4 From the Specify pump flux list, choose Pump speed.
- **5** In the S_G text field, type ps.

Vacuum Pumb 2

- I Right-click Vacuum Pump I and choose Duplicate.
- 2 In the Settings window for Vacuum Pump, locate the Boundary Selection section.
- 3 Click Clear Selection.
- 4 Select Boundary 26 only.

Mesh the geometry.

MESH I

Edge I

- I In the Mesh toolbar, click A Boundary and choose Edge.
- **2** Select Edges 9, 10, 12, 13, 15, 18, 22, 26, 29, 30, 32, 34, 37, 38, 43, 44, 46, 48, 54, 60, 63, 64, 67, 69, 72, 73, 75–77, and 79–81 only.

This rather long list includes all of the circular edges where different cylinders are connected in the geometry. A shortcut is to copy the selection list from these instructions and then click the Paste selection button. An alternative is to create an Explicit selection, where you can select the Group by continuous tangent check box to reduce the number of clicks required.

Size

- I In the Model Builder window, click Size.
- 2 In the Settings window for Size, locate the Element Size section.
- 3 From the Predefined list, choose Extra fine.

Mapped I

- I In the Mesh toolbar, click A Boundary and choose Mapped.
- **2** Select Boundaries 2–5, 18–21, 24, 25, 31, 34, 37–40, and 42–45 only.

This boundary selection comprises the sides of all of the long cylinders in the geometry. As for the edge selection above, an Explicit selection with the Group by continuous tangent check box can reduce the number of clicks required.

Distribution 1

- I Right-click Mapped I and choose Distribution.
- **2** Select Edges 3, 51, 65, and 74 only.
- 3 In the Settings window for Distribution, locate the Distribution section.
- 4 In the Number of elements text field, type 80.

Distribution 2

- I In the Model Builder window, right-click Mapped I and choose Distribution.
- **2** Select Edge 31 only.
- 3 In the Settings window for Distribution, locate the Distribution section.
- 4 In the Number of elements text field, type 160.
- 5 Click **Build Selected**.

Free Triangular 1

- I In the Mesh toolbar, click A Boundary and choose Free Triangular.
- 2 In the Settings window for Free Triangular, locate the Boundary Selection section.
- 3 From the Geometric entity level list, choose Remaining.
- 4 Click Build All.

STUDY I

In the **Home** toolbar, click **Compute**.

RESULTS

Total Pressure (fmf)

Plot the pressure profile.

ID Plot Group 4

- I In the Home toolbar, click Add Plot Group and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, click to expand the Title section.
- **3** From the **Title type** list, choose **None**.

- 4 Locate the Plot Settings section.
- **5** Select the **x-axis label** check box. In the associated text field, type **Position** (cm).
- **6** Select the **y-axis label** check box. In the associated text field, type Pressure (torr).

Line Graph 1

- I Right-click ID Plot Group 4 and choose Line Graph.
- 2 In the Settings window for Line Graph, locate the y-Axis Data section.
- **3** In the **Expression** text field, type fmf.ptot.
- 4 Locate the x-Axis Data section. From the Parameter list, choose Expression.
- **5** In the **Expression** text field, type x.
- 6 Locate the y-Axis Data section. From the Unit list, choose Torr.
- **7** Select Edges 7, 19, 33, 35, 49, 70, and 82 only.
- 8 Click to expand the **Legends** section. Select the **Show legends** check box.
- 9 From the Legends list, choose Manual.
- **10** In the table, enter the following settings:

Legends COMSOL 3D Angular Coefficient

Line Graph 2

- I Right-click Line Graph I and choose Duplicate.
- 2 In the Settings window for Line Graph, locate the y-Axis Data section.
- 3 In the Expression text field, type int1(x/1[cm]).
- **4** Locate the **Legends** section. In the table, enter the following settings:

Legends Howell 1D Conductance Model

Line Grabh 3

- I Right-click Line Graph 2 and choose Duplicate.
- 2 In the Settings window for Line Graph, locate the y-Axis Data section.
- 3 In the Expression text field, type int2(x/1[cm]).
- **4** Locate the **Legends** section. In the table, enter the following settings:

Legends						
Kersevan	3D	Monte	Carlo			

Pressure Profile

- I In the Model Builder window, under Results click ID Plot Group 4.
- 2 In the Settings window for ID Plot Group, type Pressure Profile in the Label text field.
- 3 Locate the Legend section. From the Position list, choose Lower right.
- 4 Locate the Axis section. Select the Manual axis limits check box.
- 5 In the y minimum text field, type 1e-10.
- 6 In the y maximum text field, type 1e-8.
- 7 Select the y-axis log scale check box.
- 8 In the Pressure Profile toolbar, click Plot. Compare the resulting plot with that in Figure 5.