

Creating the PS4 Adaptive controller

Table of contents

1.	Introduction	2
2.	Bill of materials (BOM).....	3
3.	Preparations	4
3.1	Dissasemble the controller	4
3.2	De-solder the joysticks	11
4.	Assembly.....	13
4.1	Placing and fastening 3.5mm sockets	13
4.2	Screw pcb to pcb holder	13
4.3	Soldering the speaker	14
4.4	Screwing the pcb holder to the case.....	15
4.5	Soldering the buttons to sockets.....	15
4.6	Place and connect usb port module	41
4.7	Secure the battery.....	42
5.	Testing	43
6.	Troubleshooting	45

1. Introduction

The PS4 Adaptive controller is designed to be used by people with a physical limitation. The modular designs allows the buttons and joysticks (we call them ,modules') to be placed as the user needs them.

By making it open source we allow the community to come up with their own designs and share them with others.

The skillset required to create your own controller is kept as low as possible to allow the creation of as much controllers as possible: Knowledge of using a soldering iron, access to and knowledge of a 3D printer and a laser cutter (optional), and the use of some basic tools like a wire stripper are the only things needed. We try to provide as much information as we can on how to create your own controller.

If you have any questions you can contact me at kefcom@hotmail.com

Have fun creating and using the ps4 adaptive controller,

Kevin E. (-kefcom-)

2. Bill of materials (BOM)

The list of materials needed to create a ps4 adaptive controller and a link to where to buy them are listed in Bill_Of_Materials.txt.

We keep it central so people can modify it when needed.

If a link is dead contact me at kefcom@hotmail.com and I'll try to provide a new link.

3. Preparations

3.1 Print and/or laser cut the models

3D print the PCB holder model and print or laser cut the front and back plate.


3.2 Disassemble the controller

This is where the real work begins :).

At the back of the controller there are 4 screws, unscrew them.



Now open the shell, but be careful of the flex cable from the usb port to the pcb!



Gently unplug the cable on the PCB side and put the top shell away for now.


Disconnect the battery and remove it. The plastic holder can be removed as well.




De-solder the vibrators left and right (the red and black wires)



Unplug the touchpad flex (lift the black tab and unplug the cable)




Remove the screw in the center




Now remove the middle assembly and remove the pcb.

You should end up with the pcb with the joysticks




Now take the shell with the usb port


Lift the white bar holding the plastics in place and remove the plastics



Remove the screw holding the usb port in place and remove the usb port



You should end up with a usb port assembly:



Now for some cleanup of the rest of the shell. These components are re-used in some modules, so take them if you want to create the speaker and d-pad module

Remove the d-pad pad and plastic



To remove the speaker, **gently** push from the front. It's glued in place




This concludes the cleanup and disassembly of the controller.


3.3 De-solder the joysticks

Be very careful in this step! If you flex the board too much or over heat it, the controller can break and become useless.


First remove the joystick tops, these can be pulled off.



Then pry the potentiometers from the joysticks and de-solder them first



After the potmeters are gone you can start to work on the joysticks themselves



What I found what works for me is to use a small screwdriver and stick it between the pcb and the joystick, please keep in mind to be gentle and not put too much force when prying.

This concludes the prep work, next step: assembly!

4. Assembly


4.1 Placing and fastening 3.5mm sockets

Place the 24 sockets in the front plate and secure them with the provided nuts.

When finished, flatten all ground pins (the top ones) for easy access later.


4.2 Screw pcb to pcb holder

Place the pcb on the pcb holder, with the headset port facing down, then screw the pcb to the holder as seen in the image




4.3 Soldering the speaker

Before we screw the pcb holder to the case, we need to solder the speaker. Use the following schematic to solder the speaker to the socket.




Wiring the speaker

Connect as shown



4.4 Screwing the pcb holder to the case

Align the 4 pre-made holes in the pcb holder to the case and screw the pcb holder to the case.





4.5 Soldering the buttons to sockets

Time to solder all the things!

Use the schematics to solder the buttons to the sockets.


4.5.1 Create a shared ground plane

Because all the buttons (except L2 and R2) need to be connected to P1 on the pcb, we need to create a ground plane. To do this solder all the top pins (except VIBR,SND,L2,R2 and the 4 joystick sockets) together via 1 wire and connect that 1 wire to pad P1 on the pcb.





Creating a shared ground for buttons

Solder a wire across all ground pins that are marked. then solder a single wire to GND




4.5.2 Create a shared VCC for L2 and R2

Same as for the shared ground, but for VCC (pad P3 on the pcb) L2 and R2 need VCC instead of GND.





Creating a shared VDD for L2 and R2

Solder a wire across all ground pins that are marked.
then solder a single wire to VDD




4.5.3 Soldering the vibrator





Wiring the vibrator

Connect + and - pads on the board to the socket as shown.




4.5.4 Soldering the 'up' D-pad button





Wiring the up button

Connect ground pin to shared ground to GND
and bottom pin to AU




4.5.5 Soldering the 'left' D-pad button





Wiring the left button

Connect ground pin to shared ground to GND
and bottom pin to A1




4.5.6 Soldering the options button





Wiring the options button

Connect ground pin to shared ground to GND and bottom pin to OP




4.5.7 Soldering the triangle button





Wiring the triangle button

Connect ground pin to shared ground to GND and bottom pin to Y




4.5.8 Soldering the X button





Wiring the X button

Connect ground pin to shared ground to GND and bottom pin to A




4.5.9 Soldering the PS button





Wiring the PS button

Connect ground pin to shared ground to GND and bottom pin to PS




4.5.10 Soldering the L3 button





Wiring the L3 button

Connect ground pin to shared ground to GND and bottom pin to KL3




4.5.11 Soldering the L2 button





Wiring the L2 button

Connect ground pin to VDD shared with R2 and bottom pin to KL2




4.5.12 Soldering the L1 button





Wiring the L1 button

Connect ground pin to shared ground to GND and bottom pin to KL1




4.5.13 Soldering the left joystick (up/down)





Wiring the left joystick Up/Down

Connect as shown, remember that the pcb is upside down when you solder, so the left joystick is on the right!




4.5.14 Soldering the left joystick (left/right)





Wiring the left joystick Left/Right

Connect as shown, remember that the pcb is upside down when you solder, so the left joystick is on the right!




4.5.15 Soldering the 'down' d-pad button





Wiring the down button

Connect ground pin to shared ground to GND and bottom pin to AD




4.5.16 Soldering the 'right' d-pad button





Wiring the right button

Connect ground pin to shared ground to GND and bottom pin to AR




4.5.17 Soldering the share button





Wiring the share button

Connect ground pin to shared ground to GND and bottom pin to SH




4.5.18 Soldering the circle button





Wiring the circle button

Connect ground pin to shared ground to GND and bottom pin to B




4.5.19 Soldering the square button





Wiring the square button

Connect ground pin to shared ground to GND and bottom pin to X




4.5.20 Soldering the touch button




Wiring the touch button

Connect ground pin to shared ground to GND and bottom pin to TO




4.5.21 Soldering the R3 button





Wiring the R3 button

Connect ground pin to shared ground to GND and bottom pin to KR3




4.5.22 Soldering the R2 button





Wiring the R2 button

Connect ground pin to **VDD** shared with L2 and bottom pin to KR2




4.5.23 Soldering the R1 button





Wiring the R1 button

Connect ground pin to shared ground to GND and bottom pin to KR1




4.5.24 Soldering the right joystick (up/down)





Wiring the right joystick Up/Down

Connect as shown, remember that the pcb is upside down when you solder, so the right joystick is on the left!




4.5.25 Soldering the right joystick (left/right)




Wiring the right joystick Left/Right

Connect as shown, remember that the pcb is upside down when you solder, so the right joystick is on the left!



4.6 Place and connect usb port module


Place the USB module in the provided slot and use a screw to secure it to the pcb holder.



4.7 Secure the battery

Use some putty adhesive (blue tack / stuff to put posters up on your wall) around the bottom of the battery to secure it in the provided slot.

Connect the battery to the PCB.



5. Testing

Now comes the time to test, to perform a test you need 2 joysticks and at least 1 button.


Connect the 2 joysticks

Connect the controller via usb to a windows pc (if you don't have one, I propose you test directly on the ps4)

Open the control panel and go to hardware and sound -> devices and printers -> find your controller ('wireless controller'), right click and select game controller settings.

A new window will open, select properties.

A new window will open:



Here you can test the controller, make sure the joysticks work (in this image there are no joysticks connected, the crosshair should be in the middle and the Z axis and rotation should show half a bar).

Use the following mapping to test your buttons. The number of the pressed button should light up

Button	Number
Up	Point of view Hat
Down	Point of view Hat
Options	10
Triangle	4
X	2
PS	13
L3	11
L2	7
L1	5
Down	Point of view Hat
Right	Point of view Hat
Share	9
Circle	3
Square	1
Touch	14
R3	12
R2	8
R1	6

If all works, you're good to go!

Place the back plate and close the case using the provided screws and feet.

Remember that just like a normal controller you need to connect the ps4 adaptive controller to the PS4 via usb before you can use it wirelessly.

6. Troubleshooting

Here are a few troubleshooting tips:

Problem	Suggested solution
No connection	Make sure the USB port flex cable is plugged in with the blue marker facing left.
No connection	Try to test with joysticks attached, sometimes the pcb does not work if no joysticks are connected.
Joysticks not working (or behaving strange)	Make sure you wired it as shown in the schematic. The joysticks have to be wired exact.
Connection lost when pressing L2/R2	You might have connected them to ground instead of VCC. Make sure the top pin of the socket goes to P3 instead of P1
Pressing 1 button triggers 2 or more	You might have a short somewhere, check cables to see if the copper touches