

### **Please Call First!**

#### **DO NOT RETURN TO STORE**

Need help with assembly? Missing or broken parts?

**Business Hours: M-F 8am-5pm PST** 

Toll Free: 1 (866) 632-6632 support@slambrands.com

03.08 C

# **AURA**WIDE TV STAND

**Assembly Instructions** 

Item #222258







### IMPORTANT INFORMATION

Read carefully before assembling TV Stand. Keep these instructions for further use.




#### **SAFETY FIRST**

- ! When moving TV Stand, remove TV first. Do NOT move TV Stand with a TV on top
- ! TVs are front heavy. Place TV as far from front surface of stand as possible.
- ! To avoid injury, assemble TV Stand in final location. Moving the stand after assembled is not recommended.

This product is sold with anti-tip hardware and it is intended that the product be used with this hardware attached. Danger from tipping may result if the hardware is not attached to both the wall and the TV Stand. Slam Brands, Inc. is not responsible for any personal injury or damage to stand, television, components, or household effects resulting from improper use of this product.




### **ASSEMBLY OVERVIEW**





### PARTS IDENTIFICATION





## HARDWARE IDENTIFICATION



(A) 1/4" x 3/4" Hex Bolt (6) H00240



(B) 1/4" x 11/2" Hex Bolts (10) H00044



© Ø 13mm Washer (10) H00212



① Ø ¼" Spring Washer (10) H00193



E 4 x 4mm Allen Wrench (1) H00005



F) 6mm Rubber Bumper (12) H00194



G 46 x 20 x 4mm Safety Bracket (2) H00228



(H) #7 x 1<sup>1</sup>/<sub>4</sub>" Wood Screws (2) H00195



(1) #7 x 3/4" Wood Screws (2) H00211



J 250 x 8 x 1mm Safety Bracket Strip (1) H00230



(K) 15 x 11mm Cams (4) H00092




(L) 7 x 32mm Cam Bolts (4) H00074




## THE "CAM" ASSEMBLY SYSTEM

THIS PAGE IS A <u>REFERENCE</u> FOR COMPLETING THE STEP-BY-STEP INSTRUCTIONS ON THE FOLLOWING PAGES. BEGIN ASSEMBLY WITH STEP 1. REFER TO THIS PAGE FOR ADDITIONAL INFORMATION AS DIRECTED.




Screw Cam Bolts (L) into designated holes.




Press Cams (K) into designated holes.

Arrow on Cams should face the hole at the edge of the board.



Align Cam Bolt with hole at Cam and press boards together.




Turn Cam ½ turn clockwise to lock.



### STEP 1: ASSEMBLE WOOD DETAILS AND SIDE SUPPORTS


Please refer to the "Cam" assembly system.

WARNING: DO NOT APPLY DOWNWARD PRESSURE WHEN INSERTING CAMS.






# STEP 2: ASSEMBLE FRAME




# STEP 3: ATTACH BACKBOARD





### STEP 4: PLACE AND SECURE GLASS TOP AND SHELVES



### STEP 5: SECURE STAND TO WALL

