1 Hello_NuMaker-M032BTAI

1.1 Prerequisites

Before proceeding with the commands, ensure you have the following installed:

- make
- gcc-arm-none-eabi or docker
- Python 3.7+ and pip (for flashing and debugging)

1.2 Quick Commands

The following quick commands are available for convenience:

• make upgrade: Executes make clean, make, and make flash sequentially.

1.3 Building the Firmware

1.3.1 Using Makefile

To build the firmware using Makefile, run:

```
1 make clean && make
```

or build the firmware using Docker:

```
1 make update && make docker
```

1.4 Flashing the Firmware

We use pyOCD for cross-platform compatibility and to support the latest versions. OpenOCD is not used in this process.

1.4.1 Installing pyOCD

First, install pyOCD using pip:

```
1 python -m pip install -U pyocd
```

1.4.2 Installing the Required Pack

Next, install the pack for the target MCU:

```
1 pyocd pack install M032BTAIAAN
```

1.4.3 Flashing the MCU

Finally, flash the MCU with the following command:

```
1 make flash
```

1.5 Debugging the Firmware

To debug the firmware manually, use the following commands:

1.5.1 Starting the GDB Server

Start the GDB server with pyOCD:

```
pyocd gdbserver -t M032BTAIAAN --elf Source\build\TRSP_UART_Central.elf
```

1.5.2 Connecting GDB to the Target

In the GDB command line, connect to the target and load the firmware:

```
1 (gdb) target remote localhost:3333
2 (gdb) monitor reset halt
3 (gdb) load
```

1.6 Documentation

To build the documentation, run:

```
1 make docs
```

1.6.1 You need to install these software first

• On Windows:

```
1 choco install -y pandoc miktex
```

• On macOS:

```
1 brew install pandoc
2 brew install --cask mactex-no-gui
```

• On Linux:

```
sudo apt-get update && sudo apt-get install -y pandoc texlive-latex-
base texlive-fonts-recommended texlive-fonts-extra texlive-latex-
extra
```

• Then, install the required extensions:

```
1 make docs-install
```