
Board can be configured for Line or Tree/Star network. Tile 0 UART.TX LVDS7.out1 L7.in1 ← LVDS7.out0 OUT0 L7.in0 ← L7.out0 D L7.out1 D L7.in0 < LVDS7.in0 DINO POWER XTAG LVDS7.in1 LVDS_EN UART_RX ♦ DLVDS_EN LVDS.sch UART_TX ♦ XTAGout.in1 >XL.in1 RST L4.in1 < XTAGout.in0 XL.in0 TileO.sch XTAGout.out0 XL.out0 power.sch XTAGout.out1 DXL.out1 XTAG.in1 >XTAG.in1 XTAG.in0 Tile1 >XTAG.in0 XTAG.out0 XMOS USB/JTAG XTAG.out0 L7.in1< LVDS4.out1 L4.in1 ← XTAG.out1 OXTAG.out1 XMOS_TDO 2 LVDS4.out0 L4.in0 TDI 1 LVDS4.in0 >TDI XMOS_TDID L4.out0 TMS L4.out0D DINO TMS L4.out1D L4.out1 LVDS4.in1 DIN1 TCK >TCK DEBUG **DEBUG ♦** ♦ DEBUG XTAG.sch XMOS_USB.sch LVDS_EN LINE TREE LVDS2 L2.in1 →XTAGout.out1 TREE LINE L2.in1 L2.in1 V+□→ +3V3 LVDS3 XTAG.out1 → →XTAGout.out0 LVDS2.out0 DEN OUT1D / DL3.in1 L2.in0< L3.in0 L2.out0 LVDS3.out0 XTAG.out0 → ← XTAGout.in0 L2.out0 ✓ LVDS2.in0 >INO +3∨3 ← ∪∨+ >L3.in0 L3.out0 XTAG.in0 ← LVDS2.in1 >IN1 v-d→ \ \frac{2}{5} L3.out0 L2.out1 ₹ 4+v-LVDS.sch L3.out1 RN2 XTAG.in1 ← <mark>⊒ 3</mark> □L3.out0 1L3.out1 LVDS.sch Tile1.sch Open Source openPnP Sheet: / H2 MountingHole H4 MountingHole File: XMOS_XUF216_FB236.sch Title: XMOS top level Size: A4 Date: 2019-01-03 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 1/16




RJ45 PINOUT:

Lx0 IN +/-3/6

Lx1_OUT +/-

Lx1_IN +/-



RJ45_smetueu DOUT1+ J1 L.out1-DOUT-DIN1 L.in0-DIN2 INOD-DOUT2+ DOUT2-ROUT1 OUTO & RIN1+ 0UT1 **(** ROUT2 RIN1-R4 100R RIN2+ Not a Diff-pair. (EN & !EN) $\frac{16}{9}$ EN L.in1-GND RIN2-100R DS90LV049TMT 100nF C1

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.


	_		
Lx0_OUT +	1 🔪	1	Lx0_OUT -
Lx0_OUT -	2	\sim 2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	$\sqrt{4}$	Lx1_OUT -
Lx1_OUT -	$5 \searrow$	5	Lx1_OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	→ 8	Lx1_IN -
	T		
DC GND	SHIELD -	SHIELD	DC GND


Open Source openPnP Sheet: /LVDS7/ File: LVDS.sch Title: LVDS <-> Xlinks


Size: A4 Date: 2019-01-03 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 2/16


Cards can be power by USB or by the barrel jack 8-48V. Alternative "+48V" can come from a connected daugther card. Both USB and +48V should not be connected on the same PCB. USB ground should be isolated from power ground for PC safety.

Power ports are Global in the schematics.










VDDIO/OTP_VCC and VDD can ramp up independently.


In order to reduce stresses on the device, it is preferable to make them ramp up in a short time frame of each other, no more than 50 ms apart.

RST_N and TRST_N should be kept low until all power supplies are stable and within tolerances of their final voltage.

If your design is powered by VBUS, then RST_N should go high within 10 ms of attaching to VBUS in order to ensure that USB timings are met. RST_N should be at least 1 ms after VDDIO good to enable the built—in flash to settle

m





Open Source

openPnP

Sheet: /POWER/
File: power.sch

 File: power.sch

 Title: Power


 Size: A4
 Date: 2019-01-03
 Rev: BETA


 KiCad E.D.A. kicad (5.0.2)-1
 Id: 3/16





Lx0 IN +/-





100nF C15


Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.


This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.


T 0 07777	. 4		T 0 01777
$Lx0_OUT +$	$1 \sim$	1	Lx0_OUT +
Lx0_OUT -	2 🔪 🕽 🗲	1 /2	Lx0_OUT -
$Lx0_IN +$	3	> 3	$Lx0_IN +$
Lx1_OUT +	4 🔪	4	Lx1_OUT +
Lx1_OUT -	5 >	5	Lx1_OUT -
Lx0 IN -	6	6	Lx0 IN -
Lx1 IN +	7	7	Lx1 IN +
Lx1_IN -	8	8	Lx1_IN -
]		
DC GND	SHIELD 🕳	→ SHIELD	DC GND


Open Source openPnP Sheet: /LVDS2/ File: LVDS.sch Title: LVDS <-> Xlinks


Size: A4 Date: 2019-01-03 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 4/16














4/5 Lx1_OUT +/-


7/8 Lx1_IN +/-



DOUT2-ROUT1 OUTO & RIN1+ 0UT1 **(** ROUT2 RIN1-R34 100R L.in1+ RIN2+ Not a Diff-pair. (EN & !EN) END END END L.in1-GND RIN2-!EN R33 100R DS90LV049TMT 100nF C46

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.




Open Source
openPnP
Sheet: /Tile1/LVDS1/
File: LVDS.sch

 Title: LVDS <-> Xlinks

 Size: A4
 Date: 2019-01-03
 Rev: BETA


 KiCad E.D.A. kicad (5.0.2)-1
 Id: 9/16





4/5 Lx1_OUT +/-

7/8 Lx1_IN +/-



OUTO 14 ROUT2 RIN1+
OUT1 O 14 ROUT2 RIN1+
ROUT2 RIN1+
ROUT2 RIN2+

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transclever needs to be in HiZ during XMOS reset.


This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.


R38 100R

	_		
Lx0_OUT +	1 🔪	1	Lx0_OUT -
Lx0_OUT -	2	2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	4	Lx1_OUT -
Lx1_OUT -	$5 \searrow$	5	Lx1_OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	→ 8	Lx1_IN -
	T		
DC GND	SHIELD 🕳	SHIELD	DC GND

Open Source
openPnP
Sheet: /LVDS4/
File: LVDS.sch

Title: LVD3 <-> Alliks		
Size: A4	Date: 2019-01-03	Rev: BETA
KiCad E.D.A. ki	cad (5.0.2)-1	ld: 10/16








Lx0 IN +/-3/6

Lx1_OUT +/-

 $Lx1_IN +/-$



DOUT2-ROUT1 OUTO & RIN1+ 0UT1 **(** ROUT2 RIN1-R45 100R RIN2+ Not a Diff-pair. (EN & !EN) $\frac{16}{9}$ EN L.in1-RIN2- 4 GND !EN 100R DS90LV049TMT


> Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

	_		
Lx0_OUT +	1 🔪	1	Lx0_OUT -
Lx0_OUT -	2	2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	4	Lx1_OUT -
Lx1_OUT -	$5 \searrow$	5	Lx1_OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	→ 8	Lx1_IN -
	T		
DC GND	SHIELD 🕳	SHIELD	DC GND

Open Source openPnP Sheet: /Tile0/LVDS6/ File: LVDS.sch


Title: LVDS <-> Xlinks Size: A4 Date: 2019-01-03 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 12/16





4/5 Lx1_OUT +/-

7/8 Lx1_IN +/-



DOUT2-ROUT1 OUTO & RIN1+ 0UT1 **(** ROUT2 RIN1-R49 100R RIN2+ Not a Diff-pair. (EN & !EN) $\frac{16}{9}$ EN L.in1-RIN2- 4 GND !EN R48 100R DS90LV049TMT

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

	_		
Lx0 OUT +	1	_1	Lx0 OUT -
Lx0_OUT -	2	\sim 2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	$\sqrt{4}$	Lx1_OUT -
Lx1_OUT -	$5 \searrow$	\sim 5	Lx1_OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	\ 8	Lx1_IN -
	T	•	
DC GND	SHIELD -	SHIELD	DC GND


Open Source
openPnP
Sheet: /TileO/LVDS5/

File: LVDS.sch

Title: LVDS <-> Xlinks

 Size: A4
 Date: 2019-01-03
 Rev: BETA


 KiCad E.D.A. kicad (5.0.2)-1
 Id: 13/16





4/5 Lx1_OUT +/-

7/8 Lx1_IN +/-



DOUT2-ROUT1 OUTO & RIN1+ 0UT1 **(** ROUT2 RIN1-R53 100R RIN2+ Not a Diff-pair. (EN & !EN) END_{0}^{16} EN L.in1-GND RIN2-!EN R52 100R DS90LV049TMT 100nF C50

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

Lx0_OUT +	1 🔪	1	Lx0_OUT -
Lx0_OUT -	2	2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	$\sqrt{4}$	Lx1_OUT -
Lx1_OUT -	$5 \searrow$	5	Lx1_OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	→ 8	Lx1_IN -
	T		
DC GND	SHIELD -	SHIELD	DC GND

Open Source openPnP

Sheet: /Tile0/LVDS0/ File: LVDS.sch

File: LVDS.sch

Title: LVDS <-> Xlinks


 Size: A4
 Date: 2019-01-03
 Rev: BETA

 KiCad E.D.A. kicad (5.0.2)-1
 Id: 14/16

3

2

3








4/5 Lx1_OUT +/-

7/8 Lx1_IN +/-



Not a Diff-pair. (EN & !EN) END 16 EN END 15 EN END 16 EN END 25 END 25

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transclever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

R57 100R

	_		
Lx0_OUT +	1 🔪	1	Lx0_OUT +
Lx0_OUT -	2	\sim 2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	$\sqrt{4}$	Lx1_OUT +
Lx1_OUT -	$5 \searrow$	\sim 5	Lx1_OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	→ 8	Lx1_IN -
	T		
DC GND	SHIELD -	SHIELD	DC GND

Open Source
openPnP
Sheet: /LVDS3/
File: LVDS.sch

Title: LVDS <-> Xlinks

 Title: LVD3 <-> Xtiliks

 Size: A4
 Date: 2019-01-03
 Rev: BETA

 KiCad E.D.A. kicad (5.0.2)-1
 Id: 16/16