
Board can be configured for Line or Tree/Star network. Tile 0 UART.RX UART.TX LVDS7.out1 L7.in1 ← V+□→ +3V3 L7.in0 ← LVDS7.out0 L7.out0 D L7.out1 2 L7.in0 < аоито LVDS7.in0 DINO POWER XTAG LVDS7.in1 LVDS_EN UART_RX ♦ DLVDS_EN LVDS.sch UART_TX 💠 XTAGout.in1 >XL.in1 RST L4.in1 < XTAGout.in0 XL.in0 Tile0.sch XTAGout.out0 XL.out0 power.sch XTAGout.out1 XL.out1 XTAG.in1 >XTAG.in1 XTAG.in0 Tile1 >XTAG.in0 XTAG.out0 XMOS USB/JTAG LVDS4 XTAG.out0 L7.in1< LVDS4.out1 L4.in1 ← XTAG.out1 OXTAG.out1 XMOS_TDO 2 LVDS4.out0 L4.in0 ← L4.in0 OTUOD TDI 1 LVDS4.in0 XMOS_TDID >TDI L4.out0 TMS L4.out0D >INO L4.out1D L4.out1 TMSD TMS LVDS4.in0 DIN1 TCK >TCK DEBUG **DEBUG ♦** ♦ DEBUG XTAG.sch XMOS_USB.sch LVDS_EN LINE TREE LVDS2 L2.in1 →XTAGout.out1 aout1 TREE LINE L2.in1 L2.in1 LVDS3 V+□→ +3V3 XTAG.out1 → →XTAGout.out0 LVDS2.out0 DEN OUT1D 6 DL3.in1 L2.in0< L3.in0 ← XTAGout.in0 ENC LVDS3.out0 XTAG.out0 → LVDS2.in0 >INO L3.in0 L2.out0 +3∨3 ← ∪∨+ >L3.in0 L3.out0 L2.out1 XTAG.in0 ← L2.out0D LVDS2.in1 >IN1 v-d→ \ \frac{2}{5} L3.out0 L2.out1D L2.out1 ₹ 4+v-LVDS.sch L3.out1 RN2 XTAG.in1 ← 3 (1L3.out0 -\13.out1 LVDS.sch Tile1.sch Open Source openPnP Sheet: / File: XMOS_XUF216_FB236.sch Title: XMOS top level Size: A4 Date: 2019-01-01 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 1/16






3/6 Lx0 IN +/-

4/5 Lx1_OUT +/-

7/8 Lx1_IN +/-



Not a Diff-pair. (EN & !EN) END 16 EN 2 EN END 18 EN 2 DS90LV049TMT

| Not a Diff |

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

Lx(OUT +	1 🔪	1	Lx0_OUT -
Lx(_OUT -	2	/2	Lx0_OUT -
Lx(IN +	3	> 3	Lx0_IN +
Lx1	L_OUT +	4 🔪	4	Lx1_OUT -
Lx1	L_OUT -	$5 \searrow$	\sim 5	Lx1_OUT -
Lx(_IN -	6	6	Lx0_IN -
Lx1	L_IN +	7	7	Lx1_IN +
Lx1	L_IN -	8	→ 8	Lx1_IN -
		•	ľ	
DC	GND	SHIELD -	■ SHIELD	DC GND

Open Source
openPnP
Sheet: /LVDS7/
File: LVDS.sch

 Title:
 LVDS
 <-> Xlinks


 Size:
 A4
 Date:
 2019-01-01


 Size: A4
 Date: 2019-01-01
 Rev: BETA


 KiCad E.D.A. kicad (5.0.2)-1
 Id: 2/16


Cards can be power by USB or by the barrel jack 8-48V. Alternative "+48V" can come from a connected daugther card. Both USB and +48V should not be connected on the same PCB. USB ground should be isolated from power ground for PC safety.

Power ports are Global in the schematics.











VDDIO/OTP_VCC and VDD can ramp up independently.


In order to reduce stresses on the device, it is preferable to make them ramp up in a short time frame of each other, no more than 50 ms apart.

RST_N and TRST_N should be kept low until all power supplies are stable and within tolerances of their final voltage.

If your design is powered by VBUS, then RST_N should go high within 10 ms of attaching to VBUS in order to ensure that USB timings are met. RST_N should be at least 1 ms after VDDIO good to enable the built—in flash to settle











Lx0 IN +/-3/6

Lx1_OUT +/-

Lx1_IN +/-






Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.


This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.


	_		
Lx0_OUT +	1 🔪	1	Lx0_OUT +
Lx0_OUT -	2	/2	Lx0_OUT -
Lx0 IN +	3	> 3	Lx0 IN +
Lx1 OUT +	$4 \sim$	$\sqrt{4}$	Lx1 OUT +
Lx1 OUT -	$5 \searrow$	\sim 5	Lx1 OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	→ 8	Lx1_IN -
	T		
DC GND	SHIELD -	SHIELD	DC GND


Open Source openPnP Sheet: /LVDS2/ File: LVDS.sch Title: LVDS <-> Xlinks


Size: A4 Date: 2019-01-01 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 4/16












RJ45 PINOUT:

1/2 Lx0_OUT +/-

3/6 Lx0_IN +/-

4/5 Lx1_OUT +/-

7/8 Lx1_IN +/-



> Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

R34 100R

R33 100R


	_		
Lx0_OUT +	1 🔪	1	Lx0_OUT -
Lx0_OUT -	2	2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	4	Lx1_OUT -
Lx1_OUT -	$5 \searrow$	5	Lx1_OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	→ 8	Lx1_IN -
	T		
DC GND	SHIELD -	SHIELD	DC GND

Open Source
openPnP
Sheet: /Tile1/LVDS1/
File: LVDS.sch


 Title: LVDS <-> Xlinks

 Size: A4
 Date: 2019-01-01
 Rev: BETA

 KiCad E.D.A. kicad (5.0.2)-1
 Id: 9/16







Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.


	_		
Lx0 OUT +	1	_1	Lx0 OUT -
Lx0_OUT -	2	/2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	$\sqrt{4}$	Lx1_OUT -
Lx1_OUT -	$5 \searrow$	\sim 5	Lx1_OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	\ 8	Lx1_IN -
	T	•	
DC GND	SHIELD -	SHIELD	DC GND

Open Source
openPnP
Sheet: /LVDS4/
File: LVDS.sch

Title: LVDS <-> Xlinks

 Size: A4
 Date: 2019-01-01
 Rev: BETA

 KiCad E.D.A. kicad (5.0.2)-1
 Id: 10/16






RJ45 PINOUT:

Lx0 IN +/-3/6

Lx1_OUT +/-

 $Lx1_IN +/-$



RJ45_smetueu J16 L.out1-DOUT-DIN1 L.in0-DIN2 INOD-DOUT2+ DOUT2-ROUT1 OUTO & RIN1+ 0UT1 **(** ROUT2 RIN1-R45 100R RIN2+ Not a Diff-pair. (EN & !EN) $\frac{16}{9}$ EN L.in1-RIN2- 4 GND !EN 100R DS90LV049TMT


Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

	_		
Lx0 OUT +	1	_1	Lx0 OUT -
Lx0_OUT -	2	/2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	$\sqrt{4}$	Lx1_OUT -
Lx1_OUT -	$5 \searrow$	\sim 5	Lx1_OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	\ 8	Lx1_IN -
	T	•	
DC GND	SHIELD -	SHIELD	DC GND

Open Source openPnP Sheet: /Tile0/LVDS6/ File: LVDS.sch

Title: LVDS <-> Xlinks Size: A4 Date: 2019-01-01 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 12/16






Lx0_OUT +/-1/2

Lx0 IN +/-3/6

Lx1_OUT +/-

Lx1_IN +/-



RIN2-

DS90LV049TMT

GND

!EN

Not a Diff-pair. (EN & !EN) END_{0}^{16} EN

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

L.in1-


R48 100R

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

$Lx0_OUT +$	1 🔪	-1	$Lx0_OUT +$
Lx0_OUT -	2	\sim 2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	$4 \sim$	$\sqrt{4}$	Lx1_OUT +
Lx1 OUT -	5 >	5	Lx1 OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1 IN +	7	7	Lx1 IN +
Lx1_IN -	8	8	Lx1_IN -
	T		
DC GND	SHIELD -	SHIELD	DC GND

Open Source openPnP Sheet: /Tile0/LVDS5/ File: LVDS.sch Title: LVDS <-> Xlinks

Size: A4 Date: 2019-01-01 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 13/16






Lx0_OUT +/-1/2

Lx0 IN +/-3/6

Lx1_OUT +/-

 $Lx1_IN +/-$



RJ45_smetueu L.in0-DIN2 INOD-DOUT2+ DOUT2-ROUT1 OUTO & RIN1+ 0UT1 **(** ROUT2 RIN1-R53 100R RIN2+ Not a Diff-pair. (EN & !EN) $\frac{16}{9}$ EN L.in1-RIN2- 4 GND !EN R52 100R DS90LV049TMT 100nF C50

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.


	_		
Lx0_OUT +	1 🔪	1	Lx0_OUT -
Lx0_OUT -	2	2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	4	Lx1_OUT -
Lx1_OUT -	$5 \searrow$	5	Lx1_OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	→ 8	Lx1_IN -
	T		
DC GND	SHIELD 🕳	SHIELD	DC GND


Open Source openPnP

Sheet: /Tile0/LVDS0/

File: LVDS.sch Title: LVDS <-> Xlinks

Size: A4 Date: 2019-01-01 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 14/16








1/2 Lx0_OUT +/-

3/6 Lx0_IN +/-

4/5 Lx1_OUT +/-

7/8 Lx1_IN +/-



Not a Diff-pair. (EN & !EN) END 16 EN RIN2- | RIN1- | RIN2- | RIN3- |

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

R57 100R

	_		
Lx0 OUT +	1	_1	Lx0 OUT H
Lx0_OUT -	2	\sim 2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	4	Lx1_OUT +
Lx1_OUT -	5 >	5	Lx1_OUT -
Lx0 IN -	6	6	Lx0 IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	→ 8	Lx1_IN -
	T		
DC GND	SHIELD -	■ SHIELD	DC GND

Open Source
openPnP
Sheet: /LVDS3/
File: LVDS.sch

 Title: LVDS <-> Xlinks

 Size: A4
 Date: 2019-01-01
 Rev: BETA

 KiCad E.D.A. kicad (5.0.2)-1
 Id: 16/16