



Basic Small Messages Protocol (BSMP)

Version 2.20 February 25th, 2016

Bruno Martins bruno.martins@lnls.br Controls Group

Revision History

Revision	Changes
2.20 02/25/2016	 Prevent writing operations on a read-only curve. Values of variables, curves or functions do not need to be in bigendian order.
2.10 08/09/2014	Add a new error code: (0xE8) Resource Busy.
2.00 02/12/2014	 Change the name of the protocol. Was: Sirius Low Level Protocol (SLLP).
2.00-rc2 01/24/2014	Add the possibility of a Curve block contain less than SBLOCK bytes of data.
2.00-rc1 01/23/2014	First release candidate.

Index

L	Introduction	1
2	Transport Layer	2
	2.1 Addressing	2
	2.2 Multicast groups	2
3	Application Layer	3
	3.1 Concepts	3
	3.1.1 Network, Message, Command, Master and Node (or Slave)	3
	3.1.2 Protocol Type	3
	3.1.3 Message Structure	3
	3.2 Entities	4
	3.2.1 Variable	4
	3.2.2 Group of Variables	5
	3.2.3 Curve	5
	3.2.4 Function	6
	3.3 Protocol Commands	
	3.4 (0x0_) Query commands	8
	3.4.1 (0x00) Query Protocol Version	8
	3.4.2 (0x01) Protocol Version	
	3.4.3 (0x02) Query List of Variables	
	3.4.4 (0x03) List of Variables	9
	3.4.5 (0x04) Query List of Group of Variables	
	3.4.6 (0x05) List of Group of Variables	
	3.4.7 (0x06) Query Group of Variables	10
	3.4.8 (0x07) Group of Variables	11
	3.4.9 (0x08) Query List of Curves	
	3.4.10 (0x09) List of Curves	
	3.4.11 (0x0A) Query Curve Checksum	
	3.4.12 (0x0B) Curve Checksum	
	3.4.13 (0x0C) Query List of Functions	
	3.4.14 (0x0D) List of Functions	
	3.5 (0x1_) Reading Commands	
	3.5.1 (0x10) Read Variable	
	3.5.2 (0x11) Variable's Value	
	3.5.3 (0x12) Read Group of Variables	
	3.5.4 (0x13) Group of Variables' Values	
	3.6 (0x2_) Writing Commands	
	3.6.1 (0x20) Write Variable	
	3.6.2 (0x22) Write Group of Variables	
	3.6.3 (0x24) Binary Operation in a Variable	
	3.6.4 (0x26) Binary Operation in a Group	
	3.6.5 (0x28) Write and Read Variables	
	3.7 (0x3_) Group of Variables' Manipulation Commands	
	3.7.1 (0x30) Create Group of Variables	
	3.7.2 (0x32) Remove all Groups of Variables	
	3.8 (0x4_) Curve Transfer Commands	23

	3.8.1	(0x40) Request Curve Block	23
		(0x41) Curve Block	
	3.8.3	(0x42) Recalculate Curve Checksum	25
3.	9 (0x5	5_) Function Execution Commands	26
	3.9.1	(0x50) Execute Function	26
	3.9.2	(0x51) Function Return	27
	3.9.3	(0x53) Function Error	27
3.	10 (02	xE_) Error Commands	28
	3.10.1	(0xE0) OK	28
		(0xE1) Malformed Message	
	3.10.3	(0xE2) Operation not supported	28
	3.10.4	(0xE3) Invalid ID	28
		(0xE4) Invalid Value	
	3.10.6	(0xE5) Invalid Payload Size	29
	3.10.7	(0xE6) Read-Only	29
	3.10.8	(0xE7) Insufficient Memory	29
		(0xE8) Resource Busy	

1 Introduction

In order to standardize all communications between equipment developed for the Sirius project and connected to the Controls Network, a common communication protocol was created. The protocol was named Basic Small Messages Protocol – BSMP. This protocol describes two layers: transport and application. Those layers are independent from one another.

The Sirius' Controls Network is composed of Ethernet and RS485 networks. The devices residing in the lowest levels of the hierarchy will communicate over RS485 with Single Board Computers (SBC). The SBC's, in turn, will communicate with the computers in the higher level of the hierarchy through Ethernet, therefore having a role of a gateway between Ethernet and RS485 networks.

All RS485 devices developed for the Sirius accelerator that will connect to the Controls Network **must** use both layers described in this document. All Ethernet devices **must** use UDP/IP or TCP/IP and the application layer described in this document in order to communicate with a SBC.

2 Transport Layer

The transmission unit of the Transport Layer is the **packet**. Each packet holds a **message**. The Transport Layer **requires** all data in a packet to be in binary, which means that no byte value should have special meaning. The end of a packet is indicated with a silence on the Serial line with duration of 2 bytes. For example, in a 10 Mbps Serial network the silence after a packet should last 1.6 µs. This layer does not impose a size limit on the message inside a packet.

Addressing	Message						Checksum			
DESTINATION										CHECKSUM

Table 1- Structure of a Transport Layer packet

Packets in the Serial network have a well defined format. The first byte is used for addressing and should have a valid address of a device or group of devices. If the packet is from a node to a master, DESTINATION **must** be 0. The last byte of the packet **must** be the CHECKSUM. This structure is shown in the Table 1. The CHECKSUM is the sum of all Addressing and Message bytes, in 2's complement. Therefore, the sum of all bytes of a valid packet **must** be equal to zero (8-bit sum). Each packet carries only one message.

2.1 Addressing

The devices in a serial network **must** be given an address between 0 and 31, inclusive. This range restricts the existence of only thirty two devices in a single serial network. The device with address 0 is the **master** of the network, the other devices being **nodes** (or **slaves**). Every network must have **exactly** one master and **at least** one node.

2.2 Multicast groups

Nodes can be part of Multicast Groups. A Multicast Group can have an address between 248 and 255, which allows the existence of up to eight of such groups. The Multicast Group with address 255 is a special Group called Broadcast. All devices in a serial network **must** be in the Broadcast Group. A node can belong to more than one Multicast Group. The address ranges of serial networks are specified in the Table 2.

Address range	0	1 to 31	32 to 247	248 to 254	255
Used for	Master	Node	Reserved	Multicast Group	Broadcast

Table 2- Addresses on the Serial network

3 Application Layer

The Application Layer defines all the messages that can be exchanged between devices and the actions that must be taken in response to a message.

3.1 Concepts

This section defines the concepts that will be used to describe the Application Layer.

3.1.1 Network, Message, Command, Master and Node (or Slave)

Devices connected with BSMP are components of a **network**. **Network** components communicate exchanging **messages**. Each **message** holds a **command**, that can be either a request or a response.

Network components can perform one of two roles: **master** or **node** (also called **slave**). There must be **exactly** one **master** per **network**. The amount of **nodes** in a **network** is not limited by the Application Layer.

3.1.2 Protocol Type

The **protocol** here described is a token protocol. Only the device with the token can initiate a transmission in the network. In this protocol the token is implicit. Therefore, all communications are initiated by the master. Once the master sends a direct message to a node, it is understood that the node has the token until it answers the master, returning the token. The protocol is stateless: each pair request/response is a whole independent transaction.

The protocol is **byte oriented**, which means that the smaller unit of the message is one byte.

If the Application Layer is used together with the Transport Layer, two restrictions apply:

- 1. Multicast packets **must not** be answered.
- 2. The master must establish a *timeout* to avoid the loss of the token.

3.1.3 Message Structure

A protocol message must have at least three bytes, which are part of its header: COMMAND and LENGTH (with two bytes). The COMMAND field specifies which command should be executed by the node or the response of the execution of a command. All the commands of the protocol are described in the section Protocol Commands. The field LENGTH holds the length of the Payload of the message, in **big endian**. If the message has no payload, both LENGTH bytes must be 0. The structure of the message is depicted in Table 3. The field LENGTH can assume values between 0 and 65535.

Header						Pā	ay]	loa	ad	l	
COMMAND	LENGTH	LENGTH									

Table 3- Structure of a BSMP's message

3.2 Entities

Devices communicate with each other in order to manipulate Entities of the protocol. Entities fall on one of four categories: Variable, Group of Variables, Curve and Function. The maximum amount of each entity in a node are listed in Table 4. Every Entity is identified by an ID. An ID must be unique within a category. IDs must start with 0 and be continuous within each category. For instance, the Variables of a node with 4 Variables must have the IDs 0, 1, 2 and 3. If the same node also has 8 Curves, their IDs must be 0, 1, 2, 3, 4, 5, 6 and 7.

Entity	Maximum Amount	Properties
Variable	128	ID, TYPE, SIZE
Group of Variables	8	ID, TYPE, SIZE
Curve	128	ID, TYPE, SIZE, CHECKSUM
Function	128	ID, INPUT, OUTPUT

Table 4- Amounts and properties of the protocol's Entities

3.2.1 Variable

The Variable is the central Entity of the protocol. Each node has a number of Variables. Each Variable has a value that can be read from and, for writable Variables, written to. The meaning of each Variable must be specified by the device developer, including the *endianness* to be adopted in data transmissions. Each Variable has one value and three properties, listed in Table 5. It's important to stress that a writable Variable **can** also be read (in which case the read value would be the last written value). However, to write in a read-only Variable **must not** be allowed.

Property	Description
ID	Unique number that identifies the Variable
TYPE	The Variable may be read-only (TYPE 0) or writable (TYPE 1)
SIZE	The length of the Variable's value, between 1 and 128

Table 5- Properties of a Variable

3.2.2 Group of Variables

It is possible to create Groups of Variables so that some sets of Variables can be read from or written to with a single command. Each Group of Variables has three properties and a list of Variables in the Group, according to Table 6. A Variable can belong to more than one Group. There **must** exist, at all times, at least three Groups of Variables, presented in Table 7. Those Groups are called Standard Groups, which **must not** be deleted. A writable Group **must** contain **only** writable Variables. However a read-only Group **may** contain both writable and read-only Variables.

Property Description					
ID	Unique number that identifies the Group				
TYPE	The Group may be read-only (TYPE 0) or writable (TYPE 1)				
SIZE	The amount of Variables in the Group, between 1 and 128				

Table 6- Properties of a Group of Variables

ID	TYPE	Group's Variables
0	0	All Variables of a node
1	0	All read-only Variables of a node
2	1	All writable Variables of a node

Table 7- Standard Groups of Variables

3.2.3 Curve

A Curve is a long sequence of bytes, which may or may not be related to each other. Values of a Curve can be transmitted in either direction (master \rightarrow node or node \rightarrow masted). A Curve has five properties, listed in Table 8.

Property	Description
ID	Unique number that identifies the Curve
TYPE	The Curve may be read-only (TYPE 0) or writable (TYPE 1)
SBLOCK	The size of an individual block, between 1 and 65520
NBLOCKS	The amount of blocks in the Curve, between 1 and 65536
CHECKSUM	MD5 hash of all values of a Curve

Table 8- Properties of a Curve

The TYPE property indicates if the values of a Curve can (1) or cannot (0) be written to. The Curve's size is limited to 65536 (2¹⁶) blocks, each block being, at most, 65520 bytes long, which gives a total of 4095 MiB per Curve. The NBLCOKS field is the number of blocks of a Curve. The SBLOCK field is the maximum size of a single block. A Curve may have a CHECKSUM associated with it, which must be calculated using the MD5 algorithm. Therefore, the length of the CHECKSUM field is 16 bytes.

3.2.4 Function

A Function is a kind of a Remote Procedure Call - RPC. A Function can receive between zero and fifteen bytes as input and return between zero and fifteen bytes as successful output or one byte as error output. A successful return is signaled by the command (0x51) Function Return; an error in the execution of the Function is indicated by the command (0x53) Function Error. The meaning of the input bytes, the output bytes and the error codes is specific to each Function and must be provided by the developer of the device. The properties of a Function are described in Table 9.

Property	Description
ID	Unique number that identifies the Function
ENTRADA	Amount of bytes taken as input (between 0 and 15)
SAIDA	Amount of bytes returned as output (between 0 and 15)

Table 9- Properties of a Function

3.3 Protocol Commands

All the codes accepted in the field COMMAND of the messages and their meaning and structure are described in this section. The commands are divided in classes, being grouped by their semantic likeness. Each command code is consisted of one byte, being the most significant nibble the indicative of the command's class. In general, the convention for the command's codes is that even codes are for commands from the master to the slave and odd commands from the slave to the master. The exceptions are the error codes (section (0xE_) Error Commands), which are always from the slave to the master, and the (0x41) Curve Block command, which can be sent both ways.

If a node happens to receive a message in which the number of bytes indicated in the LENGTH field differs from the actual length of the Payload, it will return the error (0xE1) Malformed Message. If a node receive a command that it doesn't know how to perform, it will return the error (0xE2) Operation not supported. If the number of bytes in the payload of a command differs from the number of bytes expected for that specific command, the error (0xE5) Invalid Payload Size will be returned.

A summary of all commands of the protocol and their payloads is given in Table 10. Detailed descriptions are given in the following sections.

Direction	Payload
M → N	
M ← N	[Version, Subversion, Revision]
M → N	
M ← N	[Type Size] * (# of Vars)
M → N	
M ← N	[Type Size] * (# of Groups)
M → N	[Group ID]
M ← N	[Var ID] * (# of Vars in the Group)
M → N	
M ← N	[Type,NBlocks(2 bytes),SBlock(2 bytes)]*(# curves)
M → N	[Curve ID]
M ← N	16 bytes (MD5 Checksum)
M → N	
M ← N	[Input Output] * (# of Functions)
M → N	[Var ID]
M ← N	[Value]
M → N	[Group ID]
M ← N	[Value] * (# of Vars in the Group)
M → N	[Var ID, Value]
M → N	[Group ID], [Value]*(# of Vars in the Group)
M → N	[Var ID, Operation,Mask]
M → N	[Group ID, Operation],[Mask]*(# of Vars in the Group)
M → N	[Var ID (to be written), Var ID (to be read), Value]
M → N	[Var ID] * (# of desired Vars)
M → N	
M → N	[Curve ID, block offset (2 bytes)]
M ↔ N	[Curve ID, block offset (2 bytes), Data (up to Sblock bytes)]*
M → N	[Curve ID]
M → N	[Function ID, Input (between 0 and 15 bytes)]
M ← N	[Output (between 0 and 15 bytes)]
M ← N	[Error code]
	M → N M ← N M → N M ← N M → N

Errors: (0xE0) OK, (0xE1) Malformed Message, (0xE2) Operation not supported, (0xE3) Invalid ID, (0xE4) Invalid Value, (0xE5) Invalid Payload Size, (0xE6) Read-Only, (0xE7) Insufficient Memory, (0xE8) Resource Busy

Table 10- Summary of the commands of the protocol

3.4 (0x0_) Query commands

3.4.1 (0x00) Query Protocol Version

Direction	Payload Size	Expected Answer				
Master → Node	0	(0x01) Protocol Version				
	Description					
Request the Version of the protocol supported by the Node.						

3.4.2 (0x01) Protocol Version

Direction		Payloa	d Size		Expected Answer			
Master ← Nod	le	3	3		-			
			Description	ı				
The first byte is the Version field. The second one, the Subversion field. The third one, the Revision. A version string can be constructed with the format "Version.Subversion.Revision". Implementations of the same Version of the Protocol must be compatible. Greater Protocol's Subversion numbers mean that new commands were added. The Revision field is used to identify								
different imple	IIIeiitatioiis	•	Structure					
			Structure					
			Payload					
	Version Subversion Revision							
Example								
Header Payload On 100 02 03 14 00 Answer with Version 2, Subversion 20 and Revision 0: "2.20.0".								

3.4.3 (0x02) Query List of Variables

01 00 03 02 14 00

Direction	Payload Size	Expected Answer			
Master → Node	0	(0x03) List of Variables			
Description					
Request the list of	f Variables in the node.				

3.4.4 (0x03) List of Variables

Direction	Payload Size	Expected Answer
Master ← Node	(number of Variables in the node)	-

Description

Contains a list with the TYPE and the SIZE of all node's Variables.

Structure

Payload				
First Variable		Last Variable		
TYPE (1 bit) SIZE (7 bits)		TYPE (1 bit) SIZE (7 bits)		

For each Variable is returned one byte of information. The Variables are in ascending order of their IDs. The first Variable has the ID 0. The most significant bit of each byte indicates if the Variable is read-only (bit = 0) or writable (bit = 1). The remaining seven bits contain the SIZE of the Variable. If SIZE is 0, the Variable is 128 bytes wide.

Example

Н	ead	er]	Payload			
03	00	06	03	03	83	83	01	81

Two read-only Variables of size 3, two writable Variables of size 3, one read-only Variable of size 1, one writable Variable of size 1.

3.4.5 (0x04) Query List of Group of Variables

Direction	Payload Size	Expected Answer			
Master → Node	0	(0x05) List of Group of Variables			
Description					
Request the node to return a list describing all of his Groups of Variables.					

3.4.6 (0x05) List of Group of Variables

Direction	Payload Size	Expected Answer
Master ← Node	(number of Groups in the node)	-

Description

Contains a list with the TYPE and the SIZE of all node's Groups.

Structure

Payload				
First Group		Last Group		
TYPE (1 bit) SIZE (7 bits)	•••	TYPE (1 bit) SIZE (7 bits)		

One byte of information is returned for each Group in the node. The Groups are in their ascending ID order. The first Group has the ID 0. The most significant bit of each byte indicates the TYPE of the Group (0 for read-only, 1 for writable). The seven remaining bits contain the SIZE of the Group. If SIZE is 0, the Group has 128 Variables.

Example

Н	ead	er	Pa	yloa	ad
05	00	03	0A	05	85

Three Groups. The first one is read-only and has 10 Variables. The second one is also read-only and has 5 Variables. The last one is writable and has 5 Variables.

3.4.7 (0x06) Query Group of Variables

Direction	Direction Payload Size		Expected Answer				
Master → No	Master → Node 1		(0x07) Group of Variables				
		Description					
Request the n	ode to ret	urn the list of Variables of the specified Grou	ıp.				
	Structure						
Payload			our to be gueried				
Group	ID	The Payload must contain the ID of the Group to be queried.					
	Example						
Header Payload							
06 00 01	02	Query the Group with ID 2.					

Possible Errors

(0xE3) Invalid ID: There is no Group with the specified ID.

3.4.8 (0x07) Group of Variables

Direction		Payloa	d Size	Expected Answer				
Master ← Node		(number of Variab	les in the Group)	-				
	Description							
Contains the list	Contains the list of all Variables in the Group.							
			Structure					
	Paylo	ad]					
First Variable	غ آ	Last Variable	The Variable's IDs order.	are listed in their ascending				
ID	•••	ID	- Order.					
			Example					
Header 07 00 0		Payload 05 06 07 09	Group of 5 Variables	with IDs 4, 5, 6, 7 e 9.				

3.4.9 (0x08) Query List of Curves

Direction	Payload Size	Expected Answer					
Master → Node	0	(0x09) List of Curves					
	Description						
Request the list of	Request the list of Curves in the node.						

3.4.10 (0x09) List of Curves

Direction	Payload Size	Expected Answer
Master ← Node	5*(number of Curves in the node)	-

Description

Contains a list with TYPE, SBLOCK and NBLOCKS fields of all node's Curves.

Structure

	Payload											
	F	irst Cur	ve				L	ast Curv	ve			
	SBL	SBLOCK NBLOCKS		NBLOCKS		NBLOCKS			SBL	OCK	NBLO	OCKS
TYPE	most sig.	least sig.	most sig.	least sig.	•••	TYPE	most sig.	least sig.	most sig.	least sig.		

The Curves are listed in the ascending order of their IDs. The first Curve has the ID 0. There are five bytes for each Curve. The first byte is the TYPE of the Curve (0 for read-only, 1 for writable). Second and third bytes contain the size of a block (SBLOCK). Fourth and fifth bytes contain the number of blocks (NBLOCKS). If NBLOCKS is 0, the Curve has 65536 blocks.

Example

Н	ead	er	Payload						
09	00	03	00	40	00	02	00		

List with only one Curve. It is read-only (00) and has 512 (200h) 16384-byte (4000h) blocks.

3.4.11 (0x0A) Query Curve Checksum

Direction	Payload Size	Expected Answer
Master → Node	1	(0x0B) Curve Checksum
	Description	

Description

Request the CHECKSUM of a Curve in the node.

Structure

Payload	
Curve ID	

The ID of the Curve to be queried is specified.

Example

Н	ead	Payload	
0A	00	01	02

Query the CHECKSUM of the Curve with ID 2.

Possible Errors

(0xE3) Invalid ID: There's no Curve with the ID specified.

3.4.12 (0x0B) Curve Checksum

Direction			Payload Size Expected							ted A	Ansv	wer						
Master ← Node					1	.6									-			
						Des	scrip	tion										
Contains the CH	IECKS	SUM	of a C	Curve	<u>.</u>													
						St	ruct	ure										
						P	aylo	ad										
					N	MD5	Che	ksu	m									
	mo	st sig	gnifica	nt						le	east s	igni	fica	nt				
The 16 bytes of	the M	D5 C	CHECI	KSUI	M ar	e ret	urne	l fro	m th	e mo	st to	the	leas	t sig	gnifi	cant	byte.	
	Example																	
Неа	ıder	Payload																
0B 0	0 10	01	01 23 45 67 89 AB CD EF FE DC BA 98 76 54 32						32	10								
Curve with CHECKSUM 0123456789abcdeffedcba9876543210.																		

3.4.13 (0x0C) Query List of Functions

Direction	Payload Size	Expected Answer						
Master ← Node	0	(0x0D) List of Functions						
	Description							
Request the list of Functions in the node.								

3.4.14 (0x0D) List of Functions

Direction	Payload Size	Expected answer
Master ← Node	(number of Functions in the node)	-

Description

Contains a list with the INPUT and the OUTPUT of all node's Functions.

Structure

Payload							
First Function		Last Function					
INPUT (4 bits) OUTPUT (4 bits)	•••	INPUT (4 bits) OUTPUT (4 bits)					

The list of Functions are listed in the ascending order of their IDs. The first Function has the ID 0. There is one byte for each Function. The most significant nibble of the byte contains the INPUT length of the Function (between 0 and 15). Likewise, the least significant nibble contains the OUTPUT length of the Function (also between 0 and 15).

Example

Н	ead	er	Payload				
0D	00	03	F0	0F	22		

Three Functions. The Function with ID 0 takes 15 bytes as input and returns 0 bytes as output. The Function with ID 1 returns 15 bytes as output and takes no input. The Function with ID 2 takes 2 bytes as input and returns 2 bytes as output.

3.5 (0x1_) Reading Commands

3.5.1 (0x10) Read Variable

Direction		Payload Size Expected answer							
Master → Node		1 (0x11) Variable's Value							
Description									
Request the VALUE of a Variable.									
Structure									
Payload	l								
Variable I	D	The payload contains the ID of the Variable to be read.							
	Example								
	Request to read the Variable with ID 3.								
		Possible Errors							
(0xE3) Invalid ID):	There's no Variable with the ID specified	l .						
(0xE8) Resource	Busy:	The Variable was in use and couldn't be r	read.						

3.5.2 (0x11) Variable's Value

11 00 03 03 FF FF

Direction		Payload S	Size]	Expected answer	
Master ← Node		(SIZE of the V	ariable)		-	
		D	escripti	ion			
Contains the VA by the developer			eaning o	of the VALUE	of a Va	riable must be specified	
		S	Structu	re			
			Payloa	d			
		Varia					
	First <i>byte</i> Last byte						
The VALUE of t	he Variable i	s given byte by l	oyte.				
]	Examp	le			
Header	Payload						

Variable with the VALUE 03h FFh FFh.

3.5.3 (0x12) Read Group of Variables

Direction	Payload Size	Expected answer							
Master → Node	1	(0x13) Group of Variables' Values							
Description									
Request the VALUE of all Variables in a Group.									
Structure									
Payload									
Group ID	The payload contains the ID of	The payload contains the ID of the Group to be read.							
	Example								
	Header Payload Request the VALUEs of the Variables in the Group with ID 1.								
	Possible Errors								
(0xE3) Invalid II	D: There's no Group with the spec	ified ID.							
(0xE8) Resource	Busy: At least one Variable was in us	e and couldn't be read.							

3.5.4 (0x13) Group of Variables' Values

Direction		Payload Si			Expected answer					
Master ← Node	Node (sum of SIZES of the Variables of a Group) -									
Description										
Contains the VALUEs of all the Variables in a Group.										
Structure										
Payload										
	VALUE of the	First Variable		VALUE of the Last Variable						
	First byte	. Last byte		First byte		Last byte				
	•									

The VALUEs of the Variables of the Group are listed in the ascending order of the Variables' IDs.

Exampl	e

Н	lead	er	Payload												
13	00	0C	03	FF	FF	03	FF	FF	03	FF	FF	03	FF	FF	AA

Sequence of the VALUES of the Variables of a Group. It's possible to interpret those VALUES once it's known which Variables are in the Group (with (0x06) Query Group of Variables).

3.6 (0x2_) Writing Commands

3.6.1 (0x20) Write Variable

Master \rightarrow Node 1 + (SIZE of the Variable)	(0xE0) OK

Description

Writes in the VALUE of a Variable. The Variable must be writable.

Structure

	Payload	l				
17:	Variable's VALUE					
Variable ID	First byte		Last byte			

The payload contains the ID of the Variable followed by the sequence of bytes to be written in the Variable's VALUE.

Example

Н	ead	er		Pay	load	l
20	00	04	04	01	ВВ	ВВ

Request to write 01h BBh BBh in the VALUE of the Variable with ID 4.

Possible Errors

(0xE3) Invalid ID: There's no Variable with the specified ID.

(0xE6) Read-Only: Variable can't be written (its TYPE is read-only). (0xE8) Resource Busy: The Variable was in use and couldn't be written.

3.6.2 (0x22) Write Group of Variables

Direction	Payload Size	Expected answer
Master → Node	1+(sum of the SIZEs of the Variable's of a Group)	(0xE0) OK

Description

Contains values to be written to Variables in a specific Group. The Group must be writable.

Structure

Payload										
Group	VALUE of th	e fii	rst Variable		VALUE of tl	ne la	st Variable			
ID	First byte		Last byte	•••	First byte		Last byte			

The payload contains the ID of the Group followed by the bytes to be written in the VALUE field of all Group's Variables.

Example

H	lead	er							Pay	loa	d					
22	00	0E	02	01	ВВ	ВВ	01	ВВ	ВВ	01	ВВ	ВВ	01	ВВ	ВВ	CC

Sequence of VALUES to be written in the Variables of the Group with ID 2. It's possible to interpret this particular sequence of values knowing the Variables of the Group (with the command (0x06) Query Group of Variables).

Possible Errors

(0xE3) Invalid ID: There's no Group with the specified ID.

(0xE6) Read-Only: Group couldn't be written (it's TYPE is read-only).

(0xE8) Resource Busy: At least one Variable was in use and couldn't be written.

3.6.3 (0x24) Binary Operation in a Variable

Direction	Payload Size	Expected answer
Master → Node	2+(SIZE of the Variable)	(0xE0) OK

Description

Perform a binary operation in the VALUE of a Variable with a specified mask. The available operations are listed in Table 11. The Variable must be writable.

Code Operation		Description
0x53 ('S') SET		'Turn on' (make 1) the bits specified in the mask.
0x43 ('C')	CLEAR	'Turn off' (make 0) the bits specified in the mask.
0x54 ('T')	TOGGLE	Invert the bits specified in the mask.
0x41 ('A')	AND	Perform a logical AND between the Variable's VALUE and the mask.
0x4F ('O')	OR	Perform a logical OR between the Variable's VALUE and the mask.
0x58 ('X')	XOR	Perform a logical XOR between the Variable's VALUE and the mask.

Table 11- Binary operations

Structure

	Payload							
Variable	Operation	N	⁄Iask					
ID	Code	First byte		Last byte				

The payload contains the ID of the Variable and the code of the operation to be performed, followed by the bytes of the mask.

Example

Н	ead	er	Pá	aylo	Perfo	
24	00	03	09	53	F0	mask Varia

Perform a SET operation (53h) in the Variable with ID 09h with the mask F0h, which will cause the most significant nibble of the Variable's VALUE to have all 1's.

Possible Errors

(0xE2) Operation not supported: The binary operation requested isn't valid. (0xE3) Invalid ID: There's no Variable with the specified ID.

(0xE6) Read-Only: Variable couldn't be written (its TYPE is read-only).

(0xE8) Resource Busy: The Variable was in use and couldn't be written.

3.6.4 (0x26) Binary Operation in a Group

Direction	Payload Size	Expected answer
Master → Node	1+(sum of the SIZEs of the Variable's of a Group)	(0xE0) OK

Description

Perform a binary operation in the VALUEs of the Variables of a Group with a specified mask. The available operations are listed in Table 11. The Group must be writable.

Structure

				Payload				
Group	Operation	Fi	rst Ma	ask		Las	st Ma	sk
ID	Code	First byte	•••	Last byte	•••	First byte		Last byte

The payload contains the ID of the Group and the code of the operation to be performed, followed by the bytes of the masks.

Example

	ead				ylo			Perform an OR operation (4Fh) with the mask 55h in all bytes
26	00	05	02	4F	55	55	55	of all Variables' VALUEs in the Group with ID 02h.

Possible Errors

(0xE2) Operation not supported: The requested binary operation is invalid.
(0xE3) Invalid ID: There's no Group with the specified ID.
(0xE6) Read-Only: Group couldn't be written (its TYPE is read-only).
(0xE8) Resource Busy: At least one Variable was in use and couldn't be written.

3.6.5 (0x28) Write and Read Variables

Direction	Payload Size	Expected answer
Master → Node	2 + (SIZE of the Variable to be written)	(0xE0) OK

Description

Writes in the VALUE of a Variable. The Variable must be writable. Returns the VALUE of a second Variable, to be read.

Structure

Payload							
ID of the Variable	ID of the Variable	VALUE of	the Variable t	o be written			
to be written	to be read	First byte	•••	Last byte			

The payload contains the ID of the Variable to be written, followed by the ID of the Variable to be read and by sequence of bytes to be written.

Example

H	[ead	er		Pa	ayloa	ad	
20	00	05	04	05	01	ВВ	ВВ

Request to write 01h BBh BBh to the VALUE of the Variable with ID 4. Request the VALUE of the Variable with ID 5.

Possible Errors

(0xE3) Invalid ID: There's no Variable with the specified ID.

(0xE6) Read-Only: Variable can't be written (its TYPE is read-only).

(0xE8) Resource Busy: At least one Variable was in use and couldn't be written or read.

3.7 (0x3_) Group of Variables' Manipulation Commands

3.7.1 (0x30) Create Group of Variables

Direction	Payload Size	Expected answer
Master → Node	(number of Variables in the Group)	(0xE0) OK

Description

Create a new Group of Variables with the Variables specified in the payload. The ID of the newly created Group is equal to the ID of the last Group in the node, plus 1.

Structure

Payload					
First Variable		Last Variable			
ID	•••	ID			

The IDs of the Variables to be added to the new Group.

Example

Header			Payload			
30	00	04	04	05	06	07

Create a Group with the Variables with IDs 4, 5, 6 and 7.

Possible Errors

(0xE3) Invalid ID: At least one of the specified ID's doesn't exist.

(0xE5) Invalid Payload Size: Number of Variables is zero or greater than the number of

Variables in the node.

(0xE7) Insufficient Memory: There's no memory available to create the Group.

3.7.2 (0x32) Remove all Groups of Variables

Direction	Payload Size	Expected answer				
Master → Node	0	(0xE0) OK				
Description						
Request for the node to remove all his Groups, except for the Standard Groups.						

3.8 (0x4_) Curve Transfer Commands

3.8.1 (0x40) Request Curve Block

Direction	Payload Size	Expected answer
Master → Node	3	(0x41) Curve Block

Description

Request for the node to send a specific block of the specified Curve.

Structure

Payload						
Curve	Bloc	k offset				
ID	Most significant byte	Least significant byte				

The payload contains the ID of the Curve and two bytes for the block offset (in Big Endian). The first block has the offset zero (0000h).

Example

Header			Payload			
40	00	03	03	00	04	

Request the fifth block (0004h) of the Curve with ID 03h.

Possible Errors

(0xE3) Invalid ID: There's no Curve with the specified ID.

(0xE4) Invalid Value: The block offset specified is invalid.

(0xE8) Resource Busy: The Curve was in use and couldn't be read.

3.8.2 (0x41) Curve Block

Direction	Payload Size	Expected answer
Master ↔ Node	3 + (from 0 to SBLOCK)	(0xE0) OK

Description

Transmission of a Curve block sent either byte the node or by the master. If the block is sent by the master, it means that it is a request to write in the values of the specified block; the CHECKSUM of the Curve must be zeroed if the write operation is successful. When the master is done writing blocks to a Curve of the node, it should then send the (0x42) Recalculate Curve Checksum command. The block data can have less than SBLOCK bytes.

Structure

	Payload							
Curve	Block	Block Data						
ID	Most significant byte Least significant byte		First byte		Last byte			

The payload contains the ID of a Curve and two bytes for the offset of the Curve's block, followed by 16384 bytes containing the data of the specified block.

Example

Н	ead	er	Pä			Payload		
41	40	03	07	04	00	DD		DD

Block offset 1024 (0400h) of the Curve with ID 07h that contains 16384 bytes DDh.

Possible Errors

(0xE3) Invalid ID: There's no Curve with the specified ID.

(0xE4) Invalid Value: The block offset specified is invalid.

(0xE6) Read-Only: Curve couldn't be written (its TYPE is read-only).

(0xE8) Resource Busy: The Curve was in use and couldn't be written.

3.8.3 (0x42) Recalculate Curve Checksum

Direction		Payload Size	Expected answer				
Master → Node		1	(0x0B) Curve Checksum				
	Description						
Request that the	CHECK	ASUM of a Curve be recalculated.					
		Structure					
Payload	Payload The payload contains the ID of the Curve to have its CHECKSU						
Curve II	D	recalculated.					
		Example					
Header Pa	ayload	Dogwood to wood out to the CHECKSIN	I of the Course with ID 0				
42 00 01	Request to recalculate the CHECKSUM of the Curve with ID 0. $00 \mid 01 \mid 00$						
Possible Errors							
(0xE3) Invalid ID: There's no Curve with the specified ID.							
(0xE8) Resource	Busy:	The Curve was in use and couldn't be acce	essed.				

3.9 (0x5_) Function Execution Commands

3.9.1 (0x50) Execute Function

Direction	Payload Size	Expected answers
Master → Node	1+(Function INPUT)	(0x51) Function Return or (0x53) Function Error

Description

Request a specific Function to be executed with the given parameters.

Structure

Payload						
Function Input parameters						
ID	First byte		Last Byte			

The payload contains the ID of the Function to be executed followed by a list of bytes to be passed as input parameters. The amount of bytes for the input parameters must be exactly INPUT bytes.

Example

Header		P	ayloa	ıd	
50	00	03	01	BE	57

Execute the Function with ID 01h passing BEh 57h as input parameters.

Possible Errors

(0xE3) Invalid ID: There's no Function with the specified ID.

(0xE5) Invalid Payload Size: The number of bytes passed as input differs from the expected.

3.9.2 (0x51) Function Return

Direction		Payload Size	Expected answer	
Master ← Node	(F	unction OUTPUT)	-	
		Description		
Contains the resu	ılt of the executio	on of a Function.		
	Structure			
Payload				
Functio	n output	The payload contains all bytes returned by the Function as output.		
First byte	Last byte			
Example				
Header Payload 51 00 01 00		Response for the execution of a Function that returned just 1 byte, 00h.		

3.9.3 (0x53) Function Error

Direction		Payload Size	Expected answer		
Master ← Node		1	-		
		Description			
Indicates that the	re was an er	ror returned by the execution of a Fun	ction.		
	Structure				
Pay	load	The payload contains the error code returned by the Function, which is specific to the Function and must have its meaning			
Erroi	· Code	described by the developer of t	S		
Example					
Header	Payload	An arrest vertices and of DDh			
53 00 03	ВВ	An error return code of BBh.			

3.10(0xE_) Error Commands

All Error Commands are in the direction Master ← Node and don't have payload.

3.10.1 (0xE0) OK

Direction	Payload Size	Expected answer			
Master ← Node	0	-			
	Description				
The last command was successfully executed.					

3.10.2 (0xE1) Malformed Message

Direction	Payload Size	Expected answer		
Master ← Node	0	-		
Description				
The number of bytes received in the payload differs from what was specified in the message's SIZE field.				

3.10.3 (0xE2) Operation not supported

Direction	Payload Size	Expected answer		
Master ← Node	0	-		
Description				
The requested command is not supported.				

3.10.4 (0xE3) Invalid ID

Direction	Payload Size	Expected answer			
Master ← Node	0	-			
	Description				
One of the IDs specified was invalid.					

3.10.5 (0xE4) Invalid Value

Direction	Payload Size	Expected answer		
Master ← Node	0	-		
Description				
A value passed is out of the acceptable range.				

3.10.6 (0xE5) Invalid Payload Size

Direction	Payload Size	Expected answer			
Master ← Node	0	-			
	Description				
The payload size is different than the size expected by the command.					

3.10.7 (0xE6) Read-Only

Direction	Payload Size	Expected answer			
Master ← Node	0	-			
	Description				
Tried to write on a read-only Entity.					

3.10.8 (0xE7) Insufficient Memory

Direction	Payload Size	Expected answer		
Master ← Node	0	-		
Description				
There wasn't enough memory to complete the request.				

3.10.9 (0xE8) Resource Busy

Direction	Payload Size	Expected answer		
Master ← Node	0	-		
Description				
The required resource was in use and, therefore, inaccessible.				