


# KEYMASTER By MØMZB

## 4-Key CW CAT Controller



Use paddle, bug,  
straight key and  
cootie together



Automatically  
detects the  
active key



Remembers  
radio settings  
for each key



Instantly sets  
WPM, keyer, sidetone,  
band & more via CAT



CAT control  
for Yaesu,  
Icom & more



Built for CW  
operators  
by MØMZB

TURN YOUR RADIO INTO A CW MASTER STATION

# USER MANUAL

Version 20260802

VERSION 1.0

Issue Date 20260705

## WARNINGS/ADVICE

Thank you for choosing KeyMaster. I hope it becomes a useful addition to your station. Please read the following information before connecting the unit.

- **DO NOT** Hot swap the serial connectors. The KeyMaster must be powered down (remove the DC jack) before swapping any serial connector. You have been warned, you may get away with it once, twice or even 10 times, but hot swapping serial connectors has the potential to damage the KeyMaster.
- **DO NOT** exceed the recommended voltage (13.8V)
- Although a 5V supply connector is provided on the rear panel, this is primarily as a convenience when uploading firmware. The unit has not been tested for long term operation on a direct 5V supply, but there is no reason it will not work.
- **DO NOT** Connect more than one serial interface at any one time – connect to only one radio at a time.
- **DO** Use the same power supply for the KeyMaster as your radio. If you intend to use a different supply, be careful that you do not introduce a different GND - you could cause significant damage by doing this.

## TABLE OF CONTENTS

|                                                            |           |
|------------------------------------------------------------|-----------|
| <b>WARNINGS/ADVICE.....</b>                                | <b>2</b>  |
| <b>TABLE OF CONTENTS.....</b>                              | <b>3</b>  |
| <b>Introduction.....</b>                                   | <b>4</b>  |
| <b>Quick Start Guide.....</b>                              | <b>5</b>  |
| <b>Controls Overview.....</b>                              | <b>6</b>  |
| <b>Band Buttons and Band LEDs.....</b>                     | <b>7</b>  |
| <b>Key Buttons and Key LEDs.....</b>                       | <b>8</b>  |
| <b>Auto Key Switching.....</b>                             | <b>9</b>  |
| <b>WPM and Keyer Control (Encoder 1).....</b>              | <b>10</b> |
| <b>Volume and Breaking Control (Encoder 2).....</b>        | <b>11</b> |
| <b>Adjusting Radio Communication Settings.....</b>         | <b>12</b> |
| Selecting the radio.....                                   | 12        |
| Supported Radios.....                                      | 13        |
| Setting the CAT Baud rate.....                             | 13        |
| Special requirements for Kenwood TS-590S and TS-590SG..... | 14        |
| Encoder Direction Setting.....                             | 16        |
| Default Settings.....                                      | 17        |
| <b>LED Messages Summary.....</b>                           | <b>18</b> |
| <b>Rear Panel Connections.....</b>                         | <b>19</b> |
| Troubleshooting.....                                       | 20        |

## Introduction

KeyMaster is a smart controller for sharing one radio between four CW key inputs. KeyMaster allows up to four different CW keys to remain permanently connected to a single radio. Each key remembers its own CW speed, keyer mode and break-in setting, allowing instant changes between keys without repeatedly adjusting the radio.

**KeyMaster has a unique autosense mode**, where the KeyMaster senses which key is in use, and automatically switches to route the active key to the radio. The keys can also be switched manually, using buttons on the front panel.

Each of the **four key inputs on KeyMaster has its own saved operating bank of settings**, so changing from one key to another will also recall the chosen CW speed, keyer mode, and break-in mode for that key. Sidetone/monitor volume and band choice is shared across all banks and remains unchanged when switching keys.

The unit can run standalone with no radio connected. When a supported radio is connected by CAT, KeyMaster sends the front-panel changes to the radio. The KeyMaster polls the radio so any changes made directly on the radio interface are read-back by KeyMaster, and the relevant settings updated.

When adjusting WPM, sidetone volume, Keyer ON/OFF and Break-in ON/OFF the KeyMaster displays the current value using the front panel LEDs as a bar chart, or animation.

The KeyMaster features Band select buttons, allowing the operator to quickly switch between bands on the connected radio. This is especially useful for radio such as the Yaesu FTDX10, where there is no direct access to band selection on the front panel.

The KeyMaster **uses an analogue switch, so there is no latency introduced to CW key use**

With Key Master auto-keying you can

- Have several keys connected, and a different WPM set on each, allowing super quick changes of speed.
- Have a Bug, Paddle, Straight key and Cootie attached all at the same time, and rapidly switch between them
- Have a bug and paddle connected at the same time, use the paddle to sound a phrase, and then try to sound with the bug. This is a great way to practice bug sending, and get your bug fist as close to perfect as possible.
- Directly adjust WPM, Sidetone volume, Keyer, Break-in, and choose a new band – it's like having a top-of-the line radio where all the settings are available on the front panel!

## Quick Start Guide

1. Connect the KeyMaster to your radio via one of the serial connectors. For example, direct connection via a standard Serial DB9 connector to an FTDX10.
2. Connect the Key output on the rear panel of the KeyMaster to your radio Key input
3. Connect up to four keys to the KeyMaster
4. Connect to the same power supply as your radio (assuming it's in the range 8 to 13.8V) via the DC barrel jack socket.
5. The KeyMaster will start up, and default to the ftDX10 settings. You can select a different radio by (i) Short press Key 3 to activate Key 3 (even if there is no key connected, this is needed to enter the radio setting mode). (ii) Long press Key 3 for about 3 seconds (iii) Choose your radio with the band switches (see manual for which switch corresponds to which radio. Long press Key 3 again to exit band settings
6. Toggle the LED bar graph mode ON/OFF by selecting Key 2, and then long press on Key 2.
7. Toggle auto key switching by selecting Key 1 and then long press on Key 1
8. Now you are up and running, enjoy!

### Power

8–13.8V DC

### Connections

- KEY OUT -> Radio Key input
- Radio control (12V and 5V Serial)
- Up to four keys

### Short Press

Band buttons Select band

Key buttons Select key

### Encoder 1

Rotate =increase/decrease WPM

Press = toggle keyer

### Encoder 2


Rotate = Change Sidetone Volume

Press = toggle break-In

### Long Press

- Key1 Toggle Auto Switching (auto sensing and switching of keys)
- Key2 Toggle LED Display (animated LEDs and bar graph for WPM, volume, etc)
- Key3 Radio Select Mode (choose radio and baud rate)
- Key4 Display Firmware Version (LEDs display firmware number in binary notation)

## Controls Overview



- The KeyMaster includes two rows of buttons. LEDs and two encoders. The top row of buttons allow selection of bands. The LEDs show the chosen band. The Band LEDs are also used as a momentary bar-chart display of settings values, as explained below.
- The Key LEDs/Buttons allow manual selection of the Key to use (manual selection is always available, even if autokey selection is enabled).
- A pair of push-button encoders allow selection of WPM, sidetone volume, Keyer (ON/OFF) and break-in (ON/OFF)
- Four key inputs are provided via 3.5mm sockets. The selected key is routed to the socket on the rear of the unit. An analogue switch is used, so there is no latency introduced.

## Band Buttons and Band LEDs

The eight band buttons select:

80m 60m 40m 30m 20m 17m 15m 10m

The small LEDs above the band row show the selected band. Some temporary displays reuse the band LEDs for short animations, then return to the selected band display. Where a band-stack register is available on a radio, the KeyMaster will make use of it (i.e. the radio recalls the previous mode and frequency used on that band).

If the settings display is toggled ON (via Key 3 button, see below) the band LEDs show a momentary bar chart of the WPM or volume value when rotating the WPM or Volume encoder. The Band LEDs show a bar graph from left to right, with the value of “9” indicated by alternate LEDs illuminated.

The tens values are shown by the Key LEDs (Key1 LED =10, Key 2=20 etc.).



## Key Buttons and Key LEDs

The key buttons can be used to manually select the key in operation. The active key is shown by the corresponding LED. When break-in is off, the active key LED flashes with a short off period. When break-in is on, the active key LED stays solid.

The buttons also have a secondary function that can be accessed by holding for three seconds, but only when that key is chosen. The active key LED blinks after about one second of holding as a warning that the three-second action is about to trigger. To access the secondary function, first short press the key button (if that key is not already chosen) and then long press.

| Action                                                      | Result                                                                               |
|-------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Short press <code>Key1</code> to <code>Key4</code>          | Select that key/input bank                                                           |
| Hold the currently selected <code>Key1</code> for 3 seconds | Toggle automatic key-based input switching                                           |
| Hold the currently selected <code>Key2</code> for 3 seconds | Toggle encoder-value display on the LEDs                                             |
| Hold the currently selected <code>Key3</code> for 3 seconds | Enter or leave radio-selection mode                                                  |
| Hold the currently selected <code>Key4</code> for 3 seconds | Display firmware version, then send callsign <code>M0MZB</code> on the LEDs in Morse |



## Auto Key Switching

This where the KeyMaster can make your collection of CW keys much more fun! You can have four completely different keys connected to your radio at the same time, and seamlessly switch between them.

With Auto Key Switching Enabled (see above section for instructions on how to do this), the KeyMaster detects which key is in use, and activates that key. A quick press of the left hand paddle (for dual paddles) or closed contact on a straight key is all that is needed for the KeyMaster to select you key.

When the KeyMaster detects a different key being used, relative to the one currently selected. It will firstly disengage all keys, then change the setting on the radio to those stored for the newly selected key (eg turning the Keyer ON/OFF, changing the WPM or changing break-in) and then reactivate the key connection to the radio.

With auto-keying you can

- Have several keys connected, and a different WPM set on each, allowing super quick changes of speed.
- Have a Bug, Paddle, Straight key and Cootie attached all at the same time, and rapidly switch between them
- Have a bug and paddle connected at the same time, use the paddle to sound a phrase, and then try to sound with the bug. This is a great way to practice bug sending, and get your bug fist as close to perfect as possible.

## WPM and Keyer Control (Encoder 1)

| Action        | Result                                |
|---------------|---------------------------------------|
| Turn WPM/Kyr  | Change CW speed for the active bank   |
| Press WPM/Kyr | Toggle keyer mode for the active bank |

When encoder-value display is enabled, changing WPM briefly shows the value on the band LEDs before the display returns to normal.

Keyer feedback on the band LEDs: when selecting Keyer ON/OFF the band LEDs provide visual feedback.



PUSH

Toggling the Keyer OFF  
Display shows a single line  
(ie a straight key)



PUSH

Toggling the Keyer ON  
Display shows a pair  
Of lines

(ie paddles)

## Volume and Breaking Control (Encoder 2)

| Action       | Result                                    |
|--------------|-------------------------------------------|
| Turn Vol/Bk  | Change the shared monitor/sidetone volume |
| Press Vol/Bk | Toggle break-in for the active bank       |

When encoder-value display is enabled, changing volume briefly shows the value on the LEDs before the display returns to normal.

Break-in feedback on the band LEDs: when selecting Keyer ON/OFF the band LEDs provide visual feedback. When break-in is off, the active key LED flashes with a short off period. When break-in is on, the active key LED stays solid

Settings are saved automatically, but not instantly. Leave the unit powered for at least 30 seconds after changing settings if you want to be certain the latest changes have been written.



Toggling the Break-In OF  
The Band LEDs show a brief  
animation.  
The selected Key LED will  
blink whenever Break-In is  
OFF




Toggling the Break-In ON  
The Band LEDs show the  
reverse animation.  
The selected Key LED is solid  
whenever Break-In is ON

## Adjusting Radio Communication Settings

### Selecting the radio

Each radio typically requires a unique set of commands, which have been pre-stored in the KeyMaster firmware. KeyMaster can support up to 255 distinct radios. The following steps allow selection of the radio type:

1. Short press **Key3** so bank 3 is the active bank.
2. Hold **Key3** for 3 seconds to enter radio-selection mode.
3. All band LEDs illuminate. The LED for the current radio flashes.
4. Press one of the band buttons below.
5. Hold **Key3** again for 3 seconds to leave radio-selection mode.



| Band button   | Radio driver               |
|---------------|----------------------------|
| 80 / button 1 | Yaesu FTDX10<br>Yaesu 991A |
| 60 / button 2 | QRP Labs QMX               |
| 40 / button 3 | Kenwood TS-590S            |
| 30 / button 4 | Kenwood TS-590SG           |
| 20 / button 5 | Yaesu FT-710               |
| 17 / button 6 | Kenwood TS890S             |

The radio choice is saved to EEPROM on the next scheduled settings write.

## Supported Radios

| Radio            | Default CAT rate | Implemented status/control                                                                      |
|------------------|------------------|-------------------------------------------------------------------------------------------------|
| Yaesu FTDX10     | 38400 baud       | Band, CW speed, keyer, monitor volume, break-in                                                 |
| Yaesu FT991A     |                  |                                                                                                 |
| Yaesu FT-710     | 38400 baud       | Band, CW speed, keyer, monitor volume, break-in                                                 |
| QRP Labs QMX     | 9600 baud        | Band and CW speed status; band, CW speed, keyer, monitor volume, and practice/break-in control  |
| Kenwood TS-590S  | 9600 baud        | Band, CW speed, keyer, and monitor status; band, CW speed, keyer, monitor, and break-in control |
| Kenwood TS-590SG | 9600 baud        | Band, CW speed, keyer, and monitor status; band, CW speed, keyer, monitor, and break-in control |
| Kenwood TS-890S  | 9600 baud        | Band, CW speed, keyer, monitor, and break-in status/control                                     |

Yaesu FT818, and Icom IC7300 support in future versions. Selecting an unsupported type falls back to the FTDX10 driver.

## Setting the CAT Baud rate

The baud rate is set while in radio-selection mode.

1. Short press `Key3` so bank 3 is the active bank.
2. Hold `Key3` for 3 seconds to enter radio-selection mode.
3. All key LEDs illuminate. The LED for the current baud rate flashes.
4. Press one of the key buttons, shown below, to choose the baud rate.
5. Hold `Key3` again for 3 seconds to leave radio-selection mode.

| Key button | CAT baud rate |
|------------|---------------|
| Key1       | 4800          |
| Key2       | 9600          |
| Key3       | 19200         |
| Key4       | 38400         |

## Special requirements for Kenwood TS-590S and TS-590SG

STRAIGHT KEY OR MECHANICAL BUG -> KEYMASTER INPUT

|                       |                         |
|-----------------------|-------------------------|
| Key or bug contact    |                         |
| o/ o                  |                         |
|                       |                         |
| +-----                | SLEEVE (common/GND)     |
|                       |                         |
| +-----                | RING (DAH / dash)       |
| TIP (DIT / dot) ----- | NO CONNECTION           |
|                       | Leave isolated/floating |

KEYMASTER OUTPUT -> TS-590 PADDLE

|                                 |                        |
|---------------------------------|------------------------|
| KeyMaster TIP (DIT) -----       | TS-590 TIP (DIT)       |
| KeyMaster RING (DAH) -----      | TS-590 RING (DAH)      |
| KeyMaster SLEEVE (common) ----- | TS-590 SLEEVE (common) |

This is a normal, fully wired TRS-to-TRS paddle cable.

The TS-590S and TS-590SG have separate rear-panel inputs: KEY is intended for a straight key or external keyer, while PADDLE feeds the radio's internal electronic keyer. KeyMaster must connect to the radio's PADDLE socket so it can route ordinary iambic paddles as well as straight keys and bugs.


The TS-590 is peculiar in that the hardware does not allow disabling the keyer when using the paddle socket. The TS-590 CAT command set cannot change the PADDLE socket into a true straight-key input. KeyMaster works around this radio limitation by using the TS-590 Bug key function.

Selecting Keyer “on” with the KeyMaster disables Bug mode on the TS-590 and gives normal electronic/iambic operation. Keyer “off” enables Bug mode as a means to permit use of straight keys and bugs. The KeyMaster makes use of the fact that during Bug mode, the dash contact behaves as a straight key. With Bug mode selected on the TS-590, the dit contact still generates automatic dots, while dah becomes manually timed and can behave like a straight-key input.

The only thing the user needs to be concerned with is that there is isolation of the dit contact at the individual straight-key or bug connection into KeyMaster. That is, a stereo cable must be used to connect your bug or straight key to the keymaster; the

dit contact (tip or the jack) of the stereo cable must be left floating (not connected) and the dah contact (the ring) is used to connect to your key. The GND contact (sleeve) is connected to your key as usual

An ordinary paddle connects to a KeyMaster input normally, with dit, dah, and common all wired. KeyMaster routes both paddle contacts through its multiplexer and the fully wired output cable to the TS-590 PADDLE socket. This is why the output cable must retain its tip/dit connection.



Do not use a mono TS plug for a straight key or bug at a KeyMaster input. Depending on the socket construction, it can short a paddle contact to common. Do not join tip and ring together: in Bug mode, grounding tip asks the radio's internal keyer to generate automatic dots.

This arrangement deliberately uses the TS-590 PADDLE socket rather than its separate KEY socket, allowing KeyMaster to select either a fully wired paddle or a dah-only straight key/bug without moving the radio plug. It remains an emulation imposed by the TS-590 hardware: keyer-off mode is technically Bug mode, not a true straight-key input mode, and CW message memory is unavailable while Bug mode is enabled.

The diagrams assume the radio's dot/dash reversal setting is OFF: tip is dit and ring is dah. If reversal is enabled, those physical roles exchange, so disable reversal when using this wiring.

## Encoder Direction Setting

The direction of each encoder can be reversed independently. The usual setting is for clockwise rotation to increase values, but this can be reversed if desired. The LED bar graph is unaffected by reversing the encoder direction.

| Encoder | How to reverse its direction           |
|---------|----------------------------------------|
| WPM/Kyr | Hold its push-button while powering on |
| Vol/Bk  | Hold its push-button while powering on |

Keep the button held throughout the startup LED chase. When the confirmation LEDs appear, release it. The outermost key/band LEDs mean that the selected encoder is now reversed; the innermost LEDs mean normal direction. Repeat the same procedure to toggle it back. Each direction setting is saved immediately and remains in effect after power-off.



## Default Settings

On blank or invalid EEPROM, KeyMaster starts on input 1 with automatic key switching enabled, encoder-value display disabled, shared monitor volume 20, and the FTDX10 driver selected.

| Bank | CW speed | Keyer | Break-in |
|------|----------|-------|----------|
| 1    | 25       | On    | Off      |
| 2    | 35       | On    | Off      |
| 3    | 25       | Off   | Off      |
| 4    | 35       | Off   | Off      |

## LED Messages Summary

| Display                                            | Meaning                                 |
|----------------------------------------------------|-----------------------------------------|
| One key LED solid                                  | Active key/input bank                   |
| Active key LED flashing                            | Break-in is off for the active bank     |
| One band LED solid                                 | Active band                             |
| All band LEDs on, one flashing                     | Radio-selection mode                    |
| Band LEDs show a temporary bar graph               | Encoder-value display for WPM or volume |
| Every other band LED and every key LED lit briefly | CAT command queue overflow warning      |
| Key LEDs flashing during a button hold             | Long-press warning                      |

The overflow warning means the firmware could not queue a CAT command at that moment. The unit continues running; if the radio is disconnected or not responding, KeyMaster should still operate as a standalone key/input controller.

## Rear Panel Connections



- A standard 5.5x2.1mm DC jack is used to provide power (user supplied)
- A standard DB9 serial cable is used to connect the 12V Serial to a radio. This connection is perfect for the Yaesu FTDX10 which has a DB9 connector on the rear. Just connect the radio and KeyMaster with a standard DB9 Serial cable
- 5V serial is provided, with a screw terminal plug supplied with the KeyMaster to allow easy make-up of your own cables to suit any radio. 5V Serial is also provided via a 3.5mm socket (Tip=Tx, Ring=Rx and Sleeve=GND). It is very easy to make your own cable with readily available 3.5mm plugs.
- The Key output is a 3.5mm socket that connects to the radio Key input

## Troubleshooting

| Symptom                                      | Things to check                                                                                      |
|----------------------------------------------|------------------------------------------------------------------------------------------------------|
| Radio does not respond to controls           | Confirm the selected radio type, CAT cable, radio CAT baud rate, and that the radio is powered       |
| KeyMaster works until the radio is unplugged | This should not happen in current firmware; if it does, note the LED pattern and selected radio type |
| Active key LED keeps flashing                | Break-in is off for that bank; press Vol/Bk to toggle it                                             |
| The wrong key bank is selected when keying   | Check whether automatic key-based input switching is enabled                                         |
| A long press does nothing                    | Make sure you are holding the currently selected key button, not an inactive bank button             |
| Latest setting was lost after power-off      | Leave the unit powered for 30 seconds after changing settings                                        |
| Uploading firmware fails                     | Disconnect or isolate the radio CAT interface while programming                                      |