# Tyrata Simulator User Manual



Author: Zike Qin Yinsi Zhang Zhizhou Zhang Yifan Li Haohong Zhao

# Contents

Contents	•
1. System Overview	2
2. Getting Started	2
System Requirements	2
Launching the Application	2
Initializing Tire Sensor Information	3
Saving/Importing Tire Sensor Information	2
Generating S11 Data	5
Sending the Generated Data to Mobile App via Bluetooth	5

## 1. System Overview

This desktop program serves as the data simulator & generator for Tyrata system. Specifically, the simulator & generator program consists of the following components:

- 1.1. Tire sensor information initialization & modification
- 1.2. Data generation & simulation configuration
- 1.3. Data file save & import
- 1.4. Data Transmission via Bluetooth

### 2. Getting Started

#### **System Requirements**

Windows 10 PC (with Bluetooth support)

#### **Launching the Application**

To launch the application, double click .exe. The main user interface of the launched application is shown in Figure.4




Figure. 4. Main interface

#### **Initializing Tire Sensor Information**

To generate tire sensor information,

- 1. Click "Tire Config" on Menu bar and then click "Generate Tires", as shown in Figure.5.
- 2. Enter the number of tire sensors and click "OK", as shown in Figure.6.




Figure.5. TireConfig menu

Figure.6. Enter the number of tires

After quick generation of tire sensor information, you can view the current generated tire sensor information on the lower left section of the main user interface shown in Figure.4.

To add a new tire sensor, delete a generated tire sensor, or edit the information about a tire sensor,

- Click "New" button to add a new tire sensor. Enter the specific sensor information in the new "New Tire" window popped up, as shown in Figure.7.
- Click "Edit" button to modify the information about a current tire sensor in the "Edit Tire" window popped up, as shown in Figure.8.
- Click "Delete" button to delete the selected tire sensor information record.




Figure. 7. New Tire

Figure. 8. Edit Tire

To clear all tire sensor information records, click "TireConfig" button on the menu bar and select "Clear All Tires", as shown in Figure. 5.

#### **Saving/Importing Tire Sensor Information**

To save the current tire sensor information records for later use,

• Click "Tire Config" on menu bar and then click "Save" or "Save As", as shown in Figure. 5.

To import a local tire sensor information XML file,

• Click "Tire Config" on menu bar and then click "Import", as shown in Figure. 5.

#### **Generating S11 Data**

To generate s11 data points,

- Fill out all the fields on the upper right section of the main user interface, as shown in Figure.9. The units of Time Span, Daily Mileage, and Outlier Interval are days, miles, and days, respectively.
- If needed, check the "Outlier Enable" checkbox and enter the expected outlier generation frequency/period in "Outlier Interval" field.
- Click "Generate" button to generate specified S11 data.
- Click "Show" button to show the generated S11 data, as shown in Figure. 10.
- Click "Save" button to save the generated S11 data into a local XML file.




Figure. 9. Data Generator




Figure. 10. Show Generated Data

#### Sending the Generated Data to Mobile App via Bluetooth

To send the Generated Data to Mobile App:

- Click on the broadcast button, a dialogue box will prompt, letting you choose the XML file you want to transmit via Bluetooth as shown in Figure.11
- After you have chosen the file you want to transmit, the white screen at the right-bottom corner will show the status of the bluetooth connection (Figure.12)

 Before you start next bluetooth connection, you should first cancel or close the currently running bluetooth connection by clicking on the "Cancel" button as shown in Figure. 13




Figure. 11. Chosing file via Broadcast button

Figure. 12. Bluetooth Status Notification




Figure. 13. Cacnel Bluetooth Connection