

# Planning IoT wireless links

Marco Zennaro  
T/ICT4D Laboratory  
ICTP-Italy




# Goals

- ▶ To be able to calculate how far we can go with the equipment we have
- ▶ To understand why we need high masts for long links
- ▶ To learn about software that help the process of planning radio links



# Power in a wireless system




# Free Space Loss (any frequency)

- ▶ Using decibels to express the loss and using a generic frequency  $f$ , the equation for the Free Space Loss is:

$$L_{fs} = 32,45 + 20 \log(D) + 20 \log(f)$$

- ▶ ...where  $L_{fs}$  is expressed in dB,  $D$  is in kilometers and  $f$  is in MHz.



# Link budget

- ▶ The performance of any communication link depends on the quality of the equipment being used.
- ▶ **Link budget** is a way of quantifying the link performance.
- ▶ The received power in an radio link is determined by three factors: **transmit power**, **transmitting antenna gain**, and **receiving antenna gain**.
- ▶ If that power, minus the **free space loss** of the link path, is greater than the **minimum received signal level** of the receiving radio, then a link is possible.
- ▶ The difference between the minimum received signal level and the actual received power is called the **link margin**.
- ▶ The link margin must be positive, and should be maximized (should be at least 10dB or more for reliable links).

## 12.2 Specifications

Table 8 – WiFi specifications

Description	Min	Typ.	Max	Unit
Input Frequency	2412	–	2484	MHz
Tx power Output power of PA for 72.2 Mbps	13	14	15	dBm
Output power of PA for 11b mode	19.5	20	20.5	dBm
Sensitivity				
DSSS, 1Mbps	–	–	98	dBm
CCK, 11 Mbps	–	–	91	dBm
OFDM, 6 Mbps	–	–	93	dBm
OFDM, 54 Mbps	–	–	75	dBm
HT20, MCS0	–	–	93	dBm
HT20, MCS7	–	–	73	dBm
HT40, MCS0	–	–	90	dBm
HT40, MCS7	–	–	70	dBm
MCS32	–	–	89	dBm

# Example link budget calculation


Let's estimate the feasibility of a **5 km** link, with two radios that we will call Radio 1 and Radio 2.

Radio 1 is connected to an antenna with **10 dBi** gain, with a transmitting power of **20 dBm** and a receive sensitivity of **-89 dBm**.

Radio 2 is connected to an antenna with **14 dBi** gain, with a transmitting power of **15 dBm** and a receive sensitivity of **-82 dBm**.

The cables in both systems are short, with a loss of **2dB** at each side at the 2.4 GHz frequency of operation.

# Radio 1 to Radio 2 link



# Link budget: Radio 1 to Radio 2

20 dBm	(TX Power Radio 1)
+ 10 dBi	(Antenna Gain Radio 1)
- 2 dB	(Cable Losses Radio 1)
+ 14 dBi	(Antenna Gain Radio 2)
- 2 dB	(Cable Losses Radio 2)

---

40 dB	Total Gain
-114 dB	(free space loss @5 km)


---

-73 dBm	(expected received signal level)
--82 dBm	(sensitivity of Radio 2)

---

9 dB (link margin)

# Opposite direction: Radio 2 to Radio 1



# Link budget: Radio 2 to Radio 1

15 dBm	(TX Power Radio 2)
+ 14 dBi	(Antenna Gain Radio 2)
- 2 dB	(Cable Losses Radio 2)
+ 10 dBi	(Antenna Gain Radio 1)
- 2 dB	(Cable Losses Radio 1)

---

35 dB	Total Gain
-114 dB	(free space loss @5 km)

---

-78 dBm	(expected received signal level)
--89 dBm	(sensitivity of Radio 1)


---

10 dB (link margin)

# Fresnel Zone

- ▶ The First Fresnel Zone is an ellipsoid-shaped volume around the Line-of-Sight path between transmitter and receiver.
- ▶ The Fresnel Zone is important to the integrity of the RF link because it defines a volume around the LOS that must be clear of any obstacle for the maximum power to reach the receiving antenna.
- ▶ Objects in the Fresnel Zone as trees, hilltops and buildings can considerably attenuate the received signal, even when there is an unobstructed line between the TX and RX.

# Line of Sight and Fresnel Zones



a free line-of-sight **IS NOT EQUAL TO** a free Fresnel Zone


# Fresnel Zone

- ▶ The radius of the first Fresnel Zone at a given point between the transmitter and the receiver can be calculated as:

$$r = 17.31 * \sqrt{((d1*d2) / (f*d))}$$

- ▶ ...where **r** is the radius of the zone in meters, **d1** and **d2** are distances from the obstacle to the link end points in meters, **d** is the total link distance in meters, and **f** is the frequency in MHz.
- ▶ Note that this gives you the radius of the zone, not the height above ground. To calculate the height above ground, you need to subtract the result from a line drawn directly between the tops of the two towers.

# Line of Sight and Fresnel Zones



$$r = 17.31 * \sqrt{((d_1 * d_2) / (f * d))}$$

# Clearance of the Fresnel Zone and earth curvature

This table shows the minimum height above flat ground required to clear 70% of the first Fresnel zone for various link distances at 2.4 GHz.

Notice that earth curvature plays a small role at short distances, but becomes more important as the distance increases.

Distance (km)	1st zone (m)	70% (m)	Earth curvature (m)	Required height (m)
1	5.5	3.9	0.0	3.9
5	12.4	8.7	0.4	9.1
10	17.5	12.2	1.5	13.7
15	21.4	15.0	3.3	18.3
20	24.7	17.3	5.9	23.2
25	27.7	19.4	9.2	28.6
30	30.3	21.2	18	34.5

# Fresnel Zone

- ▶ Considering the importance of the Fresnel Zone, it is important to quantify the degree to which it can be blocked.
- ▶ Typically, 20% - 40% Fresnel Zone blockage introduces little to no interference into the link.
- ▶ It is better to err to the conservative side allowing no more than 20% blockage of the Fresnel Zone.


# Radio Mobile

- ▶ Radio Mobile is a free tool to aid in the design and simulation of wireless systems.
- ▶ It can automatically calculate the power budget of a radio link, calculating the Fresnel zone clearance. It can use digital maps, GIS (Geographical Information Systems), or any other digital map, including maps provided by yourself.
- ▶ Runs on Windows 95, 98, ME, NT, 2000 and XP.


*<http://www.cplus.org/rmw/english1.html>*

# Radio Mobile

- ▶ Uses Digital terrain Elevation Model for the calculation of coverage, indicating received signal strength at various point along the path.
- ▶ Radio Mobile automatically builds a profile between two points in the digital map showing the coverage area and 1st Fresnel zone.
- ▶ Different antenna heights can be tried to achieve optimum performance.



# Radio Mobile



# Telegram Bot: BotRf


- ▶ Telegram is an instant messaging service. Telegram clients exist for both mobile (Android, iOS, Windows Phone, Ubuntu Touch) and desktop systems (Windows, OS X, Linux). Users can send messages and exchange photos, videos, stickers and files of any type. Telegram also provides optional end-to-end encrypted messaging.

<https://telegram.org/>





# Telegram Bot: BotRf

- ▶ Telegram Bots are special accounts that do not require an additional phone number to set up. These accounts serve as an interface for code running somewhere on your server.



# Telegram Bot: BotRf

- ▶ Start by installing Telegram on your smartphone (works on iOS, Android and Microsoft) or PC.
- ▶ Choose **BotRf** as a contact




# Telegram Bot: BotRf

- ▶ There are three main commands:
- ▶ **Freq**: to change the frequency
- ▶ **Site**: to insert information about the sites (you need at least two sites for a link!)
- ▶ **Calc**: to check if the sites are in line of sight
- ▶ **HIp** will give you a help about all the commands.


# Telegram Bot: BotRf

- ▶ Let's start by setting the frequency to 5.8 Ghz



# Telegram Bot: BotRf

- ▶ Now let's create one site called `mountain_1`, with latitude -4.3409, longitude 55.7450 and antenna height 5 meters above the ground




Message



# Telegram Bot: BotRf

- ▶ You can find positions of sites using a GPS or by using this site:
- ▶ <http://itouchmap.com/latlong.html>



**Get the Latitude and Longitude of a Point**

When you click on the map, move the marker or enter an address the latitude and longitude coordinates of the point are inserted in the boxes below.

Latitude:   
Longitude:


**Show Point from Latitude and Longitude**

Use this if you know the latitude and longitude coordinates of a point and want to see where on the map the point is.  
Use: + for N Lat or E Long - for S Lat or W Long.  
Example: +40.689060 -74.044636  
Note: Your entry should not have any embedded spaces.


Decimal Deg. Latitude:   
Decimal Deg. Longitude:

# Telegram Bot: BotRf

- ▶ If you are using your smartphone, you can use it to get the position of the site



# Telegram Bot: BotRf



**Send your current location**

Accurate to 20 meters

OR CHOOSE A PLACE



**ICTP Galileo Guest House**

Via Beirut 7



**enrico fermi building**

Italy




**ICTP Leonardo Building**




# Telegram Bot: BotRf

- Once you have two sites (let's say they are called `mountain_1` and `mountain_2`), you can check the profile between them with **Calc**



# Telegram Bot: BotRf



Sent results 3:05 PM

Free space path loss: 104.99 dB

# Telegram Bot: BotRf

- ▶ **Excercise**
- ▶ Can you deploy an IoT link from IMSP to Cotonou at 868 MHz?
- ▶ How far are they?
- ▶ How high do you have to raise the antennas?
  
- ▶ Calculate the link budget using Pycom LoPy devices