

Introduction to Robotics CSE 461

Chapter 2: Lecture 6 (Forward Kinematics)

Niloy Irtisam Lecturer, Dept. of Computer Science and Engineering BRAC University

Last Class


Kinematics

Degrees of Freedom (DOF)

D-H Parameters

Recall D-H Parameters


D-H Parameters




 d_i : distance from origin of (i-1) coordinate to intersection of Z_{i-1} & X_i along Z_{i-1}


 θ_i : rotation angle from X_{i-1} to X_i about Z_{i-1}

Position





Rotation




Z-axis:
$$\begin{bmatrix} p'_x \\ p'_y \\ p'_z \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \bullet \begin{bmatrix} p_x \\ p_y \\ p_z \end{bmatrix}$$

X-axis:
$$\begin{bmatrix} p'_x \\ p'_y \\ p'_z \end{bmatrix} = \begin{bmatrix} 1 & 0 & 0 \\ 0 & \cos\theta & -\sin\theta \\ 0 & \sin\theta & \cos\theta \end{bmatrix} \bullet \begin{bmatrix} p_x \\ p_y \\ p_z \end{bmatrix}$$

Y-axis:
$$\begin{bmatrix} p'_x \\ p'_y \\ p'_z \end{bmatrix} = \begin{bmatrix} \cos\theta & 0 & \sin\theta \\ 0 & 1 & 0 \\ -\sin\theta & 0 & \cos\theta \end{bmatrix} \bullet \begin{bmatrix} p_x \\ p_y \\ p_z \end{bmatrix}$$

Rotation



$$x_2 = |OL| = |OP| - |LP|$$

$$y_2 = |LA| = |LN| + |NA|$$

$$|OP| = |OM| \cos \alpha$$

$$= x_1 \cos \alpha$$

$$|LN| = |PM| = |OM| \sin \alpha$$

$$= x_1 \sin \alpha$$

$$|LP| = |NM| = |MA| \sin \alpha$$

$$= y_1 \sin \alpha$$

$$|NA| = |MA| \cos \alpha$$

$$= y_1 \cos \alpha$$

Combining these eqns., we get

$$x_2 = x_1 \cos \alpha - y_1 \sin \alpha$$

$$y_2 = x_1 \sin \alpha + y_1 \cos \alpha$$

Homogeneous Transformation Matrix

Homogeneous Transformation Matrices are commonly used to represent linkages (for robot arm) in a systematic way for representing *Position Vector* and *Rotation* Matrices {4X4 Matrix}.

$$T = \begin{bmatrix} R_{3x3} & | & P_{3x1} \\ -- & | & -- \\ f_{1x3} & | & 1x1 \end{bmatrix} = \begin{bmatrix} Rotation & Position \\ Matrix & Matrix \\ ----- & Perspective \\ Transformation & Scaling \end{bmatrix}$$


Denavit-Hartenberg (D-H) Homogeneous Transformation matrices

$$A_i = R_{z,\theta_i} \mathrm{Trans}_{z,d_i} \mathrm{Trans}_{x,a_i} R_{x,\alpha_i}$$

$$= \begin{bmatrix} c_{\theta_i} & -s_{\theta_i} & 0 & 0 \\ s_{\theta_i} & c_{\theta_i} & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & d_i \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} 1 & 0 & 0 & a_i \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & c_{\alpha_i} & -s_{\alpha_i} & 0 \\ 0 & s_{\alpha_i} & c_{\alpha_i} & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$= \begin{bmatrix} c_{\theta_i} & -s_{\theta_i} c_{\alpha_i} & s_{\theta_i} s_{\alpha_i} & a_i c_{\theta_i} \\ s_{\theta_i} & c_{\theta_i} c_{\alpha_i} & -c_{\theta_i} s_{\alpha_i} & a_i s_{\theta_i} \\ 0 & s_{\alpha_i} & c_{\alpha_i} & d_i \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

D-H Parameters



 d_i : distance from origin of (i-1) coordinate to intersection of Z_{i-1} & X_i along Z_{i-1}

 θ_i : rotation angle from X_{i-1} to X_i about Z_{i-1}

Transformation Matrices

Joint i	α_i	a_i	d_i	Θ_i
1	0	a_0	0	θ_1
2	-90	a_1	0	Θ_2
3	0	0	d_2	θ3

$$T_{i-1}^{i} = \begin{bmatrix} C\theta_{i} & -C\alpha_{i}S\theta_{i} & S\alpha_{i}S\theta_{i} & a_{i}C\theta_{i} \\ S\theta_{i} & C\alpha_{i}C\theta_{i} & -S\alpha_{i}C\theta_{i} & a_{i}S\theta_{i} \\ 0 & S\alpha_{i} & C\alpha_{i} & d_{i} \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$T_{2}^{2} = \begin{bmatrix} \cos\theta_{2} & 0 & -\sin\theta_{2} & a_{1}\cos\theta_{2} \\ \sin\theta_{2} & 0 & \cos\theta_{2} & a_{1}\sin\theta_{2} \\ 0 & -1 & 0 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$T_{3}^{3} = (T_{0}^{1})(T_{1}^{2})(T_{2}^{3})$$

$$T_{2}^{3} = \begin{bmatrix} \cos\theta_{3} & -\sin\theta_{3} & 0 & 0 \\ \sin\theta_{3} & \cos\theta_{3} & 0 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$T_0^3 = (T_0^1)(T_1^2)(T_2^3)$$

$$T_{0}^{1} = \begin{bmatrix} \cos\theta_{1} & -\sin\theta_{1} & 0 & a_{0}\cos\theta_{1} \\ \sin\theta_{1} & \cos\theta_{1} & 0 & a_{0}\sin\theta_{1} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$


$$T_1^2 = \begin{bmatrix} \cos\theta_2 & 0 & -\sin\theta_2 & a_1\cos\theta_2 \\ \sin\theta_2 & 0 & \cos\theta_2 & a_1\sin\theta_2 \\ 0 & -1 & 0 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$T_{2}^{3} = \begin{bmatrix} \cos\theta_{3} & -\sin\theta_{3} & \mathbf{0} & 0\\ \sin\theta_{3} & \cos\theta_{3} & 0 & 0\\ 0 & 0 & 1 & d_{2}\\ \mathbf{0} & \mathbf{0} & \mathbf{0} & \mathbf{1} \end{bmatrix}$$

Forward Kinematics

TABLE 2.1. D-H Parameters of a 3-DOF Manipulator

Joint i	α_i	a_i	d_i	θ_{i}
1	0	a_1	0	θ_1
2	0	a_2	0	θ_2
3	0	a_3	0	θ_3



$${}^{0}A_{1} = \begin{bmatrix} c\theta_{1} & -s\theta_{1} & 0 & a_{1}c\theta_{1} \\ s\theta_{1} & c\theta_{1} & 0 & a_{1}s\theta_{1} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$


$${}^{1}A_{2} = \begin{bmatrix} c\theta_{2} & -s\theta_{2} & 0 & a_{2}c\theta_{2} \\ s\theta_{2} & c\theta_{2} & 0 & a_{2}s\theta_{2} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix},$$


$${}^{2}A_{3} = \begin{bmatrix} c\theta_{3} & -s\theta_{3} & 0 & a_{3}c\theta_{3} \\ s\theta_{3} & c\theta_{3} & 0 & a_{3}s\theta_{3} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}.$$

Overall transformation matrix?


$${}^{0}\!A_{3} = \begin{bmatrix} c\theta_{123} & -s\theta_{123} & 0 & a_{1}c\theta_{1} + a_{2}c\theta_{12} + a_{3}c\theta_{123} \\ s\theta_{123} & c\theta_{123} & 0 & a_{1}s\theta_{1} + a_{2}s\theta_{12} + a_{3}s\theta_{123} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}.$$

Overall transformation matrix?






- 1. Define z axis
- 2. Define x,y using R.H rule



- 1. Define z axis
- 2. Define x,y using R.H rule
- 3. Calculate D-H parameters


TABLE 2.1. D-H Parameters of a 3-DOF Manipulator				
Joint i	α_i	a_i	di	θ_i
1	0	a_1	0	θ_1
2	0	a_2	0	θ_2




- 1. Define z axis
- 2. Define x,y using R.H rule
- 3. Calculate D-H parameters
- 4. Put the parameters to the homogeneous transformation matrices

TABLE 2.1. D-H Parameters of a 3-DOF Manipulator

Joint i	α_i	a_i	d_i	θ_i
1	0	a_1	0	θ_1
2	0	a_2	0	θ_2





Joint i	α_i	a_i	d_i	θ_i
1	0	a_1	0	θ_1
	•		0	θ_2


TABLE 2.1. D-H Parameters of a 3-DOF Manipulator

1. Define z axis

 $\begin{bmatrix} c_{\theta_i} & -s_{\theta_i} c_{\alpha_i} & s_{\theta_i} s_{\alpha_i} & a_i c_{\theta_i} \\ s_{\theta_i} & c_{\theta_i} c_{\alpha_i} & -c_{\theta_i} s_{\alpha_i} & a_i s_{\theta_i} \\ 0 & s_{\alpha_i} & c_{\alpha_i} & d_i \\ 0 & 0 & 0 & 1 \end{bmatrix}$

- 2. Define x,y using R.H rule
- 3. Calculate D-H parameters
- 4. Put the parameters to the homogeneous transformation matrices
- 5. Multiply for each joints

$$T_0^3 = (T_0^1)(T_1^2)(T_2^3)$$




Forward Kinematics

Initial position vector:
$${}^{3}\mathbf{q} = [0, 0, 0, 1]^{T}$$

Final position vector?

$$\begin{bmatrix} q_x \\ q_y \\ q_z \\ 1 \end{bmatrix} = {}^{0}A_{3} \begin{bmatrix} 0 \\ 0 \\ 0 \\ 1 \end{bmatrix} = \begin{bmatrix} a_{1}c\theta_{1} + a_{2}c\theta_{12} + a_{3}c\theta_{123} \\ a_{1}s\theta_{1} + a_{2}s\theta_{12} + a_{3}s\theta_{123} \\ 0 \\ 1 \end{bmatrix}$$

Assignment: Calculate position of end effector of this 3 DOF Manipulator



Angles of three joints are 30 degree, 45 degree and 10 degree.

$$a_1 = 10$$

$$a_2 = 8$$

$$a_3 = 3$$

Next class

Inverse Kinematics

Thanks